

Introduction



GTE OMNI SBCS

The OMNI SBCS Installation and Maintenance Student Workbook Manual is a reference source to aid you in understanding and performing OMNI SBCS installation and maintenance procedures.

This workbook is designed to provide the student with basic installation and maintenance information in a logical and easy to understand format. The content of the workbook was taken from the OMNI SBCS GTEP Manual and other reference sources. This workbook is divided into the following major sections:

- System Installation
- System Data Base
- System Maintenance
- Package B/SVR 1.5.X.X Enhancements
- Package C/SVR 2.0.X.X Enhancements

Classroom laboratory activities and review exercises are included in the workbook to provide reinforcement for all subject areas stressed.

Student Performance Report



GTE OMNI SBCS

Name: SAMPLE

Course: GTE OMI SBCS I & M

Dates: 01-06-86 to 01-17-86

OBJECTIVES

ACTUAL PERFORMANCE

In Classroom		On Equipment		NOT MEASURED
OBJECTIVE MET	NOT MET	OBJECTIVE MET	NOT MET	

ENABLING OBJECTIVE 1.1

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PERIPHERALS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- REVIEW EXERCISE

ACTION:

- IDENTIFY AND DESCRIBE GTE OMNI SBCS SYSTEM ARCHITECTURE AND INTERFACES

CRITERIA:

- REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION

<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
-------------------------------------	--------------------------	--------------------------	--------------------------	--------------------------

Student Performance Report



GTE OMNI SBCS

Name: SAMPLE

Course: GTE OMNI SBCS I & M

Dates: 01-06-86 to 01-17-86

OBJECTIVES

ACTUAL PERFORMANCE

In Classroom		On Equipment		NOT MEASURED
OBJECTIVE MET	NOT MET	OBJECTIVE MET	NOT MET	

TERMINAL OBJECTIVE 1.0

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PERIPHERALS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- ASSORTED GAUGE WIRE, REQUIRED CABLES, AND HARDWARE
- STANDARD INSTALLATION TOOLS
- TEST EQUIPMENT
- WRITTEN TEST

ACTION:

- INSTALL, INITIALIZE, AND VERIFY OPERATION OF THE GTE OMNI SBCS AND ASSOCIATED PERIPHERALS
- COMPLETE WRITTEN TEST

CRITERIA:

- SYSTEM WILL BE INSTALLED, INITIALIZED AND OPERATIONAL IN ACCORDANCE WITH GTE OMNI SBCS GTEP MANUAL
- WRITTEN TEST WILL BE COMPLETED IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION

<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Installation and Maintenance Course Outline



GTE OMNI SBCS

- **MODULE I — SYSTEM INSTALLATION**
 - System Overview
 - Cabinet Installation
 - Peripheral Installation
 - Start-up and Initialization
- **MODULE II — SYSTEM DATA BASE ADMINISTRATION**
 - Data Base Overview
 - Data Base Modification
 - Implementation Forms Package
- **MODULE III — SYSTEM MAINTENANCE**
 - Maintenance Overview
 - Maintenance Data Base Commands
 - Troubleshooting
 - Diagnostics
- **MODULE IV — PACKAGE B/SVR 1.5.X.X ENHANCEMENTS**
 - Package B Overview
 - Installation (Package B)
 - Data Base Administration (Package B)
 - Maintenance (Package B)
- **MODULE V — PACKAGE C/SVR 2.0.X.X ENHANCEMENTS**
 - Package C Overview
 - Installation (Package C)
 - Data Base Administration (Package C)
 - Maintenance (Package C)



GTE OMNI SBCS

MODULE I

SYSTEM INSTALLATION



Table of Contents/System Installation

GTE OMNI SBCS

	Page
INTRODUCTION	
SYSTEM OVERVIEW (OBJECTIVES)	1.3
SYSTEM WITH INTERFACES	1.4
SYSTEM APPLICATIONS	1.5
EQUIPMENT CABINET	1.6
• MAJOR HARDWARE COMPONENTS	1.7
• MAJOR SOFTWARE COMPONENTS	1.8
• MINIMUM SYSTEM CONFIGURATION	1.9
• MAXIMUM SYSTEM CONFIGURATION	1.10
• TRUNK/STATION LINE COMBINATIONS	1.11
• FRAME IMAGE FOR THE SBCS SYSTEM	1.12
• CPM CARD	1.13
• MEM CARD	1.14
• SWC CARD	1.15
• LINE CARDS: 8EKC AND 8SLC	1.16
• 8DTC CARD	1.17
• TRUNK CARDS: 4BWC, 2TTL, AND 2TTE	1.18
• DUAL TONE MULTI-FREQUENCY RECEIVER CARD - 4DMR	1.19
• OPTIONAL RGEN CARD	1.20
• OPTIONAL POWER FAIL TRANSFER CARD - 6PFT	1.21
• MAXIMUM NUMBER OF CARDS	1.22
PERIPHERALS	
• CS-10 ELECTRONIC KEY TELEPHONE	1.23
• CS-20 ELECTRONIC KEY TELEPHONE	1.24
• BUSY LAMP FIELD / DIRECT STATION SELECTION MODULE	1.25
• CSD DIGITAL TELEPHONE	1.26
• PORTABLE MAINTENANCE PANEL	1.27
• OPTIONAL FLOPPY DISKETTE DRIVE	1.28
• STATION MESSAGE DETAIL RECORDING PRINTER	1.29
• NIGHT BELL	1.30
• MUSIC-ON-HOLD	1.31
OMNI SBCS CONFIGURATION	1.32
REVIEW EXERCISE (1.1)	1.34

Table of Contents/System Installation (Continued)



GTE OMNI SBCS

INSTALLATION	Page
CABINET INSTALLATION (OBJECTIVES)	1.39
• INSTALLATION SEQUENCE	1.40
• MOUNTING BRACKET	1.41
• MOUNTING PROCEDURE	1.42
• CABINET - POWER SUPPLY CABLE	1.43
• GROUND WIRE TERMINALS	1.44
• CARD PLACEMENT PROCEDURE	1.45
• LABORATORY ACTIVITY (1.2)	1.46
• REVIEW EXERCISE (1.2)	1.48
PERIPHERAL INSTALLATION (OBJECTIVES)	1.51
• AMP CONNECTOR NUMBER RECEPTACLES	1.52
• RELATIONSHIP OF CARD SLOTS AND CIRCUITS TO CABLES AND AMP CONNECTOR PINS	1.53
• CS-10, CS-20, BLF/DSS INSTALLATION	1.54
• SINGLE LINE TELEPHONE INSTALLATION	1.55
• CSD TELEPHONE INSTALLATION	1.56
• CO TRUNK INSTALLATION	1.57
• LOOP TIE TRUNK INSTALLATION	1.58
• E&M TIE TRUNK (TYPE I) INSTALLATION	1.59
• E&M TIE TRUNK (TYPE II) INSTALLATION	1.60
• CDF CROSS CONNECT REFERENCE CHARTS	1.61
• OPTIONAL POWER FAIL TRANSFER INSTALLATION	1.65
• PORTABLE MAINTENANCE PANEL INSTALLATION	1.66
• OPTIONAL FLOPPY DISKETTE DRIVE INSTALLATION	1.67
• OPTIONAL SMDR PRINTER INSTALLATION	1.68
• OPTIONAL NIGHT BELL INSTALLATION	1.69
• OPTIONAL MUSIC-ON-HOLD INSTALLATION	1.70
• LABORATORY ACTIVITY (1.3)	1.72
• REVIEW EXERCISE (1.3)	1.78
START UP AND INITIALIZATION (OBJECTIVES)	1.87
• CPM CONTROLS AND INDICATORS	1.88
• SYSTEM INITIALIZATION	1.89
• OPERATIONAL CHECKS	1.90
• LABORATORY ACTIVITY (1.4)	1.92
• REVIEW EXERCISE (1.4)	1.94

1.0 Terminal Objective/ System Installation



GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - ASSORTED GAUGE WIRE, REQUIRED CABLES, AND HARDWARE
 - STANDARD INSTALLATION TOOLS
 - TEST EQUIPMENT
 - WRITTEN TEST
- ACTION:**
- INSTALL, INITIALIZE, AND VERIFY OPERATION OF THE GTE OMNI SBCS AND ASSOCIATED PERIPHERALS.
 - COMPLETE WRITTEN TEST.
- CRITERIA:**
- SYSTEM WILL BE INSTALLED, INITIALIZED, AND OPERATIONAL IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL.
 - WRITTEN TEST WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

SYSTEM INSTALLATION

Introduction

1.1 Enabling Objective/ System Overview




GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - REVIEW EXERCISE
- ACTION:**
- IDENTIFY AND DESCRIBE GTE OMNI SBCS SYSTEM ARCHITECTURE AND INTERFACES.
- CRITERIA:**
- REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



System With Interfaces

GTE OMNI SBCS





System Applications

GTE OMNI SBCS

- KEY TELEPHONE SYSTEM WITH INTERCOM** NO COMMON HOLD FOR A OR B - PKG ONLY EXCLUSIVE C PKG & ABOVE COMMON HOLD
- PABX (PRIVATE AUTOMATIC BRANCH EXCHANGE) C-PKG TATT CONSOLE
- CIRCUIT SWITCHED DATA COMMUNICATIONS* INTERNAL DATA ONLY 30 CSD's WITH CSD + DIV INST. STA FOR SYSTEM
- SATELLITE TO A PABX TRUNK INTERFACE
- SPECIALIZED HOTEL/HEALTH CARE**

*Package B/Phase 1.5 availability


**Package C/Phase 2.0 availability

Equipment Cabinet



GTE OMNI SBCS

- SINGLE CABINET
- 34" x 14.6" x 16"
- WEIGHT — 121 LBS.
- WALL MOUNTED
- CUTOUTS AND LOUVERS FOR COOLING




Major Hardware Components



GTE OMNI SBCS

- **POWER SUPPLY** *SOLID AMP FUSE INSIDE*
 - 110 VAC INPUT
 - SEALED UNIT
- **BATTERY** *3 BATTERIES (5 YR LIFESPAN)*
 - BACKS UP SYSTEM MEMORY
 - TWO WEEK MEMORY RETENTION
- **CABINET/POWER SUPPLY CABLE**
- **CABINET**
 - HOUSES SYSTEM PRINTED CIRCUIT BOARDS
 - PROVIDES INTERFACE TO AMPHENOL CONNECTORS





Major Software Components

GTE OMNI SBCS

- OPERATING SYSTEM
 - RESIDENT IN SYSTEM MEMORY (EPROM) - ^{ROM} CHIP - D-PKG 1.2 MEBYTES
 - CONTAINS AND MONITORS ALL ADMINISTRATIVE, CALL PROCESSING, MAINTENANCE AND SMDR PROGRAMS
- DEFAULT STANDARD DATA BASE - EVERYTHING WIRED IN AND INSTALLED
 - RESIDENT IN SYSTEM MEMORY (ROM)
 - CONTAINS ALL SYSTEM FEATURE AND SERVICE PARAMETERS
 - DATA BASE CONTENTS ARE SITE DEPENDENT AND PROGRAMMABLE




Minimum System Configuration

GTE OMNI SBCS

EVERY SYSTEM HAS TO HAVE THESE COMPONENTS

- POWER SUPPLY
- CABINET
- BATTERY
- CABINET AND POWER SUPPLY CABLE
- CPM CARD - CPU
- SWC CARD - SWITCH MATRIX CONTROL
- MEM CARD - MEMORY




Maximum System Configuration



GTE OMNI SBCS

- POWER SUPPLY
- CABINET
- BATTERY
- CABINET AND POWER SUPPLY CABLE
- CPM CARD
- SWC CARD
- MEM CARD
- RGEN CARD - RING GEN
- 6PFT CARD - POWER FAIL X-FER
- 4DMR CARD - DTMF RCVR
- 120 STATIONS/40 TRUNKS*



*THIS MAXIMUM CONFIGURATION CANNOT BE REACHED SIMULTANEOUSLY.

Trunk-Station Line Combinations



GTE OMNI SBCS

common configuration

C.O. TRUNKS	0	4	8	12	16	20	24	28	32	36	40	40	40	40	40	40	40	40	40	
STATION LINES	120	120	120	120	120	112	104	96	88	80	72	64	56	48	40	32	24	16	8	0

- STATION AND TRUNK MAXIMUMS CANNOT BE REACHED SIMULTANEOUSLY DUE TO CAPACITY OF UNIVERSAL CARD SLOTS.
- CHART ASSUMES THAT ONLY ELECTRONIC SETS WITH NO BLF/DSS INSTRUMENTS HAVE BEEN INSTALLED.
- CHART ASSUMES THAT ALL TRUNKS USE 4BWC CARDS.

(CARD SLOTS CAPACITY)

CARD	CARD SLOT NUMBER																						
	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
8SLC																							
8EKC																							
4DMR1																							
4BWC2																							
2TTL3																							
2TTE3																							

*ANY SLOT 0-14
DTX CARD*


*00-05 STATION ONLY
15-18 TRUNKS ONLY
06-14 LINE OR TRUNK CARD
19-22 COMMON CONTROL CARDS
22 PER*

- 1 2 MAXIMUMS
- 2 10 MAXIMUMS
- 3 COMBINED MAXIMUMS OF 6

Frame Image



GTE OMNI SBCS




- CARD SLOTS 00 THROUGH 05 CAN CONTAIN ONLY LINE CARDS.
- CARD SLOTS 15 THROUGH 18 CAN CONTAIN ONLY TRUNK CARDS.
- CARD SLOTS 06 THROUGH 14 CAN CONTAIN ANY TYPE OF CARD.
- CARD SLOTS 19, 20, AND 21 ARE RESERVED FOR COMMON CONTROL CARDS: SWC, CPM, AND MEM.
- CARD SLOT 22 IS RESERVED FOR 6PFT CARD.

CPM Card (Central Processing Unit and Basic Memory Card)



GTE OMNI SBCS




- 16 BIT MICROPROCESSOR (INTEL 8086 COMPATIBLE)
- TWO RS-232-C PORTS:
 - PMP
 - SMDR
- ROM FOR OPERATING SYSTEM SOFTWARE AND DEFAULT STANDARD DATA BASE
- RAM FOR CUSTOMIZED DATA BASE (REMAINDER OF RAM RESIDES IN MEM CARD)
- REAL TIME CLOCK — RTS (REAL TIME SOURCE)

MEM Card (Memory Card)



GTE OMNI SBCS



- ACTS AS EXTENSION OF CPM CARD - NOT ENOUGH MEM ON CPM CARD → CENTRALIZED BATTERY BACKUP (IF NOT ON CARD)
- ROM FOR OPERATING SYSTEM SOFTWARE AND DEFAULT STANDARD DATA BASE
- RAM FOR CUSTOMIZED DATA BASE (ALSO RESIDES IN CPM CARD)

YOU LOSE MEMORY IF YOU PULL CPM OR MEM CARD,


1.14

TO WRITE TO TAPE TAKES 2 1/2 HRS → IF AT 1200 BAUD CALL PROCESSING UNAFFECTED
IF OVER 1200 BAUD " " GOES DOWN



SWC Card (Switch Control Card)

GTE OMNI SBCS



RS 232 PORTS
DO NOT GO THRU
THIS CARD,
EVERYTHING ELSE DOES
SWITCH MATRIX

SWCA - ANY PKG
(40 TRUNKS)
IF YOU ADD
SWRA - EXPANSION CAR.
OR SINGLE CAR. FOR
(52 TRUNKS) TRUNKS
C PKG OR ABOVE.


- CONTAINS PCM TIME DIVISION SWITCHING CIRCUITRY
- TONE SOURCE
- MIXING CIRCUITS
- MULTIPLEXER/DEMULTIPLEXER CIRCUITS
- PADDING CIRCUITS
- ACTS AS INTERFACE BETWEEN LINE/TRUNK CARDS AND CPM CARD

INDICATES NUMBER OF PORTS

Line Cards: 8EKC (Electronic Key Telephone Card) and 8SLC (Single Line Telephone Card)



GTE OMNI SBCS



- 8EKC AND 8SLC CARDS CAN BE INSERTED SLOTS 00 THROUGH 14.
- 8SLC: — POTS PHONES
 - 8 CIRCUITS PER CARD
 - 600 Ω LOOP LIMIT/2000 FEET
 - SUPPORTS DTMF (WITH 4DMR CARD) AND ROTARY DIAL SETS
 - NIGHT BELL INTERFACE
 - POWER FAIL TRANSFER INTERFACE
 - REQUIRES OPTIONAL RGEN CARD (RING GENERATOR)
- 8EKC: — CS-10, CS-20, DSS, BLF
 - 8 CIRCUITS PER CARD
 - 2000 FEET LOOP LIMIT
 - SUPPORTS CS-10, CS-20 AND BLF/DSS

> 1 PAIR T&R

> 2 PAIR


T&R
DATA/POWER

POLARITY
SENSITIVE

8DTC Card (CSD Telephone/Digital Interface Card)*



GTE OMNI SBCS



DIGITAL CARD
 FOR CSD PHONES
 OR DIV
 1 PAIR (DIGITAL TAP)
 NOT POLARITY SENSITIVE
 INTERNAL DATA ONLY
 OTHERWISE, YOU NEED A
 MODEM.

- 8DTC CARDS CAN BE INSERTED IN SLOTS 00 THROUGH 14 (IF CSD TELEPHONES EQUIPPED WITH DATA TERMINAL ADAPTER (DTA) ARE INSTALLED, ONLY SLOTS 00, 03, 06, 09, AND 12 MAY BE USED). ONLY 12 OF THESE CARDS
- SYSTEM CAPACITY OF FIVE 8DTC CARDS FOR VOICE/DATA OR 15 8DTC CARD FOR VOICE ONLY APPLICATION.
- 8DTC SPECIFICATIONS:
 - EIGHT CIRCUITS PER CARD (ONLY SIX IF CSD TELEPHONES ARE USED FOR DATA TRANSMISSION)
 - PROVIDES SIMULTANEOUS VOICE/DATA TRANSMISSION, CONTROL DATA TRANSMISSION, AND POWER FEEDING (-24V) OVER A SINGLE PAIR OF WIRES
 - SUPPORTS CSD DIGITAL TELEPHONES OR CSD TELEPHONES WITH DATA TERMINAL INTERFACES VIA DATA TERMINAL ADAPTER OR DATA INTERFACE UNITS**
 - 2000 FEET LOOP LIMIT
 - CHANNEL CAPACITY = 64 Kbps FOR VOICE AND DATA, 8 Kbps FOR TELEPHONE CONTROL
 - LINE BIT RATE = 384 Kbps


*PACKAGE B/PHASE 1.5 AVAILABILITY

**PACKAGE C/PHASE 2.0 AVAILABILITY

Trunk Cards: 4BWC (Bothway Trunk Card), 2TTE (E & M Tie Trunk Card), 2TTL (Loop Dial Tie Trunk Card)



GTE OMNI SBCS



TIE TRUNK CARDS
SUPPORT
DID
TRUNKS

- 4BWC, 2TTE, AND 2TTL CARDS CAN BE INSERTED IN SLOTS 06 THROUGH 18.
- MAXIMUM OF 10 4BWC, MAXIMUM OF 6 2TTE OR 6 2TTL (PACKAGES A AND B).
- 4BWC:
 - 4 CIRCUITS PER CARD
 - LOOP START OR GROUND START
 - MUSIC-ON-HOLD INTERFACE
 - EXTERNAL PAGING INTERFACE
 - POWER FAIL TRANSFER INTERFACE
- 2TTE:
 - 2 CIRCUITS PER CARD
 - 2 WIRE
 - SUPPORTS TYPE I AND TYPE II E & M SIGNALING
- 2TTL:
 - 2 CIRCUITS PER CARD
 - TIP AND RING LOOP START

MAX 6
PER SYSTEM

NO 4 WIRE EFM TRUNKS


SWCA CARD PROVIDES
MAX 10 BWC CARDS
= 40 TRUNKS

SWCB = 13 BWC CARDS
= 52 TRUNKS

4DMR Cards (Dual Tone Multi-Frequency Receiver Card)



GTE OMNI SBCS



MAX
2 PER
CAB.


USUALLY
NEED ONLY ONE

- RECEIVES DTMF TONES FROM PUSHBUTTON TELEPHONE INSTRUMENT AND CONVERTS THEM INTO DIALED NUMBERS.
- 4DMR CARDS CAN BE INSERTED IN SLOTS 06 THROUGH 14.
- 4DMR:
 - 4 CIRCUITS
 - REQUIRED ONLY WHEN DTMF INSTRUMENTS OR RECEIVERS (I.E. DTMF TIE TRUNKS) ARE USED
 - MAXIMUM OF TWO CARDS/SYSTEM

Optional RGEN Card (Ring Generator)



GTE OMNI SBCS



- RGEN INSERTED IN MOUNTING SLOT LEFT OF CARD SLOT 00.
- GENERATES RINGING TONE FOR SINGLE LINE TELEPHONE INSTRUMENTS.
- SUPPLIES POWER TO MESSAGE WAITING FEATURE FOR SLT INSTRUMENTS WITH MESSAGE WAITING LAMP.*
- MESSAGE WAITING FEATURE FOR SLT IS ACTIVATED THROUGH A STRAPPING OPTION ON RGEN CARD. (STRAPPING OPTION IS DESCRIBED IN OMNI SBCS GTEP MANUAL).*
- RINGING:
 - FREQUENCY: 20 ± 2 Hz
 - VOLTAGE: 80 V RMS (NOMINAL)
- MESSAGE WAITING:
 - VOLTAGE: -100V DC *POTS PHONES*
 - ON/OFF INTERVAL: 1 SECOND ON, 3 SECONDS OFF
- REQUIRED FOR OPERATION OF OPTIONAL CUSTOMER SUPPLIED NIGHT BELL.


*PACKAGE B/PHASE 1.5 AVAILABILITY

1.20

Optional 6PFT Card: (Power Fail Transfer)



GTE OMNI SBCS



*CONTACT
CLOSURES*

- 6PFT CARD CAN BE INSERTED IN SLOT 22.
- 6PFT:
 - SIX CIRCUITS CAN BE DESIGNATED FOR POWER FAIL TRANSFER
 - AUTOMATIC OPERATION
 - MANUAL TESTING — FLIP SWITCH TO TEST
 - INTERFACES WITH 8SLC AND 4BWC CARD



Maximum Number of Cards

GTE OMNI SBCS

<u>TYPE OF CARD</u>	<u>INTERFACE FUNCTION</u>	<u>CAPACITY</u>
● 8SLC	SINGLE LINE TELEPHONE CARD	15
● 8EKC	ELECTRONIC KEY TELEPHONE CARD	15
● 8DTC*	CSD TELEPHONE/DIGITAL INTERFACE CARD	5
● 4DMR	DUAL TONE MULTI-FREQUENCY RECEIVER CARD	2
● 4BWC	BOTHWAY TRUNK CARD	10
● 2TTE, 2TTL	E&M AND LOOP DIAL TIE TRUNK CARDS	6 (TOTAL)
● 4CHT** HOTEL MOTEL PRINTER	CHARACTER TRUNK CARD	2
● 6PFT	POWER FAIL TRANSFER CARD	1
● RGEN	RING GENERATOR	1

*PACKAGE B/PHASE 1.5 AVAILABILITY

**PACKAGE C/PHASE 2.0 AVAILABILITY

CS-10 Electronic Key Telephone

GTE

GTE OMNI SBCS

- 10 PROGRAMMABLE BUTTONS
- 100% MODULAR
- HANDS-FREE DIALING
- MONITOR CAPABILITIES
- INTERFACE THROUGH 8EKC CARD
- 4 WIRE:
 - 2 ANALOG TIP AND RING
 - 2 DATA/POWER LEADS
- 2000 FEET LOOP LIMIT




CS-20 Electronic Key Telephone

GTE

GTE OMNI SBCS


- 10 PROGRAMMABLE BUTTONS
- 100% MODULAR
- SPEAKERPHONE
- 20 CHARACTER X 1 LINE LCD DISPLAY
- INTERFACE THROUGH 8EKC CARD
- 4 WIRE
 - 2 ANALOG TIP AND RING
 - 2 DATA/POWER LEADS
- 2000 FEET LOOP LIMIT




Busy Lamp Field/Direct Station Selection Module



GTE OMNI SBCS



40 BUTTON MODULE



80 BUTTON MODULE

DON'T REALLY
NEED 1 AR
PAIR, ONLY
DATA PAIR
NEEDED

- MAXIMUM OF: 8
 - SIX 40 BUTTON MODULES
 - TWO 80 BUTTON MODULES
- INTERFACE THROUGH 8EKC CARD
- ONE MODULE PER PHONE (2 WITH ATD → PRO C)
- 2000 FEET LOOP LIMIT




CSD Digital Telephone

GTE OMNI SBCS

- TEN PROGRAMMABLE FEATURE BUTTONS (TWO PREPROGRAMMED DATA COMMUNICATION BUTTONS: DATA CALL AND VOICE/DATA MODE)
- FOUR FIXED FEATURE BUTTONS: SPEAKERPHONE, MUTE, TRANSFER, AND HOLD
- SPEAKERPHONE
- FOUR LINE, 20 CHARACTER LCD DISPLAY
- INTERFACE THROUGH 8DTC CARD
- LINE POWERED
- TWO WIRE:
 - 2 DIGITAL TIP AND RING
- 2000 FEET LOOP LIMIT
- MAY BE CONNECTED TO BLF/DSS MODULE *(SOFTWARE CONNECTION)*
- OPTIONAL DATA TERMINAL ADAPTER (DTA) INSTALLED WITHIN CSD PROVIDES RS-232-C INTERFACE TO CUSTOMER-SUPPLIED DATA TERMINAL
- SYSTEM CAPACITY OF 40 CSD TELEPHONES INTERFACE (8 CIRCUITS X 5 CARDS) OR 30 CSD TELEPHONES WITH DTA INTERFACE (6 CIRCUITS X 5 CARDS)


C PKG - 80



Portable Maintenance Panel



GTE OMNI SBCS




NEED TO
INITIALIZE TO
TALK W/ SYSTEM
PMP CONTROL
PROGRAM

- BATTERY POWERED WITH AC RECHARGER (LEAVE IN ALL THE TIME)
- CABLE CONNECTED TO I/O PORT 0 (DEFAULT SETTING)
- 1200 BAUD (DEFAULT SETTING)
- OPTIONAL FLOPPY DISKETTE DRIVE UNIT (REQUIRES EXPANSION RAM FOR PMP)



Optional Floppy Diskette Drive

GTE OMNI SBCS



- EPSON TF-20 FLOPPY DISKETTE DRIVE UNIT MAY BE USED FOR SAVING AND LOADING INSTEAD OF PMP'S BUILT-IN MICROCASSETTE TAPE DRIVE.
- PMP REQUIRES INSTALLATION OF EXPANSION RAM (EXPANSION UNIT H20 EU) FOR DISKETTE DRIVE OPERATION.


Station Message Detail Recording (SMDR or MDR) Printer



GTE OMNI SBCS

NO INCOMING CALLS

- SUPPORTS THE RECORDING OF SYSTEM CALL RECORDS PERTAINING TO OUTGOING TRUNK CALLS AND TRUNK-TO-TRUNK CALLS. *only*
- TRANSFERS DATA AT RATES OF 110, 150, 300, 600, 1200, 2400, OR 4800 BAUD AS DETERMINED IN THE SYSTEM DATA BASE.
- INTERFACES WITH THE SYSTEM MICROPROCESSOR VIA THE RS-232-C PORT 1 (DEFAULT SETTING).



NOTE: SMDR OUTPUT MAY INTERFACE TO A MINI-COMPUTER, DISK DRIVE OR OTHER MASS STORAGE DEVICES.



Night Bell

GTE OMNI SBCS

- **ALLOWS INCOMING CALLS TO BE DIVERTED TO A NIGHT BELL ATTACHED TO A STATION EQUIPMENT NUMBER WHICH HAS BEEN DESIGNATED AS A NIGHT ANSWER STATION.**
- **NIGHT BELL INTERFACES TO THE SYSTEM THROUGH THE 8 SLC AND RGEN CARDS.**
- **NIGHT BELLS ARE CUSTOMER FURNISHED.**



Music-On-Hold

GTE OMNI SBCS

MUSIC SOURCE:

- FM RADIO
- PACKAGED MUSIC
- ETC. ...

- PROVIDES MUSIC TO CALLING PARTIES FOR THE DURATION OF TIME THE CALL IS PLACED IN THE HOLD QUEUE.
- MUSIC SOURCE INTERFACES TO THE SYSTEM VIA A UNIVERSAL SLOT. MUSIC SOURCE IS COUPLED THROUGH 4BWC CARD.
- MUSIC SOURCE MUST BE 600 Ω IMPEDENCE.


NOTE: NO LIMITATION EXISTS FOR THE NUMBER OF LINES OR TRUNKS THAT CAN BE CONNECTED TO THE MUSIC-ON-HOLD FEATURE.

The SBCS Configuration



GTE OMNI SBCS

ICG	INTERFACE CARD GROUP
SWC	SWITCH CONTROL CARD
EKI	ELECTRONIC KEY INSTRUMENT INTERFACE
DTI	DIGITAL TELEPHONE INTERFACE
SLI	SINGLE LINE INSTRUMENT INTERFACE
PFT	POWER FAILURE TRANSFER
BWT	BOTHWAY TRUNK INTERFACE
ETT	E&M TIE TRUNK INTERFACE
LTT	LOOP TIE TRUNK INTERFACE
DTMFR	DTMF RECEIVER
SCI	SERIAL COMMUNICATION INTERFACE
CPU	CENTRAL PROCESSOR UNIT
BMEM	BASIC MEMORY
MEM	MEMORY
CPM	CENTRAL PROCESSING AND MEMORY CARD



1.32 RS 232 JACKS
TRU SWITCHING MATRIX

Student Notes



GTE OMNI SBCS

Review Exercise (1.1) — Installation Overview



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, FILL IN THE BLANK OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. (TRUE OR FALSE) _____ THE OMNI SBCS SYSTEM REQUIRES ADDITIONAL COOLING.
2. (TRUE OR FALSE) _____ THE OMNI SBCS POWER SUPPLY WILL ACCEPT EITHER 110 VAC, 220 VAC, OR 48 VDC AS ITS INPUT POWER SOURCE.
3. THE SYSTEM BACKUP BATTERY WILL MAINTAIN THE SYSTEM MEMORY FOR A PERIOD OF APPROXIMATELY:
A. 2 DAYS B. 5 DAYS C. 1 WEEK D. 2 WEEKS _____
4. (TRUE OR FALSE) _____ THE DEFAULT STANDARD DATA BASE MUST BE LOADED FROM TAPE OR FLOPPY DISKETTE AT TIME OF SYSTEM INSTALLATION.
5. THE COMMON CONTROL CARDS REQUIRED FOR A MINIMUM SYSTEM CONFIGURATION CONSIST OF:
A. CPM, SWC, AND RGEN CARDS
B. CMC, MEM, AND RGEN CARDS
C. CPM, 4DMR, AND 6PFT CARDS
D. CPM, SWC, AND MEM CARDS
6. THE MAXIMUM NUMBER OF STATIONS SUPPORTED BY THE SYSTEM IS _____ AND THE MAXIMUM NUMBER OF TRUNKS SUPPORTED BY THE SYSTEM IS _____, ALTHOUGH THESE CAPACITIES CANNOT BE ACHIEVED SIMULTANEOUSLY.

Review Exercise (1.1) — Installation Overview (Continued)



GTE OMNI SBCS

7. (TRUE OR FALSE) _____ CARD SLOTS 06 THROUGH 18 CAN CONTAIN LINE OR TRUNK CARDS.
8. (TRUE OR FALSE) _____ CARD SLOTS 19, 20, AND 21 ARE RESERVED FOR COMMON CONTROL CARDS.
9. THE TWO RS-232-C PORTS AVAILABLE ON THE SYSTEM CABINET FOR THE PORTABLE MAINTENANCE PANEL OR THE SMDR PRINTER ARE _____ OR _____.

MATCH THE FOLLOWING CARDS WITH THE CORRECT DESCRIPTION:

- | | |
|---------------------|---|
| 10. _____ CPM CARD | A. 2 CIRCUIT E&M TIE LINE TRUNK CARD SUPPORTING TYPE I AND TYPE II SIGNALING |
| 11. _____ MEM CARD | B. 8 CIRCUIT LINE CARD SUPPORTING ELECTRONIC KEY TELEPHONES |
| 12. _____ SWC CARD | C. CONTAINS PCM TIME DIVISION MULTIPLEXOR/DEMULTIPLEXOR CIRCUITS |
| 13. _____ RGEN CARD | D. INTERFACES WITH 8SLC AND 4BWC CARD TO PROVIDE SIX POWER FAIL TRANSFER STATIONS |
| 14. _____ 8EKC CARD | E. 8 CIRCUIT DIGITAL INTERFACE CARD SUPPORTING CSD TELEPHONES AND DATA INTERFACE UNITS |
| 15. _____ 8SLC CARD | F. 4 CIRCUIT CO TRUNK CARD WHICH CAN ALSO PROVIDE MUSIC-ON-HOLD, EXTERNAL PAGING, AND POWER FAILURE TRANSFER INTERFACES |
| 16. _____ 4BWC CARD | G. 8 CIRCUIT LINE CARD SUPPORTING DTMF AND ROTARY DIAL SINGLE LINE TELEPHONES |
| 17. _____ 2TTE CARD | H. 2 CIRCUIT LOOP START TIE LINE TRUNK CARD |
| 18. _____ 2TTL CARD | I. CONTAINS ADDITIONAL MEMORY AS EXTENSION OF CPM CARD WITH ROM FOR OPERATING SYSTEM SOFTWARE AND RAM FOR CUSTOMIZED DATA BASE |
| 19. _____ 4DMR CARD | J. 4 CIRCUIT CARD PROVIDING TONES IF TELEPHONES REQUIRING DUAL TONE MULTI-FREQUENCY ARE INSTALLED |
| 20. _____ 6PFT CARD | K. GENERATES RINGING TONES FOR SINGLE LINE TELEPHONES OR POWER TO MESSAGE WAITING FEATURE ON SINGLE LINE TELEPHONES WITH MESSAGE WAITING LAMP |
| 21. _____ 8DTC CARD | L. CONTAINS 16 BIT MICROPROCESSOR FOR SYSTEM OPERATION, REAL TIME CLOCK, AND ROM FOR OPERATING SYSTEM SOFTWARE AND RAM FOR CUSTOMIZED DATA BASE |

Review Exercise (1.1) — Installation Overview (Continued)



GTE OMNI SBCS

MATCH THE FOLLOWING COMPONENTS WITH THE CORRECT DESCRIPTION:

- | | |
|---|--|
| 22. _____ CS-10 | A. DTMF OR DIAL PULSE (ROTARY) TELEPHONE INSTRUMENT |
| 23. _____ CS-20 | B. ELECTRONIC KEY TELEPHONE WITH 10 PROGRAMMABLE BUTTONS AND MONITOR CAPABILITIES |
| 24. _____ CSD | C. MICROCOMPUTER USED FOR SYSTEM DATA BASE ADMINISTRATION AND MAINTENANCE |
| 25. _____ BLF/DSS | D. OPTIONAL UNIT USED TO DECREASE TIME ASSOCIATED WITH SAVING OR LOADING THE CUSTOMIZED DATA BASE |
| 26. _____ PMP | E. PROVIDES MUSIC TO CALLING PARTIES BY MUSIC SOURCE INTERFACED THROUGH A 4BWC CARD |
| 27. _____ SMDR | F. ELECTRONIC KEY TELEPHONE WITH 10 PROGRAMMABLE BUTTONS, SPEAKERPHONE, AND 20 CHARACTER LCD DISPLAY |
| 28. _____ MUSIC-ON-HOLD | G. 40 OR 80 BUTTON EXPANSION MODULE USED TO PROVIDE VISUAL INDICATORS FOR STATUS OF LINES IN SYSTEM |
| 29. _____ SLT | H. PRINTER USED TO PROVIDE HARD COPY RECORDS OF SYSTEM CALLS |
| 30. _____ FLOPPY DISKETTE DRIVE | I. DIGITAL TELEPHONE WHICH CAN PROVIDE INTERFACE TO DATA TERMINAL IF EQUIPPED WITH DATA TERMINAL ADAPTER (DTA) |
| 31. (TRUE OR FALSE) _____ ONLY SIX ELECTRONIC KEY TELEPHONES MAY BE DESIGNATED AS POWER FAIL TRANSFER STATIONS. | |

Student Notes



GTE OMNI SBCS



GTE OMNI SBCS

SYSTEM INSTALLATION

Cabinet Installation

1.2 Enabling Objective/ Cabinet Installation



GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS WITH MOUNTING BRACKET, CABINET, AND POWER SUPPLY
 - GTE OMNI SBCS PCB CARDS
 - #6 AWG CABLE, POWER SUPPLY CABLE, AND HARDWARE
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - STANDARD INSTALLATION TOOLS
 - REVIEW EXERCISE
- ACTION:**
- MOUNT AND INSTALL SYSTEM CABINET AND POWER SUPPLY.
 - CONNECT POWER SUPPLY CABLE.
 - GROUND WIRE TERMINALS TO COLD WATER GROUND AND CONNECT SIGNAL WIRE GROUND.
 - INSERT AND SEAT COMMON CONTROL, LINE, TRUNK, AND RING GENERATOR CARDS IN CORRECT CARD SLOTS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- CABINET AND POWER SUPPLY WILL BE INSTALLED AND GROUNDED IN ACCORDANCE WITH GTE OMNI SBCS GTEP MANUAL. CARDS WILL BE INSERTED AND SEATED CORRECTLY IN DESIGNATED CARD SLOTS.
 - REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



Basic Installation Sequence


GTE OMNI SBCS

- (1) INSTALL MOUNTING BRACKET.
- (2) MOUNT AND INSTALL CABINET AND POWER SUPPLY. (NOTE: DO NOT POWER ON SYSTEM UNTIL CARDS AND PERIPHERALS HAVE BEEN INSTALLED).
- (3) GROUND POWER SUPPLY AND CABINET.
- (4) INSTALL COMMON CONTROL CARDS, LINE CARDS, AND TRUNK CARDS.
- (5) INSTALL CABLES FROM CABINET AND RECEPTACLES TO CDF CROSS CONNECTION BLOCKS.
- (6) WIRE ALL STATION AND TRUNK CROSS CONNECTIONS.
- (7) INSTALL PERIPHERAL INSTRUMENTS (E.G., STATION INSTRUMENTS, BLF/DSS CONSOLES, SMDR, PMP, ETC.).
- (8) POWER SYSTEM ON.
- (9) COLD RESTART SYSTEM TO ESTABLISH DEFAULT STANDARD DATA BASE.
- (10) VERIFY SYSTEM/FEATURE OPERATION.
- (11) DRESS AND TIE CABLES AS REQUIRED. CLEAR INSTALLATION SITE.
- (12) MODIFY DEFAULT STANDARD DATA BASE TO MEET CUSTOMER'S REQUIREMENTS.

Mounting Bracket

GTE

GTE OMNI SBCS




- MOUNT BRACKET EITHER DIRECTLY TO WALL OR TO PLYWOOD.
- ENSURE THAT BRACKET IS SECURELY MOUNTED TO WALL.



Mounting Procedure

GTE OMNI SBCS






- (1) MOUNT EQUIPMENT CABINET TO THE MOUNTING BRACKET BY LOWERING THE CABINET ONTO THE BRACKETS.
- (2) AFTER CABINET IS SECURELY MOUNTED, THEN INSTALL THE POWER SUPPLY.
- (3) SECURE BOTH CABINET AND POWER SUPPLY WITH THE SCREWS PROVIDED.




Cabinet — Power Supply Cable

GTE OMNI SBCS



FRONT VIEW OF CONNECTORS

CABLE FOR CABINET-POWER SUPPLY CONNECTION




LOCATION OF RECEPTACLES

NOTE: CONNECT POWER SUPPLY CABLE TO EQUIPMENT CABINET ONLY WHEN SYSTEM INSTALLATION PROCEDURE HAS BEEN COMPLETED.

Ground Wire Terminals

GTE OMNI SBCS



- (1) **GROUND BOTH FRAME GROUND TERMINALS (FOR EQUIPMENT CABINET AND POWER SUPPLY UNIT) TO AN APPROVED EARTH GROUND.**
- (2) **RUN SEPARATE GROUND WIRE FOR THE SIGNAL GROUND.**
- (3) **USE #6 AWG STANDARD CABLE.**

START TRUNK CARDS FROM SLOT 18 & WORK DOWN
START LINE CARDS FROM SLOT 00 & WORK UP
THIS WAY UNIVERSAL CARD SLOTS STAY FREE.



Card Placement Procedure

GTE OMNI SBCS

- (1) ENSURE THAT PROPER ELECTROSTATIC GROUNDING PROCEDURES ARE FOLLOWED PRIOR TO HANDLING PCB CARDS. FAILURE TO DO SO WILL RESULT IN CARD FAILURES.
- (2) INSTALL COMMON CONTROL CARDS: SWC IN SLOT 19, CPM CARD IN SLOT 20, AND MEM CARD IN SLOT 21.
- (3) INSTALL LINE CARDS:
 - STARTING FROM SLOT 00, INSTALL ALL 8EKC CARDS IN DESIGNATED CARD SLOTS.
 - AFTER INSTALLING 8EKC CARDS, INSTALL ALL 8SLC CARDS IN DESIGNATED CARD SLOTS.
- (4) INSTALL TRUNK CARDS:
 - STARTING FROM SLOT 18, INSTALL ALL 4BWC CARDS IN DESIGNATED CARD SLOTS.
 - AFTER INSTALLING 4BWC CARDS, INSTALL ALL 2TTE AND 2TTL CARDS IN DESIGNATED CARD SLOTS.
- (5) INSTALL OPTIONAL 4DMR, RGEN, AND 6PFT CARDS AS REQUIRED IN APPROPRIATE CARD SLOTS.

NOTE: ENSURE THAT CARDS HAVE BEEN PROPERLY SEATED:

- CARD EDGE CONNECTORS TOWARD BACKPLANE.
- CARD EDGES RIDE ON TRACKS (TOP AND BOTTOM).
- SLIDE EACH CARD IN SLOT UNTIL IT STOPS WITH GENTLE PRESSURE.
- SIMULTANEOUSLY PUSH ON TOP AND BOTTOM EJECTOR LEVERS TO SEAT CARD.

Laboratory Activity (1.2) – Cabinet Installation



GTE OMNI SBCS

PERFORM THE INSTALLATION TASKS IN THE SEQUENCE OUTLINED BELOW, IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO CABINET INSTALLATION UPON COMPLETION OF THIS LABORATORY ACTIVITY.

- (1) MOUNT CABINET AND POWER SUPPLY TO MOUNTING BRACKET.
 - (A) REFER TO GTEP MANUAL OR STUDENT WORKBOOK FOR MOUNTING BRACKET REQUIREMENTS.
 - (B) MOUNT THE BRACKET TO A SOLID SURFACE OR TO A STUD IN THE WALL. USE 24" CENTERS.
 - (C) ENSURE THAT MOUNTING BRACKET IS LEVEL.
 - (D) MOUNT THE POWER SUPPLY MOUNTING BRACKET TO LEFT OF SYSTEM CABINET.
- (2) WIRE SYSTEM GROUNDING.
 - (A) REFER TO GTEP MANUAL OR STUDENT WORKBOOK FOR CORRECT GROUNDING PROCEDURES.
 - (B) GROUND THE SYSTEM USING #6 AWG WIRING.
 - (C) ENSURE THAT THE FRAME GROUND IS CONNECTED TO THE POWER SUPPLY AND TO AN APPROVED GROUND POINT.
 - (D) ENSURE THAT THE SYSTEM GROUND IS CONNECTED TO THE CORRECT POINT ON THE CABINET AND FROM THERE TO AN APPROVED EARTH GROUND.
- (3) CONNECT POWER SUPPLY CABLE TO THE POWER SUPPLY ONLY. DO NOT CONNECT CABLE TO SYSTEM CABINET UNTIL INSTRUCTED TO POWER ON THE SYSTEM AT A LATER TIME.

LAB MILESTONE:

- VERIFY THAT MOUNTING BRACKET, CABINET, AND POWER SUPPLY ARE INSTALLED CORRECTLY. THE SYSTEM SHOULD BE GROUNDED AND THE POWER SUPPLY CABLE SHOULD BE HANGING FROM THE POWER SUPPLY.
- ASK INSTRUCTOR TO INSPECT INSTALLATION.
- TURN TO REVIEW EXERCISE 1.2 AND ANSWER QUESTIONS 1-5.

Laboratory Activity (1.2) – Cabinet Installation (Continued)



GTE OMNI SBCS

- (4) ENSURE THAT SYSTEM IS GROUNDED AND THAT YOU ARE WEARING A GROUNDED ANTI-STATIC WRIST STRAP DEVICE.
- (5) REMOVE HINGED CABINET DOOR AND TEMPORARILY STORE IT OUT OF THE WAY.
- (6) BEGIN INSTALLING THE DESIGNATED PRINTED CIRCUIT BOARDS (IN THE SEQUENCE OUTLINED BELOW), FROM LEFT TO RIGHT IN THE SYSTEM CABINET:
 - (A) INSTALL THE RING GENERATOR IN THE MARKED SLOT TO THE FAR LEFT. ENSURE THAT COMPONENTS FOR THIS CARD ARE ON THE RIGHT SIDE OF THE BOARD.
NOTE: FOR INSTALLATION OF ALL OTHER PCB CARDS, THE CARD COMPONENTS WILL BE ON LEFT SIDE OF THE BOARDS.
 - (B) INSERT AND SEAT AN ELECTRONIC KEY TELEPHONE (8EKC) CARD IN SLOT 01.
 - (C) INSERT AND SEAT A SINGLE LINE TELEPHONE (8SLC) CARD IN SLOT 02.
 - (D) INSERT AND SEAT A DIGITAL TELEPHONE (8DTC) CARD IN SLOT 00.
 - (E) INSERT AND SEAT A DTMF RECEIVER (4DMR) CARD IN SLOT 06.
 - (F) INSERT AND SEAT A BOTHWAY CO TRUNK (4BWC) CARD IN SLOT 18.
 - (G) INSERT AND SEAT A TIE LINE LOOP TRUNK (2TTL) CARD IN SLOT 16.
 - (H) INSERT AND SEAT A TIE LINE E&M TRUNK (2TTE) CARD IN SLOT 17.
 - (I) INSERT AND SEAT THE SWITCH (SWC) CARD IN SLOT 19.
 - (J) INSERT AND SEAT THE CONTROL PROCESSOR MEMORY (CPM) CARD IN SLOT 20.
 - (K) INSERT AND SEAT THE MEMORY (MEM) CARD IN SLOT 21.
 - (L) INSERT AND SEAT THE POWER FAIL TRANSFER (6PFT) CARD IN SLOT 22.

LAB MILESTONE:

- VERIFY THAT PCB CARDS ARE INSTALLED AND SEATED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT INSTALLATION OF CARDS.
- TURN TO REVIEW EXERCISE 1.2 AND ANSWER QUESTIONS 6-14. SUBMIT YOUR COMPLETED REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.
- YOU HAVE NOW COMPLETED THE CABINET INSTALLATION LABORATORY ACTIVITY.

Review Exercise (1.2) — Cabinet Installation



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, FILL IN THE BLANK OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE MOUNTING BRACKET IS DESIGNED TO PERMIT MOUNTING ON _____
OR _____ INCH CENTERS.
2. (TRUE OR FALSE) _____ THE POWER SUPPLY IS MOUNTED TO THE RIGHT OF THE
SYSTEM CABINET.
3. THREE GROUND WIRES ARE REQUIRED FOR SYSTEM OPERATION _____,
_____, AND _____.
4. WHERE DOES THE GROUND ORIGINATE FOR GROUND START TRUNKS? _____
5. WHAT PREVENTS INCORRECT INSTALLATION OF THE POWER SUPPLY CABLE?


6. TO PROTECT AGAINST ELECTROSTATIC DISCHARGE, A GROUNDED _____
SHOULD ALWAYS BE WORN WHEN INSERTING OR REMOVING PCB CARDS.

Review Exercise (1.2) — Cabinet Installation (Continued)



GTE OMNI SBCS

7. COMPLETE THE OMNI SBCS FRAME IMAGE BELOW, BY IDENTIFYING WHAT TYPE OF CARDS WERE INSTALLED IN EACH CARD SLOT DURING THE LAB ACTIVITY.



8. WHICH CARD IS INSERTED WITH COMPONENTS FACING THE RIGHT SIDE OF THE CABINET WHEN INSTALLED CORRECTLY? _____
9. OTHER THAN LINE OR TRUNK CARDS, WHICH THREE TYPES OF CARDS ARE CONSIDERED TO BE OPTIONAL? _____, _____, AND _____
10. HOW MANY CIRCUITS CAN BE ASSIGNED AS POWER FAIL TRANSFER CIRCUITS?

11. HOW MANY OMNI SBCS SLOTS CAN BE DEDICATED TO LINE CARDS? _____
12. HOW MANY OMNI SBCS SLOTS CAN BE DEDICATED TO TRUNK CARDS? _____
13. HOW MANY OMNI SBCS SLOTS CAN CONTAIN EITHER LINE OR TRUNK CARDS? _____
14. WHAT THREE CARDS ARE REFERRED TO AS COMMON CONTROL CARDS?
_____, _____, AND _____

SBCS/STARLOG

FEATURE ACCESS CODE ASSIGNMENTS
 PACKAGE C (Continued)

CMC 100

Feature Name	Feature Number P1	Default Access Code	Enter New Access Code P2
Station speed calling	48	*0	_____
Station Prefix	2	NONE	_____
Subordinate data call setup (2.0)	160	67	_____
System speed calling	49	##	_____
Trunk camp-on (activate)	151	*7	_____
Trunk camp-on (cancel)	91	#7	_____
Trunk access - direct trunk access	130	61*	_____
Wake-up other (activate) (2.0)	70	NONE	_____
Wake-up self (activate) (2.0)	78	NONE	_____
Wake-up self (cancel) (2.0)	79	NONE	_____



GTE OMNI SBCS

SYSTEM INSTALLATION

Peripheral Installation

1.3 Enabling Objective/ Peripheral Installation




GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - ASSORTED GAUGE WIRE, AMP CONNECTOR CABLES, CDF BLOCKS, MODULAR TELEPHONE JACKS, AND HARDWARE
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - STANDARD INSTALLATION TOOLS
 - REVIEW EXERCISE
- ACTION:**
- CONNECT AND FASTEN AMP CONNECTOR CABLES FROM OMNI SBCS TO CDF BLOCKS.
 - INSTALL PERIPHERAL DEVICES BY MAKING CORRECT CROSS CONNECTIONS FROM MODULAR TELEPHONE JACKS TO CDF BLOCKS.
 - WIRE POWER FAIL TRANSFER CROSS CONNECTIONS.
 - INSTALL CO AND TIE LINE TRUNKS BY MAKING CORRECT CROSS CONNECTIONS.
 - WIRE NIGHT BELL AND MUSIC-ON-HOLD CROSS CONNECTIONS.
 - CONNECT AND INSTALL SMDR PRINTER, PORTABLE MAINTENANCE PANEL, AND FLOPPY DISKETTE DRIVE UNIT.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- PERIPHERALS WILL BE INSTALLED IN ACCORDANCE WITH GTE OMNI SBCS GTEP MANUAL.
 - REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

AMP Connector Number Receptacles



GTE OMNI SBCS



- (1) AFTER CARDS HAVE BEEN INSTALLED, DETERMINE WHICH INTERFACE CARD GROUP (ICG) WILL REQUIRE CABLES.
- (2) INSTALL MALE ENDED 25 PAIR AMP CABLES TO CONNECTOR NUMBER RECEPTACLES WHICH MATCH THE ICG OF THE INSTALLED CARDS.
- (3) ENSURE THAT AMP CONNECTORS ARE SECURED FIRMLY TO THE AMP CONNECTOR NUMBER RECEPTACLES USING THE SCREWS PROVIDED.
- (4) ATTACH THE CABLE TO THE WALL USING TIE WRAPS OR SIMILAR DEVICES TO PREVENT THE CONNECTOR FROM WORKING LOOSE.


ICG 0-4 (2 CABLES)
 IDENTICAL (5 SLOTS)
 ICG 5 (2 CABLES)
 4 SLOTS

ICG - INTERFACE CARD
 GROUPS
 6 PER SYSTEM
 = GROUP OF CKTS

Relationship of Card Slots and Circuits to Cables and AMP Connector Pins



GTE OMNI SBCS



ICG 0 → 4 ARE THE SAME
 (3 SLOTS)

ICG 5 DIFFERENT
 SLOTS 15, 16, 17, 18
 (TRUNKS)





CS-10, CS-20, or BLF/DSS Installation

ALSO ATT CONSOLE → NOTE ★


GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CS-10 OR CS-20 ELECTRONIC TELEPHONE.
- EACH CS-10 AND CS-20 TELEPHONE WILL REQUIRE TWO PAIRS OF WIRES. ONE PAIR IS FOR TIP AND RING, THE OTHER FOR DATA/POWER. DATA PAIRS MUST BE INSTALLED PROPERLY FOR TELEPHONE TO WORK. BLF/DSS REQUIRES ONLY ONE PAIR OF WIRES (DATA/POWER) FOR OPERATION.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR AN 8EKC INTERFACE CARD IN SLOT 01, USING CABLE NUMBER (CN) 1. CONNECTOR BLOCK SHOWN WOULD HANDLE THE LAST FOUR CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.

25 PAIR	CDF	BLOCK
26	---	---
1	---	---
27	---	---
2	---	---
28	---	---
3	---	---
29	---	---
4	---	---
30	---	---
5	---	---
31	---	---
6	---	---
32	---	---
7	---	---
33	---	---
8	---	---
34	---	---
9	---	---
35	---	---
10	---	---
36	---	---
11	---	---
37	---	---
12	---	---
38	---	---
13	---	---
39	---	---
14	---	---
40	---	---
15	---	---
41	---	---
16	---	---
42	---	---
17	---	---
43	---	---
18	---	---
44	---	---
19	---	---
45	---	---
20	---	---
46	---	---
21	---	---
47	---	---
22	---	---
48	---	---
23	---	---
49	---	---
24	---	---
50	---	---
25	---	---



CS-10 AND CS-20 TYPICAL CROSS CONNECTION



BLF/DSS - DON'T REALLY NEED TIP ONLY DATA, BUT RUN BOTH

1.54



IF ATT MORE THAN 300' FROM SWITCH, MUST USE ANOTHER DATA PAIR FROM ANOTHER PORT FROM 8EKC CARD, ADDS COPPER LESSENS RESISTANCE TIE ON 3RD PAIR OF MOD. JACK


3 PR JACKS

Single Line Telephone Installation




GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A SINGLE LINE TELEPHONE.
- EACH SINGLE LINE TELEPHONE REQUIRES ONLY ONE PAIR OF WIRES FOR TIP AND RING. ON THE CDF TERMINAL BLOCK, ONLY EVERY OTHER PAIR OF WIRES IS USED.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR AN 8SLC INTERFACE CARD IN SLOT 02, USING CABLE NUMBER (CN) 1. CONNECTOR BLOCK SHOWN WOULD HANDLE ALL EIGHT CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



25 PAIR	CDF	BLOCK
26	-	-
1	-	-
27	-	-
2	-	-
28	-	-
3	-	-
29	-	-
4	-	-
30	-	-
5	-	-
31	-	-
6	-	-
32	-	-
7	-	-
33	-	-
8	-	-
34	-	-
9	-	-
35	-	-
10	-	-
36	-	-
11	-	-
37	-	-
12	-	-
38	-	-
13	-	-
39	-	-
14	-	-
40	-	-
15	-	-
41	-	-
16	-	-
42	-	-
17	-	-
43	-	-
18	-	-
44	-	-
19	-	-
45	-	-
20	-	-
46	-	-
21	-	-
47	-	-
22	-	-
48	-	-
23	-	-
49	-	-
24	-	-
50	-	-
25	-	-

25 PAIR CABLE






DIV - 8DTC CARD
SINGLE PAIR



CSD Telephone Installation

GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CSD TELEPHONE.
- EACH CSD TELEPHONE REQUIRES ONLY ONE PAIR OF WIRES FOR TIP AND RING (SIMILAR TO SLT CROSS CONNECTIONS). ON THE CDF TERMINAL BLOCK, ONLY EVERY OTHER PAIR OF WIRES IS USED.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR AN 8DTC INTERFACE CARD IN SLOT 00, USING CABLE NUMBER (CN) 0. CONNECTOR BLOCK SHOWN WOULD HANDLE ALL EIGHT CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN OF STUDENT WORKBOOK, INSTALLATION MODULE FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



25 PAIR CABLE


TYPICAL CSD CROSS CONNECTION

CO Trunk Installation




GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CO TRUNK.
- EACH CO TRUNK FROM A 4BWC CARD REQUIRES ONLY ONE PAIR OF WIRES FOR TIP AND RING. EACH 4BWC CARD HAS FOUR CIRCUITS AND ON THE CDF TERMINAL BLOCK, ONLY EVERY OTHER PAIR OF WIRES IS USED.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR A 4BWC INTERFACE CARD IN SLOT 06, USING CABLE NUMBER (CN) 4. CONNECTOR BLOCK SHOWN WOULD HANDLE ALL FOUR CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE, USING 26/1, 28/3, 30/5, AND 32/7 FOR EACH CIRCUIT.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



25 PAIR	CDF	BLOCK
26	-	-
1	-	-
27	-	-
2	-	-
28	-	-
3	-	-
29	-	-
4	-	-
30	-	-
5	-	-
31	-	-
6	-	-
32	-	-
7	-	-
33	-	-
8	-	-
34	-	-
9	-	-
35	-	-
10	-	-
36	-	-
11	-	-
37	-	-
12	-	-
38	-	-
13	-	-
39	-	-
14	-	-
40	-	-
15	-	-
41	-	-
16	-	-
42	-	-
17	-	-
43	-	-
18	-	-
44	-	-
19	-	-
45	-	-
20	-	-
46	-	-
21	-	-
47	-	-
22	-	-
48	-	-
23	-	-
49	-	-
24	-	-
50	-	-
25	-	-







Loop Tie Trunk Installation

GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A LOOP TIE TRUNK.
- EACH LOOP TIE TRUNK FROM A 2TTL CARD REQUIRES ONLY ONE PAIR OF WIRES FOR TIP AND RING. EACH 2TTL CARD HAS TWO CIRCUITS.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR A 2TTL INTERFACE CARD IN SLOT 08, USING CABLE NUMBER (CN) 5. CONNECTOR BLOCK SHOWN WOULD HANDLE BOTH CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE, USING PINS 34/9 FOR THE FIRST CIRCUIT AND 36/11 FOR THE SECOND CIRCUIT.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



25 PAIR	CDF	BLOCK
26	-	-
1	-	-
27	-	-
2	-	-
28	-	-
3	-	-
29	-	-
4	-	-
30	-	-
5	-	-
31	-	-
6	-	-
32	-	-
7	-	-
33	-	-
8	-	-
34	-	-
9	-	-
35	-	-
10	-	-
36	-	-
11	-	-
37	-	-
12	-	-
38	-	-
13	-	-
39	-	-
14	-	-
40	-	-
15	-	-
41	-	-
16	-	-
42	-	-
17	-	-
43	-	-
18	-	-
44	-	-
19	-	-
45	-	-
20	-	-
46	-	-
21	-	-
47	-	-
22	-	-
48	-	-
23	-	-
49	-	-
24	-	-
50	-	-
25	-	-





E&M (Type I) Tie Trunk Installation



GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A E&M (TYPE I) TIE TRUNK.
- EACH TYPE I E&M TRUNK FROM A 2TTE CARD REQUIRES TWO PAIR OF WIRES. ONE PAIR FOR TIP AND RING, THE OTHER PAIR FOR E (RECEIVE) AND M (TRANSMIT). EACH 2TTE CARD HAS TWO CIRCUITS.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR A 2TTE INTERFACE CARD IN SLOT 08, USING CABLE NUMBER (CN) 5. CONNECTOR BLOCK SHOWN WOULD HANDLE BOTH CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE, USING PINS 34/9, 35/10 FOR THE FIRST CIRCUIT AND 38/13, 39/14 FOR THE SECOND CIRCUIT.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.

25 PAIR CDF BLOCK







E&M (Type II) Tie Trunk Installation

GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A E&M (TYPE II) TIE TRUNK.
- EACH TYPE II E&M TRUNK FROM A 2TTE CARD REQUIRES THREE PAIR OF WIRES. ONE PAIR FOR TIP AND RING, THE OTHER FOUR WIRES FOR SIGNAL GROUND, E (RECEIVE), M (TRANSMIT), AND SIGNAL BATTERY. EACH 2TTE CARD HAS TWO CIRCUITS.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR A 2TTE INTERFACE CARD IN SLOT 06, USING CABLE NUMBER (CN) 4. CONNECTOR BLOCK SHOWN WOULD HANDLE BOTH CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE, USING PINS 26/1, 28/3, 29/4 FOR THE FIRST CIRCUIT AND 30/5, 32/7, AND 33/8 FOR THE SECOND CIRCUIT.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



25 PAIR
CABLE

CDF Cross Connect Reference Chart



GTE OMNI SBCS

CARD SLOT	CABLE NUMBER	CIRCUIT NUMBER	AMP CONN	CDF CABLE COLOR	8SLC	8EKC	8BTC	4BWC	2TTE (TYPE I)	2TTE (TYPE II)	2TTL	NOTES:			
00 03 06 09 12	0 2 4 6 8	0	26	WHT-BLU	TIP 0	TIP 0	TIP 0	TIP 0	TIP 0	TIP 0	TIP 0	<ul style="list-style-type: none"> • 8SLC, 8EKC, AND 8BTC CARDS CANNOT BE INSERTED IN SLOTS 15, 16, 17, AND 18. • 8BTC ONLY CAN BE INSERTED IN SLOTS 00, 03, 06, 09, AND 12 WHEN USED FOR VOICE/DATA (DTA OPTION). • 4BWC, 2TTE, AND 2TTL CANNOT BE INSERTED IN SLOTS 00, 01, 02, 03, 04, OR 05. • MAXIMUM NUMBER OF TIE TRUNKS IN SYSTEM IS 12. 			
		1	27	BLU-WHT	RING 0	RING 0	RING 0	RING 0	RING 0	RING 0	RING 0				
		2	28	WHT-ORN	1	ORN-WHT	TIP 1 RING 1	DATA	TIP 1 RING 1	TIP 1 RING 1	SG E M SB		TIP 1 RING 1		
		3	29	WHT-GRN		ORN-WHT		DATA							
		4	30	GRN-WHT	2	WHT-BRN	TIP 2 RING 2	DATA	TIP 2 RING 2	TIP 2 RING 2	TIP 1 RING 1		TIP 1 RING 1		
		5	31	WHT-SL		SL-WHT		DATA							
		6	32	RED-BLU	3	BLU-RED	TIP 3 RING 3	DATA	TIP 3 RING 3	TIP 3 RING 3	SG E M SB		----		
		7	33	RED-ORN		ORN-RED		DATA							
		8	34	ORN-RED	4	RED-GRN	TIP 4 RING 4	ORN-RED	TIP 4 RING 4	----	----		----		
		9	35	GRN-RED		BRN-RED		DATA							
		01 04 07 10 13	0 2 4 6 8	10	36	RED-SL	5	SL-RED	TIP 5 RING 5	----	----		----	----	
				11	37	BLK-BLU		BLU-BLK							DATA
				12	38	BLU-BLK	6	ORN-BLK	TIP 6 RING 6	DATA	TIP 6 RING 6		----	----	----
				13	39	BLK-GRN		GRN-BLK		DATA					
				14	40	GRN-BLK	7	BLK-BRN	TIP 7 RING 7	DATA	TIP 7 RING 7		----	----	----
				15	41	BRN-BLK		BLK-SL		DATA					
				16	42	SL-BLK	0	YEL-BLU	TIP 0 RING 0	DATA	TIP 0 RING 0		TIP 0 RING 0	TIP 0 RING 0	TIP 0 RING 0
				17	43	YEL-BLU		BLU-YEL		DATA					
				18	44	YEL-ORN	1	ORN-YEL	TIP 1 RING 1	TIP 0	TIP 1 RING 1		TIP 0 RING 0	TIP 0 RING 0	TIP 0 RING 0
				19	45	YEL-ORN		ORN-YEL		DATA					
		20	46	GRN-YEL	2	YEL-GRN	TIP 2 RING 2	DATA	TIP 2 RING 2	TIP 1 RING 1	TIP 1 RING 1		TIP 1 RING 1		
		21	47	GRN-YEL		YEL-GRN		DATA							
		22	48	YEL-BRN	3	BRN-YEL	TIP 3 RING 3	DATA	TIP 3 RING 3	----	SG E M SB		----		
		23	49	BRN-YEL		YEL-SL		DATA							
		24	50	SL-YEL	2	VIO-BLU	TIP 2 RING 2	DATA	TIP 2 RING 2	TIP 1 RING 1	TIP 1 RING 1		TIP 1 RING 1		
25	51	VIO-BLU	BLU-VIO	DATA											
26	52	VIO-ORN	3	ORN-VIO	TIP 3 RING 3	DATA	TIP 3 RING 3	----	SG E M SB	----					
27	53	VIO-ORN		VIO-GRN		DATA									
28	54	GRN-VIO	4	VIO-BRN	TIP 4 RING 4	DATA	TIP 4 RING 4	----	SG E M SB	----					
29	55	VIO-BRN		BRN-VIO		DATA									
30	56	BRN-VIO	5	VIO-SL	TIP 5 RING 5	DATA	TIP 5 RING 5	----	SG E M SB	----					
31	57	VIO-SL		SL-VIO		DATA									

CDF Cross Connect Reference Chart (Continued)



GTE OMNI SBCS

CARD SLOT	CABLE NUMBER	CIRCUIT NUMBER	AMP CONN	CDF CABLE COLOR	8SLC	8EKC	8DTC	4BWC	2TTE (TYPE I)	2TTE (TYPE II)	2TTL	NOTES:
		4	26	WHT-BLU	TIP 4	TIP 4	TIP 4	----	----	----	----	<ul style="list-style-type: none"> • 8SLC, 8EKC, AND 8DTC CARDS CANNOT BE INSERTED IN SLOTS 15, 16, 17, AND 18. • 8DTC ONLY CAN BE INSERTED IN SLOTS 00, 03, 06, 09, AND 12 WHEN USED FOR VOICE/DATA (DATA OPTION). • 4BWC, 2TTE, AND 2TTL CANNOT BE INSERTED IN SLOTS 00, 01, 02, 03, 04, OR 05. • MAXIMUM NUMBER OF TIE TRUNKS IN SYSTEM IS 12.
			1	BLU-WHT	RING 4	RING 4	RING 4					
			27	WHT-ORN		DATA						
			2	ORN-WHT		DATA						
01	1	5	28	WHT-GRN	TIP 5	TIP 5	TIP 5	----	----	----	----	
04	3		3	GRN-WHT	RING 5	RING 5	RING 5					
07	5		29	WHT-BRN		DATA						
10	7		4	BRN-WHT		DATA						
13	9	6	30	WHT-SL	TIP 6	TIP 6	TIP 6	----	----	----	----	
			5	SL-WHT	RING 6	RING 6	RING 6					
			31	RED-BLU		DATA						
			6	BLU-RED		DATA						
		7	32	RED-ORN	TIP 7	TIP 7	TIP 7	----	----	----	----	
12	8		7	ORN-RED	RING 7	RING 7	RING 7					
			33	RED-GRN		DATA						
			8	GRN-RED		DATA						
		0	34	RED-BRN	TIP 0	TIP 0	TIP 0	TIP 0	TIP 0	TIP 0	TIP 0	
			9	BRN-RED	RING 0	RING 0	RING 0	RING 0	RING 0	RING 0	RING 0	
			35	RED-SL		DATA			M	M		
			10	SL-RED		DATA			E	E		
		1	36	BLK-BLU	TIP 1	TIP 1	TIP 1	TIP 1		SE	TIP 1	
			11	BLU-BLK	RING 1	RING 1	RING 1	RING 1		E	RING 1	
			37	BLK-ORN		DATA				M		
			12	ORN-BLK		DATA				SB		
		2	38	BLK-GRN	TIP 2	TIP 2	TIP 2	TIP 2	TIP 1	TIP 1	----	
02	1		13	GRN-BLK	RING 2	RING 2	RING 2	RING 2	RING 1	RING 1		
05	3		39	BLK-BRN		DATA			M	M		
08	3		14	BRN-BLK		DATA			E	E		
11	7	3	40	BLK-SL	TIP 3	TIP 3	TIP 3	TIP 3		SG	----	
14	9		15	SL-BLK	RING 3	RING 3	RING 3	RING 3		E		
			41	YEL-BLU		DATA				M		
			16	BLU-YEL		DATA				SB		
		4	42	YEL-ORN	TIP 4	TIP 4	TIP 4	----	----	----	----	
			17	ORN-YEL	RING 4	RING 4	RING 4					
			43	YEL-GRN		DATA						
			18	GRN-YEL		DATA						
		5	44	YEL-BRN	TIP 5	TIP 5	TIP 5	----	----	----	----	
			19	BRN-YEL	RING 5	RING 5	RING 5					
			45	YEL-SL		DATA						
			20	SL-YEL		DATA						
		6	46	VIO-BLU	TIP 6	TIP 6	TIP 6	----	----	----	----	
			21	BLU-VIO	RING 6	RING 6	RING 6					
			47	VIO-ORN		DATA						
			22	ORN-VIO		DATA						
		7	48	VIO-GRN	TIP 7	TIP 7	TIP 7	----	----	----	----	
			23	GRN-VIO	RING 7	RING 7	RING 7					
			49	VIO-BRN		DATA						
			24	BRN-VIO		DATA						
			50	VIO-SL								
			25	SL-VIO								

CDF Cross Connect Reference Chart (Continued)



GTE OMNI SBCS

CARD SLOT	CABLE NUMBER	CIRCUIT NUMBER	AMP CONN	CDF CABLE COLOR	8SLC	8EKC	8DTC	4BWC	2TTE (TYPE I)	2TTE (TYPE II)	2TTL	NOTES:		
15	10	0	26	WHT-BLU	----	----	----	TIP 0	TIP 0	TIP 0	TIP 0	<ul style="list-style-type: none"> • 8DTC ONLY CAN BE INSERTED IN SLOTS 00, 03, 06, 09, AND 12 WHEN USED FOR VOICE/DATA (OTA OPTION). • 8SLC, 8EKC, AND 8DTC CARDS CANNOT BE INSERTED IN SLOTS 15, 16, 17, AND 18. • 4BWC, 2TTE, AND 2TTL CANNOT BE INSERTED IN SLOTS 00, 01, 02, 03, 04, OR 05. • MAXIMUM NUMBER OF TIE TRUNKS IN SYSTEM IS 12. 		
			1	BLU-WHT				RING 0	RING 0	RING 0	RING 0			
			27	WHT-ORN										
		1	2	ORN-WHT										
			28	WHT-GRN	----	----	----	TIP 1			SG		TIP 1	
			3	GRN-WHT				RING 1			E		RING 1	
		2	29	WHT-BRN										
			4	BRN-WHT										
			30	WHT-SL	----	----	----	TIP 2			TIP 1		TIP 1	
		3	5	SL-WHT							RING 1		RING 1	
			31	RED-BLU										
			6	BLU-RED							M			
		0	32	RED-ORN	----	----	----	TIP 3						
			7	ORN-RED									SG	
			33	RED-GRN									E	
0	8	GRN-RED								M				
	34	RED-BRN	----	----	----	TIP 0			TIP 0	TIP 0				
	9	BRN-RED									RING 0			
1	35	RED-SL												
	10	SL-RED												
	36	BLK-BLU	----	----	----	TIP 1				SG	TIP 1			
2	11	BLU-BLK								E	RING 1			
	37	BLK-ORN								M				
	12	ORN-BLK								SB				
3	38	BLK-GRN	----	----	----	TIP 2			TIP 1	TIP 1				
	13	GRN-BLK							RING 1	RING 1				
	39	BLK-BRN												
0	14	BRN-BLK												
	40	BLK-SL	----	----	----	TIP 3				SG				
	15	SL-BLK								E				
1	41	YEL-BLU								M				
	16	BLU-YEL								SB				
	42	YEL-ORN	----	----	----	TIP 0			TIP 0	TIP 0				
2	17	ORN-YEL									RING 0			
	43	YEL-GRN												
	18	GRN-YEL												
3	44	YEL-BRN	----	----	----	TIP 1				SG	TIP 1			
	19	BRN-YEL								E	RING 1			
	45	YEL-SL								M				
0	20	SL-YEL								SB				
	46	VIO-BLU	----	----	----	TIP 2			TIP 1	TIP 1				
	21	BLU-VIO												
1	47	VIO-ORN												
	22	ORN-VIO												
	48	VIO-GRN	----	----	----	TIP 3				SG				
2	23	GRN-VIO								E				
	49	VIO-BRN								M				
	24	BRN-VIO								SB				
3	50	VIO-SL	----	----	----									
	25	SL-VIO												

CDF Cross Connect Reference Chart (Continued)



GTE OMNI SBCS

CARD SLOT	CABLE NUMBER	CIRCUIT NUMBER	AMP CONN	CDF CABLE COLOR	8SLC	8EKC	8DTC	4BWC	2TTE ₁	2TTE ₂	2TTL	NOTES:		
18	11	0	26	WHT-BLU	----	----	----	TIP 0	TIP 0	TIP 0	TIP 0	<ul style="list-style-type: none"> • 8SLC, 8EKC AND 8DTC CARDS CANNOT BE INSERTED IN SLOTS 15, 16, AND 17. • 2TTE₁ IS FOR TYPE I SIGNALING. • 2TTE₂ IS FOR TYPE II SIGNALING. • MAXIMUM NUMBER OF TIE TRUNKS IN SYSTEM IS 12. PINS 34 AND 9 CAN BE USED FOR REMOTE MINOR ALARM (DRY CONTACT ONLY). • PINS 35 AND 10 CAN BE USED FOR REMOTE MAJOR ALARM. (DRY CONTACT ONLY). 		
			1	1	27	BLU-WHT				RING 0	RING 0		RING 0	
			2	2	28	WHT-ORN								
		1	28	3	ORN-WHT	----	----	----	TIP 1		SG		TIP 1	
				4	WHT-GRN				RING 1		E		RING 1	
				5	GRN-WHT						M			
		2	29	6	WHT-BRN	----	----	----	TIP 2	TIP 1	M		TIP 1	
				7	BRN-WHT				RING 2	RING 1	E		RING 1	
				8	WHT-SL									
		3	30	9	SL-WHT	----	----	----	TIP 3					
				10	RED-BLU				RING 3					
				11	BLU-RED									
		01	0	1	12	RED-ORN	----	----	----				SG	
					13	ORN-RED							E	
					14	RED-GRN							M	
					15	GRN-RED							SB	
					16	RED-BRN								
					17	BRN-RED								
					18	RED-SL								
					19	SL-RED								
					20	BLK-BLU								
					21	BLU-BLK								
					22	BLK-ORN								
					23	ORN-BLK								
					24	BLK-GRN								
					25	GRN-BLK								
					26	BLK-BRN								
		27	BRN-BLK											
		28	BLK-SL											
		29	SL-BLK											
		30	YEL-BLU											
		31	BLU-YEL											
		32	YEL-ORN											
		33	ORN-YEL											
		34	YEL-GRN											
35	GRN-YEL													
36	YEL-BRN													
37	BRN-YEL													
38	YEL-SL													
39	SL-YEL													
40	VIO-BLU													
41	BLU-VIO													
42	VIO-ORN													
43	ORN-VIO													
44	VIO-GRN													
45	GRN-VIO													
46	VIO-BRN													
47	BRN-VIO													
48	VIO-SL													
49	SL-VIO													

Optional Power Fail Transfer Installation






GTE OMNI SBCS

- THIS SLIDE REPRESENTS A TYPICAL EXAMPLE OF HOW THE CROSS CONNECTIONS WOULD BE MADE FOR A POWER FAIL TRANSFER STATION.
- EXAMPLE ILLUSTRATES THE 6PFT CARD WHEN INSTALLED IN CARD SLOT 22 AND THE CABLE IN CALBE NUMBER 12.
- EACH 6PFT CARD HAS SIX CIRCUITS AND USES FOUR PAIRS OF WIRES FOR EACH POWER FAIL CIRCUIT.

CN	CS	CONNECTING BLOCK PINS
12	22	CO LINE 28.1
		4BWC 27.2
		STATION 28.3
		8SLC 29.4

- ONE CONNECTOR BLOCK WILL HANDLE ALL SIX CIRCUITS.






Portable Maintenance Panel Installation


GTE OMNI SBCS

THE PINS ARE
 REVERSE BATTERY
 BUT REMOVE PINS
 INTO A/C SO
 BATTERY WON'T
 BE DAMAGED



8 PIN MALE DIN CONNECTOR

25 PIN MALE DB25 CONNECTOR



1.66

Circle 13

SCREEN SHOULD BE DISPLAYED.
 CONFIGURATION PROMPT

- (3) POWER EPSON ON AND PORT CABLE TO PORT ON EPSON HX20.
- (2) CONNECT 8PIN DIN CONNECTION OF 715 CABLE TO I/O 0 ON OMNI SBCS.
- (1) CONNECT DB25 CONNECTION OF 715

PROCEDURE

DISKETTE.
 MICROCASSETTE TAPE OR FLOPPY

- PMP PROGRAM RESIDES IN PMP MEMORY, BACKED UP ON
- BAUD RATE IS SET TO 1200 BAUD.
- EITHER PORT 0 OR PORT 1. (PMP) MAY BE CONNECTED TO PORT 0 - SERIAL
- PORTABLE MAINTENANCE PANEL

Optional Floppy Diskette Drive Installation




GTE OMNI SBCS


INSTALLATION PROCEDURE:

- (1) SET BIT 4 OF PMP'S DIP SWITCH TO ON POSITION. DIP SWITCH IS LOCATED ON BOTTOM OF PMP.
- (2) ENSURE THAT PMP AND TF-20 POWER SWITCHES ARE OFF.
- (3) USING #707 CABLE, CONNECT PMP SERIAL INTERFACE CONNECTOR FROM PMP TO 6-PIN SERIAL INTERFACE CONNECTOR PORT IN REAR OF TF-20.
- (4) CONNECT PMP'S CABLE #715 FROM BACK DIN CONNECTOR PORT IN REAR OF PMP TO RS-232-C PORT I/O 0 ON OMNI SBCS.
- (5) POWER ON TF-20 DRIVE BEFORE TURNING ON PMP POWER SWITCH.


NOTE: REFER TO DATA BASE ADMINISTRATION MODULE OF STUDENT WORKBOOK (MODULE II) FOR PMP START-UP, INITIALIZATION AND OPERATION WITH INSTALLED FLOPPY DISKETTE DRIVE UNIT.



LOCATION OF PMP DIP SWITCHES





DIP SWITCH SETTINGS FOR OPERATION WITH FLOPPY DISKETTE DRIVE



Optional SMDR Printer Installation



GTE OMNI SBCS



CABLE 14

INSTALLATION PROCEDURE:

- (1) CONNECT PRINTER CABLE TO I/O PORT 1
- (2) BE SURE PORT CONFIGURATION MATCHES THE REQUIREMENTS OF THE PRINTER:
 - 300 BAUD
 - 1 STOP BIT
 - EVEN PARITY
 - ECHO OFF
 - 7 BIT WORD



NOTE: REFER TO GTEP MANUAL FOR RS-232-C PORT CONFIGURATION AND SMDR PRINTER CABLE REQUIREMENTS

Optional Night Bell Installation



GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CUSTOMER-SUPPLIED NIGHT BELL.
- A NIGHT BELL REQUIRES ONE PAIR OF WIRES FOR ITS INTERFACE TO AN 8SLC CARD (SAME AS SLT INSTALLATION). EVERY OTHER PAIR OF PINS IS USED ON THE CONNECTING BLOCK.
- EXAMPLE ILLUSTRATES A NIGHT BELL CDF CROSS CONNECTION FOR AN 8SLC CARD IN SLOT 01, USING CABLE NUMBER (CN) 1. CONNECTOR BLOCK SHOWN WOULD HANDLE FOUR OF THE EIGHT CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.





Optional Music-on-Hold Installation



GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CUSTOMER-SUPPLIED MUSIC SOURCE.
- MUSIC-ON-HOLD REQUIRES ONE PAIR OF WIRES FOR ITS INTERFACE TO A 4BWC CARD (SAME AS CO TRUNK INSTALLATION). EACH 4BWC CARD HAS FOUR CIRCUITS AND ONLY EVERY OTHER PAIR OF PINS IS USED ON THE CONNECTING BLOCK.
- EXAMPLE ILLUSTRATES A MUSIC SOURCE CDF CROSS CONNECTION FOR A 4BWC CARD IN SLOT 07, USING CABLE NUMBER (CN) 4. CONNECTOR BLOCK SHOWN WOULD HANDLE ALL FOUR CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



LIKE C.O. TRUNK INSTALL
ON 4BWC CARD



Laboratory Activity (1.3) – Peripheral Installation



GTE OMNI SBCS

- (1) USING 25 PAIR CABLES WITH MALE CONNECTORS ON ONE END, CONNECT FIVE CABLES TO THE FOLLOWING RECEPTACLES: CN 0, CN 1, CN 10, CN 11, CN 12.
- (2) RUN CABLES NEATLY FROM THE OMNI SBCS CABINET USING SCREWS TO FASTEN THE CONNECTORS TIGHTLY TO THE RECEPTACLES. CONNECT EACH CABLE TO THE CDF BLOCK DESIGNATED BELOW:
 - (A) CN 0 - FIRST STATION CDF BLOCK
 - (B) CN 1 - SECOND STATION CDF BLOCK
 - (C) CN 10 - FIRST STATION CDF BLOCK
 - (D) CN 11 - SECOND STATION CDF BLOCK
 - (E) CN 12 - POWER FAIL TRANSFER CDF BLOCK
- (3) ENSURE THAT CDF BLOCKS ARE MOUNTED TO THE WALL. MARK EACH CABLE FOR EASY IDENTIFICATION.

LAB MILESTONE:

- VERIFY THAT ALL CDF CABLES ARE INSTALLED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT INSTALLATION OF CABLES AND INITIAL YOUR PERFORMANCE CHECKLIST.
- TURN TO REVIEW EXERCISE 1.3 AND ANSWER QUESTIONS 1-3.

Laboratory Activity (1.3) – Peripheral Installation (Continued)



GTE OMNI SBCS

- (4) WIRE CROSS CONNECTIONS AND INSTALL THE FOLLOWING STATION INSTRUMENTS USING THE DESIGNATED CONFIGURATIONS:
- ✓ (A) CS-10 TELEPHONE USING 8EKC CARD IN SLOT 01, CIRCUIT 0. DEFAULT STATION DIRECTORY NUMBER WILL BE 208. DO NOT CONNECT THIS STATION TO THE MODULAR JACK AT THIS TIME. IT WILL BE ADDED DURING A DATA BASE PROGRAMMING LAB ACTIVITY.
 - ✓ (B) CS-10 TELEPHONE USING 8EKC CARD IN SLOT 01, CIRCUIT 7. DEFAULT STATION DIRECTORY NUMBER WILL BE 215.
 - ✓ (C) CS-20 TELEPHONE USING 8EKC CARD IN SLOT 01, CIRCUIT 4. DEFAULT STATION DIRECTORY NUMBER WILL BE 212.
 - ✓ (D) CS-20 TELEPHONE USING 8EKC CARD IN SLOT 01, CIRCUIT 6. DEFAULT STATION DIRECTORY NUMBER WILL BE 214.
 - ✓ (E) BLF/DSS CONSOLE USING 8EKC CARD IN SLOT 01, CIRCUIT 5. BLF/DSS WILL BE CONNECTED TO CS-20 TELEPHONE AT DIRECTORY NUMBER 212.
 - ✓ (F) BLF/DSS CONSOLE USING 8EKC CARD IN SLOT 01, CIRCUIT 3. DO NOT CONNECT THIS BLF/DSS AT THIS TIME. IT WILL BE ADDED DURING A DATA BASE PROGRAMMING LAB ACTIVITY. THIS BLF/DSS WILL BE CONNECTED IN FUTURE TO THE CS-20 TELEPHONE AT DIRECTORY NUMBER 214.
 - ✓ (G) SINGLE LINE TELEPHONE INSTRUMENT USING 8SLC CARD IN SLOT 02, CIRCUIT 0. THIS DIRECTORY NUMBER WILL BE 216.
 - ✓ (H) SINGLE LINE TELEPHONE INSTRUMENT USING 8SLC CARD IN SLOT 02, CIRCUIT 7. DEFAULT STATION DIRECTORY NUMBER WILL BE ~~223~~ 217.
 - ✓ (I) CSD TELEPHONE USING 8DTC CARD IN SLOT 00, CIRCUIT 0. DEFAULT STATION DIRECTORY NUMBER WILL BE 200.
 - ✓ (J) CSD TELEPHONE USING 8DTC CARD IN SLOT 00, CIRCUIT 1. DEFAULT STATION DIRECTORY NUMBER WILL BE 201.
- (5) LABEL EACH INSTRUMENT WITH THE APPROPRIATE STATION DIRECTORY NUMBER AND EQUIPMENT NUMBER (CARD SLOT AND CIRCUIT NUMBER).

LAB MILESTONE:

- VERIFY THAT ALL STATION CROSS CONNECTIONS ARE WIRED AND THAT STATION INSTRUMENTS ARE INSTALLED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT CROSS CONNECTIONS AND STATION INSTALLATION AND INITIAL YOUR PERFORMANCE CHECKLIST.
- TURN TO REVIEW EXERCISE 1.3 AND ANSWER QUESTIONS 4-6

Laboratory Activity (1.3) — Peripheral Installation (Continued)



GTE OMNI SBCS

- (6) WIRE CROSS CONNECTIONS FOR THE POWER FAIL TRANSFER STATION:
- (A) SINGLE LINE TELEPHONE INSTRUMENT USING 8SLC CARD IN SLOT 02, CIRCUIT 0 TO POWER FAIL TRANSFER CDF BLOCK.
 - (B) POWER FAIL TRANSFER CARD (6PFT) IN SLOT 22, CIRCUIT 0 TO CO TRUNK ON 4BWC CARD IN SLOT 18, CIRCUIT 0.

LAB MILESTONE:

- VERIFY THAT POWER FAIL TRANSFER CROSS CONNECTIONS ARE WIRED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT THE CROSS CONNECTIONS AND INITIAL YOUR PERFORMANCE CHECKLIST.
- TURN TO REVIEW EXERCISE 1.3 AND ANSWER QUESTION 7.

Laboratory Activity (1.3) – Peripheral Installation (Continued)



GTE OMNI SBCS

- (7) VERIFY THAT POWER FAIL TRANSFER TRUNKS HAVE BEEN INSTALLED FROM CARD SLOT 18, CIRCUIT 0. WIRE CROSS CONNECTIONS AND INSTALL THE FOLLOWING TRUNK LINES USING THE DESIGNATED CONFIGURATIONS:
- (A) THREE ADDITIONAL CO TRUNK LINES USING 4BWC CARD IN SLOT 18, CIRCUITS 1, 2, AND 3.
 - (B) TWO LOOP TIE LINES USING 2TTL CARD IN SLOT 16, CIRCUITS 0 AND 1. THESE TIE LINES WILL BE USED TO ACCESS OTHER OMNI SBCS LAB SYSTEMS. INSTRUCTOR WILL PROVIDE INSTRUCTIONS REGARDING CONNECTION.
 - (C) TWO E&M TIE LINE (TYPE II) USING 2TTE CARD IN SLOT 17, CIRCUITS 0 AND 1. THESE TIE LINES WILL BE USED TO ACCESS OTHER OMNI SBCS LAB SYSTEMS. INSTRUCTOR WILL PROVIDE INSTRUCTIONS REGARDING CONNECTIONS.

LAB MILESTONE:

- VERIFY THAT ALL TRUNK LINE CROSS CONNECTIONS ARE WIRED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT CROSS CONNECTIONS AND INITIAL YOUR PERFORMANCE CHECKLIST.
- TURN TO REVIEW EXERCISE 1.3 AND ANSWER QUESTION 8. SUBMIT YOUR COMPLETED REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.

Laboratory Activity (1.3) — Peripheral Installation (Continued)



GTE OMNI SBCS

- (8) CONNECT PORTABLE MAINTENANCE PANEL (PMP) TO OMNI SBCS CABINET. CONNECT DIN PLUG OF EPSON CABLE #715 TO PORT MARKED "RS-232-C" ON BACK OF PMP. CONNECT DB-25 CONNECTOR END OF CABLE TO PORT CN13 (I/O 0) ON THE SBCS CABINET.
- (9) ENSURE THAT BOTH OMNI SBCS AND PMP POWER SWITCHES ARE OFF.
- (10) INSTALL FLOPPY DISKETTE UNIT TO PMP USING PROCEDURE FOUND IN THE STUDENT WORKBOOK. DO NOT POWER ON THE PMP OR FLOPPY DISKETTE DRIVE UNIT UNTIL INSTRUCTED TO DO SO DURING THE INITIALIZATION LAB ACTIVITY.
- (11) CONNECT SMDR PRINTER CABLE TO PORT CN14 (I/O 1) ON THE SBCS CABINET. INSTRUCTOR WILL PROVIDE SPECIAL INSTRUCTIONS RELATING TO TYPE OF PRINTER BEING INSTALLED. PORT CONFIGURATION REQUIREMENTS WILL BE DISCUSSED DURING THE DATA BASE ADMINISTRATION MODULE OF THIS COURSE. DO NOT POWER ON SMDR PRINTER UNTIL DIRECTED TO DO SO.

LAB MILESTONE:

- VERIFY THAT PORTABLE MAINTENANCE PANEL, FLOPPY DISKETTE DRIVE, AND SMDR PRINTER ARE CORRECTLY INSTALLED.
- ASK INSTRUCTOR TO INSPECT THESE INSTALLATIONS AND INITIAL YOUR PERFORMANCE CHECKLIST.
- TURN TO REVIEW EXERCISE 1.3 AND ANSWER QUESTIONS 9-12. SUBMIT YOUR COMPLETED REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.
- YOU HAVE NOW COMPLETED THE BASIC PERIPHERAL INSTALLATION LAB ACTIVITY.

Optional Laboratory Activity (1.3) — Peripheral Installation



GTE OMNI SBCS

COMPLETE ALL OR PART OF THE FOLLOWING ACTIVITY IF TIME PERMITS OR IF INSTRUCTOR DIRECTS YOU TO DO SO.

- (1) WIRE CROSS CONNECTIONS AND INSTALL ONE OR BOTH OF THE FOLLOWING OPTIONAL PERIPHERAL EQUIPMENT USING THE DESIGNATED CONFIGURATIONS BELOW:
 - (A) NIGHT BELL USING 8SLC CARD IN SLOT 02, CIRCUIT 3.
 - (B) MUSIC SOURCE FOR MUSIC-ON HOLD USING 4BWC CARD IN SLOT 18, CIRCUIT 2.

LAB MILESTONE:

- VERIFY THAT NIGHT BELL AND MUSIC SOURCE ARE WIRED AND INSTALLED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT CROSS CONNECTIONS AND INITIAL YOUR PERFORMANCE CHECKLIST.
- TURN TO REVIEW EXERCISE 1.3 AND ANSWER OPTIONAL QUESTIONS 13 AND 14. SUBMIT YOUR COMPLETED REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.
- YOU HAVE NOW COMPLETED THE OPTIONAL PERIPHERAL INSTALLATION LAB ACTIVITY.

Review Exercise (1.3) — Peripheral Installation



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, FILL IN THE BLANK OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. WHAT CARD SLOTS AND CIRCUITS DO THESE SYSTEM CABLES SUPPORT (ALL SPACES WILL NOT BE REQUIRED);

<u>CABLE</u>	<u>CARD SLOT / CIRCUITS</u>	<u>CARD SLOT / CIRCUITS</u>	<u>CARD SLOT / CIRCUITS</u>
0	_____	_____	_____
1	_____	_____	_____
10	_____	_____	_____
11	_____	_____	_____
12	_____	_____	_____

2. DESCRIBE THE FUNCTIONS OF CABLE NUMBER 12. _____
3. IF ALL CIRCUITS ON THE LINE AND TRUNK CARDS YOU INSTALLED WERE USED, HOW MANY STATIONS AND TRUNK LINES COULD ACTUALLY BE INSTALLED?


_____ STATIONS _____ TRUNKS

Review Exercise (1.3) – Peripheral Installation (Continued)



GTE OMNI SBCS

4. COMPLETE THE FOLLOWING DIAGRAM INDICATING THE CROSS CONNECTIONS THAT WERE MADE FOR THE SIX EKT TELEPHONES. ONE OF THE CS-10 TELEPHONES HAS BEEN COMPLETED, AS AN EXAMPLE.






Review Exercise (1.3) — Peripheral Installation (Continued)



GTE OMNI SBCS

5. COMPLETE THE FOLLOWING DIAGRAM INDICATING THE CROSS CONNECTIONS THAT WERE MADE FOR THE TWO SINGLE LINE TELEPHONES.



Review Exercise (1.3) – Peripheral Installation (Continued)



GTE OMNI SBCS

7. COMPLETE THE FOLLOWING DIAGRAM INDICATING THE CROSS CONNECTIONS THAT WERE MADE FOR THE POWER FAILURE TRANSFER INSTALLATION (INCLUDE TRUNK AND INSTRUMENT CROSS CONNECTIONS, AS WELL AS CROSS CONNECTIONS TO THE THREE CARDS).

CABLE 1
(TO 8SLC)

26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

CABLE 12
(TO 6PFT)

26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

CABLE 11
(TO 4BWC)

26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

Review Exercise (1.3) – Peripheral Installation (Continued)




GTE OMNI SBCS

6. COMPLETE THE FOLLOWING DIAGRAM INDICATING THE CROSS CONNECTIONS THAT WERE MADE FOR THE CSD TELEPHONES.


26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

CABLE 0

CSD (CKT0)



CSD (CKT1)



Review Exercise (1.3) – Peripheral Installation (Continued)



GTE OMNI SBCS

8. COMPLETE THE FOLLOWING DIAGRAMS INDICATING THE CROSS CONNECTIONS THAT WERE MADE FOR THE EIGHT TRUNKS THAT WERE INSTALLED (POWER FAIL, CO, LOOP TIE LINES, AND E&M TIE LINES).

CABLE 10

26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

CABLE 11

26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

CABLE 12

26	-	-	-	-
1	-	-	-	-
27	-	-	-	-
2	-	-	-	-
28	-	-	-	-
3	-	-	-	-
29	-	-	-	-
4	-	-	-	-
30	-	-	-	-
5	-	-	-	-
31	-	-	-	-
6	-	-	-	-
32	-	-	-	-
7	-	-	-	-
33	-	-	-	-
8	-	-	-	-
34	-	-	-	-
9	-	-	-	-
35	-	-	-	-
10	-	-	-	-
36	-	-	-	-
11	-	-	-	-
37	-	-	-	-
12	-	-	-	-
38	-	-	-	-
13	-	-	-	-
39	-	-	-	-
14	-	-	-	-
40	-	-	-	-
15	-	-	-	-
41	-	-	-	-
16	-	-	-	-
42	-	-	-	-
17	-	-	-	-
43	-	-	-	-
18	-	-	-	-
44	-	-	-	-
19	-	-	-	-
45	-	-	-	-
20	-	-	-	-
46	-	-	-	-
21	-	-	-	-
47	-	-	-	-
22	-	-	-	-
48	-	-	-	-
23	-	-	-	-
49	-	-	-	-
24	-	-	-	-
50	-	-	-	-
25	-	-	-	-

Review Exercise (1.3) — Peripheral Installation (Continued)



GTE OMNI SBCS

9. THE PMP MAY BE CONNECTED TO EITHER OMNI SBCS PORT _____ OR _____.
10. BEFORE THE FLOPPY DISKETTE DRIVE MAY BE INSTALLED, THE PMP REQUIRES THAT ADDITIONAL _____ MUST FIRST BE INSTALLED.
11. MATCH THE FOLLOWING TYPES OF CABLES TO THEIR APPROPRIATE CONNECTIONS:
_____ # 715 (A) FLOPPY DISKETTE DRIVE UNIT TO PMP
_____ # 707 (B) PMP TO OMNI SBCS PORT
12. THE SMDR PRINTER IS INSTALLED IN WHAT OMNI SBCS PORT? _____

OPTIONAL PERIPHERAL QUESTIONS (NIGHT BELL AND MUSIC-ON-HOLD INSTALLATION)

13. NIGHT BELL INSTALLATION REQUIRES _____ WIRES, CROSS CONNECTED TO A _____ INTERFACE CARD.
14. MUSIC-ON-HOLD USING A CUSTOMER-PROVIDED MUSIC SOURCE REQUIRES _____ WIRES, CROSS CONNECTED TO A _____ INTERFACE CARD.



GTE OMNI SBCS

SYSTEM INSTALLATION

Start Up and Initialization

1.4 Enabling Objective/Start Up and Initialization



GTE OMNI SBCS


- GIVEN:**
- INSTALLED GTE OMNI SBCS AND PERIPHERALS
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - REVIEW EXERCISE
- ACTION:**
- POWER ON SYSTEM AND PERFORM COLD RESTART TO INITIALIZE DEFAULT STANDARD DATA BASE.
 - PERFORM SYSTEM OPERATION CHECKS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- SYSTEM WILL BE INITIALIZED AND OPERATION WILL BE VERIFIED IN ACCORDANCE WITH GTE OMNI SBCS GTEP MANUAL.
 - REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

CPM Controls & Indicators



GTE OMNI SBCS

- GREEN LED SHOWS SYSTEM STATUS. NORMAL CONDITION IS ON.
- ALM (RED) LED INDICATES A MINOR ALARM.
- TO (RED) LED INDICATES A MAJOR ALARM.





System Initialization

GTE OMNI SBCS

COLD RESTART - LOSE DATA BASE, LOADS DEFAULT

DESCRIPTION:

- LOADS SYSTEM OPERATING PROGRAM AND DATA BASE MANAGEMENT PROGRAM FROM ROM TO WORKING ROM AND EPROM.
- INITIALIZES SYSTEM BY LOADING DEFAULT STANDARD DATA BASE AT TIME OF INSTALLATION.
- REQUIRES THAT AT LEAST ONE LINE CARD AND ONE TRUNK CARD ARE SEATED IN CARD SLOTS FOR SYSTEM PROGRAMMING.
- MUST BE PERFORMED WHENEVER CPM OR MEM CARDS ARE REPLACED.
- MUST ALSO BE PERFORMED AFTER SERIOUS POWER OUTAGE WITH LOSS OF SYSTEM BATTERY BACKUP.

PROCEDURE:

- (1) HOLD TOGGLE SWITCH ON CPM CARD IN UP POSITION WHILE SIMULTANEOUSLY PRESSING RESTART BUTTON.
- (2) RELEASE TOGGLE SWITCH BACK TO CENTER POSITION.

HOT RESTART

FOR NEW CARD -> DATA BASE STAYS INTACT
(FOR SYSTEM TO RECOGNIZE)

CALL PROCESSING STD P'S

DESCRIPTION:

- CONTROLS, BUT DOES NOT AFFECT CONTENTS OF RAM.
- CALL PROCESSING CEASES.
- ALL DATA BASE MODIFICATIONS IN CUSTOMIZED DATA BASE REMAIN.
- SYSTEM AUTOMATICALLY INITIATES HOT RESTART DURING ITS RECOVERY FROM MAJOR POWER FAILURE.

PROCEDURE:

- (1) HOLD TOGGLE SWITCH ON CPM CARD IN DOWN POSITION WHILE SIMULTANEOUSLY PRESSING RESTART BUTTON.
- (2) RELEASE TOGGLE SWITCH BACK TO CENTER POSITION.

MANUAL RESET

DESCRIPTION:

- RECOVERS SYSTEM AND CALL PROCESSING FROM MOMENTARY POWER INTERRUPTION.
- DOES NOT AFFECT CONTENTS OF RAM.
- ALL DATA BASE MODIFICATIONS IN CUSTOMIZED DATA BASE REMAIN.
- MUST BE PERFORMED WHENEVER LINE OR TRUNK CARDS ARE REPLACED.

PROCEDURE:

- (1) ENSURE THAT TOGGLE SWITCH ON CPM CARD IS IN CENTER POSITION.
- (2) PUSH RESTART BUTTON.



Operational Checks

GTE OMNI SBCS

AFTER SYSTEM HAS BEEN INITIALIZED WITH A COLD RESTART AND PROGRAMMED ACCORDING TO CUSTOMER SPECIFICATIONS, PERFORM THE FOLLOWING CHECKS AS APPLICABLE:

- (1) TEST STATION INSTRUMENTS TO ENSURE THAT EACH IS OPERATING CORRECTLY. LISTEN FOR DIAL TONE, TEST FEATURE BUTTONS, AND VERIFY CAPABILITY TO MAKE STATION-TO-STATION CALLS AND TRUNK CALLS.**
- (2) TEST PERSONAL LINES AND KEY SYSTEM TYPE LINES.**
- (3) TEST SYSTEM ACCESS CODES.**
- (4) TEST CLASSES OF RESTRICTION.**
- (5) TEST LEAST COST ROUTING.**
- (6) TEST SMDR PRINTER AND POWER FAULT TRANSFER, IF EQUIPPED.**

Laboratory Activity (1.4) – Start Up and Initialization



GTE OMNI SBCS

- (1) ENSURE THAT POWER SUPPLY AC PLUG IS NOT CONNECTED TO THE 110 VAC RECEPTACLE AND THAT THE POWER SUPPLY SWITCH IS OFF.
- (2) CONNECT THE CABINET POWER SUPPLY CABLE TO OMNI SBCS CABINET.
- (3) CONNECT THE POWER SUPPLY AC PLUG TO THE 110 VAC RECEPTACLE AND TURN THE POWER SUPPLY SWITCH TO THE ON POSITION.
- (4) VERIFY THAT THE OPE LAMP ON THE POWER SUPPLY AND THE RUN LAMP ON THE CPM CARD ARE LIT. (BOTH LAMPS ARE GREEN).
- (5) INITIALIZE THE SYSTEM BY PERFORMING A COLD RESTART.
- (6) VERIFY INITIALIZATION OF THE SYSTEM DEFAULT STANDARD DATA BASE BY READING THE LED DISPLAYS ON THE CS-20 AND CSD TELEPHONES. ALL DISPLAYS SHOULD READ "HH:MM". IF DISPLAYS ARE CORRECT, PROCEED TO STEP 8.
- (7) IF "HH:MM" IS NOT DISPLAYED ON THE CS-20 AND CSD TELEPHONES, PERFORM THE COLD RESTART PROCEDURE AGAIN. IF DISPLAYS STILL DO NOT OPERATE, POWER SYSTEM OFF AND ON, AND THEN ATTEMPT COLD RESTART PROCEDURE. IF THIS FAILS, CHECK THE CROSS CONNECTIONS FOR EACH INSTRUMENT. NOTIFY YOUR INSTRUCTOR IF YOU CONTINUE TO HAVE PROBLEMS WITH SYSTEM INITIALIZATION.
- (8) PERFORM THE FOLLOWING SYSTEM OPERATIONAL CHECKS:
 - (A) VERIFY THAT ALL STATION INSTRUMENTS HAVE DIAL TONE AND THAT BLF/DSS LAMPS ARE LIT WHEN EACH STATION IS OFF HOOK.
 - (B) DIAL SEVERAL STATION TO STATION CALLS USING DIRECTORY NUMBERS ASSIGNED EARLIER.
 - (C) DIAL A CO TRUNK LINE CALL FROM ONE OF THE STATIONS USING THE DEFAULT ACCESS CODE "75".
 - (D) DIAL A STATION TO LOOP TIE LINE CALL USING THE DEFAULT ACCESS CODE "82" FOR THE LOOP TIE LINE.
 - (E) DIAL A STATION TO E&M TIE LINE CALL USING THE DEFAULT ACCESS CODE "80" FOR THE E&M TIE LINE.
 - (F) DIAL AN INCOMING CALL TO YOUR SYSTEM FROM ANOTHER SWITCH (USING THE CO ACCESS CODE). THE TRUNK NUMBER FOR YOUR SYSTEM WILL BE PROVIDED BY THE INSTRUCTOR.

Laboratory Activity (1.4) – Start Up and Initialization (Continued)



GTE OMNI SBCS

- (11) CLEAR YOUR LABORATORY INSTALLATION SITE OF ALL DEBRIS AND REMNANTS OF THE INSTALLATION. SAVE ALL BOXES AND STACK THEM NEARBY YOUR LABORATORY AREA FOR LATER USE.

LAB MILESTONE:

- VERIFY THAT THE SYSTEM IS OPERATIONAL.
- ASK INSTRUCTOR TO INSPECT YOUR FINAL SYSTEM INSTALLATION, IMPLEMENTATION START UP, AND INITIALIZATION TASKS. AFTER INSPECTION, INSTRUCTOR WILL INITIAL YOUR PERFORMANCE CHECKLIST.
- YOU HAVE NOW COMPLETED OMNI SBCS SYSTEM INSTALLATION AND INITIALIZATION.

Review Exercise (1.4) – Start Up and Initialization



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, FILL IN THE BLANK OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. MATCH EACH CPM INDICATOR WITH THE CORRECT DESCRIPTION OF ITS FUNCTION WHEN LIT:

- | | |
|----------------------------------|---|
| _____ RUN LED (GREEN) | (A) INDICATES THAT SOFTWARE HAS DETECTED A FAILURE IN ONE OR MORE AREAS OF SYSTEM OPERATION |
| _____ MINOR ALARM LED | (B) INDICATES NORMAL OPERATIONAL STATUS. |
| _____ MAJOR TIMER OVERFLOW ALARM | (C) INDICATES THAT WATCHDOG TIMER HAS DETECTED A FAILURE IN CPM CARD OR OPERATING SYSTEM. |

2. WHAT TYPE OF RESTART/RESET SHOULD BE PERFORMED DEPENDING ON THE TYPE OF CARDS BEING REPLACED?

Review Exercise (1.4) – Start Up and Initialization (Continued)



GTE OMNI SBCS

3. WHAT TYPE OF RESTART/RESET LOADS THE DEFAULT STANDARD DATA BASE INTO ROM AND EPROM? _____
4. WHAT TYPE OF RESTART/RESET IS PERFORMED AUTOMATICALLY BY THE SYSTEM TO RECOVER FROM A POWER FAILURE? _____
5. WHAT VISUAL EVIDENCE INDICATES THAT A COLD RESTART HAS BEEN PERFORMED, ASSUMING THAT CS-20 OR CSD TELEPHONES HAVE BEEN INSTALLED?

6. WHAT TYPE OF RESTART/RESET REQUIRES REPROGRAMMING OR RELOADING THE CUSTOMIZED DATA BASE FROM TAPE OR DISKETTE? _____
7. WHAT IS REQUIRED IF ADDITIONAL LINE OR TRUNK CARDS ARE INSERTED AND SEATED IN CARD SLOTS AFTER THE DEFAULT STANDARD DATA BASE HAS BEEN INITIALIZED? _____



GTE OMNI SBCS

MODULE II
DATA BASE
ADMINISTRATION

Table of Contents



GTE OMNI SBCS

OVERVIEW	
DATA BASE ADMINISTRATION (OBJECTIVES)	2.3
OVERVIEW — SYSTEM DATA BASE	2.4
DATA BASE CAPABILITIES	2.5
PROGRAMMING TOOLS AND EQUIPMENT	2.6
PORTABLE MAINTENANCE PANEL	2.7
• CABLE CONNECTION — LOCAL	2.8
• PORT CONFIGURATION	2.9
• KEYBOARD	2.10
• TAPE DRIVE	2.11
• MICRO PRINTER	2.12
• INITIALIZING AND LOADING THE PMP CONTROL PROGRAM	2.13
• PMP CONTROL PROGRAM BACKUP TAPE	2.14
• LABORATORY ACTIVITY (2.1)	2.16
• PROGRAM SECURITY LEVELS	2.17
• SECURITY ACCESS PROCEDURE	2.18
• CONTROL PROGRAM ACCESS	2.19
• CURSOR CONTROL KEY OPERATION	2.20
• FUNCTION KEY OPERATION	2.21
• CHANGE AND MAINTENANCE CODE COMMANDS	2.22
• CMC PARAMETER FORMAT	2.23
• PROCESS DISPLAYS	2.24
• ERROR MESSAGES	2.25
• LABORATORY ACTIVITY (2.1)	2.26



Table of Contents (Continued)

GTE OMNI SBCS

DEFAULT STANDARD DATA BASE

● STATUS AND CAPACITY	2.27
● STANDARD STATION NUMBERING PLAN	2.28
● DEFAULT STANDARD ASSIGNED FEATURES AND ACCESS CODES	2.29
● DEFAULT STANDARD TIMING VALUES	2.31
● DIALED OUTPUTSED RECOGNIZE/SEND PLAN	2.32
● GUIDE TO OMNI SBCS PROGRAMMING AT TIME OF SYSTEM INSTALLATION	2.33
● REVIEW EXERCISE (2.1)	2.34

PROGRAMMING STATION INSTRUMENTS AND BLF/DSS MODULES

● PROGRAMMING STATION INSTRUMENTS AND BLF/DSS MODULES (OBJECTIVES) 	2.39
● DEFAULT STANDARD EKT BUTTON ARRANGEMENTS	2.40
● DEFAULT STANDARD CSD BUTTON ARRANGEMENT	2.41
● STATION INSTRUMENTS — STATION INSTALLATION (DEFAULT STANDARD)	2.42
● STATION INSTALLATION (MANUAL)	2.43
● MODIFYING STATION INFORMATION	2.46
● CMC COMMAND SUMMARY	2.47
● DEFAULT STANDARD BLF/DSS CONSOLE BUTTON STATION NUMBER APPEARANCE	2.48
● BLF/DSS INSTALLATION (DEFAULT STANDARD)	2.49
● BLF/DSS INSTALLATION (MANUAL)	2.50
● MODIFYING OR REMOVING BLF/DSS MODULE	2.51
● CMC COMMAND SUMMARY	2.52
● LABORATORY EXERCISE (2.2)	2.53
● REVIEW EXERCISE (2.2)	2.59

PROGRAMMING BASIC TRUNK DATA

● PROGRAMMING BASIC TRUNK DATA (OBJECTIVES)	2.67
● DEFAULT STANDARD TRUNK ASSIGNMENTS	2.68
● TRUNK INSTALLATION	2.69
● TRUNK MODIFICATION	2.70
● SPECIALIZED COMMON CARRIER	2.71
● CMC COMMAND SUMMARY	2.72
● LABORATORY EXERCISE (2.3)	2.74
● REVIEW EXERCISE (2.3)	2.77



Table of Contents (Continued)

GTE OMNI SBCS

PROGRAMMING TRUNK TERMINATIONS

• PROGRAMMING TRUNK TERMINATIONS (OBJECTIVES)	2.83
• OVERVIEW OF PROGRAMMING TRUNK TERMINATIONS	2.84
• TRUNK/STATION/EKT BUTTON ASSIGNMENTS	2.86
• TRUNK TERMINATION ASSIGNMENTS	2.87
• DIRECT-IN LINE ASSIGNMENT	2.88
• KEY SYSTEM TRUNK LINE ASSIGNMENT	2.89
• PERSONAL/PRIVATE TRUNK LINE ASSIGNMENT	2.90
• POOLED INCOMING TRUNK LINES ASSIGNMENT	2.91
• POOLED OUTGOING TRUNK LINES ASSIGNMENT	2.92
• POOLED BOTHWAY TRUNK LINES ASSIGNMENT	2.93
• CMC COMMAND SUMMARY	2.94
• LABORATORY EXERCISE (2.4)	2.95
• REVIEW EXERCISE (2.4)	2.98

PROGRAMMING SERVICE FUNCTIONS

• PROGRAMMING SERVICE FUNCTIONS (OBJECTIVES)	2.101
• SYSTEM SPEED CALLING DIRECTORY	2.102
• STATION HUNT GROUP ASSIGNMENT	2.103
• STATION PICKUP GROUP ASSIGNMENT	2.104
• HOT LINE STATION ASSIGNMENT	2.105
• INTERNAL SPEAKER PAGING GROUP ASSIGNMENT	2.106
• MUSIC-ON-HOLD	2.107
• NIGHT ANSWER	2.108
• CMC COMMAND SUMMARY	2.109
• LABORATORY EXERCISE (2.5)	2.110
• REVIEW EXERCISE (2.5)	2.118

PROGRAMMING CLASS OF SERVICE

• PROGRAMMING CLASS OF SERVICE (OBJECTIVES)	2.123
• FEATURE ASSIGNMENT	2.124
• STATION ASSIGNMENT	2.125
• TRUNK GROUP ASSIGNMENT	2.126
• CMC COMMAND SUMMARY	2.127



Table of Contents (Continued)

GTE OMNI SBCS

PROGRAMMING CLASS OF SERVICE (Continued)

- LABORATORY EXERCISE (2.6) 2.128
- REVIEW EXERCISE (2.6) 2.132

SYSTEM-WIDE PROGRAMMING CHANGES

- SYSTEM-WIDE PROGRAMMING CHANGES (OBJECTIVES) 2.135
- NUMBERING PLAN ASSIGNMENT 2.136
- SERVICE PARAMETER ASSIGNMENT 2.137
- SYSTEM TIMING PARAMETER ASSIGNMENT 2.138
- SYSTEM PARAMETER ASSIGNMENT 2.139
- NETWORK LOSS PLAN ASSIGNMENT 2.140
- TRUNK ROUTE TIMING 2.141
- CMC COMMAND SUMMARY 2.142
- LABORATORY ACTIVITY (2.7) 2.143
- REVIEW EXERCISE (2.7) 2.149

PROGRAMMING STATION MESSAGE DETAIL RECORDER

- PROGRAMMING SMDR (OBJECTIVES) 2.153
- SMDR SCREENING 2.154
- SMDR OUTPUT FORMAT 2.156
- CMC COMMAND SUMMARY 2.157
- LABORATORY ACTIVITY (2.8) 2.158
- REVIEW EXERCISE (2.8) 2.162

PROGRAMMING TOLL AND MULTI-DIGIT RESTRICTION

- PROGRAMMING TOLL AND MULTI-DIGIT RESTRICTION (OBJECTIVES) 2.165
- TOLL AND MULTI-DIGIT RESTRICTION 2.166
- AREA AND OFFICE CODE RESTRICTION ASSIGNMENTS 2.167
- DIAL GROUP ASSIGNMENT 2.169
- SCC RESTRICTION ASSIGNMENT 2.170
- CMC COMMAND SUMMARY 2.171
- LABORATORY ACTIVITY (2.9) 2.172
- REVIEW EXERCISE (2.9) 2.180

Table of Contents (Continued)



GTE OMNI SBCS

PROGRAMMING LEAST COST ROUTING	
• PROGRAMMING LEAST COST ROUTING (OBJECTIVES)	2.183
• PROGRAMMING LEAST COST ROUTING	2.184
• CMC COMMAND SUMMARY	2.186
• LABORATORY ACTIVITY (2.10)	2.187
• REVIEW EXERCISE (2.10)	2.192
PROGRAMMING SPECIAL SYSTEM CONFIGURATIONS	
• PROGRAMMING SPECIAL SYSTEM CONFIGURATIONS (OBJECTIVES)	2.195
• SBCS BEHIND A PABX	2.196
• TENANT ASSIGNMENTS	2.197
• OFF-PREMISES EXTENSION	2.199
• CMC COMMAND SUMMARY	2.200
• LABORATORY ACTIVITY (2.11)	2.202
• REVIEW EXERCISE (2.11)	2.205
SAVE/LOAD PROCEDURES	
• SAVE/LOAD (OBJECTIVES)	2.209
• SAVING ODDB TO TAPE	2.210
• LOADING ODDB FROM TAPE	2.213
• SAVING AND LOADING ODDB TO FLOPPY DISKETTE	2.217
• LABORATORY ACTIVITY (2.12)	2.220
• REVIEW EXERCISE (2.12)	2.225
IMPLEMENTATION FORMS PACKAGE	
• IMPLEMENTATION FORMS (OBJECTIVES)	2.229
• LABORATORY ACTIVITY (2.13)	2.230
• REVIEW EXERCISE (2.13)	2.231

2.0 Terminal Objective



GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBCS PERIPHERALS
- PMP CONTROL PROGRAM AND BLANK OFFICE DEPENDENT DATA BASE TAPES
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- GTE OMNI SBCS IMPLEMENTATION FORMS PACKAGE
- LABORATORY ACTIVITIES
- WRITTEN TEST

ACTION:

- MODIFY GTE OMNI SBCS SYSTEM DATA BASE AND VERIFY PROPER OPERATION.
- USE DATA COLLECTION AND INSTALLATION PROGRAMMING FORMS TO CUSTOMIZE GTE OMNI SBCS DATA BASE.
- COMPLETE AND PASS WRITTEN TEST.

CRITERIA:

- DATA BASE WILL BE MODIFIED IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND CORRECTLY USING DATA COLLECTION AND INSTALLATION PROGRAMMING FORMS.
- TEST WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Overview



GTE OMNI SBCS

2.1 Enabling Objective

GIVEN:

- GTE OMNI SBCS
- PORTABLE MAINTENANCE PANEL
- PMP CONTROL PROGRAM
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- PMP PRIMER
- LABORATORY ACTIVITY REVIEW EXERCISE

ACTION:

- IDENTIFY AND USE GTE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT BY DEMONSTRATING CORRECT PROCEDURES TO:
 - LOAD AND INITIALIZE PMP CONTROL PROGRAM.
 - OBTAIN SOFTWARE SECURITY ACCESS.
 - OPERATE PORTABLE MAINTENANCE PANEL.
 - ENTER, MODIFY, AND DELETE PARAMETER VALUES FOR CMC COMMANDS.
 - LOAD GTE OMNI SBCS OPERATING SYSTEM AND DEFAULT STANDARD DATA BASE WITH COLD RESTART.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL, PMP PRIMER, AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



Overview — System Data Base

GTE OMNI SBCS

- DEFINITION:** SOFTWARE DRIVEN AND SOFTWARE CONTROLLED SYSTEM WHICH PROVIDES FLEXIBILITY FOR DATA BASE MODIFICATIONS AND ALLOWS EFFICIENT UPGRADE OF SYSTEM.
- LOCATION:** RESIDENT ON CPM AND MEM CARDS
- PACKAGING:** ORGANIZED BY CHANGE AND MAINTENANCE CODE (CMC) COMMAND TABLES FOR EASY REFERENCE AND MODIFICATION
- BACKUP:** MICROCASSETTE TAPE OR FLOPPY DISKETTE.

Data Base Capabilities



GTE OMNI SBCS

- **CUSTOMIZING THE OMNI SBCS DEFAULT STANDARD DATA BASE**
- **STORING MODIFICATIONS TO THE OFFICE DEPENDANT DATA BASE (ODDB) TAPE OR FLOPPY DISK.**
- **PERFORMING MAINTENANCE THROUGH FAULT ISOLATION AND TROUBLE SHOOTING STRATEGIES.**
- **PERFORMING ROUTINE DIAGNOSTIC PROCEDURES.**

Programming Tools and Equipment

GTE

GTE OMNI SBCS


- SBCS OPERATING SYSTEM SOFTWARE
 - CONTAINS OPERATING PROGRAM WITH CHANGE AND MAINTENANCE TABLES STORED IN ROM.
 - CONTAINS DEFAULT DATA BASE WHICH IDENTIFIES AND CONTROLS SYTEM HARDWARE AND FEATURE ACCESS.
 - WRITTEN IN CHILL HIGH LEVEL PROGRAMMING LANGUAGE.

- PROGRAMMING DEVICES/EQUIPMENT
 - PORTABLE MAINTENANCE PANEL (PMP) EPSON HX-20 MICROCOMPUTER
 - PMP CONTROL PROGRAM TAPE OR FLOPPY DISKETTE
 - OFFICE DEPENDENT DATA BASE TAPE (ODDB) OR FLOPPY DISKETTE
 - MASTER CONTROL TELEPHONE (CSD ELECTRONIC TELEPHONE SET) *

- OPTIONAL EQUIPMENT
 - MODEM
 - REMOTE MAINTENANCE CAPABILITY
 - FLOPPY DISKETTE DRIVE
 - COMPATIBLE WITH PMP
 - PERFORMS SAVE/LOAD FUNCTION IN LESS TIME THAN MICROCASSETTE TAPE

- CHANGE AND MAINTENANCE CODE COMMAND (CMC) TABLES
 - OMNI SBCS GTEP MANUAL, MAINTENANCE AND DATA BASE PROGRAMMING SECTIONS.

*PACKAGE B/PHASE 1.5 AVAILABILITY



PORTABLE MAINTENANCE PANEL




CSD TELEPHONE AS
MASTER CONTROL TELEPHONE

Portable Maintenance Panel (Epson HX-20 Microcomputer)


GTE

GTE OMNI SBCS



- 80 CHARACTER ALPHANUMERIC LCD DISPLAY
- BATTERY OPERATED (AC POWER SUPPLY FOR RECHARGING)
- RS-232-C PORT FOR CABLE INTERFACE WITH OMNI SBCS
- STANDARD KEYBOARD WITH SPECIAL FUNCTION KEYS
- BUILT IN MICROCASSETTE DRIVE FOR LOADING AND STORING THE PMP CONTROL PROGRAM AND OFFICE DEPENDENT DATA BASE
- BUILT IN MICROPRINTER FOR HARD COPY OF SCREEN DISPLAY

PMP Cable Connection - Local



PROCEDURE

- (1) CONNECT DIN PLUG OF EPSON CABLE #715 TO PORT MARKED RS-232-C ON THE BACK OF PMP.
- (2) CONNECT DB-25 CONNECTOR END OF EPSON CABLE #715 TO PORT CN13 (MARKED I/O 0) ON OMNI SBCS CABINET.
- (3) ENSURE THAT COMMON CONTROL CARDS (CPM, MEM, AND SWC) ARE SEATED AND THAT BOTH OMNI SBCS AND PMP POWER SWITCHES ARE ON.

NOTE: PMP CONTROL PROGRAM MUST BE LOADED INTO PMP MEMORY FOR COMMUNICATION WITH OMNI SBCS.



GTE OMNI SBCS

PMP Port Configuration

- **FOR COMMUNICATION BETWEEN PMP AND OMNI SBCS, THE PMP CONTROL PROGRAM PORT CONFIGURATION MUST MATCH THE OMNI SBCS RS-232-C PORT AT CN13, I/O 0.**

- **PORT CONFIGURATION IS PRESET TO FOLLOWING VALUES:**
 - **BIT RATE = 1200 BAUD**
 - **STOP BITS = 1 BIT**
 - **PARITY = EVEN**
 - **CHARACTER LENGTH = 7 BITS**
 - **ECHO = OFF**


- **PORT CONFIGURATION MAY BE CHANGED THROUGH CMC-900 (refer to OMNI SBCS GTEP MANUAL, DATA BASE PROGRAMMING SECTION).**

- **POWERING THE PMP OFF AND ON RETURNS PMP TO THE PRESET PORT CONFIGURATION.**



PMP Keyboard

GTE OMNI SBCS




- STANDARD TYPEWRITER FORMAT.
- SPECIAL CONTROL KEYS TO ENABLE FUNCTION AND MICROPRINTER OPERATION.
- PROGRAM FUNCTION (PF) KEYS WHICH CHANGE MEANING AND FUNCTION DURING PMP CONTROL PROGRAM OPERATION.
- CURSOR CONTROL KEYS FOR QUICK MOVEMENT OF CURSOR.
- NUMERIC KEYS FOR ENTRY OF DATA BASE PARAMETER VALUES.

PMP Tape Drive



GTE OMNI SBCS




- **USES STANDARD MICROCASSETTE TAPES:**
 - ONE 30 MINUTE TAPE FOR SAVING PMP CONTROL PROGRAM
 - ONE OR MORE 60 MINUTE TAPE(S) FOR SAVING OFFICE DEPENDENT DATA BASE
- **USED TO LOAD PMP CONTROL PROGRAM INTO PMP MEMORY AT TIME OF INITIALIZATION OR IF PMP BATTERIES DISCHARGE.**
- **USED TO SAVE AND LOAD OFFICE DEPENDENT DATA BASE.**

PMP Micro Printer



GTE OMNI SBCS



PROCEDURE

- (1) COMPLETE ANY CMC COMMAND IN PROGRESS AND ENSURE CURSOR IS DISPLAYED ON SCREEN.
- (2) PRESS PRINTER ON/OFF SWITCH (LOCATED ON SIDE OF PMP).
- (3) PRESS CONTROL KEY AND PF2 KEY SIMULTANEOUSLY.
- (4) AFTER SCREEN HAS PRINTED, PRESS PAPER FEED KEY TO ADVANCE PAPER FOR REMOVAL FROM PMP.

- NOTE:
1. MAKE CERTAIN COMMAND PROCESS HAS BEEN COMPLETED BEFORE ADVANCING PAPER OR PRINTING, OR COMMAND WILL BE INTERRUPTED AND INPUT DATA WILL BE LOST.
 2. ONLY CONTENTS OF DISPLAY SCREEN IS PRINTED.

Initilizing and Loading The PMP Control Program



GTE OMNI SBCS

PROCEDURE

- (1) CONNECT PORTABLE MAINTENANCE PANEL CABLE TO PORT β , IF NOT CONNECTED ALREADY.
 (2) POWER ON PMP BY PRESSING POWER ON SWITCH LOCATED ON RIGHT SIDE OF PMP. THE PROGRAM MENU WILL BE DISPLAYED:

```
CTRL/@INITIALIZE
1 MONITOR
2 BASIC
```

- (3) **PRESS CONTROL AND @ KEYS SIMULTANEOUSLY**. PMP WILL DISPLAY THE FOLLOWING SCREEN WHICH PROMPTS FOR YEAR, DATE, AND TIME:

```
ENTER DATE AND TIME
MM DD YY HH MM SS CR
=
PRESS BREAK TO ABORT
```

- (4) **TYPE YEAR, DATE, AND TIME (AS IN EXAMPLE):**

```
ENTER DATE AND TIME
MM DD YY HH MM SS CR
= 092785143000
PRESS BREAK TO ABORT
```

- (5) **PRESS RETURN KEY**, PMP WILL DISPLAY FOLLOWING SCREEN:

```
CTRL/@INITIALIZE
1 MONITOR
2 BASIC
```

IF MENU DOES NOT APPEAR, PRESS RESET SWITCH LOCATED ON RIGHT REAR OF PMP.

- (6) **PRESS NUMERIC 2 KEY** TO SELECT BASIC MODE. DO NOT PRESS RETURN. SCREEN WILL DISPLAY:

```
COPYRIGHT 1982 BY
MICROSOFT & EPSON
P1: 0 BYTES
```

- (7) PUSH TAPE DRIVE COVER RELEASE (ON RIGHT OF PMP) TO OPEN TAPE DRIVE. INSERT PMP CONTROL PROGRAM MICROCASSETTE INTO TAPE DRIVE.

- (8) TYPE: **WIND** AND **PRESS RETURN** TO REWIND TAPE.

```
MICROSOFT & EPSON
P1:
WIND
```

- (9) TYPE: **RUN "CASE:LOADER"** AND **RETURN** (MAKING CERTAIN A NUMERIC ZERO IS USED FOR THE FIRST 0 IN THE COMMAND). DISPLAY WILL READ:

```
WIND
RUN "CASE:LOADER"
SEARCHING
```

THEN:

```
RUN "CASE:LOADER"
SEARCHING
FOUND: LOADER
```

WHICH INDICATES MACHINE CODE AND PMP CONTROL PROGRAM ARE BEING LOADED.

- (10) WAIT APPROXIMATELY FIVE MINUTES. WHEN TAPE HAS FINISHED MOVING, CURSOR WILL APPEAR ON SCREEN:

```
RUN "CASE:LOADER"
SEARCHING
FOUND: LOADER
=
```

- (11) TYPE: **TITLE "PMPctrl"** (EXACTLY AS SHOWN) AND **PRESS RETURN**. THIS WILL IDENTIFY CONTROL PROGRAM ON MAIN MENU.

```
SEARCHING
FOUND: LOADER
TITLE: "PMPctrl"
```

- (12) TYPE: **MON** AND **PRESS RETURN**, SCREEN WILL DISPLAY:

```
A=00 B=6E X=AB1C
C=C4 S=3CEC P=A385
```

- (13) TYPE: **K3**. DO NOT PRESS RETURN KEY.

```
-K3
A=00 B=6E X=AB1C
C=C4 S=3CEC P=A385
```

- * THE NUMBER THREE (3) IN THIS ENTRY CAN VARY. IT IDENTIFIES THE NUMERIC ORDER OF PROGRAMS IN THE EPSON HX-20. THE MAIN MENU DISPLAYS ALL STORED PROGRAMS IN ORDER. IF PROGRAM THREE ALREADY EXISTS, 3 CANNOT BE USED IN THIS ENTRY. ENTER THE NEXT AVAILABLE NUMBER IN SEQUENCE INSTEAD OF 3.

- (14) **PRESS CONTROL KEY AND @ SIMULTANEOUSLY**. DO NOT PRESS THE RETURN KEY. **TURN POWER OFF AND THEN ON**. MAIN PROGRAM MENU WILL NOW BE DISPLAYED INDICATING THE PMP CONTROL PROGRAM IS NOW LOADED AND WILL RUN AUTOMATICALLY.

PMP Control Program Backup Tape



GTE OMNI SBCS

PROCEDURE

- (1) TURN PMP POWER ON.
- (2) AFTER MAIN MENU APPEARS AND PORT CONFIGURATION SCREEN ARE DISPLAYED. **PRESS THE BREAK KEY.**
- (3) TYPE: "**LOGIN2**" AND **PRESS RETURN.**
- (4) INSERT PMP CONTROL PROGRAM TAPE INTO CASSETTE TAPE DRIVE.
- (5) TYPE: "**WIND**" AND **PRESS RETURN.** TAPE WILL NOT REWIND.
- (6) TYPE: "**LOAD "CASØ:LOADER"**" AND **PRESS RETURN.** WAIT APPROXIMATELY FIVE MINUTES.
- (7) AFTER TAPE STOPS MOVING, INSERT BLANK TAPES.
- (8) TYPE: "**WIND**" AND **PRESS RETURN.** TAPE WILL REWIND.
- (9) AFTER TAPE STOPS, TYPE: "**RUN2**" AND **PRESS RETURN.**
- (10) AFTER TAPE STOPS, TYPE: "**SAVE "CASØ:PMPCTRL.BSC"**" AND **PRESS RETURN.**

Student Notes



GTE OMNI SBCS

Laboratory Activity — Data Base Overview



GTE OMNI SBCS

INSTRUCTIONS: PERFORM THE FOLLOWING TASKS IN THE SEQUENCE OUTLINED BELOW IN ACCORDANCE WITH THE STUDENT WORKBOOK, THE OMNI GTEP MANUAL AND THE PMP PRIMER.

WORK ORDER #2.1	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.1 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none">• Initialize and load PMP Control program microcassette tape.• Create a backup copy of the PMP Control Program.	
<u>INSTRUCTIONS:</u>	
<ol style="list-style-type: none">(1) Power ON the PMP.(2) Load the PMP Control Program from the microcassette tape using the procedure in the Student Workbook.(3) Using the blank microcassette tape, make a backup of the original PMP Control Program tape using the procedure in the Student Workbook.	

PMP Program Security Levels/Access Codes



GTE OMNI SBCS

- ACCESS CODES ARE PROVIDED FOR TWO LEVELS OF SECURITY (ACCESS CODES CHANGE ACCORDING TO SOFTWARE VERSION RELEASE).

SECURITY LEVELS	SVR.1.0.2.2. (PACKAGE A)	SVR.1.5.X.X AND 2.0.X.X (PACKAGES B AND C)
HIGH SECURITY ACCESS	703	#803
LOW SECURITY ACCESS	#380	#380

- HIGH SECURITY CODES ALLOW ACCESS TO ALL CMC TABLES.
- LOW SECURITY CODES ALLOW ACCESS TO CMC TABLES WHICH DO NOT HAVE CRITICAL IMPACT ON SYSTEM.
- REQUIRED SECURITY LEVEL IS NOTED IN CMC TABLE LISTING IN OMNI SBCS GTEP MANUAL.



PMP Security Access Procedure

GTE OMNI SBCS

- IF HIGH LEVEL SECURITY CODE IS ENTERED AT SECURITY CODE PROMPT (AS ILLUSTRATED BELOW), ALL CMC COMMANDS MAY BE ACCESSED. ENTER APPROPRIATE CODE FOR SOFTWARE RELEASE AND PRESS **RETURN**.

SECURITY CODE = #803

- IF LOW LEVEL CODE IS ENTERED AT SECURITY PROMPT AND ACCESS TO A CMC COMMAND REQUIRING HIGH SECURITY IS ATTEMPTED, PMP WILL DISPLAY "LOCKED" MESSAGE (AS ILLUSTRATED BELOW):

CMC=108
LOCKED

NOTE: FOR SOFTWARE VERSION 1.5.X.X, USERS MUST PRESS SHIFT + PF1 TO EXIT TO THE INITIAL SECURITY PROMPT. THEN THE HIGH LEVEL CODE MUST BE ENTERED TO ACCESS THE COMMAND REQUIRING HIGH SECURITY.

FOR SOFTWARE VERSION 1.0.2.2, USERS MAY ENTER THE HIGH LEVEL CODE AT THE POINT WHERE THEY RECEIVE THE "LOCKED" MESSAGE. THIS WILL UNLOCK THE CMC COMMAND AND ALLOW ENTRY. (THE PMP WILL REVERT TO LOW LEVEL STATUS AFTER THE USER EXITS FROM THE HIGH LEVEL CMC COMMAND.)



PMP Control Program Access

GTE OMNI SBCS

PROCEDURE

- (1) POWER ON PMP. A SCREEN DISPLAYING MAIN PROGRAM MENU AND COPYRIGHT INFORMATION WILL APPEAR BRIEFLY AND THEN DISAPPEAR. PMP PORT CONFIGURATION WILL BE DISPLAYED:

```

PORT CONFIGURATION
CHANGE?
YES OR NO (Y/N)
  
```

- (2) ENTER: **N** DO NOT PRESS RETURN.

THIS WILL SKIP PORT CONFIGURATION SCREENS AND ASSUME DEFAULT VALUES WHICH ARE PRESENT TO MATCH OMNI SBCS DEFAULT PORT 0 CONFIGURATION.

- (3) SECURITY CODE PROMPT WILL NOW BE DISPLAYED:

```

SECURITY CODE=
  
```

ENTER DESIRED SECURITY LEVEL NUMBER: **#380** AND **PRESS RETURN KEY**. SECURITY CODE WILL NOT APPEAR (ECHO) ON SCREEN. IF SECURITY CODE IS NOT ACCEPTED, SYSTEM DISPLAYS:

```

SECURITY CODE=
ERROR
  
```

IF ANOTHER TERMINAL HAS ACCESS TO THE SYSTEM (A MODEM OR ANOTHER PMP CONNECTED TO CN14), SYSTEM DISPLAYS:

```

SECURITY CODE=
BUSY
  
```

- (4) IF SECURITY ACCESS HAS BEEN CLEARED, THE FOLLOWING SCREEN APPEARS WHICH INDICATES THAT USER IS NOW IN PMP COMMAND MODE:

```

CMC= #####
COMMAND READY
  
```

NOTE: IF HIGH SECURITY LEVEL IS REQUIRED WHEN USING SVR 1.0.2.2, SYSTEM DISPLAYS:

```

CMC = _____
END
  
```


ENTER REQUIRED HIGH LEVEL SECURITY CODE TO OBTAIN CMC ACCESS.



Cursor Control Key Operation

GTE OMNI SBCS

LOCATION OF CURSOR CONTROL KEYS



(SUPERSCRIPT NUMBER OVER LETTER KEY INDICATES ASSOCIATED PARAMETER LOCATION ON SCREEN.)

CURSOR MAY BE MOVED FROM ONE PARAMETER TO THE NEXT PARAMETER IN SEQUENCE BY USING THE RETURN KEY OR DIRECTLY TO A DESIRED PARAMETER LOCATION BY USING THE CURSOR CONTROL KEYS.

CURSOR CONTROL KEYS

PARAMETER


SHIFT + J
 SHIFT + K
 SHIFT + L
 SHIFT + U
 SHIFT + I
 SHIFT + O

P1
 P2
 P3
 P4
 P5
 P6

Function Key Operation



GTE OMNI SBCS



<u>NAME</u>	<u>PMP KEY</u>	<u>FUNCTION</u>
SELECT/ RETURN	RETURN	USED AFTER TYPING THE SECURITY CODE OR CMC THREE-DIGIT NUMBER. CAN BE USED AFTER TYPING P VALUE TO MOVE THE CURSOR TO THE NEXT PARAMETER POSITION.
RELEASE/RLS	PF1	EXIT FROM A COMMAND AT ANY TIME. USEFUL TO CHANGE TO ANOTHER COMMAND OR EXIT FROM AN ERROR CONDITION.
TERMINATE/TRM	SHIFT + PF1	TERMINATE THE CMC COMMAND. USED BEFORE ENTERING ANY P VALUES TO EXIT FROM A TABLE.
CANCEL/CAN	PF2	CANCELS A KEYED IN VALUE. USED TO ERASE TYPING ERROR. WILL NOT DELETE A VALUE FROM MEMORY.
PRINT	CTRL + PF2	THE DISPLAY OF CURRENT SCREEN IS SENT TO THE PRINTER. ONE SCREEN IS PRINTED AT A TIME. THE CURSOR MUST BE VISIBLE ON THE SCREEN AND ALL PMP/SYSTEM COMMUNICATION COMPLETED BEFORE PRESSING PRINT. OTHERWISE, DATA FROM THE SCREEN IS LOST, TRANSMISSION IS INTERRUPTED, AND THE PMP MUST BE TURNED OFF AND ON TO REINITIALIZE PMP PROGRAM CONTROL.
ADD/CHG	PF3	WRITES (ENTERS) THE ENTERED P VALUE INTO DATA BASE MEMORY. IN SOME TABLES, RMV MUST BE USED TO DELETE PREVIOUS VALUE BEFORE PRESSING ADD/CHG. DISPLAY INDICATES WHETHER THE P VALUE WAS ADDED OR CHANGED.
DUPLICATE/DUP	PF4	INCREMENTS THE TABLE'S MAIN PARAMETER WHILE CAUSING REMAINING P VALUES TO STAY THE SAME AS THE PREVIOUS SCREEN. USEFUL FOR ENTERING REPETITIVE P VALUES SUCH AS STATION AND TRUNK DATA.
TAPE START	SHIFT + PF4	STARTS THE ODDB BACK UP TAPE DURING THE LOAD OR SAVE DATA BASE PROCEDURE.
DISPLAY/DSP	PF5	REQUIRED AFTER ENTERING SOME CMC COMMAND. DISPLAYS P VALUES OF A TABLE. IF NO VALUES EXIST FOR A PARAMETER, THE P VALUE IS BLANK. DEPRESSING DSP A SECOND TIME INCREMENTS THE MAIN PARAMETERS AND THEIR P VALUES ARE DISPLAYED. DEPRESSING DSP AT THE END OF A TABLE LISTING EITHER DISPLAYS THE FIRST P VALUE GAIN OR TERMINATES THE TABLE BY EXITING.
REMOVE/RMV	SHIFT + PF5	DELETES ALL P VALUES EXCEPT THE MAIN PARAMETER FROM A TABLE. REQUIRED AT SOME TABLES BEFORE NEW VALUES CAN BE ENTERED.

Change and Maintenance Code (CMC) Commands



GTE OMNI SBCS

DESCRIPTION

- OMNI SBCS DATA BASE IS MODIFIED OR ENHANCED BY ADDRESSING DATA BASE TABLES AND THEN ENTERING OR CHANGING PARAMETER VALUES. DATA BASE TABLES ARE ADDRESSED BY CMC (CHANGE AND MAINTENANCE CODE) COMMAND ENTERED VIA THE PORTABLE MAINTENANCE PANEL OR THE MASTER CONTROL TELEPHONE.
- THE THREE-DIGIT CMC COMMAND IS THE SAME AS THE CMC TABLE NUMBER ADDRESS.
- PARAMETER VALUES ARE ENTERED USING PROGRAM FUNCTION (PF) KEYS, NUMERIC KEYS, *, AND #.

PROCEDURE

TO ACCESS A DATA BASE CMC TABLE USING THE PMP:

- (1) AT SECURITY CODE PROMPT, ENTER APPROPRIATE LEVEL REQUIRED FOR DESIRED CMC TABLE.
- (2) AT CMC COMMAND PROMPT, ENTER DESIRED THREE-DIGIT CMC NUMBER AND PRESS **RETURN** KEY.
- (3) PARAMETER VALUES MAY NOW BE ENTERED OR MODIFIED USING CMC COMMAND'S INPUT MENU DISPLAYED ON PMP SCREEN.

SECURITY CODE=___

CMC=___ *****

COMMAND READY

SCREEN DISPLAYS:

- **PMP ERROR CODE MESSAGES:** COMMUNICATIONS ERRORS ARE DISPLAYED IF OCCURING WHILE IN CMC TABLE.
- **PROGRESS:** INFORMATION IS BEING PROCESSED BY PROGRAM.

CMC Parameter Format



GTE OMNI SBCS


```
CMC= XXX
P1:    P4:
P2:    P5:
P3:    P6:
```

- EACH CMC TABLE CAN HAVE UP TO SIX PARAMETERS. XXX IDENTIFIES THREE-DIGIT CMC COMMAND.
- PARAMETERS ARE ALWAYS NUMBERED ON SCREEN AND LOCATED IN SAME POSITION.
- CMC TABLES WITH LESS THAN SIX PARAMETERS WILL DISPLAY ONLY REQUIRED NUMBER OF PARAMETERS.
- ALL CMC COMMAND TABLES ARE LOCATED IN OMNI SBCS GTEP MANUAL (DATA BASE PROGRAMMING SECTION). PARAMETER VALUES (P VALUES) AND CMC COMMAND OPERATION ARE OUTLINED FOR EACH COMMAND.

PMP Process Displays



GTE OMNI SBCS



- (1) CMC PROMPT
- (2) CMC COMMAND CODE — THREE DIGIT CMC NUMBER IDENTIFYING SPECIFIC CMC COMMAND TABLE.
- (3) OPERATIONAL STATUS AREA —
 - DSP: INDICATES DISPLAY PROGRAM FUNCTION KEY HAS BEEN PRESSED AND SCREEN DISPLAYS P VALUES.
 - ADD OR CHANGE: INDICATES ADD/CHANGE PROGRAM FUNCTION KEY HAS BEEN PRESSED AND NEW DATA OR MODIFICATION IS BEING WRITTEN TO OMNI SBCS MEMORY.
 - RMV: INDICATES REMOVE PROGRAM FUNCTION KEY HAS BEEN PRESSED AND PARAMETER VALUE DATA IS BEING DELETED FROM OMNI SBCS MEMORY.
- (4) MESSAGE DISPLAY AREA:
 - MM/DD/YY: DATE IS DISPLAYED BEFORE ENTERING COMMAND TABLE.
 - HH:MM: TIME IS DISPLAYED DURING DISPLAY, ADD/CHANGE, OR REMOVE PROGRAM FUNCTIONS.
- (5) PARAMETER DISPLAY AREA — IDENTIFIES VALUES OF PARAMETERS BEING CHANGED OR VERIFIED.
- (6) CURSOR — INDICATES LOCATION OF CURSOR ON SCREEN.



Error Messages

GTE OMNI SBCS

- TWO TYPES OF ERROR MESSAGES:
 - (1) PMP PROGRAM CODE OR PMP/CPM COMMUNICATION ERRORS (SEE TABLE BELOW).
 - (2) CMC PROGRAMMING PARAMETER ERRORS (SEE OMNI SBCS GTEP MANUAL, DATA BASE PROGRAMMING SECTION).

PMP DISPLAY	CAUSE AND REACTION
# LINE ERROR	TRANSMISSION ERROR, CPM FAILED TO RECEIVE DATA TRANSMITTED FROM PMP CORRECTLY (E.G., LINE PARITY ERROR).
HIT ANY KEY	HIT ANY KEY TO REINITIALIZE THE PMP. THE PMP DISPLAYS THE PORT CONFIGURATION CHANGE SCREEN.
# NO TRANSMISSION	TRANSMISSION ERROR. NO TRANSMISSION FROM CPM TO PMP. HIT ANY KEY TO REINITIALIZE THE PMP. THE PMP DISPLAYS THE PORT CONFIGURATION CHANGE SCREEN.
# SYSTEM NOT READY	TRANSMISSION ERROR. CPM SENT UNEXPECTED DATA TO PMP. THE "SECURITY CODE =" SCREEN WILL APPEAR IN A FEW SECONDS. ENTER THE SECURITY CODE.
# BASIC PRG. ERROR	PMP PROGRAM CODE ERROR. THE PMP MONITORS ITS OWN CC ERROR IN 1 1 1 1 INSTRUCTION CODES AND REPORTS A BASIC PROGRAM ERROR WHEN THE PMP CANNOT EXECUTE THE INSTRUCTION. "CC" MEANS AS FOLLOWS: CO: BUFFER OVERFLOW IO: DEVICE I/O ERROR UP: UNPRINTABLE ERROR "1 1 1 1" INDICATES THE LINE NUMBER OF THE PMP PROGRAM CODE WHERE THE ERROR OCCURRED. HIT ANY KEY TO REINITIALIZE THE PMP. THE PMP DISPLAYS THE PORT CONFIGURATION SCREEN.

Laboratory Activity – Data Base Overview (Continued)



GTE OMNI SBCS

INSTRUCTIONS: PERFORM THE FOLLOWING TASKS IN THE SEQUENCE OUTLINED BELOW IN ACCORDANCE WITH THE STUDENT WORKBOOK, THE OMNI SBCS GTEP MANUAL, AND THE PMP PRIMER.

WORK ORDER #2.1	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.1</u> (TASK #2)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Access the PMP Control Program.• Complete 12 introductory exercises in the PMP Primer to become familiar with the format and operation of basic CMC commands.	
<u>INSTRUCTIONS:</u> <ol style="list-style-type: none">(1) COLD Restart the system and power ON the PMP.(2) Access the PMP program which has been loaded by using the procedure in the Student Workbook. Use the high level security code access.(3) Turn to the laboratory exercises in the PMP Primer. Complete the 12 introductory exercises. Be certain to carefully read the description for each CMC command, the required parameters, and the error conditions. All of these programming commands will be addressed in greater detail during later programming activities. Ask your instructor for assistance or clarification as needed.	

Default Standard Data Base/Status and Capacity



GTE OMNI SBCS

ITEM	MAXIMUM CAPACITY (Packages A and B)	MAXIMUM CAPACITY (Package C)	DEFAULT STATUS	ITEM	MAXIMUM CAPACITY (Packages A and B)	MAXIMUM CAPACITY (Package C)	DEFAULT STATUS	ITEM	MAXIMUM CAPACITY (Packages A and B)	MAXIMUM CAPACITY (Package C)	DEFAULT STATUS
EKT's	120	120	ASGN	SIMULTANEOUS RINGER (PH1)	6	6/12	FIXED	STATION SPEED DIALING/ STATION (VOICE)	10	10	STA
CSD's	40 (B only)	80	ASGN	SIMULTANEOUS RINGER (PH2)	6	6/12	FIXED	SYSTEM SPEED CALLING (VOICE)	100	100	CMC
TRUNKS	40	52/104	ASGN	SIMULTANEOUS RINGER (PH3)	6	6/12	FIXED	SIMULTANEOUS TRUNK QUEUEING	20	20	STA
TIE TRUNKS	12	12/24	ASGN	SIMULTANEOUS RINGER (PH4)	6	6/12	FIXED	MASTER CONTROL TELEPHONE	4 (B ONLY)	4	CMC
SIMULTANEOUS CALLS	40 (A only) 72 (B only)	96	FIXED	HUNT GROUPS (VOICE)	10	20	CMC	NUMBER OF SIMULTANEOUS TRAFFIC MEASUREMENTS FOR TGN	10	10	CMC
STATION LINES	120	120/240	ASGN	HUNT GROUPS (DATA)	10 (B ONLY)	10	CMC	CALL FORWARD	N/A	N/A	STA
TRUNK DIALING GROUPS (DGN)	3	3	ASGN (1)	HUNT MEMBERS/GROUP (VOICE OR DATA)	16	16	CMC	DO NOT DISTURB	N/A	N/A	STA
TRUNK RESTRICTION GROUPS (RGN)	3	3	ASGN (1)	TENANTS	5	5	ASGN (0)	MESSAGE WAITING	N/A	N/A	STA
TRUNK GROUPS (TGN)	64	64	ASGN	PICK UP GROUPS	10	20	CMC	TRUNK CAMP-ON	N/A	N/A	STA
LCR AREA CODE ROUTE GROUPS	15	15	CMC	PICK UP MEMBERS/ GROUP	32	32	CMC	DO NOT DISTURB OVERRIDE	N/A	N/A	STA
LCR AREA CODES/ ROUTE GROUP	10	10	CMC	HOT LINES (VOICE)	10	20	CMC	AUTOMATIC INTERCOM	N/A	N/A	STA
LCR AREA CODE TABLES	160	160	CMC	HOT LINES (DATA)	40 (B ONLY)	40	CMC	CALL ANNOUNCE	N/A	N/A	VOICE
LCR AREA OFFICE CODE/TABLE	800 OFC for 8 AC	800 OFC for 8 AC	CMC	MESSAGE WAITING CAPACITY/STATION	4	5	STA	DAY/NIGHT MODE	N/A	N/A	DAY
LCR OFFICE CODE ROUTE GROUPS	15	15	CMC	NIGHT ANSWER GROUPS (INCLUDES OVERFLOW STATION)	16	32	CMC	OFF-HOOK INCOMING SIGNAL	N/A	N/A	SIGNAL
LCR OFFICE CODES/ ROUTE GROUP	10	10	CMC	NIGHT ANSWER MEMBERS/GROUP	8	8	CMC	ATTENDANT CONSOLES	--	2	FIXED
LCR OFFICE CODE TABLES	800	800	CMC	EKT PAGING ZONES	9	9	CMC	FRONT DESK CONSOLES	--	NO LIMIT	CMC
AREA AND OFFICE RESTRICTION TABLES	1000 (total codes)	1000 (total codes)	CMC	EKT MEMBERS/ZONE	4	4	CMC	HOTEL/MOTEL PRINTERS	--	2	CMC
NUMBER OF DATA TERMINALS (DTA's)	30 (B ONLY)	80	ASGN	EXTERNAL PAGING ZONES	9 (B ONLY)	9	CMC	IDLE LINE PREFERENCE (WITH ICM BUTTON)	--	N/A	ICM LINE
TOTAL NUMBER OF DSS 80 BUTTON	2	2	ASGN	SCC ROUTES	6	6	CMC	RINGING LINE PREFERENCE (WITH ICM BUTTON)	--	N/A	TRUNK/ICM LINE
40 BUTTON	6	8	ASGN	SIMULTANEOUS STATION CAMP-ON	30	30	STA	PRE-SELECTION/ONE TOUCH ACCESS	--	N/A	ONE TOUCH
3-WAY CONFERENCES	5	5/10	FIXED	SIMULTANEOUS USE OF EKT SPEAKER	48	48	FIXED				

• DEFAULT STATUS COLUMN IDENTIFIES STATUS OF ITEMS IN DEFAULT STANDARD DATA BASE:

ASGN = ITEMS DEPENDENT UPON SYSTEM CONFIGURATION (NUMBER OF TRUNKS, STATIONS, OR LINES). SPECIFIC DEFAULT ASSIGNMENTS ARE INDICATED IN PARENTHESES.

FIXED = ITEMS WITH MAXIMUM DEFAULT VALUES, INDEPENDENT OF DATA BASE CHANGES

CMC = ITEMS REQUIRING ADDITIONAL PROGRAMMING THROUGH CHANGE AND MAINTENANCE CODE COMMANDS.

STA = ITEMS REQUIRING INPUT BY STATION USER.

• STATION USERS HAVE ACCESS TO ALL FEATURES EXCEPT EXECUTIVE OVERRIDE THROUGH DEFAULT COS LEVEL:

1. (REFER TO CMC-104, CMC-202, AND CMC-252).

Default Standard Numbering Plan



GTE OMNI SBCS

	ICG0		ICG1		ICG2		ICG3		ICG4						
	Slots		Slots		Slots		Slots		Slots						
	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14
CKT 0	200	208	216	224	232	240	248	256	264	272	280	288	296	304	312
CKT 1	201	209	217	225	233	241	249	257	265	273	281	289	297	305	313
CKT 2	202	210	218	226	234	242	250	258	266	274	282	290	298	306	314
CKT 3	203	211	219	227	235	243	251	259	267	275	283	291	299	307	315
CKT 4	204	212	220	228	236	244	252	260	268	276	284	292	300	308	316
CKT 5	205	213	221	229	237	245	253	261	269	277	285	293	301	309	317
CKT 6	206	214	222	230	238	246	254	262	270	278	286	294	302	310	318
CKT 7	207	215	223	231	239	247	255	263	271	279	287	295	303	311	319

- **AUTOMATIC ASSIGNMENT OF VOICE STATION DIRECTORY NUMBERS TO CIRCUIT UPON STATION INSTALLATION.***
- **STATION CARDS (8EKC, 8SLC and 8DTC) CAN BE REPLACED IN SLOTS 00-14.**
- **STATION NUMBERS WHERE NO LINE CARD OR EKT IS INSTALLED IN VACANT NUMBER.**
NOTE: STATION NUMBERS FOR 8SLC WHERE NO SINGLE LINE INSTRUMENT IS CONNECTED MUST BE "MADE BUSY" (SEE CMC 701).
- **IF 4DMR CARD IS INSTALLED IN CARD SLOT 06-14, DTMF AND DP TELEPHONES CAN BE CONNECTED TO 8SLC CARD. IF 4DMR CARD IS NOT INSTALLED, ONLY DP, SINGLE LINE TELEPHONES CAN BE CONNECTED TO 8SLC CARD AND NO TOUCH TONE TIE TRUNKS CAN BE USED.**
- **IF 8EKC CARD IS PLACED IN CARD SLOT 01, DSS CONSOLES ARE AUTOMATICALLY ASSIGNED TO CIRCUITS ALLOTTED FOR STATION DIRECTORY NUMBERS.**

*DEFAULT DATA TERMINAL STATION NUMBERING PLAN IS DESCRIBED IN MODULE IV.

Default Standard Assigned Features and Access Codes



GTE OMNI SBCS

FEATURES	PACKAGES A AND B DEFAULT DATA BASE ACCESS CODES (FAC)	PACKAGE C DEFAULT DATA BASE ACCESS CODES (FAC)
Attendant Operator		0
Default Station Numbers (Voice)	200-319	200-319 (Basic) 320-439 (Expanded)
Default Station Numbers (Data) — (DTA only)	350-379	350-379 (Basic) 4400-4429 (Expanded)
Least Cost Routing (default allows all routes)	9	9
CO 1 Access	75	75
CO 2 Access	76	76
CO 3 Access	85	85
CO 4 Access	86	86
CO 5 Access	45	45 (Basic) not assigned (Expanded)
CO 6 Access	46	46 (Basic) not assigned (Expanded)
FX 1 Access	10	10
FX 2 Access	12	12
FX 3 Access	13	13
FX 4 Access	14	14
FX 5 Access	15	15
FX 6 Access	16	16
WATS 1 Access	70	70
WATS 2 Access	72	72
WATS 3 Access	73	73
WATS 4 Access	74	74
TIE 1 Access (E & M)	80	80
TIE 2 Access (Loop)	82	82
TIE 3 Access	83	83
TIE 4 Access	84	84

Default Standard Assigned Features and Access Codes (Continued)



GTE OMNI SBCS

FEATURES	PACKAGES A AND B DEFAULT DATA BASE ACCESS CODES (FAC)	PACKAGE C DEFAULT DATA BASE ACCESS CODES (FAC)
SCC 1 Access	40	40 (Basic) 46 (Expanded)
SCC 2 Access	42	42 (Basic) 47 (Expanded)
SCC 3 Access	43	43 (Basic) 48 (Expanded)
SCC 4 Access	44	44 (Basic) 49 (Expanded)
Station Speed Calling	*O + user programmed SPC (0-9)	*O + user programmed SPC (0-9)
System Speed Calling	## + installer programmed SPC (00-99)	## + installer programmed SPC (00-99)
Save/Repeat Last Number Dialed	*8	*8
EKT Paging Access - All Zone/Zone	77 + for all zones or 1-9 for each zone	77 + for all zones or 1-9 for each zone
EKT Paging Answer (Package B)	87 + for all zones or 1-9 for each zone	87 + for all zones or 1-9 for each zone
External Paging Access - All Zone/Zone (Package B)	78 + for all zones or 1-9 for each zone	78 + for all zones or 1-9 for each zone
External Paging Answer (Package B)	78 + for all zones or 1-9 for each zone	78 + for all zones or 1-9 for each zone
Call Forwarding - All Calls Activate	*34 + STA DN	*34 + STA DN/ATT Access
Call Forwarding - All Calls Cancel	*30	*30
Call Forwarding - Busy No Answer Activate	*33 + STA DN	*33 + STA DN/ATT Access
Call Forwarding - No Answer Activate	*32 + STA DN	*32 + STA DN/ATT Access
Call Forwarding - Busy/No Answer and No Answer Cancel	*31	*31
Do-Not-Disturb Activate	*6	*6
Do-Not-Disturb Cancel	#6	#6
Message Leaving Activate	*1 + STA DN	*1 + STA DN
Message Leaving Cancel	#1 + STA DN	# + STA DN
Message Pickup	*5	*5

Default Standard Assigned Features and Access Codes (Continued)



GTE OMNI SBCS

FEATURES	PACKAGES A AND B DEFAULT DATA BASE ACCESS CODES (FAC)	PACKAGE C DEFAULT DATA BASE ACCESS CODES (FAC)
Station Camp-On Cancel	#*	#*
Trunk Camp-On Cancel	#7	#7
Group Pickup	*4	*4
Call Park Answer	#9 + Call Park Orbit No. (1-4 digits)	#9 + Call Park Orbit No. (1-4 digits)
Night Answer Pick Up (self-tenant)	#30	#30
Night Answer Pick Up (all-tenant)	#31	#31
Directed Call Pick Up	17 + STA DN	17 + STA DN
DSS Park Answer	18 + Orbit No. (3 digits)	18 + Orbit No. (3 digits)
Data Call Attribute Change	69 + Parameter	69 + Parameter
Do Not Disturb Override Activate	*2 + STA DN	*2 + STA DN
Do Not Disturb Override Cancel	#2	#2
Automatic Intercom User Programmability	#4 + (button key) + STA DN or SPCC	#4 + (button key) + STA DN or SAC + SPC
Station Speed Call User Programmability	#0 + SPC + TAC + DN	#0 + SPC + TAC + DN
Off-Hook Incoming Call Signaling Change (EKT only)	57 + 0 for lamp only or 1 for ringing	57 + 0 for lamp only or 1 for ringing
Call Announce Receive ON/OFF (EKT only) (see CMC 101)	#8 + 1 for ON or 0 to disallow	#8 + 1 for ON or 0 to disallow
Pre-selection Mode Change		(Basic) 542 + 0 = cancel 1 = activate
Ringing Line Preference Change		541 + 0 = cancel 1 = ICM 2 = ICM or trunk
Idle Line Preference Change		541 + 0 = cancel 1 = ICM 2 = trunk
Direct Trunk Access	61* + trunk DN	61* + trunk DN
Day/Night Mode Change (this tenant only)	*# + 0 day or 1 = night	*# + 0 day or 1 = night
Night Mode Change (all tenants)	0# + 0 = day or 1 = night	0# + 0 = day or 1 = night
Key Touch Tone Control (EKT only)	58 + 0 = cancel or 1 = activate	58 + 0 = cancel or 1 = activate
Station Camp-On Activate	**	**
Trunk Camp-On Activate	*7	*7

Default Standard Assigned Features and Access Codes (Continued)



GTE OMNI SBCS

FEATURES	PACKAGES A AND B DEFAULT DATA BASE ACCESS CODES (FAC)	PACKAGE C DEFAULT DATA BASE ACCESS CODES (FAC)
Limited Executive Override (overrides only stations with higher COR)	#5	#5
Call Park Activate	*9 + 3 digit orbit no.	*9 + 3 digit orbit no.
Add Data Call Set Up (Package B)	67	67
Account Code/Client Billing	56 + identifier (1 to 15 digits)	56 + identifier (1 to 15 digits)
Executive Override (extends Limited Override to override all stations)	#5 (not in default data base, must add COS of this feature at CMC 104, same code)	#5 (not in default data base, must add COS of this feature at CMC 104, same code)

NOTES:

1. SPC = Speed Access Code: Station = 0-9 programmed by user, System = 00-99 programmed by installer.
2. TAC = Trunk Feature Access Code (listed this table)
3. DN = Directory Number or Station Number
4. EKT = Electronic Key Telephone



Default Standard Timing Values

GTE OMNI SBCS

DESCRIPTION	PACKAGES A/B DEFAULT VALUE IN SECONDS (± 0.2)	PACKAGE C DEFAULT VALUE IN SECONDS (± 0.2)	CMC TABLE
Digit Receive			
Incoming digit receive time out	11.26	11.26	254
Incoming interdigit time out	7.17	7.17	254
Digit Send			
Pre-pause timing (manual)	2.30	2.05	254
Interdigit timing (10 pps)	0.86 (DP)	0.77 (DP)	254
Interdigit timing (20 pps)		0.51	
Pre-pause timing (speed call)	3.3	3.1	254
Interdigit pause (speed call)	2.1 (PB)	2.05	254
	3.0 (DP)		
Interdigit timing (DTMF)	0.06	0.13	254
System Timing			
Station hook signal (maximum before disconnect)	1.05	1.05	103
Call start time after sending all digits	16.40	16.40	103
Confirmation tone time out	11.26	11.26	103
Confirmation tone burst	0.70	0.70	103
Service Registration time out	2.05	2.05	103
Call Forwarding — No Answer timing	13.31	13.31	103
Station Camp-On callback release	31.74	31.74	103
Station Camp-On ringback	31.74	31.74	103
Station Camp-On release	infinite	infinite	103
Trunk Camp-On callback cancel	11.26	11.26	103
Trunk Camp-On cancel	infinite	infinite	103
Call Park recall	62.46	62.46	103
No Answer recall	31.74	31.74	103
Recalled station look-in	2.05	2.05	103
Called party release	1.02	1.02	103
DSS Camp-On recall	31.74	31.74	103
DSS Call Hold recall	31.74	31.74	103
Long hold recall (line and ICM hold)	185.34	185.34	103
Forward All Calls and DND reminder	0.7	0.7	103
Preselection Release (future)	11.26	4.1	103
Camp-On burst	2.05	0.2	103

DESCRIPTION	PACKAGES A/B DEFAULT VALUE IN SECONDS (± 0.2)	PACKAGE C DEFAULT VALUE IN SECONDS (± 0.2)	CMC TABLE
Override warning burst	2.05	2.05	103
Paging warning burst (internal and external)	2.05	2.05	103
BT, ROT timing	31.74	31.74	103
Call announce warning burst	2.05	2.05	103
Pre-pause for second DT (LCR, SCC)		1.0	103
Account code registration display timing		1.1	103
Direct-in line called party busy burst timing		2.0	103
Direct-in line called party look-in timing		2.0	103
Paging EKT calling timing		1.0	103
Station hold loop recall timing		181.0	103
Automatic release for DISA ROT		11.0	103
Reseizure for DMR hunt failure of TIE/DID		2.0	103
Attendant Call Park recall		31.0	103
Attendant Camp-On recall		31.0	103
Attendant long hold recall		61.0	103
Attendant transfer call recall		31.0	103
Attendant incoming overflow timing		61.0	103
Common hold operation		1.6	103
Delayed ringing timing		11.0	103
Verify display timing		31.0	103
CFT timing for wake-up answer		21.0	103
Recalled station look-in timing		2.0	103
Auto pause timing		2.1	103
Trunk Route Timing			
Central Office line release timeout. Maximum duration of off-cycle incoming ringing	5.05	5.05	254
CT timing from incoming answer to transmission	0.15	0.15	254
Trunk guard release	1.0	1.0	254
Ground trunk seizure time out	5.10	5.10	254
Flash timing (disconnect)	1.0	1.0	254

- **DEFAULT STANDARD TIMING VALUES ASSOCIATED WITH TRANSMISSION AND TRUNK ROUTE TIMING MAY BE CHANGED WITH CMC-254.**
- **ALL DEFAULT STANDARD TIMING VALUES ASSOCIATED WITH SYSTEM OR STATION FEATURES MAY BE CHANGED WITH CMC-103.**

Default Standard Dial Outpulsed Recognized/Send Plan



GTE OMNI SBCS

DIALING DESTINATION	DIALING PATTERN
Local/Toll Operator	0
International Operator	01
Toll Prefix	1
International Prefix	011
Special Number	N11
Office Code	NNX
Area Code	N0/1X
Station Number	X to XXXX


NOTES:

1. X = 0 to 9, N = 2 to 9
2. Type of call available:
 - NNX + XXXX
 - 1 + NNX + XXXX
 - N0/1X + NNX + XXXX
 - 1 + N0/1X + NNX + XXXX
 - 0 + (time out)
 - 0 + NNX + XXXX
 - 0 + N0/1X + NNX + XXXX
 - N11
 - 011 + 12X's

Guide to Data Base Programming at Time of System Installation



GTE OMNI SBCS



Review Exercise — Data Base Overview (2.1)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE OMNI SBCS OPERATING SYSTEM SOFTWARE AND DEFAULT DATA BASE RESIDE ON BOTH THE _____ AND _____ CARDS.
2. PROGRAM CHANGES CAN BE MADE WITH THE _____ OR _____ INSTRUMENTS.
3. SPECIAL FUNCTIONS (ADD/CHANGE, ETC.) ARE PERFORMED WITH THE _____ KEYS WHEN USING THE PMP.
4. THE PORTABLE MAINTENANCE PANEL USUALLY INTERFACES TO THE OMNI SBCS THROUGH RS-232-C PORT _____.
5. WHEN IS THE PMP CONTROL PROGRAM LOADED INTO THE PMP? _____

6. THE SECURITY CODE FOR HIGH SECURITY ACCESS IS _____ AND LOW SECURITY ACCESS IS _____ WITH SVR 1.5.X.X.
7. MATCH EACH OF THE FOLLOWING PF KEYS WITH ITS CORRECT FUNCTION:

_____ PF1	A. SELECT
_____ SHIFT + PF5	B. RELEASE
_____ PF3	C. CANCEL
_____ PF2	D. ADD/CHANGE
_____ RETURN	E. REMOVE
8. A CMC TABLE CAN HAVE UP TO _____ PARAMETERS.
9. CMC COMMAND PARAMETER VALUES ARE ENTERED FROM THE PMP KEYBOARD USING _____, _____, _____ AND _____ KEYS.
10. WHAT PARAMETER DOES THE SYSTEM REQUIRE TO BE INPUT FOR MOST CMC COMMANDS? _____

Review Exercise – Data Base Overview (2.1) (Continued)



GTE OMNI SBCS

11. WHAT IS DISPLAYED ON THE PMP SCREEN IF THE SECURITY CODE IS NOT ACCEPTED BY THE SYSTEM? _____ .
12. THE _____ PROCEDURE LOADS AND ESTABLISHES THE SYSTEM DEFAULT STANDARD DATA BASE.
13. THE PORTABLE MAINTENANCE PANEL IS USED PRIMARILY:
_____ A. AS AN INSTRUCTIONAL DEVICE TO TEACH CUSTOMERS ABOUT OMNI SBCS FEATURES.
_____ B. FOR PERFORMING ROUTINE MAINTENANCE, CREATING OR MODIFYING THE OMNI SBCS DATA BASE, AND ISOLATING HARDWARE FAULTS.
_____ C. FOR PROGRAMMING NEW OMNI SBCS SOFTWARE PROGRAMS.
_____ D. FOR LEARNING THE CHILL HIGH-LEVEL PROGRAMMING LANGUAGE.
14. THE CURSOR MAY BE MOVED AROUND THE CMC COMMAND SCREEN THROUGH THE USE OF _____ OR _____ .
15. WHAT MESSAGE IS DISPLAYED IF A LOW SECURITY CODE IS ENTERED AND ENTRY TO A CMC COMMAND TABLE REQUIRING HIGH ACCESS THEN IS ATTEMPTED? _____
16. A _____ MINUTE BLANK MICROCASSETTE TAPE IS REQUIRED TO MAKE A BACK-UP OF THE PMP CONTROL PROGRAM.
17. MODIFICATIONS TO A CMC COMMAND TABLE ARE NOT ENTERED INTO THE DATA BASE UNTIL: _____
18. LOCAL PMP CONNECTION TO THE OMNI SBCS REQUIRES USE OF A _____ CABLE.
19. THE DEFAULT PMP PORT CONFIGURATION IS SET TO _____ BAUD WITH THE ECHO TURNED _____ .
20. THE DEFAULT STATUS FOR THE NUMBER OF SIMULTANEOUS CALLS ALLOWED IN THE SYSTEM IS _____ , INDEPENDENT OF DATA BASE CHANGES.

Review Exercise — Data Base Overview (2.1) (Continued)



GTE OMNI SBCS

21. WHAT SCREEN IS DISPLAYED WHEN THE PMP IS IN "COMMAND MODE"? _____

22. WHAT IS THE PROCEDURE FOR OBTAINING A HARD COPY OF A CMC COMMAND WITH CURRENT PARAMETER STATUS? _____

23. (TRUE OR FALSE) _____ THE PMP CANNOT COMMUNICATE WITH THE OMNI SBS IF THE MEM AND SWC CARDS HAVE NOT BEEN SEATED.
24. OMNI SBCS DATA BASE TABLES ARE ADDRESSED BY A THREE-DIGIT: _____ .
25. THE OMNI SBCS DEFAULT STANDARD STATION DIRECTORY NUMBERING PLANS BEGINS WITH DIRECTORY NUMBER _____ AND ENDS WITH _____ .



GTE OMNI SBCS

**DATA BASE ADMINISTRATION
Programming Station Instruments
and BLF/DSS Modules**



2.2 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY - PROGRAMMING STATION INSTRUMENTS AND BLF/DSS MODULES.
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - INSTALL AND REMOVE EKT INSTRUMENTS, SLT INSTRUMENTS, AND BLF/DSS MODULES.
 - ASSIGN AND MODIFY EKT, BLF/DSS BUTTON ASSIGNMENTS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING PROGRAM.

Default Standard EKT Button Assignment/CS-10 and CS-20



GTE OMNI SBCS

STANDARD CONFIGURATION (CARD SLOTS 00 OR 02-14)

CS-10

6	7	8	9	10
LINE (ORIG.)	CAMP-ON	FORWARD ALL	SAVE/ REPEAT	ICM HOLD ANSWER
1	2	3	4	5
DND	CALL ANNOUNCE	MONITOR	TRANSFER	HOLD

CS-20

6	7	8	9	10
LINE (ORIG.)	CAMP-ON	FORWARD ALL	SAVE/ REPEAT	ICM HOLD ANSWER
1	2	3	4	5
CALL ANNOUNCE	MUTE	SPEAKER PHONE	TRANSFER	HOLD

ALTERNATE CONFIGURATION (CARD SLOT 01)

CS-10

6	7	8	9	10
LINE (ORIG.)	LINE (TERM)	FORWARD ALL	SAVE/ REPEAT	ICM HOLD ANSWER
1	2	3	4	5
DND	CALL ANNOUNCE	MONITOR	TRANSFER	HOLD

CS-20


6	7	8	9	10
LINE (ORIG.)	LINE (TERM)	FORWARD ALL	SAVE/ REPEAT	ICM HOLD ANSWER
1	2	3	4	5
CALL ANNOUNCE	MUTE	SPEAKER PHONE	TRANSFER	HOLD

Default Standard CSD* Button Assignment




GTE OMNI SBCS


CSD CONNECTED TO AN 8DTC CARD INSTALLED IN CARD SLOT 01



CSD CONNECTED TO 8DTC CARDS INSTALLED IN CARD SLOTS 02-14



CSD EQUIPPED WITH DTA INTERFACE INSTALLED IN CARD SLOTS 00, 03, 06, 09, and 12



* PACKAGE B/PHASE 1.5 AVAILABILITY

Programming Station Instruments/Default Standard Station Installation



GTE OMNI SBCS

PROCEDURE

*

1. COLD RESTART THE SYSTEM (IF AT TIME OF INITIAL SYSTEM INSTALLATION) OR HOT RESTART THE SYSTEM (IF INSTALLING INSTRUMENT AFTER INITIAL SYSTEM INSTALLATION).
 2. REFER TO DEFAULT STANDARD DATA BASE TABLES FOR DEFAULT DIRECTORY NUMBER ASSIGNMENT AND BUTTON ASSIGNMENTS (FOR CS-10, CS-20, OR CSD).
 3. PROGRAM DESIRED DATA BASE CHANGES WITH APPLICABLE CMC COMMANDS USING DEFAULT STANDARD SETTINGS AS BASIS FOR THE CUSTOMIZED DATA BASE.
- *ASSUMES LINE CARD HAS BEEN INSTALLED IN APPROPRIATE SLOT AND TELEPHONE INSTRUMENT HAS BEEN PHYSICALLY CONNECTED TO DESIRED SLOT AND CIRCUIT LOCATION.

Programming Station Instruments/Manual

Station Installation



GTE OMNI SBCS

PROCEDURE

* (REFER TO OMNI SBCS GTEP MANUAL, DATA BASE PROGRAMMING SECTION)

1. USE CMC-200 TO ASSIGN:

- EQUIPMENT NUMBER (P1)
- STATION DIRECTORY NUMBER (P2)
- TYPE OF TERMINAL (P3)
- COPIED STATION DIRECTORY NUMBER (P4)

CMC= 200
P1: 017 P4
P2: 215
P3: 2

2. USE CMC-201 TO ASSIGN:

- DIRECTORY NUMBER (P1)
- OPERATION MODE (P2)
- TYPE OF DIALING (P3)
- TENANT NUMBER (P4)
- METERING GROUP (P5)

CMC=201
P1: 215 P4: 2
P2: 1 P5: 2
P3: 3

3. USE CMC-202 TO ASSIGN:

- STATION DIRECTORY NUMBER (P1)
- DAY CLASS OF SERVICE (P2)
- NIGHT CLASS OF SERVICE (P3)
- DAY CLASS OF RESTRICTION (P4)
- NIGHT CLASS OF RESTRICTION (P5)

CMC=202
P1: 215 P4: 1
P2: 1 P5: 1
P3: 3

Programming Station Instruments/Manual Station Installation (Continued)



GTE OMNI SBCS

4. USE CMC-204 (IF APPLICABLE) TO ASSIGN:
- STATION DIRECTORY NUMBER (P1)
 - DATA SECURE PATH (P2)
 - OFF PREMISES EXTENSION (P3)
 - SLT WITH MESSAGE WAITING LAMP (P4)**

CMC= 204	
P1: 215	P4: 0
P2: 1	
P3: 0	

5. USE CMC-203 (ONLY FOR CS-10, CS-20, AND CSD INSTRUMENTS) TO ASSIGN FEATURES OR SERVICES TO BUTTONS:
- STATION DIRECTORY NUMBER (P1)
 - BUTTON NUMBER (P2)
 - FEATURE NUMBER (P3)
 - SUPPLEMENTARY DATA (P4)
 - LINE TERMINATION TYPE (P5)
 - RINGING MODE (P6)

CMC= 203	
P1: 215	P4:
P2: 10	P5:
P3: 85	P6:

NOTE: IF LINE BUTTON IS ASSIGNED TO A CS-10, CS-20, OR CSD INSTRUMENT, USE CMC-253 TO ASSIGN TRUNK TERMINATION. (REFER TO STUDENT WORKBOOK FOR INSTRUCTIONS FOR PROGRAMMING TRUNK TERMINATION OR KEY SYSTEM TYPE LINES.)

*ASSUMES LINE CARD HAS BEEN INSTALLED IN APPROPRIATE SLOT AND TELEPHONE INSTRUMENT HAS BEEN PHYSICALLY CONNECTED TO DESIRED SLOT AND CIRCUIT.

**PACKAGE B/PHASE 1.5 AVAILABILITY

Student Notes



GTE OMNI SBCS

Programming Station Instruments/Modification- Removal of Station Information



GTE OMNI SBCS

PROCEDURE (CHANGE)

1. USE CMC-203 TO:
 - REMOVE UNWANTED EKT BUTTON ASSIGNMENTS
 - ENTER NEW BUTTON ASSIGNMENTS
2. USE CMC-200 TO:
 - CHANGE STATION DIRECTORY NUMBERS AND/OR EQUIPMENT NUMBERS
3. CHECK CMC-201, CMC-202 AND CMC-204 TO:
 - MAKE ANY CHANGES AFFECTED BY DIRECTORY NUMBER CHANGE (COS/COR OPERATION MODE TYPE OF DIALING, TENANT NUMBER, METERING GROUP, DATA SECURITY OR OPX DESIGNATION).
4. CHECK CMC-306 AND CMC-307 TO:
 - MAKE ANY CHANGES AFFECTED BY EQUIPMENT NUMBER CHANGE.

PROCEDURE (REMOVE)

1. USE CMC-203 TO:
 - REMOVE ALL BUTTON ASSIGNMENTS ASSOCIATED WITH STATION.
2. CHECK CMC-201, CMC-204, CMC-210, CMC-301, CMC-302 AND CMC-304 TO:
 - REMOVE STATION DIRECTORY NUMBERS FROM APPLICABLE TABLES.
3. USE CMC-200 TO:
 - CHANGE STATION DIRECTORY NUMBER ASSIGNMENT AND EQUIPMENT NUMBER ASSIGNMENT.
4. CHECK CMC-306 AND CMC-307 TO:
 - CHANGE STATION DIRECTORY NUMBERS AFFECTED BY THE CHANGES.

Programming Station Instruments/ CMC Command Summary



GTE OMNI SBCS


<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• STATION DN ASSIGNMENT	200	ASSIGNS, REMOVES, OR CHANGES DIRECTORY NUMBER AND TYPE OF TERMINAL.
• STATION DATA ASSIGNMENT	201	ASSIGNS, REMOVES, OR CHANGES A STATION'S OPERATION MODE, TYPE OF DIALING, TENANT NUMBER, OR METERING GROUP NUMBER.
• STATION COS/COR ASSIGNMENT	202	ASSIGNS, REMOVES, OR CHANGES A STATION'S CLASS OF SERVICE OR CLASS OF RESTRICTION LEVEL FOR DAY OR NIGHT MODE.
• EKT BUTTON ASSIGNMENT	203	ASSIGNS, REMOVES, OR CHANGES FEATURE BUTTON ASSIGNMENT ON EKT.
• DATA SECURITY AND OPX	204	IDENTIFIES A DIRECTORY NUMBER AS A DATA SECURE LINE OR OFF-PREMISE EXTENSION.

Programming BLF/DSS Modules/Default Standard Console Button Station Number Appearance



GTE OMNI SBCS

71 200	72 201	73 202	74 203	75 204	76 205	77 206	78 207	79 208	80 209
61 210	62 211	63 212	64 213	65 214	66 215	67 216	68 217	69 218	70 219
51 220	52 221	53 222	54 223	55 224	56 225	57 226	58 227	59 228	60 229
41 230	42 231	43 232	44 233	45 234	46 235	47 236	48 237	49 238	50 239
31 240	32 241	33 242	34 243	35 244	36 245	37 246	38 247	39 248	40 249
21 250	22 251	23 252	24 253	25 254	26 255	27 256	28 257	29 258	30 259
11 260	12 261	13 262	14 263	15 264	16 265	17 266	18 267	19 268	20 269
1 270	2 271	3 272	4 273	5 274	6 275	7 276	8 277	9 278	10 279



DSS 80

Programming BLF/DSS Modules

BLF/DSS Installation — Default Standard



GTE OMNI SBCS

DESCRIPTION

- **ALLOWS FOR PREPROGRAMMED STATION BUTTON ASSIGNMENTS ON BLF/DSS MODULE.**
- **BLF/DSS SHOULD BE ASSIGNED TO ODD CIRCUIT NUMBER ON 8KCC CARD INSERTED INTO CARD SLOT 01.**
- **REQUIRES THAT CS-10 OR CS-20 ASSOCIATED WITH BLF/DSS MUST BE INSTALLED AS A STATION ON SAME 8KCC CARD IN SLOT 01. ASSOCIATED EKT SHOULD BE CONNECTED TO THE EVEN NUMBERED CIRCUIT ONE NUMBER LESS THAN THE BLF/DSS CIRCUIT NUMBER (I.E., EKT = CIRCUIT 0, BLF/DSS = CIRCUIT 1).**

PROCEDURE

* (UTILIZING DEFAULT STANDARD DATA BASE SETTINGS)

- **COLD RESTART THE SYSTEM. ALL TRUNKS AND STATIONS WILL AUTOMATICALLY RECEIVE THE DEFAULT STANDARD DATA BASE SETTINGS.**

WARNING: DO NOT USE THIS PROCEDURE AFTER DATA BASE MODIFICATIONS HAVE BEEN MADE. A COLD RESTART DELETES ALL PREVIOUS DATA BASE CHANGES SINCE SYSTEM WILL REVERT TO DEFAULT STANDARD DATA BASE SETTINGS.

***ASSUMES 8KCC CARD IS SEATED IN CARD SLOT 01 AND BLF/DSS IS PHYSICALLY CONNECTED TO APPROPRIATE CIRCUIT.**

Programming BLF/DSS Instruments — BLF/DSS Installation — Manual



GTE OMNI SBCS

DESCRIPTION

- ASSUMES THAT COMPLETE PROGRAMMING OF BLF/DSS CONSOLE IS REQUIRED.
- PROCEDURE USED IF DEFAULT STANDARD DATA BASE IS NOT USED OR IF THE BLF/DSS IS NOT CONNECTED TO AN 8KCC CARD IN CARD SLOT 01.*
- THE CS-10 OR CS-20 ASSOCIATED WITH THE BLF/DSS MUST ALREADY BE INSTALLED PRIOR TO BLF/DSS INSTALLATION.

PROCEDURE

1. USE CMC-210 TO ASSIGN:
 - IDENTIFYING BLF/DSS INSTRUMENT NUMBER (P1)
 - BLF/DSS TYPE (P2)
 - EQUIPMENT NUMBER (P3)
 - ASSOCIATED EKT STATION DIRECTORY NUMBER (P4)
 - COPIED BLF/DSS INSTRUMENT NUMBER (P5)
 - BLF/DSS ORDER**
2. USE CMC-211 TO ASSIGN:
 - ASSOCIATED EKT STATION DIRECTORY NUMBER (P1)
 - BLF/DSS BUTTON NUMBER (P2)
 - TYPE OF BLF/DSS FEATURE (P3)
 - STATION DIRECTORY NUMBER ASSIGNED TO BUTTON (P4)
 - LINE TERMINATION TYPE FOR LINE ACCESS WHEN P3 = 9 (P5)
 - RINGING MODE WHEN P3=9 (P6)

*ASSUMES 8KCC CARD IS SEATED IN CARD SLOT 00 OR 02-14 AND BLF/DSS IS PHYSICALLY CONNECTED TO APPROPRIATE CIRCUIT.

**PACKAGE C AVAILABILITY

CMC= 210
P1: 1 P4: 214
P2: 1 P5:
P3: 013 P6:

CMC= 211
P1: 214 P4:
P2: 3 P5:
P3: 6 P6:

Programming BLF/DSS Instruments

Modify/Remove a BLF/DSS Module



GTE OMNI SBCS

PROCEDURE (CHANGE)

- USE CMC-211 TO REMOVE BLF/DSS BUTTON ASSIGNMENT BEFORE ENTERING NEW BUTTON ASSIGNMENTS.

PROCEDURE (REMOVE)

- USE CMC-211 TO REMOVE BLF/DSS BUTTON ASSIGNMENTS
- USE CMC-210 TO REMOVE BLF/DSS ASSIGNMENT

NOTE: EXISTING ENTRIES MUST BE REMOVED BEFORE CHANGING BLF/DSS MODULE ASSIGNMENTS.

Programming BLF/DSS Modules CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
● BLF/DSS ASSIGNMENT	210	ASSIGNS OR REMOVES BLF/DSS MODULES.
● BLF/DSS BUTTON ASSIGNMENT	211	ASSIGNS, REMOVES, OR CHANGES BLF/DSS FEATURE OR STATION INTERCOM BUTTONS FOR EACH BLF/DSS BUTTON.

Laboratory Activity – Programming Station Instruments and BLF/DSS Modules



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW, USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO STATION AND BLF/DSS PROGRAMMING UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.2	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.2 (TASK #1)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
<p><u>TASKS:</u></p> <ul style="list-style-type: none"> • Add, modify, or remove a station with CMC-200. • Assign station characteristics with CMC-201. 	
<p><u>PARAMETERS:</u></p> <ol style="list-style-type: none"> (1) Install and add a CS-10 to card 01, circuit 0. (NOTE: Cross connect wiring was completed during installation. Simply connect station to modular jack, perform HOT Restart, and proceed with required programming. (2) Change default station directory number assignment from 208 to 308. (3) Assign station characteristics: <ul style="list-style-type: none"> Operation Mode = Bothway Type of Dialing = DTMF (4) Remove station 215. 	<p><u>INSTRUCTIONS:</u></p> <ol style="list-style-type: none"> (1) Perform programming changes for station instruments. (2) HOT Restart system after installation. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Proceed to next work order task.

Laboratory Activity – Programming Station Instruments and BLF/DSS Modules (Continued)



GTE OMNI SBCS

WORK ORDER #2.2	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.2</u> (TASK #2)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none"> • Restore station 215 to system by adding it with CMC-200. • Change station operation mode, tenant group, and SMDR metering group using CMC-201. 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Add station 215 at slot 01, circuit 07. (2) Change operation mode for SLT at slot 02, circuit 0 from bothway, to incoming only. (3) Change dialing mode to DTMF for this instrument. (4) Assign both SLT instruments to tenant group 1 and metering group 10. <p><u>NOTE:</u> Programming of station tenant assignment, SMDR printer output, and station COS/COR assignments will be addressed in later laboratory activities.</p>	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Perform programming changes for station instrument. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity — Programming Station Instruments and BLF/DSS Modules (Continued)



GTE OMNI SBCS

WORK ORDER #2.2	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.2</u> (TASK #3)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Identify a station directory number as a data secure line or an off-premises extension with CMC-204. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Make station 214 a data secure line. (2) Designate the SLT at slot 02, circuit 7 as an off-premises extension. 	<ol style="list-style-type: none"> (1) Perform programming changes for station instruments. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity – Programming Station Instruments and BLF/DSS Modules (Continued)



GTE OMNI SBCS

WORK ORDER #2.2	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 2.2 (TASK #4)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS <ul style="list-style-type: none"> Assign and remove feature assignments for EKT button with CMC-203. 	
PARAMETERS: <ol style="list-style-type: none"> Assign "Call Park" to button 1 for both CS-20 instruments. Change the "Forward All" feature assigned by default to a button on station 308, to the "Do Not Disturb" feature. Change the "Call Announce" feature also assigned by default to a button on station 308, to the "System Speed Calling" feature (code 00). 	INSTRUCTIONS: <ol style="list-style-type: none"> Perform programming changes for station instruments. Check/test the operation of changes after completion of this portion of the laboratory activity. Complete review exercise questions 1-17.
NOTE: Programming of EKT buttons for trunk termination or key system type features will be addressed in later laboratory activities.	

LAB MILESTONE
<ul style="list-style-type: none"> VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. ASK INSTRUCTOR TO INSPECT STATION PROGRAMMING CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. MAKE CERTAIN QUESTIONS 1-17 OF REVIEW EXERCISE 2.2 HAVE BEEN COMPLETED BEFORE COMPLETING THE REMAINING WORK ORDERS.

Laboratory Activity — Programming Station Instruments and BLF/DSS Modules (Continued)



GTE OMNI SBCS

WORK ORDER #2.2	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.2</u> (TASK #5)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Add, change, or delete a BLF/DSS module with CMC-210. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Install and add a 40 button BLF/DSS to card 01, circuit 3. (NOTE: Cross connect wiring was completed during installation. Simply connect BLF/DSS to modular jack, perform HOT Restart, and proceed with required programming.) (2) Assign the BLF/DSS as BLF/DSS module Number 2. Pair it with the CS-20 instrument at station directory 214. 	<ol style="list-style-type: none"> (1) Perform programming changes for BLF/DSS modules. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity — Programming Station Instruments and BLF/DSS Modules (Continued)



GTE OMNI SBCS

WORK ORDER #2.2																									
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212																								
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.4 (TASK #5)																								
ORIGINATOR: TELECOMMUNICATIONS MANAGER																									
TASKS:																									
<ul style="list-style-type: none"> Assign and remove BLF/DSS button assignments with CMC-211. 																									
PARAMETERS:	INSTRUCTIONS:																								
<p>(1) Assign the following features to the BLF/DSS installed in the previous task:</p> <table border="1"> <thead> <tr> <th>BUTTON</th> <th>FEATURE</th> </tr> </thead> <tbody> <tr><td>1</td><td>DSS Park Answer</td></tr> <tr><td>2</td><td>DSS Camp On</td></tr> <tr><td>3</td><td>Alternate (assign directory number 212)</td></tr> <tr><td>4</td><td>Alarm</td></tr> <tr><td>5</td><td>Night</td></tr> <tr><td>6</td><td>External Paging</td></tr> <tr><td>7</td><td>Automatic Intercom (DN 212)</td></tr> <tr><td>8</td><td>Automatic Intercom (DN 214)</td></tr> <tr><td>9</td><td>Automatic Intercom (DN 216)</td></tr> <tr><td>10</td><td>Automatic Intercom (DN 223)</td></tr> <tr><td>11</td><td>Automatic Intercom (DN 308)</td></tr> </tbody> </table>	BUTTON	FEATURE	1	DSS Park Answer	2	DSS Camp On	3	Alternate (assign directory number 212)	4	Alarm	5	Night	6	External Paging	7	Automatic Intercom (DN 212)	8	Automatic Intercom (DN 214)	9	Automatic Intercom (DN 216)	10	Automatic Intercom (DN 223)	11	Automatic Intercom (DN 308)	<p>(1) Perform programming changes for BLF/DSS modules.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Complete review exercise questions 18-30.</p>
BUTTON	FEATURE																								
1	DSS Park Answer																								
2	DSS Camp On																								
3	Alternate (assign directory number 212)																								
4	Alarm																								
5	Night																								
6	External Paging																								
7	Automatic Intercom (DN 212)																								
8	Automatic Intercom (DN 214)																								
9	Automatic Intercom (DN 216)																								
10	Automatic Intercom (DN 223)																								
11	Automatic Intercom (DN 308)																								

LAB MILESTONE:
<ul style="list-style-type: none"> VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. ASK INSTRUCTOR TO INSPECT STATION PROGRAMMING CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. MAKE CERTAIN QUESTIONS 18-30 OF REVIEW EXERCISE 2.2 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO YOUR INSTRUCTOR FOR GRADING.

Review Exercise – Programming Station Instruments and BLF/DSS Modules (2.2)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.S. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. IF YOU ATTEMPT TO ADD AN EKT STATION THROUGH PROGRAMMING BEFORE IT HAS BEEN WIRED, WHAT WILL OCCUR? (TRY THIS IN THE LAB TO VERIFY).

2. MATCH THE DEFINITION OF EACH PARAMETER FOR CMC-200 TO ITS CORRECT LOCATION:

_____ P1	A. DIRECTORY NUMBER
_____ P2	B. EQUIPMENT NUMBER
_____ P3	C. TYPE OF TERMINAL
_____ P4	D. COPIED STATION DIRECTORY NUMBER

3. THE KEY OR MAIN PARAMETER FOR CMC-200 IS: _____

4. DEFINE THE COMPONENTS OF A THREE DIGIT EQUIPMENT NUMBER: _____

5. ASSIGN A CS-20 TO EQUIPMENT NUMBER 004. WHAT ERROR MESSAGE IS DISPLAYED? _____

Review Exercise – Programming Station Instruments and BLF/DSS Modules (2.2) (Continued)



GTE OMNI SBCS

6. MATCH THE DEFINITION OF EACH PARAMETER FOR CMC-201 TO ITS CORRECT LOCATION:
- | | |
|----------|--------------------------|
| _____ P1 | A. METERING GROUP NUMBER |
| _____ P2 | B. TYPE OF DIALING |
| _____ P3 | C. DIRECTORY NUMBER |
| _____ P4 | D. TENANT NUMBER |
| _____ P5 | E. OPERATION MODE |
7. WHAT IS THE DEFAULT OPERATION CODE FOR STATION INSTRUMENTS? _____
- A. BOTHWAY
 - B. ORIGINATE ONLY
 - C. TERMINATE ONLY
 - D. BOTH RESTRICTED (ICM ONLY)
8. WHAT DOES A P VALUE OF 3 INDICATE FOR CMC-201, PARAMETER 3? _____
- _____
9. HOW COULD FIVE TENANT GROUPS BE INDICATED USING CMC-201? _____
- _____
10. MATCH THE DEFINITION OF EACH PARAMETER FOR CMC-204 WITH ITS CORRECT LOCATION:
- | | |
|----------|----------------------------------|
| _____ P1 | A. OFF-PREMISES EXTENSION |
| _____ P2 | B. DATA SECURE SPEECH PATH |
| _____ P3 | C. SLT WITH MESSAGE WAITING LAMP |
| _____ P4 | D. STATION DIRECTORY NUMBER |

Review Exercise — Programming Station Instruments and BLF/DSS Modules (2.2) (Continued)



GTE OMNI SBCS

11. IDENTIFY THE DEFAULT BUTTON ASSIGNMENTS USING FEATURE NUMBERS (FNO) FOR THE EKT BUTTON ON A CS-10 ASSIGNED TO A CIRCUIT ON CARD SLOT 01

FNO: _____	FNO: _____	FNO: _____	FNO: _____	FNO: _____
6	7	8	9	10
FNO: _____	FNO: _____	FNO: _____	FNO: _____	FNO: _____
1	2	3	4	5

12. MATCH THE DEFINITION OF EACH PARAMETER WITH ITS CORRECT LOCATION IN CMC-203:

_____ P1	A. RINGING MODE
_____ P2	B. FEATURE NUMBER
_____ P3	C. STATION DIRECTORY NUMBER
_____ P4	D. LINE TERMINATION TYPE
_____ P5	E. BUTTON NUMBER
_____ P6	F. SUPPLEMENTARY DATA

13. WHAT IS THE FEATURE NUMBER (FNO) FOR THE "CALL PARK" FEATURE ASSIGNED DURING THE WORK ORDER? _____

14. IF FNO 48 IS ASSIGNED USING CMC-203, WHAT OTHER PARAMETERS ARE REQUIRED?

Review Exercise — Programming Station Instruments and BLF/DSS Modules (2.2) (Continued)



GTE OMNI SBCS

15. IDENTIFY AND DEFINE FIVE FEATURES THAT CANNOT BE ASSIGNED TO EKT BUTTONS:

FNO	DEFINITION
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

16. WHAT IS THE FUNCTION OF CMC-203's PARAMETER 6? _____

THE FEATURE NUMBERS THAT REQUIRE A VALUE ASSIGNED TO THIS PARAMETER ARE

_____, _____, _____, AND _____.

17. THE _____ PROGRAM FUNCTION KEY MUST BE USED BEFORE A BUTTON ASSIGNMENT CAN BE CHANGED.

18. WHAT OCCURS IF A BLF/DSS IS ASSIGNED THROUGH USE OF CMC-210 BEFORE IT IS WIRED? (TRY THIS TO VERIFY).

19. IF A BLF/DSS IS INSTALLED AFTER THE SYSTEM HAS BEEN INITIALIZED WITH A COLD RESTART, WHAT PROGRAMMING MUST BE IMPLEMENTED?

20. THE OMNI SBCS CAN SUPPORT _____ 40 BUTTON AND _____ 80 BUTTON BLF/DSS MODULES.

21. HOW MANY BLF/DSS MODULES CAN BE ADDED TO A STATION? _____

Review Exercise — Programming Station Instruments and BLF/DSS Modules (2.2) (Continued)



GTE OMNI SBCS

22. MATCH THE DEFINITION OF EACH PARAMETER WITH ITS CORRECT LOCATION IN CMC-210:

- | | |
|----------|--|
| _____ P1 | A. STATION DIRECTORY NUMBER OF EKT ATTACHED TO BLF/DSS |
| _____ P2 | B. BLF/DSS TYPE |
| _____ P3 | C. COPIED DSN |
| _____ P4 | D. BLF/DSS MODULE NUMBER |
| _____ P5 | E. EQUIPMENT NUMBER |
| _____ P6 | F. BLF/DSS ORDER |

23. DESCRIBE THE TWO WAYS IN WHICH BUTTONS CAN BE ASSIGNED TO A BLF/DSS MODULE.

- (1) _____
- (2) _____

24. A BLF/DSS CAN HAVE _____ "DSS PARK" BUTTONS ASSIGNED TO IT.

25. A BLF/DSS CAN HAVE _____ "DSS CAMP ON" BUTTONS ASSIGNED TO IT.

26. WHAT IS THE PURPOSE OF THE "ALTERNATE" FEATURE BUTTON ON A BLF/DSS? _____

27. WHAT PARAMETERS AND P VALUES ARE REQUIRED IF "AUTOMATIC INTERCOM" IS ASSIGNED TO A BLF/DSS BUTTON?

Review Exercise — Programming Station Instruments and BLF/DSS Modules (2.2) (Continued)



GTE OMNI SBCS

28. MATCH THE DEFINITION OF EACH PARAMETER WITH ITS CORRECT LOCATION IN CMC-211:

- | | |
|----------|--|
| _____ P1 | A. BUTTON NUMBER |
| _____ P2 | B. STATION DIRECTORY NUMBER OF EKT ATTACHED TO BLF/DSS |
| _____ P3 | C. TYPE OF DSS FEATURE ASSIGNMENT |
| _____ P4 | D. DIRECTORY NUMBER |
| _____ P5 | E. RINGING MODE |
| _____ P6 | F. LINE TERMINATION TYPE FOR LINE ACCESS |

29. THE BLF/DSS MODULE BUTTON NUMBERING PLAN IS ORDERED: _____

- A. LEFT TO RIGHT DOWNWARD
- B. RIGHT TO LEFT DOWNWARD
- C. RIGHT TO LEFT UPWARD
- D. LEFT TO RIGHT UPWARD

30. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DESCRIPTION.

- | | |
|---------------|---|
| _____ CMC-200 | A. EKT BUTTON ASSIGNMENT |
| _____ CMC-201 | B. BLF/DSS BUTTON ASSIGNMENT |
| _____ CMC-203 | C. STATION DATA ASSIGNMENT |
| _____ CMC-204 | D. BLF/DSS EQUIPMENT ASSIGNMENT |
| _____ CMC-210 | E. STATION DIRECTORY ASSIGNMENT |
| _____ CMC-211 | F. DATA SECURITY AND OFF-PREMISES EXTENSION DESIGNATION |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Basic

Trunk Data



2.3 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PERIPHERALS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- LABORATORY ACTIVITY — PROGRAMMING BASIC TRUNK DATA
- REVIEW EXERCISE

ACTION:

- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - INSTALL AND MODIFY BASIC TRUNK LINE DATA FOR CO, TIE, AND SCC.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Basic Trunk Data — Default Standard Trunk Assignments



GTE OMNI SBCS

DESCRIPTION

- ALL CO TRUNK LINES ARE PLACED IN TRUNK GROUP 13. TRUNK GROUPS MAY BE DIAL ACCESSED VIA FEATURE ACCESS CODES (FEATURE NUMBERS 4-27).
- TRUNK INSTALLATION ASSUMES DEFAULT STANDARD DATA BASE ASSIGNMENTS FOR TYPE OF TRUNK CARD (4BWC, 2TTE, OR 2TTL) BEING INSTALLED.
- DEFAULT TRUNK ASSIGNMENT DATA:

	TRUNK CARDS			
	2TTE	2TTL	4DMR	4BWC
Type of Terminal	3-E&M	2-Loop	1-DTMF	6-CO
Incoming/Outgoing	3-BW	3-BW	Blank	3-BW
Trunk Group Number (TGN)	31	32	1	13
Line Type	1-Ground	2-Loop	Blank	2-Loop
Dial/Receive Send	2-Delay	2-Delay	Blank	Blank
Signal Type/Break Ratio	2-10/60%	2-10PSS/60%	Blank	2-10PSS/60%
COS	1	1		1
NCOS	1	1		1
COR	1	1		1
NCOR	1	1		1

1 = CO — BOTHWAY CO TRUNK
 2 = BW — BOTHWAY TERMINATION
 3 = NUMBERS REFER TO DATA BASE PARAMETERS ENTRIES.

- TIE TRUNK GROUP — IF 2TTL OR 2TTE (E&M) CARDS ARE INSTALLED TO CARD SLOTS 06 TO 18, OMNI SBCS WILL GROUP THESE TIE TRUNK GROUPS (TIE #1 AND #2). IDLE TRUNK IN GROUP CAN BE ACCESSED BY DIALING "80" FOR TIE #1 (2TTE) OR "82" FOR TIE #2 (2TTL).
- DTMF RECEIVER — 4DMR CARDS INSTALLED IN CARD SLOTS 06 TO 14 ARE GROUPED INTO TGN1 (SEE CMC-250). THESE DMTF RECEIVERS ARE AVAILABLE FOR TYPE-2500 SLT INSTRUMENTS TO ORIGINATE CALLS OR ACCESS FEATURES.
- CO TRUNK GROUP — 4BWC CARDS INSTALLED IN CARD SLOTS 06 TO 18 WILL BE GROUPED INTO A CO TRUNK GROUP NUMBER THIRTEEN (CO #1). IDLE TRUNK IN GROUP CAN BE ACCESSED BY PRESSING TRUNK (OUT), ON CS 10 OR CS 20 OR BY DIALING "75".
- TERMINATING CALLS TO TRUNK GROUP WILL BE ROUTED TO TRUNK (IN), ON CS-10 OR CS-20 INSTRUMENTS WITH STATION NUMBER 208 THROUGH 215 (CARD SLOT 01).

Programming Basic Trunk Data/Trunk Installation



GTE OMNI SBCS

PROCEDURE * (REFER TO OMNI SBCS GTEP MANUAL, DATA BASE PROGRAMMING SECTION)

1. USE CMC-250 TO ASSIGN/ADD TRUNK

- TRUNK EQUIPMENT NUMBER (P1)
- TYPE OF TRUNK (P2)
- TRUNK GROUP NUMBER (P3)
- OPERATION MODE (P4)
- SIGNALING (P5)
- ZONE NUMBER AND START MODE (P6)

CMC=250
P1: 182 P4: 3
P2: 6 P5: 2
P3: 14 P6: 1

2. USE CMC-251 TO ASSIGN TRUNK DATA ASSOCIATED WITH INSTALLED TRUNK.

- EQUIPMENT NUMBER (P1)
- DIAL PULSE OR DTMF (P2)
- TRUNK DIRECTORY NUMBER (P3)
- TENANT NUMBER (OPTIONAL) (P4)

CMC = 251
P1: 182 P4: 2
P2: 5
P3: 182

3. USE CMC-306 (IF APPLICABLE) TO ASSIGN TRUNK FOR NIGHT RING DESTINATION.

*ASSUMES TRUNK CARD IS SEATED IN APPROPRIATE CARD SLOT AND TRUNK LINE IS PHYSICALLY CONNECTED TO DESIRED SLOT AND CIRCUIT.

Programming Basic Trunk Data/Trunk Modification



GTE OMNI SBCS

PROCEDURE * (REFER TO OMNI SBCS GTEP MANUAL, DATA BASE PROGRAMMING SECTION)

1. USE CMC-250 TO REMOVE TRUNK FROM ASSIGNED GROUP.* THIS OPERATION ALSO AFFECTS OTHER CMC TABLES BY:
 - AUTOMATICALLY REMOVING TRUNK DATA ASSIGNMENTS FROM CMC-251.
AND
 - AUTOMATICALLY REMOVES TRUNK FROM THE TERMINATING TRUNK GROUP.
2. USE CMC-307 (IF APPLICABLE) TO REMOVE TRUNK FROM DIRECT IN-LINE ASSIGNMENT.
3. USE CMC-306 (IF APPLICABLE) TO REMOVE TRUNK FROM NIGHT RINGING DESTINATION ASSIGNMENT.
4. ASSIGN TRUNK USING PROCEDURES FOR ADDING TRUNKS (SEE STUDENT WORKBOOK).

*TRUNK MUST BE REMOVED FROM ANY BUTTON ASSIGNMENTS (CMC-203) PRIOR TO REMOVAL OF TRUNK FROM ASSIGNED TRUNK GROUP.

Programming Basic Trunk Data/ Specialized Common Carrier



GTE OMNI SBCS

DESCRIPTION

ALLOWS STATION USER TO PLACE OUTGOING CALLS VIA CO LINE TO ACCESS SCC NETWORK (SPRINT, MCI, ETC.). SBCS SYSTEM AUTOMATICALLY SEIZES CO TRUNK, OUTPUTS DIRECTORY NUMBER OF DESIGNATED SCC SWITCH TO CO AND OUTPUTS REQUIRED SECURITY CODE AND DESTINATION DIRECTORY NUMBER TO SCC SWITCH.

PROCEDURE * (REFER TO OMNI SBCS GTEP MANUAL, DATA BASE PROGRAMMING SECTION)

1. USE CMC-404 TO ASSIGN:

- SCC ROUTE NUMBER (WHICH CORRESPONDS TO DESIGNATED TRUNK GROUP NUMBER) (P1)
- SCC GATE OFFICE DIRECTORY NUMBER (P2)
- SCC SECURITY CODE (P3)
- REQUIRED SCC DEFAULT TIMING VALUES (P4)

CMC=404
P1: 2 P4: 0200
P2: 9500777
P3: 3241111

NOTE: TIME INTERVAL REQUIRED (IN SECONDS) BETWEEN SENDING SCC GATE DN AND SENDING SECURITY CODE
AND

TIME INTERVAL (IN SECONDS) BETWEEN SENDING SECURITY CODE AND CALLED PARTY DIRECTORY NUMBER

2. USE CMC-405 (WHEN OUTGOING TRUNK CALLS ARE USING DIFFERENT FACILITY TO REACH SCC) TO ASSIGN:

- SCC TRUNK GROUP NUMBER (P1)
- ASSOCIATED ROUTING DESTINATION TRUNK GROUP NUMBER (P2)

CMC = 405
P1: 52
P2: 14

* ASSUMES TRUNK CARD HAS BEEN SEATED IN APPROPRIATE SLOT.

Programming Basic Trunk Data/ CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• TRUNK GROUP ASSIGNMENT	250	ASSIGN TRUNK CIRCUITS TO TRUNK GROUPS.
• TERMINATING TRUNK GROUP ASSIGNMENT	253	ASSIGN TRUNKS TO TERMINATING TRUNK GROUP MEMBERS.
• TRUNK DATA ASSIGNMENT	251	ASSIGNS A DIRECTORY NUMBER TO A TRUNK, ASSIGN TO TENANT, SET TRUNK PARAMETERS IF NECESSARY.
• NIGHT ANSWER ASSIGNMENT	306	ASSIGN TRUNKS TO NIGHT ANSWER GROUP.
• DIRECT-IN LINE ASSIGNMENT	307	ASSIGNS A DIRECT-IN TRUNK CIRCUIT TO A DIRECTORY NUMBER.
• SPECIALIZED COMMON CARRIER (SCC) ASSIGNMENT	404	ASSIGNS IDENTITY DIGITS FOR SCC TRUNK ROUTE TABLE.

Laboratory Activity – Programming Basic Data Trunk



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO THE BASIC TRUNK PROGRAMMING UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.3	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.3 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none"> • Add, modify, or remove a trunk with CMC-250. • Remove a terminating trunk group number assignment with CMC-253 (prior to removing a trunk with CMC-250). 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Assign CO trunk at slot 18, circuit 2 as a music source. (Remainder of programming for music-on-hold will be addressed in a later laboratory activity). (2) Change the CO trunk at slot 18, circuit 1 to Trunk Group number 14. (3) Remove the E & M tie trunk at slot 17, circuit 0. (4) Change the CO trunk at slot 18, circuit 0 to a WATS trunk. 	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Check all appropriate CMC tables before removing trunks. (2) Perform basic programming changes for trunks. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Proceed to next work order task.

Laboratory Activity – Programming Basic Trunk Data (Continued)



GTE OMNI SBCS

WORK ORDER #2.3	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.3 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none"> • Restore E & M tie line assignment with CMC-250. • Assign dial mode and break ratio with CMC-251. • Assign tenant number to trunks with CMC-251. 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Return the E & M tie line to slot 17 circuit 0. (2) Change the dial mode for trunks at slot 18, circuits 0 and 1 to DTMF. (3) Assign the CO trunk at slot 18, circuit 1 to tenant group 1. <p><u>NOTE:</u> Programming of tenant groups will be addressed in greater detail in a later laboratory activity.</p>	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Perform programming changes for dial mode and tenant assignment. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity – Programming Basic Trunk Data (Continued)



GTE OMNI SBCS

WORK ORDER #2.3	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.4 (TASK #5)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Establish and assign an SCC trunk with CMC-404 and CMC-405. • Restore default tenant group status with CMC-251. • Restore CO trunk with CMC-250. 	
PARAMETERS: <ol style="list-style-type: none"> Assign an SCC trunk with CMC-404 using the following parameters: Route Number = 1 SCC Gate Office Directory Number (for SPRINT) = 9500777 TM1 and TM2 Timing Values = 02 00 Access code = 123456 Assign the above Trunk Group Number to an SCC routing destination trunk group with CMC-405 using the following parameters: SCC Trunk Group Number = 51 Routing Destination Trunk Group Number = 14 Restore the default tenant group status of the CO trunk at slot 18, circuit 1 to no tenant assignment. Restore CO trunk with CMC-250. 	INSTRUCTIONS: <ol style="list-style-type: none"> Perform basic trunk programming changes. Check/test the operation of changes after completion of this portion of the laboratory activity. Complete Review Exercise Questions 1-17.

LAB MILESTONE:
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. • ASK INSTRUCTOR TO INSPECT TRUNK CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN QUESTIONS 1-17 OF REVIEW EXERCISE 2.3 HAVE BEEN COMPLETED BEFORE COMPLETING THE REMAINING WORK ORDERS.

Review Exercise — Programming Basic

Trunk Data (2.3)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. IDENTIFY THE EQUIPMENT NUMBERS FOR EACH TRUNK WHEN IT WAS INITIALLY INSTALLED:

- CO _____
- CO _____
- CO _____
- CO (MUSIC SOURCE) _____
- TIE (LOOP) _____
- TIE (LOOP) _____
- TIE (E&M) _____
- TIE (E&M) _____

2. SELECT THE DEFAULT STANDARD OPERATION MODE FOR CO TRUNKS: _____

- A. OGT (OUTGOING TRUNK)
- B. BWC (BOTHWAY TRUNK)
- C. ICT (INCOMING TRUNK)

3. WHAT CMC TABLE ENTRIES MUST BE REMOVED PRIOR TO REMOVING A TRUNK FROM A TRUNK GROUP WITH CMC-250?

Review Exercise — Programming Basic Trunk Data (2.3)



GTE OMNI SBCS

4. SELECT THE TYPES OF SIGNALING WHICH ARE AVAILABLE WHEN ADDING TRUNKS: _____
 - A. WINK, DELAY, OR IMMEDIATE
 - B. E&M OR INCOMING
 - C. DIAL PULSE OR DTMF
 - D. GROUND OR LOOP

5. IDENTIFY THE DEFAULT STANDARD TRUNK GROUP NUMBERS FOR THE FOLLOWING TRUNKS:
_____ CO

_____ E&M TIE

_____ LOOP START TIE

6. WHAT ARE THE REQUIRED PARAMETERS WHEN ADDING A WATS TRUNK LINE WITH CMC-250?

7. WHY WOULD A "NOT RGTR" MESSAGE BE DISPLAYED WHEN ADDING TRUNK EQUIPMENT NUMBER 184 IN THE LAB?

Review Exercise — Programming Basic

Trunk Data (2.3)



GTE OMNI SBCS

8. WHAT ERROR MESSAGE WILL BE DISPLAYED IF A LOOP TIE TRUNK IS ADDED AT CMC-250 WITH A VALUE OF 1 ENTERED FOR PARAMETER 5? _____

9. CIRCUITS ON THE _____ CARD ARE ASSIGNED TO TRUNK GROUP NUMBER 1 BY DEFAULT.
10. WHAT ARE THE ADVANTAGES OF CHANGING A TRUNK'S DIAL MODE TO DTMF? _____

11. THE OMNI SBCS WILL ALLOW _____ TENANT TRUNK GROUPS.
12. WHAT OCCURS WHEN A STATION FROM A DIFFERENT TENANT GROUP TRIES TO ACCESS A TRUNK THAT IS NOT IN THEIR TENANT GROUP? _____

13. IN THE LAB, ATTEMPT TO REMOVE ONE OF THE CO TRUNKS WITH CMC-250 WITHOUT CHANGING CMC-251. WHAT HAPPENS TO THE DIAL MODE AND BREAK RATIO AT CMC-251?

14. EXPLAIN THE DIFFERENCE BETWEEN TM1 AND TM2 TIMING VALUES WHEN ASSIGNING AN SCC TRUNK.

Review Exercise — Programming Basic

Trunk Data (2.3)



GTE OMNI SBCS

15. WHAT IS THE DEFAULT FEATURE ACCESS CODE FOR EACH TRUNK ACCESS:

- ___ CO #1
- ___ WATS #1
- ___ TIE #1 (E&M)
- ___ TIE #2 (LOOP)
- ___ SCC #1

16. MATCH EACH OF THE FOLLOWING TERMS WITH ITS CORRECT DEFINITION:

- | | |
|------------------------------------|---|
| ___ TRUNK FEATURE ACCESS CODES | A. USED BY SYSTEM TO ACCESS SCC NETWORK |
| ___ TRUNK GROUP NUMBER | B. GROUND OR LOOP START |
| ___ SIGNALING | C. ASSIGNMENT IDENTIFYING GROUPS OF TRUNKS TERMINATING TO STATION INSTRUMENTS |
| ___ DIAL MODE/BREAK RATIO | D. DIAL PULSE OR DTMF |
| ___ TERMINATING TRUNK GROUP NUMBER | E. CARD SLOT AND CIRCUIT NUMBER |
| ___ TRUNK EQUIPMENT NUMBER | F. ALLOWS DIRECT CONNECTION TO SPECIFIC TRUNK GROUPS |
| ___ GATE OFFICE DIRECTORY NUMBER | G. ASSIGNMENT GROUP BASED ON TYPE OF TRUNKS. |

17. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DESCRIPTION.

- | | |
|-------------|--|
| ___ CMC-250 | A. NIGHT ANSWER ASSIGNMENT (STATIONS AND TRUNKS) |
| ___ CMC-251 | B. SCC ROUTING TRUNK GROUP NUMBER ASSIGNMENT |
| ___ CMC-253 | C. TRUNK DATA ASSIGNMENT |
| ___ CMC-306 | D. TRUNK ASSIGNMENT |
| ___ CMC-307 | E. SCC ASSIGNMENT |
| ___ CMC-404 | F. DIRECT-IN LINE ASSIGNMENT |
| ___ CMC-405 | G. TERMINATING TRUNK GROUP ASSIGNMENT |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Trunk Terminations



2.4 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PERIPHERALS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- LABORATORY ACTIVITY — PROGRAMMING TRUNK TERMINATIONS
- REVIEW EXERCISE

ACTION:

- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - ASSIGN A DIRECT-IN LINE.
 - ASSIGN KEY SYSTEM TRUNK LINE TO EKT STATION.
 - CREATE A PERSONAL/PRIVATE TRUNK LINE.
 - ASSIGN POOLED INCOMING TRUNK LINES.
 - ASSIGN POOLED OUTGOING TRUNK LINES.
 - ASSIGN POOLED BOTHWAY TRUNK LINES.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Trunk Terminations/ Overview



GTE OMNI SBCS

DESCRIPTION

- TRUNKS CAN BE TERMINATED TO SINGLE LINE TELEPHONE SETS OR TO BUTTONS ON ELECTRONIC KEY TELEPHONE SETS.
- DEFAULT STANDARD DATA BASE ASSIGNS ALL TRUNK GROUPS TO TRUNK GROUP 13 UPON INSTALLATION.
- TERMINATING TRUNK GROUP (TTGN) ASSIGNMENTS MUST BE SPECIFIED TO TERMINATE TRUNKS TO STATION INSTRUMENTS.
- TYPES OF TRUNK TERMINATIONS:
 - DIRECT-IN TRUNK LINE — DIRECT TERMINATION OF CO TRUNK LINE TO SLT OR EKT INSTRUMENT, BYPASSING A BLF/DSS ANSWERING STATION. DOES NOT REQUIRE TERMINATION TO BUTTON ON EKT.
 - KEY SYSTEM TRUNK LINE — EMULATES OPERATION OF TRADITIONAL KEY TELEPHONE SYSTEM BY ONE OR MORE EKT STATION'S BUTTONS BEING PROGRAMMED TO HAVE ACCESS TO A SPECIFIC TRUNK LINE.
 - PERSONAL/PRIVATE LINE — RESERVES ONE TRUNK LINE FOR INCOMING AND/OR OUTGOING CALLS FOR ONE SPECIFIC EKT STATION.
 - POOLED INCOMING TRUNK GROUP — ALLOWS INCOMING TRUNK LINES TO BE POOLED INTO A TERMINATING TRUNK GROUP CONNECTED TO MULTIPLE STATIONS (BYPASSING A BLF/DSS ANSWERING STATION). EACH CONNECTED STATION WILL HAVE LINE APPEARANCE OF INCOMING TRUNK.

Programming Trunk Terminations/ Overview (Continued)



GTE OMNI SBCS

POOLED OUTGOING TRUNK GROUP — ALLOWS OUTGOING TRUNK LINES TO BE POOLED INTO A TERMINATING TRUNK GROUP CONNECTED TO MULTIPLE STATIONS. EACH CONNECTED STATION WILL HAVE LINE APPEARANCE FOR OUTGOING POOLED TRUNKS WITH ACCESS TO CO, WATS, OR FX TRUNK CALLS.

POOLED BOTHWAY TRUNK GROUP — ALLOWS BOTHWAY TRUNK LINES TO BE POOLED INTO A TERMINATING TRUNK GROUP CONNECTED TO MULTIPLE STATIONS. EACH CONNECTED STATION WILL HAVE LINE APPEARANCE FOR TWO-WAY POOLED TRUNKS WITH DIRECT ACCESS TO INCOMING OR OUTGOING CAPABILITIES.

Programming Trunk Terminations Possible Trunk/Station/EKT Button Assignments



GTE OMNI SBCS


TYPE	MAX. NO. OF BUTTONS/EKT	APPEARANCES (NO. OF MULTIPLE LINES)	NO. OF TRUNKS ASSIGNMENTS TO KEYS	REMARKS
POOLED INCOMING TRUNK GROUP	BUTTONS OTHER THAN FEATURE ACCESS BUTTONS	16/TRUNK GROUP	1 TRUNK GROUP PER BUTTON	A BOTHWAY TRUNK ASSIGNED TO THIS TRUNK GROUP CANNOT BE ASSIGNED TO AN OUTGOING TRUNK GROUP SIMULTANEOUSLY
KEY SYSTEM LINE	BUTTONS OTHER THAN FEATURE ACCESS BUTTONS	16/TRUNK	1 TRUNK PER BUTTON	1 TRUNK/GROUP
PERSONAL/ PRIVATE LINE	BUTTONS OTHER THAN FEATURE ACCESS BUTTONS	1/TRUNK	1 TRUNK PER BUTTON	1 TRUNK/GROUP
POOLED OUTGOING TRUNK GROUP	BUTTONS OTHER THAN FEATURE ACCESS BUTTONS	NOT LIMITED	1 TRUNK GROUP PER BUTTON	A BOTHWAY TRUNK ASSIGNED TO THIS TRUNK GROUP CANNOT BE ASSIGNED TO AN INCOMING TRUNK GROUP SIMULTANEOUSLY
POOLED BOTHWAY TRUNK GROUP	BUTTONS OTHER THAN FEATURE ACCESS BUTTONS	16/TRUNK GROUP	1 TRUNK GROUP PER BUTTON	BOTHWAY TRUNKS CAN BE ASSIGNED TO THIS LINE TYPE
DIRECT-IN LINE	NO BUTTON (INTERCOM)	1/TRUNK	NOT ASSIGNABLE TO KEYS	

NOTE: MAXIMUM OF 31 TRUNK GROUPS CAN BE ASSIGNED

Programming Trunk Terminations/Diagram of Trunk Termination Assignments



GTE OMNI SBCS



Programming Trunk Terminations/ Direct-in Trunk Line Assignment



GTE OMNI SBCS

DESCRIPTION

- PROVIDES DIRECT TERMINATION OF ONE CO TRUNK TO SLT OR EKT, BYPASSING A BLF/DSS ANSWERING STATION.
- CAN BE BOTHWAY OR INCOMING TRUNK LINE.
- MULTIPLE DIRECT-IN TRUNK LINES CAN BE ASSIGNED TO ONE STATION.
- ONLY ONE STATION ASSIGNMENT CAN BE MADE PER TRUNK LINE.
- STATION WILL RING ON INTERCOM AND NO LED WILL LIGHT ON EKT INSTRUMENT.
- TOLL RESTRICTIONS APPLY, BUT LCR AND SCC NOT AVAILABLE.

PROCEDURE

1. USE CMC-307 TO ASSIGN TRUNK LINE TO DESIGNATED SLT OR EKT STATION:
 - TRUNK EQUIPMENT NUMBER (P1)
 - DIRECTORY NUMBER OF TERMINATED STATION (P2)

*ASSUMES TRUNK HAS BEEN REMOVED FROM ANY TTGN ASSIGNMENT.

CMC=307
P1: 161
P2: 215

Programming Trunk Terminations/ Key System Trunk Line Assignment



GTE OMNI SBCS

DESCRIPTION

- EMULATES OPERATION OF TRADITIONAL KEY TELEPHONE SYSTEM BY RESERVING ONE TRUNK LINE FOR UP TO 16 EKT STATIONS.
- TERMINATES TO ONE BUTTON ON EKT.
- UTILIZES BOTHWAY, OUTGOING, OR INCOMING TRUNK LINE.
- TOLL RESTRICTIONS APPLY, BUT LCR AND SCC NOT AVAILABLE.

PROCEDURE *

1. USE CMC-253 to assign:
 - TERMINATING TRUNK GROUP (P1)
 - EQUIPMENT NUMBER (P2)
 - TRUNK TERMINATION FLAG (P3)

CMC=253
P1: 3
P2: 152
P3: 2

NOTE: ENSURE THAT TRUNK TYPE VALUE FOR CMC-250 (PARAMETER 4).
MATCHES THE TRUNK TYPE VALUE FOR CMC-253 (PARAMETER 3).

2. USE CMC-203 TO ASSIGN TTGN TO DESIGNATED EKT BUTTON:
 - STATION DIRECTORY NUMBER (P1)
 - BUTTON NUMBER (P2)
 - FEATURE NUMBER (P3)
 - SUPPLEMENTARY DATA (P4)
 - LINE TERMINATION TYPE (P5)
 - RINGING MODE (P6)

CMC=203
P1: 502 P4: 3
P2: 7 P5: 2
P3: 5 P6: 1

3. USE CMC-251 TO ASSIGN TRUNK DIRECTORY NUMBER AND TENANT NUMBER (IF APPLICABLE).

Programming Trunk Terminations/ Personal-Private Trunk Line Assignment



GTE OMNI SBCS

DESCRIPTION

- RESERVES ONE TRUNK LINE FOR A SINGLE EKT STATION BUTTON.
- UTILIZES BOTHWAY, OUTGOING, OR INCOMING TRUNK LINE.
- BYPASSES BLF/DSS ANSWERING STATION AND CALLS CANNOT BE PICKED UP BY ANY OTHER STATION.
- TOLL RESTRICTIONS APPLY, BUT LCR AND SCC NOT AVAILABLE.

PROCEDURE *

1. USE CMC-253 to assign:
 - TERMINATING TRUNK GROUP (P1)
 - EQUIPMENT NUMBER (P2)
 - TRUNK TERMINATION FLAG (P3)
2. USE CMC-203 TO ASSIGN TTGN TO DESIGNATED EKT BUTTON:
 - STATION DIRECTORY NUMBER (P1)
 - BUTTON NUMBER (P2)
 - FEATURE NUMBER (P3)
 - SUPPLEMENTARY DATA (P4)
 - LINE TERMINATION TYPE (P5)
 - RINGING MODE (P6)
3. USE CMC-251 TO ASSIGN TRUNK DIRECTORY NUMBER AND TENANT NUMBER (IF APPLICABLE).

CMC=253
P1: 4
P2: 142
P3: 1

CMC=203
P1: 308 P4: 4
P2: 6 P5: 1
P3: 6 P6: 1

*ASSUMES TRUNK HAS BEEN REMOVED FROM ANY PREVIOUS TTGN ASSIGNMENT.

Programming Trunk Terminations/Pooled Incoming Trunk Lines Assignments



GTE OMNI SBCS

DESCRIPTION

- ALLOWS INCOMING TRUNK LINES TO BE POOLED INTO ONE TTGN — NO LIMIT ON NUMBER OF TRUNKS PLACED IN TTGN.
- UTILIZES BOTHWAY AND/OR INCOMING TRUNKS, BUT BOTHWAY TRUNKS WILL BE LIMITED TO INCOMING CAPABILITIES ONLY.
- BYPASSES BLF/DSS ANSWERING STATION.
- CAN APPEAR AT MULTIPLE STATIONS (16 MAXIMUM) AND TO ANY NUMBER OF DESIGNATED BUTTONS ON AN EKT INSTRUMENT.
- ONE BUTTON PER TRUNK GROUP SHOULD BE ASSIGNED.

PROCEDURE *

1. USE CMC-253 TO CREATE POOLED INCOMING TTGN GROUP:
 - TERMINATING TRUNK GROUP (P1)
 - EQUIPMENT NUMBER (P2)
 - TRUNK TERMINATION FLAG (P3)
2. USE CMC-203 TO ASSIGN TTGN TO DESIGNATED EKT BUTTONS ON DESIRED STATIONS:
 - STATION DIRECTORY NUMBER (P1)
 - BUTTON NUMBER (P2)
 - FEATURE NUMBER (P3)
 - SUPPLEMENTARY DATA (P4)
 - LINE TERMINATION TYPE (P5)
 - RINGING MODE (P6)
3. IF APPLICABLE, USE CMC-251 TO ASSIGN TRUNK TO TENANT GROUP.

CMC=253
P1: 7
P2: 143
P3: 4

CMC=203
P1: 308 P4: 7
P2: 6 P5: 1
P3: 6 P6: 1

*ASSUMES TRUNK HAS BEEN REMOVED FROM ANY PREVIOUS TTGN ASSIGNMENT.

Programming Trunk Terminations/Pooled Outgoing Trunk Lines Assignment



GTE OMNI SBCS

DESCRIPTION

- ALLOWS OUTGOING TRUNK LINES TO BE POOLED INTO ONE TTGN — NO LIMIT ON NUMBER OF TRUNKS PLACED IN TTGN.
- UTILIZES BOTHWAY AND/OR OUTGOING TRUNKS, BUT BOTHWAY TRUNKS WILL BE LIMITED TO OUTGOING CAPABILITIES ONLY.
- DATA SECURITY OF LINE IS AUTOMATIC.
- CAN APPEAR AT MULTIPLE STATIONS (16 MAXIMUM) AND TO ANY NUMBER OF DESIGNATED BUTTONS ON AN EKT INSTRUMENT.
- TOLL RESTRICTIONS APPLY, BUT LCR AND SCC NOT AVAILABLE.

PROCEDURE *

1. USE CMC-253 TO ASSIGN:
 - TERMINATING TRUNK GROUP (P1)
 - EQUIPMENT NUMBER (P2)
 - TRUNK TERMINATION FLAG (P3)
2. USE CMC-203 TO ASSIGN TTGN TO DESIGNATED EKT BUTTONS ON DESIRED STATIONS:
 - STATION DIRECTORY NUMBER (P1)
 - BUTTON NUMBER (P2)
 - FEATURE NUMBER (P3)
 - SUPPLEMENTARY DATA (P4)
 - LINE TERMINATION TYPE (P5)
 - RINGING MODE (P6)
3. IF APPLICABLE, USE CMC-251 TO ASSIGN TRUNK TO TENANT GROUP.

CMC=253
P1: 8
P2: 151
P3: 3

CMC=203
P1: 308 P4: 8
P2: 6 P5: 1
P3: 6 P6: 1

*ASSUMES TRUNK HAS BEEN REMOVED FROM ANY PREVIOUS TTGN ASSIGNMENT.

Programming Trunk Terminations/ Pooled Bothway (Two-Way) Trunk Lines Assignment



GTE OMNI SBGS

DESCRIPTION

- ALLOWS INCOMING TRUNK LINES TO BE POOLED INTO ONE TTGN.
- UTILIZES BOTHWAY ONLY.
- BYPASS BLF/DSS ANSWERING STATION.
- CAN APPEAR AT MULTIPLE STATIONS (16 MAXIMUM) AND TO ANY NUMBER OF DESIGNATED BUTTONS ON AN EKT INSTRUMENT.
- NO LIMIT PLACED ON NUMBER OF TRUNKS PLACED IN TTGN, BUT ONLY POOLED BOTHWAY TRUNKS MAY BE ASSIGNED.

PROCEDURE *

NOTE: IF TRUNK CARD WERE SEATED AT TIME OF COLD RESTART, THE DEFAULT DATA BASE PLACES ALL TRUNKS IN TTGN 1 AND DESIGNATES THEM AS BOTHWAY TRUNKS.

1. (IF TRUNK CARDS WERE UNSEATED) USE CMC-253 TO ASSIGN:
 - TERMINATING TRUNK GROUP (P1)
 - EQUIPMENT NUMBER (P2)
 - TRUNK TERMINATION FLAG (P3)
2. USE CMC-203 TO ASSIGN TTGN TO DESIGNATED EKT BUTTONS ON DESIRED STATIONS:
 - STATION DIRECTORY NUMBER (P1)
 - BUTTON NUMBER (P2)
 - FEATURE NUMBER (P3)
 - SUPPLEMENTARY DATA (P4)
 - LINE TERMINATION TYPE (P5)
 - RINGING MODE (P6)
3. IF APPLICABLE, USE CMC-251 TO ASSIGN TRUNK TO TENANT GROUP.

CMC=253
P1: 9
P2: 172
P3: 3

CMC=203
P1: 308 P4: 9
P2: 6 P5: 1
P3: 6 P6: 1

*ASSUMES TRUNK HAS BEEN REMOVED FROM ANY PREVIOUS TTGN ASSIGNMENT.

Programming Trunk Terminations/ CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• TERMINATING TRUNK GROUPS	253	ASSIGNS DIRECT-IN, PERSONAL, KEY SYSTEM AND POOLED TRUNKS TO TERMINATING TRUNK GROUPS.
• EKT BUTTON ASSIGNMENT	203	ASSIGNS TTGN TO AN EKT BUTTON.
• TRUNK DATA	251	ASSIGNS DIRECTORY NUMBER AND TENANT NUMBER TO A TRUNK.
• DIRECT-IN LINE ASSIGNMENT	307	ASSIGNS DIRECT-IN LINE SERVICE.

Laboratory Activity — Programming Trunk Terminations



GTE OMNI SBCS

PERFORM THE FOLLOWING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO PROGRAMMING TRUNK TERMINATIONS UPON COMPLETION OF THIS LABORATORY AVTIVITY.

WORK ORDER #2.4	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.4 (TASK #1)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Pool bothway trunks into one Terminating Trunk Group Number. • Assign a key system type trunk line with CMC-253, CMC-250, CMC-203, and CMC-251. • Assign a personal/private line with CMC-253, CMC-203, and CMC-251. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Create a TTGN of 2 for the bothway CO trunks at slot 18, circuits 0 and 1 with CMC-253. (2) Assign the TTGN to a button on both CS-20 instruments with CMC-203. Select "ringing" option. (3) Assign a reserved key system trunk line to EKT buttons on station directory number 212 using the CO trunk at slot 18, circuit 0. (4) Assign a personal line to station directory number 308. Select the "no ringing" option when programming the EKT button with CMC-203 using the CO trunk at slot 18, circuit 1. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Ensure that trunks are removed from any previous TTGN assignments. (2) Perform programming changes for trunk termination. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Proceed to next work order task.

Laboratory Activity – Programming Trunk Terminations (Continued)



GTE OMNI SBCS

WORK ORDER #2.4	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.4 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none"> • Remove previously programmed key system and personal line. • Assign a direct-in line with CMC-307. 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Remove key system assignment from station directory number 212. (2) Remove personal line from station directory number 308. (3) Add a direct-in line assignment to station directory number 216 using the CO trunk at slot 18, circuit 0. 	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Ensure that trunks are removed from any previous TTGN assignments. (2) Perform programming changes from trunk terminations. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Proceed to next work order task.

Laboratory Activity – Programming Trunk Terminations (Continued)



GTE OMNI SBCS

WORK ORDER #2.4	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.4</u> (TASK #3)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> • Remove the previously programmed direct-in line assignment.	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
(1) Remove the previously assigned direct-in line from station directory number 216.	(1) Ensure that trunks are removed from any previous TTGN assignments. (2) Perform programming changes for trunk terminations. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Complete the review exercise questions 1-16.

LAB MILESTONE
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. • ASK INSTRUCTOR TO INSPECT THESE TRUNK TERMINATION CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN QUESTIONS 10 - 17 OF REVIEW EXERCISE 2.4 HAVE COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.

Review Exercise — Programming Trunk Terminations (2.4)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE DEFAULT STANDARD TERMINATING TRUNK GROUP NUMBER FOR CO TRUNKS IS _____ .
2. EKT INSTRUMENTS CAN HAVE _____ TERMINATING TRUNK GROUP NUMBERS ASSIGNED TO EACH BUTTON.
3. THE FLAG DESIGNATING PERSONAL LINES IS SET TO _____ AND FOR KEY SYSTEMS _____ AT CMC-253, P3.
4. HOW IS THE "RINGING/NO RINGING" OPTION PROGRAMMED FOR A TRUNK TERMINATION LINE BUTTON?

5. WHAT STEPS MUST BE PERFORMED BEFORE A KEY SYSTEM LINE CAN BE ASSIGNED TO A BUTTON WITH CMC-203?

6. IN WHAT TERMINATING TRUNK GROUP WAS THE PERSONAL LINE PLACED DURING THE LAB ACTIVITY? _____
7. A PERSONAL LINE RESERVES ONE TRUNK FOR INCOMING AND/OR OUTGOING CALLS FOR A SPECIFIC _____ STATION.

Review Exercise — Programming Trunk Terminations (2.4) (Continued)



GTE OMNI SBCS

8. IF A CUSTOMER DESIRES ONE OR MORE EKT STATIONS TO HAVE ACCESS TO THE SAME TRUNK LINE THROUGH EKT BUTTONS, A _____ TRUNK TERMINATION SHOULD BE PROGRAMMED.
9. THE SYSTEM WILL ALLOW A MAXIMUM _____ DIRECT IN-LINES PER TRUNK GROUP.
10. A DIRECT IN-LINE CAN BE ASSIGNED TO BOTH _____ OR _____ TYPES OF STATION INSTRUMENTS.
11. CMC- _____ IS USED TO ASSIGN OR REMOVE A DIRECT-IN LINE FROM A SPECIFIC STATION.
12. A MAXIMUM OF _____ POOLED INCOMING TRUNK LINES MAY BE ASSIGNED TO A TERMINATING TRUNK GROUP.
13. A POOLED _____ TRUNK GROUP IS A TYPE OF TRUNK TERMINATION WHERE A NUMBER OF OUTGOING TRUNKS FROM A SINGLE TRUNK GROUP ARE SHARED BY A TERMINATING TRUNK GROUP.
14. HOW DOES AN SLT OR A STATION WITHOUT A LINE TERMINATION BUTTON ASSIGNMENT ACCESS A POOLED BOTHWAY TRUNK?

15. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DESCRIPTION:
_____ CMC-203 A. DIRECT IN-LINE ASSIGNMENT
_____ CMC-250 B. TRUNK ASSIGNMENT
_____ CMC-253 C. EKT BUTTON ASSIGNMENT
_____ CMC-307 D. TERMINATING TRUNK GROUP ASSIGNMENT.



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Service

Functions



2.5 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — PROGRAMMING SERVICE FUNCTIONS
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - ESTABLISH A SYSTEM SPEED CALLING DIRECTORY.
 - ASSIGN STATIONS TO HUNT AND PICKUP GROUPS.
 - INSTALL AND ASSIGN SYSTEM MUSIC-ON-HOLD FEATURE.
 - CREATE HOT LINE SERVICE.
 - ASSIGN INTERNAL SPEAKER PAGING GROUPS.
 - ESTABLISH NIGHT RINGING ANSWER STATION.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Service Functions/System Speed Calling Directory



GTE OMNI SBCS

DESCRIPTION

- A MAXIMUM OF 100 DIRECTORY NUMBERS CAN BE PLACED IN A SYSTEM SPEED CALLING DIRECTORY. STATION USER DIALS AN ENTRY CODE TO ACCESS NUMBER ON SPEED CALLING LIST.
- DEFAULT STANDARD ACCESS CODE FOR SYSTEM SPEED CALLING NUMBER IS ##.

PROCEDURE

1. USE CMC-300 TO ASSIGN, CHANGE OR DELETE:
 - SYSTEM SPEED CALLING USER ENTRY CODE (P1)
 - ACCESS CODE (SYSTEM ACCESS CODES FOR CO, FX, WATS, TIE LINE, SCC OR LCR) (P2)
 - SEND NUMBER (P3)
2. USE CMC-100 TO CHANGE ACCESS CODE NUMBERING PLAN.

CMC=300
P1: 02
P2: 75
P3: 9361111

Programming Service Functions/ Station Hunt Group Assignment



GTE OMNI SBCS

DESCRIPTION

- STATION DIRECTORY NUMBER MAY BE ASSIGNED TO ONE OF THREE TYPES OF HUNT GROUPS:
 - CIRCULAR — IF CALLED DIRECTORY NUMBER IS BUSY, ALL STATIONS WITHIN GROUP ARE TRIED IN TURN UNTIL AN IDLE STATION IS FOUND. IF CALLED DIRECTORY NUMBER IS NOT REACHED AFTER CIRCULAR HUNTING, CALLING PARTY IS CONNECTED TO BUSY TONE.
 - TERMINATING — DIRECTORY NUMBERS WITHIN GROUP ARE ASSIGNED A PRIORITY. WHEN CALLED STATION IS BUSY, IDLE STATION IS HUNTED IN ORDER OF PROGRAMMED PRIORITY. CALLING PARTY IS CONNECTED TO BUSY TONE IF NO IDLE STATION IS FOUND.
 - PILOT — DIRECTORY NUMBER IS ASSIGNED AS PILOT STATION. IF PILOT IS BUSY, ALL STATIONS WITHIN GROUP ARE TRIED. IF NO IDLE STATION IS FOUND, CALLING PARTY IS CONNECTED TO BUSY TONE. IF OTHER DIRECTORY NUMBERS ARE BUSY, NO GROUP HUNT OCCURS SINCE HUNT MUST ORIGINATE FROM PILOT STATION.
- SYSTEM DEFAULT CAPACITY ALLOWS FOR MAXIMUM OF 10 VOICE OR DATA HUNT GROUPS WITH UP TO 16 DIRECTORY NUMBER MEMBERS IN EACH HUNT GROUP.*

PROCEDURE

1. USE CMC 301 TO ADD, CHANGE OR REMOVE:
 - STATION HUNTING GROUP NUMBER (P1)
 - TERMINATING ORDER (P2)
 - DIRECTORY NUMBER OF HUNT GROUP (P3)
 - HUNTING TYPE (P4)

CMC=301
P1: 2 P4: 2
P2: 3
P3: 412

- NOTES: 1. WHEN ENTERING PARAMETER FOR TERMINATING ORDER OF PILOT HUNT GROUP, FIRST DIRECTORY NUMBER ENTERED IS DESIGNATED PILOT STATION.
2. EXISTING ENTRIES MUST BE REMOVED BEFORE CHANGING HUNT GROUP ASSIGNMENTS.

* PACKAGE C ALLOWS 20 VOICE HUNT GROUPS.

Programming Service Functions/ Pickup Group Assignment



GTE OMNI SBCS

DESCRIPTION

- SYSTEM DEFAULT CAPACITY ALLOWS FOR MAXIMUM OF 10 PICKUP GROUPS WITH UP TO 32 DIRECTORY NUMBER MEMBERS IN EACH PICKUP GROUP.*

PROCEDURE

1. USE CMC-302 TO ADD CHANGE OR DELETE:

- PICKUP GROUP NUMBER (P1)
- DIRECTORY NUMBER OF PICKUP GROUP MEMBER (P2)

CMC= 302
P1: 10
P2: 517

NOTE: EXISTING ENTRIES MUST BE DELETED BEFORE CHANGING PICKUP GROUP DIRECTORY NUMBERS. CHANGE (CHG) PROGRAM FUNCTION IS USED TO ASSIGN NEW ENTRY.

*** PACKAGE C ALLOWS 20 PICKUP GROUPS.**

Programming Service Functions/ Hot Line Station Assignment



GTE OMNI SBCS

DESCRIPTION

- HOT LINE FEATURE ALLOWS FOR SINGLE-LINE STATIONS TO BE PROGRAMMED TO AUTOMATICALLY SIGNAL A TERMINATING INTERNAL STATION WHENEVER IT GOES OFF-HOOK.
- DESIGNATED HOT LINE STATIONS CAN ACCEPT TERMINATING CALLS AND USE CONSULTATION HOLD, TRANSFER, AND OTHER SERVICES.
- SYSTEM DEFAULT CAPACITY ALLOWS FOR A MAXIMUM OF 10 SYSTEM HOT LINES FOR VOICE (PACKAGES A AND B) AND 40 FOR DATA (PACKAGE B).

PROCEDURE

1. USE CMC-304 TO ASSIGN OR REMOVE:
 - HOT LINE NUMBER (P1)
 - ORIGINATING STATION DIRECTORY NUMBER (P2)
 - TERMINATING STATION DIRECTORY NUMBER (P3)

CMC= 304
P1: 2
P2: 500
P3: 523

NOTE: EXISTING ENTRIES MUST BE DELETED BEFORE CHANGING HOT LINE STATION ASSIGNMENTS. CHANGE (CHG) PROGRAM FUNCTION IS USED TO ASSIGN NEW ENTRY.

*** PACKAGE C ALLOWS 20 SYSTEM HOT LINES FOR VOICE AND 40 FOR DATA.**

Programming Service Functions/Internal Speaker Paging Group Assignment



GTE OMNI SBCS

DESCRIPTION

- INTERNAL PAGING IS ACCOMPLISHED BY UTILIZING SPEAKERS ON EKT INSTRUMENTS.
- PROXIMITY OF EKT INSTRUMENTS TO USERS SERVED WITHIN EACH GEOGRAPHIC PAGING ZONE MUST BE CONSIDERED WHEN ESTABLISHING PAGING ZONES.
- SYSTEM DEFAULT CAPACITY ALLOWS FOR MAXIMUM OF NINE PAGING ZONES (GROUPS) WITH UP TO FOUR EKT DIRECTORY MEMBERS ASSIGNED TO EACH ZONE.

PROCEDURE

1. USE CMC-303 TO ADD OR REMOVE:
 - PAGING GROUP (P1)
 - DIRECTORY NUMBER OF A PAGING GROUP MEMBER (P2)

CMC=303
P1:2
P2:346

NOTES: 1. EXISTING ENTRIES MUST BE DELETED WITH **REMOVE** (RMV) PROGRAM FUNCTION BEFORE CHANGING PAGING GROUPS ASSIGNMENTS. ADD (ADD) PROGRAM FUNCTION IS USED TO ASSIGN NEW ENTRY.

2. EXTERNAL PAGING WILL BE COVERED IN MODULE IV.

Programming Service Functions — Music-On-Hold



GTE OMNI SBCS

DESCRIPTION

- MUSIC-ON-HOLD SERVICE REQUIRES CUSTOMER PROVIDED 600 OHM IMPEDANCE MUSIC SERVICE

PROCEDURE

*

1. USE CMC-250 TO ASSIGN TYPE OF TRUNK.
2. USE CMC-305 TO ASSIGN:
 - EQUIPMENT NUMBER FOR MUSIC SOURCE (P1)

CMC=305
P1:182

- * ASSUMES TRUNK CARD (4BWC) HAS BEEN SEATED IN APPROPRIATE SLOT AND CUSTOMER PROVIDED MUSIC SOURCE HAS BEEN PHYSICALLY CONNECTED TO DESIRED SLOT AND CIRCUIT.

Programming Service Functions/ Night Answer Station Assignment



GTE OMNI SBCS

DESCRIPTION

- NIGHT ANSWER ASSIGNMENT ALLOWS INCOMING CALLS TO BE DIRECTED TO A SPECIFIC NIGHT ANSWER STATION OR TO ACTIVATE A NIGHT BELL WHICH ALLOWS A PICK-UP BY ANY INTERNAL STATION.
- SYSTEM DEFAULT CAPACITY IS 16 NIGHT ANSWER GROUPS* WITH UP TO 8 MEMBERS IN EACH GROUP.
- DEFAULT ACCESS CODE TO ANSWER NIGHT RINGING CALL IS #31 (ALL TENANT) OR #30 (SELF TENANT). NOTE: ACCESS CODE MAY BE CHANGED WITH CMC-100.
- AT LEAST ONE TRUNK AND ONE STATION MUST BE ASSIGNED TO INITIALIZE NIGHT ANSWER FEATURE.

PROCEDURE

1. USE CMC-306 TO ASSIGN:
 - NIGHT ANSWER GROUP NUMBER (P1)
 - TRUNK/STATION FLAG (P2)
 - EQUIPMENT NUMBER (P3)
2. USE CMC-201 AND CMC-251 (IF APPLICABLE) TO CHECK TENANT ASSIGNMENTS

CMC=306
P1:2
P2:1
P3:013

*PACKAGE C ALLOWS 32 NIGHT ANSWER GROUPS.

- NOTES:
- IF NIGHT BELL IS SELECTED FOR NIGHT ANSWER OPERATION, THE BELL MUST BE PROGRAMMED AS A STATION (ASSIGNED AN EQUIPMENT NUMBER), PHYSICALLY CONNECTED TO DESIRED CIRCUIT ON 8SLC CARD, AND RGEN MUST BE INSTALLED.
 - EXISTING TRUNK OR STATION ASSIGNMENTS MUST BE DELETED BY **REMOVE PROGRAM** FUNCTION BEFORE CHANGING OR REMOVING NIGHT GROUP ASSIGNMENTS.

Programming Service Functions/ CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
● SYSTEM SPEED CALLING DIRECTORY	300	ADDS, REMOVES, OR CHANGES SYSTEM SPEED CALLING DIRECTORY NUMBERS.
● STATION HUNT GROUP ASSIGNMENT	301	ASSIGNS, REMOVES, OR CHANGES VOICE OR DATA FROM ONE OF THREE TYPES OF HUNT GROUPS: CIRCULAR, TERMINATING OR PILOT.
● PICKUP GROUP ASSIGNMENT	302	ASSIGNS, REMOVES OR CHANGES STATIONS FROM PICK-UP GROUPS.
● EKT SYSTEM PAGING GROUP ASSIGNMENT	303	ASSIGNS, REMOVES OR CHANGES EKT STATIONS FROM PAGING ZONES.
● HOT LINE STATION ASSIGNMENT	304	ASSIGNS, REMOVES OR CHANGES STATIONS FROM HOT LINE SERVICE
● MUSIC ON HOLD ASSIGNMENT	305	ASSIGNS OR REMOVES MUSIC ON HOLD SERVICE
● NIGHT ANSWER STATION ASSIGNMENT	306	ASSIGNS, REMOVES OR CHANGES STATIONS OR TRUNKS FROM NIGHT RING GROUPS.

Programming Service Functions/ Night Answer Station Assignment



GTE OMNI SBCS

DESCRIPTION

- NIGHT ANSWER ASSIGNMENT ALLOWS INCOMING CALLS TO BE DIRECTED TO A SPECIFIC NIGHT ANSWER STATION OR TO ACTIVATE A NIGHT BELL WHICH ALLOWS A PICK-UP BY ANY INTERNAL STATION.
- SYSTEM DEFAULT CAPACITY IS 16 NIGHT ANSWER GROUPS* WITH UP TO 8 MEMBERS IN EACH GROUP.
- DEFAULT ACCESS CODE TO ANSWER NIGHT RINGING CALL IS #31 (ALL TENANT) OR #30 (SELF TENANT). NOTE: ACCESS CODE MAY BE CHANGED WITH CMC-100.
- AT LEAST ONE TRUNK AND ONE STATION MUST BE ASSIGNED TO INITIALIZE NIGHT ANSWER FEATURE.

PROCEDURE

1. USE CMC-306 TO ASSIGN:
 - NIGHT ANSWER GROUP NUMBER (P1)
 - TRUNK/STATION FLAG (P2)
 - EQUIPMENT NUMBER (P3)
2. USE CMC-201 AND CMC-251 (IF APPLICABLE) TO CHECK TENANT ASSIGNMENTS

CMC=306
P1:2
P2:1
P3:013

*PACKAGE C ALLOWS 32 NIGHT ANSWER GROUPS.

- NOTES:
- IF NIGHT BELL IS SELECTED FOR NIGHT ANSWER OPERATION, THE BELL MUST BE PROGRAMMED AS A STATION (ASSIGNED AN EQUIPMENT NUMBER), PHYSICALLY CONNECTED TO DESIRED CIRCUIT ON 8SLC CARD, AND RGEN MUST BE INSTALLED.
 - EXISTING TRUNK OR STATION ASSIGNMENTS MUST BE DELETED BY **REMOVE PROGRAM** FUNCTION BEFORE CHANGING OR REMOVING NIGHT GROUP ASSIGNMENTS.

Programming Service Functions/ CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
● SYSTEM SPEED CALLING DIRECTORY	300	ADDS, REMOVES, OR CHANGES SYSTEM SPEED CALLING DIRECTORY NUMBERS.
● STATION HUNT GROUP ASSIGNMENT	301	ASSIGNS, REMOVES, OR CHANGES VOICE OR DATA FROM ONE OF THREE TYPES OF HUNT GROUPS: CIRCULAR, TERMINATING OR PILOT.
● PICKUP GROUP ASSIGNMENT	302	ASSIGNS, REMOVES OR CHANGES STATIONS FROM PICK-UP GROUPS.
● EKT SYSTEM PAGING GROUP ASSIGNMENT	303	ASSIGNS, REMOVES OR CHANGES EKT STATIONS FROM PAGING ZONES.
● HOT LINE STATION ASSIGNMENT	304	ASSIGNS, REMOVES OR CHANGES STATIONS FROM HOT LINE SERVICE
● MUSIC ON HOLD ASSIGNMENT	305	ASSIGNS OR REMOVES MUSIC ON HOLD SERVICE
● NIGHT ANSWER STATION ASSIGNMENT	306	ASSIGNS, REMOVES OR CHANGES STATIONS OR TRUNKS FROM NIGHT RING GROUPS.

Laboratory Activity — Programming Service Functions



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO PROGRAMMING SERVICE FUNCTIONS UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER # 2.5														
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212													
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.5</u> (TASK #1)													
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER														
<u>TASKS:</u>														
<ul style="list-style-type: none"> • Establish a system speed calling directory with CMC-300. 														
<u>PARAMETERS:</u> (1) Add the following numbers and access codes to the system speed calling directory: <u>SPEED DIAL:</u> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; padding: 2px;">CODE</th> <th style="text-align: left; padding: 2px;">ACCESS CODE</th> <th style="text-align: left; padding: 2px;">SEND NUMBER</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">00</td> <td style="padding: 2px;">75 (FOR CO TRUNK 1)</td> <td style="padding: 2px;">301 555 1221</td> </tr> <tr> <td style="padding: 2px;">01</td> <td style="padding: 2px;">75</td> <td style="padding: 2px;">737 8866</td> </tr> <tr> <td style="padding: 2px;">02</td> <td style="padding: 2px;">75</td> <td style="padding: 2px;">202 936 1111</td> </tr> </tbody> </table>	CODE	ACCESS CODE	SEND NUMBER	00	75 (FOR CO TRUNK 1)	301 555 1221	01	75	737 8866	02	75	202 936 1111	<u>INSTRUCTIONS:</u> (1) Perform programming change for service function. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.	
CODE	ACCESS CODE	SEND NUMBER												
00	75 (FOR CO TRUNK 1)	301 555 1221												
01	75	737 8866												
02	75	202 936 1111												

Laboratory Activity – Programming Service Functions (Continued)



GTE OMNI SBCS

WORK ORDER # 2.5			
<u>COMPANY NAME:</u> NU SYSTEM CO.		<u>PHONE #:</u> (703) 555-1212	
<u>LOCATION:</u> RESTON, VIRGINIA		<u>WORK ORDER # 2.5</u> (TASK #2)	
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER			
<u>TASKS:</u>			
<ul style="list-style-type: none"> • Assign stations to a hunt group with CMC-301. 			
<u>PARAMETERS:</u>		<u>INSTRUCTIONS:</u>	
(1) Assign stations to a terminating type hunt group using the following parameters:		(1) Perform programming change for service function. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.	
<u>STATION DN</u>	<u>HUNT GROUP #</u>		<u>TERMINATING ORDER</u>
214	1		1
308	1		2
212	1		3
223	1	4	

Laboratory Activity – Programming Service Functions (Continued)



GTE OMNI SBCS

WORK ORDER #2.5															
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212														
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.5</u> , (TASK #3)														
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER															
<u>TASKS:</u>															
<ul style="list-style-type: none"> ● Assign stations to a pickup group with CMC-302. 															
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>														
<p>(1) Assign the following stations to designated pickup groups.</p> <table border="1"> <thead> <tr> <th>PICKUP GROUP</th> <th>STATION DN</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>214</td> </tr> <tr> <td>1</td> <td>308</td> </tr> <tr> <td>1</td> <td>212</td> </tr> <tr> <td>2</td> <td>223</td> </tr> <tr> <td>2</td> <td>216</td> </tr> <tr> <td>2</td> <td>215</td> </tr> </tbody> </table>	PICKUP GROUP	STATION DN	1	214	1	308	1	212	2	223	2	216	2	215	<p>(1) Perform programming change for service function.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Proceed to next work order task.</p>
PICKUP GROUP	STATION DN														
1	214														
1	308														
1	212														
2	223														
2	216														
2	215														

Laboratory Activity — Programming Service Functions (Continued)



GTE OMNI SBCS

WORK ORDER # 2.5	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 2.5 (TASK #4)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none">• Create a hot line service with CMC-304.	
PARAMETERS: (1) Assign hot line service using the following parameters: Hot line number = 1 Originating station = 216 Terminating station = 223	INSTRUCTIONS: (1) Perform programming change for service function. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity — Programming Service Functions (Continued)



GTE OMNI SBCS

WORK ORDER # 2.5	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER # 2.5 (TASK #5)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Remove hot line service with CMC-304.• Create an internal paging group with CMC-303.	
<u>PARAMETERS:</u> <ol style="list-style-type: none">(1) Remove previously assigned hot line service from station directory numbers 216 and 225.(2) Assign all CS-20 and CS-10 EKT instruments to paging group 1. <p><u>NOTE:</u> Programming of external zone paging (speaker amplifier) will be addressed in Module IV.</p>	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none">(1) Perform programming changes for service functions.(2) Check/test the operation of changes after completion of this portion of the laboratory activity.(3) Proceed to next work order task.

Laboratory Activity — Programming Service Functions (Continued)



GTE OMNI SBGS

COMPLETE MUSIC-ON-HOLD SERVICE FUNCTION TASK IF TIME PERMITS OR IF INSTRUCTOR DIRECTS YOU TO DO SO.

WORK ORDER # 2.5	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER # 2.5 (TASK #6)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign music-on-hold with CMC-305. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Verify that the music-on-hold service has been physically connected to circuit on 4BWC card and music source assigned to correct trunk circuit (slot 18, circuit 2) with CMC-250. (2) Activate the music-on-hold service with CMC-305 using the equipment number designated above. 	<ol style="list-style-type: none"> (1) Perform programming change for service function. (2) Check the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity — Programming Service Functions (Continued)



GTE OMNI SBCS

COMPLETE NIGHT ANSWER SERVICE FUNCTION TASK IF TIME PERMITS OR IF INSTRUCTOR DIRECTS YOU TO DO SO.

WORK ORDER # 2.5	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 2.5 (TASK #7)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> • Assign night ring trunks and answer station with CMC-306. 	
PARAMETERS:	INSTRUCTIONS:
<p>(1) Identify following trunks as incoming night trunks:</p> <p style="padding-left: 40px;">180 181 160 170</p> <p>Select night answer group "1".</p> <p>(2) Assign both CS-20 instruments as night answer stations. Select night answer group "1".</p> <p>(3) If night bell was previously installed, assign its designated equipment number (023) as station night answer. Select night answer group number "1".</p>	<p>(1) Perform programming change for service function.</p> <p>(2) Check the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Complete review exercise questions 1-28.</p>
LAB MILESTONE:	
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. • ASK INSTRUCTOR TO INSPECT SERVICE FUNCTION CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN QUESTIONS 1-28 OF REVIEW EXERCISE 2.5 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING. 	

Review Exercise — Programming Service Functions (2.5)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE OMNI SBCS ALLOWS UP TO _____ NUMBERS IN THE SYSTEM SPEED CALLING DIRECTORY.
2. IN CMC-300, P2 IDENTIFIES _____ .
3. THE SYMBOL _____ IS USED TO INDICATE A PAUSE IN THE SYSTEM SPEED CALLING SEND NUMBER.
4. IF DESIRED, CMC- _____ IS USED TO CHANGE TRUNK ACCESS CODES PRIOR TO ENTRY IN THE SYSTEM SPEED CALLING DIRECTORY.
5. THE STATION HUNTING GROUP NUMBERS 51-60 ARE RESERVED FOR _____ .
6. A MAXIMUM OF _____ VOICE HUNT GROUPS WITH UP TO _____ DIRECTORY NUMBER MEMBERS IN EACH GROUP MAY BE ASSIGNED (PACKAGES A AND B).
7. MATCH EACH OF THE FOLLOWING TERMS WITH ITS CORRECT DESCRIPTION:

_____ CIRCULAR HUNT GROUP TYPE	A. ALL STATIONS ARE TRIED IN ORDER OF PROGRAMMED PRIORITY.
_____ TERMINATING HUNT GROUP TYPE	B. ALL STATIONS ARE TRIED AROUND THE GROUP UNTIL IDLE STATION IS FOUND.
_____ PILOT HUNT GROUP TYPE	C. IF A DESIGNATED STATION IS TRIED AND IS BUSY, ALL STATIONS WITHIN GROUP ARE TRIED.
8. WHAT OCCURS IF A PILOT STATION AND THE OTHER MEMBERS OF ITS HUNT GROUP ARE BUSY?

Review Exercise — Programming Service Functions (2.5) (Continued)



GTE OMNI SBCS

9. IS IT POSSIBLE FOR A PHONE IN ONE PICKUP GROUP TO ANSWER AN INCOMING CALL TO ANOTHER PICKUP GROUP? _____
10. A MAXIMUM OF _____ PICKUP GROUPS WITH UP TO _____ DIRECTORY NUMBER MEMBERS IN EACH GROUP MAY BE ASSIGNED (WITH PACKAGES A AND B).
11. EXPLAIN THE PROCEDURE TO MOVE A MEMBER OF ONE PICKUP GROUP TO ANOTHER GROUP. _____

12. HOT LINE NUMBERS 1-10 ARE RESERVED FOR _____ AND 51-90 FOR _____ (WITH PACKAGES A AND B).
13. IS IT POSSIBLE FOR TWO STATION INSTRUMENTS TO BE BOTH ORIGINATING AND TERMINATING HOT LINE STATIONS TO EACH OTHER? _____
14. A MAXIMUM OF _____ VOICE HOT LINES MAY BE ASSIGNED (WITH PACKAGES A AND B).
15. IS IT POSSIBLE FOR HOT LINE STATIONS TO RECEIVE TERMINATING CALLS? _____
16. A MAXIMUM OF _____ PAGING GROUPS WITH UP TO _____ DIRECTORY NUMBER MEMBERS MAY BE ASSIGNED.
17. INTERNAL ZONE PAGING REQUIRES THE USE OF _____ INSTRUMENTS FOR BROADCAST.
18. EXPLAIN THE PROCEDURE TO MOVE A MEMBER OF ONE PAGING GROUP TO ANOTHER GROUP. _____

Review Exercise — Programming Service Functions (2.5) (Continued)



GTE OMNI SBCS

19. WHAT FACTOR(S) SHOULD BE CONSIDERED WHEN ESTABLISHING AN INTERNAL PAGING SYSTEM? _____

20. WHAT PARAMETERS ARE REQUIRED WHEN ASSIGNING A MUSIC-ON-HOLD TRUNK WITH CMC-250? _____

21. CMC _____ ACTIVATES THE MUSIC-ON-HOLD FEATURE AFTER TRUNK ASSIGNMENT.
22. WHAT HAPPENS TO TRUNK CALLS WHEN THE SYSTEM IS PLACED IN NIGHT MODE?

23. A MAXIMUM OF _____ NIGHT ANSWER GROUPS WITH UP TO _____ NIGHT ANSWER MEMBERS IN EACH GROUP MAY BE ASSIGNED.
24. EXPLAIN THE PROCEDURE IN WHICH AN INTERNAL STATION CAN ANSWER A CALL RINGING AT A NIGHT BELL OR STATION.

25. WHAT HAPPENS TO A NIGHT CALL WHEN THE NIGHT ANSWER STATION IS USING ITS "CALL FORWARD" FEATURE TO ANOTHER STATION? (ATTEMPT THIS IN THE LAB). _____

Review Exercise — Programming Service Functions (2.5) (Continued)



GTE OMNI SBCS

26. WHAT HAPPENS TO A NIGHT CALL WHEN THE NIGHT ANSWER STATION IS USING ITS "DO NOT DISTURB" FEATURE? (ATTEMPT THIS IN THE LAB.)

27. A NIGHT BELL MAY BE ASSIGNED TO A NIGHT ANSWER STATION THROUGH THE USE OF A CIRCUIT ON THE _____ CARD.

28. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DESCRIPTION.

- | | |
|-------------|--|
| ___ CMC-300 | A. HOT LINE ASSIGNMENT |
| ___ CMC-301 | B. INTERNAL ZONE PAGING ASSIGNMENT |
| ___ CMC-302 | C. SYSTEM SPEED CALLING DIRECTORY ASSIGNMENT |
| ___ CMC-303 | D. NIGHT ANSWER ASSIGNMENT |
| ___ CMC-304 | E. MUSIC-ON-HOLD ASSIGNMENT |
| ___ CMC-305 | F. PICKUP GROUP ASSIGNMENT |
| ___ CMC-306 | G. HUNT GROUP ASSIGNMENT |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Class of Service



2.6 Enabling Objective

GTE OMNI SBSC

GIVEN:

- GTE OMNI SBSC
- GTE OMNI SBSC PERIPHERALS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBSC COURSE AND SITE DOCUMENTATION PACKAGE
- LABORATORY ACTIVITY - PROGRAMMING CLASS OF SERVICE
- REVIEW EXERCISE

ACTION:

- USE OMNI SBSC PROGRAMMING TOOLS AND EQUIPMENT TO:
 - ASSIGN STATION AND TRUNK FEATURES TO SYSTEM CLASS OF SERVICE TABLE.
 - ASSIGN CLASS OF SERVICE LEVELS TO STATION.
 - ASSIGN CLASS OF SERVICE AND CLASS OF RESTRICTION TO TRUNK GROUPS.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBSC GTEP MANUAL AND OMNI SBSC STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Class of Service/Feature Assignment



GTE OMNI SBCS

DESCRIPTION

- ALLOWS STATION AND TRUNK FEATURES TO BE ASSIGNED OR REMOVED FROM SYSTEM CLASS OF SERVICE (COS) TABLE.
- DEFAULT DATA BASE ASSIGNS ALL STATIONS TO COS 1 WHICH PROVIDES ACCESS TO ALL FEATURES.
- 16 COS LEVELS MAY BE ASSIGNED PER TENANT GROUP WITH COS LEVEL 1 BEING LEAST RESTRICTIVE AND COS LEVEL 16 BEING MOST RESTRICTIVE.
- AFTER ASSIGNING FEATURES TO THE SYSTEM COS TABLE, INDIVIDUAL STATIONS RECEIVE COS DESIGNATIONS WITH CMC-202. TRUNK GROUP COS ASSIGNMENTS ARE MADE WITH CMC-252.

PROCEDURE

*

1. USE CMC-104 TO ASSIGN OR REMOVE:
 - CLASS OF SERVICE (P1)
 - FEATURE NUMBER (P2)
- * REVIEW DEFAULT COS TABLE TO IDENTIFY COS LEVELS REQUIRING ADDITION OR REMOVAL OF FEATURES.

CMC=104
P1: 3
P2: 130

Programming Class of Service and Class of Restriction/Station Assignment



GTE OMNI SBCS

DESCRIPTION

- STATIONS MAY BE ASSIGNED ONE OF 16 COS AND COR LEVELS.
- SEPARATE COS/COR ASSIGNMENTS MAY BE MADE FOR DAY AND NIGHT MODES.
- ALL STATIONS RECEIVE A COS LEVEL OF 1 OR COR LEVEL OF 1 THROUGH DEFAULT STANDARD DATA BASE SETTING.
- CSD DATA STATION COS AND COR LEVELS ARE ASSIGNED SEPARATELY WITH CMC-221.

PROCEDURE

*

IDENTIFY APPROPRIATE COS AND COR LEVELS FOR EACH STATION IN THE SYSTEM.

1. USE CMC-202 TO ASSIGN OR CHANGE COS AND COR FOR EACH STATION:
 - STATION DIRECTORY NUMBER (P1)
 - CLASS OF SERVICE IN DAY MODE (P2)
 - CLASS OF SERVICE IN NIGHT MODE (P3)
 - CLASS OF RESTRICTION IN DAY MODE (P4)
 - CLASS OF RESTRICTION IN NIGHT MODE (P5)

CMC=202
P1: 547 P4: 1
P2: 1 P5: 1
P3: 6

- * CLASS OF RESTRICTION IS DISCUSSED IN TOLL AND MULTI-DIGIT RESTRICTION SECTION OF THIS WORKBOOK MODULE.

Programming Class of Service and Class of Restriction/Trunk Group Assignment



GTE OMNI SBCS

DESCRIPTION

- TRUNK GROUPS MAY BE ASSIGNED TO ONE OF 16 COS AND COR LEVELS.
- SEPARATE COS/COR ASSIGNMENTS MAY BE MADE FOR DAY AND NIGHT MODES.
- ALL TRUNK GROUPS RECEIVE A COS LEVEL OF 1 AND COR LEVEL OF 1 THROUGH DEFAULT STANDARD DATA BASE SETTING.

PROCEDURE *

1. USE CMC-252 TO ASSIGN OR CHANGE COS AND COR FOR EACH TRUNK GROUP:
 - TRUNK GROUP NUMBER (P1)
 - CLASS OF SERVICE (P2)
 - CLASS OF SERVICE IN NIGHT MODE (P3)
 - CLASS OF RESTRICTION (P4)
 - CLASS OF RESTRICTION IN NIGHT MODE (P5)

* CLASS OF RESTRICTION IS DISCUSSED IN TOLL AND MULTI-DIGIT RESTRICTION SECTION OF THIS WORKBOOK MODULE.

CMC-252
P1: 14 P4: 1
P2: 1 P5: 1
P3: 6

Programming Class of Service/ Class of Restriction – CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• CLASS OF SERVICE — FEATURE ASSIGNMENT	CMC-104	ASSIGNS FEATURES TO SYSTEM CLASS OF SERVICE TABLE.
• STATION CLASS OF SERVICE AND CLASS OF RESTRICTION	CMC-202	ASSIGNS COS AND COR TO STATION FOR DAY/NIGHT MODE.
• TRUNK CLASS OF SERVICE AND CLASS OF RESTRICTION	CMC-252	ASSIGNS COS AND COR TO TRUNKS FOR DAY/NIGHT MODE.

Laboratory Activity — Programming Class of Service



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO COS/COR PROGRAMMING UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.6	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.6 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign station and trunk features to a COS table with CMC-104. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Change "limited override" to "full executive override" for COS 1. (2) Remove "system speed dial" from COS 2. 	<ol style="list-style-type: none"> (1) Perform programming changes for COS table. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity – Programming COS/ (Continued)



GTE OMNI SBCS

WORK ORDER #2.6	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER # 2.6 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign COS to station with CMC-202. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Change station directory number 308 from COS 1 (default setting) to COS 12 for day mode. (2) Change station directory number 215 from COS 1 to COS 6 for day mode. (2) Change station directory numbers 212 and 214 from COS 1 to COS 3 for night mode. 	<ol style="list-style-type: none"> (1) Perform programming changes for COS. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity — Programming COS/ (Continued)



GTE OMNI SBCS

WORK ORDER #2.6	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.6</u> (TASK #3)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Assign COS to trunk group with CMC-252.	
<u>PARAMETERS:</u> (1) Change both tie lines (TGN 31 and 32) from COS 1 (default setting) to COS 2.	<u>INSTRUCTIONS:</u> (1) Perform programming changes for COS. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Complete review exercise questions 1-10. <u>NOTE:</u> COR assignment will be addressed in Multi-digit Restriction lab activity.

LAB MILESTONE:

- VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY.
- ASK INSTRUCTOR TO INSPECT COS/COR CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST.
- MAKE CERTAIN QUESTIONS 1-10 OF REVIEW EXERCISE 2.6 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.

Student Notes



GTE OMNI SBCS

A series of 20 horizontal lines spanning the width of the page, intended for student notes.

Review Exercise — Programming Class of Service (2.6)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. FEATURES MAY BE ASSIGNED OR REMOVED FROM A COS LEVEL WITH CMC- _____ .

2. INDICATE WITH AN X THE FOLLOWING FEATURES WHICH CAN BE ASSIGNED TO A COS GROUP:

_____ EKT SPEAKERPHONE BUTTON	_____ CALL PARK ANSWER
_____ CO# 1 ACCESS	_____ STATION SPEED CALLING
_____ OFF-HOOK INCOMING CALL SIGNALING CHANGE	_____ GROUP PICKUP

3. LIST THE COS LEVELS WHICH CONTAIN THE FOLLOWING FEATURES IN THE DEFAULT STANDARD BASE:

SAVE/REPEAT LAST NUMBER DIALED: _____

CO #2 ACCESS: _____

DO NOT DISTURB: _____

STATION CAMP-ON: _____

DIRECT TRUNK ACCESS: _____

Review Exercise — Programming Class of Service (2.6) (Continued)



GTE OMNI SBCS

4. THE TWO MODES ALLOWED IN THE SYSTEM FOR COS AND COR ARE _____
AND _____ .
5. NIGHT CLASS OF SERVICE FOR STATIONS IS ASSIGNED WITH CMC-_____, PARAMETER
_____. NIGHT CLASS OF RESTRICTIONS FOR STATIONS IS ASSIGNED WITH CMC-_____,
PARAMETER _____ .
6. WHAT FEATURES IS A STATION ALLOWED WITH A COS LEVEL OF 16? _____

7. DAY CLASS OF SERVICE FOR TRUNKS IS ASSIGNED WITH CMC-_____, PARAMETER
_____. NIGHT CLASS OF SERVICE FOR TRUNKS IS ASSIGNED WITH CMC-_____,
PARAMETER _____ .
8. A MAXIMUM OF _____ COS LEVELS AND _____ COR LEVELS ARE ALLOWED IN THE
SYSTEM DATA BASE FOR STATIONS AND TRUNKS.
9. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DEFINITION:
_____ CMC-104 A. TRUNK COS/COR ASSIGNMENT
_____ CMC-202 B. FEATURE SERVICE TO CLASS OF SERVICE ASSIGNMENT
_____ CMC-252 C. STATION COS/COR ASSIGNMENT



GTE OMNI SBCS

DATA BASE ADMINISTRATION

System-wide Programming Changes

2.7 Enabling Objective



GTE OMNI SBSCS

GIVEN:

- GTE OMNI SBSC
- GTE OMNI SBSC PERIPHERALS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBSC COURSE AND SITE DOCUMENTATION PACKAGE
- LABORATORY ACTIVITY - SYSTEM-WIDE PROGRAMMING CHANGES
- REVIEW EXERCISE

ACTION:

- USE OMNI SBSC PROGRAMMING TOOLS AND EQUIPMENT TO:
 - MODIFY DEFAULT STANDARD SYSTEM NUMBERING PLAN, DEFINE FEATURE NUMBERS, FEATURE ACCESS CODES, AND SEND AND SAVE/SEND AS DIALED SETTINGS FOR TIE LINES AND SCC.
 - CHANGE SERVICE PARAMETER FLAGS FOR TRUNK-TO-TRUNK TRANSFER RESTRICTION, EXECUTIVE OVERRIDE WARNING BURST, AND VOICE/RINGING OPTION FOR CALL ANNOUNCE INTERCOM FEATURE.
 - MODIFY SYSTEM TIMING VALUES.
 - CHANGE SYSTEM PARAMETER FLAGS.
 - MODIFY OMNI SBSC DEFAULT PAD CIRCUIT VALUES TO CORRECT NETWORK LOSS RESULTING FROM DIGITAL PAD CIRCUIT IN NETWORK.
 - SET TRUNK ROUTE TIMING PARAMETER.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBSC GTEP MANUAL AND OMNI SBSC STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Systemwide Programming Changes/ Numbering Plan Assignment



GTE OMNI SBCS

DESCRIPTION

- DEFAULT STANDARD SYSTEM NUMBERING PLAN DEFINING FEATURE NUMBERS, FEATURE ACCESS CODES, TRUNK GROUP NUMBERS, AND SEND AND SAVE/SEND AS DIALED FOR TIE LINES.

PROCEDURE *

IDENTIFY FEATURE ACCESS CODES TO BE CHANGED USING DEFAULT STANDARD TABLE.

1. USE CMC-100 TO CHANGE:

- FEATURE NUMBER (P1)
- FEATURE ACCESS CODE (P2)
- TRUNK GROUP NUMBER (P3)
- OUTGOING DIRECTORY NUMBER (P4)
- ACCESS CODE DIGITS TO BE SENT FOR TIE ACCESS ONLY (P5)
- DIAL AND STORE AND FORWARD FLAG (P6)

CMC= 100	
P1: 92	P4:
P2: 2	P5:
P3:	P6: 0

- * CAUTION SHOULD BE EXERCISED TO ENSURE THAT ANY MODIFICATION OF FEATURE ACCESS CODES DOES NOT CONFLICT WITH EXISTING FEATURE ACCESS CODES OR STATION DIRECTORY NUMBER ASSIGNMENTS.

Systemwide Programming Changes/Service Parameter Assignment



GTE OMNI SBCS

DESCRIPTION

- **ALLOWS FLAGS TO BE SET FOR THE FOLLOWING SERVICE FUNCTIONS:**
 - A CHECK FOR TRUNK-TO-TRUNK TRANSFER RESTRICTION.
 - INDICATION OF WHETHER A WARNING BURST (TONE) INTERRUPTS USERS WHEN EXECUTIVE OVERRIDE FEATURE IS ACTIVATED.
 - DESIGNATION OF VOICE OR TONE OPTION WHEN CALL ANNOUNCE INTERCOM FEATURE IS ACTIVATED.
- **WHILE DEFAULT SYSTEM CAPACITY FOR SYSTEM FLAGS IS 32, ONLY 3 FLAGS (AS DEFINED ABOVE) CAN BE USED AT THE PRESENT TIME. REMAINING FLAGS HAVE BEEN RESERVED FOR PROGRAM USE OR FOR FUTURE ENHANCEMENTS.**

PROCEDURE *

1. **USE CMC-101 TO ASSIGN:**
 - SYSTEM FLAG IDENTIFICATION NUMBER (P1)
 - FLAG VALUE (0 or 1) (P2)

CMC-101
P1: 3
P2: 1

* **CMC TABLE IN OMNI SBCS GTEP MANUAL CONTAINS THE AVAILABLE IDENTIFICATION NUMBERS AND VALUES FOR SYSTEM SERVICE FEATURES.**

Systemwide Programming Changes/System Timing Assignment



GTE OMNI SBCS

DESCRIPTION

- ALLOWS CHANGE OF TIMING PARAMETERS FOR VARIOUS SYSTEM FUNCTIONS.
- ACTUAL TIMING FOR EACH TIMING PARAMETER IS CALCULATED BY MULTIPLYING THE TIMING PARAMETER'S DESIGNATED FIXED UNIT BY A MULTIPLIER VALUE (0 TO 255).

EXAMPLE:

FOR DSS CAMP-ON RECALL (PARAMETER 1), FIXED TIMING UNIT IS 1024 ms. THE DEFAULT MULTIPLIER (PARAMETER 2) IS 31:

$$1024 \text{ ms} \times 31 = 31.1744 \text{ SECONDS}$$

TO INCREASE TIME TO APPROXIMATELY ONE MINUTE, CHANGE VALUE FOR PARAMETER 2 TO 60:

$$1024 \text{ ms} \times 60 = 6144 \text{ SECONDS}$$

PROCEDURE *

1. USE CMC-103 TO SELECT:
 - SYSTEM TIMING IDENTIFICATION NUMBER (P1)
 - MULTIPLIER (P2)

CMC=103
P1: 22
P2: 60

NOTE: CMC TABLE IN OMNI SBCS GTEP MANUAL CONTAINS IDENTIFICATION NUMBER FOR ALL SYSTEM TIMING FUNCTIONS.

Systemwide Programming Changes/System Parameter Assignment **GTE**

GTE OMNI SBCS

DESCRIPTION

- ALLOWS UP TO 26 FLAGS TO BE SET FOR VARIOUS SYSTEM FUNCTIONS.

PROCEDURE *

1. USE CMC-102 TO ADD/CHANGE:
 - FLAG NUMBER (P1)
 - SET FLAG VALUE (P2)

CMC=102
P1: 6
P2: 1

* SEE CMC TABLE IN OMNI SBCS GTEP MANUAL, FOR A LISTING OF FLAG NUMBERS AND APPROPRIATE SETTING OF PARAMETER VALUES.

REFER TO CMC TABLE IN OMNI SBCS GTEP MANUAL WHEN CHANGING FLAG NUMBER 5 (SIGNALING CHECK FOR TRUNK TO TRUNK CONNECTION RESTRICTION).

System-wide Programming Changes/ Network Loss Plan Assignment



GTE OMNI SBCS

DESCRIPTION

- ALLOWS CHANGE IN DIGITAL PAD CIRCUIT (PAD) VALUE TO IMPROVE QUALITY OF INCOMING OR OUTGOING CONNECTIONS.

PROCEDURE *

DETERMINE WHICH INCOMING OR OUTGOING ROUTES ARE AFFECTED BY CIRCUIT LOSS QUALITY. IDENTIFY SPECIFIC CIRCUITS THAT ARE EXPERIENCING CIRCUIT LOSS.

1. USE CMC-106 TO CHANGE VALUE OF DIGITAL PAD:
 - INCOMING ROUTE (P1)
 - OUTGOING ROUTE (P2)
 - VALUE OF DIGITAL PADDING CIRCUIT (P3)

CMC=106
P1: 2
P2: 5
P3: 4

- * SEE CMC TABLE IN OMNI SBCS GTEP MANUAL, FOR A LISTING OF AVAILABLE INCOMING/OUTGOING ROUTE PARAMETERS.
SEE CMC TABLE IN OMNI SBCS GTEP MANUAL, FOR A LISTING OF AVAILABLE DECIBEL (dB) LEVELS FOR PAD VALUE PARAMETERS.

System-Wide Programming Changes/ Trunk Route Timing



GTE OMNI SBCS

DESCRIPTION

- SETS TRUNK ROUTE TIMING PARAMETER FOR VARIOUS SYSTEM TRUNK ROUTES
- TIMING IS CALCULATED BY MULTIPLYING THE TRUNK'S FIXED TIMING UNIT (IN ms) BY A DESIGNATED MULTIPLIER.

PROCEDURE

1. USE CMC-254 TO ASSIGN:
 - TRUNK GROUP NUMBER (P1)
 - ROUTE TIMING ID NUMBER (P2)
 - NORMALIZED TIMING/MULTIPLIER (P3)

CMC=254
P1: 13
P2: 1
P3: 14

- * REFER TO CMC TABLE IN OMNI SBCS GTEP MANUAL FOR DESCRIPTIONS OF AVAILABLE ROUTE TIMING AND MULTIPLIER FOR NORMALIZED TIMING.

System-wide Programming Changes/CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• NUMBERING PLAN ASSIGNMENT	CMC-100	DEFINES DEFAULT STANDARD SYSTEM NUMBERING PLAN (FEATURE NUMBERS, FEATURE ACCESS CODES, TRUNK GROUP NUMBERS, ETC.)
• SERVICE PARAMETER ASSIGNMENT	CMC-101	DEFINES SYSTEM SERVICE FUNCTION PARAMETERS.
• SYSTEM PARAMETERS ASSIGNMENT	CMC-102	DEFINES SYSTEM FUNCTION PARAMETERS.
• SYSTEM TIMING PARAMETER ASSIGNMENT	CMC-103	DEFINES SYSTEM TIMING PARAMETERS.
• NETWORK LOSS (PAD) CONTROL	CMC-106	DEFINES DIGITAL PAD CIRCUIT VALUES.
• TRUNK ROUTE TIMING	CMC-254	SETS THE TRUNK ROUTE TIMING PARAMETER.

Laboratory Activity — System-wide Programming Changes



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO SYSTEM-WIDE PROGRAMMING CHANGES UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.7	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 2.7 (TASK #1)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
<p><u>TASKS:</u></p> <ul style="list-style-type: none"> • Modify default standard numbering plan with CMC-100. 	
<p><u>PARAMETERS:</u></p> <p>(1) Change the feature access code for "Save/Repeat Last Number Dialed" from "8" (default) to 89 (Parameters 3, 4, 5, and 6 will be blank).</p>	<p><u>INSTRUCTIONS:</u></p> <p>(1) Perform programming changes for system-wide function.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Proceed to next work order task.</p>

Laboratory Activity – System-wide Programming Changes (Continued)



GTE OMNI SBCS

WORK ORDER #2.7	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.7 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Change a service parameter flag with CMC-101. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Change the flag indicating whether a warning burst is heard during executive override, to "send burst". 	<ol style="list-style-type: none"> (1) Perform programming changes for system-wide function. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to the next work order task.

Laboratory Activity — System-Wide Programming Changes (Continued)



GTE OMNI SBCS

WORK ORDER #2.7	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.7 (TASK #3)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Change a system parameter flag with CMC-102.	
<u>PARAMETERS:</u> <p>(1) Change the flag indicating the type of ringing pattern for off-premises extensions to "recall ringing."</p> <p>NOTE: Programming off-premises extensions will be addressed in later module.</p>	<u>INSTRUCTIONS:</u> <p>(1) Perform programming change for system-wide function.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Proceed to next work order task.</p>

Laboratory Activity — System-Wide Programming Changes (Continued)



GTE OMNI SBCS

WORK ORDER #2.7	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.7 (TASK #4)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> • Modify a system timing parameter with CMC-103. 	
PARAMETERS: (1) Change the timing value for "call park recall" to 1/2 minute. (Note: current multiplier is set at 61, yielding a default timing value of 62.464. A multiplier of 88 will provide a timing value of 91.112 seconds, or appropriately a minute and a half). (2) Change the timing value for "no answer recall" timing to approximately 45 seconds.	INSTRUCTIONS: (1) Perform programming change for system-wide function. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.

Laboratory Activity — System-Wide Programming Changes (Continued)



GTE OMNI SBCS

WORK ORDER #2.7	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.7 (TASK #5)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> • Modify the default network PAD circuit values with CMC-106. 	
PARAMETERS:	INSTRUCTIONS:
<p>(1) Reduce the PAD value for outgoing station dial tone with the following parameters:</p> <p style="padding-left: 40px;">Incoming route = 1 (dial tone and recall dial tone)</p> <p style="padding-left: 40px;">Outgoing route = 6 (station)</p> <p style="padding-left: 40px;">Value of padding circuit = 6 (-8.5 db)</p> <p>(2) After inspection by instructor, restore the PAD value modified above to its default value.</p>	<p>(1) Perform programming change for system-wide function.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Complete review exercise questions 1-13.</p>

LAB MILESTONE:
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. • ASK INSTRUCTOR TO INSPECT SYSTEM-WIDE PROGRAMMING CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN QUESTIONS 1-13 OF REVIEW EXERCISE 2.7 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.

Review Exercise — System-Wide Programming Changes (2.7)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE DEFAULT FEATURE NUMBER (FNO) FOR GROUP PICKUP IS _____ AND DEFAULT FEATURE ACCESS CODE IS _____.
2. FEATURE ACCESS CODES MAY BE COMPOSED OF A MAXIMUM OF _____ DIGITS, WITH THE SYMBOLS _____ AND _____ USED AS WELL.
3. WHEN WOULD YOU SPECIFY THE NUMBER OF ACCESS CODE DIGITS TO BE SENT IF USING CMC-100?

4. THE EKT PAGING ACCESS CODE CAN TAKE _____ ADDITIONAL DIGIT AND IDENTIFIES:

5. NAME THREE OF THE SYSTEM FLAGS WHICH CAN BE SET WITH CMC-101:
_____, _____ and _____.
6. WHAT IS THE DEFAULT SETTING FOR CMC-101, FLAG 4, PARAMETER 2? _____
7. WHAT VALUE WOULD YOU ASSIGN TO FLAG 1 FOR CMC-102, TO INDICATE THAT TENANTS WILL BE SHARING OUTGOING TRUNKS? _____

Review Exercise — System-Wide Programming Changes (2.7) (Continued)



GTE OMNI SBCS

8. HOW IS TIMING CALCULATED FOR SYSTEM TIMING VALUES? _____

9. WHAT MULTIPLIER VALUE WOULD YOU USE TO CHANGE THE CALL ANNOUNCE WARNING BURST TO ONE SECOND? _____
10. WHAT MULTIPLIER VALUE WOULD YOU USE TO CHANGE THE DSS CAMP-ON RECALL TIMING TO 1½ MINUTES? _____
11. WHEN MIGHT IT BE NECESSARY TO CHANGE THE DEFAULT PAD CIRCUIT VALUES? _____

12. STATION USERS HAVE COMPLAINED THAT THE BUSY TONE IS TOO LOUD. WHAT PARAMETERS NEED CHANGING WITH CMC-106 TO CORRECT THIS PROBLEM?
- P1 = _____
- P2 = _____
- P3 = _____
13. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DEFINITION:
- | | |
|---------------|---|
| _____ CMC-100 | A. SERVICE PARAMETER ASSIGNMENT |
| _____ CMC-101 | B. NETWORK LOSS PLAN ASSIGNMENT |
| _____ CMC-102 | C. SYSTEM TIMING PARAMETER ASSIGNMENT |
| _____ CMC-103 | D. FEATURE ACCESS CODE NUMBER PLAN ASSIGNMENT |
| _____ CMC-106 | E. SYSTEM PARAMETER ASSIGNMENT |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Station Message Detail Recorder



GTE OMNI SBCS

2.8 Enabling Objective

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS Peripherals
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — PROGRAMMING STATION MESSAGE
DETAIL RECORDER
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
— INSTALL STATION MESSAGE DETAIL RECORDER AND ASSIGN
CALL SCREENING OPTIONS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PRO-
CEDURES OUTLINES IN GTEP MANUAL AND OMNI SBCS STUDENT
WORKBOOK
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCOR-
DANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING
ORGANIZATION.

Programming Station Message Detail Recorder/SMDR (MDR) Screening



GTE OMNI SBCS

DESCRIPTION

- PROVIDES LOCAL PRINTOUT OF SYSTEM CALL INFORMATION.
- IF SMDR OPTION IS INSTALLED THE FOLLOWING INFORMATION IS RECORDED FOR EVERY CALL:
 - TIME OF CALL ORIGINATION
 - CALL DURATION RECORDED IN HOURS, MINUTES, AND SECONDS
 - ORIGINATING STATION NUMBER
 - TRUNK NUMBER WITH IDENTIFICATION
 - CALLING PARTY IDENTIFICATION
 - TRUNK ACCESS CODE
 - DIRECTORY NUMBER DIALED AND PERSONAL ACCOUNTING CODE (SVR 1.5.X.X)
 - ACCOUNT CODE
 - TENANT NUMBER (FOR MULTI-TENANT APPLICATION)
 - METERING GROUP NUMBER
- AUTOMATIC SCREENING OPERATION
- OPTIONAL CALL SCREENING OPTIONS:
 - OUTGOING CALLS THROUGH CO TRUNK LINES
 - OUTGOING CALLS THROUGH TIE TRUNK LINES
 - ACCOUNT CODE CALLS
 - TOLL CALLS
 - OVERTIME CALLS
 - TRUNK GROUP SELECTION
 - CLASS OF RESTRICTION SELECTION
 - TENANT SELECTION
- CALLS LASTING LESS THAN PROGRAMMED DATA BASE THRESHOLD TIME ARE NOT RECORDED IN ORDER TO EXCLUDE INCOMPLETE CALLS (E.G., TERMINATED TO BUSY TONE, REORDER TONE, OR NO ANSWER) FROM CALL RECORD.

Programming Station Message Detail Recorder/SMDR Screening



GTE OMNI SBCS

PROCEDURE *

1. USE CMC-500 TO ASSIGN SMDR OUTPUT OPTIONS ON OUTGOING CONNECTION:

- CO OUTGOING CONNECTION (P1)
- TIE LINE OUTGOING CONNECTION (P2)
- ACCOUNT FLAG (P3)
- TOLL CALL FLAG (P4)

CMC=500
P1: 1 P4: 1
P2: 0
P3: 0

2. USE CMC-501 TO ASSIGN TRUNK GROUPS FOR SMDR OUTPUT:

- TRUNK GROUP NUMBER (P1)**
- OUTPUT IDENTIFICATION FLAG (P2)

CMC=501
P1: 13
P2: 1

3. USE CMC-502 TO ASSIGN COR FOR SMDR OUTPUT:

- CLASS OF RESTRICTION (P1)
- OUTPUT IDENTIFICATION FLAG (P2)

CMC=502
P1: 3
P2: 1

4. USE CMC-503 TO ASSIGN SMDR OUTPUT FOR TENANTS:

- TENANT NUMBER (P1)
- OUTPUT IDENTIFICATION FLAG (P2)

CMC=503
P1: 2
P2: 1

5. USE CMC-504 TO SET MINIMUM CALL DURATION FOR SMDR OUTPUT:

- HOURS FOR MINIMUM CALL DURATION (P1)
- MINUTES FOR MINIMUM CALL DURATION (P2)
- SECONDS FOR MINIMUM CALL DURATION (P3)

CMC=504
P1: 0
P2: 0
P3: 45

NOTE: REFER TO MODULE III FOR SMDR MAINTENANCE COMMANDS (CMC 705 AND 901)

* ASSUMES PHYSICAL INSTALLATION OF SERIAL PRINTER.

** REFER TO DATA BASE PROGRAMMING SECTION IN OMNI SBCS GTEP MANUAL FOR LISTING OF TRUNK GROUP NUMBERS.

Programming Station Message Detail Recorder/SMDR Output Format



GTE OMNI SBCS

- TIME MESSAGE IS PRINTED WITH SMDR REPORT TO SEPARATE EACH SMDR MESSAGE. TIME INCREMENTS BY HOUR.

09:27	02/07/86
(1)	(2)
Time	Date

- SAMPLE OUTPUT:

08:15	00.00.36	ST	0201	C1234	1600	07035344789	123456780123	00	00
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(09)	(10)

- | | | |
|------|---|---|
| (1) | = | Time of call origination |
| (2) | = | Duration of call |
| (3) | = | Calling party identification:
ST = Station
AT = Attendant
TI = TIE trunk |
| (4) | = | Originating Station number |
| (5) | = | Trunk Identification and Trunk number:
C: CO trunk DDD: Trunk number
F: FX trunk
W: WATS trunk
T: TIE trunk |
| (6) | = | Trunk access code (also when line button on EKT is used, access code is output) |
| (7) | = | Directory number dialed (maximum 20 digits) |
| (8) | = | Account code (if not specified, no code is output) |
| (9) | = | Tenant number (if not specified, no tenant number is output) |
| (10) | = | Metering group (if not specified, no metering group is output) |

Programming Station Message Detail Recorder/CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• OUTGOING MDR	CMC-500	SELECTS CO, TIE, ACCOUNT AND TOLL FOR SMDR OUTPUT
• MDR TRUNK SCREEN	CMC-501	SELECTS TRUNK GROUPS FOR MDR OUTPUT
• CLASS OF RESTRICTION	CMC-502	SELECTS COR GROUPS FOR MDR OUTPUT
• TENANT	CMC-503	SELECTS TENANTS FOR SMDR OUTPUT
• CALL DURATION	CMC-504	SETS MINIMUM CALL DURATION FOR MDR REGISTRATION

NOTE: REFER TO MODULE III FOR SMDR MAINTENANCE COMMANDS (CMC-705) AND CMC-901).

Laboratory Activity – Station Message Detail Recorder Programming



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO STATION MESSAGE DETAIL RECORDER PROGRAMMING UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.8	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.8 (TASK #1)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> Determine SMDR output for system parameters with CMC-500. 	
PARAMETERS:	INSTRUCTIONS:
<ol style="list-style-type: none"> Assign both tie line outgoing connections with "no SMDR output". Change toll call flag to indicate "SMDR output for toll calls only". 	<ol style="list-style-type: none"> Perform programming changes for Station Message Detail Recorder. Check/test the operation of changes after completion of this portion of the laboratory activity. Proceed to next work order task.

Laboratory Activity — Station Message Detail Recorder Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.8	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.8 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Establish minimum call duration for SMDR with CMC-504.	
<u>PARAMETERS:</u> <ol style="list-style-type: none">(1) Specify 45 seconds for "minimum call duration" to receive SMDR output.	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none">(1) Perform programming changes for Station Message Detail Recorder.(2) Check/test the operation of changes after completion of this portion of the laboratory activity.(3) Proceed to next work order task.

Laboratory Activity — Station Message Detail Recorder Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.8	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.8</u> (TASK #3)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign SMDR output for COR with CMC-502. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
(1) Change COR 3 and 4 to indicate "no SMDR OUTPUT".	(1) Perform programming changes for Station Message Detail Recorder.
	(2) Check/test the operation of changes after completion of this portion of the laboratory activity.
	(3) Complete review exercise questions 1-8.
	<u>NOTE:</u>
	Tenant Group SMDR output was assigned previously during Special System Configuration laboratory activity with CMC-503.

LAB MILESTONE:
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. • ASK INSTRUCTOR TO INSPECT STATION MESSAGE DETAIL RECORDER AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN QUESTIONS 1-8 OF REVIEW EXERCISE 2.8 HAVE BEEN COMPLETED BEFORE SUBMITTING TO THE INSTRUCTOR FOR GRADING.

Review Exercise — Station Message Detail Recorder (2.8)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE FOLLOWING INFORMATION IS RECORDED FOR EVERY CALL IF SMDR OUTPUT IS SELECTED: _____
 - A. TIME OF CALL ORIGATION, CALL DURATION, AND CLASS OF RESTRICTION SELECTION.
 - B. CALL DURATION, CALLING PARTY IDENTIFICATION, AND TOLL CALLS.
 - C. CALL DURATION, ORIGINATING STATION NUMBER, AND TRUNK ACCESS CODE.
 - D. TIME OF CALL ORIGATION, OVERTIME CALLS, AND METERING GROUP NUMBER.
2. WHAT CMC COMMAND, PARAMETERS AND SETTINGS WOULD BE REQUIRED TO ESTABLISH SMDR OUTPUT FOR OUTGOING CO CONNECTIONS, AND TOLL AND NON-TOLL CALLS?

3. SMDR OUTPUT FOR TRUNKS IS IDENTIFIED ON PRINTOUT BY _____
4. WHY MIGHT A MINIMUM CALL DURATION TO RECEIVE SMDR OUTPUT BE SELECTED?

5. WHAT CMC COMMAND, PARAMETERS, AND SETTINGS WOULD BE REQUIRED TO ESTABLISH A MINIMUM CALL DURATION OF 1½ MINUTES?

Review Exercise — Station Message Detail Recorder (2.8)



GTE OMNI SBCS

6. WHAT CMC COMMAND, PARAMETERS, AND SETTING WOULD BE REQUIRED TO PROVIDE SMDR OUTPUT FOR COR LEVELS 6 AND 16?

7. IS IT NECESSARY FOR ALL FIVE TENANTS TO RECEIVE SMDR OUTPUT? _____

PLEASE EXPLAIN _____

8. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DEFINITION:

- | | |
|---------------|--|
| _____ CMC-500 | A. SMDR COR SCREENING ASSIGNMENT |
| _____ CMC-501 | B. SMDR CALL DURATION SCREENING ASSIGNMENT |
| _____ CMC-502 | C. SMDR OUTGOING CONNECTION SCREENING ASSIGNMENT |
| _____ CMC-503 | D. SMDR TENANT SCREENING ASSIGNMENT |
| _____ CMC-504 | E. SMDR TRUNK GROUP SCREENING ASSIGNMENT |
| _____ CMC-705 | F. SMDR IN/OUT OF SERVICE |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Toll and Multi-Digit Restriction



2.9 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — PROGRAMMING TOLL AND MULTI-DIGIT RESTRICTION PROGRAMMING
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - ASSIGN TOLL AND TRUNK GROUP RESTRICTIONS TO CLASS OF RESTRICTION TABLE.
 - CREATE AREA CODE, OFFICE CODE, AND COMBINED AREA/OFFICE CODE MULTI—DIGIT RESTRICTION TABLES.
 - ESTABLISH TOLL AND OPERATOR CALL RESTRICTION NUMBER.
 - IDENTIFY AND ASSIGN TOLL AND OPERATOR PREFIX CODES FOR TRUNK DIAL GROUP NUMBERS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Toll and Multi-Digit/ Restriction Assignment



GTE OMNI SBGS

DESCRIPTION

- RESTRICTS CONNECTION TO CO (INCLUDING FX OR WATS) AND TIE TRUNK LINES.
- 16 COR LEVELS MAY BE ASSIGNED WITH COR LEVEL 1 BEING LEAST RESTRICTIVE AND COR LEVEL 16 BEING MOST RESTRICTIVE.
- COR DESIGNATION MAY BE MADE SEPARATELY FOR INCOMING OR OUTGOING CONNECTIONS.
- DEFAULT DATA BASE ASSIGNS ALL STATIONS AND TRUNK GROUPS TO COR LEVEL 1 WHICH ALLOWS ACCESS AND CONNECTION TO ALL AVAILABLE TRUNK GROUPS.

PROCEDURE

REVIEW DEFAULT COR TABLE TO IDENTIFY ANY RESTRICTIONS TO BE ADDED OR REMOVED FROM COR LEVELS.

1. IF DESIRED USE CMC-105 TO ASSIGN OR CHANGE RESTRICTION TO EACH COR LEVEL:
 - CLASS OF RESTRICTION (P1)
 - RESTRICTION ON OUTGOING CONNECTIONS TO CO LINES (INCLUDING FX AND WATS) (P2)
 - RESTRICTION ON INCOMING CONNECTIONS FROM CO LINES (INCLUDING FX AND WATS) (P3)
 - RESTRICTION ON OUTGOING CONNECTIONS TO TIE LINES (P4)
 - RESTRICTION ON INCOMING CONNECTIONS FROM TIE LINES (P5)
2. IF DESIRED USE CMC-202 TO ASSIGN OR CHANGE COR FOR EACH STATION:
 - STATION DIRECTORY NUMBER (P1)
 - CLASS OF SERVICE IN DAY MODE (P2)
 - CLASS OF SERVICE IN NIGHT MODE (P3)
 - CLASS OF RESTRICTION IN DAY MODE (P4)
 - CLASS OF RESTRICTION IN NIGHT MODE (P5)
3. IF DESIRED USE CMC-252 TO ASSIGN OR CHANGE COR FOR EACH TRUNK GROUP:
 - TRUNK GROUP NUMBER (P1)
 - CLASS OF SERVICE IN DAY MODE (P2)
 - CLASS OF SERVICE IN NIGHT MODE (P3)
 - CLASS OF RESTRICTION IN DAY MODE (P4)
 - CLASS OF RESTRICTION IN NIGHT MODE (P5)

CMC=105
P1: 3 P4: 0
P2: 1 P5: 0
P3: 1

CMC=202
P1: 417 P4: 1
P2: 1 P5: 3
P3: 3

CMC=252
P1: 14 P4: 1
P2: 1 P5: 3
P3: 3

Programming Toll and Multi-Digit/ Restriction Area and Office Code Restriction Assignments



GTE OMNI SBCS

DESCRIPTION

- DEFINES AREA CODE AND OFFICE CODE RESTRICTIONS FOR OUTGOING TRUNK GROUPS TO CONTROL TOLL EXPENSES AND PREVENT TELEPHONE ABUSE.
- RESTRICTED AREA CODES AND OFFICE CODES MUST BE DETERMINED AND ASSIGNED TO AREA CODE, OFFICE CODE, AND AREA/OFFICE CODE TABLE. THESE TABLES ARE ASSIGNED TO CLASS OF RESTRICTION ON AN ALLOWED OR DENIED BASIS.
- SYSTEM BLOCKS ANY CALLS PLACED TO RESTRICTED AREA CODES OR OFFICE CODES.
- SYSTEM CAPACITY IS TOTAL OF 1000 AREA AND OFFICE CODES IN COMBINED RESTRICTION TABLES.

PROCEDURE

1. USE CMC-411 TO ESTABLISH TOLL AND OPERATOR CALL RESTRICTION NUMBERS:

- RESTRICTION GROUP NUMBER (P1)
- CLASS OF RESTRICTION
- FLAG IDENTIFICATION VALUE (P3)**
- FLAG VALUE (P4)**

CMC=411
P1: 3 P4: 0
P2: 1
P3: 1

2. USE CMC-413 TO DEFINE AREA CODES TO BE INCLUDED IN RESTRICTION TABLE:

- RESTRICTION GROUP NUMBER (P1)
- CLASS OF RESTRICTION (P2)
- CALLS ALLOWED/DENIED FLAG (P3)*
- AREA CODE (P4)

CMC=413
P1: 1 P4: 301
P2: 3
P3: 0

NOTE: REPEAT ABOVE STEPS TO ASSIGN OTHER AREA CODES.

*ALLOW OR DENY FLAG AFFECTS ALL AREA AND OFFICE CODES WHICH PREVIOUSLY HAVE BEEN ASSIGNED TO RESTRICTION TABLE. MOST RECENT SETTING OVERRIDES EARLIER SETTINGS.

Programming Toll and Multi-Digit Restriction/ Area/Office Code Restriction Assignment



GTE OMNI SBCS

PROCEDURE (Continued)

3. USE CMC-412 TO DEFINE OFFICE CODES TO BE INCLUDED IN RESTRICTION TABLE:

- RESTRICTION GROUP NUMBER (P1)
- CLASS OF RESTRICTION (P2)
- CALLS ALLOWED/DENIED FLAG (P3)*
- OFFICE CODE (P4)

CMC=412
P1: 1 P4: 279
P2: 3
P3: 1

NOTE: REPEAT ABOVE STEPS TO ADD OTHER OFFICE CODES.

4. USE CMC-414 TO DEFINE COMBINED OFFICE AND AREA CODES TO BE INCLUDED IN RESTRICTION TABLE:

- RESTRICTION GROUP NUMBER (P1)
- CLASS OF RESTRICTION (P2)
- CALLS ALLOWED/DENIED FLAG (P3)*
- AREA CODE (P4)
- OFFICE CODE (P5)

CMC=414
P1: 2 P4: 301
P2: 6 P5: 270
P3: 1

NOTE: REPEAT STEPS TO ADD OTHER COMBINED OFFICE AND AREA CODES.

*ALLOW OR DENY FLAG AFFECTS ALL AREA AND OFFICE CODES WHICH PREVIOUSLY HAVE BEEN ASSIGNED TO RESTRICTION TABLE. MOST RECENT SETTING OVERRIDES EARLIER SETTINGS.

**REFER TO OMNI SBCS GTEP MANUAL, CMC TABLE FOR LIST OF FLAG IDENTIFICATION NUMBERS AND FLAG VALUES.

Programming Toll and Multi-Digit Restriction/Dial Group, Restriction Group and NO/1X Office Code Assignment



GTE OMNI SBCS

DESCRIPTION

- CMC-400 ASSIGNS DIALING GROUP AND RESTRICTION GROUP NUMBERS TO DESIGNATED TRUNK GROUP NUMBERS.
- CMC-401 IDENTIFIES CUSTOMER TOLL PREFIX CODES AND OPERATOR TOLL PREFIX CODES WITH TRUNK DIAL GROUP NUMBERS. DEFAULT SETTING FOR CUSTOMER TOLL PREFIX IS 1+. DEFAULT SETTING FOR OPERATOR TOLL PREFIX IS 0+.
- CMC-402 PROVIDES ASSIGNMENT FOR THOSE AREAS WHICH REQUIRE A PROGRAMMED NO/1X OFFICE CODE DUE TO CONFLICTING OFFICE AND AREA CODES (E.G., LOS ANGELES, CHICAGO, NEW YORK, ETC.)

PROCEDURE

1. USE CMC-400 TO ASSIGN:
 - TRUNK GROUP NUMBER (P1)
 - DIAL GROUP NUMBER (P2)
 - TOLL RESTRICTION GROUP NUMBER (P3)

CMC=400
P1: 13
P2: 1
P3: 2

2. USE CMC-401 TO ASSIGN:
 - DIAL GROUP NUMBER (P1)
 - CUSTOMER TOLL PREFIX CODE (P2)
 - OPERATOR TOLL PREFIX CODE (P3)

CMC=401
P1: 2
P2: 1
P3: 0

NOTE: UP TO THREE DIAL GROUPS MAY BE ASSIGNED.

3. USE CMC-402 TO ASSIGN NO/1X OFFICE CODE:
 - TOLL PREFIX REQUIRED (P1)
 - DIAL GROUP NUMBER (P2)
 - REGISTRATION DIGIT FLAG (P3)
 - REGISTRATION DIGITS (P4)

CMC=402
P1: 1 P4: 312
P2: 2
P3: 1

Programming Toll and Multi-Digit Restriction/SCC Restriction Assignment



GTE OMNI SBCS

DESCRIPTION

- DEFINES SCC ACCESS CODE RESTRICTION TABLE AND ASSIGNS TABLE TO RESTRICTION GROUPS BASED ON CLASS OF RESTRICTION.
- UP TO 10 CARRIER ACCESS CODES MAY BE ASSIGNED TO EACH COR.

PROCEDURE

1. IF APPLICABLE USE CMC-415 TO ASSIGN/REMOVE:
 - RESTRICTION GROUP NUMBER (P1)
 - CLASS OF RESTRICTION (P2)
 - CARRIER ACCESS CODE (P3)

CMC=415
P1: 2
P2: 3
P3: 10288

Programming Toll and Multi-Digit Restriction/CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• TRUNK RESTRICTION	CMC 105	ASSIGNS TRUNK RESTRICTION TO COR
• STATION CLASS OF RESTRICTION	CMC 202	ASSIGNS COR TO STATIONS FOR DAY/NIGHT MODE
• TRUNK CLASS OF RESTRICTION	CMC 252	ASSIGNS COR TO TRUNKS FOR DAY/NIGHT MODE
• TRUNK DIALING GROUP/ RESTRICTION GROUP ASSIGNMENT	CMC 400	ASSIGNS DIALING GROUP AND RESTRICTION GROUP NUMBERS TO TRUNK GROUP NUMBERS
• TOLL PREFIX AND OPERATOR ACCESS CODE ASSIGNMENT	CMC 401	ASSIGNS CUSTOMER TOLL PREFIX AND OPERATOR TOLL PREFIX TO TRUNK DIAL GROUP NUMBERS
• NO/1X OFFICE CODE ASSIGNMENT	CMC 402	ASSIGNS NO/1X OFFICE CODE TO IDENTIFY EITHER OFFICE OR AREA CODE CORRESPONDING TO DIAL GROUP NUMBER
• TOLL AND OPERATOR CALL RESTRICTION ASSIGNMENT	CMC 411	ASSIGNS TOLL AND OPERATOR RESTRICTION NUMBERS
• OFFICE CODE RESTRICTION	CMC 412	ASSIGNS OFFICE CODE RESTRICTIONS FOR OUTGOING TRUNK GROUPS
• AREA CODE RESTRICTION	CMC 413	ASSIGNS AREA CODE RESTRICTIONS FOR OUTGOING TRUNK GROUPS
• AREA/OFFICE CODE RESTRICTION	CMC 414	ASSIGNS AREA/OFFICE CODE RESTRICTIONS FOR OUTGOING TRUNK GROUPS
• CARRIER ACCESS CODE RESTRICTION	CMC 415	DEFINES CARRIER ACCESS CODE RESTRICTION TABLE

Laboratory Activity – Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO MULTI-DIGIT RESTRICTION PROGRAMMING UPON COMPLETION OF THIS LABORATORY SETTING.

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.9 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Reassign trunk circuits to trunk group numbers with CMC-250. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<p>(1) Reassign each of the following trunks to the designated trunk group and type of trunk using CMC-250:</p> <p>EN 160 to TGN 31 (TIE 1) EN 161 to TGN 32 (TIE 2) EN 170 to TGN 33 (TIE 3) EN 171 to TGN 34 (TIE 4)</p> <p>NOTE: Existing trunks must be removed before new values can be added.</p>	<p>(1) Perform programming changes for trunks required for Multi-digit restriction laboratory activity.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Proceed to next work order task.</p>

Laboratory Activity – Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 2.9 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Assign station directory numbers to Class of Restriction with CMC-202.	
<u>PARAMETERS:</u> (1) Assign the following stations to the following designated COR levels: DN = 212 to COR 1 DN = 215 to COR 2 DN = 208 to COR 3	<u>INSTRUCTIONS:</u> (1) Perform programming changes for Multi-digit Restriction. (2) Check-test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity – Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 2.9 (TASK #3)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign trunk group numbers to dial groups and restriction groups with CMC-400. • Assign customer toll prefix and operator access codes to dial groups with CMC-401. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Assign TGN 13 to dialing group number 1 and restriction group number 1 using CMC-400. (2) Assign CTP 1 and OTP 0 to dialing group number 1. 	<ol style="list-style-type: none"> (1) Perform programming changes for Multi-digit Restriction. (2) Check/test the operation of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity — Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 2.9 (TASK #4)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> Assign toll restrictions to a restriction group and assign the restriction groups to a Class of Restriction with CMC-411. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<p>(1) Assign the following toll restrictions and COR levels to the following designated restriction groups:</p> <p>RGN = 1 COR = 1 FLAG ID = 1 FLAG VALUE = 0 RGN = 1 COR = 1 FLAG ID = 2 FLAG VALUE = 0 RGN = 1 COR = 1 FLAG ID = 3 FLAG VALUE = 0 RGN = 1 COR = 1 FLAG ID = 4 FLAG VALUE = 1 RGN = 1 COR = 1 FLAG ID = 5 FLAG VALUE = 0 RGN = 1 COR = 1 FLAG ID = 6 FLAG VALUE = 0 RGN = 1 COR = 1 FLAG ID = 7 FLAG VALUE = 1</p> <p>RGN = 1 COR = 2 FLAG ID = 1 FLAG VALUE = 1 RGN = 1 COR = 2 FLAG ID = 2 FLAG VALUE = 1 RGN = 1 COR = 2 FLAG ID = 3 FLAG VALUE = 0 RGN = 1 COR = 2 FLAG ID = 4 FLAG VALUE = 0 RGN = 1 COR = 2 FLAG ID = 5 FLAG VALUE = 0 RGN = 1 COR = 2 FLAG ID = 6 FLAG VALUE = 0 RGN = 1 COR = 2 FLAG ID = 7 FLAG VALUE = 0</p>	<p>(1) Perform programming changes for Multi-Digit Restriction.</p>

Laboratory Activity — Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 2.9 (TASK #4 — Continued)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • WORK ORDER #2.8, TASK #4 (Continued) 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
RGN = 1 COR = 3 FLAG ID = 1 FLAG VALUE = 1 RGN = 1 COR = 3 FLAG ID = 2 FLAG VALUE = 1 RGN = 1 COR = 3 FLAG ID = 3 FLAG VALUE = 1 RGN = 1 COR = 3 FLAG ID = 4 FLAG VALUE = 0 RGN = 1 COR = 3 FLAG ID = 5 FLAG VALUE = 1 RGN = 1 COR = 3 FLAG ID = 6 FLAG VALUE = 0 RGN = 1 COR = 3 FLAG ID = 7 FLAG VALUE = 0	(2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity – Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 2.9 (TASK #5)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Establish office code restriction table with CMC-412. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Within restriction group number 1, COR 1, deny office codes 258, 494, 491, 428, 778, 235, and 243. (2) Within restriction group number 1, COR 2, allow office codes 490, 491, 494, 258, 353, 428, 670, and 748. (3) Within restriction group number 1, COR 3, deny office code 555. 	<ol style="list-style-type: none"> (1) Perform programming changes for Multi-digit Restriction. (2) Check/test the operation of after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity — Multi-Digit Restriction Programming (Continued)



GTE OMNI SBGS

WORK ORDER #2.9	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 2.9 (TASK #6)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Establish area code restriction tables with CMC-413. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Within restriction group number 1, COR 1, deny area codes 703, 304, 213, 301, 302, and 609. (2) Within restriction group number 1, COR 2, allow area codes 304, 302, 804, 215, and 703. 	<ol style="list-style-type: none"> (1) Perform programming changes for Multi-digit Restriction. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity – Multi-Digit Restriction Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.9	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER 2.9 (TASK #7)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> Establish combination area/office code restriction tables with CMC-414. 	
PARAMETERS:	INSTRUCTIONS:
<ol style="list-style-type: none"> With restriction group number 1, COR 2, deny area code 304 and office code 490. Within restriction group number 1, COR 1, allow area code 703 and office codes 771, 777, and 327. 	<ol style="list-style-type: none"> Perform programming changes for Multi-digit Restriction. Check/test the operation of changes after completion of this portion of the laboratory activity. Complete review exercise questions.

LAB MILESTONE:
<ul style="list-style-type: none"> VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. ASK INSTRUCTOR TO INSPECT STATION PROGRAMMING CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST. MAKE CERTAIN QUESTIONS 1-10 OF REVIEW EXERCISE 2.9 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.

Review Exercise – Toll and Multi-Digit Restriction (2.9)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. ASSIGNED RESTRICTION TABLES MUST BE _____ OR _____ THROUGH CLASS OF RESTRICTION.
2. DESIGNATED TRUNKS GROUP NUMBERS ARE ASSIGNED TO DAY AND NIGHT COR LEVELS WITH CMC- _____.
3. A MAXIMUM OF _____ AREA AND OFFICE CODES ARE ALLOWED IN THE SYSTEM'S COMBINED RESTRICTION TABLES.
4. WHAT CMC COMMANDS, PARAMETERS AND SETTINGS WOULD REQUIRE ENTRY TO ALLOW INTERNATIONAL, TOLL ASSISTANCE, AND LONG DISTANCE DIRECTORY?

5. THE DEFAULT SETTING FOR CUSTOMER TOLL PREFIX IS _____ AND FOR OPERATOR PREFIX IS _____.
6. AREA CODES AND OFFICE CODES ARE SELECTED IN RESTRICTION TABLES BASED ON THE KEY PARAMETERS, _____ AND _____.
7. (TRUE OR FALSE) _____ WHEN ASSIGNING OFFICE AND AREA CODE RESTRICTION TABLES, THE MOST RECENT SETTING FOR A RESTRICTION GROUP OVERRIDES ALL PREVIOUS SETTINGS.

Review Exercise – Toll and Multi-Digit Restriction (2.9) (Continued)



GTE OMNI SBCS

8. WHAT CMC COMMAND, PARAMETERS, AND SETTINGS WOULD BE REQUIRED TO ASSIGN 916 & 418 AS OFFICE CODES?

9. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DEFINITION:

- | | |
|---------------|---|
| _____ CMC-105 | A. TRUNK COS/COR ASSIGNMENT |
| _____ CMC-252 | B. OFFICE CODE RESTRICTION ASSIGNMENT |
| _____ CMC-400 | C. AREA/OFFICE CODE RESTRICTION ASSIGNMENT |
| _____ CMC-401 | D. ASSIGN A TOLL PREFIX CODE |
| _____ CMC-402 | E. TOLL AND OPERATOR CALL RESTRICTION ASSIGNMENT |
| _____ CMC-411 | F. AREA CODE RESTRICTION ASSIGNMENT |
| _____ CMC-412 | G. NO/1X OFFICE CODE ASSIGNMENT |
| _____ CMC-413 | H. TRUNK DIALING GROUP/RESTRICTION GROUP ASSIGNMENT |
| _____ CMC-414 | I. TRUNK RESTRICTION |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Least Cost Routing

2.10 Enabling Objective



GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — LEAST COST ROUTING PROGRAMMING
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - CREATE AREA CODE, OFFICE CODE, AND COMBINED AREA/OFFICE CODE ROUTE TABLES INCLUDING DESIRED ROUTE SELECTION SEQUENCE, DESIGNATED TRUNK GROUPS, AND DIALING PATTERN.
 - IDENTIFY AND ASSIGN APPROPRIATE CARRIER ACCESS CODES FOR OUTGOING LCR CONNECTIONS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Least Cost Routing



GTE OMNI SBCS

DESCRIPTION

- ALLOWS SYSTEM TO SELECT MOST ECONOMICAL TRUNK ROUTE FOR OUTGOING CALLS (BASED ON OUTSIDE NUMBER DIALED).
- STORES AND EXAMINES EACH DIALED NUMBER AND CHECKS AREA AND/OR OFFICE CODES TO SELECT MOST APPROPRIATE TRUNK FROM LCR ROUTE TABLE.
- PROVIDES 15 ROUTE TABLES FOR DEFINING TRUNK GROUPS BASED ON AREA CODES OR COMBINED AREA/OFFICE CODES AND ANOTHER 15 ROUTE TABLES FOR OFFICE CODES - 10 SELECTION SEQUENCES CAN BE REGISTERED FOR EACH ROUTE TABLE.
- CALLING STATION'S CLASS OF SERVICE DETERMINES THE LCR ROUTES.
- TOLL AND MULTI-DIGIT RESTRICTION APPLY TO OUTGOING CALLS USING LCR.

PROCEDURE

1. USE CMC-421 TO ESTABLISH AREA CODE ROUTE TABLE
 - AREA CODE ROUTE TABLE NUMBER (P1)
 - ROUTE SELECTION SEQUENCE (P2)
 - DESIGNATED TRUNK GROUP NUMBER (P3)*
 - DIGIT COMPOSING (DIALING PATTERN) FLAG (P4)**
2. USE CMC-423 TO ASSIGN LCR AREA CODE TO ROUTE TABLE NUMBER:
 - AREA CODE ROUTE TABLE NUMBER (P1)
 - (THREE DIGIT) AREA CODE FOR AREA CODE ROUTE TABLE (FOR CMC-421) (P2)
3. USE CMC-420 TO ESTABLISH OFFICE CODE ROUTE TABLE:
 - OFFICE CODE ROUTE TABLE NUMBER (P1)
 - ROUTE SELECTION SEQUENCE (P2)
 - DESIGNATED TRUNK GROUP NUMBER (P3)*
 - DIGIT COMPOSING (DIALING PATTERN) FLAG (P4)**

- * REFER TO CMC TABLE, OMNI SBCS GTEP MANUAL, FOR LIST OF TRUNK GROUPS NUMBERS.
** REFER TO CMC TABLE, OMNI SBCS GTEP MANUAL, FOR LIST OF FLAG VALUE DENITIONS.

CMC = 421
P1: 2 P4: 1
P2: 1
P3: 25

CMC = 423
P1: 2
P2: 213

CMC = 420
P1: 2 P4: 3
P2: 1
P3: 14

Programming Least Cost Routing



GTE OMNI SBCS

PROCEDURE (CONTINUED)

4. USE CMC-422 TO ASSIGN LCR OFFICE CODE FOR ROUTE TABLE NUMBER:
 - DESIGNATED OFFICE CODE ROUTE TABLE NUMBER (FOR CMC-420) (P1)
 - THREE-DIGIT OFFICE CODE (P2)

5. USE CMC-424 TO ASSIGN LCR AREA/OFFICE CODE TO AREA/OFFICE CODE ROUTE TABLE NUMBER:
 - DESIGNATED AREA/OFFICE CODE ROUTE TABLE NUMBER (FOR CMC-421) (P1)
 - THREE-DIGIT AREA CODE (P2)
 - THREE-DIGIT OFFICE CODE (P3)

6. USE CMC-425 TO ASSIGN CARRIER ACCESS CODES WHEN OUTGOING CONNECTIONS ARE MADE BY LCR:
 - CARRIER ACCESS CODE (P1)*
 - DESIGNATED 5-DIGIT CARRIER ACCESS NUMBER (P2)

CMC = 422
P1: 2
P2: 273

CMC = 424
P1: 3
P2: 614
P3: 486

CMC = 425
P1: 1
P2: 10288

* REFER TO CMC TABLE, OMNI SBCS GTEP MANUAL, FOR APPROPRIATE CODE.

Programming Least Cost Routing/CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• LCR OFFICE CODE ROUTE SELECTION	420	DEFINES OFFICE CODE ROUTE SEQUENCE
• LCR AREA AND AREA/ OFFICE CODE ROUTE SELECTION	421	DEFINES AREA CODE ROUTE SEQUENCE
• LCR OFFICE CODE ASSIGNMENT	422	DEFINES OFFICE CODE TABLE
• LCR AREA CODE ASSIGNMENT	423	DEFINES AREA CODE TABLE
• LCR AREA/OFFICE CODE ASSIGNMENT	424	DEFINES AREA/OFFICE CODE TABLE
• LCR CARRIER ACCESS CODE ASSIGNMENT	425	DEFINES SCC ACCESS CODE TABLE

Laboratory Activity – Least Cost Routing Programming



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO LEAST COST ROUTING PROGRAMMING UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.10															
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212														
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.10 (TASK #1)</u>														
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER															
<u>TASKS:</u>															
<ul style="list-style-type: none"> • Build LCR Office code route tables with CMC-420. 															
<u>PARAMETERS:</u> (1) Establish office code route table numbers for following trunk group numbers including designated selection sequence and digit composing flag: <table style="width: 100%; border: none;"> <tr> <td style="padding: 2px;">Office Code</td> <td style="padding: 2px;">Selection Sequence=1 TGN=19 Flag=3</td> </tr> <tr> <td style="padding: 2px;">Route Table 1</td> <td style="padding: 2px;">Selection Sequence=2 TGN=32 Flag=3</td> </tr> <tr> <td></td> <td style="padding: 2px;">Selection Sequence=3 TGN=31 Flag=3</td> </tr> <tr> <td style="padding: 2px;">Office Code</td> <td style="padding: 2px;">Selection Sequence=1 TGN=32 Flag=3</td> </tr> <tr> <td style="padding: 2px;">Route Table 2</td> <td style="padding: 2px;">Selection Sequence=2 TGN=33 Flag=3</td> </tr> <tr> <td></td> <td style="padding: 2px;">Selection Sequence=3 TGN=31 Flag=3</td> </tr> <tr> <td></td> <td style="padding: 2px;">Selection Sequence=4 TGN=19 Flag=3</td> </tr> </table>	Office Code	Selection Sequence=1 TGN=19 Flag=3	Route Table 1	Selection Sequence=2 TGN=32 Flag=3		Selection Sequence=3 TGN=31 Flag=3	Office Code	Selection Sequence=1 TGN=32 Flag=3	Route Table 2	Selection Sequence=2 TGN=33 Flag=3		Selection Sequence=3 TGN=31 Flag=3		Selection Sequence=4 TGN=19 Flag=3	<u>INSTRUCTIONS:</u> (1) Perform programming changes for Least Cost Routing. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.
Office Code	Selection Sequence=1 TGN=19 Flag=3														
Route Table 1	Selection Sequence=2 TGN=32 Flag=3														
	Selection Sequence=3 TGN=31 Flag=3														
Office Code	Selection Sequence=1 TGN=32 Flag=3														
Route Table 2	Selection Sequence=2 TGN=33 Flag=3														
	Selection Sequence=3 TGN=31 Flag=3														
	Selection Sequence=4 TGN=19 Flag=3														

Laboratory Activity – Least Cost Routing Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.10	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.10 (TASK #2)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign office codes to route tables with CMC-422. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<p>(1) Assign the following office codes to the designated office code route table:</p> <p>Office Code Route Table 1 Office Codes = 490, 491, and 494</p> <p>Office Code Route Table 2 Office Codes = 258, 353, 428, 670, 753, 843, and 870</p>	<p>(1) Perform programming changes for Least Cost Routing.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Proceed to next work order task.</p>

Laboratory Activity – Least Cost Routing Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.10	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.10 (TASK #3)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Build LCR area code route tables with CMC-421. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<p>(1) Establish area code route numbers for following trunk group numbers including designated selection sequence and digit composing flag:</p> <p>Area Code Selection Sequence=1 TGN=33 Flag=10 Route Table 1 Selection Sequence=2 TGN=32 Flag=10 Selection Sequence=3 TGN=19 Flag=10</p> <p>Area Code Selection Sequence=1 TGN=25 Flag=10 Route Table 2 Selection Sequence=2 TGN=29 Flag=10 Selection Sequence=3 TGN=34 Flag=10 Selection Sequence=4 TGN=33 Flag=10 Selection Sequence=5 TGN=19 Flag=10</p> <p>Area Code Selection Sequence=1 TGN=19 Flag=10 Route Table 3</p>	<p>(1) Perform programming changes for Least Cost Routing.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Proceed to next work order task.</p>

Laboratory Activity – Least Cost Routing Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.10					
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212				
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.10 (TASK #4)</u>				
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER					
<u>TASKS:</u>					
<ul style="list-style-type: none"> • Assign exceptions to area/office code route tables with CMC-423. 					
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>				
<p>(1) Assign following area code exceptions to designated area code route table numbers.</p> <table> <tr> <td>Area Code Route Table 1</td> <td>Area Codes = 301, 302, 304, and 804.</td> </tr> <tr> <td>Area Code Route Table 2</td> <td>Area Codes = 609, 212, 718, 215, 415, and 213.</td> </tr> </table>	Area Code Route Table 1	Area Codes = 301, 302, 304, and 804.	Area Code Route Table 2	Area Codes = 609, 212, 718, 215, 415, and 213.	<ol style="list-style-type: none"> (1) Perform programming changes for Least Cost Routing. (2) Check/test the operation of changes after completion of this portion of the laboratory activity. (3) Proceed to next work order task.
Area Code Route Table 1	Area Codes = 301, 302, 304, and 804.				
Area Code Route Table 2	Area Codes = 609, 212, 718, 215, 415, and 213.				

Laboratory Activity – Least Cost Routing Programming (Continued)



GTE OMNI SBCS

WORK ORDER #2.10	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.10 (TASK #5)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Assign combined office/area code route tables with CMC-424. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<p>(1) Assign the following office/area codes to the designated area/office code table:</p> <p>Area/Office Code Route Table 1 Area Code = 703 Office Codes = 771, 777, and 327</p>	<p>(1) Perform programming changes for Least Cost Routing.</p> <p>(2) Check/test the operation of changes after completion of this portion of the laboratory activity.</p> <p>(3) Complete review exercise questions 1-10.</p>

- LAB MILESTONE:**
- VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY.
 - ASK INSTRUCTOR TO INSPECT LEAST COST ROUTING PROGRAMMING CHANGES AND INITIAL YOUR PERFORMANCE CHECKLIST.
 - MAKE CERTAIN QUESTIONS 1-10 OF REVIEW EXERCISE 2.10 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING.

Review Exercise — Least Cost Routing (2.10)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. LEAST COST ROUTING STORES AND SELECTS TRUNK ROUTE BASED ON: _____
 - A) AVAILABILITY
 - B) LCR ROUTE TABLE
 - C) CALLING STATION'S COS
 - D) ALL OF THE ABOVE
 - E) NONE OF THE ABOVE
2. LCR PROVIDES _____ AREA CODE OR COMBINED AREA/OFFICE CODE ROUTE TABLES AND _____ OFFICE CODE ROUTE TABLES.
3. A MAXIMUM OF _____ TRUNK GROUP ALTERNATIVES MAY BE ASSIGNED TO EACH LCR ROUTE.
4. (TRUE OR FALSE) _____ TOLL AND MULTI-DIGIT RESTRICTION DO NOT APPLY TO LCR CALLS.
5. BEFORE ASSIGNING LCR OFFICE OR AREA CODES, LCR _____ MUST BE BUILT WITH CMC-420 AND 421.
6. WHAT PARAMETER WOULD YOU USE TO ASSIGN THE APPROPRIATE DIGIT COMPOSING FLAG WHEN BUILDING AN OFFICE OR AREA ROUTE TABLE WITH CMC-420 AND 421? _____
7. OFFICE AND AREA CODES MAY BE ASSIGNED TO _____ WITH CMC-422 AND CMC-423.

Review Exercise — Least Cost Routing (2.10) (Continued)



GTE OMNI SBCS

8. WHAT CMC COMMANDS, PARAMETERS, AND SETTINGS WOULD BE REQUIRED TO ESTABLISH AREA CODE ROUTE TABLE NUMBER 1 FOR A CO TRUNK USING AREA CODES 614, 317, and 201?

9. WHICH COS LEVELS WOULD ALLOW ACCESS TO ALL ROUTES IN THE LCR TABLES? _____

10. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DESCRIPTION:

- | | |
|---------------|---|
| _____ CMC-420 | A. LCR AREA CODE ASSIGNMENT |
| _____ CMC-421 | B. LCR OFFICE CODE ASSIGNMENT |
| _____ CMC-422 | C. LCR AREA AND AREA/OFFICE CODE ROUTE SELECTION ASSIGNMENT |
| _____ CMC-423 | D. LCR CARRIER ACCESS CODE ASSIGNMENT |
| _____ CMC-424 | E. LCR AREA/OFFICE CODE ASSIGNMENT |
| _____ CMC-425 | F. LCR OFFICE CODE ROUTE SELECTION ASSIGNMENT |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Programming Special System

Configurations



2.11 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — SPECIAL SYSTEM CONFIGURATION PROGRAMMING
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - MODIFY SYSTEM PARAMETERS TO ACCOMMODATE FRONT-END ARRANGEMENT WHERE OMNI SBCS FUNCTIONS BEHIND A PABX.
 - ASSIGN TENANT SERVICE CONFIGURATION.
 - ESTABLISH AN OFF-PREMISE EXTENSION.
 - MODIFY SYSTEM TANDEM TRUNK SWITCHING FOR NETWORK APPLICATIONS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Special System Configurations/**GTE** SBCS Behind a PABX

GTE OMNI SBCS

DESCRIPTION

- SBCS CAN FUNCTION AS A STANDALONE COMMUNICATION SYSTEM OR AS A FRONT-END SYSTEM BEHIND OTHER SWITCHING EQUIPMENT, SUCH AS A PABX.
- SOME SYSTEM PARAMETER VALUES MAY REQUIRE RESETING TO ACCOMMODATE CONFIGURATIONS POSSIBLE WITH A FRONT-END ARRANGEMENT.

PROCEDURE

REFER TO CMC-100 TO COORDINATE FEATURE ACCESS NUMBERING PLANS FOR BOTH SYSTEMS AND CMC-200 TO COORDINATE STATION NUMBERING PLANS.

1. USE CMC-250 TO MODIFY TRUNK ASSIGNMENT DATA:
 - EQUIPMENT NUMBER (P1)
 - TYPE OF TRUNK (P2)
 - TRUNK GROUP NUMBER (P3)
 - OPERATION MODE (P4)
 - SIGNALING (P5)
 - START MODE/ZONE NUMBER (P6)

CMC = 250
P1: 182 P4: 3
P2: 6 P5: 1
P3: 13 P6: 1

2. USE CMC-254 TO MODIFY TRUNK ROUTE TIMING SO THAT SBCS FLASH TIMING VALUE MATCHES HOST PABX:
 - TRUNK GROUP NUMBER (P1)
 - ROUTE TIMING IDENTIFICATION NUMBER (P2)
 - NORMALIZED TIMING (P3)

CMC = 254
P1: 13
P2: 12
P3: 5

3. USE CMC-400 TO MODIFY TRUNK DIALING GROUP NUMBERS AND RESTRICTION GROUP ASSIGNMENTS:
 - TRUNK GROUP NUMBER (P1)
 - DIAL GROUP NUMBERS (P2 = BLANK)
 - TOLL RESTRICTION GROUP NUMBER (P3 = BLANK)

CMC = 400
P1: 13
P2:
P3:

Programming Special System Configurations/**GTE** Tenant Assignments

GTE OMNI SBCS

DESCRIPTION

- **ALLOWS SBCS TO BE SHARED BY AS MANY AS FIVE TENANTS. TENANTS MAY USE OWN STATIONS AND/OR TRUNKS, BUT SHARE COMMON CONTROL LOGIC, POWER SUPPLY, ATTENDANT CONSOLE, AND SERVICE TRUNKS.**
- **STATIONS AND TRUNKS (EXCEPT TIE TRUNKS) ARE ASSIGNED TO TENANT NUMBERS SO EACH TENANT CAN ACCESS OWN TRUNKS. TENANTS SHARE SAME FEATURE ACCESS CODE AND STATION NUMBERING PLAN.**
- **THREE TYPES OF TENANT TRUNK SHARING DESIGNATIONS ARE AVAILABLE:**
 - **OUTGOING/INCOMING TENANT (NO TRUNK SHARING WITH OTHER TENANTS)**
 - **OUTGOING ONLY TENANT (SHARING INCOMING TRUNKS WITH OTHER TENANTS)**
 - **INCOMING ONLY TENANT (SHARING OUTGOING TRUNKS WITH OTHER TENANTS)**
- **STATION MESSAGE DETAIL RECORDING (SMDR) OUTPUT CAN BE RECORDED BY TENANT NUMBERS. FIFTH TENANT IS INDICATED BY CORRESPONDING "BLANK" OUTPUT FOR TENANT NUMBER REFERENCE.**

Programming Special System Configurations/**GTE** Tenant Assignment

GTE OMNI SBCS

PROCEDURE

1. USE CMC-201 TO ASSIGN TENANT NUMBERS TO STATIONS:
 - STATION DIRECTORY NUMBER (P1)
 - OPERATION MODE (P2)
 - TYPE OF DIALING (P3)
 - TENANT NUMBER (P4)
 - METERING GROUP NUMBER FOR SMDR (P5)
2. IF APPLICABLE, USE CMC-102 TO SELECT:
 - FLAG NUMBER (P1)
 - SET VALUE (P2)
3. USE CMC-251 TO ASSIGN TENANT NUMBERS TO TRUNKS:
 - EQUIPMENT NUMBER (P1)
 - DIAL MODE/BREAK RATIO (P2)
 - TRUNK DIRECTORY NUMBER (P3)
 - TENANT NUMBER (P4)
4. USE CMC-503 TO ASSIGN SMDR OUTPUT FOR TENANTS:
 - TENANT NUMBER (P1)
 - OUTPUT IDENTIFICATION FLAG (P2)

CMC = 201
P1: 236 P4: 2
P2: 1 P5:
P3: 3

CMC = 102
P1: 1
P2: 1

CMC = 251
P1: 161 P4: 3
P2: 5
P3: 3

CMC = 503
P1: 2
P2: 1

Programming Special System Configurations/ Off-Premises Extension (OPX)



GTE OMNI SBCS

DESCRIPTION

- ALLOW CONNECTION TO THE SBCS SYSTEM OF SINGLE-LINE TELEPHONE INSTRUMENTS LOCATED AT OFF-PREMISES LOCATION.
- CUSTOMER PROVIDED LOOP EXTENDER MUST BE INSTALLED TO EXTEND STATION LINES AND TO PROTECT PUBLIC SWITCHED NETWORK, IF THE IMPEDANCE OF THE PHONE EXCEEDS THE LOOP LIMIT OF THE SYSTEM.
- OFF PREMISES EXTENSION (OPX) EQUIPMENT IS MOUNTED AND POWERED EXTERNALLY TO OMNI SBCS CABINET.
- RINGING PATTERN FOR OPX STATIONS IS FIXED AND DEFAULT PATTERN IS STATION RINGING PATTERN.

PROCEDURE*

1. USE CMC-200 TO ASSIGN OPX EQUIPMENT NUMBER TO STATION DIRECTORY NUMBER.
 - EQUIPMENT NUMBER (P1)
 - DIRECTORY NUMBER (P2)
 - TYPE OF TERMINAL (P3)
 - COPIED STATION DIRECTORY NUMBER (P4)
2. USE CMC-204 TO IDENTIFY DIRECTORY NUMBER AS OPX EXTENSION:
 - STATION NUMBER (P1)
 - DATA SECURE (P2)
 - OFF-PREMISES EXTENSION (P3)
 - SLT WITH MESSAGE WAITING LAMP (P4)
3. USE CMC-102 TO CHANGE RINGING PATTERN:
 - FLAG NUMBER (P1) — (FLAGS 2 AND 9)
 - SET VALUE (P2)

CMC = 200
P1: 015 P4:
P2: 346
P3: 1

CMC = 204
P1: 346 P4: 0
P2: 0
P3: 1

CMC = 102
P1: 2
P2: 2

* ASSUMES INSTALLATION OF SINGLE-LINE TELEPHONE INSTRUMENT AND LOOP EXTENDER AND PHYSICAL CONNECTION OF OPX LINE TO DESIRED CIRCUIT ON 8SLC CARD.

Programming Special System Configuration/**GTE** CMC Command Summary

GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• SBCS BEHIND A PABX	CMC-250	MODIFY TRUNK ASSIGNMENT DATA
	CMC-254	MODIFY TRUNK ROUTE TIMING ASSIGNMENT
	CMC-400	MODIFY TRUNK DIALING ASSIGNMENT
• TENANT ASSIGNMENT	CMC-201	ASSIGN TENANT NUMBERS TO STATIONS
	CMC-251	ASSIGN TENANT NUMBERS TO TRUNKS
	CMC-503	ASSIGN SMDR OUTPUT FOR TENANTS
• OFF-PREMISE EXTENSION	CMC-200	ASSIGN OPX EQUIPMENT NUMBER TO STATION DIRECTORY NUMBER
	CMC-204	IDENTIFY DIRECTORY NUMBER AS OPX EXTENSION
	CMC-102	CHANGE RINGING PATTERN FOR OPX FIXED RINGING

Laboratory Activity — Programming Special System Configurations



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO SPECIAL SYSTEM CONFIGURATIONS UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.11	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.11 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none"> • Perform necessary system modifications required to program OMNI SBCS behind a host PABX with CMC-100, CMC-254, CMC-400, and CMC-300. 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Modify the OMNI SBCS flash timing value to .500 seconds using CMC-254. Change P3 to value of 5. (2) Change the trunk dialing group and restriction group numbers with CMC-400. Ensure that P2 and P3 are blank. (3) Change any system speed calling directory numbers with CMC-300 to conform to host system. Ensure that access code (P2) is 9 and send number (P3) begins with 9#. 	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Verify that there are no numbering conflicts in feature access for the OMNI SBCS or the host PABX, using CMC-100. Examine station numbering plan for conflicts and make appropriate changes with CMC-200. (2) Perform programming changes for special system configuration. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Proceed to next work order task.

Laboratory Activity — Programming Special System Configurations (Continued)



GTE OMNI SBCS

WORK ORDER #2.11															
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212														
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.11 (TASK #2)														
ORIGINATOR: TELECOMMUNICATIONS MANAGER															
TASKS: <ul style="list-style-type: none"> Assign tenant assignments with CMC-201, CMC-102, and CMC-251. 															
PARAMETERS: <ol style="list-style-type: none"> Assign stations to tenant numbers with CMC-201 using the following groups: <table border="1"> <thead> <tr> <th>Station DN</th> <th>Tenant Group</th> </tr> </thead> <tbody> <tr> <td>308</td> <td>1</td> </tr> <tr> <td>215</td> <td>1</td> </tr> <tr> <td>212</td> <td>1</td> </tr> <tr> <td>214</td> <td>2</td> </tr> <tr> <td>216</td> <td>2</td> </tr> <tr> <td>223</td> <td>2</td> </tr> </tbody> </table> Select "own trunk for outgoing - share incoming trunks" option with CMC-102. Assign trunk equipment number to tenant group 1 and trunk equipment number to tenant group 2 with CMC-251. If SMDR has been installed, indicate that tenant groups 1 and 2 will require output with CMC-503. 	Station DN	Tenant Group	308	1	215	1	212	1	214	2	216	2	223	2	INSTRUCTIONS: <ol style="list-style-type: none"> Perform programming changes for special system configuration. Check/test the operation of changes after completion of this portion of the laboratory activity. Proceed to next work order task.
Station DN	Tenant Group														
308	1														
215	1														
212	1														
214	2														
216	2														
223	2														

Laboratory Activity – Programming Special System Configurations (Continued)



GTE OMNI SBCS

WORK ORDER #2.11	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.11</u> (TASK #3)
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Perform programming required for single line station designated as off-premises extension with CMC-200, CMC-204, and CMC-102. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Verify the OPX equipment number 027 has been assigned to the SLT instrument (directory number 223) using CMC-200. (2) Identify above station as OPX station using CMC-204 (P3). (3) Change ringing pattern for OPX station using CMC-102 (P2, flag 2) from station call ringing (default) to incoming call ringing. 	<ol style="list-style-type: none"> (1) Ensure that off-premises SLT instrument and customer provided loop extender are physically installed. NOTE: Above verification is not required for this lab activity since lab activity simulates OPX installation and actually uses an on-site SLT. (2) Perform programming changes for special system configuration. (3) Check/test the operation of changes after completion of this portion of the laboratory activity. (4) Complete review exercise questions 1 - 10.

LAB MILESTONE:
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED IN WORK ORDERS HAVE BEEN PERFORMED CORRECTLY. • ASK INSTRUCTOR TO INSPECT SPECIAL SYSTEM CONFIGURATIONS PROGRAMMING AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN QUESTIONS 1-10 OF REVIEW EXERCISE 2.11 HAVE BEEN COMPLETED BEFORE SUBMITTING TO THE INSTRUCTOR FOR GRADING.

Review Exercise — Special System Configurations (2.11)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. **EXPLAIN WHY IT IS NECESSARY TO EXAMINE TABLES FOR CMC-100 AND CMC-200 WHEN INSTALLING AN OMNI SBCS BEHIND A PABX.** _____

2. **HOW WOULD YOU INCREASE THE OMNI SBCS FLASH TIMING VALUE WITH CMC-254?** _____

3. **WHY WOULD YOU LEAVE THE PARAMETERS FOR TRUNK DIAL GROUP NUMBER AND TOLL RESTRICTION GROUP BLANK WHEN MODIFYING CMC-400 TO ALLOW FOR THE OMNI SBCS BEHIND A PABX?** _____

Review Exercise — Special System Configurations (2.11) (Continued)



GTE OMNI SBCS

4. THE SYSTEM WILL ALLOW A MAXIMUM OF _____ TENANT GROUPS FOR STATIONS AND TRUNKS.

5. WHAT PROGRAMMING WOULD BE REQUIRED TO ALLOW TENANTS TO HAVE THEIR OWN INCOMING AND OUTGOING TRUNKS?

6. WHAT ADDITIONAL CUSTOMER PROVIDED EQUIPMENT IS REQUIRED FOR OPX INSTALLATION? WHY?

7. WHAT PROCEDURE(S) COULD BE USED TO CHANGE THE DEFAULT STANDARD RINGING PATTERN FOR AN OPX STATION?

8. OPX STATIONS INTERFACE TO THE OMNI SBCS THROUGH A _____ CARD.

Review Exercise — Special System Configurations (2.11) (Continued)



GTE OMNI SBCS

9. WHAT PARAMETER AND SETTING IS REQUIRED FOR CMC-204 FOR DESIGNATING AN OPX STATION?

10. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DEFINITION:

- | | |
|---------------|---|
| _____ CMC-100 | A. TRUNK DIALING GROUP AND RESTRICTION GROUP ASSIGNMENT |
| _____ CMC-102 | B. TRUNK DATA ASSIGNMENT |
| _____ CMC-200 | C. SYSTEM PARAMETER ASSIGNMENT |
| _____ CMC-201 | D. DATA SECURITY AND OPX ASSIGNMENT |
| _____ CMC-204 | E. TRUNK GROUP ROUTE TIMING ASSIGNMENT |
| _____ CMC-251 | F. SMDR TENANT SCREENING |
| _____ CMC-254 | G. STATION DIRECTORY NUMBER ASSIGNMENT |
| _____ CMC-400 | H. NUMBERING PLAN ASSIGNMENT |
| _____ CMC-503 | I. STATION DATA ASSIGNMENT |



GTE OMNI SBCS

DATA BASE ADMINISTRATION

Save/Load Procedures



2.12 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — SAVING AND LOADING OFFICE DEPENDENT DATA BASE (ODDB)
 - REVIEW EXERCISE
- ACTION:**
- USE OMNI SBCS PROGRAMMING TOOLS AND EQUIPMENT TO:
 - SAVE OFFICE DEPENDENT DATA BASE TO TAPE.
 - LOAD OFFICE DEPENDENT DATA BASE FROM TAPE.
 - SAVE OFFICE DEPENDENT DATA BASE TO FLOPPY DISKETTE.
 - LOAD OFFICE DEPENDENT DATA BASE FROM TAPE.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINES IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Saving Office Dependent Data Base to Tape



GTE OMNI SBCS

DESCRIPTION

- AFTER PROGRAMMING CHANGES, CUSTOMIZED DATA BASE OR OFFICE DEPENDENT DATA BASE (ODDB) STORED IN THE OMNI SBCS SYSTEM MAIN MEMORY MUST BE STORED TO A PMP MICROCASSETTE.
- TIME REQUIRED TO WRITE ODDB TO TAPE IS DEPENDENT UPON SIZE OF ODDB AND LINE SPEED.
- SAVE PROCEDURE WILL NOT INTERRUPT CALL PROCESSING IF OPERATING AT LESS THAN 1200 BITS PER SECOND.
- SAVE PROCEDURE CANNOT BE PERFORMED USING MASTER CONTROL TELEPHONE.

PROCEDURE

1. USE CMC-903 TO SAVE ODDB TO PMP TAPE:

- VERIFICATION (P1)
 - a. ENTER: **SAVE**
 - b. **PRESS ADD/CHANGE**. SCREEN WILL PROMPT.

*SAVE PROCESS
SET DATA TAPE
HIT PF9 TO START

- c. INSERT A BLANK 60 MINUTE MICROCASSETTE INTO THE TAPE DRIVE. (PMP WILL AUTOMATICALLY REWIND TAPE IF NECESSARY).
- d. **PRESS PF9 (SHIFT + PF4)**. SCREEN WILL DISPLAY MESSAGE THAT SAVE PROCESS HAS BEGUN:

*SAVE PROCESS
START

Saving Office Data Base to Tape (Continued)



GTE OMNI SBCS

- e. THEN SCREEN WILL DISPLAY TAPE DATE INCLUDING SAVED DATE, TAPE VERSION, AND VOLUME SERIAL NUMBER:

```
*SAVE PROCESS  
SAVED DATE NN/DD/YY  
TAPE VER xxx/VOL xx
```

- f. WHEN SAVE PROCESS IS COMPLETED, THE SCREEN WILL DISPLAY:

```
*SAVE PROCESS  
COMPLETION
```

ERRORS

- IF ODDB BACKUP TAPE HAS NOT BEEN INSERTED OR IF TAPE IS OVERWRITE PROTECTED, SCREEN WILL DISPLAY:

```
*SAVE PROCESS  
TAPE DOES NOT EXIST  
SEE DATA TAPE  
HIT PF9 TO START
```

INSERT TAPE OR BREAK OVERWRITE TAPE. REPEAT STEP 5 AND CONTINUE PROCEDURE.

- IF TAPE ENDS BEFORE SAVE PROCESS IS COMPLETED, SCREEN WILL DISPLAY:

```
*SAVE PROCESS  
DATA TAPE END  
CHANGE DATA TAPE  
HIT PF9 TO START
```


ATTEMPT TO LOAD TAPE AGAIN OR INSERT ANOTHER TAPE. REPEAT STEP 5 TO RESTART THE SAVE PROCESS.

Saving Office Data Base to Tape (Continued)



GTE OMNI SBCS

- IF RELEASE (PF1) KEY IS ACCIDENTALLY PRESSED, SAVE PROCESS WILL BE INTERRUPTED AND SCREEN WILL DISPLAY:



BEGIN SAVE PROCEDURE AGAIN FROM STEP a.

Loading Office Dependent Data Base From Tape



GTE OMNI SBCS

DESCRIPTION

- TIME REQUIRED TO LOAD ODDB FROM TAPE IS DEPENDENT UPON SIZE OF ODDB AND LINE SPEED.
- ALL CALL PROCESSING STOPS DURING LOADING PROCESS.
- AFTER COMPLETION OF LOADING PROCESS, OMNI SBCS AUTOMATICALLY INITIATES HOT RESTART.

PROCEDURE

NOTE: BECAUSE CALL PROCESSING STOPS DURING LOADING PROCESS, CHECK CALL STATUS WITH DSS/BLF CONSOLE AND WAIT UNTIL CALLS ARE COMPLETED. IF LOADING REQUIREMENT IS URGENT, INTERRUPT CALLS THROUGH EXECUTIVE OVERRIDE FEATURE AND WARN USERS THAT CALL PROCESSING SERVICE WILL BE INTERRUPTED.

1. USE CMC-904 TO VERIFY TAPE VERSION AGAINST OMNI SBCS SYSTEM SOFTWARE VERSION.
 - VERSION IDENTIFICATION NUMBER (P1)
2. USE CMC-902 TO LOAD ODDB FROM PMP TAPE TO SYSTEM MEMORY.
 - VERIFICATION (P1)
 - a. ENTER: **LOAD**
 - b. **PRESS ADD/CHANGE.** SCREEN WILL PROMPT:

*LOAD PROCESS
SET DATA TAPE
HIT PF9 TO START
 - c. INSERT ODDB MICROCASSETTE TAPE. ENSURE THAT TAPE IS REWOUND.

Loading Office Dependent Data Base From Tape (Continued)



GTE OMNI SBCS

- d. **PRESS PF9 (SHIFT + PF4).** CALL PROCESSING NOW IS INTERRUPTED. SCREEN WILL DISPLAY:

*LOAD PROCESS
START

THEN SCREEN WILL DISPLAY TAPE DATA INCLUDING SAVED DATE, TAPE VERSION, AND VOLUME SERIAL NUMBER:

*LOAD PROCESS
SAVED DATE NN/DD/YY
TAPE VER xxx/VOL.xx
HIT PF9 TO START

- e. **PRESS PF9 (SHIFT + PF4) TO START LOADING PROCESS.**
- f. WHEN LOAD PROCESS IS COMPLETED, THE SYSTEM WILL AUTOMATICALLY INITIATE A HOT RESTART. THE SCREEN WILL DISPLAY:

*LOAD PROCESS
COMPLETION

- g. CONFIRM HOT RESTART BY VERIFYING THAT "SECURITY CODE=" IS DISPLAYED ON SCREEN. **MANUALLY HOT RESTART SYSTEM** (CPM CARD TOGGLE SWITCH DOWN WHILE PRESSING RESTART BUTTON) IF SYSTEM FAILS TO HOT RESTART AUTOMATICALLY.
- h. THE TIMER OVERFLOW LAMP WILL BE ON. **ENTER CMC-801 AND READ OUT ALL FAULTS.** LAMP WILL BE TURNED OFF WHEN FAULT LISTING IS COMPLETED.
- i. THE SCREEN MAY DISPLAY "NO TRANSMISSION" IF PMP HAS BEEN UNATTENDED FOLLOWING LOADING OF ODDB TAPE. THIS INDICATES THAT COMMUNICATION CHANNEL BETWEEN PMP AND OMNI SBCS HAS BEEN IDLE. **PRESS ANY ALPHABETIC KEY TO STOP MESSAGE.**

Loading Office Dependent Data Base From Tape (Continued)



GTE OMNI SBCS

ERRORS

- IF ODDB TAPE VERSION DOES NOT MATCH OMNI SBCS SOFTWARE VERSION,, THE SCREEN WILL DISPLAY:

```
*LOAD PROCESS  
BAD TAPE/SF VER xxx  
CHANGE DATA TYPE  
HIT PF9 TO START
```

CHANGE TAPE AND **PRESS PF9 (SHIFT + PF4)**. REPEAT STEP D AND CONTINUE PROCEDURE.

- IF INSERTED TAPE IS NOT ODDB TAPE, THE SCREEN WILL DISPLAY:

```
*LOAD PROCESS  
BAD TAPE  
CHANGE DATA TAPE  
HIT PF9 TO START
```

CHANGE TAPE AND **PRESS PF9 (SHIFT + PF4)**. REPEAT STEP D AND CONTINUE PROCEDURE.

- IF ODDB TAPE VOLUME SERIAL NUMBER IS NOT CORRECT, THE SCREEN WILL DISPLAY:

```
*LOAD PROCESS  
ILLEGAL VOL XX  
CHANGE DATA TAPE  
HIT PF9 TO START
```

CHANGE TAPE AND **PRESS PF9 (SHIFT + PF4)**. REPEAT STEP d AND CONTINUE PROCEDURE.

- IF TAPE ENDS BEFORE LOAD PROCESS IS COMPLETED, SCREEN WILL DISPLAY:

```
*LOAD PROCESS  
DATA TAPE ENDS  
CHANGE DATA TAPE  
HIT PF9 TO START
```

CHANGE TO NEXT TAPE AND **PRESS PF9 (SHIFT + PF4)**. REPEAT STEP d TO RESTART LOAD PROCESS.

Loading Office Dependent Data Base From Tape (Continued)



GTE OMNI SBCS

- IF A DEVICE ERROR OCCURS, SCREEN WILL DISPLAY:

*LOAD PROCESS
HARD ERROR
CHANGE DATA TAPE
HIT PF9 TO START

CHANGE TAPE AND **PRESS PF9 (SHIFT + PF4)** TO CONTINUE.

- IF RELEASE (PF1) KEY IS ACCIDENTALLY PRESSED, LOAD PROCESS WILL BE INTERRUPTED AND SCREEN WILL DISPLAY:

*LOAD PROCESS
QUIT

BEGIN LOAD PROCEDURE AGAIN FROM STEP a.

Saving and Loading Office Dependent Data Base to Floppy Diskette



GTE OMNI SBCS

DESCRIPTION

- FLOPPY DISKETTES CAN SIGNIFICANTLY REDUCE TIME REQUIRED FOR ODDB BACKUP AND LOADING.
- AN EPSON TF-20 FLOPPY DISKETTE DRIVE UNIT IS USED IN CONJUNCTION WITH PORTABLE MAINTENANCE PANEL.
- SAVING AND LOADING OPERATING PROCEDURE IS SIMILAR TO PROCEDURE FOR PMP MICROCASSETTES.
- ONE SAVE FLOPPY DISKETTE CAN HOLD ONE COMPLETE OMNI SBCS DATA BASE BACKUP USING A SEQUENTIAL FILE.
- SAVE FLOPPY DISKETTE MUST BE INITIALIZED OR HAVE BEEN USED PREVIOUSLY FOR A BACKUP OPERATION. SAVE DATA ON DISKETTE USED PREVIOUSLY WILL BE WRITTEN OVER BY NEW BACKUP DATA.

PROCEDURE

1. TO CONFIGURE AND CONNECT TF-20 FLOPPY DISKETTE DRIVE TO PORTABLE MAINTENANCE PANEL:
 - ENSURE THAT PMP IS EQUIPPED WITH EXPANSION RAM (EXPANSION UNIT H20EU).
 - SET BIT 4 OF PMP'S DIP SWITCH TO ON. DIP SWITCH IS LOCATED WELL INSIDE AND TO LEFT AS VIEWED WHEN OPENING LID OF BOTTOM PANEL.
 - ENSURE THAT PMP AND TF-20 POWER SWITCHES ARE OFF BEFORE INSERTING OR REMOVING CONNECTORS.
 - USING A NUMBER 707 CABLE, CONNECT THE PMP SERIAL INTERFACE CONNECTOR TO THE TF-20 TOP (6- PIN) SERIAL INTERFACE CONNECTOR LOCATED ON REAR OF TF-20.
 - PMP CAN NOW BE CONNECTED TO OMNI SBCS PORT WITH RS-232-C CONNECTOR.
2. TO OPERATE FLOPPY DISKETTE UNIT —

FIRST POWER ON TF-20 FLOPPY DISKETTE DRIVE:
 - ENSURE THAT PUSHBUTTON IS OFF.
 - INSERT FLOPPY DISKETTE INTO DISKETTE DRIVE.
 - ALWAYS TURN TF-20 POWER SWITCH ON BEFORE TURNING PMP POWER SWITCH TO ON. WHEN DISCONNECTING, TURN PMP POWER SWITCH OFF, THEN TURN TF-20 POWER SWITCH TO OFF.

Saving and Loading Office Dependent Data Base to Floppy Diskette (Continued)



GTE OMNI SBCS

PROCEDURE (CONTINUED)

TO LOAD FLOPPY DISKETTE:

- ENSURE THAT PUSHBUTTON IS OFF.
- INSERT FLOPPY DISKETTE INTO DRIVE, WITH WRITE-PROTECTION NOTCH UP (STANDARD LABEL AT RIGHT).
- PUSH FLOPPY DISKETTE IN UNTIL A CLICK IS HEARD AND EJECT LOCK LEVER POPS OUT.
- SLOWLY DEPRESS PUSHBUTTON TO TURN DRIVE ON.

TO EJECT FLOPPY DISKETTE:

- ENSURE THAT DRIVE SELECT LED IS OFF FOR DRIVE CONTAINING FLOPPY DISKETTE. IF STILL ON, INPUT CLOSE OR RESET COMMAND.
- DEPRESS PUSHBUTTON UNTIL IT POPS INTO OFF POSITION. FLOPPY DISKETTE WILL BE EJECTED 2 TO 3 CM.
- SLOWLY REMOVE FLOPPY DISKETTE FROM DRIVE.

4. TO START PMP WITH FLOPPY DISKETTE DRIVE UNIT:

- TURN TF-20 POWER SWITCH ON.
- INSERT TF-20 SYSTEM DISKETTE (EPSON TF-20 DISK BASIC) INTO DRIVE A SLOT OF TF-20. ENSURE THAT DRIVE SELECT LED BLINKS TO INDICATE THAT DISK OPERATING SYSTEM (DOS) IS STARTING.
- TURN PMP POWER SWITCH ON. ENSURE THAT DRIVE SELECT LED BLINKS AGAIN, TO INDICATE THAT DISKETTE BASIC HAS BEEN BOOTED ON THE PMP.
- PORT CONFIGURATION PROMPT SCREEN WILL BE DISPLAYED ON SCREEN:

PORT CONFIGURATION
CHANGE?

YES OR NO (Y/N)

Saving and Loading Office Dependent Data Base to Floppy Diskette (Continued)



GTE OMNI SBCS

PROCEDURE (CONTINUED)

5. TO INITIALIZE NEW FLOPPY DISKETTE FOR BACKUP:
 - WHEN PORT CONFIGURATION SCREEN IS DISPLAYED, PRESS PMP's BREAK KEY. ENTER: 2 TO SELECT BASIC MODE.
 - INSERT FLOPPY DISKETTE TO BE INITIALIZED IN DRIVE A OF TF-20 UNIT.
 - USING PMP, ENTER: **FORMAT "A"**. **PRESS RETURN**. SCREEN WILL PROMPT, "ARE YOU SURE?"
 - **PRESS RETURN** TO FORMAT DISKETTE

6. TO SAVE OFFICE DEPENDENT DATA BASE TO FLOPPY DISKETTE:
 - PUT PMP INTO COMMAND MODE.
 - ENTER CMC-903 (SVR 1.5.X.X) OR CMC 703 (SVR 1.0.2.2)
 - AT PARAMETER 1, ENTER: **SAVE AND PRESS ADD/CHANGE** PROGRAM FUNCTION KEY
 - INSERT FLOPPY DISKETTE FOR BACKUP INTO DRIVE B OF TF-20 UNIT. ALSO ENSURE THAT A BLANK FLOPPY DISKETTE IS IN DRIVE A.
 - **PRESS PF9 (SHIFT + PF4)** PROGRAM FUNCTION KEY.

7. TO LOAD OFFICE DEPENDENT DATA BASE FROM FLOPPY DISKETTE:
 - PUT PMP INTO COMMAND MODE.
 - ENTER CMC-902 (SVR 1.5.X.X.) OR CMC-702 (SVR 1.0.2.2).
 - AT PARAMETER 1, ENTER: **LOAD AND PRESS ADD/CHANGE** PROGRAM FUNCTION KEY.
 - INSERT FLOPPY DISKETTE WITH BACKUP OF DATA BASE INTO DRIVE B OF TF-20 UNIT. ALSO ENSURE THAT A BLANK FLOPPY DISKETTE IS IN DRIVE A.
 - **PRESS PF9 (SHIFT + PF4)** PROGRAM FUNCTION KEY.
 - ENSURE THAT CORRECT SAVE DATE AND FILE VERSION ARE DISPLAYED ON SCREEN. **PRESS PF 9 (SHIFT + PF4)** PROGRAM FUNCTION KEY.

Laboratory Activity — Saving and Loading the Office Dependent Data Base



GTE OMNI SBCS

PERFORM THE FOLLOWING DATA BASE TASKS IN THE SEQUENCE OUTLINED BELOW USING THE SAMPLE WORK ORDERS AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO SAVING AND LOADING THE ODDB UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #2.12	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER 2.12 (TASK #1)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> • Save Office Dependent Data Base (programmed during previous data base lab activities) to microcassette tape with CMC-903. 	
PARAMETERS:	INSTRUCTIONS:
<ol style="list-style-type: none"> (1) Save ODDB to tape from system main memory using PMP tape drive. Follow instructions outlined in Student Workbook for operation of CMC-903. (2) Label tape with contents and date that back-up tape was created. 	<ol style="list-style-type: none"> (1) Ensure that blank microcassette tape is 60 minutes in length. (2) Proceed to the next work order task.

LAB MILESTONE:
<ul style="list-style-type: none"> • ASK INSTRUCTOR TO INSPECT TAPE BACK-UP PROCEDURE AND INITIAL YOUR PERFORMANCE CHECKLIST. • PROCEED TO THE NEXT WORK ORDER TASK.

Laboratory Activity — Saving and Loading the Office Dependent Data Base (Continued)



GTE OMNI SBCS

WORK ORDER #2.12	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER 2.12 (TASK #2)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Load Office Dependent Data Base (programmed during previous data base lab activities) from microcassette tape with CMC-902. 	
PARAMETERS: <ol style="list-style-type: none"> (1) LOAD ODDB from tape to system main memory using PMP tape drive. Use tape created during previous work order task. Follow instructions outlined in Student Workbook for operation of CMC-902. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Since all call processing stops during loading process, remember to check call status with BLF/DSS before proceeding with CMC-902, when performing an actual load at a customer site. (2) Proceed to the next work order task.

LAB MILESTONE: <ul style="list-style-type: none"> • ASK INSTRUCTOR TO INSPECT TAPE LOADING PROCEDURE AND INITIAL YOUR PERFORMANCE CHECKLIST. • PROCEED TO THE NEXT WORK ORDER TASK.
--

Laboratory Activity – Saving and Loading the Office Dependent Data Base (Continued)



GTE OMNI SBCS

WORK ORDER #2.12	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #2.12 (TASK #3)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u>	
<ul style="list-style-type: none"> • Save Office Dependent Data Base (programmed during previous data base lab activities) to floppy diskette with CMC-903. 	
<u>PARAMETERS:</u>	<u>INSTRUCTIONS:</u>
<ol style="list-style-type: none"> (1) Save ODDB to floppy diskette from system main memory using EPSON TF-20 floppy diskette drive in conjunction with PMP. Follow instructions outlined in Student Workbook for operation of CMC-903 using floppy diskette. (2) Label diskette with contents and date that back-up diskette was created. 	<ol style="list-style-type: none"> (1) Verify that TF-20 diskette drive and expansion RAM are correctly installed and connected to PMP. (2) Initialize new floppy diskette before proceeding with back-up. (3) Proceed to the next work order task.

LAB MILESTONE:
<ul style="list-style-type: none"> • ASK INSTRUCTOR TO INSPECT THE FLOPPY DISKETTE BACK-UP PROCEDURE AND INITIAL YOUR PERFORMANCE CHECKLIST. • PROCEED TO THE NEXT WORK ORDER TASK.

Laboratory Activity — Saving and Loading the Office Dependent Data Base (Continued)



GTE OMNI SBCS

WORK ORDER #2.12	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #2.12 (TASK #4)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Load Office Dependent Data Base (programmed during previous data base lab activities) from floppy diskette with CMC-902. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Load ODDB from floppy diskette to system main memory using EPSON TF-20 floppy diskette drive in conjunction with PMP. Use ODDB back-up diskette created during Work Order 2.13 (Task 3). Follow instructions outlined in Student Workbook for operation of CMC-902. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Verify that TF-20 diskette drive and expansion RAM are correctly installed and connected to PMP. (2) Complete review exercise questions 1-15.

LAB MILESTONE
<ul style="list-style-type: none"> • Ask instructor to inspect the floppy diskette loading procedure and initial your performance checklist. • Make certain questions 1-15 of review exercise 2.12 have been completed before submitting to the instructor for grading.

Review Exercise — Saving and Loading the Office Dependent Data Base (2.12)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. WHAT FACTORS AFFECT THE LENGTH OF TIME REQUIRED TO SAVE THE ODDB TO TAPE?

2. MICROCASSETTE TAPES USED FOR BACK-UPS MUST BE AT LEAST ____ MINUTES IN LENGTH.

3. SAVING THE ODDB WITH CMC-903 CANNOT BE PERFORMED USING THE _____ PROGRAMMING INSTRUMENT.

4. IF THE TAPE ENDS BEFORE THE SAVE PROCESS IS COMPLETED, THE PMP SCREEN WILL DISPLAY:

5. WHAT OCCURS IF THE PF1 KEY (RELEASE) IS ACCIDENTALLY PRESSED DURING THE SAVE OPERATION?

6. ALL _____ STOPS DURING THE ODDB LOADING PROCESS.

7. WHAT IS INDICATED IF A "NO TRANSMISSION" MESSAGE IS RECEIVED ON THE PMP SCREEN FOLLOWING THE LOADING OF THE ODDB? _____

Review Exercise — Saving and Loading the Office Dependent Data Base (2.12) (Continued)



GTE OMNI SBCS

8. THE SYSTEM AUTOMATICALLY INITIATES A _____ FOLLOWING THE LOADING OF THE ODDB TAPE.

9. IF THE ODDB TAPE VOLUME SERIAL NUMBER IS NOT CORRECT, THE PMP SCREEN WILL DISPLAY:

10. WHAT IS INDICATED IF THE MESSAGE "BAD TAPE/SF VER.XXX" IS DISPLAYED ON THE PMP SCREEN?

11. WHAT ADDITIONAL EQUIPMENT IS REQUIRED TO SAVE AND LOAD THE ODDB USING A FLOPPY DISKETTE?

12. WHAT PROCEDURE MUST BE PERFORMED BEFORE A NEW FLOPPY DISKETTE MAY BE USED?

13. THE OMNI SBCS REQUIRES _____ FLOPPY DISKETTES TO STORE A COMPLETE ODDB.

14. (TRUE OR FALSE): _____ SAVING AND LOADING THE ODDB WITH THE DISKETTE DRIVE (WHEN USING SVR 1.5.X.X) REQUIRES DIFFERENT CMC COMMANDS THAN THE TAPE BACK-UPS.

Review Exercise — Saving and Loading the Office Dependent Data Base (2.12) (Continued)



GTE OMNI SBCS

15. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT DEFINITION:

- _____ CMC-902 A. LOAD ODDB TO SYSTEM MEMORY FROM TAPE OR FLOPPY DISKETTE.
- _____ CMC-903 B. SAVE ODDB FROM SYSTEM MEMORY TO TAPE OR FLOPPY DISKETTE.



GTE OMNI SBCS

DATA BASE ADMINISTRATION Implementation Forms

2.13 Enabling Objective



GTE OMNI SBCS

- GIVEN**
- GTE OMNI SBCS
 - GTE OMNI SBCS PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITY — COMPLETING AND USING OMNI SBCS IMPLEMENTATION FORMS PACKAGE
 - REVIEW EXERCISE
- ACTION:**
- INTERPRET AND USE OMNI SBCS IMPLEMENTATION FORMS PACKAGE AS ESSENTIAL TOOL FOR SYSTEM CONFIGURATION AND DATA BASE ADMINISTRATION.
 - COMPLETE REVIEW EXERCISE
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Laboratory Activity – Implementation Package



GTE OMNI SBCS

PERFORM THE PROGRAMMING TASKS DESIGNATED BY THE COMPLETED SAMPLE IMPLEMENTATION FORMS ATTACHED TO THE WORK ORDER BELOW. COMPLETE THE REVIEW EXERCISE QUESTIONS PERTAINING TO THE IMPLEMENTATION FORMS PACKAGE UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER # 2.13	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 2.13
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Reestablish the default standard data base with COLD Restart. • Perform all data base modification required for tables and parameters outlined in the Implementation Forms Package. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Complete Implementation Forms Package following instructor's directions. (2) Program all required data base changes using completed Implementation Forms Package. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Check/test the operation of changes after completion of this portion of the laboratory activity. (2) Complete review exercise questions 1-9.

LAB MILESTONE:
<ul style="list-style-type: none"> • VERIFY THAT ALL PROGRAMMING CHANGES REQUESTED ON IMPLEMENTATION FORMS HAVE BEEN PERFORMED CORECTLY. • ASK INSTRUCTOR TO INSPECT DATA BASE MODIFICATIONS AND INITIAL YOUR PERFORMANCE CHECKLIST. • MAKE CERTAIN ALL QUESTIONS OF REVIEW EXERCISE 2.13 HAVE BEEN COMPLETED BEFORE SUBMITTING THE REVIEW EXERCISE TO THE INSTRUCTOR FOR GRADING. • YOU HAVE NOW COMPLETED THE DATA BASE ADMINISTRATION MODULE.

Review Exercise – Implementation Forms Package (2.13)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE IMPLEMENTATION FORMS PACKAGE PROVIDES: _____ .
 - A. INFORMATION USED TO DETERMINE HARDWARE AND SOFTWARE FAULTS.
 - B. A PERMANENT RECORD OF PROGRAMMING REQUIRED FOR CUSTOMER DATA BASE SPECIFICATIONS AT TIME OF INSTALLATION.
 - C. A DESCRIPTION OF THE DEFAULT STANDARD DATA BASE
 - D. A RECORD OF ALL PROGRAMMING CHANGES MADE AFTER LATER SVR UPGRADES.
 2. THE _____ AND _____ IMPLEMENTATION FORMS ARE USED PRIMARILY TO PROVIDE GENERAL SYSTEM INFORMATION RATHER THAN USED AS PROGRAMMING TOOLS.
 3. SYSTEM/STATION DIALING PATTERNS ARE PROGRAMMED USING THE _____ IMPLEMENTATION FORM(S).
 4. A CUSTOMER WISHING TO DEFINE CLASS OF RESTRICTION FOR RESTRICTION GROUPS WOULD COMPLETE THE _____ IMPLEMENTATION FORM(S).
 5. WHAT GTEP TABLE IS USED TO IDENTIFY TRUNK GROUP NUMBERS WHEN PROGRAMMING TRUNK ASSIGNMENTS?
-

Review Exercise — Implementation Forms Package (2.13) (Continued)



GTE OMNI SBSCS

6. THE _____ IMPLEMENTATION FORM IS USED WHEN PROGRAMMING COMMON CARRIER ACCESS CODES FOR LEAST COST ROUTING IN AREAS WITH EQUAL ACCESS.

7. WHAT CMC COMMAND AND PARAMETER SETTINGS ARE REQUIRED WHEN PROGRAMMING THE AUTOMATIC INTERCOM FEATURE USING THE BLF/DSS FEATURE ASSIGNMENT FORM?

8. NAME TWO TYPES OF INFORMATION REQUIRED FOR STATION INSTALLATION ON THE SINGLE LINE STATION DETAIL FORM THAT ARE NOT RELATED TO DATA BASE PROGRAMMING.

9. MATCH THE FOLLOWING IMPLEMENTATION FORMS WITH THE TYPE OF INFORMATION INCLUDED ON EACH:

_____ MULTI-DIGIT/TOLL
RESTRICTION FORM

_____ EKT FEATURE BUTTON
ASSIGNMENT FORM

_____ SYSTEM SPEED CALL
FORM

_____ STATION HUNTING
GROUPS FORM

_____ SYSTEM OVERVIEW
FORM

A. A MAXIMUM OF 100 PHONE NUMBERS PROGRAMMED FOR SYSTEM USE.

B. NO/1X AREA/OFFICE ASSIGNMENT TABLES

C. IDENTIFIES TYPE OF SBSC DEVICE USED TO PROGRAM THE SYSTEM

D. BUTTON ASSIGNMENTS

E. PILOT STATION ASSIGNMENT



GTE OMNI SBCS

MODULE III

SYSTEM MAINTENANCE

Table of Contents



GTE OMNI SBCS

	Page
MAINTENANCE OVERVIEW	
• MAINTENANCE OVERVIEW (OBJECTIVES)	3.3
• MAJOR MAINTENANCE FUNCTIONS	3.4
• MAINTENANCE TOOLS	3.6
• REMOTE MAINTENANCE	3.7
• PREVENTIVE MAINTENANCE	3.8
• VISUAL INDICATORS OF SYSTEM STATUS	3.9
• CPM LED LAMPS	3.10
• REMOTE ALARM STATES	3.11
• INSTRUMENT ALARM BUTTON	3.12
• VISUAL ALARMS SCHEMATIC	3.13
• REVIEW EXERCISE (3.1)	3.14
MAINTENANCE DATA BASE COMMANDS	
• MAINTENANCE DATA BASE COMMANDS (OBJECTIVES)	3.17
• CLOCK, DAY AND DATE	3.18
• CIRCUIT BUSY ASSIGNMENT	3.19
• SOFTWARE AND DISTRIBUTED PROCESSOR VERSION NUMBER DISPLAYS	3.21
• DEVICE STATUS DISPLAY	3.23
• FAULT LOG DISPLAY	3.25
• FAULT CODE TRANSLATION	3.27
• SMDR PRINTER CONTROLS	3.29
• RS-232-C PORT CONFIGURATION ASSIGNMENT	3.30
• DIAGNOSTIC TRUNK CONNECTION ASSIGNMENT	3.31
• TRAFFIC MEASUREMENT	3.32
• CMC COMMAND SUMMARY	3.33
• LABORATORY ACTIVITY (3.2)	3.36
• REVIEW EXERCISE (3.2)	3.40



Table of Contents (Continued)

GTE OMNI SBCS

Page

TROUBLESHOOTING

● TROUBLESHOOTING (OBJECTIVES)	3.45
● TROUBLESHOOTING OVERVIEW	3.46
● SYSTEM-WIDE PROBLEMS	3.47
● MULTIPLE CARD/INTERFACE SIGNAL PROBLEMS	3.51
● SINGLE ICG CARD PROBLEMS	3.53
● SINGLE STATION OR TRUNK PROBLEMS	3.55
● RINGING PROBLEMS	3.57
● DTMF SINGLE LINE TELEPHONE PROBLEMS	3.61
● SWC AND CPM CARD PROBLEMS	3.62
● PRINTED CIRCUIT BOARD CARD REPLACEMENT	3.63
● LABORATORY ACTIVITY/REVIEW EXERCISE (3.3)	3.64

DIAGNOSTICS

● DIAGNOSTICS (OBJECTIVES)	3.77
● DIAGNOSTICS/OVERVIEW	3.78
● SYSTEM SELF-DIAGNOSTICS	3.79
● CALL PROCESSING DIAGNOSTICS	3.80
● MANUAL TRUNK CONNECTION DIAGNOSTICS	3.83
● LAMP STATUS FAULT ISOLATION	3.85
● EKT AND BLF/DSS INSTRUMENT DIAGNOSTICS	3.87
● EKT AND BLF/DSS TEST EXECUTION	3.88
● LABORATORY ACTIVITY (3.4)	3.90
● REVIEW EXERCISE (3.4)	3.91

3.0 Terminal Objective



GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS PERIPHERALS
 - STANDARD MAINTENANCE TOOLS
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - LABORATORY ACTIVITIES
 - WRITTEN TEST
- ACTION:**
- ISOLATE AND IDENTIFY ROUTINE SYSTEM HARDWARE FAULTS.
 - PERFORM ROUTINE DIAGNOSTICS ON SYSTEM AND PERIPHERAL DEVICES.
 - COMPLETE AND PASS WRITTEN TEST.
- CRITERIA:**
- TROUBLESHOOTING AND DIAGNOSTIC PROCEDURES WILL BE COMPLETED IN ACCORDANCE WITH SBCS GTEP MANUAL.
 - TEST WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



GTE OMNI SBCS

SYSTEM MAINTENANCE

Overview



3.1 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBCS PERIPHERALS
- STANDARD MAINTENANCE TOOLS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- REVIEW EXERCISE

ACTION:

- IDENTIFY SBCS MAINTENANCE TOOLS AND FUNCTIONS.
- DESCRIBE PREVENTIVE MAINTENANCE PROCEDURES FOR CABINET AND PERIPHERALS.
- DETERMINE SYSTEM STATUS THROUGH USE OF VISUAL INDICATORS SUCH AS CPM CONTROLS AND ALARMS.


CRITERIA:

- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

System Maintenance/Overview

GTE OMNI SBCS

OMNI SBCS EMPLOYS SIX TYPE OF MAINTENANCE FUNCTIONS:



Major Maintenance Functions



GTE OMNI SBCS

- PREVENTIVE MAINTENANCE
 - CABINET AND PERIPHERALS
 - PCB CARD INSTALLATION
 - BATTERY
 - PMP
- TROUBLESHOOTING
 - SYSTEM OPERATION CHECKS
 - VISUAL INDICATORS
 - DEVICE STATUS AND FAULT LOG THROUGH LOCAL OR REMOTE ACCESS
 - INSTRUMENT DIAGNOSTICS
 - FAULT ISOLATION
 - DEFECTIVE CARD REPLACEMENT
- DIAGNOSTICS
 - DIAGNOSTIC ALARMS/FAULTS
 - SYSTEM SELF-DIAGNOSTICS
 - CALL PROCESSING DIAGNOSTICS
 - TRUNK CONNECTION DIAGNOSTICS
 - INSTRUMENT DIAGNOSTICS
- SUPPORT
 - RS-232-C PORT ASSIGNMENT
 - SOFTWARE AND DISTRIBUTED PROCESSOR VERSION ID DISPLAYS
- ROUTINE MAINTENANCE
 - SYSTEM SECURITY CODES
 - SMDR PRINTER CONTROL
 - TIME AND DATE
 - CIRCUIT IN/OUT OF SERVICE
- TRAFFIC MANAGEMENT
 - TRUNK GROUP SCREENING


Maintenance Tools



GTE OMNI SBCS


- THE FOLLOWING DATA BASE TOOLS ARE REQUIRED, IN ADDITION TO TOOLS NORMALLY CARRIED BY A FIELD TECHNICIAN:

PORTABLE MAINTENANCE PANEL (PMP)



OR

MASTER CONTROL TELEPHONE (MCT)




- BOTH DEVICES ALLOW ACCESS TO ROUTINE CMC MAINTENANCE AND DIAGNOSTIC COMMAND TABLES, HOWEVER, CHANGES WHICH MUST BE STORED TO ODDB TAPE OR FLOPPY DISKETTE CAN ONLY BE PERFORMED WITH PMP.

Remote Maintenance



GTE OMNI SBCS



REMOTE PMP ACCESS TO OMNI SBCS

- (1) ENSURE COMPATIBILITY OF AUTO ANSWER MODEM AT OMNI SBCS SITE AND MODEM AT REMOTE SITE AND THAT RS-232-C CONFIGURATIONS FOR FOLLOWING PORTS MATCH:
 - OMNI SBCS PORT CN13, I/O 0 (SET WITH CMC-900)
 - LOCAL MODEM AT OMNI SBCS SITE REQUIRES AUTO ANSWER WITH LOSS OF CARRIER DISCONNECT, ASYNCHRONOUS, AND FULL DUPLEX CAPABILITIES
 - REMOTE MODEM (AT&T DATA SET IS RECOMMENDED)
 - PMP AT REMOTE SITE
- (2) CONNECT MODULAR PHONE WIRE FROM LOCAL MODEM TO SLT JACK THAT HAS BEEN PROGRAMMED AS A DATA SECURE, DIRECT IN-LINE STATION FOR DATA BASE MAINTENANCE.
- (3) CONNECT THE RS-232-C CABLE FROM LOCAL MODEM TO PORT CN13, I/O 0 OF THE OMNI SBCS.
- (4) POWER ON OMNI SBCS (IF NOT ALREADY POWERED) AND LOCAL MODEM.
- (5) CONNECT PMP TO RS-232-C PORT ON REMOTE DATA SET MODEM.
- (6) POWER ON PMP AT REMOTE SITE (WHICH MUST BE INITIALIZED WITH PMP CONTROL PROGRAM) AND SELECT PMP CONTROL PROGRAM.
- (7) WHEN PORT CONFIGURATION PROMPT IS DISPLAYED ON THE PMP SCREEN, ENTER: Y TO REVIEW PORT CONFIGURATION MENU AND SETTINGS.
- (8) LIFT REMOTE DATA SET MODEM HANDSET AND PRESS TALK KEY.
- (9) USING REMOTE DATA SET MODEM, DIAL DIRECTORY NUMBER OF LOCAL AUTO ANSWER MODEM CONNECTED TO OMNI SBCS.
- (10) WHEN CONFIGURATION ANSWER TONE IS HEARD, QUICKLY PRESS DATA KEY ON THE REMOTE DATA SET MODEM AND REPLACE HANDSET ON THE HOOK.
- (11) PRESS RETURN KEY ON THE PMP TO EXIT FROM PORT CONFIGURATION SCREEN. WHEN PORT CONFIGURATION PROMPT IS DISPLAYED, ENTER: N.
- (12) WHEN SECURITY CODE PROMPT SCREEN IS DISPLAYED, ENTER CORRECT SECURITY ACCESS CODE.
- (13) COMPLETE DATA BASE TASKS BY ENTERING DESIRED CMC COMMANDS AND PARAMETERS ACCORDING TO PROCEDURES OUTLINED IN PROGRAMMING SECTIONS OF THIS WORKBOOK OR OMNI SBCS GTEP MANUAL.
- (14) WHEN DATA BASE TASKS HAVE BEEN COMPLETED, PRESS DATA KEY ON REMOTE DATA SET MODEM TO DISCONNECT. POWER OFF PMP AND REMOTE DATA SET MODEM.



Preventive Maintenance

GTE OMNI SBCS

- CHECK VISUAL INDICATORS AND DEVICE STATUS TABLE (CMC-800) REGULARLY TO DETERMINE SYSTEM OPERATING STATUS.
- DO NOT OBSTRUCT AIR FLOW AT TOP OF SYSTEM CABINET OR POWER SUPPLY. KEEP FOREIGN PARTICLES AND LIQUIDS FROM ENTERING VENTILATION HOLES.
- KEEP ALL GROUNDING, POWER, AND INTERFACE CABLES DRESSED AND FREE FOR EASY ACCESS.
- CLEAN HEADS ON PMP MICROCASSETTE TAPE DRIVE WITH DENATURED ALCOHOL PRIOR TO LOADING OR SAVING OPERATIONS. I/O DEVICE ERROR CAN BE CAUSED BY DIRTY TAPE HEADS.
- AVOID STATIC ELECTRICITY DISCHARGES WHILE HANDLING PCB CARDS. MICROPROCESSORS, PROM, RAM, AND OTHER MICROCIRCUITS CAN BE DAMAGED IF FOLLOWING PROCEDURES ARE NOT IMPLEMENTED:
 - GROUND YOURSELF TO CABINET WITH ANTI-STATIC WRIST STRAP DEVICE BEFORE INSERTING OR REMOVING CARDS.
 - SPRAY SYSTEM CABINET AREA AND CARD STORAGE SURFACES WITH ANTI-STATIC SPRAY.
 - NEVER TOUCH GOLD-PLATED CONNECTORS OR COMPONENTS.
 - USE EJECTOR TABS WHEN REMOVING CARDS FROM SLOTS AND HANDLE CARDS BY EDGES ONLY.
 - ELIMINATE STATIC PRODUCING MATERIALS (CELLOPHONE, STYROFOAM, ETC.) FROM CABINET AREA.
 - STORE UNUSED CARDS IN ANTI-STATIC BAGS.
 - TURN POWER OFF WHEN INSTALLING COMMON CONTROL OR RGEN CARDS.
- IF BACKUP BATTERY CANNOT BE RECHARGED OR REPLACED IMMEDIATELY, SAVE ODDB TO TAPE OR FLOPPY DISKETTE.

Visual Indicators of System Status



GTE OMNI SBCS

- **THREE LED LAMPS ON CPM CARD**

- **MAJOR AND MINOR ALARMS AT REMOTE LOCATION**

- **ALARM BUTTON ON BLF/DSS OR EKT INSTRUMENTS**

CPM LED Lamps



GTE OMNI SBCS

RUN LAMP (GREEN):


- INDICATES NORMAL ON CONDITION.
- IF OUT, A MAJOR ALARM CONDITION IS INDICATED (DISPLAYED AT REMOTE LOCATION) CAUSED BY ONE OF FOLLOWING CONDITIONS:
 - POWER OUTAGE,
 - DEFECTIVE CPM OR SWC OSCILLATING CIRCUIT, OR
 - SIXTEENTH FAILURE TO RESTART SYSTEM VIA WATCH-DOG TIMER.
- 6PFT CARD AUTOMATICALLY SWITCHES ITS CIRCUITS TO POWER FAILURE TRANSFER MODE.

ALARM LAMP (RED):

- INDICATES A MINOR ALARM CONDITION (REMOTE LOCATION) BECAUSE SOFTWARE HAS DETECTED A FAILURE IN ONE OR MORE SYSTEM AREAS.
- FAULT LOG (CMC-801) LISTS MORE DETAILED INFORMATION ON CAUSES OF FAILURE.

TIME OVERFLOW (TO) LAMP (RED):

- INDICATES WATCH-DOG TIMER HAS DETECTED A FAILURE IN CPM CARD OR OPERATING PROGRAM.
- SYSTEM AUTOMATICALLY ATTEMPTS RESTART AND IF SUCCESSFUL, LOGS FAULT IN FAULT LOG.
- AFTER 16 UNSUCCESSFUL RETRIES, RUN LAMP IS TURNED OFF. TO LAMP MUST BE TURNED OFF BY COLD OR HOT RESTART, OR BY READING FAULT LOG.



Remote Alarm States



GTE OMNI SBCS

CUSTOMER PROVIDED ALARMS AT REMOTE LOCATIONS CAN INDICATE ONE OF TWO ALARM STATES:

MAJOR ALARM —

- **SYSTEM POWER IS OFF AND SYSTEM IS IN POWER FAILURE TRANSFER MODE.**

MINOR ALARM —


- **SYSTEM HAS FAILURE IN ONE OR MORE AREAS OF OPERATION.**

IF BOTH ALARMS ARE ON, THE SYSTEM HAS DETECTED A SYSTEM-WIDE PROBLEM.



Instrument Alarm Button

GTE OMNI SBCS




- PROGRAMMED ALARM BUTTON ON BLF/DSS (OR OTHER DESIGNATED EKT INSTRUMENT) INDICATES A MINOR ALARM CONDITION.
- LOCATION OF PROBLEM AND FAULT LOG LISTING CAN BE OBTAINED THROUGH USE OF PMP OR MCT WITH CMC-800 AND 801.



Visual Alarms Schematic

GTE OMNI SBCS



Review Exercise — Maintenance Overview (3.1)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORK-BOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE TOOLS REQUIRED FOR SYSTEM DATA BASE MAINTENANCE ARE _____ AND _____.
2. REMOTE MAINTENANCE USING A PORTABLE MAINTENANCE PANEL REQUIRES _____ AT BOTH THE REMOTE SITE AND AT THE OMNI SBCS SITE.
3. LIST THREE PREVENTIVE MAINTENANCE PROCEDURES RELATED TO PROPER CARE OF PCB CARDS:
 - (A) _____
 - (B) _____
 - (C) _____
4. THE THREE PRIMARY VISUAL INDICATORS OF SYSTEM STATUS ARE: _____
 - A. CPM LED LAMPS, CABLE WARNING SYSTEM, AND MAJOR AND MINOR ALARMS AT REMOTE LOCATION.
 - B. ALARM BUTTON ON SINGLE LINE TELEPHONE, MAJOR AND MINOR ALARMS AT REMOTE LOCATION, AND SYSTEM FAULT LOG.
 - C. POWER ON LAMP, CPM LED LAMPS, AND POWER FAIL TRANSFER ALARM.
 - D. CPM LED LAMPS, MAJOR AND MINOR ALARMS AT REMOTE LOCATIONS, AND ALARM BUTTON ON BLF/DSS OR EKT INSTRUMENTS.
5. HOW COULD MORE DETAILED INFORMATION BE FOUND ABOUT MINOR ALARM CONDITION OR WATCHDOG TIMER OVERFLOW? _____

Review Exercise — Maintenance Overview (3.1) (Continued)



GTE OMNI SBCS

6. WHAT MAY BE INDICATED IF THE RUN LAMP IS OFF AND A MAJOR ALARM CONDITION EXISTS?

7. HOW IS THE TIMER OVERFLOW LAMP RESET (TURNED OFF)? _____

8. THE SYSTEM WILL AUTOMATICALLY ATTEMPT TO RESTART THE SYSTEM _____ TIMES, IN THE EVENT OF A WATCHDOG TIMER OVERFLOW.

9. WHAT SYSTEM ALARM STATES CAN BE INDICATED BY A CUSTOMER-PROVIDED ALARM AT A REMOTE LOCATION?

10. WHAT CMC COMMAND IS USED TO PROGRAM AN ALARM BUTTON ON A BLF/DSS INSTRUMENT?



GTE OMNI SBCS

SYSTEM MAINTENANCE
Maintenance Data Base
Commands



3.2 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBCS PERIPHERALS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- LABORATORY ACTIVITY
- REVIEW EXERCISE

ACTION:

- IDENTIFY FUNCTIONS AND APPLICATIONS OF CMC MAINTENANCE COMMANDS.
- MODIFY PARAMETER VALUES FOR CMC MAINTENANCE COMMANDS.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Clock, Day and Date



GTE OMNI SBCS

DESCRIPTION

- SETS THE SYSTEM HARDWARE AND SOFTWARE CLOCKS.
- TIME AND DATE ARE DISPLAYED ON ALL EKT LCD DISPLAYS.
- CLOCK MUST BE RESET FOLLOWING COLD RESTART.

PROCEDURE

1. USE CMC-700 TO SET CURRENT CLOCK AND DATE PARAMETERS*:

- YEAR (P1)
- MONTH AND DAY (P2)
- DAY OF THE WEEK (P3)
- HOUR AND MINUTE (P4)

CMC=700
P1: 1986 P4: 0936
P2: 0207
P3: 6

*SYSTEM WILL NOT ACCEPT ERRONEOUS VALUES SUCH AS DAY 43.

NOTE: HARD ERR ERROR MESSAGE INDICATES THAT CPM CARD MAY NEED REPLACEMENT.



Circuit Busy Assignment

GTE OMNI SBCS

DESCRIPTION

- **ALLOWS CIRCUITS FOR TRUNKS AND INSTRUMENTS TO BE PUT OUT OF SERVICE (MADE BUSY) WHILE MAINTENANCE PROCEDURES ARE BEING PERFORMED.**
- **SAME COMMAND IS USED TO RESTORE SERVICE TO CIRCUIT.**

PROCEDURE

1. **USE CMC-701 TO BUSY OUT A CIRCUIT OR RETURN CIRCUIT TO SERVICE.**
 - **EQUIPMENT NUMBER (P1)**
 - **MAKE BUSY OR PUT IN SERVICE FLAG (P2)**

CMC=701
P1: 162
P2: 1

***SYSTEM WILL DENY ANY ATTEMPT TO MAKE THE MASTER CONTROL TELEPHONE'S CIRCUIT BUSY.**

NOTE: SMDR PRINTER CIRCUIT IS MADE BUSY WITH CMC-705.

Software and Distributed Processor Version Number Displays



GTE OMNI SBCS


DESCRIPTION

- CMC-904 WILL DISPLAY CURRENT SYSTEM SOFTWARE VERSION NUMBER INDICATING:
 - FEATURE PACKAGE BY ALPHABETIC CHARACTER
 - SAVE/LOAD OPERATION CAPABILITY
 - RELEASE VERSION WITH ENHANCEMENTS AFFECTING DOCUMENTATION, TECHNICAL OR SALES TRAINING.
 - POINT RELEASE VERSION WITH ENHANCEMENTS NOT AFFECTING USER OPERATION
- CMC-907 WILL DISPLAY CURRENT DISTRIBUTED PROCESSOR VERSION NUMBER FOR ANY CARD IN INTERFACE CARD GROUP.

PROCEDURE

1. USE CMC-904 TO OBTAIN CURRENT SOFTWARE VERSION NUMBER. ENTER **DISPLAY** AT P1.

- VERSION ID (P1):



CMC=904
P1: BOI 1.2 17130

Software and Distributed Processor Version Number Displays (Continued)



GTE OMNI SBCS

2. USE CMC-907 TO OBTAIN CURRENT VERSION NUMBER FOR INTERFACE CARD. ENTER **DISPLAY** AT P1:

- EQUIPMENT NUMBER (P1)
- CARD TYPE (P2)

1: 8SLC


2: 4BWC

3: 2TTE

4: 2TTL

5: 4DMR

- VERSION NUMBER (P3)



NOTE: WHEN THE CARD FOR SPECIFIED EQUIPMENT NUMBER IS NOT INSTALLED OR IS AN 8EKC OR 8DTC CARD, THE CARD TYPE AND VERSION NUMBER CORRESPONDING TO THE NEXT INSTALLED CARD (EXCEPT FOR 8EKC OR 8DTC) ARE DISPLAYED.

Device Status Display



GTE OMNI SBCS

DESCRIPTION

- CMC-800 DISPLAYS A SERIES OF THREE SCREENS BRIEFLY LISTING FAULTY DEVICES AND LOCATIONS. MORE DETAILED INFORMATION ABOUT THESE FAULTS CAN BE OBTAINED WITH CMC-801.
- FOLLOWING ABBREVIATIONS FOR FAULTY DEVICES MAY BE LISTED:

DEVICE ABBREVIATION	DEVICE NAME
CC	CPM CARD OR MEM CARD
RAM	RAM ON CPM CARD OR MEM CARD
RTS	REAL TIME SOURCE ON CPM CARD
BAT	BATTERY
SWC	SWC CARD
ICG	TRUNK/LINE CARD
TRM	ELECTRONIC KEY TELEPHONE INSTRUMENT
SCI	RS-232-C PORT
RG	RGEN CARD

- THREE DEVICE STATUS SCREENS MAY BE DISPLAYED IN SEQUENCE:
SCREEN ONE — HIGH LEVEL FAULT SUMMARY
SCREEN TWO — LINE/TRUNK CARD AND RS-232-C PORT STATUS
SCREEN THREE — EKT STATUS
- EACH FAULTY DEVICE IS DISPLAYED IN A FIXED POSITION ON THE SCREEN:

P1:	CC	RAM	RTS	BAT
P2:	SWC	ICG	TRM	SCI
P3:	RG			



Device Status Display (Continued)

GTE OMNI SBCS

PROCEDURE

1. ENTER CMC-800. AT P1, PRESS **DISPLAY** TO DISPLAY SCREEN ONE.
2. AT P1, PRESS **DISPLAY** TO DISPLAY SCREEN TWO*:
3. AT P1, PRESS **DISPLAY** TO DISPLAY AT SCREEN THREE*:
4. IF NO OTHER INFORMATION IS AVAILABLE, SCREENS ARE SKIPPED AND END IS DISPLAYED).

CMC=800 DSP
P1:
P2: ICG TRM
P3:

CMC=800 DSP
P1: ICG&SCI STATUS
P2: 0000000000
P3: 000000100 00

CMC=800 DSP
P1: FAULT TERMINAL
P2: 004 032
P3:

*PARAMETER VALUES ARE DESCRIBED IN OMNI SBCS GTEP MANUAL, (MAINTENANCE SECTION, CMC-800).

Fault Log Display



GTE OMNI SBCS

DESCRIPTION

- PROVIDES DETAILED FAULT INFORMATION FOR TROUBLE-SHOOTING INCLUDING:
 - DEVICE NAME AND EQUIPMENT NUMBER
 - TIME OF FAULT OCCURRENCE OR REPAIR
 - CAUSED FACTOR AND SUPPLEMENTARY FAULT DATA
- READING OUT FAULT LOG TURNS THE ALARM AND TIMER OVERFLOW LAMPS OFF AND INITIALIZES THE WATCH DOG TIMER RESTART COUNTER TO ZERO.
- FAULT INFORMATION IS DISPLAYED IN HISTORICAL ORDER OF OCCURRENCE WITH MOST RECENT FAULT DISPLAYED LAST.
- MAXIMUM OF 16 FAULTS IS STORED. WHEN NUMBER OF FAULTS EXCEEDS CAPACITY, OLDEST FAULT IS DELETED AND MOST RECENT FAULT IS ADDED TO THE LOG.
- MAKING A HARDCOPY PRINTOUT OF EACH FAULT LISTING IS RECOMMENDED.

Fault Log Display (Continued)



GTE OMNI SBCS

PROCEDURE

1. ENTER CMC-801. AT P1 PRESS **DISPLAY** TO DISPLAY OLDEST FAULT LISTING IN LOG:
2. CONTINUED TO PRESS **DISPLAY** AT P1 UNTIL ALL FAULTS LISTED IN LOG HAVE BEEN DISPLAYED:
3. AFTER ALL FAULTS HAVE BEEN LISTED FROM LOG, END IS DISPLAYED:

CMC=801 DSP
P1: TRM P4: 026
P2: 11: 22 02/28
P3: 0

CMC=801 DSP
P1: TRM P4: 005
P2: 12:16 02/03
P3: 1

CMC= END



Fault Code Translation

GTE OMNI SBCS

CMC-801:

<u>DEVICE NAME</u>	<u>DEVICE OR EQUIPMENT NUMBER (P4)</u>	<u>CAUSED FACTOR (P3)</u>	<u>FAULT DATA (P4) (SEE NEXT PAGE)</u>
CC (CPM CARD OR MEM CARD)	200 OR 210	0 = COLD RESTART 1 = WATCH DOG TIMER OVER-FLOW 2 = SOFTWARE MAZE 3 = RAM DATA PROBLEM 4 = ILLEGAL INTERRUPTION 5 = MANUAL HOT RESTART	
RAM RAM ON CPM OR MEM CARD		0 = TURN ALM LAMP OFF 1 = RAM MEMORY STACK	1,2) SEGMENT ADDRESS 3,4) OFFSET ADDRESS 5) 6,7) STACK DATA
		2 = RAM PROTECTION	1,2) SEGMENT ADDRESS 3,4) OFFSET ADDRESS 5, 6) READ DATA 7) WRITE DATA
RTS REAL TIME SOURCE ON CPM CARD	200 2 = ILLEGAL TIME	0 = RECOVERY 1 = STOP INCREMENTING 2 = ILLEGAL TIME	
BAT BATTERY		0 = RECOVERY 1 = DISCHARGE	
SWC SWC CARD	190	0 = TURN ALM LAMP OFF 1 = CLOCK FAILED 2 = CM MEMORY STACK	
		3 = RSM MEMORY STACK	1,2) READ AFTER WRITE DATA 5,6) CM ADDRESS 1) READ AFTER WRITE DATA 5,6) RSM ADDRESS
		4 = SSM MEMORY STACK	1) READ AFTER WRITE DATA 5,6) SSM ADDRESS
ICG TRUNK/LINE CARD	FIRST EN ON CARD	0 = RECOVERY 1 = DATA TRANSMISSION ERROR 2 = ICG AUDIT ERROR	
TRM PROPRIETARY TELEPHONE	EN OF EKT OR DSS	0 = RECOVERY 1 = DATA TRANSMISSION ERROR 2 = EKT AUDIT ERROR	
SCI RS-232-C PORT	PORT NO. 000/001	0 = RECOVERY 1 = DATA TRANSMISSION ERROR 2 = SEND DATA TIME OUT	
RG RGEN CARD	1 = RGEN FAULT	0 = RECOVERY 1 = RGEN FAULT	



Fault Log Display (Continued)

GTE OMNI SBCS

PROCEDURE

1. ENTER CMC-801. AT P1 PRESS **DISPLAY** TO DISPLAY OLDEST FAULT LISTING IN LOG:
2. CONTINUED TO PRESS **DISPLAY** AT P1 UNTIL ALL FAULTS LISTED IN LOG HAVE BEEN DISPLAYED:
3. AFTER ALL FAULTS HAVE BEEN LISTED FROM LOG, END IS DISPLAYED:

CMC=801 DSP
P1: TRM P4: 026
P2: 11: 22 02/28
P3: 0

CMC=801 DSP
P1: TRM P4: 005
P2: 12:16 02/03
P3: 1

CMC= END



Fault Code Translation

GTE OMNI SBCS

CMC-801:

<u>DEVICE NAME</u>	<u>DEVICE OR EQUIPMENT NUMBER (P4)</u>	<u>CAUSED FACTOR (P3)</u>	<u>FAULT DATA (P4) (SEE NEXT PAGE)</u>
CC (CPM CARD OR MEM CARD)	200 OR 210	0 = COLD RESTART 1 = WATCH DOG TIMER OVER-FLOW 2 = SOFTWARE MAZE 3 = RAM DATA PROBLEM 4 = ILLEGAL INTERRUPTION 5 = MANUAL HOT RESTART	
RAM RAM ON CPM OR MEM CARD		0 = TURN ALM LAMP OFF 1 = RAM MEMORY STACK	1,2) SEGMENT ADDRESS 3,4) OFFSET ADDRESS 5) 6,7) STACK DATA
		2 = RAM PROTECTION	1,2) SEGMENT ADDRESS 3,4) OFFSET ADDRESS 5) 6) READ DATA 7) WRITE DATA
RTS REAL TIME SOURCE ON CPM CARD	200 2 = ILLEGAL TIME	0 = RECOVERY 1 = STOP INCREMENTING 2 = ILLEGAL TIME	
BAT BATTERY		0 = RECOVERY 1 = DISCHARGE	
SWC SWC CARD	190	0 = TURN ALM LAMP OFF 1 = CLOCK FAILED 2 = CM MEMORY STACK	
		3 = RSM MEMORY STACK	1,2) READ AFTER WRITE DATA 5,6) CM ADDRESS 1) READ AFTER WRITE DATA 5,6) RSM ADDRESS
		4 = SSM MEMORY STACK	1) READ AFTER WRITE DATA 5,6) SSM ADDRESS
ICG TRUNK/LINE CARD	FIRST EN ON CARD	0 = RECOVERY 1 = DATA TRANSMISSION ERROR 2 = ICG AUDIT ERROR	
TRM PROPRIETARY TELEPHONE	EN OF EKT OR DSS	0 = RECOVERY 1 = DATA TRANSMISSION ERROR 2 = EKT AUDIT ERROR	
SCI RS-232-C PORT	PORT NO. 000/001	0 = RECOVERY 1 = DATA TRANSMISSION ERROR 2 = SEND DATA TIME OUT	
RG RGEN CARD	1 = RGEN FAULT	0 = RECOVERY 1 = RGEN FAULT	

Fault Code Translation (Continued)



GTE OMNI SBCS

CMC-801:

FAULT DATA TRANSLATION

1. FAULT DATA IN HEX CODE:

HH HH HH HH HH HH HH


1 2 3 4 5 6 7

H: HEX CHARACTER 0-9, A TO F OR BLANK

2. SCI STATUS

EACH BIT SHOWS THE FOLLOWING MEANING:

B B B B B B B B



SMDR Printer Controls



GTE OMNI SBCS

DESCRIPTION

- PLACE SMDR PRINTER OUT OF SERVICE WITH CMC-705 WHEN CHANGING PAPER. ENSURE THAT CORRECT RS-232-C PORT IS ENTERED.
- CHANGE THE CONTROL CONDITION FOR THE MDR PRINTER REQUIREMENTS RELATING TO PAUSE TRANSMISSION CHARACTER, POWER CONTROL AND TIMING, OR PRINTOUT FORMAT

PROCEDURE *

1. PLACE PRINTER IN OR OUT OF SERVICE WITH CMC-705:
 - PORT NUMBER (P1)
 - IN/OUT OF SERVICE FLAG (P2)
2. MODIFY PRINTER CONTROLS WITH CMC-901:
 - PORT NUMBER (P1)
 - PAUSE TRANSMISSION (XOFF/XON) CHARACTER (P2)
 - POWER CONTROL (P3)
 - POWER ON TIMING (P5)
 - POWER OFF TIMING (P6)

CMC=705
P1:1
P2:1

CMC=901
P1:1 P4:
P2:1 P5:
P3: P6:1

* REFER TO OMNI SBCS GTEP MANUAL, MAINTENANCE SECTION, FOR DESCRIPTION OF ASCII X-ON/X-OFF AND POWER CONTROL CHARACTERS.

RS-232-C Port Configuration Assignment



GTE OMNI SBCS

DESCRIPTION

- ASSIGN OR MODIFY THE CHARACTERISTICS OF THE TWO RS-232-C PORTS INCLUDING BIT RATE, PARITY, CHARACTER LENGTH, STOP BIT AND ECHO.
- BOTH PORTS ARE FULL DUPLEX.
- DEFAULT STANDARD DATA BASE PRESENTS PORT 0 FOR PMP AND PORT 1 FOR MDR PRINTER.

PROCEDURE

1. USE CMC-900 TO SET RS-232-C PORT CHARACTERISTICS:
 - PORT (P1)
 - BIT RATE (P2)
 - PARITY (P3)
 - CHARACTER LENGTH (P4)
 - STOP BIT (P5)
 - ECHO BACK (P6)

CMC=900	
P1:1	P4:7
P2:3	P5:1
P3:3	P6:1

NOTE: IF PORT TO BE CHANGED IS ASSIGNED TO SMDR PRINTER, FIRST PLACE PRINTER OUT OF SERVICE WITH CMC—705.

Diagnostic Trunk Connection Assignment



GTE OMNI SBCS

DESCRIPTION

- CMC-802 DEDICATES A TRUNK TO A DESIGNATED STATION FOR AUDITORY, RINGING, AND TRANSMISSION VERIFICATION.
- AFTER ASSIGNMENT, TESTS CAN BE MADE BY ORIGINATING A CALL TO THE TRUNK BY DIALING THE TRUNK ACCESS CODE FOR THE TRUNK GROUP.
- WORKING TRUNK CAN BE CONFIRMED BY DIALING AN OUTSIDE DIRECTORY NUMBER AND LISTENING FOR CONFIRMATION CALL PROGRESS TONES.

PROCEDURE *

1. USE CMC-802 TO ENTER STATION DIRECTORY NUMBER AND TRUNK TO BE TESTED:
 - DIRECTORY NUMBER (P1)
 - TRUNK EQUIPMENT NUMBER (P2)

CMC=802
P1:214
P2:181

NOTE: WHEN ACTIVATED STATION WILL ALWAYS SEIZE ASSIGNED TRUNK UNTIL VALUES FOR P1 AND P2 ARE DELETED WITH **REMOVE** KEY.



Traffic Measurement

GTE OMNI SBCS

DESCRIPTION

- ASSIGN OR CANCEL TRUNK GROUP NUMBERS TO BE SAMPLED WITH CMC-600.
- ACTIVATE A TRAFFIC MEASUREMENT STUDY WITH CMC-601.
- DEFINE THE DISPLAY FOR TRAFFIC MEASUREMENT BASED ON RECENT DATA (LESS THAN 10 HOURS) OR OLDER DATA (AFTER 10 HOURS).
- TRAFFIC DENSITY PERCENTAGE IS DISPLAYED BASED ON DESIGNATED TRUNK GROUP NUMBERS.

PROCEDURE *

1. ASSIGN TRUNK GROUP NUMBERS TO BE SAMPLED WITH CMC-600:
 - REGISTRATION SEQUENCE NUMBER: (P1)
 - TRUNK GROUP NUMBER (P2)
2. USE CMC-601 TO ACTIVATE TRAFFIC MEASUREMENT FLAG:
 - TRAFFIC MEASUREMENT START/STOP FLAG (P1)
3. USE CMC-602 TO DISPLAY TRAFFIC MEASUREMENT DATA:
 - TRAFFIC MEASUREMENT DATA AREA (P1)
 - REGISTRATION SEQUENCE NUMBER (P2)
 - TRUNK GROUP NUMBER (P3)
 - ELAPSED TIME IN HOURS (P4)
 - TRAFFIC DENSITY (P5)

NOTE: TRUNK GROUP NUMBERS MUST BE DELETED FROM SAMPLE WITH **REMOVE** KEY AFTER TRAFFIC STUDY HAS BEEN DEACTIVATED (CMC-601).

CMC=600
P1:1
P2:13

CMC=601
P1:1

CMC=602
P1:2 P4:1
P2:1 P5:0
P3:13

Maintenance Data Base Commands/CMC Command Summary



GTE OMNI SBCS

- TRUNK GROUP TRAFFIC SCREENING ASSIGNMENT 600 ASSIGNS TRUNK GROUP NUMBERS TO TRAFFIC SAMPLE.
- TRAFFIC MEASUREMENT ACTIVATION 601 ACTIVATES TRAFFIC MEASUREMENT STUDY.
- TRAFFIC MEASUREMENT DATA DISPLAY 602 DISPLAYS TRAFFIC DENSITY.
- TIME AND DATE SETTING 700 SETS SYSTEM HARDWARE AND SOFTWARE CLOCK.
- CIRCUIT BUSY ASSIGNMENT 701 PLACES CIRCUITS IN/OUT OF SERVICE FOR MAINTENANCE.
- SMDR IN/OUT OF SERVICE 705 PLACES SMDR IN/OUT OF SERVICE FOR MAINTENANCE.

Maintenance Data Base Commands/ CMC Command Summary (Continued)



GTE OMNI SBCS

- **DEVICE STATUS** 800 **LISTS FAULTY DEVICES AND LOCATIONS.**
- **FAULT LOG** 801 **PROVIDES DETAILED FAULT INFORMATION FOR TROUBLESHOOTING.**
- **DIAGNOSTIC TRUNK CONNECTION ASSIGNMENT** 802 **ASSIGNS A STATION TO A TRUNK FOR DIAGNOSTIC VERIFICATION.**
- **RS-232-C PORT CONFIGURATION** 900 **CHANGES CHARACTERISTICS OF RS-232-C PORTS.**
- **SMDR PRINTER CONTROL** 901 **CHANGES CONTROL CONDITION FOR SMDR.**
- **READ OUT SYSTEM SOFTWARE VERSION ID DISPLAY** 904 **DISPLAYS CURRENT SOFTWARE RELEASE.**
- **DISTRIBUTED PROCESSOR VERSION ID DISPLAY** 907 **DISPLAYS VERSION NUMBER FOR ICG CARDS.**

Laboratory Activity — Maintenance/Data Base Commands (3.2)



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASKS IN THE SEQUENCE OUTLINED BELOW AND IN ACCORDANCE WITH THE GTE OMNI SBCS MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #3.2	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 3.2 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none"> • Set time, day, date with CMC-700. • Take a circuit out of service with CMC-701. • Display software and distributed processor version number with CMC-904 and CMC-907. 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Set system clock using CMS-700. (2) Remove loop tie line circuit. (EN160) from service with CMC-701. (3) Obtain current software version number with CMC-904 and CMC-907. 	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Perform maintenance programming commands. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity — Maintenance/Data Base Commands (3.2) (Continued)



GTE OMNI SBCS

WORK ORDER #3.2	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER 3.2 (TASK #2)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Restore circuit to service with CMC-701. • Display device status with CMC-800. • Display fault log with CMC-801. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Restore the loop tie line to service. (2) Unplug one of the CS-10 telephones from its modular jack. (3) Check the device status display with CMC-800. (4) Read out the latest fault log listing with CMC-801. Was equipment number of disconnected CS-10 telephone displayed? (5) Plug the CS-10 telephone into its assigned modular jack. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Perform maintenance programming commands. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity — Maintenance/Data Base Commands (3.2) (Continued)



GTE OMNI SBCS

WORK ORDER #3.2	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER 3.2 (TASK #3)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>TASKS:</u> <ul style="list-style-type: none">• Take SMDR printer out of service with CMC-705.• Modify printer controls with CMC-901.• Change the RS-232-C port configuration assignment with CMC-900.	
<u>PARAMETERS:</u> <ol style="list-style-type: none">(1) Remove SMDR printer from service with CMC-705.(2) Change SMDR power on character to NUL and power off to DEL. Change power on timing to 800 ms and power off timing to 30 seconds.(3) Modify the RS-232-C configuration for port ϕ to:<ul style="list-style-type: none">— 2400 bps— even parity— 7 bit character length— 1 bit stop— no echo <p><i>(Above data terms will be discussed in Module IV).</i></p>	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none">(1) Perform maintenance programming commands.(2) Check/test the operation of commands after completion of this portion of the laboratory activity.(3) Proceed with next work order task.

Laboratory Activity — Maintenance/Data Base Commands (3.2) (Continued)



GTE OMNI SBCS

WORK ORDER #3.2	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER 3.2 (TASK #4)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Restore SMDR printer to service with CMC-705. • Assign diagnostic trunk connection with CMC-802. • Establish a traffic measurement study with CMC-600, CMC-601, and CMC-602. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Restore SMDR printer to service. (2) Dedicate the E&M tie line (EN170) to station directory number 212 using CMC-802. Trunk tests will be conducted later in Maintenance, Diagnostics section). (3) Assign CO trunk group 13 to traffic sample (registration sequence number 1) with CMC-600. (4) Activate the traffic measurement study with CMC-601. (5) Place several outgoing Co trunk calls. (6) Display the traffic measurement data for most recent data with CMC-602. (7) Deactivate the traffic measurement study with CMC-602. (8) Remove CO trunk group (13) from the sample registration sequence number 1 using CMC-600. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Perform maintenance programming commands. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Complete Review Exercise questions 1-15.

Review Exercise — Maintenance/Data Base Commands (3.2)




GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORK-BOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. WHEN MUST THE SYSTEM HARDWARE/SOFTWARE CLOCK BE SET OR RESET? _____

2. (TRUE OR FALSE) _____ CIRCUITS FOR ALL SYSTEM EQUIPMENT AND TRUNKS CAN BE TAKEN OUT OF SERVICE WITH CMC-701.

3. IDENTIFY THE COMPONENTS OF THE FOLLOWING SOFTWARE VERSION NUMBER (B011.2)



4. IDENTIFY THE COMPONENTS OF THE FOLLOWING VERSION NUMBER FOR THE INTERFACE CARD LISTED BELOW:

CMC = 907

P1 = 180

P2 = 2

P3 = 0

Review Exercise — Maintenance/Date Base Commands (3.2) (Continued)



GTE OMNI SBCS

5. MATCH THE CORRECT CONTENTS OF THE THREE DEVICE STATUS SCREENS FOR CMC-800:

- | | |
|--------------------|---|
| _____ SCREEN ONE | A. EKT STATUS |
| _____ SCREEN TWO | B. LINE/TRUNK CARD AND RS-232-C |
| _____ SCREEN THREE | C. HIGH LEVEL PORT STATUS FAULT SUMMARY |

6. WHAT CAN BE DONE TO OBTAIN MORE INFORMATION REGARDING A FAULTY DEVICE LISTED WITH CMC-800? _____

7. IDENTIFY THE FOLLOWING DEVICES LISTED FROM CMC-800:

SCI _____
ICG _____
RTS _____

8. IDENTIFY THE INFORMATION LISTED ON THE FOLLOWING FAULT LOG DISPLAYS:

CMC= 801 DSP
P1: TRM P4: 015
P2: 10:37 03/12
P3: 1

P1: _____
P2: _____
P3: _____
P4: _____

Review Exercise — Maintenance/Data Base Commands (3.2) (Continued)



GTE OMNI SBCS

CMC= 801
P1: ICG P4: 020
P2: 10:38 03/12
P3: 0

P1: _____
P2: _____
P3: _____
P4: _____

9. HOW COULD THE POWER OFF TIMING VALUE FOR THE SMDR PRINTER BE CHANGED TO ONE MINUTE? _____

10. THE SLOWEST BIT RATE ACCOMMODATED BY THE RS-232-C PORT CONFIGURATION IS _____ AND THE FASTEST BIT RATE IS _____.
11. TRUE OR FALSE _____ STATION ASSIGNED TO TRUNK FOR DIAGNOSTIC TRUNK TESTS WITH CMC-802 WILL ALWAYS SEIZE THAT PARTICULAR TRUNK CONNECTION.
12. WHAT MUST OCCUR BEFORE A TRAFFIC MEASUREMENT STUDY IS ACTIVATED WITH CMC-601? _____

13. TRAFFIC MEASUREMENT DATA CAN BE PROVIDED FOR _____ AND _____ STORED DATA.
14. A MAXIMUM OF _____ TRUNK GROUP MEMBERS CAN BE SAMPLED IN A TRAFFIC MEASUREMENT STUDY.

Review Exercise — Maintenance/Data Base Commands (3.2) (Continued)



GTE OMNI SBCS

15.

- | | | |
|-------|---------|---|
| _____ | CMC-600 | A. TRAFFIC TRUNK GROUP SCREENING |
| _____ | CMC-601 | B. TIME, DAY, AND DATE SETTING |
| _____ | CMC-602 | C. SMDR PRINTER IN/OUT OF SERVICE |
| _____ | CMC-700 | D. DEVICE STATUS DISPLAY |
| _____ | CMC-701 | E. TRAFFIC MEASUREMENT DATA DISPLAY |
| _____ | CMC-705 | F. RS-232-C PORT CONFIGURATION ASSIGNMENT |
| _____ | CMC-800 | G. SMDR PRINTER CONTROL |
| _____ | CMC-801 | H. CIRCUIT IN/OUT OF SERVICE |
| _____ | CMC-802 | I. FAULT LOG DISPLAY |
| _____ | CMC-900 | J. DISTRIBUTED PROCESSOR VERSION ID DISPLAY |
| _____ | CMC-901 | K. TRAFFIC MEASUREMENT ACTIVATION |
| _____ | CMC-904 | L. DIAGNOSTIC TRUNK CONNECTION ASSIGNMENT |
| _____ | CMC-907 | M. SYSTEM SOFTWARE VERSION ID DISPLAY |



GTE OMNI SBCS

SYSTEM MAINTENANCE

Troubleshooting

3.3 Enabling Objective



GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - PORTABLE MAINTENANCE PANEL
 - GTE OMNI SBCS PERIPHERALS
 - REPLACEMENT CARDS AND INSTRUMENTS
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - STANDARD MAINTENANCE TOOLS
 - LABORATORY ACTIVITY
 - REVIEW EXERCISE
- ACTION:**
- USE SBCS TROUBLESHOOTING STRATEGIES TO ISOLATE AND RESOLVE TYPICAL SYSTEM HARDWARE AND SOFTWARE PROBLEMS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- PROBLEMS WILL BE IDENTIFIED AND RESOLVED IN ACCORDANCE WITH TROUBLESHOOTING PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Troubleshooting Overview




GTE OMNI SBCS

- **TROUBLESHOOTING IS A SYSTEMATIC APPROACH TO IDENTIFYING AND ISOLATING SYSTEM PROBLEMS.**
- **PRIMARY TROUBLESHOOTING TOOLS INCLUDE BOTH THE DEVICE STATUS AND FAULT LOG TABLES, IN CONJUNCTION WITH SYSTEM VISUAL INDICATORS.**
- **ISOLATION OF A PROBLEM'S CAUSES REQUIRES:**
 1. **DETERMINATION OF SPECIFIC PROBLEMS (E.G., NO RINGING, NO DIAL TONE)**
 2. **DETERMINATION OF THE EXTENT OF THE PROBLEM (E.G., A CIRCUIT, A CARD, OR A GROUP NUMBER)**
- **CORRECTION OF A PROBLEM REQUIRES:**
 1. **INITIAL CHECKING OF CORRECT SYSTEM OPERATION.**
 2. **POSSIBLE REPLACEMENT OF DEFECTIVE COMPONENTS OR RELATED FOLLOW-UP ACTION.**
 3. **TESTING TO ENSURE CORRECT MAINTENANCE SYSTEM OPERATION.**

System-Wide Problems



GTE OMNI SBCS




- A SYSTEM-WIDE PROBLEM IS INDICATED BY A COMPLETE CALL PROCESSING FAILURE.
- SYSTEM-WIDE PROBLEMS USUALLY ARE CAUSED BY:
 - A DEFECTIVE POWER SUPPLY OR FAULT IN THE INTERCONNECTING POWER CABLES, OR
 - A DEFECTIVE COMMON CONTROL GROUP CARD.
- IF CAUSE CANNOT BE ISOLATED, THE CABINET BACKPLANE CIRCUITRY MAY BE DEFECTIVE.
- REFER TO THE FOLLOWING THREE FLOWCHARTS FOR TROUBLESHOOTING PROCEDURES FOR SYSTEM-WIDE PROBLEMS.

System-Wide Problems (Continued)



GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE (FLOWCHART 1)




System-Wide Problems (Continued)



GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE (FLOWCHART 2)




NOTE: TURN POWER OFF WHEN REINSERTING CPM, SWC, MEM, AND RGEN CARDS. UNSEATING CPM OR MEM CARDS DELETES ODDB.



System-Wide Problems (Continued)

GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE (FLOWCHART 3)



Multiple Card/Interface Signal Problems



GTE OMNI SBCS


- ASSOCIATED WITH MORE THAN ONE DEFECTIVE STATION OR TRUNK BEING SERVED BY MULTIPLE CARDS.
- PROBLEMS MAY RESULT FROM:
 - INTERFACE SIGNAL ASSOCIATED WITH A GROUP OF CARDS BEING SHORTED BY A DEFECTIVE CARD OR OPENED BY A DEFECTIVE BACKPLANE.
 - DEFECTIVE SWC CARD WHICH IS CONTROLLING THE GROUP.
- THREE TYPES OF INTERFACE SIGNAL PROBLEMS MAY OCCUR:
 1. SIGNALS ASSOCIATED WITH EACH OF THE SIX INTERFACE CARD GROUPS (WHERE EACH ICG HAS ONE INBOUND AND ONE OUTBOUND BUS TO/FROM THE SWC).
 2. SIGNALS ASSOCIATED WITH ICG 0 THROUGH 2 AND ICG 3 THROUGH 5 (WHERE LOAD SHARING ALLOWS SEVERAL CLOCK AND TIMING SIGNALS FOR ALL LINE/TRUNK CARDS TO BE DRIVEN FROM THE SWC BY TWO SEPARATE GATES).
 3. SIGNALS USED TO DISTRIBUTE TIME SLOTS AMONG THE CARD SLOTS IN EACH ICG (WHERE EACH ICG HAS ITS OWN BUS AND THREE CARD SLOTS, EXCEPT ICG 5 WHICH HAS A FOURTH CARD SLOT).
- REFER TO FOLLOWING FLOWCHART FOR TROUBLE SHOOTING PROCEDURE FOR MULTIPLE CARD PROBLEMS.

Multiple Card/Interface Signal Problems (Continued)



GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE



Single ICG Card Problems



GTE OMNI SBCS

- ASSOCIATED WITH MORE THAN ONE DEFECTIVE STATION OR TRUNK BEING SERVED BY THE SAME LINE OR TRUNK CARD.

- PRESCRIPTIVE ACTION MAY INCLUDE:
 - REPLACING THE DEFECTIVE LINE OR TRUNK CARD.

 - CHECKING FOR A LOOSE CONNECTION BETWEEN ICG CONNECTORS AND PINS AT THE CABINET.



Single Station or Trunk Problems

GTE OMNI SBCS


- **ASSOCIATED WITH A SINGLE STATION OR TRUNK.**
- **PROBLEMS MAY RESULT FROM:**
 - **DEFECTIVE LINE/TRUNK CIRCUIT.**
 - **FAULTY WIRING BETWEEN LINE CIRCUIT AND STATION, OR BETWEEN TRUNK CIRCUIT AND EXCHANGE (CO OR HOST PABX).**
 - **DEFECTIVE STATION INSTRUMENT OR CONNECTING CO/PABX.**
 - **STATION/TRUNK WAS NOT INSTALLED IN DATA BASE.**
 - **TRUNK CIRCUIT WAS PROGRAMMED FOR A DIFFERENT SIGNALING MODE (GROUND OR LOOP START) THAN THE CENTRAL OFFICE.**
- **REFER TO FOLLOWING FLOW CHART FOR TROUBLESHOOTING PROCEDURE FOR SINGLE STATION OR TRUNK PROBLEMS.**

Single Station or Trunk Problems (Continued)



GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE



Ringling Problems



GTE OMNI SBCS

- **RINGING PROBLEMS MAY RESULT FROM:**
 - **DEFECTIVE RGEN CARD (LIKELY CAUSE IF ALARM LAMP ON CPM CARD IS LIT).**
 - **OUTPUT FROM RGEN CARD BEING SHORTED BY A LINE OR TRUNK CARD.**
 - **RGEN CARD SET TO PROVIDE SYSTEM WITH DC VOLTAGE FOR MESSAGE WAITING SERVICE, BUT MESSAGE WAITING WAS NOT SPECIFIED IN THE DATA BASE.**


- **REFER TO FOLLOWING FLOWCHART FOR TROUBLESHOOTING PROCEDURES FOR RINGING PROBLEMS.**



Ringling Problems (Continued)

GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE (FLOWCHART 1)






Ringing Problems (Continued)

GTE OMNI SBCS

PROCEDURE FOR DETERMINATION OF CAUSE (FLOWCHART 2)



DTMF Single Line Telephone Problems



GTE OMNI SBCS

- **TWO TYPES OF PROBLEMS MAY OCCUR:**
 - **SINGLE CIRCUIT PROBLEM AFFECTING A SINGLE DTMF SLT INSTRUMENT.**
 - **MULTIPLE CIRCUIT PROBLEM AFFECTING ALL DTMF SLT INSTRUMENTS.**
- **REFER TO TROUBLESHOOTING PROCEDURE FOR SINGLE STATIONS/ TRUNKS FOR PROBLEMS AFFECTING SINGLE DTMF STATIONS.**
- **PROBLEMS AFFECTING ALL DTMF SLT INSTRUMENTS REQUIRE IDENTIFYING ONE OR MORE DEFECTIVE CIRCUITS ON THE 4DMR CARD. DEFECTIVE CIRCUIT(S) CAN BE ISOLATED BY USING CMC-701 TO PUT ALL DTMF CIRCUITS EXCEPT ONE BEING TESTED, OUT OF SERVICE.**



SWC and CPM Card Problems

GTE OMNI SBCS

- REPLACE THE SWC CARD IF PROBLEMS OCCUR RELATING TO ANY OF THE FOLLOWING SWC FUNCTIONS:
 - CALL PROGRESS TONE GENERATION
 - MIXING FUNCTION PERMITTING THREE-WAY CONVERSATION OR EXECUTIVE OVERRIDE
 - DTMF TONE SENDER FUNCTION
 - CONTROL LOSS (DIGITAL PAD)

- REPLACE THE CPM CARD IF THE REAL TIME SOURCE CLOCK ON THE CPM CARD BECOMES DEFECTIVE. A DEFECTIVE CONDITION IS INDICATED BY:
 - CPM ALARM LAMP ON
 - HH:MM DISPLAYED ON CS-20 AND CSD INSTRUMENTS INSTEAD OF PROGRAMMED SETTING
 - FAULT LOG LISTING FOR REAL TIME SOURCE (RTS)

NOTE: WHEN REPLACING COMMON CONTROL AND RGEN CARDS, SYSTEM POWER MUST BE OFF. UNSEATING THE CPM CARD DELETES THE ODDB. RELOAD OR REPROGRAM THE ODDB.

Printed Circuit Board Card Replacement



GTE OMNI SBCS

PROCEDURE

1. GROUND YOURSELF PRIOR TO HANDLING CARDS.
2. SYSTEM POWER MUST BE TURNED OFF WHEN INSTALLING OR REPLACING CPM, MEM, SWC, OR RGEN CARDS.
3. ALL LINE, TRUNK AND 4DMR CARDS CAN BE REPLACED WITH POWER ON. TRUNK CIRCUITS SHOULD BE TAKEN OUT OF SERVICE WITH CMC-701 PRIOR TO REMOVAL.
4. ALWAYS ENSURE THAT CARDS ARE INSERTED IN CORRECT SLOTS (REFER TO STUDENT WORKBOOK, INSTALLATION). FORCING THEM INTO INCORRECT SLOTS MAY RESULT IN CARD MALFUNCTIONS.
5. HANDLE CARDS BY EDGES ONLY. USE CAUTION BECAUSE DAMAGE TO EDGE OF CARD COULD RESULT IN MALFUNCTION.
6. WHEN REMOVING A CARD FROM A SLOT, GRASP PLASTIC EJECTORS AND FLIP TOWARD TOP AND BOTTOM OF CABINET.
7. ENSURE THAT CARD COMPONENTS FACE THE LEFT SIDE OF THE CABINET WHEN INSERTING (EXCEPT THE RGEN CARD WHOSE COMPONENTS FACE RIGHT).
8. SLIDE THE REPLACEMENT CARD COMPLETELY INTO ITS ASSIGNED SLOT AND FIRMLY PRESS PLASTIC EJECTOR TABS.
9. ENSURE THAT CARDS ARE SEATED FIRMLY INTO BACKPLANE CONNECTOR, BUT DO NOT FORCE CARDS THAT ARE NOT EASILY INSERTED. VERIFY THAT CARD BELONGS IN SLOT, THEN REINSERT IT.
10. INITIALIZE LINE/TRUNK CARDS BY PRESSING RESTART BUTTON WITH TOGGLE IN CENTER POSITION ON CPM CARD.

Laboratory Activity/Review Exercise

— Troubleshooting (3.3)



GTE OMNI SBCS

INSTRUCTIONS

- THE COMBINED LABORATORY ACTIVITY AND REVIEW EXERCISE ON THE FOLLOWING PAGES WILL ALLOW YOU TO BECOME MORE FAMILIAR WITH THE OMNI SBCS FAULT RESOLUTION PROCEDURES ASSOCIATED WITH THE FAULT CODES IN THE FAULT LOG.
- YOUR INSTRUCTOR HAS CREATED SEVEN SIMULATED FAULT CONDITIONS. USE THE TROUBLESHOOTING FLOWCHARTS INCLUDED IN THE STUDENT WORKBOOK AS A GUIDE FOR IDENTIFYING, ISOLATING, AND CORRECTING EACH OF THE FAULTS.
- TWO HOURS ARE ALLOWED TO COMPLETE THIS ACTIVITY. AS YOU PROCEED WITH EACH FAULT PROBLEM, COMPLETE THE CORRESPONDING REVIEW EXERCISE BELOW.
- SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

FAULT 1

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

Laboratory Activity/Review Exercise — Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

3. CHECK THE FAULT LOG LISTED WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

LAB MILESTONE

WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.

Laboratory Activity/Review Exercise – Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

FAULT 2

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

3. CHECK THE FAULT LOG LISTING WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

Laboratory Activity/Review Exercise — Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

LAB MILESTONE
WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.

FAULT 3

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

Laboratory Activity/Review Exercise – Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

3. CHECK THE FAULT LOG LISTING WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

LAB MILESTONE

WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.

Laboratory Activity/Review Exercise — Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

FAULT 4

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

3. CHECK THE FAULT LOG LISTED WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

Laboratory Activity/Review Exercise – Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

LAB MILESTONE

WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.

Laboratory Activity/Review Exercise — Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

FAULT 5

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

3. CHECK THE FAULT LOG LISTING WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

Laboratory Activity/Review Exercise — Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

LAB MILESTONE
WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.

FAULT 6

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

Laboratory Activity/Review Exercise — Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

3. CHECK THE FAULT LOG LISTING WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

Laboratory Activity/Review Exercise – Troubleshooting (3.3) (Continued)



GTE OMNI SBCS

LAB MILESTONE

WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.

FAULT 7

1. DETERMINE SYSTEM STATUS BY CHECKING CPM LED LAMPS AS INDICATORS. RECORD LAMP STATUS:

RUN LAMP: _____

ALARM LAMP: _____

TIMER OVERFLOW LAMP: _____

2. CHECK THE DEVICE STATUS DISPLAY WITH CMC-800 FOR AGREEMENT WITH THE CPM LED LAMPS. RECORD THE DISPLAY BELOW:

3. CHECK THE FAULT LOG LISTED WITH CMC-801. RECORD ANY FAULT INDICATED BELOW:

Laboratory Activity/Review Exercise

— Troubleshooting (3.3) (Continue@



GTE OMNI SBCS

4. TROUBLESHOOT THE FAULT USING APPROPRIATE FAULT RESOLUTION STEPS OUTLINED IN THE TROUBLESHOOTING FLOWCHARTS IN THE STUDENT WORKBOOK. RECORD THE STEPS YOU TOOK TO RESOLVE THE SPECIFIC FAULT. (INSTRUCTOR WILL BE EVALUATING YOUR STEPS BASED ON YOUR LOGIC, USE OF THE FLOWCHARTS, AS WELL AS SPEED IN IDENTIFYING THE FAULT):

LAB MILESTONE

WHEN THE FAULT HAS BEEN RESOLVED, NOTIFY THE INSTRUCTOR TO VERIFY YOUR ANSWERS.



GTE OMNI SBCS

SYSTEM MAINTENANCE

Diagnostics



3.4 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- PORTABLE MAINTENANCE PANEL
- GTE OMNI SBCS PERIPHERALS
- REPLACEMENT CARDS AND INSTRUMENTS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- STANDARD MAINTENANCE TOOLS
- LABORATORY ACTIVITY
- REVIEW EXERCISE

ACTION:

- USE OMNI SBCS SYSTEM DIAGNOSTICS TESTS TO IDENTIFY HARDWARE AND SOFTWARE MALFUNCTIONS.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DIAGNOSTIC TESTS WILL BE PERFORMED IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



Diagnostics/Overview

GTE OMNI SBCS

- **DIAGNOSTICS ARE A GROUP OF SYSTEM FUNCTIONS THAT FACILITATE MAINTENANCE BY DETECTION AND ISOLATION OF HARDWARE AND SOFTWARE MALFUNCTIONS.**

- **OMNI SBCS PROVIDES 3 TYPES OF ON-LINE SYSTEM DIAGNOSTICS:**
 - **SELF-DIAGNOSTICS: ROUTINE SELF-TESTS DONE AT TIME OF A RESTART WHERE SYSTEM RESPONDS TO A DETECTED ERROR WITH AN ALARM.**

 - **CALL-PROCESSING DIAGNOSTICS: ROUTINE TESTS DONE CONTINUOUSLY AND AUTOMATICALLY BY OPERATING SYSTEM.**

 - **MANUAL **TRUNK** CONNECTION DIAGNOSTICS: CMC COMMAND DEDICATED TO TESTING TRUNKS WHILE SYSTEM IS ON-LINE.**



System Self-Diagnostics

GTE OMNI SBCS

SYSTEM IMPLEMENTS THE FOLLOWING TESTS WHEN THE SYSTEM IS POWERED ON, BY PRESSING THE CPM RESTART BUTTON, OR BY THE WATCH DOG TIMER OVERFLOW:

- RAM READ/WRITE TEST
- RAM PROTECTION TEST
- SWITCH CONTROL TEST
- NON-VOLATILE RAM CHECK

TABLE BELOW INDICATES THE TYPE OF ALARM AND SYSTEM RESPONSE TO ERRORS DETECTED DURING SELF-DIAGNOSTIC TESTS:

TYPE OF DIAGNOSTICS	TYPE OF RESTART			TYPE OF ALARM			SYSTEM RESPONSE
	COLD	HOT	R	RUN	TO	ALM	
RAM/R/W	X	X		ON	-	ON	CALL PROCESSING UNINTERRUPTED
RAM MEMORY	X	X		ON	-	ON	CALL PROCESSING UNINTERRUPTED
SWC MEMORY R/W	X	X	X	ON	-	ON	CALL PROCESSING UNINTERRUPTED
NON-VOLATILE RAM	X	X	X	ON	-	OFF	INITIATE COLD RESTART (ODDB IS LOST)

NOTE: ALL ERRORS/RESPONSES ARE ENTERED IN THE SYSTEM FAULT LOG.

TYPES OF RESTARTS:
 X = TEST DONE AT RESTART
 COLD = COLD RESTART INITIALIZES DEFAULT DATA BASE, ODDB IS DELETED
 HOT = HOT RESTART RETAINS ODDB
 R =RESET INDICATES A MOMENTARY POWER INTERRUPT

TYPES OF ALARM:
 ON = ALARM LAMP STEADILY ON.
 OFF = ALARM LAMP STEADILY OFF.
 - = ALARM INDICATES LAST STATE.

Call Processing Diagnostics



GTE OMNI SBCS

- **SYSTEM AUTOMATICALLY SUPERVISES CALL PROCESSING OPERATION BY IMPLEMENTING THE FOLLOWING TESTS:**
 - REAL TIME SOURCE CLOCK
 - I/O CONTROL CHECK
 - SWITCH CONTROL CLOCK DOWN CHECK
 - SWITCH MEMORY TEST
 - SWITCH CONTROL TEST
 - CPM PERIPHERAL CARD DATA TRANSMISSION CHECK
 - CPM CARD GROUP DATA COMMUNICATION CHECK
 - MEMORY BACKUP BATTERY CHARGE CHECK
 - INVALID SYSTEM INTERRUPTING CHECK
 - SOFTWARE MAZE CHECK
 - RGEN CARD CHECK

- **TABLES ON FOLLOWING PAGES DESCRIBE THE TYPE OF ALARM AND: SYSTEM RESPONSE TO ERRORS DETECTED DURING CALL PROCESSING DIAGNOSTIC TESTS.**

Call Processing Diagnostics (Continued)



GTE OMNI SBCS

SYSTEM CALL PROCESSING DIAGNOSTICS

TYPES OF DIAGNOSTICS	PROBLEM	TYPES OF ALARM			FAULT LOGGED	SYSTEM RESPONSE
		RUN	TO	ALM		
REAL TIME SOURCE CLOCK (RTS)	STOP INCREMENTING TIME OUTPUT ILLEGAL TIME	ON	—	ON	YES	CALL PROCESSING UNINTERRUPTED. TIMER IS DOWN. TIME NOT OUTPUT TO EKT SCREENS.
I/O CONTROL (SERIAL COMMUNICATION INTERFACE)	PARITY ERROR. FRAMING ERROR. (NOT RECOVERABLE)	ON	—	ON	YES	CALL PROCESSING UNINTERRUPTED.
SWC CONTROL CLOCK DOWN	CLOCK DOWN.	OFF	—	ON	YES	SYSTEM DOWN (PFT ACTIVATED) WHEN THE CLOCK IS RESTORED AND HOT RESTART INITIATED TO LAMP GOES TO ON.
SWC MEMORY ERROR	MEMORY R/W ERROR.	ON	—	ON	YES	CALL PROCESSING UNINTERRUPTED.
ICG CARD GROUP DATA ERROR	CARD OR CIRCUIT HAS BEEN REMOVED. ILLEGAL FUNCTION ATTEMPTED.	ON	—	ON	YES	MAKES FAULTY LINE/TRUNK CIRCUITS BUSY
EKT ERROR	DATA PARITY ERROR LINE CARD OR EKT	ON	—	ON	YES	MAKES FAULTY EKT CIRCUIT BUSY.
MEMORY BACKUP BATTERY CHARGE	BACKUP BATTERY DISCHARGED	ON	—	ON	YES	CALL PROCESSING UNINTERRUPTED.
SWC CONTROL ERROR	BUSY FLAG STACK	ON	—	ON	YES	INITIATES HOT RESTART
SOFTWARE MAZE (MEMORY PROBLEM).	SOFTWARE LOGIC ERROR	ON	—	OFF	YES	INITIATES HOT RESTART.
RGEN CARD	RGEN DEFECTIVE	ON	—	ON	YES	NO RINGING TO SLT.

Call Processing Diagnostics (Continued)



GTE OMNI SBCS

HARDWARE FAULT DETECTION

TYPE OF DIAGNOSTICS	TYPES OF ALARM			SYSTEM RESPONSE
	RUN	TO	ALM	
CPM CLOCK FAILURE	OFF	ON	OFF	SYSTEM DOWN (PFT IS ACTIVATED)
WATCH DOG TIMER OVERFLOW	ON	ON	OFF	INITIATE HOT RESTART
RESTART THRESHOLD EXCEEDED	OFF	ON	OFF	SYSTEM DOWN (PFT IS ACTIVATED)

Manual Trunk Connection Diagnostics



- SYSTEM PROVIDES CMC-802 AS A DIAGNOSTIC TOOL FOR DEDICATING A SPECIFIC TRUNK LINE TO A DESIGNATED STATION FOR AUDITORY, RINGING, AND TRANSMISSION VERIFICATION.
- REFER TO DIAGNOSTIC TRUNK CONNECTION IN STUDENT WORKBOOK FOR TESTING PROCEDURE.



Lamp Status Fault Isolation

GTE OMNI SBCS

TABLE BELOW DESCRIBES PRESCRIPTIVE ACTIONS TO BE TAKEN IF AN ERROR OR FAULT IS DETECTED AND INDICATED ON THE SYSTEM LED STATUS LAMPS.

LAMP STATUS				LAMP STATUS FAULT	ISOLATION/PRESCRIPTIVE ACTION
LAMP STATUS				LIKELY PROBLEM	ACTION
POWER	RUN	TO	ALM		
OFF	OFF	OFF	OFF	POWER DOWN OR POWER SUPPLY FAULT	REFER TO CMC FAULT ISOLATION TABLE ON NEXT PAGE.
ON	OFF	ON	OFF	CPM FAULT: CLOCK FAILED RESTARTRETRYOVERRUN	REPLACE CPM CARD AND REPLACE SWC CARD.
ON	OFF	OFF	ON	SWC FAULT: CLOCK DOWN	READ OUT FAULT LOG, THEN REPLACE SWC CARD.
ON	OFF	ON	ON	CPM OR SWC FAULT: PERIPHERAL CARD FAULT EKT FAULT	REPLACE SWC CARD AND CHECK THE SYSTEM STATUS. IF NECESSARY, CHANGE CPM CARD.
ON	ON	ON	OFF	SOFTWARE FAULT: CPM INTERMITTENT FAULT	READ OUT THE FAULT LOG, THEN RESPOND ACCORDING TO CMC FAULT ISOLATION TABLE ON NEXT PAGE.
ON	ON	OFF	ON	SWC FAULT: PERIPHERAL CARD FAULT EKT FAULT RGEN FAULT	READ OUT THE FAULT LOG, THEN RESPOND ACCORDING TO CMC FAULT ISOLATION TABLE ON NEXT PAGE.
ON	ON	ON	ON	SOFTWARE FAULT: CPM/SWC INTERMITTENT FAULT PERIPHERAL CARD FAULT EKT FAULT	READ OUT THE FAULT LOG, THEN RESPOND ACCORDING TO CMC FAULT ISOLATION TABLE ON NEXT PAGE.

Lamp Status Fault Isolation (Continued)



GTE OMNI SBCS

TYPES OF FAULTS	ACTION
COMMON CONTROL (CC)	GENERALLY NO ACTION REQUIRED. IF PROBLEM GETS WORSE, INITIATE RESTART IN THIS ORDER: RESET, HOT, COLD. THE COLD RESTART WILL LOSE THE ODDB.
REAL TIME SOURCE CLOCK	REPLACE CPM CARD DURING LOW TRAFFIC PERIOD.
RAM MEMORY	REPLACE CPM CARD DURING LOW TRAFFIC PERIOD.
BACK-UP BATTERY	IF THERE HAS BEEN A LONG TERM POWER FAILURE, NO ACTION IS NEEDED. THE BATTERY IS BEING CHARGED. IF DISCHARGE CONDITION CONTINUES MORE THAN TWO DAYS, CHANGE BACK-UP BATTERY. SAVE CUSTOMER DATA BASE TO TAPE.
SWITCH CONTROL	REPLACE SWC CARD.
LINE/TRUNK CARD	TROUBLESHOOT ACCORDING TO PROCEDURE FOR SINGLE ICG CARD PROBLEMS.
TERMINAL (TRM) EKT OR DSS	TEST EKT AND/OR BLF/DSS. IF INSTRUMENT IS FAULTY, REPLACE IT IF INSTRUMENT IS OPERATIONAL.
SERIAL COMMUNICATION INTERFACE	CHECK I/O EQUIPMENT. CHECK CONFIGURATION MATCH OF RS-232-C PORT (CMC-900) AND THE CONNECTION. IF OPERATIONAL, CHANGE CPM CARD DURING LOW TRAFFIC CONDITION.
SOFTWARE	NO RESPONSE IS NEEDED. IF SYSTEM OPERATION DETERIORATES, INITIATE RESTART. (RESET, HOT, OR COLD RESTART).
RGEN CARD	REPLACE WITH SPARE RGEN CARD.

NOTE: IF FAULT LOG CANNOT BE ACCESSED, REPLACE CPM CARD. INITIATE RESET AND VERIFY SYSTEM OPERATION BEFORE CHANGING CPM CARD. ENSURE THAT ODDB HAS BEEN SAVED BEFORE REPLACING CPM OR MEM CARDS.

EKT and BLF/DSS Instrument Diagnostics



GTE OMNI SBCS

DESCRIPTION

- . CS-10, CS-20, CSD, AND BLF/DSS MUST BE TESTED OFF-LINE.

- . THE FOLLOWING TESTS CAN BE PERFORMED:
 - BUTTON AND KEY PAD TEST
 - LED LAMP TEST
 - LCD DISPLAY TEST
 - VOICE CIRCUIT TEST
 - AUDIBLE TONE TEST

PROCEDURE — EKT INSTRUMENTS

1. UNPLUG TELEPHONE CORD FROM MODULAR JACK IN BACK OF TELEPHONE.
2. PRESS 1 AND 3 KEYS SIMULTANEOUSLY.
3. PLUG TELEPHONE CORD INTO MODULAR JACK IN BACK OF TELEPHONE WHILE KEEPING THE 1 AND 3 KEYS PRESSED.
4. PRESS APPROPRIATE TEST EXECUTION KEYS (REFER TO TABLES ON FOLLOWING PAGES OF STUDENT WORKBOOK) AND MONITOR RESULTS. IF RESULTS VARY FROM THOSE LISTED, RETURN DEFECTIVE INSTRUMENT FOR REPAIR.

PROCEDURE | — BLF/DSS INSTRUMENTS

1. UNPLUG TELEPHONE CORD FROM MODULAR JACK IN BACK OF INSTRUMENT.
2. PRESS FUNCTION KEYS 23 AND 3 SIMULTANEOUSLY.
3. PLUG TELEPHONE CORD INTO MODULAR JACK WHILE KEEPING FUNCTION KEYS 23 AND 3 PRESSED.
4. PRESS APPROPRIATE TEST EXECUTION KEYS (REFER TO TABLE ON FOLLOWING PAGES OF STUDENT WORKBOOK) AND MONITOR RESULTS. IF RESULTS VARY FROM THOSE LISTED, RETURN DEFECTIVE INSTRUMENT FOR REPAIR.

EKT and BLF/DSS Test Execution



GTE OMNI SBCS

KEYS PRESSED	RESULT
1	STOP RINGING. CS 20 AND CSD DISPLAYS "1".
2	START RINGING IN PATTERN 1. CS 20 AND CSD DISPLAYS "2".
3	START RINGING IN PATTERN 2. CS 20 AND CSD DISPLAY "3".
4	START RINGING IN PATTERN 3. CS 20 AND CSD DISPLAY "4".
5	START RINGING IN PATTERN 4. CS 20 AND CSD DISPLAY "5".
6	START RINGING IN PATTERN 5. CS 20 AND CSD DISPLAY "6".
7	START RINGING IN PATTERN 6. CS 20 AND CSD DISPLAY "7".
8	START RINGING IN PATTERN 7. CS 20 AND CSD DISPLAY "8".
9	START RINGING IN PATTERN 8. CS 20 AND CSD DISPLAY "9".
0	ASSOCIATED LED LAMP FLASHING. (REPEAT OF 0.125 SEC ON, 0.125 SEC OFF, 0.125 SEC ON AND 1.625 SEC OFF).
#	ASSOCIATED LED LAMP FLASHING. (REPEAT OF 1.0 SEC ON AND 1.0 SEC OFF). CS 20 AND CSD DISPLAY "#".
*	ASSOCIATED LED LAMP FLASHING. (REPEAT OF 0.125 SEC ON, 0.25 SEC OFF, and 1.625 SEC OFF). CS 20 AND CSD DISPLAY "."

EKT and BLF/DSS Test Execution (Continued)



GTE OMNI SBOS

KEYS PRESSED	RESULT
FK1	ASSOCIATED LED LAMP ON
FK2	ASSOCIATED LED LAMP ON
FK3	ASSOCIATED LED LAMP ON
FK4	ASSOCIATED LED LAMP ON
FK5	ASSOCIATED LED LAMP ON
FK6	ASSOCIATED LED LAMP ON
FK7	ASSOCIATED LED LAMP ON
FK8	ASSOCIATED LED LAMP ON
FK9	ASSOCIATED LED LAMP ON. DISPLAY ALL DOT PATTERN ON THE LCD OF THE CS 20 AND CSD.
FK10	ASSOCIATED LED LAMP ON. DISPLAY BLANK ON THE LCD OF THE CS 20 AND CSD.
FK11-14 (CSD ONLY)	ASSOCIATED LED LAMP ON
FK1 I-80 (DSS ONLY)	ASSOCIATED LED LAMP ON
SK1 (CSD ONLY)	LED ASSOCIATED WITH FK1 FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC OFF)
SK2 (CSD ONLY)	LED ASSOCIATED WITH FK2 FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC. OFF)
SK3 (CSD ONLY)	LED ASSOCIATED WITH FK3 FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC OFF).
SK4 (CSD ONLY)	LED ASSOCIATED WITH FK4 FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC OFF)
SK5 (CSD ONLY)	LED ASSOCIATED WITH FK5 FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC OFF)
SK6 (CSD ONLY)	LED ASSOCIATED WITH FK6 FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC OFF).
HOOKSWITCH	GO ON-HOOK: HIGH VOLUME TONE RINGER. ALL LED _s FLASHING (REPEAT OF 0.5 SEC ON, 0.5 SEC OFF) GO OFF-HOOK: LOW VOLUME TONE RINGER. ALL LED _s FLASHING (REPEAT OF 0.125 SEC ON, 0.125 SEC OFF)
DTA TEST SWITCH (CSD ONLY)	ON: ALL LED _s FLASHING (REPEAT OF 1.875 SEC ON, 0.125 SEC OFF) OFF: ALL LED _s FLASHING (REPEAT OF 0.125 SEC ON, 0.125 SEC OFF, 0.125 SEC ON AND 1.625 SEC OFF)

Laboratory Activity — Diagnostics (3.4)



GTE OMNI SBCS

(INSTRUMENT DIAGNOSTICS)

1. USING THE INSTRUCTIONS PROVIDED IN THE STUDENT WORKBOOK, TEST ONE OF THE CS-20 TELEPHONES. BE SURE TO USE ALL TEST EXECUTION KEYS LISTED AND MONITOR THE RESULTS.
2. USING THE INSTRUCTIONS PROVIDED IN THE STUDENT WORKBOOK, TEST ONE OF THE BLF/DSS INSTRUMENTS. BE SURE TO USE ALL TEST EXECUTION KEYS LISTED AND MONITOR THE RESULTS.

(TRUNK DIAGNOSTICS)

3. VERIFY AUDITORY, RINGING, AND TRANSMISSION FOR THE TRUNK (EN170) ASSIGNED TO STATION DIRECTORY NUMBER 212 FOR DIAGNOSTICS (LABORATORY ACTIVITY 3.2). ORIGINATE A CALL TO THE TRUNK BY NUMBER AND LISTEN FOR CONFIRMATION CALL PROGRESS TONES. (BE SURE TO RELEASE SEIZED TRUNK AFTER DIAGNOSTIC TESTING USING CMC-802).



Review Exercise — Diagnostics (3.4)

GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. THE OMNI SBCS PROVIDES THREE TYPES OF ON-LINE SYSTEM DIAGNOSTICS: _____, _____, AND _____.
2. WHICH ACTIONS WILL AUTOMATICALLY INITIATE SYSTEM SELF-DIAGNOSTICS?

3. WHAT OCCURS IF A NON-VOLATILE RAM ERROR IS DETECTED DURING THE SELF-DIAGNOSTIC TEST?

4. WHAT TYPE OF PROBLEMS COULD BE IDENTIFIED FROM I/O CONTROL (SERIAL COMMUNICATION INTERFACE) DIAGNOSTICS? _____

5. EXPLAIN THE PROCEDURE FOR PERFORMING MANUAL TRUNK CONNECTION DIAGNOSTICS:

Review Exercise — Diagnostics (3.4) (Continued)



GTE OMNI SBCS

6. DESCRIBE THE LIKELY AND PRESCRIPTIVE ACTION FOR THE CPM LAMP STATUS OUTLINED BELOW:

POWER = ON

RUN = OFF

ALM = ON

TO=ON

7. IF EKT TELEPHONES BEGIN DISPLAYING INCORRECT (ILLEGAL) TIME DISPLAYS, IT PROBABLY INDICATES:

Review Exercise — Diagnostics (3.4) (Continued)



GTE OMNI SBCS

-
-
8. (TRUE OR FALSE) _____ A RAM MEMORY FAULT USUALLY REQUIRES REPLACEMENT OF THE SWC CARD DURING A LOW TRAFFIC PERIOD.

 9. (TRUE OR FALSE) _____ AN RGEN FAULT USUALLY REQUIRES REPLACEMENT OF THE NON-RINGING SLT INSTRUMENT.

 10. AFTER AN EKT TELEPHONE IS TAKEN OFF-LINE IT CAN BE TESTED BY UNPLUGGING THE TELEPHONE CORD AND PRESSING THE _____ AND _____ KEYS SIMULTANEOUSLY.



GTE OMNI SBCS

MODULE IV
PACKAGE B/SVR 1.5.X.X

Table of Contents



GTE OMNI SBCS

	Page
PACKAGE B OVERVIEW	
• PACKAGE B OVERVIEW (OBJECTIVES)	4.3
• OMNI SBCS DEVELOPMENT PHASES	4.4
• SYSTEM WITH PACKAGE B INTERFACES	4.5
• SUMMARY OF FEATURES AND ENHANCEMENTS	4.6
• DATA COMMUNICATIONS OVERVIEW/SELF-TEST	4.8
• PACKAGE B/DATA CAPABILITIES	4.14
• INTERNAL DATA CALL CONNECTION	4.15
• PACKAGE B DATA FEATURES	4.15
NEW/ENHANCED CARDS AND PERIPHERALS	
• CPMB (ENHANCED CENTRAL PROCESSING UNIT AND BASIC MEMORY CARD)	4.19
• MEMB (ENHANCED MEMORY CARD)	4.20
• REVIEW OF OPTIONAL RGEN CARD	4.21
• 8DTC (CSD TELEPHONE/DATA TERMINAL INTERFACE CARD)	4.22
• CSD DIGITAL TELEPHONE	4.24
• DATA TERMINAL ADAPTER (DTA)	4.25
• DATA TERMINAL STATION	4.26
• OPTIONAL EXTERNAL PAGING AMPLIFIER	4.27
• REVIEW EXERCISE (4.1)	4.27
PACKAGE INSTALLATION	
• PACKAGE B INSTALLATION (OBJECTIVES)	4.31
• CARD INSTALLATION	4.32
• DATA TERMINAL ADAPTER (DTA) INSTALLATION	4.33
• CSD TELEPHONE INSTALLATION	4.35
• DATA TERMINAL INSTALLATION	4.37
• MESSAGE WAITING ON SLT INSTRUMENTS	4.41
• OPTIONAL EXTERNAL PAGING INSTALLATION	4.42
• LABORATORY ACTIVITY (4.2)	4.43
• REVIEW EXERCISE (4.2)	4.45



Table of Contents (Continued)

GTE OMNI SBCS

	Page
PACKAGE B DATA BASE ADMINISTRATION	
● PACKAGE B DATA BASE ADMINISTRATION (OBJECTIVES)	4.49
● DATA SWITCHING PROGRAMMING	4.50
● EXTERNAL SPEAKER PAGING ASSIGNMENT	4.55
. MESSAGE WAITING FOR SLT PROGRAMMING	4.57
. ACCESS CODES/SVR 1.5.X.X	4.56
● SYSTEM PARAMETERS/SVR 1.5.X.X	4.59
● EQUAL ACCESS PROGRAMMING	4.61
. LABORATORY ACTIVITY (4.3)	4.63
● REVIEW EXERCISE (4.3)	4.69
PACKAGE B MAINTENANCE	
. PACKAGE B MAINTENANCE (OBJECTIVES)	4.73
● MASTER CONTROL TELEPHONE ASSIGNMENT	4.74
● MASTER CONTROL TELEPHONE OPERATION	4.75
. SECURITY CODE ASSIGNMENT	4.76
. LABORATORY ACTIVITY (4.4)	4.76
. REVIEW EXERCISE (4.4)	4.79



4.0 Terminal Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PACKAGE B EQUIPMENT AND PERIPHERALS
- PORTABLE MAINTENANCE PANEL/MASTER CONTROL TELEPHONE
- STANDARD INSTALLATION TOOLS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- PRE-READING ASSIGNMENT (DATACOM FOR TELECOM — THE BASICS)
- WRITTEN TEST

ACTION:

- INSTALL PACKAGE B EQUIPMENT AND PERIPHERALS.
- MODIFY THE SYSTEM DATA BASE USING NEW OR ENHANCED PACKAGE B CMC COMMANDS.
- PERFORM DATA BASE ADMINISTRATION AND MAINTENANCE TASKS USING CSD TELEPHONE AS A MASTER CONTROL TELEPHONE.
- DESCRIBE RETROFIT PROCEDURES REQUIRED TO UPGRADE GTE OMNI SBCS TO SVR 1.5.X.X (PACKAGE B).
- COMPLETE WRITTEN TEST.

CRITERIA:

- INSTALLATION, DATA BASE ADMINISTRATION, AND MAINTENANCE TASKS WILL BE COMPLETED IN ACCORDANCE WITH PACKAGE B PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- TEST WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



GTE OMNI SBCS

PACKAGE B

Overview

4.1 Enabling Objective



GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PACKAGE B EQUIPMENT AND PERIPHERALS
 - PRE-READING ASSIGNMENT (DATACOM FOR TELECOM - THE BASICS)
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - REVIEW EXERCISE
- ACTION:**
- DESCRIBE THE NEW FEATURES AND ENHANCEMENTS AVAILABLE WITH SVR PACKAGE B.
 - IDENTIFY AND DESCRIBE THE FUNCTIONS OF PACKAGE B EQUIPMENT AND INTERFACES.
 - DEFINE BASIC DATA COMMUNICATIONS TERMS APPLICABLE TO PACKAGE B
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

OMNI SBCS Development Phases



GTE OMNI SBCS

THE OMNI SBCS IS BEING DEVELOPED IN PHASES CORRESPONDING TO SYSTEM VERSION RELEASES. THIS MODULE WILL ADDRESS THE INSTALLATION, DATA BASE ADMINISTRATION, AND MAINTENANCE TASKS ASSOCIATED WITH PACKAGE B (SVR 1.5.X.X). HIGHLIGHTS OF EACH NEW DEVELOPMENT PHASE ARE DESCRIBED BELOW.

PACKAGE B/PHASE 1.5 — INTRODUCES BASIC INTERNAL DATA COMMUNICATION FEATURES FOR LOW SPEED DATA TERMINALS, ALLOWING SIMULTANEOUS VOICE/DATA TRANSMISSION.


PACKAGE C/PHASE 2.0 — EXPANDS SYSTEM TO INCLUDE LOW SPEED DATA COMMUNICATION USING REMOTE DATA TERMINALS, KEY SYSTEM FEATURES, DIRECT INWARD SYSTEM ACCESS, DIRECT INWARD DIALING, A HOTEL/MOTEL PACKAGE, AND AN ATTENDANT CONSOLE WITH RELATED FEATURES.

PACKAGE D/PHASE 3.0 — PROJECTED TO EXPAND SYSTEM TO INCLUDE AUTOMATIC CALL DISTRIBUTION, MULTI STATION LINE APPEARANCES ON EKT INSTRUMENTS, VOICE MESSAGE, SILENT MESSAGE, AND DICTATION AND CONTROL.



System With Package B Interfaces

GTE OMNI SBCS



Package B/Summary of Features and Enhancements



GTE OMNI SBCS

- BASIC DATA SWITCHING** — ALLOWS INTERNAL DATA COMMUNICATION BETWEEN ON-SITE, LOW SPEED DATA TERMINALS. PROVIDES ASYNCHRONOUS OR SYNCHRONOUS TRANSMISSION IN HALF OR FULL DUPLEX MODES.

- SIMULTANEOUS VOICE/DATA TRANSMISSION EQUAL ACCESS** — PROVIDES VOICE AND DATA TRANSMISSION SIMULTANEOUSLY OVER SINGLE PAIR WIRING THROUGH USE OF CSD DIGITAL TELEPHONE. EQUIPPED WITH DATA TERMINAL ADAPTER.
— ACCOMMODATES CARRIER EQUAL ACCESS IN GEOGRAPHIC AREAS WHERE SERVICE IS NOW AVAILABLE.

- MASTER CONTROL TELEPHONE** — ALLOWS DATA BASE ADMINISTRATION AND MAINTENANCE TASKS TO BE PERFORMED FROM PROGRAMMING CSD TELEPHONES.

Package B/Summary of Features and Enhancements (Continued)



GTE OMNI SBCS

- ENHANCED PAGING — ALLOWS ACCESS TO EXTERNAL PAGING AMPLIFIER AND PROVIDES IMPROVED PAGING FEATURES.
- CALL SPLITTING — ALLOWS STATION USERS TO SPLIT A CALL CONNECTION PROVIDING CAPABILITY OF TALKING TO EITHER CALLED OR CALLING PARTY WITHOUT EITHER HEARING THE OTHER'S CONVERSATION.
- MESSAGE WAITING FEATURE FOR SLT INSTRUMENTS — PROVIDES MESSAGE WAITING FEATURE FOR SINGLE LINE TELEPHONES (DP OR DTMF) EQUIPPED WITH MESSAGE WAITING LAMPS. MESSAGE LEAVING STATIONS ARE ACCESSED BY THE SLT USING A MESSAGE PICKUP ACCESS CODE.

Package B/Summary of Features and Enhancements



GTE OMNI SBCS

- BASIC DATA SWITCHING** — ALLOWS INTERNAL DATA COMMUNICATION BETWEEN ON-SITE, LOW SPEED DATA TERMINALS. PROVIDES ASYNCHRONOUS OR SYNCHRONOUS TRANSMISSION IN HALF OR FULL DUPLEX MODES.

- SIMULTANEOUS VOICE/DATA TRANSMISSION EQUAL ACCESS** — PROVIDES VOICE AND DATA TRANSMISSION SIMULTANEOUSLY OVER SINGLE PAIR WIRING THROUGH USE OF CSD DIGITAL TELEPHONE. EQUIPPED WITH DATA TERMINAL ADAPTER.
— ACCOMMODATES CARRIER EQUAL ACCESS IN GEOGRAPHIC AREAS WHERE SERVICE IS NOW AVAILABLE.

- MASTER CONTROL TELEPHONE** — ALLOWS DATA BASE ADMINISTRATION AND MAINTENANCE TASKS TO BE PERFORMED FROM PROGRAMMING CSD TELEPHONES.

Package B/Summary of Features and Enhancements (Continued)



GTE OMNI SBGS




- ENHANCED PAGING** — ALLOWS ACCESS TO EXTERNAL PAGING AMPLIFIER AND PROVIDES IMPROVED PAGING FEATURES.
- CALL SPLITTING** — ALLOWS STATION USERS TO SPLIT A CALL CONNECTION PROVIDING CAPABILITY OF TALKING TO EITHER CALLED OR CALLING PARTY WITHOUT EITHER HEARING THE OTHER'S CONVERSATION.
- MESSAGE WAITING FEATURE FOR SLT INSTRUMENTS** — PROVIDES MESSAGE WAITING FEATURE FOR SINGLE LINE TELEPHONES (DP OR DTMF) EQUIPPED WITH MESSAGE WAITING LAMPS. MESSAGE LEAVING STATIONS ARE ACCESSED BY THE SLT USING A MESSAGE PICKUP ACCESS CODE.

Data Communications Overview/ Self-Test



GTE OMNI SBCS

**WHAT DO YOU KNOW ABOUT
DATA COMMUNICATIONS?**



STUDENTS ARE REQUIRED TO COMPLETE A PRE-READING ASSIGNMENT (DATACOM FOR TELECOM - THE BASICS) PRIOR TO BEGINNING THIS COURSE MODULE. AN UNDERSTANDING OF BASIC DATA COMMUNICATIONS CONCEPTS IS HELPFUL BECAUSE THE PRIMARY FUNCTION OF PACKAGE B INCLUDES BASIC, INTERNAL DATA SWITCHING.

- INSTRUCTIONS:
- ON THE NEXT SEVERAL PAGES YOU WILL BE GIVEN THE OPPORTUNITY TO TEST YOUR UNDERSTANDING OF DATA COMMUNICATIONS BY MATCHING SIMPLE TERMS TO THEIR DEFINITIONS. TEST ITEMS DO NOT ADDRESS ALL OF THE CONTENT DISCUSSED IN THE PRE-READING ASSIGNMENT, BUT INSTEAD FOCUS ON AREAS MOST RELEVANT TO PACKAGE B DATA COMMUNICATIONS.
 - CORRECT YOUR RESPONSE USING THE ANSWER KEY PROVIDED AND ASK YOUR INSTRUCTOR TO REVIEW ANY TERMS THAT MAY NEED FURTHER EXPLANATION OR CLARIFICATION. NO SCORE WILL BE RECORDED FOR STUDENT PERFORMANCE ON THIS SELF-TEST.

Data Communications Overview/Self-Test **GTE**

(Continued)

GTE OMNI SBCS

MATCH THE FOLLOWING ITEMS:

<u>TERMS</u>	<u>DEFINITIONS</u>
1. _____ ANALOG	A. FACTS, NUMBERS, LETTERS, SYMBOLS, ETC. PROCESSED OR PRODUCED BY A COMPUTER
2. _____ SYNCHRONOUS	B. DEVICE WHICH CONVERTS DIGITAL DATA TO ANALOG DATA FOR TRANSMISSION OVER A TELEPHONE LINE, THEN BACK
3. _____ WORD LENGTH	C. TRANSMISSION ERROR CHECKING
4. _____ ECHOPLEX	D. TWO-WAY SIMULTANEOUS TRANSMISSION
5. _____ FULL DUPLEX	E. NUMBER OF BITS IN A BINARY WORD
6. _____ DIGITAL	F. TRANSMISSION RATE FOR DIGITAL DATA
7. _____ TERMINAL	G. LAST BIT IN AN ASYNCHRONOUS TRANSMISSION, USED TO ENSURE RECOGNITION OF NEXT STARTING
8. _____ RS-232-C	H. TRANSMISSION WHERE THE SENDING DEVICE SIGNALS THE RECEIVING DEVICE BEFORE IT TRANSMITS EACH BYTE OF DATA
9. _____ HALF DUPLEX	I. CHARACTERS ARE DISPLAYED OR REFLECTED BACK ON SCREEN FOR ERROR CONTROL (AS THEY ARE TYPED) PRIOR TO TRANSMISSION TO ANOTHER TERMINAL
10. _____ MODEM	J. AN INPUT/OUTPUT DEVICE FOR SENDING OR RECEIVING DATA
11. _____ BITS PER SECOND	K. DATA TRANSMITTED IN A CONTINUOUSLY, VARYING SIGNAL; VOICE TRANSMISSION
12. _____ ASYNCHRONOUS	
13. _____ PARITY	
14. _____ STOP BIT	
15. _____ DATA	

Data Communications Overview/Self-Test (Continued)



GTE OMNI SBCS

DEFINITIONS (Continued)

- L. TWO-WAY TRANSMISSION NOT OCCURRING SIMULTANEOUSLY, WHICH REQUIRES TURNAROUND TIME
- M. DATA TRANSMITTED IN BINARY FORM, USING A PATTERN OF O's AND I's OR MARKS AND SPACES
- N. TRANSMISSION WHERE SENDING AND RECEIVING DEVICES TRANSMIT AND RECEIVE DATA AS A RESULT OF AGREED UPON CLOCK SIGNALS
- O. THE STANDARD CABLE INTERFACE BETWEEN DATA TERMINALS AND DATA COMMUNICATION (TRANSMISSION) EQUIPMENT

Data Communications Overview/Answer Key




GTE OMNI SBCS

1. K
2. N
3. E
4. I
5. D
6. M
7. J
6. O
9. L
10. B
11. F
12. H
13. c
14. G
15. A

Package B/Data Capabilities

GTE

GTE OMNI SBCS



- OMNI SBCS PROVIDES SIMULTANEOUS, INTERNAL VOICE/DATA COMMUNICATION BASED ON CIRCUIT SWITCHING WITH A NON-BLOCKING DIGITAL SWITCH.
- CUSTOMER-SUPPLIED DATA TERMINALS ARE CONNECTED WITH THE OMNI SBCS USING A CSD DIGITAL TELEPHONE EQUIPPED WITH A DATA TERMINAL ADAPTER, AND A ONE PAIR DIGITAL LINE INTERFACE.
- SYSTEM SUPPORTS ASYNCHRONOUS AND SYNCHRONOUS DATA TRANSMISSION SPEED OF UP TO 19.2 Kbps IN FULL OR HALF-DUPLEX MODES.
- LISTED ON THE FOLLOWING PAGE IS A SUMMARY OF THE KEY DATA FEATURES AVAILABLE WITH PACKAGE B REQUIRED DATA BASE PROGRAMMING FOR THESE FEATURES WILL BE ADDRESSED LATER IN THIS MODULE.

NOTE: REFER TO CSD USER'S GUIDE FOR PACKAGE B FEATURE OPERATION INSTRUCTIONS.




Internal Data Call Connection

GTE OMNI SBCS

- PACKAGE B PROVIDES BASIC INTERNAL DATA SWITCHING ALLOWING DATA CALL CONNECTION (HALF OR FULL DUPLEX) USING THE CSD TELEPHONE'S KEYPAD AND PREPROGRAMMED DATA FEATURE BUTTONS.

CONNECTION PATTERN BETWEEN DATA TERMINALS



Package B Data Features



GTE OMNI SBCS

- . DATA AUTOMATIC ANSWER — . IN THIS MODE, A DATA TERMINAL STATION CAN AUTOMATICALLY ANSWER A DATA CALL WITHOUT USER INTERVENTION.
 - USER CAN CHANGE FROM MANUAL DATA ANSWER MODE USING THE CSD TELEPHONE'S DATA CHANGE FEATURE BUTTON.
- AUTOMATIC DISCONNECT — . ALLOWS A DATA CALL TO BE RELEASED AUTOMATICALLY BY THE CALLING DATA TERMINAL STATION'S CALL RELEASE OPERATION.
- . DATA CLASS OF SERVICE/ — . SIMILAR TO VOICE COS/COR, BUT THIS DATA BASE CLASS OF RESTRICTION — FEATURE ALLOWS OR DENIES DATA TERMINAL STATIONS ACCESS TO SYSTEM DATA FEATURES BASED ON THEIR ASSIGNED COS/COR LEVELS.
- DATATERMINAL STATION — • ALLOWS DATA TERMINAL STATIONS TO BE ASSIGNED FLEXIBLE NUMBERING PLAN — DATA STATION DIRECTORY NUMBERS IN THE SAME MANNER AS VOICE DIRECTORY NUMBERS, USING FLEXIBLE NUMBERING SCHEME.
- DATA CALL INITIATION — • ALLOWS DATA CALLS TO BE PLACED DIRECTLY FROM A CSD TELEPHONE EQUIPPED WITH DATA TERMINAL ADAPTER (DTA) USING THE DATA CALL FEATURE BUTTON IN THE DATA TERMINAL STATION'S ASSOCIATED CSD TELEPHONE.
 - ALLOWS VOICE CALLS TO BE PLACED SIMULTANEOUSLY WHILE A DATA CALL IS IN PROGRESS BY USING THE VOICE/DATA MODE FEATURE BUTTON ON THE DATA TERMINAL STATION'S ASSOCIATED CSD.
 - ALSO ALLOWS DATA CALLS TO BE PLACED SIMULTANEOUSLY WHILE A VOICE CALL IS IN PROGRESS, BY USING THE VOICE/DATA MODE FEATURE BUTTON ON THE DATA TERMINAL STATION'S ASSOCIATED CSD TELEPHONE.



Package B Data Features

GTE OMNI SBCS

- . DATA HOT LINE — ● ALLOWS A DATA TERMINAL STATION TO AUTOMATICALLY PLACE A DATA CALL TO ANOTHER PREDETERMINED DATA TERMINAL STATION WITHOUT DIALING FROM THE TERMINAL'S ASSOCIATED CSD TELEPHONE.
- . VOICE PORT NUMBER DATA — ● ALLOWS A DATA TERMINAL STATION TO PLACE A DATA CALL BY DIALING THE VOICE PORT (STATION DIRECTORY) NUMBER OF THE CSD TELEPHONE ASSOCIATED WITH THE DATA TERMINAL STATION BEING CALLED.
- DATA TERMINAL STATION — GROUP HUNTING
 - ALLOWS A DATA CALL AT AN IDLE STATION IN A DEFINED DATA HUNTING GROUP, AFTER IT ENCOUNTERS A BUSY DATA TERMINAL STATION.
 - PROVIDES THE SAME TYPES OF HUNTING GROUPS (PILOT, CIRCULAR, AND TERMINATING) AS THE VOICE GROUP HUNTING FEATURE.




GTE OMNI SBCS

**PACKAGE B
NEW/ENHANCED CARDS
AND PERIPHERALS**

CPMB (Enhanced Central Processing Unit and Basic Memory Card)



GTE OMNI SBCS




- CPMA (PACKAGE A/SVR 1.0.2.2) and CPMB (PACKAGE B/SVR 1.5.X.X) BOTH INCLUDE:
 - 16 BIT MICROPROCESSOR (INTEL 8086 COMPATIBLE)
 - TWO RS-232-C PORTS:
 - PMP
 - SMDR
 - ROM FOR OPERATING SYSTEM SOFTWARE AND DEFAULT STANDARD DATA BASE
 - RAM FOR CUSTOMIZED DATA BASE (REMAINDER OF RAM RESIDES IN MEMB CARD)
 - REAL TIME CLOCK
- CPM5 (PACKAGE B/SVR 1.5.X.X):
 - SUPPORTS ALL PACKAGE B EQUIPMENT AND FEATURES
 - FUNCTIONS ONLY WITH MEMB CARD



MEMB (Enhanced Memory Card)

GTE OMNI SBCS




- . MEMA (PACKAGE A/SVR 1.0.2.2) AND MEMB (PACKAGE B/SVR 1.5.X.X) BOTH INCLUDE:
 - ROM FOR OPERATING SYSTEM SOFTWARE AND DEFAULT STANDARD DATA BASE
 - RAM FOR CUSTOMIZED DATA BASE (ALSO RESIDES IN CPM CARD)
- . MEMB (PACKAGE B/SVR 1.5.X.X):
 - SUPPORTS PACKAGE B EQUIPMENT AND FEATURES
 - FUNCTIONS ONLY WITH CPMB CARD
 - CONTAINS MORE MEMORY THAN CPMA CARD:

	ROM (IN BYTES)	RAM (IN BYTES)
MEMA	64K	0
MEMB	192K	48K
CPMA/MEMA	256K	96K
CPMB/MEMB	448K	144K

Review of Optional RGEN Card (Ring Generator) Package B Strapping Option



GTE OMNI SBCS



- RGEN CARD IS INSERTED IN MOUNTING SLOT LEFT OF CARD SLOT 00.
- GENERATES RINGING TONES FOR SINGLE LINE TELEPHONE INSTRUMENTS.
- SUPPLIES POWER TO MESSAGE WAITING FEATURE FOR SLT INSTRUMENTS EQUIPPED WITH MESSAGE WAITING LAMP (PACKAGE B).
- MESSAGE WAITING FEATURE FOR SLT IS ACTIVATED THROUGH A STRAPPING OPTION ON THE RGEN CARD. (STRAPPING OPTION INSTRUCTIONS ARE DESCRIBED IN SVR 1.5.X.X, INSTALLATION SECTION).
- RINGING:


FREQUENCY:	2 ± 2 Hz
VOLTAGE:	80 V RMS (NOMINAL)
- MESSAGE WAITING LAMP:

VOLTAGE:	-100 V DC
ON/OFF INTERVAL:	1 SECOND ON, 3 SECONDS OFF

8DTC Card (CSD Telephone/Data Terminal Interface Card)



GTE OMNI SBCS




- 8DTC CARDS CAN BE INSERTED IN SLOTS 00 THROUGH 14 (IF CSD TELEPHONES EQUIPPED WITH DATA TERMINAL ADAPTER (DTA) ARE INSTALLED, ONLY SLOTS 00, 03, 06, 09 AND 12 MAY BE USED).
- SYSTEM CAPACITY OF FIVE 8DTC CARDS.
- 8DTC SPECIFICATIONS:
 - EIGHT CIRCUITS PER CARD (ONLY SIX IF CSD TELEPHONES ARE USED FOR DATA TRANSMISSION)
 - PROVIDES SIMULTANEOUS VOICE/DATA TRANSMISSION CONTROL DATA TRANSMISSION, CONTROL DATA TRANSMISSION, AND POWER FEEDING (-24V) OVER A SINGLE PAIR OF WIRES
 - SUPPORTS CSD DIGITAL TELEPHONES OR CSD TELEPHONES WITH DATA TERMINAL INTERFACES VIA DATA TERMINAL ADAPTER
 - 2000 FEET LOOP LIMIT
 - CHANNEL CAPACITY = 64 KBPS FOR VOICE AND DATA, 8 KBPS FOR TELEPHONE CONTROL
 - LINE BIT RATE = 384 KBPS

CSD Digital Telephone

GTE

GTE OMNI SBCS

- TEN PROGRAMMABLE FEATURE BUTTONS (TWO PREPROGRAMMED DATA COMMUNICATION BUTTONS: DATA CALL AND VOICE/DATA MODE)
- FOUR FIXED FEATURE BUTTONS: SPEAKERPHONE, MUTE, TRANSFER, AND HOLD
- SPEAKERPHONE
- FOUR LINE, 20 CHARACTER LCD DISPLAY
- INTERFACE THROUGH 8DTC CARD
- LINE POWERED
- TWO WIRE:
 - 2 DIGITAL TIP AND RING
- 2,000 FEET LOOP LIMIT
- MAY BE CONNECTED TO BLF/DSS INSTRUMENT & AS CONSOLE
- OPTIONAL DATA TERMINAL ADAPTER (DTA) INSTALLED WITHIN CSD PROVIDES RS-232-C INTERFACE TO CUSTOMER-SUPPLIED DATA TERMINAL.
- SYSTEM CAPACITY OF 40 CSD TELEPHONES (8 CIRCUITS X 5 CARDS) OR 30 CSD TELEPHONES WITH DATA INTERFACE (6 CIRCUITS X 5 CARDS).




DTA Terminal Adapter (DTA)




GTE OMNI SBCS

- INSTALLED IN CSD TELEPHONES REQUIRING DATA APPLICATIONS
- SUPPORTS ASYNCHRONOUS/SYNCHRONOUS RS-232-C INTERFACE
- DATA SPEED = UP TO 19.2 KBPS
- CONNECTS TO CSD TELEPHONE USING ONE 64 KBPSCHANNEL
- POWERED BY SEPARATE AC POWER SUPPLY ADAPTER (9V DC)
- INTERFACES WITH 8DTC CARDS IN SLOTS 00, 03, 06, 09, OR 12.
- CUSTOMER-SUPPLIED DATA TERMINAL, WORK STATION, OR PRINTER CONNECTS TO DTA'S RS-232-C CONNECTOR LOCATED IN REAR OF CSD TELEPHONE).



REAR OF CSD TELEPHONE EQUIPPED WITH DTA




NOTE: REFER TO PACKAGE B, INSTALLATION SECTION FOR INSTRUCTIONS FOR INSTALLING DTA IN CSD TELEPHONE.



Data Terminal Station

GTE OMNI SBCS

- CUSTOMER-PROVIDED MICROCOMPUTER, WORK STATION, CRT TERMINAL, PRINTER, OR MODEM
- INTERFACES TO OMNI SBCS VIA DTA IN CSD TELEPHONE
- DATA STATION DIRECTORY NUMBERING PLAN BEGINS WITH DIRECTORY NUMBER 350
- REQUIRES 25 PIN RS-232-C CONNECTOR CABLE (4, 7, OR 12 PIN CABLE MAY BE USED DEPENDING ON SYSTEM APPLICATION)
- RS-232-C PIN CONFIGURATION MUST BE COMPATIBLE WITH PIN CONFIGURATION OF DTA IN CSD TELEPHONE
- SYSTEM ACCOMMODATES DATA TERMINALS WITH:
 - ASYNCHRONOUS OR SYNCHRONOUS TRANSMISSION
 - HALF OR FULL DUPLEX OPERATION
 - DATA SPEED OF UP TO 19.2 KBPS




NOTE: REFER TO CSD USER'S GUIDE FOR DATA CALL OPERATING INSTRUCTIONS.

Optional External Paging Amplifier Interface



GTE OMNI SBCS



- PROVIDES SYSTEM ACCESS TO CUSTOMER PROVIDED PAGING SPEAKER/AMPLIFIER.
- ALLOWS FOR PAGING TO A MAXIMUM OF 9 PAGING ZONES.
- INTERFACES WITH SYSTEM VIA A 4BWC TRUNK CIRCUIT.

Review Exercise —SVR.1.5.X.X

Overview (4.1)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. OMNI SBCS PACKAGE B DEVELOPMENT PHASE (SVR.1.5.X.X) DIFFERS FROM THE LATER DEVELOPMENT PHASE BY PROVIDING BASIC _____ DATA COMMUNICATIONS ONLY.

2. MATCH EACH OF THE FOLLOWING PACKAGE B FEATURES OR ENHANCEMENTS WITH ITS CORRECT DEFINITION:

- | | |
|--|---|
| _____ EQUAL ACCESS | a. ACCESS TO EXTERNAL SPEAKER/AMPLIFIER |
| _____ SIMULTANEOUS VOICE/DATA TRANSMISSION | b. ACTIVATES LAMP ON SLT TELEPHONES |
| _____ CALL SPLITTING | c. INTERNAL DATA COMMUNICATION BETWEEN ON-SITE, LOW SPEED DATA TERMINALS |
| _____ MASTER CONTROL TELEPHONE | d. CSD TELEPHONE FOR DATA BASE ADMINISTRATION AND MAINTENANCE TASKS |
| _____ BASIC DATA SWITCHING | e. VOICE AND DATA AT SAME TIME OVER CSD TELEPHONE'S SINGLE PAIR WIRING |
| _____ ENHANCED PAGING | f. CAPABILITY OF TALKING TO EITHER CALLED OR CALLING PARTY WITHOUT HEARING THE OTHER'S CONVERSATION |
| _____ MESSAGE WAITING FOR SLT INSTRUMENTS | g. AUTOMATIC TRUNK CONNECTION TO CARRIER IN GEOGRAPHIC AREAS WHERE SERVICE IS AVAILABLE |

Review Exercise — SVR.1.5.X.X

Overview (4.1) (Continued)



GTE OMNI SBCS

3. _____ ASYNCHRONOUS TRANSMISSION IS:

- a. TWO-WAY SIMULTANEOUS TRANSMISSION
- b. **TRANSMISSION** WHERE THE SENDING DEVICE SIGNALS THE RECEIVING DEVICE BEFORE IT TRANSMITS EACH BYTE OF DATA
- c. TRANSMISSION ERROR CHECKING
- d. DATA TRANSMITTED IN A CONTINUOUSLY, VARYING SIGNAL

4. (TRUE OR FALSE) _____ DATA TERMINALS MUST BE CONNECTED TO A CSD TELEPHONE PROGRAMMED AS A MASTER CONTROL TELEPHONE.

5. MATCH EACH OF THE FOLLOWING PACKAGE B DATA FEATURES WITH ITS CORRECT DEFINITION:

- | | |
|--|---|
| _____ DATA HOT LINE | a. RELEASES A DATA CALL AUTOMATICALLY BY THE CALLING STATION'S CALL RELEASE OPERATION |
| _____ AUTOMATIC DISCONNECT | b. ALLOWS OR DENIES DATA TERMINAL STATIONS ACCESS TO SYSTEM DATA FEATURES BASED ON ASSIGNED LEVELS |
| _____ DATA TERMINAL GROUP HUNTING | c. ALLOWS A DATA TERMINAL STATION TO BE AUTOMATICALLY CONNECTED TO ANOTHER PREDETERMINED DATA TERMINAL STATION |
| _____ DATA CLASS OF SERVICE/
CLASS OF RESTRICTION | d. ALLOWS A DATA CALL TO CALL AT AN IDLE STATION IN A DEFINED DATA TERMINAL STATION SELECTION GROUP AFTER IT ENCOUNTERS A BUSY SIGNAL |

6. THE PRIMARY ENHANCEMENT INCLUDED ON THE CPMB CARD IS ITS SUPPORT OF ALL _____ EQUIPMENT AND FEATURES.

7. (TRUE OR FALSE) -THE MEMBCARD FUNCTIONS ONLY WITH THE CPMB CARD AND CONTAINS MORE THAN TWICE THE MEMORY OF THE MEMA CARD.



GTE OMNI SBCS

PACKAGE B INSTALLATION

4.2 Enabling Objective



GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS (PREVIOUSLY INSTALLED)
- GTE OMNI SBCS PACKAGE B EQUIPMENT AND PERIPHERALS
 - CPMB, MEMB, 8DTC, AND RGEN CARDS
 - CSD TELEPHONES
 - CSD DATA ADAPTERS (DTA)
 - DATA TERMINALS/WORK STATIONS
 - EXTERNAL PAGING AMPLIFIER
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- STANDARD INSTALLATION TOOLS
- REVIEW EXERCISE

ACTION:

- INSERT AND SEAT PACKAGE B CARDS AND ACTIVATE STRAPPING OPTION ON RGEN CARD FOR MESSAGE WAITING FEATURE ON SLT INSTRUMENTS.
- INSTALL DATA ADAPTER IN CSD TELEPHONES.
- INSTALL CSD TELEPHONE AND WIRE CROSS CONNECTIONS.
- CONNECT DATA TERMINALS TO CSD TELEPHONES.
- INSTALL EXTERNAL PAGING AMPLIFIER AND WIRE CROSS CONNECTIONS.
- COMPLETE REVIEW EXERCISE.


CRITERIA:

- ENHANCED CARDS AND NEW PERIPHERALS WILL BE INSTALLED IN ACCORDANCE WITH STUDENT WORKBOOK AND GTE OMNI SBCS GTEP MANUAL.
- REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Package B Card Installation



GTE OMNI SBCS




PROCEDURE

1. GROUND YOURSELF PRIOR TO HANDLING CARDS.
2. SINCE SYSTEM POWER MUST BE TURNED OFF WHEN INSTALLING OR REPLACING CPMB OR MEMB CARDS, OFFICE DEPENDENT DATA BASE WILL BE DELETED AND CUSTOMIZED DATA BASE MUST BE REPROGRAMMED.
3. IF MESSAGE WAITING ON SLT INSTRUMENTS IS REQUIRED, CUT STRAP OR SLIDE SWITCH ON RGEN CARD.
4. INSTALL CARDS AFFECTED BY PACKAGE B IN DESIGNATED SLOTS:
RGEN — RGEN SLOT
8DTC — SLOTS 00 THROUGH 14 (IF DTA IS INSTALLED, USE SLOTS 00, 03, 06, 09, OR 12)
CPMB — SLOT 20
MEMB — SLOT 21
5. INITIALIZE CARDS BY COLD RESTARTING SYSTEM. PRESS RESTART BUTTON WITH TOGGLE IN UPPER POSITION ON CPMB CARD.
6. REPROGRAM THE SYSTEM IF CPMB, MEMB, OR RGEN CARDS HAVE BEEN REPLACED.

Data Terminal Adapter (DTA) Installation



GTE OMNI SBCS



PROCEDURE1

- INSTALLATION OF DATA ADAPTER (DTA) IN CSD TELEPHONE ALLOWS RS-232-C INTERFACE CONNECTION TO A CUSTOMER-SUPPLIED TERMINAL OR WORK STATION.
- REFER TO FOLLOWING PAGE FOR DTA INSTALLATION PROCEDURE.

Data Adapter (DTA) Installation (Continued)



GTE OMNI SBCS

PROCEDURE

1. ENSURE THAT YOU ARE WEARING A GROUNDED ANTI-STATIC WRIST STRAP.
2. REMOVE THE DTA, AC POWER SUPPLY ADAPTER, TWO GROUNDING WIRES, FIVE WASHERS, AND THREE SCREWS FROM PACKAGE.
3. REMOVE UPPER CASE AND MASKING PLATE FROM CSD TELEPHONE.
4. INSTALL TWO GROUNDING WIRES TO CSD CONTROL CIRCUIT CARD. GROUNDING WIRE A IS TWO INCHES IN LENGTH AND WIRE B IS EIGHT AND FIVE-EIGHTHS INCHES IN LENGTH. ATTACH WIRES WITH ONE WASHER AND SCREW, IN FOLLOWING SEQUENCE: WASHER, WIRE, AND SCREW.
5. PLACE THE DTA ON THE BOSSES, THEN CONNECT THE TWO GROUNDING WIRES TO THE DTA WITH THE TWO WASHERS AND SCREWS USED TO FASTEN THE DTA TO THE BOSSES.
6. INSTALL THE THIRD WASHER AND SCREW USED TO FASTEN THE DTA TO THE BOSSES.
7. CONNECT THE CONNECTOR FROM THE DTA TO THE CONNECTOR ON THE CONTROL CIRCUIT CARD.
8. REPLACE THE CSD TELEPHONE'S UPPER CASE.
9. PLUG THE POWER ADAPTER CORD INTO THE AC POWER JACK ON THE REAR OF THE CSD TELEPHONE.
10. PLUG THE AC POWER SUPPLY ADAPTER INTO AN AC POWER OUTLET.
11. PROCEED WITH CSD TELEPHONE INSTALLATION AND CROSS CONNECTION.


CSD Telephone Installation



- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CSD TELEPHONE.
- EACH CSD TELEPHONE REQUIRES ONLY ONE PAIR OF WIRES FOR TIP AND RING (SIMILAR TO SLT CROSS CONNECTIONS). ON THE CDF TERMINAL BLOCK, ONLY EVERY OTHER PAIR OF WIRES IS USED.
- EXAMPLE ILLUSTRATES CDF CROSS CONNECTION FOR AN 8DTC INTERFACE CARD IN SLOT 00, USING CABLE NUMBER (CN) 0. CONNECTOR BLOCK SHOWN WOULD HANDLE ALL EIGHT CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECT REFERENCE CHART IN OF STUDENT WORKBOOK, INSTALLATION MODULE FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.


GTE OMNI SBCS

25 PAIR CDF BLOCK




TIP
RING

MODULAR JACK




GREEN
RED

MODULAR CABLE



TYPICAL CSD CROSS CONNECTION




25 PAIR CABLE



Data Terminal Installation

GTE OMNI SBCS

DESCRIPTION




- **REQUIRES FOLLOWING PIECES OF EQUIPMENT:**
 - **CUSTOMER SUPPLIED DATA TERMINAL, WORK STATION, OR PRINTER**
 - **CSD TELEPHONE WITH INSTALLED DATA TERMINAL ADAPTER (DTA)**
 - **AC POWER SUPPLY ADAPTER**
 - **CSD TO DATA TERMINAL CABLE**

Data Terminal Installation (Continued)



GTE OMNI SBCS

DESCRIPTION (Continued)



- DATA TERMINAL'S RS-232-C PORT PIN CONFIGURATION MUST BE COMPATIBLE WITH PIN CONFIGURATION FOR RS-232-C PORT ON CSD TELEPHONE'S DATA TERMINAL ADAPTER (DTA), AS LISTED BELOW:

<u>PIN CONFIGURATION</u>	<u>SIGNAL</u>	<u>DESCRIPTION</u>
1	FG	PROTECTIVE GROUND
2	TD	TRANSMITTED DATA
3	RD	RECEIVED DATA
4	RTS	REQUEST TO SEND
5	CTS	CLEAR TO SEND
6	DSR	DATA SET READY
7	SG	SIGNAL GROUND (COMMON GROUND)
8	RLSD	RECEIVED LINE SIGNAL DETECTOR
9		
10		
11		
12		
13		
14		
15	ST2	TRANSMISSION SIGNAL ELEMENT TIMING
16		
17		
18		
19		
20	DTR	DATA TERMINAL READY
21		
22	RI	RING INDICATOR
23		
24		
25		




Data Terminal Installation (Continued)



GTE OMNI SBCS

PROCEDURE

1. ENSURE THAT DTA IS INSTALLED IN CSD TELEPHONE.
2. PLUG DATA TERMINAL POWER CABLE INTO THE POWER OUTLET.
3. CONNECT CSD AND DATA TERMINAL WITH THE CSD TO DATA TERMINAL CABLE.





Data Terminal Installation (Continued)



GTE OMNI SBCS

PROCEDURE

4. PLUG THE AC POWER SUPPLY ADAPTER INTO THE POWER OUTLET.
5. PLUG THE ROUND END OF THE AC POWER SUPPLY ADAPTER INTO THE CSD TELEPHONE.



NOTE: REFER TO OPERATIONS MANUAL SUPPLIED WITH CUSTOMER-SUPPLIED DATA TERMINAL FOR OPERATING INSTRUCTIONS.

Message Waiting on SLT Instruments




GTE OMNI SBCS

DESCRIPTION

- MESSAGES CAN BE LEFT AT SLT INSTRUMENTS (DIAL PULSE OR DTMF) EQUIPPED WITH MESSAGE WAITING LAMPS.
- MESSAGE WAITING FEATURE FOR SLT INSTRUMENTS IS ACTIVATED THROUGH A STRAPPING OPTION ON THE RGEN CARD AND TWO DATA BASE COMMANDS.

PROCEDURE

1. CUT STRAPPING JUMPER ON RGEN CARD (SEE DIAGRAM) OR IF EQUIPPED, SLIDE MESSAGE WAITING SWITCH (LOCATED IN SAME PLACE) TO ON.
2. ACTIVATE MESSAGE WAITING ON SLT INSTRUMENTS FOR SYSTEM WITH CMC-102. (REFER TO PACKAGE B, DATA BASE ADMINISTRATION SECTION).
3. IDENTIFY DIRECTORY NUMBERS OF SLT INSTRUMENTS TO BE ASSIGNED MESSAGE WAITING FEATURE WITH CMC-204. (REFER TO PACKAGE B, DATA BASE ADMINISTRATION SECTION).






Optional External Paging Installation


GTE OMNI SBCS

- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A CUSTOMER-SUPPLIED EXTERNAL PAGING AMPLIFIER.
- EXTERNAL PAGING REQUIRES ONE PAIR OF WIRES FOR ITS INTERFACE TO A 4BWC CARD (SAME AS CO TRUNK INSTALLATION). EACH 4BWC CARD HAS FOUR CIRCUITS AND ONLY EVERY OTHER PAIR OF PINS IS USED ON THE CONNECTING BLOCK.
- OPERATION MAY REQUIRE 24 VOLT POWER SUPPLY (DEPENDENT ON CUSTOMER-SUPPLIED EQUIPMENT)




25 PAIR CABLE

25 PAIR CDF BLOCK



TIP RING



CN	CS	CONNECTING BLOCK PINS			
4	8	26.1	28.3	30.5	32.7
	9				
	12				
6	7	42.17	4.19	46.21	40.23
	10				
8	13	34.9	36.11	38.13	40.15
	11				
5	6	26.1	28.3	20.5	32.7
7	14				
	15				
9	16	34.9	36.11	38.13	40.15
	17				
	18				
10	19	42.17	44.19	46.26	48.23
	20				
11	21	26.1	28.3	30.5	32.7
	22				

REFER TO CDF CROSS CONNECT REFERENCE CHART IN STUDENT WORKBOOK FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.

Laboratory Activity — Package B

Installation (4.2)



GTE OMNI SBCS

1. POWER SYSTEM OFF.
2. ENSURE THAT PROPER ELECTROSTATIC GROUNDING PROCEDURES ARE FOLLOWED PRIOR TO HANDLING PCB CARDS.
3. BEGIN REPLACING AND INSTALLING THE DESIGNATED PRINTED CIRCUIT BOARDS IN CARD SLOTS IDENTIFIED BELOW (IF NOT PREVIOUSLY INSTALLED IN MODULE I). ENSURE THAT CARD COMPONENTS ARE ON LEFT SIDE OF THE BOARDS.
 - (A) INSERT AND SEAT AN INTERFACE CARD FOR CSD/DTA INSTRUMENTS (8DTC) IN CARD SLOT 00.
 - (B) REPLACE THE CPMA CARD IN SLOT 20 WITH THE ENHANCED CONTROL PROCESSOR MEMORY CARD (CPMB).
 - (C) REPLACE THE MEMA CARD IN SLOT 21 WITH THE ENHANCED MEMORY CARD (MEMB).
4. REMOVE THE RING GENERATOR (RGEN). CUT STRAP OR SLIDE SWITCH ON CARD TO ACTIVATE MESSAGE WAITING FOR SLT INSTRUMENTS. INSERT AND SEAT RGEN WITH CARD COMPONENTS ON RIGHT SIDE OF THE BOARD.
5. INSTALL DATA TERMINAL ADAPTERS IN TWO CSD TELEPHONES.
6. WIRE CROSS CONNECTIONS AND INSTALL CSD TELEPHONES USING THESE DESIGNATED CONFIGURATIONS (IF NOT PREVIOUSLY INSTALLED IN MODULE I).
 - (A) CSD TELEPHONE USING 8DTC CARD IN SLOT 00, CIRCUIT 0. DEFAULT DIRECTORY NUMBER WILL BE 200 (VOICE).
 - (B) CSD TELEPHONE USING 8DTC CARD IN SLOT 00, CIRCUIT 1. DEFAULT DIRECTORY NUMBER WILL BE 201 (VOICE).
7. LABEL EACH INSTRUMENT WITH THE APPROPRIATE STATION DIRECTORY NUMBER AND EQUIPMENT NUMBER (CARD SLOT AND CIRCUIT NUMBER).
6. INSTALL DATA TERMINAL STATIONS TO BOTH CSD TELEPHONES.

Laboratory Activity — Package B Installation (4.2) (Continued)



GTE OMNI SBCS

9. WIRE CROSS CONNECTION AND INSTALL EXTERNAL SPEAKER TO 4BWC CARD IN SLOT 18, CIRCUIT 3.
10. POWER SYSTEM ON AND RESET SYSTEM BY PRESSING RESTART BUTTON ON CPMB CARD WITH TOGGLE SWITCH IN CENTER POSITION.
11. REPROGRAM THE ODDB.

Review Exercise — Package B

Installation (4.2)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E. STUDENT WORKBOOK, NOTES AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. (TRUE OR FALSE) _____ CPMB CAN BE INSTALLED AS A COMMON CONTROL CARD WITH SWC AND **MEMA** CARDS.
2. (TRUE OR FALSE) _____ 'REPLACING CPMB OR MEMB AUTOMATICALLY DELETES THE ODDB.
3. INSTALLATION OF THE DTA REQUIRES _____ GROUNDING WIRES.
4. (TRUE OR FALSE) _____ THE DTA OBTAINS ITS POWER DIRECTLY FROM THE CSD INSTRUMENT.
5. A CSD TELEPHONE CROSS CONNECTED TO THE SECOND CIRCUIT OF AN 8DTC INSTALLED IN SLOT 03 WOULD USE PINS - A N D ___ ON THE CDF TERMINAL BLOCK.
6. INDICATE WHICH OF THE FOLLOWING PIECES OF EQUIPMENT ARE REQUIRED FOR INTERNAL DATA TERMINAL INSTALLATION: _____
 - a. CSD TO DATA TERMINAL CABLE, MODEM, DATA TERMINAL, AND CSD TELEPHONE.
 - b. CSD TELEPHONE WITH DTA, AC POWER SUPPLY ADAPTER, DATA TERMINAL, AND CSD TO DATA TERMINAL CABLE.
 - c. AC POWER SUPPLY, MASTER CONTROL TELEPHONE, DATA TERMINAL, AND CODEC.
 - d. CSD TO DATA TERMINAL CABLE, DATA TERMINAL, CSD TELEPHONE, AND AC POWER SUPPLY.
7. THE MESSAGE WAITING OPTION ON THE RING GENERATOR IS INSTALLED BY: (1) CUTTING A STRAPPING JUMPER
OR, (2) _____
8. AN EXTERNAL PAGING AMPLIFIER CROSS CONNECTED TO THE THIRD CIRCUIT OF A **4BWC** CARD INSTALLED IN SLOT 15 WOULD USE PINS - A N D _____ ON THE CDF TERMINAL BLOCK.

Review Exercise — Package B Installation (4.2) (Continued)



GTE OMNI SBCS

9. What card slots may be used for 8DTC cards when CSD telephones are installed without Data Terminal Adapters?

10. Identify the correct descriptions for the RS-232-C pin configuration required for the RS-232-C port on a CSD equipped with a DTA:

PIN	SIGNAL	DESCRIPTION
1	FG	PROTECTIVE GROUND
2	TD	
3	RD	RECEIVED DATA
4	RTS	
5	CTS	
6	DSR	DATA SET READY
7	SC	SIGNAL GROUND
8	RLSD	
9
10
11
12
13
14
15	ST2	TRANSMISSION SIGNAL
16
17	-mm-w-
18
19
20	DTR	
21
22	RI	
23
24
25



GTE OMNI SBCS

**PACKAGE B
DATA BASE
ADMINISTRATION**



4.3 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PACKAGE B EQUIPMENT AND PERIPHERALS
 - PORTABLE MAINTENANCE PANEL
 - OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - REVIEW EXERCISE
- ACTION:**
- IDENTIFY FUNCTIONS AND APPLICATIONS OF PACKAGE B CMC COMMANDS.
 - MODIFY PARAMETER VALUES FOR PACKAGE B CMC COMMANDS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Data Switching Programming



GTE OMNI SBCS

DESCRIPTION

- INTERNAL DATA COMMUNICATIONS CAN BE ACCOMMODATED FOR CSD TELEPHONES EQUIPPED WITH A DATA ADAPTER (DTA) USING AN RS-232-C INTERFACE BETWEEN THE CSD AND A CUSTOMER SUPPLIED DATA TERMINAL STATION.
- CALLS CAN BE ESTABLISHED AS VOICE ONLY, DATA ONLY, OR SIMULTANEOUS VOICE/DATA.
- SYSTEM PROVIDES ASYNCHRONOUS OR SYNCHRONOUS COMMUNICATION IN FULL OR HALF DUPLEX MODES WITH SPEEDS OF UP TO 19,200 BPS. DATA TERMINAL STATION ATTRIBUTES FOR BOTH THE SENDING AND RECEIVING TERMINALS MUST BE MADE COMPATIBLE WITHIN THE SYSTEM DATA BASE.
- DATA TERMINAL STATIONS CAN BE PROGRAMMED TO INITIATE DATA CALLS IN AUTO ORIGINATE OR MANUAL ORIGINATE MODE AND RECEIVE DATA CALLS IN AUTO ANSWER OR MANUAL ANSWER MODE.
- DATA CALLS CAN BE RELEASED USING EITHER NORMAL DICONNECT OR AUTOMATIC DICONNECT MODES.
- DATA TERMINAL STATIONS ARE ASSIGNED DATA TERMINAL STATION DIRECTORY NUMBERS USING A FLEXIBLE NUMBERING PLAN SEPARATE FROM THE VOICE STATION DIRECTORY NUMBERING PLAN.
- OPTIONAL DATA FEATURES INCLUDE ASSIGNMENT TO CLASS OF SERVICE LEVELS FOR DATA TERMINAL STATIONS, ASSIGNMENT TO DATA TERMINAL STATION HUNT GROUPS, OR ESTABLISHMENT OF DATA TERMINAL STATION HOT LINES.
- DATA TERMINAL STATIONS CAN BE ASSIGNED TO TENANT AND METERING GROUPS.

Data Switching Programming



GTE OMNI SBCS

PROCEDURE

1. INSTALL DATA ADAPTERS (DTA) IN CSD TELEPHONES TO BE CONNECTED TO DATA TERMINAL STATIONS.
2. INSTALL CSD INSTRUMENTS. ENSURE THAT CSD INSTRUMENTS WITH DATA 8DTC CARDS INSERTED IN SLOTS 00, 03, 06, 09 OR 12. CONNECT DATA TERMINALS STATIONS TO RS-232-C INTERFACE IN REAR OF CSD TELEPHONES.
3. ASSIGN CSD TELEPHONES AS VOICE STATIONS AND DESIGNATE APPROPRIATE SERVICE USING CMC-201, 202, 203, AND 204.

NOTE: REFER TO STUDENT WORKBOOK, DATA BASE ADMINISTRATION MODULE, FOR DESCRIPTIONS AND PROCEDURES.

4. ASSIGN DATA TERMINAL STATION WITH CMC-220:
 - . EQUIPMENT NUMBER (P1)
 - . DIRECTORY NUMBER OF DATA STATION (Pi)
 - . DATA INTERFACE TYPE (P3)
 - . DIRECTORY NUMBER OF CORRESPONDING VOICE STATION (P4)

CMC=220
P1:006 P4:206
P2:3648
P3:1

5. ASSIGN DATA TERMINAL STATION CLASS OF SERVICE/CLASS OF RESTRICTION LEVELS WITH CMC-221:
 - DIRECTORY NUMBER OF DATA STATION (P1)
 - . DAY CLASS OF SERVICE (P2) — (DEFAULT = 1)
 - NIGHT CLASS OF SERVICE (P3) — (DEFAULT = 1)
 - . DAY CLASS OF RESTRICTION (P4) — (DEFAULT = 1)
 - . NIGHT CLASS OF RESTRICTION (P5) — (DEFAULT = 1)

CMC=221
P1:3648 P4:1
P2:1 P5:3
P3:3

Data Switching Programming (Continued)



GTE OMNI SBCS

6. ASSIGN OR MODIFY FAULT DATA TERMINAL STATION ATTRIBUTES WITH CMC-222:

- DIRECTORY NUMBER OF DATA TERMINAL STATION (P1)
- DATA SPEED (P2) — (DEFAULT = 1200 BPS)
- SYNCHRONIZATION AND COMMUNICATIONS (P3) — (DEFAULT = ASYNCHRONOUS/FULL DUPLEX)
- WORD STRUCTURE (P4) — (DEFAULT = STOP BIT-1 BIT,)
- PARITY (P5) (DEFAULT = SPACE)
- ECHOPLEX (P6) (DEFAULT = NOT USED)

CMC=222	
P1:3648	P4:4
P2:5	P5:3
P3:3	P6:0

7. ASSIGN RS-232-C INTERFACE SIGNAL MODE WITH CMC-223:

- DIRECTORY NUMBER OF DATA TERMINAL STATION (P1)
- CALL CONTROL MODE (P2) — (DEFAULT = MANUAL ORIGINATE AND ANSWER MODES, NORMAL DISCONNECT MODE, AND ONE RING OPTION IN AUTO ANSWER NOT USED)
- RS-232-C INTERFACE SIGNAL/MODE 1 (P3) — (DEFAULT = DTR-NORMAL, RTS-NORMAL, AND DSR-NORMAL)
- RS-232-C INTERFACE SIGNAL/MODE 2 (P4) — (DEFAULT = R1 OPTION-STEADY ON)

CMC=223	
P1:3648	P4:0
P2:0111	
P3:111	

8. ASSIGN DATA TERMINAL STATION OPERATION MODE, DIAL MODE, TENANT GROUP AND METERING GROUP NUMBERS WITH CMC-224:

- DIRECTORY NUMBER OF DATA TERMINAL STATION (P1)
- OPERATION MODE (P2) — DEFAULT = TWO-WAY
- DIAL MODE (P3) — (DEFAULT = TELEPHONE DIAL)
- TENANT NUMBER (P4) — (DEFAULT = BLANK)
- METERING GROUP NUMBER (P5) — (DEFAULT = BLANK)

CMC=224	
P1:3648	P4:
P2:1	P5:
P3:0	

9. IF DESIRED, ASSIGN DATA TERMINAL STATIONS TO DATA HUNT GROUPS WITH CMC-301:

- DATA TERMINAL STATION HUNT GROUP NUMBER (P1)
- TERMINATING (P2)
- DIRECTORY NUMBER OF DATA TERMINAL HUNT GROUP NUMBER (P3)
- HUNT GROUP TYPE (P4)

CMC=301	
P1:51	P4:2
P2:2	
P3:3648	

Data Switching Programming (Continued)



GTE OMNI SBCS

10. IF APPLICABLE, ASSIGN DATA TERMINAL STATIONS TO HOT LINE SERVICE WITH CMC-304:

- . DATA HOT LINE NUMBER (P1) — (51-90)
- . ORIGINATING DATA TERMINAL STATION (P2)
- . TERMINATING DATA TERMINAL STATION (P3)

CMC=304 P1:51 P2:3648 P3:3661
--

NOTE: REFER TO STUDENT WORKBOOK, DATA BASE ADMINISTRATION MODULE FOR HUNT GROUP AND HOT LINE SERVICE FEATURE DESCRIPTIONS.

External Speaker Paging Assignment



GTE OMNI SBCS

DESCRIPTION

- . EXTERNAL PAGING IS ACCOMPLISHED BY UTILIZING CUSTOMER-SUPPLIED SPEAKER/AMPLIFIERS.
- PAGING IS ACTIVATED BY DEPRESSING A FEATURE BUTTON OR DIALING AN ACCESS CODE AND ZONE NUMBER.
- . PAGING AMPLIFIERS ARE PROGRAMMED FOR A MAXIMUM OF 9 PAGING ZONES.

PROCEDURE

1. INSERT 4BWC CARD AND INSTALL EXTERNAL SPEAKER/AMPLIFIER WITH APPROPRIATE CROSS CONNECTIONS (REFER TO PACKAGE B, INSTALLATION SECTION).
2. ASSIGN EQUIPMENT NUMBER AS EXTERNAL PAGING TRUNK CIRCUIT WITH CMC-250.
 - . EQUIPMENT NUMBER (P1)
 - . TYPE OF TRUNK (P2)
 - . TRUNK GROUP NUMBER (P3)
 - . OPERATION MODE (P4)
 - . SIGNALING (P5)
 - . ZONE NUMBER (P6)

CMC=250	
P1:182	P4:3
P2:9	P5:1
P3:3	P6:1

External Speaker Paging Assignment (Continued)



GTE OMNI SBCS

3. IF APPLICABLE, CHANGE FEATURE ACCESS CODES FOR EXTERNAL PAGE ACCESS AND ENTER WITH CMC-100:

- . FEATURE NUMBER (P1)
- . FEATURE ACCESS CODE (P2)

CMC=100
P1:51
P2:**

4. IF APPLICABLE, CHANGE EXTERNAL PAGING WARNING BURST TIMING WITH CMC-103:

- . IDENTIFICATION FOR TIMING (P1)
- MULTIPLIER (P2)

CMC=103
P1:45
P2:1

Message Waiting for SLT Programming



GTE OMNI SBCS

DESCRIPTION

- . PACKAGE B ACCOMMODATES THE MESSAGE WAITING LAMP FEATURE FOR SLT INSTRUMENTS USING SYSTEM ACCESS CODE.
- . FEATURE FIRST MUST BE ACTIVATED ON SYSTEM AND THEN ASSIGNED TO SLT INSTRUMENTS ON AN INDIVIDUAL BASIS.

PROCEDURE

1. ACTIVATE MESSAGE WAITING FOR SLT INSTRUMENTS WITH CMC-102:
 - . FLAG NUMBER (P1)
 - . SET VALUE (P2)
2. ASSIGN MESSAGE WAITING FEATURE TO INDIVIDUAL SLT INSTRUMENTS EQUIPPED WITH LAMP USING CMC-204:
 - . STATION DIRECTORY NUMBER (P1)
 - . SLT WITH MESSAGE WAITING LAMP IDENTIFICATION (P4)

CMC=102
P1:15
P2:1

CMC=204
P1:218 P4:1
P2:
P3:



Access Codes/Package B

GTE OMNI SBCS

DESCRIPTION

- DEFAULT ACCESS CODES FOR THE FOLLOWING PACKAGE B FEATURES CAN BE MODIFIED IF DESIRED:
- EKT PAGING ANSWER (FNO 52, ACCESS CODE = 87)
- EXTERNAL PAGING ACCESS (FNO 53, ACCESS CODE = 78)
- EXTERNAL PAGING ANSWER (FNO 54, ACCESS CODE = 88)
- DATA CALL ATTRIBUTE CHANGE (FNO 117, ACCESS CODE = 69)
- ADD DATA CALL (FNO 160, ACCESS CODE = 67)

PROCEDURE

1. CHANGE FEATURE ACCESS CODE NUMBERS WITH CMC-100:
 - FEATURE NUMBER (P1)
 - FEATURE ACCESS CODE (P2)

CMC=100
P1:54
P2:##

NOTE: P3 — P6 ARE NOT APPLICABLE FOR THESE FEATURES.

System Parameters/Package B



GTE OMNI SBCS

DESCRIPTION

- PACKAGE B MAY REQUIRE MODIFICATION OF SETTINGS FOR FOLLOWING APPLICABLE SYSTEM PARAMETER FLAGS:
 - POUND CODE TREATMENT FOR TIE OR CO TRUNKS (FLAG NUMBERS 13 AND 14)
 - ACTIVATION OF MESSAGE WAITING FOR SLT INSTRUMENTS (FLAG NUMBER 15)
 - NUMBER OF DIGITS TO BE SENT AS ACCOUNT CODES FOR SYSTEM SPECIALIZED COMMON CARRIERS (FLAG NUMBERS 16 - 21).

PROCEDURE

1. CHANGE SYSTEM PARAMETER FLAGS WITH CMC-102:
 - FLAG NUMBER (P1)
 - SET VALUE (P2)

CMC=102
P1:15
P2:1

Equal Access Programming



GTE OMNI SBCS

DESCRIPTION

- PACKAGE B ALLOWS SYSTEM DATA BASE TO ACCOMMODATE EQUAL ACCESS IN GEOGRAPHIC AREAS WHERE IT NOW IS AVAILABLE.
- PROGRAMMING REQUIRES BUILDING A RESTRICTION TABLE FOR CARRIER ACCESS CODES (CAC) SIMILAR TO TOLL RESTRICTION TABLES BUILT FOR AREA AND OFFICE CODES (REFER TO STUDENT WORKBOOK, DATA BASE ADMINISTRATION/MULTI-DIGIT RESTRICTION SECTION).
- IF LEAST COST ROUTING IS IMPLEMENTED, OUTGOING CONNECTINGS CAN BE PROGRAMMED TO INCORPORATE ANY CAC NUMBERS TO BE USED FOR LCR ROUTE TABLES.

PROCEDURE

1. BUILD CAC RESTRICTION TABLES BY ASSIGNING CAC NUMBERS AND DESIRED CLASS OF RESTRICTION LEVELS TO RESTRICTION GROUPS USING CMC-415 RESTRICTION GROUPS AND COR ARE THEN ASSOCIATED WITH OTHER TOLL RESTRICTION TABLES):
 - . RESTRICTION GROUP NUMBER (P1)
 - . CLASS OF RESTRICTION (P2)
 - CARRIER ACCESS CODE (P3)
2. ASSIGN TOLL AND OPERATOR RESTRICTIONS FOR SAME RESTRICTION GROUP NUMBER (REFERENCED ABOVE FOR CMC-415) USING CMC-411:
 - . RESTRICTION GROUP NUMBER (P1)
 - CLASS OF RESTRICTION (P2)
 - . FLAG IDENTIFICATION (P3)
 - FLAG VALUE (P4)

CMC=415
P1:1
P2:2
P3:10288

CMC=411
P1:1 P4:1
P2:2
P3:1

Equal Access Programming (Continued)



GTE OMNI SBCS

3. ASSIGN THE DIGIT COMPOSING FLAG FOR THE CAC NUMBER TO THE LCR OFFICE CODE ROUTE TABLES AND TRUNK GROUP NUMBER (PROBABLY A CO TRUNK) USING CMC-420:

- . OFFICE CODE ROUTE TABLE NUMBER (P1)
- . SELECTION SEQUENCE (P2)
- . TRUNK GROUP NUMBER (P3)
- . DIGIT COMPOSING FLAG (P4)

CMC=420
P1:1 P4:14
P2:1
P3:13

4. ASSIGN THE DIGIT COMPOSING FLAG FOR THE CAC NUMBER TO THE LCR AREA AND AREA/OFFICE CODE ROUTE TABLES AND TRUNK GROUP NUMBER USING CMC-421:

- . AREA CODE ROUTE TABLE NUMBER (P1)
- . SELECTION SEQUENCE (P2)
- . TRUNK GROUP NUMBER (P3)
- . DIGIT COMPOSING FLAG (P4)

CMC=421
P1:1 P4:11
P2:1
P3:13

5. ASSIGN THE CARRIER ACCESS CODES (USED IN THE DIGIT COMPOSING FLAGS ABOVE) IF THEY ARE TO BE USED FOR OUTGOING CONNECTIONS MADE BY LCR, USING CMC-425:

- . LEAST COST ROUTING CAC NUMBER (P1)
- . CARRIER ACCESS NUMBER (P2)

CMC=425
P1:1
P2:10288

Laboratory Activity - Package B Data Base; Administration (4.3)



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASK IN THE SEQUENCE OUTLINED BELOW AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS UPON COMPLETION OF THIS LABORATORY ACTIVITY.

WORK ORDER #4.3	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555 1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #4.3 (TASK #1)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
<p>TASKS:</p> <ul style="list-style-type: none"> • ②②① CSD telephone as a voice station with CMC-201, CMC-202, CMC-203 and CMC-204 	
<p>PARAMETERS:</p> <p>(1) Assign both CSD telephones at slot 00, circuits 0 and 1 using CMC-201: Voice Directory Number = 200 and 201 Operation Mode = Bothway Dialing = DTMF</p> <p>(2) Assign voice COS/COR to CSD telephones with CMC-202: COS (day) = 1 COS (night) = 3 COR (day) = 1 COR (night) = 1</p> <p>(3) identify both voice stations as being "data secure" with CMC-204.</p>	<p>INSTRUCTIONS:</p> <p>(1) Perform data base changes</p> <p>(2) Check/test the operation of commands after completion of this portion of the laboratory activity.</p> <p>(3) Proceed with next work order task.</p>

Laboratory Activity - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

WORK ORDER #2.2	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 4.3 (TASK #2)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Assign data terminal station with CMC-220. • Assign data terminal's COS/COR with CMC-221. 	
PARAMETERS: <p>(1) Assign the data terminal stations associated with the CSD telephones at slot 00, circuits 0 and 1 using CMC-220 and the parameters listed below: CMC-200 Equipment number = 000 and 001 Directory Number of Data Stations = 1000 and 1001 Data Interface = DTA Directory Number of Voice Stations = 200 and 201</p> <p>(2) Assign the data terminal's COS/COR using CMC-221 and the parameters listed below: CMC-221 Data Directory Number = 1000 and 1001 COS (day) = 1 COS (night) = 3 COR (day) = 1 COR (night) = 1</p>	INSTRUCTIONS: <p>(1) Perform data base changes. (2) Proceed with next work order task.</p>

Laboratory Activity - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

WORK ORDER #2.2	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #4.3 (TASK #3)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Modify default data terminal station attributes with CMC-222. • Assigns RS-232-C interface mode with CMS-223. 	
PARAMETERS: <p>(1) Assign the data attributes listed below to both data terminals using CMC-222: Data Directory Numbers 1000 and 1001 Data Speed = 300 bps Synchronization/ Communications = Asynchronous, full duplex Word Structure = 1 stop bit, word length - 8 bits Parity = Blank (not assigned) Echoplex = not used</p> <p>(2) Assign the RS-232-C interface signal mode as listed below using CMC-223: Data Directory Numbers = 1000 and 1001 Call Control Mode = manual originate, auto answer forced disconnect and use one ring option in auto answer mode.</p> <p>RS-232-C interface; signal mode 1 = forced in DTR option, forced on RTS option and DSR OFF. RS-232-C interface; signal mode 2 = RI option stand on.</p>	INSTRUCTIONS: <p>(1) Perform data base changes.</p> <p>(2) Proceed with next work order task.</p>

Laboratory Activity - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

WORK ORDER #4.3	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #4.3 (TASK #4)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
ASKS: <ul style="list-style-type: none"> • Assign data terminal mode, dial mode, tenant group and metering group number with CMC-224. 	
PARAMETERS: <p>(1) Assign both data terminal stations to the attributes listed below using CMC-224:</p> <p>Data Directory Numbers 1000 and 1001</p> <p>Operation Mode = Bothway</p> <p>Dial Mode = Tel dial</p> <p>Tenant Number = Blank</p> <p>Metering Group Number = Blank</p>	INSTRUCTIONS: <p>(1) Perform data base changes.</p> <p>(2) Check/test the operation of commands after completion of this portion of the laboratory activity.</p> <p>(3) Proceed with next work order task.</p>

Laboratory Activity - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

WORK ORDER #4.3	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #4.3 (TASK #5)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> ● Assign data terminal stations to hunt groups with CMC-301. ● Assign data terminal stations to hot line service with CMC-304. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Assign both data terminal stations to hunt group number 51 using CMC-301. Identify this group as a circular type of hunting group. (2) Create hot line number 51 using CMC-304. Assign data directory number 1000 as the originating data terminal station and 1001 as the terminating data terminal station. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Perform data base changes. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Proceed with next work order task.

Laboratory Activity - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

WORK ORDER #4.3	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER # 4.3 (TASK #6)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS:	
<ul style="list-style-type: none"> • Assign external speaker to trunk group number with CMC-250. • Activate message waiting for SLT instruments with CMC-102. • Assign message waiting feature to individual SLT instruments with CMC-204. 	
PARAMETERS:	INSTRUCTIONS:
<ol style="list-style-type: none"> (1) Assigns the trunk installed at slot 18, circuit 0 as an external paging speaker using CMC-250. (2) Activate message waiting for SLT instruments with CMC-102 using flag 15. (3) Assign the message waiting feature to directory numbers 216 and 223 using CMC-204. 	<ol style="list-style-type: none"> (1) Perform data base changes. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Complete Review Exercise questions I-I 0.

Review Exercise - Package B Data Base Administration (4.3)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. (TRUE OR FALSE) _____ DATA TERMINAL STATION DIRECTORY NUMBERING PLAN IS SEPARATE FROM THE VOICE STATION DIRECTORY NUMBERING PLAN.
2. INDICATE THE DEFAULT DATA BASE SETTING FOR THE FOLLOWING DATA TERMINAL STATION ATTRIBUTES:
DATA SPEED = _____
SYNCHRONIZATION & COMMUNICATIONS = _____
WORD STRUCTURE = _____
PARITY = _____
ECHOPLEX = _____
3. WHICH TWO VOICE SERVICE FUNCTIONS MAY ALSO BE APPLIED TO DATA TERMINAL STATIONS:

4. EXTERNAL PAGING IS ASSIGNED TO TRUNKS WITH CMC- _____ AFTER A CROSS CONNECTION IS MADE TO A _____ CARD.
5. (TRUE OR FALSE) _____ CMC-102 IS USED TO ASSIGN MESSAGE WAITING TO INDIVIDUAL SLT INSTRUMENTS.
6. IF EQUAL ACCESS OUTGOING CONNECTIONS ARE TO BE MADE BY LCR, CARRIER ACCESS CODES ARE ASSIGNED WITH CMC- _____
7. IF EQUAL ACCESS IS TO BE IMPLEMENTED, WHAT TYPE OF TABLE MUST BE BUILT FOR USE OF TOLL AND MULTI-DIGIT RESTRICTION? _____

Laboratory Activity - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

WORK ORDER #4.3	
COMPANY NAME: NU SYSTEM CO.	PHONE #: (703) 555-1212
LOCATION: RESTON, VIRGINIA	WORK ORDER #4.3 (TASK #6)
ORIGINATOR: TELECOMMUNICATIONS MANAGER	
TASKS: <ul style="list-style-type: none"> • Assign external speaker to trunk group number with CMC-250. • Activate message waiting for SLT instruments with CMC-102. • Assign message waiting feature to individual SLT instruments with CMC-204. 	
PARAMETERS: <ol style="list-style-type: none"> (1) Assigns the trunk installed at slot 18, circuit 0 as an external paging speaker using CMC-250. (2) Activate message waiting for SLT instruments with CMC-102 using flag 15. (3) Assign the message waiting feature to directory numbers 216 and 223 using CMC-204. 	INSTRUCTIONS: <ol style="list-style-type: none"> (1) Perform data base changes. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Complete Review Exercise questions 1-10.

Review Exercise - Package B Data Base Administration (4.3)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. (TRUE OR FALSE) _____ DATA TERMINAL STATION DIRECTORY NUMBERING PLAN IS SEPARATE FROM THE VOICE STATION DIRECTORY NUMBERING PLAN.

2. INDICATE THE DEFAULT DATA BASE SETTING FOR THE FOLLOWING DATA TERMINAL STATION ATTRIBUTES:
DATA SPEED = _____
SYNCHRONIZATION & COMMUNICATIONS = _____
WORD STRUCTURE = _____
PARITY = _____
ECHOPLEX = _____

3. WHICH TWO VOICE SERVICE FUNCTIONS MAY ALSO BE APPLIED TO DATA TERMINAL STATIONS:

4. EXTERNAL PAGING IS ASSIGNED TO TRUNKS WITH CMC- _____ AFTER A CROSS CONNECTION IS MADE TO A _____ CARD.

5. (TRUE OR FALSE) _____ CMC-102 IS USED TO ASSIGN MESSAGE WAITING TO INDIVIDUAL SLT INSTRUMENTS.

6. IF EQUAL ACCESS OUTGOING CONNECTIONS ARE TO BE MADE BY LCR, CARRIER ACCESS CODES ARE ASSIGNED WITH CMC- _____

7. IF EQUAL ACCESS IS TO BE IMPLEMENTED, WHAT TYPE OF TABLE MUST BE BUILT FOR USE OF TOLL AND MULTI-DIGIT RESTRICTION? _____

Review Exercise - Package B Data Base Administration (4.3) (Continued)



GTE OMNI SBCS

8. WHAT IS THE DIGIT COMPOSED FLAG SETTING FOR THE FIRST CARRIER ACCESS CODE USING A CUSTOMER TOLL PREFIX FOLLOWED BY 7 DIGITS? _____
9. (TRUE OR FALSE) _____ DATA TERMINAL STATIONS CAN BE ASSIGNED TO METERING1 GROUPS, BUT NOT TENANT GROUPS.
10. MATCH EACH OF THE FOLLOWING PACKAGE B CMC COMMANDS WITH ITS CORRECT DEFINITION:
- | | |
|---------------|--|
| _____ CMC-102 | A. TRUNK ASSIGNMENT' |
| _____ CMC-220 | B. HOT LINE STATION ASSIGNMENTS |
| _____ CMC-221 | C. CARRIER ACCESS CODE RESTRICTION ASSIGNMENT |
| _____ CMC-222 | D. DATA TERMINAL STATION ATTRIBUTES (DATA SPEED, SYNCHRONIZATION/COMMUNICATIONS, ETC.) |
| _____ CMC-223 | E. DATA TERMINAL STATION COS/COR ASSIGNMENT |
| _____ CMC-224 | F. HUNT GROUP ASSIGNMENT |
| _____ CMC-250 | G. LCR OUTGOING CONNECTIONS CARRIER ACCESS CODE ASSIGNMENT |
| _____ CMC-301 | H. SYSTEM PARAMETER ASSIGNMENT |
| _____ CMC-304 | I. DATA TERMINAL STATION ASSIGNMENT RS-232-C INTERFACE SIGNAL MODE |
| _____ CMC-415 | J. DATA TERMINAL STATION DIRECTORY ASSIGNMENT |
| _____ CMC-425 | K. DATA STATION OPERATION/DIAL MODE ASSIGNMENT |



GTE OMNI SBCS

PACKAGE B MAINTENANCE



4.4 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PERIPHERALS
- CSD TELEPHONE (ASSIGNED AS MASTER CONTROL TELEPHONE IN DATA BASE)
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- REVIEW EXERCISE

ACTION:

- USE MASTER CONTROL TELEPHONE AS AN ALTERNATE DATA BASE ADMINISTRATION AND MAINTENANCE TOOL.
- MODIFY SYSTEM SECURITY CODES IN DATA BASE.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- TASKS WILL BE PERFORMED IN ACCORDANCE WITH PROCEDURES OUTLINED ON OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Master Control Telephone Assignment




GTE OMNI SBCS

DESCRIPTION

- . MAXIMUM OF 4 CSD TELEPHONES CAN BE IDENTIFIED IN SYSTEM DATA BASE AS HAVING MASTER CONTROL TELEPHONE (MCT) CAPABILITIES FOR DATA BASE ADMINISTRATION AND MAINTENANCE ACTIVITIES.
- . CSD TELEPHONES USED AS MASTER CONTROL TELEPHONES DO NOT REQUIRE INSTALLATION OF DATA ADAPTERS (DTA).
- REFER TO PACKAGE B, MAINTENANCE SECTION FOR MCT OPERATION PROCEDURE.

PROCEDURE

1. ASSIGN OR CANCEL MCT DIRECTORY NUMBER IDENTIFICATION WITH CMC-702:
 - MCT NUMBER (PI)
 - . STATION DIRECTORY NUMBER (P2)




NOTE: ATTEMPTS TO DELETE THE MCT BEING USED TO MAKE ENTRIES WILL BE DENIED BY DATA BASE.

Master Control Telephone Operation



GTE OMNI SBCS



PROCEDURE

BUTTON CONFIGURATION OF MASTER CONTROL TELEPHONE

1. ENTER APPROPRIATE HIGH OR LOW LEVEL SECURITY CODE USING KEYBOARD OF A CSD TELEPHONE (ASSIGNED AS MCT) WHILE ON-HOOK AND IN AN IDLE STATE.
2. AT COMMAND PROMPT, ENTER APPROPRIATE CMC COMMAND AND PRESS RETURN (CSD'S TELEPHONE'S HOLD BUTTON).
3. ENTER PARAMETER VALUES USING CSD TELEPHONE'S NUMERIC KEYPAD AND DESIGNATED PROGRAM FUNCTION BUTTONS (ILLUSTRATED ABOVE).
4. PLEASE RELEASE, THEN TERMINATE TO RETURN THE MCT TO NORMAL CALL PROCESSING MODE AS A CSD TELEPHONE.

Security Code Assignment




GTE OMNI SBCS

DESCRIPTION

- PACKAGE B ALLOWS THE DEFAULT HIGH AND LOW LEVEL SECURITY CODES TO BE CHANGED BASED ON CUSTOMER PREFERENCE, OR TO PROTECT AGAINST UNAUTHORIZED DATA BASE ACCESS FROM A PMP OR MCT.
- SECURITY CODES MUST BE FOUR DIGITS IN LENGTH.

PROCEDURE

1. CHANGE DATA BASE SECURITY CODES WITH CMC-704:
 - LOW LEVEL SECURITY CODE (P1)
 - HIGH LEVEL SECURITY CODE (P2)



Laboratory Activity - Package B

Maintenance (4.4)



GTE OMNI SBCS

PERFORM THE FOLLOWING PROGRAMMING TASK IN THE SEQUENCE OUTLINED BELOW AND IN ACCORDANCE WITH THE GTE OMNI SBCS GTEP MANUAL. COMPLETE THE REVIEW EXERCISE QUESTIONS UPON COMPLETION OF THIS LABORATORY ACTIVITY


WORK ORDER #2.10	
<u>COMPANY NAME:</u> NU SYSTEM CO.	<u>PHONE #:</u> (703) 555-1212
<u>LOCATION:</u> RESTON, VIRGINIA	<u>WORK ORDER #4.4 (TASK #1)</u>
<u>ORIGINATOR:</u> TELECOMMUNICATIONS MANAGER	
<u>ASKS:</u> <ul style="list-style-type: none"> • Assign CSD as a Master Control Telephone with CMC-702. • Operate MCT. • Change high and low level security codes with CMC-704. 	
<u>PARAMETERS:</u> <ol style="list-style-type: none"> (1) Assign station as MCT with CMC-702. (2) Using MCT as programming instrument change high level security code to 9999 and low level security code to 2222. (3) After verification, restore security codes back to default settings. 	<u>INSTRUCTIONS:</u> <ol style="list-style-type: none"> (1) Perform maintenance programming commands. (2) Check/test the operation of commands after completion of this portion of the laboratory activity. (3) Use MCT to display current setting for a few CMC command tables. (4) Complete Review Exercise questions 1-6.

Review Exercise - Package B Maintenance (4.4)



GTE OMNI SBCS

1. (TRUE OR FALSE) _____ CSD TELEPHONES USED AS MASTER CONTROL TELEPHONES DO NOT REQUIRE INSTALLATION OF DATA TERMINAL ADAPTERS.
2. UP TO _____ CSD TELPHONES CAN BE DESIGNATED AS MASTER CONROL TELEPHONES.
3. IDENTIFY THE MASTER CONTROL TELEPHONE FUCNTION KEY WHICH CORRESPONDS TO EACH NUMBER BELOW:



BUTTON CONFIGURATION OF
MASTER CONTROL TELPEPHONE



GTE OMNI SBCS

MODULE V
PACKAGE C/SVR 2.0.X.X



Table of Contents

GTE OMNI SBCS

PACKAGE C OVERVIEW

Introduction

Page

- Package C Overview (Objectives) 5.4
- OMNI SBCS Development Phases 5.5
- OMNI SBCS With Package C Interfaces 5.7
- Summary of Features and Enhancements.. 5.8
- Attendant Console Package. 5.9
- Key System Features 5.12
- Enhanced Data Communications Capabilities 5.13
- Hotel/Motel Package 5.14
- Business Features 5.16

Package C Standard and Expanded Architecture

- Standard and Expanded Systems 5.18
- Expanded System Trunk/Station Line Combinations. 5.19
- Package C System Capacities (Standard and Expanded Systems) 5.20
- Expanded System Frame Image/Common Control Cards 5.21
- Expanded System Frame Image/Interface Cards 5.22
- Interface Card Group Configuration 5.23
- Expanded System/Cabinet Card Capacities 5.24

New/Enhanced Cards and Peripherals

- CPMC (Enhanced Central Processing and Basic Memory Card) 5.26
- MEMC (Enhanced Memory Card) 5.27
- SWB (Switch Control Expansion Card) 5.28
- SWE (Switch Control Basic Card) 5.29
- 4CHT (Character Trunk Card) 5.30
- PFE (Power Failure Transfer Expansion Card) 5.31



Table of Contents (Continued)

GTE OMNI SBCS

	Page
PACKAGE C OVERVIEW (Continued)	
● Attendant Console	5.32
● Front Desk Console	5.33
● Data Interface Unit	5.34
● Hotel/Motel Printer	5.35
PACKAGE C DATA COMMUNICATIONS ARCHITECTURE	
● Data Switching Internal and External Interfaces	5.38
● Package C Data Communications Configuration	5.39
● Review Exercise (5.1)	5.41
PACKAGE C INSTALLATION	
● Package C Installation (Objectives)	5.44
● Package C Card Installation	5.45
● 6PFT and 6PFE Cards Installation	5.47
● Data Interface Unit Installation	5.50
● DIU With Printer Installation	5.51
● Attendant Console Installation	5.52
● Expansion Cabinet Installation	5.53
● Hotel/Motel Printer Installation	5.54
● Laboratory Activity (5.2)	5.57
● Review Exercise (5.2)	5.58



Table of Contents (Continued)

GTE OMNI SBCS

PACKAGE C DATA BASE ADMINISTRATION

Page

● Package C Data Base Administration (Objectives)5.62
● Programming Attendant Console5.63
● Programming Hotel/Motel Features5.69
● DISA-Standard Programming5.78
● DID Programming5.82
● DID/DISA Programming	
● DIU Programming	
● DIU Associated with CS-10/CS-20 Programming5.90
● Key System Programming5.92
● Laboratory Activity (5.3)5.94
○ Review Exercise (5.3)5.99

PACKAGE C MAINTENANCE

● Package C Maintenance (Objectives)5.102
● Attendant Console Assignment as MCT5.103
● Attendant Console Operation as MCT5.104
● Attendant Console Diagnostics5.106
● Data Interface Unit Diagnostics5.112
● Hotel/Motel Printer Busy Assignment5.114
● Character Trunk (CHT) Loop Test5.115
● Expanded System Maintenance — Controls and Indicators5.118
● Expanded System Maintenance — Alarm States5.119
● Expanded System Maintenance — Power Failure Transfer Activation5.120
● Expanded System Maintenance — Fault Detection5.121
● Laboratory Activity (5.4)5.122
● Review Exercise (5.4)5.123

5.0 Terminal Objective



GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PACKAGE C EQUIPMENT AND PERIPHERALS
- PORTABLE MAINTENANCE PANEL, CSD TELEPHONE OR ATTENDANT CONSOLE AS MASTER CONTROL TELEPHONE
- STANDARD INSTALLATION TOOLS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- WRITTEN TEST

ACTION:

- INSTALL PACKAGE C EQUIPMENT AND PERIPHERALS.
- MODIFY THE SYSTEM DATA BASE USING NEW OR ENHANCED PACKAGE C CMC COMMANDS.
- DESCRIBE RETROFIT PROCEDURES REQUIRED TO UPGRADE SBCS TO SVR 2.0.X.X (PACKAGE C).
- PERFORM DATA BASE ADMINISTRATION AND MAINTENANCE TASKS USING THE ATTENDANT CONSOLE AS A MASTER CONTROL TELEPHONE.
- COMPLETE WRITTEN TEST.

CRITERIA:

- INSTALLATION, DATA BASE ADMINISTRATION, AND MAINTENANCE TASKS WILL BE COMPLETED IN ACCORDANCE WITH PACKAGE C PROCEDURES OUTLINED IN GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- TEST WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.



GTE OMNI SBCS

PACKAGE C

Overview



GTE OMNI SBCS

5.1 Enabling Objective

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PACKAGE C EQUIPMENT AND PERIPHERALS
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- REVIEW EXERCISE

ACTION:

- DESCRIBE THE NEW FEATURES AND ENHANCEMENTS AVAILABLE WITH SVR PACKAGE C.
- IDENTIFY AND DESCRIBE THE FUNCTIONS OF PACKAGE C EQUIPMENT AND INTERFACES.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

OMNI SBCS Development Phases



GTE OMNI SBCS

THE OMNI SBCS IS BEING DEVELOPED IN PHASES CORRESPONDING TO SYSTEM VERSION RELEASES. THIS MODULE WILL ADDRESS THE INSTALLATION, DATA BASE ADMINISTRATION, AND MAINTENANCE TASKS ASSOCIATED WITH PACKAGE C (SVR 2.0.X.X). HIGHLIGHTS OF EACH DEVELOPMENT PHASE ARE DESCRIBED BELOW:

PACKAGES A/SVR 1.0.X.X
AND B/SVR 1.5.X.X

- PROVIDE ADVANCED HYBRID SYSTEM FOR BUSINESS USE. INTRODUCE BASIC INTERNAL DATA COMMUNICATIONS FEATURES FOR LOW SPEED DATA TERMINALS, ALLOWING SIMULTANEOUS VOICE/DATA TRANSMISSION.

PACKAGE C/SVR 2.0.X.X

- EXPANDS SYSTEM TO INCLUDE FOLLOWING SYSTEM APPLICATIONS AND FEATURES:
 - . ATTENDANT CONSOLE - PROVIDES EFFICIENT CALL HANDLING FOR PABX APPLICATIONS AND ALLOWS USE OF ATTENDANT CONSOLE FOR DATA BASE ADMINISTRATION OR MAINTENANCE FUNCTIONS.
 - KEY TELEPHONE SYSTEM - REPLACES TRADITIONAL ELECTROMECHANICAL KEY TELEPHONE OPERATIONS WITH EMULATED KEY SYSTEM FEATURES AND ENABLES SYSTEM TO FUNCTION BEHIND A HOST PABX OR CENTREX.
 - . HOTEL/MOTEL PACKAGE - PROVIDES SINGLE BUTTON ACCESS TO LODGING OR HEALTHCARE FEATURES USING A FRONT DESK CONSOLE (CSD OR ATTENDANT CONSOLE), ROOM STATUS INDICATOR, AND HOTEL/MOTEL PRINTER.
 - . EXPANDED SYSTEM ARCHITECTURE - ALLOWS FOR USE OF AN ADDITIONAL SBCS SYSTEM CABINET TO INCREASE BASIC SYSTEM CAPACITY TO A MAXIMUM NUMBER OF 104 TRUNKS OR 240 STATIONS.*
 - . ENHANCED DATA COMMUNICATIONS - EXTENDS NUMBER OF AVAILABLE DATA TERMINALS THROUGH USE OF A DATA INTERFACE UNIT (DIU) DEVICE.

PACKAGE D/SVR 3.0.X.X
(FUTURE)


- PROJECTED TO EXPAND SYSTEM TO INCLUDE ADVANCED OFFICE APPLICATIONS AND FEATURES SUCH AS AUTOMATIC CALL DISTRIBUTION, MULTI-STATION LINE APPEARANCES ON EKT INSTRUMENTS, VOICE MESSAGE, SILENT MESSAGE, AND DICTATION AND CONTROL.

* NOT ACHIEVED SIMULTANEOUSLY

System with Package C Interfaces



GTE OMNI SBCS



Package C/Summary of Features and Enhancements



GTE OMNI SBCS

SYSTEM FEATURES:

- | | | |
|------------------------------------|---|--|
| DIRECT INWARD DIALING (DID) | — | ALLOWS INCOMING CALLS ON DID TRUNKS (USING 2TTL OR 2TTE TRUNK CARDS) TO BYPASS THE ATTENDANT CONSOLE AND RING DIRECTLY TO A STATION. |
| DIRECT INWARD SYSTEM ACCESS (DISA) | — | ALLOWS DIRECT ACCESS TO STATIONS, TRUNKS (e.g., WATS AND TIE), AND FEATURES FROM ANY REMOTE DTMF TELEPHONE. |
| ATTENDANT CONSOLE | — | ALLOWS A FULL RANGE OF ATTENDANT SERVICES SUCH AS SINGLE-BUTTON ACCESS TO CALL PROCESSING AND SYSTEM/STATION FEATURES. |
| | — | MAY BE EQUIPPED WITH OPTIONAL HEADSET. |
| | — | FUNCTIONS AS A MASTER CONTROL TELEPHONE WHILE IN SYSTEM PROGRAMMING MODE. |
| KEY SYSTEM PACKAGE | — | PROVIDES A VARIETY OF TRADITIONAL KEY SYSTEM FUNCTIONS (EMULATING A KEY OPERATION BEHIND A PABX). FEATURES INCLUDE COMMON HOLD, DSS SPEED CALLING, FLASH/NEW CALL, IDLE LINE/RINGING LINE PREFERENCE, POST/PRESELECTION, PRIME LINE PREFERENCE, ETC. |
| DATA COMMUNICATION | — | PROVIDES A MAXIMUM OF 40 DATA LINES AND SIMULTANEOUS VOICE/DATA TRANSMISSION USING A CS-10/CS-20 TELEPHONE CONNECTED TO A DATA INTERFACE UNIT (DIU). |
| | — | ALLOWS DATA CALL SET UP USING DIU OR CS-10/CS-20 (CONNECTED TO A DIU). |
| HOTEL/MOTEL PACKAGE | — | ALLOWS A CSD OR ATTENDANT CONSOLE TO SERVE AS A FRONT DESK CONSOLE. |
| | — | ALLOWS FRONT DESK CONSOLE TO BE ASSOCIATED WITH A BLF/DSS MODULE OR PRINTER. |
| | — | PROVIDES SERVICES SUCH AS AUTOMATIC WAKE-UP CALLS, MESSAGE WAITING, SPECIAL SERVICE CODES, ROOM STATUS INDICATION, ETC. |

Attendant Console Package/Programmable Features and Functions



GTE OMNI SBCS

THE FOLLOWING LISTED FEATURES MAY BE ASSIGNED TO FEATURE BUTTONS ON ATTENDANT CONSOLE:

- | | | |
|---|---|--|
| ACCOUNT CODE/CLIENT BILLING | — | ALLOWS THE ATTENDANT TO INPUT AN ACCOUNT/CLIENT CODE OF UP TO 15 DIGITS WHICH WILL BE RECORDED ON STATION MESSAGE DETAIL RECORDING. IF ACTIVATED DURING A CONVERSATION, THERE IS NO INTERRUPTION TO CALLING PARTY. |
| ALARM | — | ACTIVATED BY AN ALARM IN THE SYSTEM, THE LED LOCATED ABOVE THIS FEATURE BUTTON WILL ALERT THE ATTENDANT TO A FAULT IN THE SYSTEM. |
| AUTOMATIC INTERCOM | — | PROVIDES SINGLE BUTTON ACCESS TO A PREDETERMINED STATION. |
| BREAK-IN | — | ALLOWS ATTENDANT TO DEPRESS BUTTON WHEN A BUSY STATION IS ENCOUNTERED TO BREAK-IN ON THE CONVERSATION. WARNING TONE IS PROVIDED TO THE STATION. |
| CALL ANNOUNCE | — | PROVIDES THE ATTENDANT WITH ABILITY TO ANNOUNCE CALLS TO STATIONS UTILIZING THE INTERNAL SPEAKERS IN ELECTRONIC KEY TELEPHONES. |
| CALL PARK | — | ALLOWS ATTENDANT TO DEPRESS A FEATURE BUTTON AND DIAL A STATION NUMBER TO PARK A STATION OR TRUNK CALL. IF THE CALL IS UNANSWERED WITHIN A PRE-PROGRAMMED PERIOD OF TIME, THE CALL WILL RECALL TO THE ATTENDANT. |
| CALL RESTRICTION | — | ALLOWS ATTENDANT TO CHANGE THE OPERATION MODE OF ALL STATIONS ASSIGNED A GIVEN CLASS OF SERVICE. OPERATION MODE CAN BE DESIGNATED AS TWO-WAY, TERMINATING ONLY, ORIGINATING ONLY, OR TOTALLY RESTRICTED. |
| CLASS OF SERVICE/
CLASS OF RESTRICTION | — | ALLOWS ATTENDANT TO DEPRESS BUTTON WHILE IN CONVERSATION WITH A STATION PROVIDING DISPLAY OF THE STATION'S CLASS OF SERVICE AND CLASS OF RESTRICTION LEVELS. |

Attendant Console Package/Programmable Features and Functions (Continued)



GTE OMNI SBCS

- DO NOT DISTURB OVERRIDE** — ALLOWS A STATION IN DO NOT DISTURB MODE TO BE OVERRIDDEN SO STATION WILL RING.
- EXTERNAL PAGING** — AUTOMATICALLY DIALS THE EXTERNAL PAGING CODE. ALLOWS ATTENDANT TO DIAL THE APPROPRIATE ZONE NUMBER.
- FLASH/NEW CALL** — ALLOWS ATTENDANT TO DEPRESS BUTTON DURING ACCESS TO OR CONVERSATION ON A TRUNK TO DISCONNECT THE CALL IN PROGRESS AND RESEIZE THE TRUNK.
- FRONT DESK PROGRAM** — ALLOWS THE ATTENDANT CONSOLE TO BE UTILIZED AS THE FRONT DESK CONSOLE IN HOTEL/MOTEL APPLICATIONS. PROVIDES ACCESS TO ROOM STATUS, MESSAGE METERING, WAKE-UP, AND DO NOT DISTURB FOR GUEST ROOMS.
- MESSAGE LEAVING** — ALLOWS ATTENDANT TO DEPRESS BUTTON AND DIAL A DESIRED STATION NUMBER TO ACTIVATE THE MESSAGE WAITING LAMP ON THE STATION OR SINGLE-LINE PHONE. STATION INSTRUMENTS WITH DISPLAY WILL REGISTER A CALL FROM THE ATTENDANT CONSOLE.
- NIGHT ANSWER** — ALLOWS ATTENDANT TO DEPRESS BUTTON TO ACTIVATE THE NIGHT MODE OF OPERATION. ALL STATIONS AND TRUNKS ARE CHANGED TO NIGHT CLASS OF SERVICE AND NIGHT CLASS OF RESTRICTION. TRUNK CALLS ARE DIRECTED TO UNIVERSAL OR PREDETERMINED NIGHT ANSWER.
- PLACING AN EXTERNAL CALL** — ALLOWS ATTENDANT TO DEPRESS BUTTON TO SEIZE AN IDLE TRUNK IN THE ASSIGNED TRUNK GROUP. THE ASSOCIATED LED PROVIDES INDICATION OF ALL TRUNKS BUSY IN THE TRUNK GROUP.

Attendant Console Package/Programmable Features and Functions (Continued)



GTE OMNI SBCS

- | | |
|------------------------------------|---|
| POSITION BUSY | — ACTIVATES POSITION BUSY FEATURE REQUIRED FOR SYSTEM PROGRAMMING MODE. REMOVES THE ATTENDANT CONSOLE FROM ACTIVE STATUS SO CALLS CANNOT BE ANSWERED OR ORIGINATED FROM THE ATTENDANT CONSOLE. |
| SAVE NUMBER AND REPEAT LAST NUMBER | — AUTOMATICALLY REDIALS THE LAST NUMBER DIALED FROM THE KEY PAD ON THE ATTENDANT CONSOLE. |
| STATION PAGING | — ALLOWS ATTENDANT TO DEPRESS BUTTON TO DIAL THE STATION PAGING ACCESS CODE. ATTENDANT CAN THEN DIAL THE REQUESTED ZONE NUMBER FOR PAGING ANNOUNCEMENT. |
| STATION PICK-UP | — ALLOWS ATTENDANT TO ANSWER A STATION-TO-STATION, DIRECT INWARD DIALING, OR DIRECT-IN LINE CALL RINGING AT ANY TELEPHONE, BY DEPRESSING BUTTON AND DIALING THE STATION NUMBER OF THE RINGING TELEPHONE. |
| STATION SPEED CALLING | — PROVIDES ATTENDANT WITH ACCESS TO ONE PREDETERMINED STATION SPEED CALL NUMBER. |
| SYSTEM SPEED CALLING | — PROVIDES ATTENDANT WITH ACCESS TO ONE PREDETERMINED SYSTEM SPEED CALL NUMBER. |
| TRUNK CAMP-ON | — ALLOWS ATTENDANT TO DEPRESS A BUTTON WHEN A BUSY TRUNK/TRUNK GROUP IS ENCOUNTERED BY THE ATTENDANT TO ACTIVATE CAMP-ON WITH CALL-BACK. ATTENDANT MAY WAIT IN EITHER ON OR OFF-HOOK STATUS. IF CALLER IS ON HOLD WHEN THE BUSY TRUNK IS REACHED, ATTENDANT CAN DEPRESS FEATURE BUTTON, FOLLOWED BY POSITION RELEASE, TO CAMP THE STATION TO A TRUNK/TRUNK GROUP. |



GTE OMNI SBCS

Key System Features


THE FOLLOWING KEY SYSTEM FEATURES MAY BE ASSIGNED TO BUTTONS ON CS-10, CS-20, OR CSD TELEPHONES:

- | | | |
|-----------------------------------|---|---|
| COMMON HOLD | — | ALLOWS ALL STATION USERS TO RETRIEVE A CALL ON HOLD BY USING A LINE BUTTON ON THE TELEPHONE. |
| DSS LINE TERMINATIONS | — | ALLOWS A MAXIMUM OF 40 LINES TO TERMINATE TO BUTTONS IN A BLF/DSS MODULE. A LINE MAY HAVE 52 APPEARANCES IN SYSTEM ON STATION OR BLF/DSS BUTTONS. |
| DSS SPEED DIALING | — | ALLOWS UP TO 40 BLF/DSS BUTTONS TO BE PROGRAMMED WITH DESIGNATED SYSTEM SPEED CALL NUMBERS. |
| FLASH/NEW CALL | — | SENDS A FLASH INDICATION TO A HOST PABX. |
| DELAYED RINGING | — | ALLOWS RINGING TO OCCUR ON LINES APPEARING AT MORE THAN ONE STATION AFTER A PREDETERMINED PERIOD OF TIME. |
| IDLE LINE/RINGING LINE PREFERENCE | — | ALLOWS STATION USERS TO DESIGNATE AN IDLE OR RINGING LINE PREFERENCE FOR A STATION, ELIMINATING THE NEED TO MANUALLY PRESS THE LINE OR INTERCOM BUTTON TO ANSWER OR ORIGINATE A CALL. |
| POST/PRESELECTION | — | PROVIDES THE ABILITY TO SELECT AN INTERCOM OR LINE BUTTON BEFORE OR AFTER GOING OFF-HOOK. |
| PRIME LINE PREFERENCE | — | ALLOWS USER TO AUTOMATICALLY SELECT A LINE OR INTERCOM BUTTON DESIGNATED AS THE PRIME LINE WHEN GOING OFF-HOOK. |
| PRIVACY/PRIVACY RELEASE | — | ALLOWS USER TO RELINQUISH PRIVACY ON A LINE OR INTERCOM CALL AND PERMIT A THIRD STATION TO ENTER THE CONVERSATION BY DEPRESSING THE LINE BUTTON. |
| PROGRAMMING FROM STATION | — | ALLOWS STATION USERS TO PROGRAM STATION AND SYSTEM FEATURES (OTHER THAN LINE OR INTERCOM APPEARANCES) FOR BUTTONS ON THEIR TELEPHONES. |

Enhanced Data Communication Capabilities



GTE OMNI SBCS



- **NEW DATA INTERFACE UNIT (DIU) PROVIDES INTERFACE BETWEEN DATA TERMINALS AND SYSTEM BY SERVING AS STANDALONE UNIT (WITH MODEMS OR PRINTERS) OR BY BEING PAIRED WITH CS-10 OR CS-20 INSTRUMENTS FOR SIMULTANEOUS VOICE/DATA COMMUNICATIONS.**
- **PACKAGE C PROVIDES FOLLOWING DATA SWITCHING CONNECTION FEATURES (IN ADDITION TO BASIC DATA SWITCHING FUNCTIONS AVAILABLE WITH PACKAGE B):**
 - **DATA CALL SET UP (INTERNAL OR EXTERNAL) WITH DATA INTERFACE UNIT (DIU). AS STANDALONE UNIT**
 - **DATA CALL SET UP (INTERNAL OR EXTERNAL) WITH CS-10 OR CS-20 TELEPHONE CONNECTED TO DATA INTERFACE UNIT (DIU)**



Hotel/Motel Package

GTE OMNI SBCS

THE FOLLOWING FEATURES ARE AVAILABLE WITH THE HOTEL/MOTEL FEATURE PACKAGE:

- AUTOMATIC WAKE-UP WITH PRINTOUT — PROVIDES AUTOMATIC WAKE-UP SERVICE WITH MUSIC OR SYSTEM TONES. SECOND ATTEMPT WITH NO ANSWER OR BUSY IS REPORTED ON HOTEL/MOTEL PRINTER OR ROOM STATUS INDICATOR (BLF/DSS MODULE).
- CALL RESTRICTION — ALLOWS FRONT DESK CONSOLE TO CHANGE OPERATION MODE FOR STATIONS IN A PARTICULAR CLASS OF SERVICE/CLASS OF RESTRICTION. OPERATION MODE CHANGES MAY INCLUDE TWO-WAY CALLING, ORIGINATING ONLY, TERMINATING ONLY, OR TOTALLY RESTRICTED OPERATION.
- DO NOT DISTURB/
DO NOT DISTURB OVERRIDE — PROHIBITS CALLS FROM OTHER GUEST **ROOMS**. FEATURE MAY BE OVERRIDDEN BY FRONT DESK CONSOLE.
- FRONT DESK CONSOLE — ALLOWS ATTENDANT CONSOLE OR CSD TELEPHONE TO SERVE AS THE FRONT DESK **CONSOLE** WITH SINGLE-BUTTON ACCESS TO **HOTEL/MOTEL** FEATURES. FRONT DESK CONSOLE MAY BE ASSOCIATED WITH A **BLF/DSS** MODULE FOR ROOM STATUS INDICATION OR EQUIPPED WITH A PRINTER FOR WAKE-UP CALL AND ROOM CHARGES REPORTING.
- HOT LINE TO ATTENDANT — ALLOWS A STATION IN HOT LINE CONDITION TO AUTOMATICALLY CALL ATTENDANT OR FRONT DESK. USEFUL FOR LOBBY TELEPHONE.
- MESSAGE REGISTRATION — PROVIDES ABILITY TO AUTOMATICALLY CHARGE GUESTS FOR USE OF LOCAL LINES, WATS LINES, FX LINES, OR **OCC/SCC** FACILITIES BASED ON PREPROGRAMMED RATE TABLES IN SYSTEM. ROOM CHARGES MAY BE DISPLAYED AT FRONT DESK CONSOLE OR REPORTED ON GUEST ROOM PRINTOUT.
- MESSAGE WAITING — ALLOWS FRONT DESK CONSOLE TO ACTIVATE MESSAGE WAITING LAMPS ON EQUIPPED GUEST ROOM TELEPHONES. MESSAGES MAY BE RETRIEVED BY GUEST USING TELEPHONE'S FEATURE BUTTON OR MESSAGE PICK-UP ACCESS CODE.



Hotel/Motel Package (Continued)

GTE OMNI SBCS

- | | | |
|-----------------------------------|---|--|
| ROOM NUMBER CORRELATION | — | ALLOWS GUEST ROOM TELEPHONES TO BE ASSIGNED STATION DIRECTORY NUMBERS CORRESPONDING TO HOTEL/MOTEL ROOM NUMBERS. |
| ROOM STATUS/ROOM STATUS INDICATOR | — | ALLOWS FRONT DESK CONSOLE EQUIPPED WITH 40 OR 80 BUTTON BLF/DSS MODULE TO DISPLAY ROOM STATUS INDICATION FOR VACANT, OCCUPIED, NEEDS CLEAN-UP, DO NOT DISTURB, AND WAKE-UP/NO ANSWER STATUS. |
| ROOM TO ROOM BLOCKING | — | ALLOWS SYSTEM TO BE PROGRAMMED TO PREVENT ROOM-TO-ROOM CALLS ON A SYSTEM WIDE BASIS. |
| SERVICE CALL ROUTING | — | ALLOWS GUESTS TO DIAL ONE TO FOUR DIGIT SERVICE CODES CORRESPONDING TO FLOOR OR ZONE FOR AUTOMATIC CONNECTION TO SERVICE DEPARTMENTS OR MAID SERVICE. |
| SPECIAL SERVICE CODES | — | ALLOWS UP TO 10 SINGLE DIGIT ACCESS NUMBERS TO BE PROGRAMMED FOR GUEST CALLS TO HOTEL/MOTEL SERVICES SUCH AS ROOM SERVICE, RESTAURANT, LAUNDRY, ETC. |
| TIME OUT ROUTING TO ATTENDANT | — | AUTOMATICALLY DIALS FRONT DESK CONSOLE IF GUEST TELEPHONE REMAINS OFF-HOOK AFTER A PREPROGRAMMED PERIOD OF TIME. |
| VACANT ROOM RESTRICTION | — | RESTRICTS INCOMING AND/OR OUTGOING CALLS WHILE ROOM IS IN VACANT STATUS. |

Business Features



GTE OMNI SBCS

FEATURES LISTED MAY BE ASSIGNED TO BUTTONS ON CS-10, CS-20, OR CSD TELEPHONES:

- HEADSET OPERATION — PROVIDES HANDS-FREE OPERATION BY ALLOWING A STATION BUTTON TO SIMULATE THE HOOKSWITCH FLASH WHILE HANDSET REMAINS ON-HOOK.
- DO NOT DISTURB OVERRIDE — ALLOWS DESIGNATED STATION USERS TO OVERRIDE DO NOT DISTURB FEATURE WHEN CALLING A STATION WITH ACTIVATED DO NOT DISTURB FEATURE.
- REMINDER* — ALLOWS A STATION USER TO PROGRAM A PARTICULAR TIME TO BE REMINDED OF A PARTICULAR EVENT. AT THE PREPROGRAMMED TIME THE TELEPHONE WILL RING AND A TONE OR RECORDING WILL BE HEARD.

*IMPLEMENTED BY PROGRAMMING WAKE-UP TO A STATION WHICH IS NOT A ROOM.



GTE OMNI SBCS


PACKAGE C

Standard and Expanded Architecture



Standard and Expanded Systems

GTE OMNI SBCS



- . PACKAGE C ALLOWS SBCS TO BE ENLARGED FROM STANDARD SYSTEM (USING ONE BASIC CABINET) TO EXPANDED SYSTEM WITH ADDITION OF EXPANSION CABINET.
- . EXPANSION MODULE EXPANDS CAPACITY OF SYSTEM TO 240 STATIONS AND 104 TRUNKS (NOT ACHIEVED SIMULTANEOUSLY).
- . ALL SYSTEM AND STATION FEATURES REMAIN THE SAME AS IN THE SMALLER STANDARD SYSTEM.

Expanded System Trunk/Station Line Combinations



GTE OMNI SBCS

<u>C.O. TRUNKS</u>	<u>STATION LINES</u>	<u>C.O. TRUNKS</u>	<u>STATION LINES</u>
0	240	76	152
4	240	80	144
8	240	84	136
12	240	88	128
16	240	92	120
20	240	96	112
24	240	100	104
28	240	104	96
32	240	104	88
36	232	104	80
40	224	104	72
44	216	104	64
48	208	104	56
52	200	104	48
56	192	104	40
60	184	104	32
64	176	104	24
68	168	104	16
72	160	104	8
		104	0

Package C System Capacities (Standard and Expanded Systems)



GTE OMNI SBCS

<u>EQUIPMENT</u>	<u>MAXIMUM SYSTEM CAPACITY</u>
STATION LINES	1201240"
TRUNK LINES	40/104*
DATA TERMINALS	40**
ATTENDANT CONSOLES	2 (PACKAGE C)
DIRECT STATION SELECTION MODULES	8***
TENANT SERVICE	5
TRUNK GROUPS	62
VOICE SPEAKER PAGING	9 ZONES + ALL CALL
RS-232-C PORTS	2
FRONT DESK CONSOLES	2 (PACKAGE C)
HOTEL/MOTEL PRINTERS	2 (PACKAGE C)
POWER FAILURE TRANSFER	6/12****
DTMF RECEIVER CARDS	2/4* (8/16 CIRCUITS)
CHARACTER TRUNK CARDS	2/4* (8/16 CIRCUITS)

*UTILIZING EXPANSION CABINET

**SYSTEM MAXIMUM INCLUDES: 30 CSD TELEPHONES WITH DTA OR 40 CSD, CS-10, OR CS-20 TELEPHONES WITH DIU.


***SYSTEM MAXIMUM INCLUDES: TWO 80-BUTTON BLF/DSS MODULES, SIX 40-BUTTON BLF/DSS MODULES, OR EIGHT 40-BUTTON BLF/DSS MODULES WITH INDEPENDENT LINE ASSIGNMENT.

****SINGLE-LINE TELEPHONE SETS (6 WITH BASIC CABINET, 12 WITH EXPANSION CABINET).

Expanded System Frame Image/Common Control Cards




GTE OMNI SBCS



BASIC CABINET

COMMON CONTROL CARDS

- SWB — SWITCH CONTROL BASIC CARD
- CPMC — ENHANCED CENTRAL PROCESSING UNIT AND BASIC MEMORY CARD
- MEMC — ENHANCED MEMORY CARD



EXPANSION CABINET


SWITCH CONTROL CARD E

- SWE — SWITCH CONTROL EXPANSION CARD


Expanded System Frame Image/ Interface Cards



GTE OMNI SBCS



- 8EKC — ELECTRONIC KEY TELEPHONE CARDS
- 8DTC — CSD TELEPHONE DIGITAL INTERFACE CARDS
- 6PFT — POWER FAIL TRANSFER CARD



- 8SLC - SINGLE LINE TELEPHONE CARDS
- 4DMR — DUAL TONE MULTI-FREQUENCY RECEIVER CARDS
- 2TTL — LOOP DIAL TIE TRUNK CARDS
- 2TTE — E&M TIE TRUNK CARDS
- 4BWC — BOTHWAY TRUNK CARDS
- 4CHT — CHARACTER TRUNK CARD
- 6PFE — POWER FAIL TRANSFER EXPANSION CARD

Interface Card Group Configuration



GTE OMNI SBCS

BASIC CABINET

Card Group	No. 1			No. 2			No. 3			No. 4			No. 5			No. 6			
Slot	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18
8EKC	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X				
8SLC	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X				
4DMR							X	X	X	X	X	X	X	X	X				
8DTC	X*	X	X	X*	X	X	X*	X	X	X*	X	X	X*	X	X				
4CHT							X	X	X	X	X	X	X	X	X				
4BWC							X	X	X	X	X	X	X	X	X	X	X	X	X
2TTL/2TTE							X	X	X	X	X	X	X	X	X	X	X	X	X

EXPANSION CABINET

Card Group	No. 1			No. 2			No. 3			No. 4			No. 5			No. 6			
Slot	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18
8SLC	x	x	x	x	x	x	x	x	x	x	x	x	x	x					
4DMR							x	x	x	x	x	x	x	x					
4CHT							x	x	x	x	x	x	x	x					
4BWC							x	x	x	x	x	x	x	x	x	x	x	x	x
2TTL/2TTE							x	x	x	x	x	x	x	x	x	x	x	x	x

*FOR CSD WITH DTA OR DIU OPTIONS

Expanded System/Cabinet Card Capacities



GTE OMNI SBCS

<u>CARD TYPE</u>	<u>BASIC CABINET</u>	<u>EXPANSION CABINET</u>	<u>SYSTEM TOTAL</u>
8EKC	15	—	15
8DTC	5	—	5
8SLC	15	15	30
4DMR	2	2	4
4BWC	10/13*	13	26
2TTE,2TTL	6 TOTAL	6 TOTAL	12 TOTAL
4CHT	2	2	4
6PFT/6PFE	1	1 (6PFE)	2 TOTAL

***13 4BWC CARDS CAN BE INSTALLED IN THE BASIC CABINET WHEN USED WITH AN EXPANSION CABINET. IF ONLY BASIC CABINET IS INSTALLED, ONLY 10 4BWC CARDS CAN BE INSTALLED.**



GTE OMNI SBCS


PACKAGE C

New/Enhanced Cards and Peripherals

CPMC (Enhanced Central Processing Unit and Basic Memory Card)



GTE OMNI SBCS




- CPMC (PACKAGE C/SVR 2.0.X.X) INCLUDES:
 - 16 BIT MICROPROCESSOR (INTEL 8086 COMPATIBLE)
 - TWO RS-232-C PORTS (FOR PMP AND SMDR EQUIPMENT)
 - ROM FOR OPERATING SYSTEM SOFTWARE AND DEFAULT STANDARD DATA BASE
 - RAM FOR CUSTOMIZED DATA BASE (REMAINDER OF RAM RESIDES IN MEM CARD)
 - REAL TIME CLOCK

- CPMC CARD:
 - SUPPORTS ALL PACKAGE C EQUIPMENT AND FEATURES
 - FUNCTIONS ONLY WITH MEMC CARD

MEMC (Enhanced Memory Card)



GTE OMNI SBCS




- MEMC (PACKAGE C/SVR 2.0.X.X) INCLUDES:
 - ROM FOR OPERATING SYSTEM SOFTWARE AND DEFAULT STANDARD DATA BASE
 - RAM FOR CUSTOMIZED DATA BASE (ALSO RESIDES IN CPMC CARD)

- MEMC CARD:
 - SUPPORTS ALL PACKAGE C EQUIPMENT AND FEATURES
 - FUNCTIONS ONLY WITH CPMC CARD
 - CONTAINS MORE MEMORY THAN CPMA OR CPMB CARDS

SWE (Switch Control Expansion Card)



GTE OMNI SBCS




- LOCATED IN EXPANSION CABINET
- CONTAINS PCM TIME DIVISION SWITCHING CIRCUITRY AND SIGNAL MEMORY FOR INTERFACE BETWEEN EXPANSION CABINET AND THE CPMC CARD (LOCATED IN THE BASIC CABINET)
- EIGHT HIGHWAYS OF 256 CHANNELS MULTIPLEXING FULL DUPLEX ARE DEDICATED TO THE EXPANSION CABINET
- CONTAINS A FRONT EDGE CONNECTOR TO WHICH CABLE FROM BASIC CABINET IS CONNECTED



4CHT (Character Trunk Card)

GTE OMNI SBCS




- **4CHT CARD:**
 - ACCOMMODATES FOUR DIGITAL SENDER/RECEIVER CIRCUITS PER CARD IN CONJUNCTION WITH A DATA INTERFACE UNIT (DIU)
 - PROVIDES HOTEL/MOTEL MESSAGE OUTPUT
 - SUPPORTS THE FOLLOWING COMMUNICATION CONFIGURATION:
 - 7 BITS ASCII CODE TRANSMISSION
 - ASYNCHRONOUS TRANSMISSION
 - HALF/FULL DUPLEX OPERATION
 - DATA SPEED OF 110 BPS — 19.2 KBPS
- MAXIMUM OF TWO CARDS PER CABINET IN CARD SLOTS 06-18

PFE (Power Failure Transfer Expansion Card)



GTE OMNI SBCS




- LOCATED IN SLOT 22 OF EXPANSION CABINET
- PROVIDES SIX ADDITIONAL POWER FAILURE STATIONS FOR SIX PREDETERMINED TRUNKS
- TIED BY A CIRCUIT TO THE 6PFT (POWER FAILURE TRANSFER CARD) LOCATED IN BASIC CABINET
- ALARMS IN EXPANSION CABINET ARE TRANSMITTED TO AN EXTERNAL DEVICE BY THE 6PFE CARD
- MAY BE INSTALLED IN THE STANDARD SYSTEM (BASIC CABINET ONLY) THROUGH USE OF A TOGGLE SWITCH ON PRINTED CIRCUIT BOARD
- ACTIVATED FOR INSTALLATION IN EXPANSION CABINET BY THE NAO AND NA1 SIGNAL CONNECTED TO THE JAO AND JAI SIGNAL OF 6PFT CARD IN BASIC CABINET


Front Desk Console (FDC)



GTE OMNI SBCS



CSD TELEPHONE EQUIPPED WITH BLF/DSS MODULE




ATTENDANT CONSOLE EQUIPPED WITH BLF/DSS MODULE

- . ATTENDANT CONSOLE OR CSD TELEPHONE MAY SERVE AS FRONT DESK CONSOLE FOR HOTEL/MOTEL APPLICATIONS IF PROGRAMMED WITH FRONT DESK FEATURE BUTTON
- . FRONT DESK CONSOLE:
 - PROVIDES SINGLE-BUTTON ACCESS TO HOTEL/MOTEL FEATURES
 - MAY BE ASSOCIATED WITH A BLF/DSS FOR ROOM STATUS OR BLF/DSS INDICATION
 - FUNCTIONS AS PROGRAMMING DEVICE WHILE IN PROGRAMMING MODE
 - MAY BE EQUIPPED WITH A PRINTER TO PROVIDE PRINTOUTS OF WAKE-UP CALLS AND MESSAGE CHARGES
- . ANSWERING POSITION MAY FUNCTION AS FRONT DESK CONSOLE
- . MAXIMUM OF TWO FRONT DESK CONSOLES MAY BE ASSIGNED

Data Interface Unit (DIU)



GTE OMNI SBCS




- PROVIDES DIGITAL DATA AND CONTROL BETWEEN 8DTC CARDS AND TERMINALS, MODEMS, WORK STATIONS OR PRINTERS STATIONS(WITHOUT BEING ASSOCIATED WITH TELEPHONE)
- MAY BE ASSOCIATED WITH CS-10 OR CS-20 TELEPHONES FOR SIMULTANEOUS VOICE/DATA TRANSMISSION
- MAXIMUM OF 40 DIU INSTRUMENTS IN EXPANDED SYSTEMS
- . DIU SUPPORTS THE FOLLOWING COMMUNICATION:
 - RS-232-C INTERFACE
 - ASYNCHRONOUS/SYNCHRONOUS TRANSMISSION
 - DATA SPEEDS OF UP TO 19.2 KBPS
- . PROVIDES AN INTERFACE PORT TO RS-232-C PRINTER FOR HOTEL/MOTEL APPLICATION



Hotel/Motel Printer

GTE OMNI SBCS



- PRINTS STORED INFORMATION SUCH AS WAKE-UP EXECUTION AND MESSAGE REGISTRATION
- MAXIMUM OF TWO PRINTERS CAN BE INSTALLED
- CONNECTED TO DIU OR CSD (WITH DTA INTERFACE)
- REQUIRES 4CHT CARD FOR SYSTEM OPERATION OF PRINTER
- REQUIRES 8DTC CARD FOR DIU/DTA CONNECTION
- SYSTEM PROVIDES PRINTOUT BUFFER CAPABLE OF STORING 100 MESSAGES FOR EACH HOTEL/MOTEL PRINTER
- MAXIMUM CABLE LENGTH OF 50 FEET FROM DIU/DTA



GTE OMNI SBCS


PACKAGE C

Data Communications Architecture

Data Switching Internal and External Interfaces




GTE OMNI SBCS



Package C Data Communications Configuration



GTE OMNI SBCS



SUPPORTS SIX CSD TELEPHONES WITH DATA TERMINAL ADAPTERS AND TWO DATA INTERFACE UNITS (OR TWO VOICE ONLY CSD TELEPHONES).

Review Exercise — Package C

Overview (5.1)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. PACKAGE C EXPANDS THE SYSTEM TO INCLUDE THE FOLLOWING SYSTEM APPLICATIONS: _____
 - A. HOTEL/MOTEL, KEY SYSTEM FEATURES, AUTOMATIC CALL DISTRIBUTION, AND EXPANDED SYSTEM ARCHITECTURE
 - B. VOICE MESSAGE, ATTENDANT CONSOLE, HOTEL/MOTEL, AND ENHANCED DATA COMMUNICATIONS
 - C. KEY SYSTEM FEATURES, ATTENDANT CONSOLE, EXPANDED SYSTEM ARCHITECTURE, AND DICTATION AND CONTROL
 - D. ATTENDANT CONSOLE, KEY SYSTEM FEATURES, EXPANDED SYSTEM ARCHITECTURE, AND HOTEL/MOTEL
2. THE EXPANDED SYSTEM ARCHITECTURE INCREASES THE SYSTEM CAPACITY TO A MAXIMUM OF _____ TRUNKS AND _____ STATIONS.
3. THE _____ FEATURE ALLOWS DIRECT ACCESS TO STATIONS, TRUNKS, AND FEATURES FROM ANY REMOTE DTMF TELEPHONE.
4. THE _____ FEATURE ALLOWS INCOMING CALLS ON DID TRUNKS TO BYPASS THE ATTENDANT CONSOLE AND RING DIRECTLY TO A STATION.
5. THE _____ ATTENDANT CONSOLE FEATURE BUTTON ALLOWS THE ATTENDANT CONSOLE TO BE UTILIZED AS THE FRONT DESK CONSOLE IN HOTEL/MOTEL APPLICATIONS.
6. THE _____ KEY SYSTEM FEATURE ALLOWS A STATION USER TO AUTOMATICALLY SELECT AN INTERCOM OR LINE BUTTON BEFORE OR AFTER GOING OFF-HOOK.

Review Exercise — Package C

Overview (5.1) (Continued)



GTE OMNI SBCS

7. _____ (TRUE OR FALSE) THE DATA INTERFACE UNIT (DIU) CAN SERVE AS A STANDALONE UNIT FOR INTERFACE WITH A MODEM OR PRINTER.
8. MATCH EACH OF THE FOLLOWING HOTEL/MOTEL FEATURES WITH ITS CORRECT DEFINITION:
- | | |
|--------------------------------------|--|
| _____ DO NOT DISTURB | A. RESTRICTS INCOMING AND/OR OUTGOING CALLS WHILE ROOM IS IN VACANT STATUS |
| _____ AUTOMATIC WAKE-UP WITH PRINTER | B. ALLOWS FRONT DESK CONSOLE EQUIPPED WITH BLF/DSS MODULE TO DISPLAY INDICATION FOR VACANT, OCCUPIED, NEEDS CLEAN-UP, DO NOT DISTURB, AND WAKE-UP/NO ANSWER CONDITIONS |
| _____ ROOM STATUS | C. PROHIBITS CALLS FROM OTHER GUEST ROOMS |
| _____ MESSAGE REGISTRATION | D. PROVIDES WAKE-UP SERVICE WITH MUSIC OR SYSTEM TONES |
| _____ VACANT ROOM RESTRICTION | E. PROVIDES RECORD OF GUEST CHARGES FOR USE OF LOCAL LINES, WATS LINES, FX LINES, OR OCC/SCC FACILITIES BASED ON PREPROGRAMMED RATE TABLES IN SYSTEM |
9. THE SYSTEM ALLOWS A MAXIMUM OF _____ CSD TELEPHONES EQUIPPED WITH DATA TERMINAL ADAPTERS OR _____ CSD, CS-10, OR CS-20 TELEPHONES. INTERFACED WITH DATA INTERFACE UNITS.
10. THE NEW _____ CARD PROVIDES HOTEL/MOTEL MESSAGE OUTPUT AND ACCOMMODATES THE FOUR DIGITAL SENDER/RECEIVER CIRCUITS USED IN CONJUNCTION WITH DATA INTERFACE UNITS.



GTE OMNI SBCS

PACKAGE C

Installation



5.2 Enabling Objective

GTE OMNI SBCS

GIVEN:

- GTE OMNI SBCS (PREVIOUSLY INSTALLED)
- GTE OMNI SBCS PACKAGE C EQUIPMENT AND PERIPHERALS
 - CPMC, MEMC, 4CHT, SWB, SWE, AND PFE CARDS:
 - ATTENDANT CONSOLE
 - HOTEL/MOTEL PRINTER
 - DATA INTERFACE UNIT (DIU)
- GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- STANDARD INSTALLATION TOOLS
- REVIEW EXERCISE

ACTION:

- INSERT AND SEAT PACKAGE C CARDS
- INSTALL ATTENDANT CONSOLE AND WIRE CROSS CONNECTIONS
- INSTALL DATA INTERFACE UNIT AND WIRE CROSS CONNECTIONS
- INSTALL HOTEL/MOTEL PRINTER
- DESCRIBE PROCEDURES REQUIRED FOR EXPANDED SYSTEM INSTALLATION
- COMPLETE REVIEW EXERCISE


CRITERIA:

- ENHANCED/NEW CARDS WILL BE INSTALLED IN ACCORDANCE WITH STUDENT WORKBOOK AND GTE OMNI SBCS GTEP MANUAL.
- REVIEW EXERCISE QUESTIONS WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.




Package C Card Installation

GTE OMNI SBCS



BASIC CABINET



EXPANSION CABINET

PROCEDURE

1. GROUND YOURSELF PRIOR TO HANDLING CARDS.
2. SINCE SYSTEM POWER MUST BE TURNED OFF WHEN INSTALLING OR REPLACING CPMC OR MEMC CARDS, OFFICE DEPENDENT DATA BASE WILL BE DELETED AND CUSTOMIZED DATA BASE MUST BE REPROGRAMMED.
3. IF POWER FAIL TRANSFER IS REQUIRED IT WILL BE NECESSARY TO INSTALL A 6PFE CARD IN SLOT 22 OF THE EXPANSION CABINET USING THE CORRECT TOGGLE OPTION. CROSS CONNECT THE APPROPRIATE CONTROL LEADS BETWEEN THE BASIC AND EXPANSION CABINETS.
4. INSTALL CARDS AFFECTED BY PACKAGE C SLOTS:-
 - CPMC — SLOT 20
 - MEMC — SLOT 21
 - 6PFT/6PFE — BASIC CABINET SLOT 22
 - 6PFE — IF EXPANDED SYSTEM IS INSTALLED, USE EXPANSION CABINET SLOT 22. SLOTS 20 AND 21 WILL BE BLANK
 - 4CHT — SLOTS 06 THROUGH 14 (BASIC AND EXPANSION CABINET)
 - SWB — SLOT 19 (BASIC CABINET)
 - SWE — IF EXPANDED SYSTEM IS INSTALLED, USE EXPANSION CABINET SLOT 19
5. INITIALIZE CARDS BY USING COLD RESTART TO RESET THE SYSTEM. PRESS RESTART BUTTON WITH TOGGLE IN UPPER POSITION ON CPMC CARD.
6. REPROGRAM SYSTEM WITH ODDB.



6PFT and 6PFE Cards Installation

GTE OMNI SBCS

DESCRIPTION

- 6PFT CARD CAN BE INSTALLED ONLY IN BASIC CABINET.
- 6PFE CARD CAN BE INSTALLED IN EITHER BASIC OR EXPANSION CABINETS DEPENDING ON TOGGLE SWITCH SETTING.

PROCEDURE


- INSTALL 6PFT CARD IN SLOT 22 OF BASIC CABINET. (6PFE MAY BE USED IF TOGGLE SWITCH IS SET FOR BASIC MODE.)
- INSTALL 6PFE CARD IN EXPANSION CABINET USING EXPANSION MODE TOGGLE SETTING.
- CROSS CONNECT SIGNAL LEADS FOR BOTH CARDS (USE JAO-JAI LEAD OF CARD IN BASIC CABINET AND NAO-NAI LEAD IN EXPANSION CABINET), USING SYSTEM CROSS CONNECTIONS DESIGNATED BELOW:

<u>APM PIN NUMBER</u>	<u>SIGNAL NAME</u>	<u>CDF CABLE COLOR CODE</u>	<u>CARD SLOT NUMBER</u>	<u>48WC LEAD NAME</u>	<u>2TTL LEAD NAME</u>	<u>2TTE LEAD NAME</u>
34	JAO	RED-BRN	BASIC	JAO	REMOTE ALARM	-MAJOR
9	JAI	BRN-RED	22	JAI	EXPANSION	-JAO/1
35	NAO	RED-SL	(6PFT/6PFE)	N00	REMOTE ALARM	-MINOR
10	NA1	SL-RED		NA1	REMOTE ALARM	-MINOR
34	JAO	RED-BRN	EXPANSION	JAO	REMOTE ALARM	-MAJOR
9	JAI	BRN-RED	22	JA1	REMOTE ALARM	-MAJOR
35	NAO	RED-SL	(6PFT/6PFE)	NAO	REMOTE ALARM	-MAJOR
10	NA1	SL-RED		NA1	BASIC	-JA0/1
36						

6PFT and 6PFE Cards Installation (Continued)



GTE OMNI SBCS




- IF 6PFE IS USED IN SINGLE CABINET ONLY (STANDARD SYSTEM CONFIGURATION) OR IS INSTALLED IN BASIC CABINET (EXPANDED SYSTEM CONFIGURATION), THEN TOGGLE SWITCH MUST BE SET FOR BASIC MODE (SEE ABOVE).
- IF 6PFE IS USED IN EXPANSION CABINET (EXPANDED SYSTEM CONFIGURATION), THEN TOGGLE SWITCH MUST BE SET FOR EXPANSION MODE.



6PFT and 6PFE Card Installation (Continued)

GTE OMNI SBCS

6PFT AND 6PFE CROSS CONNECTION




Data Interface Unit (DIU) Installation




GTE OMNI SBCS


- DIAGRAM REPRESENTS A TYPICAL EXAMPLE OF CROSS CONNECTIONS FOR A DIU INSTRUMENT.
- EACH DIU REQUIRES ONLY ONE PAIR OF WIRES FOR TIP AND RING. ON THE CDF TERMINAL BLOCK, ONLY EVERY OTHER PAIR OF WIRES IS USED.
- EXAMPLE ILLUSTRATES A CDF CROSS CONNECTION FOR AN 8DTC INTERFACE CARD IN SLOT 00, USING CABLE NUMBER (CN)0. CONNECTOR BLOCK WOULD HANDLE ALL EIGHT CIRCUITS FOR THE CARD SLOT IDENTIFIED ABOVE.
- REFER TO CDF CROSS CONNECTION REFERENCE IN STUDENT WORKBOOK, INSTALLATION MODULE FOR CROSS CONNECTION INSTRUCTIONS FOR OTHER CARD AND EQUIPMENT CONFIGURATIONS.



TERMINAL BLOCK



TIP
RING



MODULAR CABLE




DATA INTERFACE UNIT

25 PAIR CABLE

TYPICAL DIU CROSS CONNECTION

Installation of Data Interface Unit (DIU) with Printer, Modem, or Data Terminal





DESCRIPTION

- DIU IS CONNECTED DIRECTLY TO A CIRCUIT ON THE 8DTC CARD AND USES ONE 64 KBPS CHANNEL.
- THE DIU CAN ACCOMMODATE A PRINTER, DATA TERMINAL, OR MODEM (DTE/DCE) OF UP TO 19.2 KBPS SYNCHRONOUS/ASYNCHRONOUS WITH ITS RS-232-C INTERFACE.

PROCEDURE


- WIRE CROSS CONNECTION FOR THE DIU TO A CDF TERMINAL BLOCK FROM A CIRCUIT ON THE 8DTC CARD (REFER TO CDF CROSS CONNECTION TABLE IN GTEP MANUAL).
- FOR HOTEL/MOTEL CONFIGURATION CONNECT THE PRINTER TO THE DIU WITH RS-232-C CABLE. THE PRINTER AND DIU MUST BE IN DATA TERMINAL EQUIPMENT (DTE) MODE.
- FOR USE WITH A MODEM, CONNECT MODEM TO DIU WITH RS-232-C CABLE. THE DIU MUST BE IN DATA COMMUNICATION EQUIPMENT (DCE) MODE.



Attendant Console Installation



GTE OMNI SBCS




DESCRIPTION

- EACH ATTENDANT CONSOLE REQUIRES TWO PAIRS OF WIRES: ONE PAIR FOR TIP AND RING, THE OTHER FOR DATA/POWER.
- REFER TO EKT CROSS CONNECTION REFERENCE CHART IN MODULE I, FOR CROSS CONNECT WIRING INSTRUCTIONS.
- ATTENDANT CONSOLE CAN BE LOCATED UP TO 300 FEET FROM SYSTEM CABINET USING 24 AWG CABLE WITH FOUR LEAD WIRING (ONE PORT) AS DESCRIBED ABOVE.
- FOR DISTANCES OF UP TO 2000 FEET, TWO PORTS CAN BE WIRED (AS ILLUSTRATED IN DIAGRAM ON FOLLOWING PAGE), USING ONE ADDITIONAL PAIR OF DATA/POWER LEADS.



Expansion Cabinet Installation

GTE OMNI SBCS



DESCRIPTION

- INSTALLATION OF SECOND (EXPANSION) CABINET FOR EXPANDED SYSTEM CONFIGURATION REQUIRES CONNECTION OF SWB CARD (IN BASIC CABINET) TO SWE CARD (IN EXPANSION CABINET) USING AN INTERMODULE CABLE.

PROCEDURE


- ENSURE THAT SYSTEM POWER IS OFF FOR BOTH CABINETS.
- GROUND END OF INTERMODULE CABLE CONNECTED TO BASIC CABINET, THEN CONNECT CABLE TO BASIC CABINET DOOR WITH BASIC CABINET SCREW.
- THREAD CABLE THROUGH OPENINGS IN BOTTOM OF BOTH BASIC AND EXPANSION CABINETS.
- CONNECT CABLE TO EXPANSION CABINET DOOR WITH EXPANSION CABINET SCREW.
- CONNECT SIGNAL GROUND WIRES (AS ILLUSTRATED IN DIAGRAM) FOR BOTH CABINETS.
- CONNECT FRAME GROUND WIRES (AS ILLUSTRATED IN DIAGRAM) FOR BOTH CABINETS.



Hotel/Motel Printer Installation

GTE OMNI SBCS

HOTEL/MOTEL PRINTER INTERFACE



PROCEDURE

1. ENSURE THAT 4CHT CARD IS INSTALLED IN SYSTEM.
2. CONNECT DIU TO SYSTEM VIA TWO WIRE INTERFACE (TO 8DTC CARD OR CONNECT TO DTA ADAPTER).
3. CONNECT THE HOTEL/MOTEL PRINTER TO THE RS-232-C PORT OF THE DIU OR DTA.
4. PROGRAM REQUIRED DATA BASE ENTRIES.

Hotel/Motel Printer Installation (Continued)



GTE OMNI SBCS

HOTEL/MOTEL COMMUNICATION REQUIREMENTS

<u>ITEM</u>	<u>REQUIREMENT*</u>
INTERFACE	RS-232-C, DTE MODE
SPEED	ASYNCHRONOUS, UP TO 19.2 KBPS
CODE	7 BIT ASCII
PARITY	NONE/ODD/EVEN
CHARACTER LENGTH	7 BIT/8 BIT**, 80 CHARACTERS
STOP BIT	1 BIT/2 BIT
ON/OFF OPTION	AVAILABLE
POWER ON/OFF OPTION	NOT AVAILABLE

* CONFIGURATION CAN BE MODIFIED BY USING MAINTENANCE COMMANDS (CMC-222 AND CMC-223), ACCORDING TO THE CHARACTERISTICS OF THE INSTALLED PRINTER.

** WHEN 8 BIT OPTION IS SELECTED, THE MOST SIGNIFICANT BIT MUST BE A SPACE OR A ZERO.

Hotel/Motel Printer Installation (Continued)



GTE OMNI SBCS

HOTEL/MOTEL PRINTER AND DIU/DTA RS-232-C PIN CONFIGURATION

<u>H/M PRINTER</u>		<u>DIU/DTA</u>	
FG	1	1	FG
TXD	2	2	TXD
RXD	3	3	RXD
RTS	4	4	RTS
CTS	5	5	CTS
DSR	6	6	DSR
SG	7	7	SG
RLSD	8	8	RLSD
DTR	20	20	DTR
25 PIN		25 PIN	

Laboratory Activity — Package C Installation; (5.2)



GTE OMNI SBCS

1. POWER SYSTEM OFF.
2. ENSURE THAT PROPER ELECTROSTATIC GROUND PROCEDURES ARE FOLLOWED PRIOR TO HANDLING PCB CARDS.
3. BEGIN REPLACING AND INSTALLING THE DESIGNATED PRINTED CIRCUIT BOARDS IN CARD SLOTS IDENTIFIED BELOW. ENSURE THAT CARD COMPONENTS ARE ON LEFT SIDE OF THE BOARDS.
 - (A) INSERT AND SEAT A CHARACTER TRUNK CARD (4CHT) IN CARD SLOT 14.
 - (B) REPLACE THE CPMB CARD IN SLOT 20 WITH THE PACKAGE C ENHANCED CONTROL PROCESSOR MEMORY CARD (CPMC).
 - (C) REPLACE THE MEMB CARD IN SLOT 21 WITH THE PACKAGE C ENHANCED MEMORY CARD (MEMC).
4. REMOVE THE CS-20 PREVIOUSLY WIRED TO CARD SLOT 01, CIRCUIT 4 (FORMERLY DIRECTORY NUMBER 212). REPLACE THE INSTRUMENT WITH AN ATTENDANT CONSOLE INSTRUMENT.
5. REMOVE THE BLF/DSS MODULE PREVIOUSLY WIRED TO CARD SLOT 01, CIRCUIT 5. REPLACE THE MODULE WITH AN ATTENDANT CONSOLE BLF/DSS MODULE WHICH WILL BE USED FOR ROOM STATUS INDICATION.
6. WIRE CROSS CONNECTION AND INSTALL A DATA INTERFACE UNIT (WITH ATTACHED PRINTER) TO CARD SLOT 00, CIRCUIT 2. DEFAULT DIRECTORY NUMBER WILL BE 202.
7. POWER SYSTEM ON AND COLD RESTART SYSTEM BY PRESSING RESTART BUTTON ON CPMC CARD WITH TOGGLE SWITCH IN UPPER POSITION.
6. REPROGRAM THE ODDB.
9. TEST OPERATION OF PACKAGE C PERIPHERALS.

Review Exercise — Package C Installation (5.2)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. _____ (TRUE OR FALSE) THE 6PFE CARD CAN PROVIDE POWER FAILURE TRANSFER INTERFACES FOR THE STANDARD OR EXPANDED SYSTEMS, IF INSTALLED IN SLOT 22 OF BOTH BASIC OR EXPANSION CABINETS.
2. IF THE 6PFE CARD IS USED IN THE EXPANSION CABINET, THE CARD'S _____ MUST BE SET IN EXPANSION MODE.
3. EACH DATA INTERFACE UNIT (DIU) REQUIRES INSTALLATION OF _____ PAIR OF WIRES ON THE TERMINAL BLOCK.
4. DATA INTERFACE UNITS USED WITH MODEMS MUST BE IN _____ MODE TO COMMUNICATE VIA THE RS-232-C CABLE.
5. HOW CAN AN ATTENDANT CONSOLE BE INSTALLED TO ACCOMMODATE DISTANCES GREATER THAN 300 FEET FROM THE SYSTEM CABINET?

6. INSTALLATION OF EXPANSION CABINET REQUIRES CONNECTION OF AN INTERMODULE CABLE FROM THE _____ CARD IN THE BASIC CABINET TO THE _____ CARD IN THE EXPANSION CABINET.

Review Exercise — Package C

Installation (5.2) (Continued)



GTE OMNI SBCS

7. _____ (TRUE OR FALSE) THE HOTEL/MOTEL PRINTER IS CONNECTED DIRECTLY TO THE SYSTEM VIA A TWO-WIRE INTERFACE TO A CIRCUIT ON THE 4CHT CARD.
8. INSTALLATION OF POWER TRANSFER FOR THE EXPANDED SYSTEM REQUIRES CROSS CONNECTIONS FOR THE _____, AND _____, SIGNAL LEADS ON THE 6PFT AND 6PFE CARDS.
9. AN ATTENDANT CONSOLE CROSS CONNECTED TO CIRCUIT 4 OF AN 8EKC CARD INSTALLED IN SLOT 01 WOULD USE PINS _____, AND _____, ON THE CDF TERMINAL BLOCK.
10. A DATA INTERFACE UNIT CROSS CONNECTED TO CIRCUIT 2 OF AN 8DTC CARD INSTALLED IN SLOT 00 WOULD USE PINS _____ AND _____ ON THE CDF TERMINAL BLOCK.



GTE OMNI SBCS

PACKAGE C

Data Base Administration



GTE OMNI SBCS

5.3 Enabling Objective

GIVEN:

- GTE OMNI SBCS
- GTE OMNI SBCS PACKAGE C EQUIPMENT AND PERIPHERALS
- PROGRAMMING DEVICE (PMP OR MCT)
- OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
- REVIEW EXERCISE



- IDENTIFY FUNCTIONS AND APPLICATIONS OF PACKAGE C CMC COMMANDS.
- PERFORM SYSTEM PROGRAMMING TASKS RELATED TO ATTENDANT CONSOLE, HOTEL/MOTEL, KEY SYSTEM, AND DID/DISA APPLICATIONS.
- COMPLETE REVIEW EXERCISE.

CRITERIA:

- DEMONSTRATION OF ABOVE TASKS IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
- REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Programming Attendant Console



GTE OMNI SBCS

DESCRIPTION

- ATTENDANT CONSOLE PROVIDES A VARIETY OF FEATURES ALLOWING FOR ANSWERING, TRANSFERRING, AND PROCESSING OF CALLS USING FIXED AND PROGRAMMABLE FEATURE BUTTONS AND ACCESS CODES.
- TWO ADD ON MODULES ARE AVAILABLE TO SUPPLEMENT THE OPERATION OF THE ATTENDANT CONSOLE: A BUSY LAMP FIELD/DIRECT STATION SELECTION (BLF/DSS) MODULE AND A ROOM STATUS INDICATOR MODULE.

PROCEDURE

- IDENTIFY CIRCUIT PORT ON 8KVC CARD TO BE USED FOR CONNECTION. (IF ATTENDANT CONSOLE IS TO BE PLACED MORE THAN 300 FEET FROM SYSTEM CABINET, A SECOND DATA PAIR WILL BE REQUIRED.)
- INSTALL ATTENDANT CONSOLE.
- ASSIGN ATTENDANT CONSOLE WITH CMC-230:
 - ATTENDANT CONSOLE (PI) - (1 OR 2)
 - EQUIPMENT NUMBER (P2)
 - TENANT NUMBER (P3) - (1 - 4)
 - ATTENDANT CONSOLE NUMBER FOR COPY (P4)

CMC= 230	
P1:	P4:
P2: 010	
P3:	

NOTE: THE ATTENDANT CONSOLE CAN BE INSTALLED OR REMOVED ONLY IN AN OFF LINE (POSITION BUSY) STATE. ATTENDANT CONSOLE CAN BE REMOVED ONLY IF BLF/DSS IS ATTACHED.

Programming Attendant Console (Continued)



GTE OMNI SBCS

PROCEDURE (Continued)

4. ASSIGN ATTENDANT CONSOLE SERVICES TO FEATURE BUTTONS WITH CMC-231:

- . ATTENDANT CONSOLE NUMBER (PI) - (1 OR 2)
- . BUTTON NUMBER (P2) - (1 - 16)
- . FEATURE NUMBER (P3) - (1 - 255)
- . SUPPLEMENTARY DATA (P4)

CMC= 231
P1: 1 P4:
P2: 1
P3: 50

5. ASSIGN ATTENDANT CONSOLE CLASS OF SERVICE (COS) AND CLASS OF RESTRICTION (COR) ASSIGNMENT WITH CMC-232:

- . ATTENDANT CONSOLE NUMBER (P1) - (1 OR 2)
- CLASS OF SERVICE - DAY MODE (P2) - (1 - 16)
- CLASS OF SERVICE - NIGHT MODE (P3) - (1 - 16)
- CLASS OF RESTRICTION - DAY MODE (P4) - (1 - 16)
- . CLASS OF RESTRICTION-NIGHT MODE (P5) - (1 - 16)

CMC= 232
P1: 1 P4: 1
P2: 1 P5: 16
P3: 16

6. ASSIGN ATTENDANT CONSOLE PRIORITY FOR INCOMING CALL TERMINATION WITH CMC-233:

- . TRUNK GROUP NUMBER (PI) - (1 - 63)
- . ANSWER PRIORITY (P2) - (1 = HIGH to 3 = LOW)

CMC= 233
P1: 13
P2: 1

Programming Attendant Console (Continued)



GTE OMNI SBCS

PROCEDURE (Continued)

7. CREATE NIGHT ANSWER GROUP FOR ATTENDANT CONSOLE OVERFLOW STATION WITH CMC-306:

- . NIGHT ANSWER GROUP NUMBER (P1) - (1 - 32)
- . TRUNK/STATION TENANT FLAG (P2) - (1 = STATION, 2 = TRUNK; 3 = TENANT)
- EQUIPMENT NUMBER (P3) - (STATION TO RECEIVE OVERFLOW CALLS)

```
CMC= 306
P1: 1
P2: 1
P3: 016
```

8. ASSIGN "ALL TENANTS" TO ATTENDANT CONSOLE OVERFLOW NIGHT ANSWER GROUP (ASSIGNED ABOVE) WITH CMC-306:

- NIGHT ANSWER GROUP NUMBER (P1)
- . TRUNK/STATION TENANT (P2) - (1 = STATION, 2 = TRUNK, 3 = TENANT)
- . EQUIPMENT NUMBER (P3) - (ASSIGN "*" TO INDICATE ALL TENANTS)


```
CMC= 306
P1: 1
P2: 3
P3: *
```


Programming Attendant Console (Continued)



GTE OMNI SBCS

ATTENDANT CONSOLE NUMBERING PLAN FOR PROGRAMMING ASSIGNABLE FEATURES (CMC-231)



Programming Attendant Console/CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
. ATTENDANT ASSIGNMENT	CMC-230	ASSIGNS ATTENDANT CONSOLE IN SYSTEM
. ATTENDANT BUTTON ASSIGNMENT	CMC-231	ASSIGNS ATTENDANT CONSOLE SERVICES TO FEATURE BUTTONS
. ATTENDANT COS/COR ASSIGNMENT	CMC-232	ASSIGNS ATTENDANT CONSOLE COS/OCR FOR DAY OR NIGHT MODE
• ATTENDANT QUEUE AND PRIORITY ASSIGNMENT	CMC-233	REGISTERS THE PRIORITY FOR ANSWERING INCOMING CALLS TO ATTENDANT CONSOLE
• ATTENDANT OVERFLOW STATION ASSIGNMENT	CMC-306	CREATES NIGHT ANSWER GROUP FOR ATTENDANT CONSOLE OVERFLOW STATION AND ASSIGNS TENANTS TO OVERFLOW NIGHT ANSWER GROUP

Programming Hotel/Motel Features



GTE OMNI SBCS

DESCRIPTION

PROGRAMMABLE HOTEL/MOTEL FEATURES INCLUDE:

- MESSAGE REGISTRATION FOR BILLING OF LOCAL CALLS TO ROOMS
- SPECIAL SERVICE CODES WHICH ENABLE ROOMS TO DIAL SPECIFIC SERVICES (ROOM SERVICE)
- ROOM STATUS INDICATOR WHICH VISUALLY DISPLAYS STATUS OF ROOMS (VACANT/OCCUPIED)
- HOTEL/MOTEL PRINTER WHICH PROVIDES PRINTOUT OF WAKE-UP CALLS AND ROOM CHARGES

PROCEDURE

1. ASSIGN FRONT DESK CONSOLE PROGRAM BUTTON TO FRONT DESK CONSOLE WITH CMC-283 (CSD) OR CMC-231 (ATTENDANT CONSOLE):

CMC-203 -

- . STATION DIRECTORY NUMBER (P1) - (1 -4 DIGITS)
- . BUTTON NUMBER (P2) - (1 - 14)
- . FEATURE NUMBER (P3) - (FNO 188)
- . SUPPLEMENTARY DATA (P4) - (NOT APPLICABLE/BLANK)
- . LINE TERMINATION TYPE (P5) - (NOT APPLICABLE/BLANK)
- . RINGING MODE (P6) - (NOT APPLICABLE/BLANK)

CMC = 203			
P1:	001	P4:	
P2:	6	P5:	
P3:	188	P6:	

CMC-231 -

- ATTENDANT CONSOLE NUMBER (P1) - (1 or 2)
- . BUTTON NUMBER (P2) (1 - 16)
- . FEATURE NUMBER (P3) - (FNO 188)
- . SUPPLEMENTARY DATA (P4) - (NOT APPLICABLE/BLANK)

CMC = 231			
P1:	1	P4:	
P2:	10		
P3:	188		

Programming Hotel/Motel Features (Continued)



GTE OMNI SBCS

(PROCEDURE *i*n *u*e *d*)

2. IDENTIFY STATION DIRECTORY NUMBERS AS HOTEL/MOTEL GUEST ROOMS WITH CMC-204:

- . STATION DIRECTORY NUMBER (P1)
- . DATA SECURE SPEECH PATH (P2)
- OFF-PREEMISES EXTENSION (P3)
- . SLT WITH MESSAGE WAITING (P4)
- . GUEST ROOM FLAG (P5) - (0 OR BLANK = NOT A GUEST ROOM, 1 = GUEST ROOM)

CMC= 204
P1: 216 P4: 1
P2: 0 P5: 1
P3: 0

3. ASSIGN ROOM STATUS INDICATOR WITH CMC-354:

- . ROOM STATUS EQUIPMENT NUMBER (P1) - (1 OR 2)
- . ROOM STATUS INDICATOR BUTTON (P2) - (1 = 40 BUTTON BLF/DSS, 2 = 80 BUTTON BLF/DSS)
- . EQUIPMENT NUMBER (P3)

CMC= 354
P1: 1
P2: 2
P3: 001

NOTE: REMOVE BLF/DSS ALREADY ASSIGNED WITH CMC-210

4. ASSIGN ROOM STATUS INDICATOR LAMP WITH CMC-355:

- . ROOM STATUS INDICATOR NUMBER (P1) - (1 OR 2)
- . BUTTON NUMBER (P2) - (1 - 80)
- . DIRECTORY NUMBER (P3) - (1 - 4 DIGITS)

CMC= 355
P1: 1
P2: 1
P3: 200

5. ASSIGN HOTEL/MOTEL PRINTER WITH CMC-356:

- . PRINTER NUMBER (P1) - (1 OR 2)
- . CHARACTER TRUNK EQUIPMENT NUMBER (P2)-(1 - 4)
- . DIU/DTA DIRECTORY NUMBER (P3) - (1 - 4 DIGITS, OR BLANK WHEN UNREGISTERED)

CMC= 356
P1: 1
P2: 080
P3: 4400

Programming Hotel/Motel Features (Continued)



GTE OMNI SBCS

PROCEDURE (Continued)

6. ASSIGN HOTEL/MOTEL PRINTOUT MESSAGE ALLOCATION, WITH CMC-357:

- . PRINTER NUMBER (P1) - (1 OR 2)
- . MESSAGE IDENTIFICATION NUMBER (P2)* -
(1 = INDEPENDENT MESSAGE,
2 = COMMON MESSAGE)
- NOTE: REFER TO TABLE BELOW
- P2 = 1 (REQUIRED IF ATTENDANT CONSOLE)

CMC= 357
P1: 1
P2: 1
P3: 01

BOTH TYPES OF MESSAGES CAN BE RECORDED

- . FRONT DESK CONSOLE DIRECTORY NUMBER (P3) - (1 - 4 DIGITS: ATTENDANT ACCOUNT CODE + ATTENDANT NUMBER)

HOTEL/MOTEL MESSAGES

INDEPENDENT MESSAGES	COMMON MESSAGES
(a) AUTOMATIC WAKE-UP STATUS (FOR ALL GUEST ROOM STATIONS UNDER REGISTRATION OF SERVICE)	(e) AUTOMATIC WAKE-UP REGISTRATION/CANCELLATION BY GUEST ROOM
(b) AUTOMATIC WAKE-UP REGISTRATION/CANCELLATION BY FRONT DESK CONSOLE	(f) AUTOMATIC WAKE-UP EXECUTION
(c) MESSAGE REGISTRATION STATUS (FOR ALL GUEST ROOM STATIONS UNDER REGISTRATION OF SERVICE)	(g) RTS FAILURE/REPAIR/CHANGE
(d) MESSAGE REGISTRATION ADDED/INITIALIZED/VERIFIED	

- NOTES: (1) UP TO TWO FRONT DESK CONSOLES CAN BE ASSIGNED TO HOTEL/MOTEL PRINTER 1 or 2
 (2) INDEPENDENT MESSAGES, ACCORDING TO ONE FRONT DESK CONSOLE, CANNOT BE PRINTED OUT TO TWO HOTEL/MOTEL PRINTERS
 (3) THE (b), (d), AND (f) MESSAGES CAN BE OMITTED BY SETTING THE ALLOW/DENY FLAG WITH CMC-358.

Programming Hotel/Motel Features (Continued)



GTE OMNI SBCS

(PROCEDURE needed)

7. ASSIGN HOTEL/MOTEL SERVICE PARAMETERS WITH CMC-358:

- . FLAG NUMBER (P1) • (1 - 32)
- . STATUS VALUE (P2) • (REFER TO TABLE BELOW)

CMC= 358
P1: 1
P2: 1

HOTEL/MOTEL OPTION DATA

FLAG NUMBER	DEFINITION	STATUSVALUE
1	HOTEL/MOTEL MESSAGE PRINTOUT (WAKE-UP REGISTRATION)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TO PRINT OUT THE CORRESPONDING INFORMATION
2	HOTEL/MOTEL MESSAGE PRINTOUT (WAKE-UP CANCELLATION)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TO PRINT OUT THE CORRESPONDING INFORMATION
3	HOTEL/MOTEL MESSAGE PRINTOUT (WAKE-UP ANSWER)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TO PRINT OUT THE CORRESPONDING INFORMATION
4	HOTEL/MOTEL MESSAGE PRINTOUT (WAKE-UP NO ANSWER)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TGO PRINT OUT THE CORRESPONDING INFORMATION
5	HOTEL/MOTEL MESSAGE PRINTOUT (MESSAGE REGISTRATION ADDED)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TO PRINT OUT THE CORRESPONDING INFORMATION
6	HOTEL/MOTEL MESSAGE PRINTOUT (MESSAGE REGISTRATION INITIALIZED)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TO PRINT OUT THE CORESPONDING INFORMATION
7	HOTEL/MOTEL MESSAGE PRINTOUT (MESSAGE REGISTRATION VERIFY-VACANT)	0 = NOT TO PRINT OUT THE CORRESPONDING INFORMATION 1 = TO PRINT OUT THE CORRESPONDING INFORMATION
8	CLEAN UP FLAG	0 = NOT TO APPLY CLEAN UP STATE 1 = TO APPLY CLEAN UP STATE
9	ROOM STATUS OPTION FLAG (LINE LOCK OUT)	0 = NOT TO DISPLAY 1 = TO DISPLAY
10	ROOM STATUS OPTION FLAG (WAKE-UP NO ANSWER)	0 = NOT TO DISPLAY 1 = TO DISPLAY
11	ROOM STATUS OPTION FLAG (DND REGISTRATION)	0 = NOT TO DISPLAY 1 = TO DISPLAY
12	ROOM TO ROOM BLOCKING FLAG	0 = NOT TO RESTRICT 1 = TO RESTRICT
13	VACANT ROOM RESTRICTION (INCOMING STATION CALL)	0 = NOT TO RESTRICT 1 = TO RESTRICT
14	VACANT ROOM RESTRICTION FLAG (OUTGOING TRUNK CALL)	0 = NOT TO RESTRICT 1 = TO RESTRICT
15	SERVICE CALL ROUTING BASE FLOOR (BASFLW)	1 to 99
16	RESERVED	
32	RESERVED	

Programming Hotel/Motel Features (Continued)



GTE OMNI SBGS

PROCEDURE (Continued)

8. ASSIGN MESSAGE REGISTRATION TRUNK GROUP NUMBER WITH CMC-350:

- . TRUNK GROUP NUMBER (P1)
- . MESSAGE REGISTRATION FLAG (P2)
(0 = TGN NOT SUBJECT TO MESSAGE REGISTRATION,
1 = TGN SUBJECT TO THE MESSAGE REGISTRATION)

CMC= 350
P1: 13
P2: 1

9. ASSIGN MESSAGE REGISTRATION OFFICE CODE WITH CMC-351:

- . BILLING RATE NUMBER (P1) - (1 - 6)
- . OFFICE CODE (P2)

CMC= 351
P1: 1
P2: 476

10. ASSIGN MESSAGE REGISTRATION BILLING RATE WITH CMC-352:

- . BILLING RATE NUMBER (P1) - (1 - 6)
- INITIAL TIME FOR THE TELEPHONE CALL (P2) (1 - 400 SECONDS)
- . INITIAL CHARGE FOR TELEPHONE CALL (P3) - (0 - 255 CENTS)
- . ADDITIONAL TIME FOR TELEPHONE CALL (P4) - (1 - 400 SECONDS)
- . ADDITIONAL CHARGE FOR TELEPHONE CALL (P5) - (0 - 255 CENTS)

L - J

CMC= 352
P1: 1 P4: 60
P2: 20 P5: 30
P3: 50

11. ASSIGN SPECIAL SERVICE CODES/SERVICE CALL ROUTING ASSIGNMENT WITH CMC-353:

- FEATURE ACCESS CODE (P1)* - (1 - 4)
- . FEATURE SELECTION CONTROL (P2) - (1 = SPECIAL SERVICE,
2 = SERVICE CALL ROUTING)
- DESTINATION DIRECTORY NUMBER (P3) - (1 - 4 DIGITS)
- . GUEST ROOM FLOOR NUMBER (P4) - (1 - 99)

CMC= 353
P1: 3 P4: 2
P2: 2
P3: 285

* FROM ACCESS CODES ASSIGNED WITH CMC-100

Programming Hotel/Motel Features (Continued)



GTE OMNI SBCS

HOTEL/MOTEL PRINTER OUTPUT FORMAT

MESSAGE TYPE	OUTPUT
AUTOMATIC WAKE-UP	
REGISTRATION:	mm/dd hh:mm WAKE-UP REG rrrr hh:mm ¹ hh:mm ² BY rrrr
CANCELLATION:	mm/dd hh:mm WAKE-UP CNCL rrrr hh:mm ¹ BY rrr
EXECUTION:	*mm/dd hh:mm WAKE-UP CALL rrrr ssssssss
REPORT:	mm/dd hh:mm WAKE-UP REGISTRATION PRINT OUT hh:mm ² rrrr rrrr rrrr rrrr rrrr eeeeee BY rrrr
NOTE:	mm/dd hh:mm = operated day and time rrrr = registered, cancelled, or verified room number hh:mm ¹ = old wake-up time hh:mm ² = new or current wake-up time BY rrrr = operated station number ssssssss = wake-up call status (answer, no answer, busy, or no ring) eeeeee = completion message (end or cancel) wake-up no answer sign
MESSAGE ** = REGISTRATION	
ADDITION:	mm/dd hh:mm MESSAGE ADDED rrrr \$ddd.cc ¹ \$ddd.cc BY rrrr
CLEAR:	mm/dd hh:mm MESSAGE CLEARED rrrr \$ddd.cc ¹ BY rrrr
VERIFICATION:	mm/dd hh:mm MESSAGE VERIFIED rrrr \$ddd.cc BY rrrr
REPORT:	mm/dd hh:mm MESSAGE REGISTRATION PRINT OUT rrrr \$ddd.cc rrrr \$ddd.cc rrrr \$ddd.cc rrrr \$ddd.cc rrrr \$ddd.cc eeeeee BY rrrr
NOTE:	mm/dd hh:mm = operated day and time rrrr = registered, cancelled, or verified room number \$ddd.cc ¹ = old or current message \$ddd.cc = new message BY rrrr = operated station number eeeeee = completion message (end or cancel)

Programming Hotel/Motel Features (Continued)



GTE OMNI SBCS

HOTEL/MOTEL PRINTER OUTPUT FORMAT (CONTINUED)

MESSAGE TYPE	OUTPUT
OTHER	
SHORT POWER FAILURE:	POWER FAIL
PRINTER FAILURE:	PRINTER FAILURE
REAL TIME CLOCK FAILURE:	CLOCK FAIL hh:mm CHECK WAKE-UP
REAL TIME CLOCK REPAIR:	CLOCK REPAIR hh:mm CHECK WAKE-UP
REAL TIME CLOCK CHANGE:	CLOCK CHANGE hh:mm CHECK WAKE-UP

Programming Hotel/Motel Features — CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
. FRONT DESK CONSOLE PROGRAM BUTTON ASSIGNMENT	CMC-203 (CSD) CMC-231 (ATTENDANT CONSOLE)	ASSIGNS FRONT DESK CONSOLE PROGRAM BUTTON TO CSD OR ATTENDANT CONSOLE DESIGNATED AS FRONT DESK CONSOLE
. CHANGE GUEST ROOM FLAG	CMC-204	IDENTIFIES STATION DIRECTORY NUMBERS AS HOTEL/MOTEL GUEST ROOMS
. ROOM STATUS INDICATOR ASSIGNMENT	CMC-354	ASSIGNS A BLF/DSS MODULE IN SYSTEM AS A ROOM STATUS INDICATOR MODULE
. ROOM STATUS INDICATOR LAMP ASSIGNMENT	CMC-355	ASSIGNS GUEST ROOM NUMBERS TO ROOM STATUS INDICATOR LAMPS
. HOTEL/MOTEL PRINTER ASSIGNMENT	CMC-356	ASSIGNS THE HOTEL/MOTEL PRINTER IN THE SYSTEM
. HOTEL/MOTEL PRINT OUT MESSAGE ALLOCATION	CMC-357	ASSIGNS THE INDEPENDENT AND COMMON PRINTER MESSAGES TO EACH HOTEL/MOTEL PRINTER
. HOTEL/MOTEL PARAMETER ASSIGNMENT	CMC-358	ASSIGNS PARAMETERS FOR DESIGNATED HOTEL/MOTEL SERVICES
. MESSAGE REGISTRATION TRUNK GROUP NUMBER SCREENING ASSIGNMENT	CMC-350	ASSIGNS TRUNK GROUP NUMBERS FOR HOTEL/MOTEL MESSAGE REGISTRATION
. MESSAGE REGISTRATION OFFICE CODE ASSIGNMENT	CMC-351	ASSIGNS OFFICE CODES CORRESPONDING TO BILLING RATE NUMBERS
. MESSAGE REGISTRATION BILLING RATE ASSIGNMENT	CMC-352	ASSIGNS TIME AND RATE CHARGES FOR MESSAGE REGISTRATION BILLING RATE NUMBERS
. SPECIAL SERVICE CODES/SERVICE CALL ROUTING ASSIGNMENT	CMC-353	ASSIGNS SPECIAL SERVICE CODES AND SERVICE CALL ROUTING TO ACCESS CODES FOR DESTINATION DIRECTORY NUMBERS AND/OR GUEST ROOM FLOOR NUMBERS

Direct Inward System Access Standard (DISA-S) Programming



GTE OMNI SBCS

DESCRIPTION

- FEATURE PROVIDES DIRECT ACCESS TO SYSTEM FEATURES FROM ANY REMOTE LOCATION.
- DISA-S IS ASSIGNED TO A GROUND START CO TRUNK AT A 4BWC PORT.
- . USERS OUTSIDE THE SYSTEM MAY ACCESS ASSIGNED DISA-S TRUNK VIA A DTMF TELEPHONE AND THEN ENTERING AN ACCESS CODE.
- . USERS HAVE ACCESS TO THE FOLLOWING FEATURES:
 - STATION CALL
 - ATTENDANT CALL
 - OUTGOING TRUNK LINES (CO, TIE, WATS, FX)
 - LCR
 - SCC
 - SYSTEM SPEED DIALING
 - EKT PAGING ACCESS
 - EXTERNAL PAGING

PROCEDURE

1. ASSIGN DISA-S TO A GROUND START TRUNK WITH CMC-250:

- . EQUIPMENT NUMBER (P1)
- . TYPE OF TRUNK (P2) - (6 = CO)
- . TRUNK GROUP NUMBER (P3)
- . OPERATION MODE (P4) - (1 = INCOMING TRUNK,
3 = BOTHWAY TRUNK)
- . SIGNALING (P5) - (1 = GROUND OR E & M)
- . DISA-S (P6) - (2 = DISA-S)

CMC= 250	
P1: 180	P4: 1
P2: 6	P5: 1
P3: 14	P6: 2

Direct Inward System Access Programming (Continued)



GTE OMNI SBCS

PROCEDURE (Continued)

2. ASSIGN COS/COR TO DISA-S TRUNK WITH CMC-252:

- . TRUNK GROUP NUMBER (PI)
- . CLASS OF SERVICE DAY (P2) - (1 - 16)
- . CLASS OF SERVICE NIGHT (P3) - (1 - 16)
- . CLASS OF RESTRICTION DAY (P4) - (1 - 16)
- . CLASS OF RESTRICTION NIGHT (P5) - (1 - 16)

CMC= 252
P1: 14 P4: 1
P2: 1 P5: 16
P3: 16

3. ASSIGN DISA-S AUTHORIZATION CODE WITH CMC-432:

- . AUTHORIZATION CODE (P1) - (1 - 8 DIGITS OR BLANK)

CMC= 432
P1: 1234

Direct Inward System Access – Standard Programming – CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
• DISA-S TRUNK ASSIGNMENT	CMC-250	ASSIGNS DIRECT SYSTEM INWARD ACCESS (STANDARD) TO A GROUND START TRUNK
• DISA-S TRUNK COS/COR ASSIGNMENT	CMC-252	ASSIGNS TRUNK COS/COR TO DISA-STANDARD TRUNK
• DISA-S AUTHORIZATION CODE ASSIGNMENT	CMC-432	ASSIGNS THE AUTHORIZATION CODE FOR THE DISA-STANDARD FEATURE

Direct Inward Dialing (DID) Programming



GTE OMNI SBCS

DESCRIPTION

- . ALLOWS INCOMING CALLS ON DID TRUNK TO BYPASS ATTENDANT CONSOLE AND DIRECTLY RING STATION
- . DID TRUNKS ARE TERMINATING-ONLY TRUNKS AND ARE ASSIGNED ONLY TO 2TTE OR 2TTL PORTS.

PROCEDURE

1. ASSIGN DID TRUNK WITH CMC-250:

- . EQUIPMENT NUMBER (P1)
- . TYPE OF TRUNK (P2) - (5 = DID E & M, 13 = DID LD)
- . TRUNK GROUP NUMBER (P3) - (57 - 62)
- . OPERATION MODE (P4) - (1 = INCOMING TRUNK)
- . SIGNALING (P5) - (1 = GROUND OR E & M)
- . START MODE (P6) - (1 = WINK START, 2 = DELAY START, 3 = IMMEDIATE START)

CMC= 250
P1: 160 P4: 1
P2: 5 P5: 1
P3: 57 P6: 3

2. ASSIGN COS/COR TO TRUNK WITH CMC-252:

- TRUNK GROUP NUMBER (P1) - (57 - 62)
- . CLASS OF SERVICE DAY (P2)
- . CLASS OF SERVICE NIGHT (P3)
- . CLASS OF RESTRICTION DAY (P4)
- . CLASS OF RESTRICTION NIGHT (P5)

CMC= 252
P1: 57 P4: 1
P2: 1 P5: 16
P3: 16

Direct Inward Dialing (DID) Programming (Continued)



GTE OMNI SBCS

PROCEDURE (Continued)

3. ASSIGN RECEIVED DIGIT LENGTH AND PREFIX CODE TO DID TRUNKS WITH CMC-430:

- . TRUNK GROUP NUMBER (P1) - (57 - 62)
- RECEIVED DIGIT LENGTH (P2) - (1 - 4 DIGITS)
- . PREFIX CODE (P3) - (1 - 4 DIGITS OR BLANK)
- . DISA DIRECTORY NUMBER (P4) - (BLANK)
- . DISA AUTHORIZATION CODE (P5) - (BLANK)

CMC = 430
P1: 57 P4:
P2: 3 P5:
P3:

4. ASSIGN THE LISTED DIRECTORY NUMBERS TO A DID TRUNK WITH CMC-431:

- TRUNK GROUP NUMBER (3) - (57 - 62)
- LISTED DIRECTORY NUMBER (P1) - (1-4 DIGITS OR BLANK)
- LISTED DIRECTORY NUMBER (P2) - (1-4 DIGITS OR BLANK)
- LISTED DIRECTORY NUMBER (P3) - (1-4 DIGITS OR BLANK)
- LISTED DIRECTORY NUMBER (P4) - (1-4 DIGITS OR BLANK)
- LISTED DIRECTORY NUMBER (P5) - (1-4 DIGITS OR BLANK)
- LISTED DIRECTORY NUMBER (P6) - (1-4 DIGITS OR BLANK)

CMC = 431
P1: 57 P4: 1402
P2: 1400 P5:
P3: 1402 P6:

NOTE: THE NUMBER OF DIGITS OF THE LISTED DIRECTORY NUMBER MUST MATCH THE RECEIVED DIGITS LENGTH (P2) OF CMC-430.

5. ASSIGN DID TRUNK LEVEL CHANGE DIGITS WITH CMC-433:

- TRUNK GROUP NUMBER (P1) - (57 - 62)
- . REPLACED DIGIT (P2) - (0 - 9)
- LEVEL CHANGE DIGIT (P3) - (0 - 9)

CMC = 433
P1: 57
P2: 3
P3: 2

Direct Inward Dialing/Direct Inward System Access Programming



GTE OMNI SBCS

DESCRIPTION

- . DIRECT INWARD SYSTEM ACCESS VIA DIRECT INWARD DIALING TRUNK (DID/DISA) ALLOWS OUTSIDE USERS ACCESS TO SYSTEM FEATURES VIA DID TRUNKS USING A DTMF TELEPHONE.
- . ACCESSIBLE DID/DISA FEATURES INCLUDE:
 - STATION CALL
 - ATTENDANT CALL
 - OUTGOING TRUNK LINE CALL (CO, TIE, WATS, FX)
 - LCR
 - SCC
 - SYSTEM SPEED DIALING
 - EKT PAGING ACCESS
 - EXTERNAL PAGING

PROCEDURE

1. ASSIGN DISA DIRECTORY NUMBER AND AUTHORIZATION CODE TO EXISTING DID TRUNK LINE WITH CMC-430:
 - . TRUNK GROUP NUMBER (PI) - (57 - 62)
 - . RECEIVED DIGIT LENGTH (P2) - (1 - 4)
 - . PREFIX CODE (P3) - (1 - 3 DIGITS OR BLANK)
 - . DISA DIRECTORY NUMBER (P4) - (1 - 4 DIGITS OR BLANK)
 - . DISA DIRECTORY NUMBER (P5) - (1 - 4 DIGITS OR BLANK)

CMC = 430	
PI: 57	P4: 123
P2: 3	P5: 456
P3:	

Direct Inward Dialing and DID/DISA Programming CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
. DID TRUNK ASSIGNMENT	CMC-250	ASSIGNS DID SERVICE TO DID TRUNKS
• DID TRUNK COS/COR ASSIGNMENT	CMC-252	ASSIGNS TRUNK COS/COR TO DID TRUNKS
• DID ADDITIONAL CODE ASSIGNMENT OR DID/DISA DIRECTORY AND CODE ASSIGNMENT	CMC-430	ASSIGNS RECEIVED DIGITS LENGTH, PREFIX CODE, DISA DIRECTORY NUMBER, AND DISA AUTHORIZATION CODE FOR DID/DISA
• DID LISTED DIRECTORY NUMBER	CMC-431	ASSIGNS LISTED DIRECTORY NUMBERS FOR DID TRUNKS
. DID TRUNK LEVEL CHANGE ASSIGNMENT	CMC-433	ASSIGNS ADDITIONAL DIGITS OR REPLACED DIGITS TO THE RECEIVED DIGIT VIA DID TRUNK

Data Interface Unit (DIU) Programming



GTE OMNI SBCS

DESCRIPTION

- . PROVIDES STANDALONE DATA STATION CAPABILITY WITH TERMINAL, MODEM, OR PRINTER
- . PROGRAMMABLE DIU FEATURES INCLUDE:
 - COS/COR
 - DATA ATTRIBUTES
 - TENANT GROUP
 - DATA HUNT GROUP
 - DATA HOT LINE

PROCEDURE

1. ASSIGN THE DIU AS A DATA STATION WITH CMC-220:
 - . EQUIPMENT NUMBER OF DATA STATION (P1)
 - . DIRECTORY NUMBER OF DATA STATION (P2)
 - DATA TERMINAL TYPE (P3) • (4 = DIU)
 - . DIRECTORY NUMBER OF VOICE STATION (P4) • BLANK
2. ASSIGN COS/COR TO DIU DATA STATION WITH CMC-221:
 - . DIRECTORY NUMBER OF DATA STATION (P1)
 - . CLASS OF SERVICE DAY (P2)
 - . CLASS OF SERVICE NIGHT (P3)
 - . CLASS OF RESTRICTION DAY (P4)
 - . CLASS OF RESTRICTION NIGHT (P5)

```
CMC = 220
P1: 030 P4:
P2: 4700 P5:
P3: 4
```

```
CMC = 221
P1: 4700 P4: 1
P2: 1 P5: 1
P3: 1
```

Data Interface Unit (DIU) Programming (Continued)



GTE OMNI SBCS

PROCEDURE (Continued) .

3. ASSIGN DATA ATTRIBUTES OF DIU WITH CMC-222:

- DIRECTORY NUMBER OF DATA STATION (P1)
- . DATA SPEED (P2)
- SYNCHRONIZATION AND COMMUNICATION (P3)
- . WORD STRUCTURE (P4)
- . PARITY (P5)
- ECHOPLEX (P6)

CMC = 222
P1: 4700 P4: 1
P2: 5 P5: 3
P3: 3

4. ASSIGN DATA ATTRIBUTES AND RS-232-C INTERFACE FOR DIU WITH CMC-223:

- . DIRECTORY NUMBER OF DATA DIU (P1)
- . CALL CONTROL MODE (P2)
- . RS-232-C INTERFACE SIGNAL MODE 1 (P3)
- RS-232-C INTERFACE SIGNAL MODE 2 (P4)

CMC = 223
P1: 4700 P4: 1
P2: 010
P3:

5. ASSIGN DATA ATTRIBUTES, TENANT GROUP, AND METERING GROUP TO DIU WITH CMC-224:

- . DIRECTORY NUMBER OF DATA DIU (P1)
- CALL OPERATION MODE (P2)
- DIAL MODE (P3) - (BLANK)
- TENANT NUMBER (P4)
- METERING GROUP (P5)

CMC = 224
P1: 4700 P4:
P2: 1 P5:
P3: 0

Data Interface Unit (DIU) Programming (Continued)



GTE OMNI SBCS

PROCEDURE (Continued)

6. ASSIGN DIU DATA STATION TO HUNT GROUP WITH CMC-301:

- . STATION HUNTING GROUP NUMBER (P1) - (51 - 60)
- TERMINATING ORDER (P2)
- . DIRECTORY NUMBER OF DATA STATION (P3)
- . HUNTING TYPE (P4)

CMC = 301	
P1: 51	P4: 1
P2: 1	
P3: 4700	

7. ASSIGN DIU DATA STATIONS TO HOT LINE SERVICE WITH CMC-304:

- HOT LINE NUMBER (P1) - (51 - 90)
- . ORIGINATING DATA STATION (DIRECTORY NUMBER) - (P2)
- . TERMINATING DATA STATION DN (DIRECTORY NUMBER) - (P3)

CMC = 304	
P1: 51	
P2: 4700	
P3: 7401	

Data Interface Unit (DIU) Programming — CMC Command Summary



GTE OMNI SBCS

<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
. DATA STATION ASSIGNMENT	CMC-220	INSTALLS OR REMOVES DIU AS DATA STATION WITH ITS ASSOCIATED DIRECTORY NUMBERS
. DATA STATION COS/COR ASSIGNMENT	CMC-221	CHANGES DATA STATION'S COS/COR ASSIGNMENT
• DATA STATION ATTRIBUTES ASSIGNMENT (I)	CMC-222	ASSIGNS DATA STATION'S ATTRIBUTES INCLUDING DATA SPEED, SYNCHRONIZATION AND COMMUNICATIONS WORD STRUCTURE, PARITY, AND ECHOPLEX
• DATA STATION'S ATTRIBUTES ASSIGNMENTS (II) AND RS-232-C SIGNAL MODES	CMC-223	ASSIGNS DATA STATION'S ATTRIBUTES INCLUDING CALL CONTROL MODE AND RS-232-C INTERFACE SIGNAL MODES
• DATA STATION ATTRIBUTES ASSIGNMENT (III)	CMC-224	ASSIGNS DATA STATIONS'S ATTRIBUTES INCLUDING OPERATION MODE, DIAL MODE, TENANT NUMBER, AND METERING GROUP
• DATA STATION HUNT GROUP ASSIGNMENT	CMC-301	ASSIGNS DATA STATION HUNT GROUPS AND MEMBERS
• DATA STATION HOT LINE ASSIGNMENT	CMC-304	ASSIGNS DATA STATION HOT LINE SERVICE

Programming Data Interface Unit (DIU) Associated with CS-10/CS-20



GTE OMNI SBCS

DESCRIPTION

- ALLOWS DIU ASSOCIATED WITH CS-10 OR CS-20 TO ESTABLISH DATA CALLS AND PROVIDE SAME OPERATION AS CSD WITH DATA TERMINAL ADAPTER (DTA).

PROCEDURE

1. ASSIGN CS-10 OR CS-20 AS VOICE STATION ASSOCIATED WITH DIU WITH CMC-220:

- EQUIPMENT NUMBER OF DATA STATION (P1)
- DIRECTORY NUMBER OF DATA STATION (P2)
- DATA TERMINAL TYPE (P3) - (2 = DIU AND CS-10/CS-20)
- DIRECTORY NUMBER OF VOICE STATION (P4)

CMC = 220
P1: 031 P4: 212
P2: 4702
P3: 2

2. ASSIGN DATA CALL BUTTON TO CS-20 OR CS-20 ASSOCIATED WITH DIU WITH CMC-203:

- STATION DIRECTORY NUMBER (P1)
- BUTTON NUMBER (P2)
- FEATURE NUMBER (P3) — (185 = DATA CALL FEATURE NUMBER)
- SUPPLEMENTARY DATA (P4) — (BLANK)
- LINE TERMINATING TYPE (P5) — (BLANK)
- RINGING MODE (P6) — (BLANK)

CMC = 203
P1: 212 P4:
P2: 4 P5:
P3: 185 P8:

Programming Data Interface Unit (DIU) Associated with CS-10/CS-20



GTE OMNI SBCS


<u>CATEGORY</u>	<u>CMC TABLE</u>	<u>FUNCTION</u>
. DATA STATION ASSIGNMENT	CMC-220	INSTALLS OR REMOVES DIU WITH CS-20/CS-20 AS VOICE/DATA STATION WITH ITS ASSOCIATED DIRECTORY NUMBERS
• EKT BUTTON ASSIGNMENT	CMC-203	ASSIGNS DATA CALL BUTTON TO CS-10 OR CS-20 TELEPHONE ASSOCIATED WITH DIU

Programming Key System Features (Continued)




GTE OMNI SBCS


KEY TELEPHONE EKT BUTTON ARRANGEMENT




CS-10 BUTTON ASSIGNMENTS FOR TELEPHONES CONNECTED TO CARD SLOTS OTHER THAN 01



CS-20 BUTTON ASSIGNMENTS FOR TELEPHONES CONNECTED TO CARD SLOTS OTHER THAN 01



CS-10 BUTTON ASSIGNMENTS FOR TELEPHONES CONNECTED TO CARD SLOT 01



CS-20 BUTTON ASSIGNMENTS FOR TELEPHONES CONNECTED TO CARD SLOT 01

NOTE: TELEPHONES CONNECTED TO CARD SLOT 01 WILL RING ON ALL INCOMING CALLS (ANSWERING STATION).

Laboratory Activity - Package C

Data Base Administration (5.3)



GTE OMNI SBCS

PART 1: ATTENDANT CONSOLE

1. TEST THE FOLLOWING ATTENDANT CONSOLE FEATURE BUTTONS (USING ATTENDANT CONSOLE USER'S GUIDE FOR REFERENCE):
 - A. COS/COR
 - B. TRUNK CAMP-ON
 - C. EKT STATION PAGING
 - D. MESSAGE LEAVING
 - E. ACCOUNT CODE ENTRY
2. USE CMC-231 TO PERFORM THE FOLLOWING TASKS:
 - A. IDENTIFY THE DEFAULT FEATURE ASSIGNED TO BUTTON 14 OF THE ATTENDANT CONSOLE.
 - B. REMOVE THE FEATURE FROM BUTTON 14 AND ASSIGN THE FDC PROGRAM FEATURE (WHICH WILL BE USED FOR HOTEL/MOTEL TASKS LATER IN THIS LABORATORY ACTIVITY).
3. USE CMC-233 TO ASSIGN ATTENDANT CONSOLE PRIORITIES FOR INCOMING CALL TERMINATION. ASSIGN LOW PRIORITY TO THE LOOP TIE TRUNK LINES AND HIGH PRIORITY TO THE E&M TIE TRUNK LINES. TEST THESE INCOMING CALL TERMINATION ASSIGNMENTS BY CALLING FROM TWO OF THE OTHER SYSTEMS, TO CONFIRM THAT ATTENDANT CONSOLE SELECTS PRIORITY BASED ON TRUNK GROUP.
4. USE CMC-306 TO COMPLETE THE FOLLOWING STEPS ASSOCIATED WITH CREATING AN ATTENDANT CONSOLE OVERFLOW STATION.
 - A. CREATE A NIGHT ANSWER GROUP FOR THE ATTENDANT CONSOLE OVERFLOW STATION (PI = 1).
 - B. IDENTIFY NIGHT ANSWER GROUP AS A STATION (P2 = 1)
 - C. IDENTIFY THE EQUIPMENT NUMBER OF THE CS-20 STATION DESIGNATED TO SERVE AS THE ATTENDANT CONSOLE OVERFLOW STATION (P3 = 016), THEN ENTER THE ABOVE PARAMETER VALUES WITH THE ADD/CHANGE FUNCTION KEY.
 - D. CONTINUE TO USE CMC-306 TO ASSIGN ALL TENANTS TO THE NIGHT ANSWER GROUP JUST CREATED BY DESIGNATING THE FOLLOWING VALUES: Pi = 1, P2 = 3 (INDICATING TENANT), AND P3 = * (INDICATING ALL TENANTS). ENTER THESE PARAMETER VALUES WITH THE ADD/CHANGE FUNCTION KEY.
 - E. TEST THE OVERFLOW ASSIGNMENT BY ACTIVATING THE ATTENDANT CONSOLE'S 'POSITION BUSY' FEATURE BUTTON. PLACE AN INCOMING CALL TO THE SYSTEM TO DEMONSTRATE THAT THE OVERFLOW STATION NOW RECEIVED THE CALLS INTENDED FOR THE ATTENDANT CONSOLE.

Laboratory Activity - Package C Data Base Administration (5.3) (Continued)



GTE OMNI SBCS

PART 2: HOTEL/MOTEL

1. USE CMC-203 TO ASSIGN THE CSD TELEPHONE (EQUIPMENT NUMBER 000) AS THE FRONT DESK CONSOLE.
2. USE CMC-204 TO SET FLAG WHICH WILL ASSIGN ALL LABORATORY STATIONS (EXCEPT PREVIOUSLY DESIGNATED CSD/FDC) AS GUEST ROOMS.
3. USE CMC-354 TO ASSIGN THE BLF/DSS MODULE (EQUIPMENT NUMBER 015) AS A ROOM STATUS INDICATOR MODULE.
4. USE CMC-355 TO ASSIGN HOTEL/MOTEL ROOMS (STATION DIRECTORY NUMBERS) TO BUTTONS ON THE ROOM STATUS INDICATOR MODULE.
5. USE CMC-356 TO ASSOCIATE THE HOTEL/MOTEL PRINTER WITH A 4CHT CIRCUIT (EQUIPMENT NUMBER 090) AND A DIU DIRECTORY NUMBER (202).
6. ASSIGN THE HOTEL/MOTEL PRINTOUT MESSAGE ALLOCATION WITH CMC-357, USING THE FOLLOWING PARAMETER VALUES:
INDEPENDENT MESSAGES —
 P1 = 1
 P2 = 1 (INDICATING INDEPENDENT MESSAGES)
 P3 = 01 (TAKING MESSAGES FROM THE ATTENDANT CONSOLE)
COMMON MESSAGES —
 PI = 1
 P2 = 2 (INDICATING COMMON MESSAGES)
 P3 = BLANK
7. USE CMC-350 TO ASSIGN THE MESSAGE REGISTRATION TRUNK GROUP NUMBER. MAKE ALL CO TRUNKS (TGN 13) SUBJECT TO HOTEL/MOTEL MESSAGE REGISTRATION.
8. USE CMC-351 TO ASSIGN MESSAGE REGISTRATION BILLING RATE NUMBER 1 TO THE FOLLOWING OFFICE CODES: 227, 476, AND 892.

Laboratory Activity - Package C Data Base Administration (5.3) (Continued)



GTE OMNI SBCS

9. USE CMC-352 TO ASSIGN THE FOLLOWING BILLING RATES FOR BILLING RATE NUMBER 1:

INITIAL TIME FOR TELEPHONE CALL (P2) = 20 SECONDS
INITIAL CHARGE FOR TELEPHONE CALL (P3) = 50 CENTS
ADDITIONAL TIME FOR TELEPHONE CALL (P4) = 60 SECONDS
ADDITIONAL CHARGE FOR TELEPHONE CALL (P5) = 30 CENTS

10. USE CMC-100 TO CREATE NEW ACCESS CODES FOR THE FOLLOWING HOTEL/MOTEL CODES:

FNO 73 — GUEST ROOM CLEAN-UP
FNO 78 — WAKE-UP REGISTRATION
FNO 79 — WAKE-UP CANCELLATION
FNO 96 — SERVICE CALL ROUTING #1
FNO 97 — SERVICE CALL ROUTING #2
FNO 98 — SERVICE CALL ROUTING #3

ENSURE THAT NEW CODES DO NOT CONFLICT WITH EXISTING SYSTEM ACCESS CODES.

11. USE CMC-353 TO ASSIGN SERVICE CODE DESTINATIONS TO THE SERVICE CALL FEATURE ACCESS CODES (PREVIOUSLY ASSIGNED). ASSIGN THE FOLLOWING PARAMETER VALUES:

P1 = (USE ACCESS CODES ASSIGNED TO FNO 96, 97, AND 98)
P2 = 1 (INDICATING SPECIAL SERVICE)
P3 = 200 (DESTINATION DIRECTORY NUMBER)
P4 = BLANK

Laboratory Activity - Package C Data Base Administration (5.3) (Continued)



GTE OMNI SBCS

PART 3: DIRECT INWARD DIALING

1. PRIOR TO PROGRAMMING, EMULATE A DID LINE BY PUNCHING THE TIP/RING WIRES FROM A SLT TO THE TIP/RING WIRES OF A LOOP TIE TRUNK CIRCUIT (USE EQUIPMENT NUMBER 160).
2. USE THE CMC-250 TO ASSIGN A DID TRUNK USING THE FOLLOWING PARAMETER VALUES:
 - EQUIPMENT NUMBER (P1) = 160
 - TYPE OF TRUNK (P2) = 13 (LOOP DIAL)
 - TRUNK GROUP NUMBER (P3) = 57
 - OPERATION MODE (P4) = 1 (INCOMING)
 - SIGNALING (P5) = 1 (FIXED)
 - START MODE (P6) = 3 (IMMEDIATE)
3. ASSIGN COS/COR TO THE DID TRUNK LINE WITH CMC-252, USING THE FOLLOWING PARAMETERS VALUES:
 - TRUNK GROUP NUMBER (P1) = 57
 - DAY COS (P2) = 1
 - NIGHT COS (P3) = 16
 - DAY COR (P4) = 1
 - NIGHT COR (P5) = 16
4. ASSIGN THE RECEIVED DIGIT LENGTH AND PREFIX CODE TO THE DID TRUNK WITH CMC-430, USING THE FOLLOWING PARAMETER VALUES:
 - TRUNK GROUP NUMBER (P1) = 57
 - RECEIVED DIGIT LENGTH (P2) = 3 (RECEIVED DIGIT LENGTH FROM CO PROVIDING DID)
 - PREFIX CODE (P3) = BLANK
 - DISA DIRECTORY NUMBER = 123 (SIMULATED)
 - DISA AUTHORIZATION CODE = 456 (SIMULATED)

Laboratory Activity - Package C Data Base Administration (5.3) (Continued)



GTE OMNI SBCS

PART 4: KEY SYSTEM FEATURES

1. REMOVE ATTENDANT CONSOLE.
2. COLD RESTART THE SYSTEM.
3. CHECK/CONFIRM KEY SYSTEM FEATURE CHANGES ON EKT INSTRUMENT BUTTONS.

Review Exercise - Package C

Data Base Administration (5.3)



GTE OMNI SBCS

INSTRUCTIONS: THE FOLLOWING EXERCISE CONSISTS OF MULTIPLE CHOICE, TRUE/FALSE, FILL IN THE BLANK, OR MATCHING TYPE QUESTIONS. ALL AVAILABLE RESOURCES (I.E., STUDENT WORKBOOK, NOTES, AND GTEP MANUAL) MAY BE USED AS REFERENCES. SUBMIT EXERCISE TO INSTRUCTOR FOR GRADING WHEN LAST QUESTION HAS BEEN COMPLETED.

1. WHAT INSTALLATION OR DATA BASE PROGRAMMING STEPS ARE REQUIRED TO ALLOW A PREVIOUSLY INSTALLED BLF/DSS MODULE TO FUNCTION AS A ROOM STATUS INDICATOR?

2. _____ (TRUE OR FALSE) A TRUNK GROUP WITH AN INCOMING CALL TERMINATION PRIORITY OF 1 WOULD BE ANSWERD BY THE ATTENDANT CONSLE BEFORE ANOTHER TRUNK GROUP WITH A PRIORITY OF 3.
3. CMC-_____ IS USED TO CREATE A NIGHT ANSWER GROUP FOR AN ATTENDANT CONSOLE OVERFLOW STATION, THEN TO ASSIGN "ALL TENANTS" TO BE ANSWERED BY THE OVERFLOW STATION.
4. THE _____ FEATURE BUTTON MUST BE ASSIGNED TO EITHER THE ATTENDANT CONSOLE OR CSD DESIGNATED TO SERVE AS THE HOTEL/MOTEL FRONT DESK CONSOLE.
5. "AUTOMATIC WAKE-UP REGISTRATION/CANCELLATION BY GUEST ROOM" IS AN EXAMPLE OF A _____ MESSAGE WHICH CAN BE RECORDED BY THE HOTEL/MOTEL PRINTER.
6. THE DTMF AUTHORIZATION CODE REQUIRED BY DISA USERS IS ASSIGNED WITH CMC-_____

Review Exercise - Package C Data Base Administration (5.3) (Continued)



GTE OMNI SBCS

7. CMC-430 ASSIGNS DISA DIRECTORY NUMBERS AND AN AUTHORIZATION CODE TO A _____ TRUNK LINE.
8. A CS-10 OR CS-20 WHICH WILL SERVE AS A VOICE STATION ASSOCIATED WITH A DIU MUST BE ASSIGNED WITH CMC-_____, AND HAVE THE _____ FEATURE BUTTON ASSIGNED WITH CMC-203.
9. EKT INSTRUMENTS CONNECTED TO CARD SLOT _____ RING ON ALL INCOMING CALLS IN A KEY TELEPHONE BUTTON ARRANGEMENT.
10. MATCH EACH OF THE FOLLOWING CMC COMMANDS WITH ITS CORRECT FUNCTION:

- | | |
|---------------|--|
| _____ CMC-223 | A. ASSIGNS TRUNK COS/COR TO DID TRUNKS |
| _____ CMC-355 | B. ASSIGNS DISA STANDARD TO A GROUND STRAT TRUNK |
| _____ CMC-252 | C. ASSIGNS GUEST ROOM NUMBERS TO ROOM STATUS INDICATOR LAMPS |
| _____ CMC-231 | D. ASSIGNS ATTENDANT CONSOLE SERVICES TO FEATURE BUTTONS |
| _____ CMC-250 | E. ASSIGNS DATA STATION ATTRIBUTES (III) AND RS-232-C SIGNAL MODES |



GTE OMNI SBCS

PACKAGE C MAINTENANCE



5.4 Enabling Objective

GTE OMNI SBCS

- GIVEN:**
- GTE OMNI SBCS
 - GTE OMNI SBCS PACKAGE C EQUIPMENT AND PERIPHERALS
 - ATTENDANT CONSOLE (ASSIGNED AS MASTER CONTROL TELEPHONE IN DATA BASE)
 - GTE OMNI SBCS COURSE AND SITE DOCUMENTATION PACKAGE
 - REVIEW EXERCISE
- ACTION:**
- USE ATTENDANT CONSOLE AS AN ALTERNATE MASTER CONTROL TELEPHONE FOR DATA BASE ADMINISTRATION AND MAINTENANCE TASKS.
 - IDENTIFY FUNCTIONS AND APPLICATIONS OF PACKAGE C CMC MAINTENANCE COMMANDS.
 - MODIFY PARAMETER VALUES FOR PACKAGE C CMC MAINTENANCE COMMANDS.
 - USE ATTENDANT CONSOLE AND DATA INTERFACE UNIT DIAGNOSTIC TESTS TO IDENTIFY INSTRUMENT MALFUNCTIONS.
 - COMPLETE REVIEW EXERCISE.
- CRITERIA:**
- TASKS WILL BE PERFORMED IN ACCORDANCE WITH PROCEDURES OUTLINED IN OMNI SBCS GTEP MANUAL AND OMNI SBCS STUDENT WORKBOOK.
 - REVIEW EXERCISE WILL BE COMPLETED CORRECTLY IN ACCORDANCE WITH PASS/FAIL CRITERIA OF THIS TRAINING ORGANIZATION.

Attendant Console Assignment as Master Control Telephone



GTE OMNI SBCS

DESCRIPTION

- A MAXIMUM OF TWO ATTENDANT CONSOLES CAN BE IDENTIFIED IN SYSTEM AS HAVING MASTER CONTROL TELEPHONE (MCT) CAPABILITIES FOR DATA BASE ADMINISTRATION AND MAINTENANCE ACTIVITIES.
- ATTENDANT CONSOLE FIRST MUST BE PLACED IN THE POSITION BUSY MODE TO FUNCTION AS AN MCT.


PROCEDURE

1. ASSIGN OR CANCEL ATTENDANT CONSOLE DIRECTORY NUMBER AS MCT WITH CMC-702:
 - MCT NUMBER (P1) - (1 - 4)
 - DIRECTORY NUMBER OF MCT ATTENDANT CONSOLE (P2) (ATTENDANT CONSOLE ACCESS (0) + ATTENDANT CONSOLE NUMBER)

CMC = 702
P1: 4
P2: 01

NOTE: ATTEMPTS TO DELETE THE MCT BEING USED TO MAKE ENTRIES WILL BE DENIED BY DATA BASE.

Attendant Console Operation as Master Control Telephone

GTE*GTE OMNI SBCS*

PROCEDURE

1. PLACE ATTENDANT CONSOLE IN POSITION BUSY MODE BY DEPRESSING THE POSITION BUSY FEATURE BUTTON. ANY CALLS IN PROCESS MUST BE CLEARED BEFORE POSITION BUSY MODE CAN BE ACTIVATED.
2. ENTER APPROPRIATE HIGH OR LOW LEVEL SECURITY CODE USING KEYBOARD OF ATTENDANT CONSOLE (PREVIOUSLY ASSIGNED AS MCT) WHILE ON-HOOK AND IN IDLE STATE.
3. AT COMMAND PROMPT, ENTER APPROPRIATE CMC COMMAND AND PRESS SELECT (ATTENDANT CONSOLE'S DEFAULT INCOMING FEATURE BUTTON).
4. ENTER PARAMETER VALUES USING ATTENDANT CONSOLE'S NUMERIC KEYPAD AND DESIGNATED PROGRAM FUNCTION BUTTONS (ILLUSTRATED ABOVE).
5. PRESS RELEASE, THEN TERMINATE PROGRAM FUNCTION BUTTONS. PRESS POSITION BUSY FEATURE BUTTON TO RETURN TO NORMAL CALL PROCESSING MODE AS AN ATTENDANT CONSOLE.

Attendant Console Instrument Diagnostics



GTE OMNI SBCS

DESCRIPTION

- . ATTENDANT CONSOLE MUST BE TESTED OFF-LINE.
- THE FOLLOWING TESTS CAN BE PERFORMED:
 - BUTTON AND KEYPAD TEST
 - LED LAMP TEST
 - LCD DISPLAY TEST
 - AUDIBLE TONE TEST

PROCEDURE


1. UNPLUG TELEPHONE CORD FROM MODULAR JACK IN BACK OF ATTENDANT CONSOLE.
2. PRESS 1 and 3 KEYS SIMULTANEOUSLY.
3. PLUG TELEPHONE CORD INTO MODULAR JACK WHILE KEEPING THE 1 AND 3 KEYS PRESSED.
4. WHEN STEP 3 IS COMPLETED, PRESS ANY KEY TO ELIMINATE INITIAL SIGNAL (INDICATING INSTRUMENT IS IN DIAGNOSTIC MODE WITH ALL LED LAMPS FLASHING AND TONE RINGER SOUNDING).
5. PRESS APPROPRIATE TEST EXECUTION KEYS (REFER TO TABLES ON FOLLOWING PAGES) AND MONITOR VISUAL AND AUDIBLE RESULTS. IF RESULTS VARY FROM THOSE LISTED, RETURN DEFECTIVE INSTRUMENT FOR REPAIR.
6. TO RETURN TO NORMAL CALL PROCESSING MODE, REMOVE TELEPHONE CORD AND THEN REPLACE IN MODULAR JACK.

Attendant Console Diagnsstics (Continued)



GTE OMNI SBCS

ATTENDANT CONSOLE TEST BUTTON ARRANGEMENT



Attendant Console Test Execution



GTE OMNI SBCS

ATTENDANT CONSOLE NUMERIC KEYPAD TEST

KEY PRESSED

FUNCTION

KEYPAD:

1	STOP RINGING, DISPLAY SHOWS 1 ON THE LCD
2	START RINGING IN PATTERN 1, DISPLAY SHOWS 2 ON THE LCD
3	START RINGING IN PATTERN 2, DISPLAY SHOWS 3 ON THE LCD
4	START RINGING IN PATTERN 3, DISPLAY SHOWS 4 ON THE LCD
5	START RINGING IN PATTERN 4, DISPLAY SHOWS 5 ON THE LCD
6	START RINGING IN PATTERN 5, DISPLAY SHOWS 6 ON THE LCD
7	START RINGING IN PATTERN 6, DISPLAY SHOWS 7 ON THE LCD
8	START RINGING IN PATTERN 7, DISPLAY SHOWS 8 ON THE LCD
9	START RINGING IN PATTERN 8, DISPLAY SHOWS 9 ON THE LCD
0	ASSOCIATED LAMP FLASHES IN PATTERN 5, DISPLAY SHOWS 0 ON THE LCD
#	ASSOCIATED LAMP FLASHES IN PATTERN 6, DISPLAY SHOWS # ON THE LCD
*	ASSOCIATED LAMP FLASHES IN PATTERN 7, DISPLAY SHOWS * ON THE LCD

Attendant Console Test Execution (Continued)



GTE OMNI SBCS

ATTENDANT CONSOLE FUNCTION KEY TEST

FUNCTION KEY:

FK16	DISPLAY SHOWS @ ON THE LCD
FK17	DISPLAY SHOWS A ON THE LCD
FK18	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS B ON THE LED
FK19	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS C ON THE LED
FK20	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS D ON THE LED
FK21	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS E ON THE LED
FK22	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS F ON THE LED
FK23	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS G ON THE LED
FK24	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS ALL DOT PATTERN ON THE LED
FK25	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS ALL BLANK PATTERN ON THE LED
FK26	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS J ON THE LED
FK27	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS K ON THE LED
FK28	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS L ON THE LED
FK29	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS M ON THE LED
FK30	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS N ON THE LED
FK31	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS 0 ON THE LED

Attendant Console Test Execution (Continued)



GTE OMNI SBCS

ATTENDANT CONSOLE FUNCTION KEY TEST

KEYPRESSED

FUNCTION

FUNCTION
KEY:

STA	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS P ON THE LED
RECALL	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS Q ON THE LED
INCOMING	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS R ON THE LED
POS.RLSE	DISPLAY SHOWS S ON LCD
SUP/HOLD	DISPLAY SHOWS T ON LCD
SER/LOCK	DISPLAY SHOWS U ON LCD
SRCE	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS V ON THE LED
DEST	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS W ON THE LED
CONF/JOIN	ASSOCIATED LAMP FLASHES IN PATTERN 4, DISPLAY SHOWS X ON THE LED
DROP/CNCL	DISPLAY SHOWS Y ON LCD
VOL UP	ALL LEDS FLASH IN PATTERN 1, DISPLAY SHOWS CONTROLLING OF VOLUME ON LCD-MAKE RECEIVER VOLUME LOUDER
VOL DOWN	ALL LEDS FLASH IN PATTERN 4, DISPLAY SHOWS CONTROLLING OF VOLUME ON LCD-MAKE RECEIVER VOLUME SOFTER
SK1	LED ASSOCIATED WITH FK18 FLASHES IN PATTERN 4
SK2	LED ASSOCIATED WITH FK19 FLASHES IN PATTERN 4
SK3	LED ASSOCIATED WITH FK20 FLASHES IN PATTERN 4
SK4	LED ASSOCIATED WITH FK21 FLASHES IN PATTERN 4
SK5	LED ASSOCIATED WITH FK22 FLASHES IN PATTERN 4
SK6	LED ASSOCIATED WITH FK23 FLASHES IN PATTERN 4

Attendant Console Test Execution (Continued)



GTE OMNI SBCS

ATTENDANT CONSOLE TEST LAMP PATTERNS

LAMP PATTERN
INDICATOR

PATTERN

0	0.125 SEC. ON, 0.125 SEC. OFF
1	0.5 SEC. ON, 0.5 SEC. OFF
2	0.125 SEC. OFF, 0.125 SEC. ON, 0.125 SEC. OFF, 0.125 SEC. ON, 1.625 SEC. OFF
3	0.125 SEC. OFF, 1.875 SEC. ON
4	STEADY ON
5	STEADY OFF
6	0.125 SEC. ON, 0.125 SEC. OFF, 0.125 SEC. ON, 0.125 SEC. OFF, 1.625 SEC. ON
7	1 SEC. ON, 1 SEC. OFF



Data Interface Unit Diagnostics

GTE OMNI SBCS

DESCRIPTION

- DATA INTERFACE UNIT (DIU) MUST BE TESTED OFF-LINE.
- THE FOLLOWING TESTS CAN BE PERFORMED:
 - INITIAL CONDITION TEST
 - CALL BUTTON TEST
 - TEST SWITCH TEST
 - DTE/DCE MODE SWITCH TEST

PROCEDURE

1. SET DIU'S TEST SWITCH TO ON POSITION, THEN SET DTE/DCE SWITCH TO DCE SIDE.
2. UNPLUG CORD FROM MODULAR JACK IN BACK OF DIU.
3. PRESS CALL BUTTON WHILE SIMULTANEOUSLY PLUGGING CORD INTO MODULAR JACK IN BACK OF DIU.
4. PRESS APPROPRIATE DIU TEST EXECUTION KEYS (REFER TO TABLE ON FOLLOWING PAGE) AND MONITOR VISUAL AND AUDIBLE RESULTS.

Data Interface Unit Test Execution



GTE OMNI SBCS

DATA INTERFACE UNIT TEST

<u>TEST ITEM</u>	<u>FUNCTION</u>
INITIAL CONDITION	RINGING START IN PATTERN 4 POW LAMP FLASHES IN PATTERN 1 TEST LAMP INDICATES ON CALL LAMP FLASHES IN PATTERN 7 MI/MIC SIGNAL IS SET TO OFF
PRESS CALL BUTTON	CALL LAMP FLASHES, CHANGING IN PATTERNS FROM 0 TO 7 RINGING STARTS, CHANGING IN PATTERNS FROM 0 TO 7
TEST SWITCH	TEST LAMP GOES ON WHEN SWITCH IS SET TO ON, TEST LAMP GOES OFF WHEN SWITCH IS SET TO OFF
DTE/DCE SWITCH MODE	IN DCE MODE, MI/MIC SIGNAL GOES OFF, AND POW LAMP FLASHES IN PATTERN 1 IN DTE MODE, MI/MIC SIGNAL GOES ON, AND POW LAMP FLASHES IN PATTERN 2

NOTE: CALL BUTTON, TEST SWITCH, AND DTE/DCE MODE SWITCH TEST OPERATIONS ARE INDEPENDENT

Hotel/Motel Printer Busy Assignment



GTE OMNI SBCS

DESCRIPTION

- PLACES HOTEL/MOTEL PRINTER OUT OF SERVICE (MADE BUSY) WHILE MAINTENANCE PROCEDURES ARE BEING PERFORMED.
- SAME COMMAND IS USED TO RESTORE SERVICE TO HOTEL/MOTEL PRINTER.

PROCEDURE

1. USE CMC-706 TO MAKE HOTEL/MOTEL PRINTER BUSY OR RETURN IT TO SERVICE:
 - PRINTER NUMBER (PI) - (1 OR 2)
 - MAKE BUSY OR PUT IN SERVICE FLAG (P2) - (0 = IN SERVICE; 1 = MAKE BUSY).

Character Trunk (CHT) Loop Test



GTE OMNI SBCS

DESCRIPTION

- . PERFORMS LOOP TEST WITHIN 4CHT CARD AND BETWEEN 4CHT CARD AND DIU/DTA.
- . TEST CHECKS FOR TRANSMISSION TIMING OUT, PARITY ERRORS, OVERRUN ERRORS, FRAMING ERRORS, CHT STATUS DISAGREEMENT, TRANSMISSION AND RECEPTION CHARACTERS, AND RECEPTION TIMING OUT.

PROCEDURE

1. USE CMC-810 TO ENTER PARAMETERS REQUIRED TO PERFORM LOOP TEST WITHIN 4CHT CARD:
 - TEST TYPE (P1) - (0 = LOOP TEST WITHIN 4 CHT;
1 = LOOP TEST BETWEEN 4CHT AND DIU/DTA)
 - . CHARACTER TRUNK EQUIPMENT NUMBER (P2)
 - . DIU/DTA DIRECTORY NUMBER (P3) - (1 - 4 DIGITS; TTP = 1)
 - . TEST RESULT 1 (P4)
 - . TEST RESULT 2 (P5)
2. PRESS DISPLAY TO PERFORM TEST. RESULTS ARE DISPLAYED IN P4 AND P5.
3. FOR LOOP TEST BETWEEN 4CHT AND DIU/DTA, SET DIU/DTA TEST SWITCH TO ON POSITION.

NOTE: REFER TO TABLE ON FOLLOWING PAGE FOR PARAMETER 4 AND 5 TEST RESULT MEANINGS AND POSSIBLE CMC ERRORS.

Character Trunk (CHT) Loop Test (Continued)



GTE OMNI SBCS

LOOP TEST RESULT MEANINGS

P4 VALUE

ANS2 (3 DIGITS)

FIRST DIGIT: 0/1 TO 9 = NORMAL/CHT STATUS DISAGREEMENT (NUMBER OF OCCURRENCES)

SECOND DIGIT: 0/1 TO 9 = NORMAL/DISAGREEMENT OF TRANSMISSION AND RECEPTION CHARACTERS (NUMBER OF OCCURRENCES)

THIRD DIGIT: 0/1 TO 9 = NORMAL/RECEPTION TIMING OUT (NUMBER OF OCCURRENCES)

P5 VALUE

ANSI (4 DIGITS)

FIRST DIGIT: 0/1 TO 9 = NORMAL/TRANSMISSION TIMING OUT (NUMBER OF OCCURRENCES)

SECOND DIGIT: 0/1 TO 9 = NORMAL/PARITY ERROR (NUMBER OF OCCURRENCES)

THIRD DIGIT: 0/1 TO 9 = NORMAL/OVERRUN ERROR (NUMBER OF OCCURRENCES)

FOURTH DIGIT: 0/1 TO 9 = NORMAL/FRAMING ERROR (NUMBER OF OCCURRENCES)

Character Trunk (CHT) Loop Test (Continued)



GTE OMNI SBCS


CMC-810 ERROR MESSAGES

- NOT RGTR** = SPECIFIED EQUIPMENT NUMBER HAS NOT BEEN INSTALLED: CHECK PARAMETERS.
- DISAGREE** = (1) DISAGREEMENT OF TERMINAL TYPES; CHECK PARAMETERS.
(2) SYNCHRONOUS MODE IS SET ON DIU/DTA; CHECK PARAMETERS.
- DENIED 20** - HOTEL/MOTEL PRINTER IS BEING CONNECTED; RELEASE PRINTER.
- NOT EXEC** = 4CHT CARD OR DIU/DTA IS FAULTY OR HAS BEEN MADE BUSY. CHT LOOP TEST IS DISABLED DURING A FAULT. IF PRINTER IS BUSY, PLACE IN SERVICE WITH CMC-706.

Expanded System Maintenance — Controls and Indicators



GTE OMNI SBCS



- **SYSTEM RESTARTS (COLD, HOT, AND RESET) ARE PERFORMED MANUALLY USING TOGGLE SWITCH ON CPM CARD IN BASIC CABINET.**
- **SYSTEM STATUS FOR BOTH CABINETS IS INDICATED BY INDICATOR LAMPS ON CPM CARD IN BASIC CABINET.**

Expanded System Maintenance — Alarm States



GTE OMNI SBCS

MAJOR ALARMS —

- POWER FAILURE TRANSFER MODE IN BASIC CABINET:
 - ENTIRE SYSTEM IS INOPERABLE
 - RUN LAMP IS OUT
- POWER FAILURE TRANSFER MODE IN EXPANDED CABINET:
 - ONLY EXPANSION CABINET IS INOPERABLE
 - ALARM LAMP IS LIT
- DEFECTIVE SWB CARD IN BASIC CABINET:
 - ENTIRE SYSTEM IS INOPERABLE
 - RUN LAMP IS OUT
- DEFECTIVE SWE CARD IN EXPANDED CABINET:
 - ONLY EXPANSION CABINET IS INOPERABLE
 - ALARM LAMP IS LIT

MINOR ALARM —

- ALL SELF DIAGNOSTIC TESTS ARE PERFORMED FOR ENTIRE SYSTEM
 - ALARM LAMP IS LIT
 - FAULT IS LOGGED INTO MEMORY (REFER TO CMC-800)

Expanded System Maintenance — Power Failure Transfer Activation



GTE OMNI SBCS

- SIX POWER FAILURE TRANSFER CIRCUITS ARE PROVIDED THROUGH 6PFT CARD IN BASIC CABINET. ADDITIONAL CIRCUITS ARE AVAILABLE THROUGH 6PFE CARD IN EXPANSION CABINET (REQUIRING WIRING OF SIGNAL LINE BETWEEN CARDS THROUGH CDF BLOCK).

EXPANDED SYSTEM POWER FAILURE TRANSFER OPERATIONAL STATUS
(BASIC AND EXPANDED CABINETS)

INCIDENTS		6PFT IN BASIC CABINET	6PFE IN EXPANSION CABINET
POWER FAILURE	BASIC CABINET	ACTIVE	ACTIVE
	EXPANSION CABINET	INACTIVE	ACTIVE
SYSTEM FAILURE	ACTIVE	ACTIVE	ACTIVE
MANUAL SWITCH	BASIC CABINET	ACTIVE	INACTIVE
ACTI- VATION	EXPANDED CABINET	INACTIVE	ACTIVE


NOTE: ACTIVE = POWER FAILURE TRANSFER CONDITION




Expanded System Maintenance — Fault Detection

GTE OMNI SBCS

- FAULTY DEVICES AND LOCATIONS ARE DISPLAYED USING CMC-800.
- CMC-800's SCREEN THREE, DISPLAYING EKT STATUS, HAS BEEN ENHANCED TO DISPLAY THE FOLLOWING INFORMATION:
 - SYSTEM PROMPT (P1) - FAULT TERMINAL
 - EQUIPMENT NUMBER OF FAULTY TERMINAL (P2) -



- EQUIPMENT NUMBER OF FAULTY TERMINAL (P3) -



- OPERATION AND INTERPRETATION OF SYSTEM FAULTS REMAINS THE SAME, OTHER THAN IDENTIFICATION OF SYSTEM CABINETS CONTAINING FAULTY TERMINALS.

Laboratory Activity – Package C

Maintenance (5.4)



GTE OMNI SBCS

1. USING THE INSTRUCTIONS PROVIDED IN THE STUDENT WORKBOOK, PERFORM THE ATTENDANT CONSOLE DIAGNOSTIC TEST. BE SURE TO USE ALL TEST EXECUTION KEYS AND MONITOR THE RESULTS. RETURN INSTRUMENT TO NORMAL CALL PROCESSING MODE AFTER TESTS HAVE BEEN PERFORMED.
2. USING THE INSTRUCTIONS PROVIDED IN THE STUDENT WORKBOOK, PERFORM THE DATA INTERFACE UNIT DIAGNOSTIC TEST. BE SURE TO USE ALL TEST EXECUTION KEYS AND MONITOR THE RESULTS. RETURN THE DIU TO NORMAL CALL PROCESSING MODE AFTER TESTS HAVE BEEN PERFORMED.
3. ASSIGN THE ATTENDANT CONSOLE AS A MASTER CONTROL TELEPHONE WITH CMC-702.
4. REMOVE THE HOTEL/MOTEL PRINTER FROM SERVICE FOR ROUTINE MAINTENANCE WITH CMC-706.
5. USING THE ATTENDANT CONSOLE AS A MASTER CONTROL TELEPHONE, PERFORM THE LOOP TEST BETWEEN THE 4CHT CARD AND THE DIU WITH CMC-810. WHAT ERROR MESSAGE IS RECEIVED?