


SMART-1

**SMART-1 CALL CONTROLLER**  
**MANUAL 1**  
**HARDWARE INSTALLATION**



© Copyright 1988 MITEL INC. All rights reserved.

® Registered Trademark of MITEL Corporation

PRINTED IN CANADA

## MITEL FIELD SERVICE

MITEL INC. has set up a National Field Service number for technical and installation assistance (214) 241-4555 during normal working hours, for U.S. customers. Outside normal working hours a telephone answering service has been established.

For Canadian customers contact the Canadian Regional Office (613) 592-0200 or the National Field Service Number.

### NOTICE TO CUSTOMERS

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL INC. or any of its affiliates and subsidiaries. MITEL INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

### WARNING

The Call Controller generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

### NOTICE TO CANADIAN CUSTOMERS

#### Warning

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using acceptable method OC connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground protections to the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together.

#### Caution

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as required.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load, to be connected to a telephone loop, that is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of Load Numbers of all the devices subject does not exceed 100. An alphabetic suffix is also specified in the Load Number and designates the appropriate ringing type (A or B), if applicable. For example, LN = 20 A designates a load number of 20 and an 'A' type ringer.

HEADING .....	PAGE
<b>1. INTRODUCTION .....</b>	<b>1.3</b>
1. 1. General .....	1.3
1. 2. Programming Devices .....	1.4
1. 3. Positive Account Code Verification .....	1.5
1. 4. Chaining .....	1.6
<b>2. BASIC HARDWARE INSTALLATION .....</b>	<b>1.7</b>
2. 1. DESCRIPTION .....	1.7
2. 1. 1. Mechanical Description .....	1.7
2. 1. 2. Electrical Description .....	1.7
2. 2. General Mounting .....	1.8
2. 3. Wall Mounting Bracket .....	1.9
2. 4. Ground .....	1.9
2. 5. Telephone Connections .....	1.10
2. 6. Installation Of A Recording Unit Or Programming Terminal .....	1.12
2. 7. Powering Up .....	1.13
2. 8. Power Failure .....	1.13
2. 9. Ground Start Installation Testing .....	1.14
<b>3. INITIALIZATION .....</b>	<b>1.15</b>
3. 1. Initialization From A DTMF Telephone .....	1.15
3. 2. Effects Of Initialization .....	1.16
3. 3. Waking Up the Controller .....	1.16
<b>APPENDIX 1 .....</b>	<b>1.17</b>
<b>HARDWARE SPECIFICATIONS .....</b>	<b>1.17</b>
<b>ORDERING INFORMATION .....</b>	<b>1.19</b>
PAV Call Controller .....	1.19
PAV Chaining Call Controller .....	1.19
Other Components .....	1.19
<b>INDEX .....</b>	<b>1.20</b>
<b>FCC INTERCONNECTION REQUIREMENTS .....</b>	<b>1.21</b>

# 1. INTRODUCTION


## 1. 1. General

The SMART- 1 Telephone Controller is a simple, compact and versatile telephone controller providing:


- Versatile Programming
- Four, or two line, or one line capacity
- Automatic Route Selection (ARS)
- Speed Call capacity of either 100, or 1000
- Handles Loop Start Or Ground Start Telephone Lines
- Off-Hook Redial
- Remote Maintenance And Programming
- Compatible With Rotary Or DTMF Telephones and Telephone Offices
- Battery Back-up Of Customer's Memory
- Separate Program Access Code To Allow Customer Speed Call Update/Maintenance
- Progress Tones Available For Call And Route Progress
- Programmable For Account Code Change On Route Change
- Compliance with FCC Parts 68 and 15
- Separate program entry to allow customer update and maintenance of PAV lists
- Progress tones programmable on a route by route basis
- Useable with Centrex Lines
- Useable behind a PBX/PABX
- Hot Line operation

It can be installed and programmed easily from either a DTMF device, or a terminal, and is typically installed as a serial device between:

- A Central Office (C. O.) trunk and the user's telephone equipment,




- The user's telephone equipment (PBX/key system) and the C.O. trunk,





# 1. INTRODUCTION

- The user's telephone and the user's PBX/key system.



The Controller provides easy access (regular dialing patterns) to the local telephone office and to Other Common Carriers (OCCs). The purpose of the Controller is to set up a call similar to the normal dialed call. The Controller can then add the access number and authorization code as required for call completion. You can program the Controller to access a number based on regular dialing patterns, or use speed call for rapid access. You can also program the unit to route or restrict calls based on digits dialed by the user. Regardless of the dialing patterns you program, a user does not hear any unusual dialing patterns and is informed of the progress by a tone at the end of routing (unless you program the Controller to act otherwise).

The product, on default, is in a cut through state and can be changed by one parameter (X23T).


In addition, the Controller, allows you to tailor its telephone line parameters for both the subscriber's telephone equipment and the Central Office (C.O.) such as loop or ground start, and Dual Tone Multi Frequency (DTMF), or rotary dial. This allows you to meet most situations or user requirements.

## 1. 2. Programming Devices

The Controller can be programmed from either:  
a DTMF telephone



or a terminal.



# 1. INTRODUCTION

## 1. 3. Positive Account Code Verification

The Controller can be programmed to require an Account Code before allowing a call. These Account Codes can be assigned to each individual person using the telephone lines connected to the Controller. These Account Codes can vary according to the route used as selected by the Controller. In addition, the Account Codes will appear on any Call Detail Records (CDR) output by the Controller through its RS-232 port. These records are valuable when determining billing information, call cost analysis or traffic patterns.

If you wish to assign Account Codes that can be verified to persons using the the telephone lines connected to the Controller, you will want to configure the unit as a Controller with Positive Account Code Verification (PAV). For call screening/toll control purposes this will limit you to one set of tables (Primary). The Alternate tables are used for the Verifiable Account Codes.

Should you not require Positive Account Code Verification you should configure the unit as a Controller without PAV.

For more information on the PAV Controller see **POSITIVE ACCOUNT CODE OPTIONS** in **MANUAL 2**.


# 1. INTRODUCTION

## 1. 4. Chaining

This feature allows multiple Controllers to be "chained" through their RS-232 port via cabling supplied with each unit. This feature provides two distinct functions:

1. The units which are chained together via their RS-232 ports (cabling supplied) may be addressed remotely or locally with DTMF instruments which can access any port on a Controller in a chain. From that access point, any combination of units within the set may be programmed with DTMF signals. A recommended method of access might be either a DTMF instrument itself, or a "Tandem" (see MANUAL 4) access from a remote location.

2. With the addition of an optional cable, a printing device may be connected to the chain. This allows the collection of call records from all units in the chain, to be output to one printing device without the need for a data concentrator or multiplexer. The call details records of the units within the chained set will be output one at a time at the printing device. Programming from this device through the optional printer chaining cable is not supported. For further information see MANUAL 3.



## 2. BASIC HARDWARE INSTALLATION

### 2. 1. DESCRIPTION


#### 2. 1. 1. Mechanical Description

The Controller (Figure 1.1 ) consists of a plastic case, enclosed circuitry and an outboard power supply.

#### 2. 1. 2. Electrical Description

Controller electrical characteristics are provided in Figure 1.1 .

Figure 1.1 Controller



**Note:** The above illustration and the rest of this manual shows the Controller as a four line unit. Your unit may be: one, two or four lines. In the programming and installation you should disregard programming for lines that you do not have.

## 2. BASIC HARDWARE INSTALLATION

### 2. 2. General Mounting


Since you are reading this part of the Installation Section, it is assumed that you have unpacked the Controller. At this point, you are ready to proceed with the installation. Before proceeding ensure you have:

- A place to mount the Controller right side up (Figure 1.2 ), on a suitable backboard (Figure 1.3 ).
- A screwdriver and wrench or pliers for the mounting hardware.
- Access to power, a ground, and telephone lines for the Controller (connected to RJ31 blocks).

You must provide a single phase power receptacle with the following recommendations:

- ④ 103.5 - 126.5 VAC, 60 Hz fused and capable of delivering 350 mA per unit installed.
- ④ The power receptacle should be wired and fused independently from all other receptacles that are not controller related.
- ④ A warning tag should be attached to circuit breaker type fuses to prevent unauthorized manual operations.
- ④ The power receptacle should not be controlled by a switch.
- ④ The live and neutral conductors at the receptacle should be wired to their proper respective connections.
- ④ The power receptacle must be a 3-wire type, with the ground wire connected to the ground of the electrical system.
- ④ The receptacle location should be selected to prevent accidental removal of the power cord.
- ④ The receptacle should be easily accessible for the removal of the plug for maintenance.
- ④ Sufficient space around the units, especially the cable side, should be left for cabling. This is very important if you intend to use chaining. You should also mark all cables as to their identity as this will ease troubleshooting problems..

Figure 1.2 Mounting Position




## 2. BASIC HARDWARE INSTALLATION

For information on installing chaining see MANUAL 3.

The Controller can be mounted in one of two ways as shown in Figure 1.3 using the mounting bracket shown in Figure 1.4 .


Figure 1.3 Mounting



### 2. 3. Wall Mounting Bracket

Either mounting bracket has two wood screws and two holes in it to facilitate mounting. You should ensure that you have a solid surface such as 1/2 inches (1.27 cm) plywood of sufficient size to mount the unit.

Figure 1.4 Mounting Brackets




### 2. 4. Ground

You must provide a good proven ground and wire as shown in Figure 1.5 . You should also ensure that all equipment (recording devices, printers, etc.) are grounded at the same point.

## 2. BASIC HARDWARE INSTALLATION


Figure 1.5 Ground Wiring




### 2. 5. Telephone Connections

The telephone connections should be made at the distribution block on your side of the telephone protection units, following established procedures and techniques (Figure 1.6 ). Typically, when you connect to the modular jacks in your building you will be on the protected side of the telephone connections (if you are not sure, you should check). Figure 1.6 illustrates the USOC RJ31X Connector and cable assembly as used by the Controller. The FIGURE also illustrates a typical distribution block set up. Note: the center bridging clips are not inserted on the station block. This means that the Controller acts as a connector between the left and right connection points on the Station Block in Figure 1.6 .


If you wire the Controller per Figure 1.6 it will when programmed, physically route calls through it, to the C.O.. This is done transparently to the user, but all digits (whether DTMF or rotary) dialed by the user can be screened and routed. This is done by splitting the user from the line when the user goes off-hook.



Once enough digits have been screened, the Controller decides the routing and dialing patterns. Then the Controller outputs the proper dialing sequence to the C.O..




Once the digits have been sent to the C.O. the caller will be connected to the C.O..



## 2. BASIC HARDWARE INSTALLATION

Figure 1.6 Distribution Wiring





## 2. BASIC HARDWARE INSTALLATION


### 2. 6. Installation Of A Recording Unit Or Programming Terminal

In order to program the Call Controller with a terminal you must connect a terminal to the Call Controller's RS-232. The terminal must comply with the requirements outlined in Figure 1.7 .

**Note:** If you are using DTMF Chaining you can not use this technique. Proceed to MANUAL 3, for the proper method to connect a recording unit.

Later, you may want to connect a recording device for Call Detail Recording (CDR). If the CDR information is considered valuable, it is recommended that the recording device and the Call Controller have a safe (protected) source of AC power in case of commercial power failure.

Figure 1.7 RS-232 Specifications




## 2. BASIC HARDWARE INSTALLATION

### 2. 7. Powering Up


To power up the Controller simply plug it in as shown in Figure 1.8 .

Figure 1.8 Powering Up



### 2. 8. Power Failure

Should a power failure occur that disables the Controller (or the Controller fails) the user's telephone will be directly connected to the C.O. line. This means that the user will still have access to the telephone network, but the Controller will not screen or route calls.




## 2. BASIC HARDWARE INSTALLATION

### 2. 9. Ground Start Installation Testing

If you have connected your Controller to a ground start trunk, you should perform the test illustrated in Figure 1.9 . If your wiring is correct you should hear a tone when you take the telephone receiver off-hook. If you don't hear a tone, try reversing the tip and ring on the C.O. side of the RJ31 block.

Figure 1.9 Ground Start Testing




### 3. INITIALIZATION

*Before performing any further installation you should power the controller(s) up for 24 hours to allow the back-up batteries to charge fully.*

In order to program the Controller the first time or you wish to reset the Controller to its default values, you must initialize the unit. This can be done from a DTMF telephone only.

#### 3. 1. Initialization From A DTMF Telephone

1. Connect a DTMF instrument to the subscriber side of the block (Tip and Ring leads of the Controller). Do not open the Controller as this will void the warranty. There must be a C.O. trunk with battery, or simulated C.O. trunk, present on the C.O. side of the RJ31X or CA31.



2. With the *power to the Controller disconnected*, go *off-hook*. While holding down the \* key on the DTMF set you will hear a tone in the earpiece of the handset. *Connect the power to the Controller*. When the power is first applied, there will be a click from the Controller as it disconnects (splits) you from the C.O. side.

3. *Continue to hold the \* key* for 10 seconds or more after applying power to the Controller (See Note 1).

4. *Release the \* key*. The unit should respond immediately with a short tone 🎵 from the handset receiver. If a single tone is not heard, return to Step 2 above and start over. The tone burst indicates that the Controller is initialized and remains in programming mode.

Dial 942 903 and two 🎵 bursts of tone will be heard indicating that default data has been loaded. It also indicates that it is still in the programming mode and awaiting a command.

*Idling in programming mode for more than two minutes will automatically exit programming mode. There will be three warning tones after 60 seconds of no activity in programming.*

5. *Go On-Hook* and programming will be exited. To exit programming mode without going on hook, dial 999.

**Note 1:** *When you press \* key on the telephone (connected to the Controller for programming using the #0\* sequence) AND IF YOU HEAR reorder tone from the C.O., or customer equipment, the telephone may be on the wrong side of the telephone block. Check your connections per Figure 1.6 .*

## 3. INITIALIZATION

### 3. 2. Effects Of Initialization

When you have initialized the Controller all dialing will be passed straight through it, to the C.O.. The Controller will not attempt to analyze, route or screen calls.

### 3. 3. Waking Up the Controller

After initializing, you must wakeup the Controller. *You must be in programming mode to wake-up* the Controller. If you are not in programming mode you should enter # 0 \*, or from a terminal a <CR> to enter programming mode. Waking up the Controller for all trunks (while in programming), can be done by dialing 5238. This causes the Controller to:

- A ♪ will be heard by the user, when the user makes a call.
- Only respond to the programming command of # 0 \* from a DTMF telephone or a carriage return (<CR>) from a terminal.
- Set all trunks to loop start, DTMF
- Route all non 1 + (local) calls go via DDD
- Route all 911, 1-411, 1-555, 1-area code-555, 1-800 calls go via DDD
- Route all other 1+ (long distance) calls go via OCC
- Route all local calls after the first digit is dialed
- Route all 1+ calls after fourth digit dialed.

## FOR ADDITIONAL PROGRAMMING

☞ PROCEED TO MANUAL 2 ☞

## FOR CHAINING INSTALLATION AND PROGRAMMING

☞ PROCEED TO MANUAL 3 ☞

# APPENDIX 1

## TABLE A1-1

### HARDWARE SPECIFICATIONS

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b><u>FCC RINGER EQUIVALENCE</u></b>			.7 B	
<b><u>IDLE LINE, LOOP START</u></b>				
<b>RINGER IMPEDANCE:</b> 15 - 60 HZ, 70 -110VAC	10		20	K Ω
20 - 3500 HZ, 10 V	1			M Ω
<b>RINGING SENSITIVITY:</b> 15 - 60 HZ	40			VOLTS
<b>LEAKAGE:</b>				
TIP TO RING, 100V	20			M Ω
TIP TO EARTH, 100V	20			M Ω
<b>OFF-HOOK CURRENT</b>	15		80	MA
<b><u>IDLE LINE, GROUND START</u></b>				
<b>SENSING RESISTANCE:</b> Tip to earth	36	40	45	K Ω
<b>OPEN CIRCUIT VOLTAGE:</b> Tip to Ring	-22	-25	-28	VOLTS
<b>GROUNDING VOLTAGE</b>	-5	0	+10	VOLTS
<b>TIME TO RECOGNIZE TIP-GROUND</b>	10		150	MS
<b>RESISTANCE:</b> Sending Ring-Ground		n/a		
<b><u>BATTERY FEED</u></b>				
<b>OPEN CIRCUIT VOLTAGE</b>	22	24	26	VOLTS
<b>FEED RESISTANCE</b>	550	600	650	Ω
<b>BALANCE:</b> DC	36	40		DB
<b>SHORT CIRCUIT CURRENT</b>			50	MA
<b><u>TERMINATION</u></b>				
<b>RESISTANCE:</b> DC, 20 MA	200		300	Ω
DC, 40 MA	200		300	Ω
AC, 300 - 3000HZ	550	600	650	Ω
<b>RETURN LOSS:</b> 600 OHMS, 20 MA	20	26		DB
<b>OPERATING CURRENT</b>	13		80	MA

# APPENDIX 1

## TABLE A1-1

### HARDWARE SPECIFICATIONS

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b><u>DIAL TONE</u></b>				
CO FEED: Gain 300 Hz	-2	0	+2	DB
<b><u>DTMF RECEIVER</u></b>				
LEVEL	-20		+3	DBM †
LEVEL DIFFERENCE	-6		+6	DB
FREQUENCY: To receive	-1.5		+1.5	%
To not receive	-3.5		+3.5	%
DURATION	34			MS
TIME BETWEEN TONES	40			MS
<b><u>ROTARY RECEIVER</u></b>				
MAKE IMPEDANCE			700	$\Omega$
MAKE DURATION	20		100	MS
BREAK IMPEDANCE	8			K $\Omega$
BREAK DURATION	20		100	MS
RATE	7		20	PPS
<b><u>DTMF SENDER</u></b>				
LEVEL	-8	-6	-3	DBM †
FREQUENCY	-1.3		+1.3	%
DURATION (PROGRAMMABLE)	40	60	130	MS
<b><u>ROTARY SENDER</u></b>				
TIMING (Programmable)	30/20	60/40	60/40	MS/MS
TIMING (60/40):				
Make	35		45	MS
Break	55		65	MS
RATE (at 60/40)	9.9	10	10.1	PPS
INTERDIGIT PAUSE (Programmable)	400	800	1300	MS
<b><u>OPERATING RANGE</u></b>				
AC SUPPLY	103.5	117.0	126.5	VAC
TEMPERATURE	0		40	$^{\circ}$ C
HUMIDITY	0		85	%
ALLOWABLE VOLTAGE (Connected to any point)			300	VOLTS
† With reference to 600 $\Omega$ termination				

# APPENDIX 1

## TABLE A1-2

### ORDERING INFORMATION

The Controller is available as a single or dual or four line unit, complete with power supply, cabling, documentation and can be ordered under the following part numbers:

<b>PAV Call Controller</b> For U.S. applications: SMART-1 Call Controller (four line unit) SMART-1 Call Controller (two line unit) SMART-1 Call Controller (one line unit) For Canadian applications: SMART-1 Call Controller (four line unit) SMART-1 Call Controller (two line unit) SMART-1 Call Controller (one line unit)	8350-005 8350-006 8350-003-PAVAXX 8350-005-CDN 8350-006-CDN 8350-003-PAVCXX
<b>PAV Chaining Call Controller</b> For U.S. applications: SMART-1 Call Controller (four line unit) SMART-1 Call Controller (two line unit) SMART-1 Call Controller (one line unit) For Canadian applications: SMART-1 Call Controller (four line unit) SMART-1 Call Controller (two line unit) SMART-1 Call Controller (one line unit)	8350-001-CHNAXX 8350-002-CHNAXX 8350-003-CHNAXX 8350-001-CHNCXX 8350-002-CHNCXX 8350-003-CHNCXX
The Call Controller Cables can be ordered as: SMART-1 Call Controller Chain Cable SMART-1 Call Controller Chaining Printer Cable	8350-026 8350-027
Call Controller documentation is: Hardware Installation General Programming Guide Chaining Installation and Programming Technical Guide	8350-345-012-NA 8350-345-013-NA 8350-345-014-NA 8350-345-015-NA
<b>Other Components</b> You can order the following components: Wall Mount Bracket Right Angle Mounting Bracket Power Pack RJ31X Cable	8350-010 8350-017 8350-012 8350-013



# INDEX

## C

Chaining, 1.6

## E

Electrical, 1.7, 1.8

## F

FCC, 1.21

FIELD SERVICE, 1.1

## G

Ground Start Testing, 1.14

## H

HARDWARE SPECIFICATIONS, 1.17

## I

Installation of a Recording Unit, 1.12

## M

Mechanical Description, 1.7

Electrical Description, 1.7

## O

ORDERING INFORMATION, 1.19

## P

Positive Account Code Verification, 1.5

Power Failure. *See* Power Up

Power Up, 1.13

## FCC INTERCONNECTION REQUIREMENTS

This equipment has been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines through the standard connection cabling provided with the unit. This section is applicable to telephone interconnection in the United States.

Prior to interconnection of this equipment, the local telephone company is to be notified; Inform the company that you have FCC-registered equipment that you wish to connect to their trunks. Give them the following information:

- The telephone number of the line that you will connect the unit to,
- The equipment number being connected is a MITEL INC. model SMART - 1 Call Controller,
- The FCC registration number for the SMART - 1 Call Controller is EMP 46K-72059-LR-E,
- The FCC Ringer Equivalence Number (REN) is 0.7B,
- The connector jacks are RJ31X.

### CONNECTION LIMITATIONS

Due to the FCC Part 68 Rule, no connection can be made to party lines and to coin telephone service. This unit is designed to be used on standard-device telephone lines. If there are any questions about the telephone line, such as how many pieces of equipment may be connected to it, the telephone company will provide this information upon request.

### NETWORK CHANGES

The telephone company may make changes to its communication service; such changes may include the change of trunk circuits, changes in operational characteristics of its trunks, etc. Before doing this, however, the company shall provide official notification, so that the operation of the Call Controller service will not be interrupted.

### MAINTENANCE LIMITATIONS

This equipment has been registered with the FCC for direct connection to the telephone network. Under the FCC program, the user is restricted from making any changes or repairs and from performing any maintenance operations other than those specifically included in this document.

There are no user repairable parts within the unit. It is sealed against user maintenance. If opened all warranties are voided.

No cabling or wiring changes within the unit are permitted by the user. Plug-ended cables, as detailed in this document, are to be used for all external connections between the unit and the unit and the telephone interface jack.

Power supply components and cabling are only to be changed or maintained by MITEL INC. or by an authorized agent of MITEL INC.

### TROUBLE CORRECTIONS


For all malfunctions, appropriate field service is provided by MITEL INC. or its authorized agents.

### DISCONNECTION

If ever it is decided to permanently disconnect the SMART - 1 Call Controller from the present line, please notify the telephone company of this change

SMART-1

SMART-1 CALL CONTROLLER  
MANUAL 2  
GENERAL PROGRAMMING GUIDE



© Copyright 1988 MITEL INC. All rights reserved.  
® Registered Trademark of MITEL Corporation  
PRINTED IN CANADA

HEADING .....	PAGE
<b>1. GENERAL .....</b>	<b>2.6</b>
1. 1. About This MANUAL .....	2.6
1. 2. As Outlined In MANUAL 1 .....	2.6
1. 3. Wakeup The Controller .....	2.6
<b>2. GENERAL NOTES ON PROGRAMMING .....</b>	<b>2.7</b>
2. 1. Programming With a DTMF Telephone .....	2.7
2. 2. Terminating Variable Length Entries .....	2.7
2. 3. Acknowledgment Tones .....	2.7
2. 4. Typical Resulting Controller Action .....	2.8
2. 5. Terminating A Variable Length Entry .....	2.9
2. 6. Programming With a Terminal .....	2.9
2. 7. Changing Terminal Program Security Code .....	2.9
2. 8. Legal and Illegal Entries .....	2.9
2. 9. Tandem Mode (942 908) .....	2.10
2. 10. Cloning (942 906) .....	2.10
2. 11. Data Verification (902) .....	2.10
2. 12. Special Functions .....	2.10
<b>3. SELECTING THE CONTROLLER TYPE .....</b>	<b>2.12</b>
3. 1. Specifying the Unit As A Call Controller Or A PAV Controller .....	2.12
<b>4. SYSTEM WIDE DATA .....</b>	<b>2.13</b>
4. 1. General .....	2.13
4. 2. Programming Speed Calls .....	2.13
4. 3. Defining The Maximum Number Of Speed Calls .....	2.13
4. 4. Setting up a Speed Call Method 1 .....	2.13
4. 5. Setting up a Speed Call Method 2 .....	2.15
4. 6. To Use A Speed Call Number From a DTMF Phone .....	2.15
4. 7. To Change the Speed Call So It Can Be Accessed From a Rotary Dial Phone .....	2.15
4. 8. If You Wish To Delete The Old Speed Call Access Code .....	2.15
4. 9. To Use The New Number From a Rotary Dial Phone .....	2.15
4. 10. Re-Order Tone Supplied By the Controller .....	2.16
4. 11. Trunks To Be Monitored For Call Detail Recording .....	2.16
4. 12. RS-232 Baud Rate .....	2.16
4. 13. Nulls After A Carriage Return .....	2.16
4. 14. Print Out Incoming Calls .....	2.16
4. 15. Print Format For CDR .....	2.17
4. 16. Route to Monitor for CDR .....	2.17
4. 17. Route Progress Tone Length .....	2.17

HEADING .....	PAGE
<b>5. LINE AND TRUNK OPTIONS .....</b>	<b>2.18</b>
5. 1. General .....	2.18
5. 2. Type Of Dialing And Trunk .....	2.18
5. 3. Rotary Dialing Rates .....	2.18
5. 4. DTMF Dialing Rates .....	2.19
5. 5. On Hook Time .....	2.19
5. 6. Flash Allowed Time .....	2.20
5. 7. Time Between Trunk Release And Next Attempt to Connect .....	2.20
5. 8. Ground Start Attempts .....	2.20
5. 9. Ground Start Attempt Timer .....	2.21
5. 10. Off-Hook Digit Refusal Time .....	2.21
5. 11. User Dial Tone .....	2.21
5. 12. Interdigit Time Out Subscriber Side .....	2.22
5. 13. Interdigit Time Out On 0+ Calls .....	2.22
5. 14. Interdigit Time Out On 01+ Calls .....	2.22
5. 15. Rotary Interdigit Pause On Calls On Outgoing Dialing .....	2.22
5. 16. Off-Hook Tone .....	2.23
5. 17. Incoming Call Detection .....	2.23
5. 18. Controller Operation On Off-Hook .....	2.23
5. 19. Specify Default Route .....	2.24
5. 20. Specify The Digit For Centrex Access .....	2.24
5. 21. Centrex Enable/Disable .....	2.24
5. 22. Time To Auto-Answer .....	2.25
5. 23. Wait For Security Code Timer .....	2.25
5. 24. Incorrect/Failed Security Code Trunk Lockout Timer .....	2.25
5. 25. Off-Hook Recognition Timer .....	2.26
5. 26. Tip Ground Application Recognition Timer .....	2.26
5. 27. Digit Recognition On Outgoing Calls .....	2.26
5. 28. Digit Recognition On Incoming Calls .....	2.27
5. 29. Tip Ground Removal Timer .....	2.27
<b>6. PRIMARY SEARCH TABLES .....</b>	<b>2.28</b>
6. 1. General .....	2.28
6. 2. Primary Search Tables .....	2.28
6. 3. Warning .....	2.28
6. 4. Digits In A Table .....	2.28
6. 5. Default Data .....	2.31
6. 6. Search Tables 801 .....	2.31
6. 7. Search Tables 803 .....	2.31
6. 8. Search Tables 804 .....	2.31
6. 9. Search Tables 807 .....	2.32
6. 10. Search Tables 808 .....	2.32

HEADING .....	PAGE
6. 11. Search Tables 810 .....	2.32
6. 12. Search Tables 811 .....	2.32
6. 13. Special Note .....	2.32
6. 14. Warning .....	2.32
<b>7. COMMON OPTION DATA .....</b>	<b>2.33</b>
7. 1. User Area Code .....	2.33
7. 2. Machine Identifier .....	2.33
7. 3. Auto-Answer Security Code .....	2.33
7. 4. Terminal Program Security Code .....	2.33
<b>8. ROUTE PARAMETER PROGRAMMING .....</b>	<b>2.34</b>
8. 1. General .....	2.34
8. 2. Primary And Alternate Routes .....	2.34
8. 3. Primary And Alternate Destination Number Format .....	2.34
8. 4. Route Progress Tones .....	2.35
8. 5. Number of Account Code Digits .....	2.36
8. 6. Account Code Entry Inter-Digit Timer .....	2.36
8. 7. Account Code Type .....	2.37
8. 8. Action on Call Failure .....	2.38
8. 9. Account Code Warning Tones .....	2.39
8. 10. Account Code Confirmation And Reroute Tones .....	2.40
<b>9. CALL CONTROL DATA ENTRY .....</b>	<b>2.41</b>
9. 1. General .....	2.41
9. 2. Route Strings .....	2.41
9. 3. Access Control Sequences (6R5) .....	2.41
9. 4. A and B Dial Tone Timers .....	2.43
9. 5. Name Of Route .....	2.44
9. 6. Access Number For OCC Telephone Network .....	2.44
9. 7. Authorization Number .....	2.44
9. 8. Dummy Account Code .....	2.45
9. 9. Centrex Number .....	2.45
<b>10. POSITIVE ACCOUNT CODE OPTIONS .....</b>	<b>2.46</b>
10. 1. Description .....	2.46
10. 2. Specifying the Unit As A Controller Or PAV .....	2.46
10. 3. Number Of Account Codes .....	2.46
10. 4. PAV List Maintenance Code .....	2.47
10. 5. Action Digits .....	2.47
10. 6. String Data .....	2.48
10. 7. Programming Positive Account Codes .....	2.48

HEADING .....	PAGE
<b>APPENDIX 1 - SYSTEM INFORMATION .....</b>	<b>2.50</b>
A1. 1 GENERAL .....	2.50
A1. 2 Print Format .....	2.50
A1. 3 MITEL Format .....	2.50
A1. 4 SMART Format .....	2.50
 <b>APPENDIX 2 - SITE INFORMATION .....</b>	 <b>2.53</b>
 CONTROLLER SITE FORM .....	 2.54
 SEARCH TABLE .....	 2.56
SEARCH TABLE FORM .....	2.57
 SPEED CALL .....	 2.58
Setting up a Speed Call Method 1 .....	2.58
Setting up a Speed Call Method 2 .....	2.58
SPEED CALL FORM .....	2.59
 POSITIVE ACCOUNT CODE .....	 2.60
Programming Positive Account Codes .....	2.60
POSITIVE ACCOUNT CODE FORM .....	2.61
 <b>INDEX .....</b>	 <b>2.62</b>

# 1. GENERAL

## 1. 1. About This MANUAL

This manual shows the Controller as a four line unit. Your unit may be one, two or four lines. While programming you should disregard programming for lines that you do not have.

## 1. 2. As Outlined In MANUAL 1

In order to program the Controller:

- ☑ You must have powered up the unit for at least 24 hours to charge the memory battery.
- ☑ You must have initialized the unit if this is an initial installation.
- ☑ You must have either a terminal, or a DTMF telephone connected to the Controller.
- ☑ You must have C.O. trunk with battery present, or a simulated C.O. trunk connected to the line you are programming the Controller with (this is not required if you are using a terminal).

## 1. 3. Wakeup The Controller

After initializing, if you did not do so in MANUAL 1, you must wakeup the Controller. *You must be in programming mode to wakeup* the Controller. If you are not in programming mode you should enter # 0 \*, or from a terminal a <CR> to enter programming mode.

To wakeup all the lines on the Controller: dial 5238. For further information on the X23 (see also page 2.23) parameter see below:

REGISTER X23	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 23T	T = 0 IMMEDIATELY DIAL DEFAULT ROUTE (HOT LINE OPERATION) SEE X24T SEE PAGE 2.24	9
ENTER 2 FOR LINE 2 + 23T		
ENTER 3 FOR LINE 3 + 23T	T = 8 WAIT FOR DIGITS AND SCREEN AND ACT ON THEM AS PROGRAMMED	
ENTER 4 FOR LINE 4 + 23T		
ENTER 5 FOR ALL + 23T	T = 9 CUT THROUGH; NO SCREENING, ROUTING, ETC	

Controller functions at this time are as follows:

- A • will be heard by a user, when the user goes off-hook.
- All trunks loop start, DTMF.
- The security access code is # 0 \*, or from a terminal a <CR>.
- All non 1 + (local) calls go via DDD.
- 911, 1-411, 1-555, 1-area code-555, 1-800 calls go via DDD.
- All other 1+ (long distance) calls go via OCC.
- All local calls go directly after the first digit is dialed.
- All 1+ calls go after fourth digit dialed.



## 2. GENERAL NOTES ON PROGRAMMING

### 2. 1. Programming With a DTMF Telephone

Programming can be done using DTMF tones. The default programming code is # 0 \*. If your situation does not allow the entry of ## (for example: behind a PBX that will not pass the #, or \* to the Controller) you should change the programming code before installing it. To exit programming, hang-up (go on-hook), or idle for more than 2 minutes while in programming mode.


### 2. 2. Terminating Variable Length Entries

To terminate a variable length entry (e.g. Speed Call, Account Codes, 6RX strings, etc.) use ##. If your situation does not allow the entry of ## (For example: behind a PBX that will not pass the ## to the Controller) there is an automatic timeout on variable length information. The entry will be made automatically for you if you do not enter the ## within the time specified by the inter-digit timer (X11 by default 6 seconds. See page 2.22).


### 2. 3. Acknowledgment Tones



While programming the Controller, with a telephone, you will receive audible indications as to correct entries, incorrect entries and programming timeouts. In general, after each correct entry, the Controller will respond with a double tone.

#### If You Hear


 means the command you have entered has been recognized as legal (correct), i.e. you entered # 0 \*.

#### If You Hear


 means the entry you have made has been accepted. This occurs after a parameter has all the digits it needs to program it, or you entered ## on a variable length parameter indicating completion of the entry.

For example: If you dial 100 you will hear , then dial 2 and you will hear .

#### If You Hear

 will be heard, should you idle in the programming mode for more than sixty seconds. After two minutes of idling, you will be automatically logged out of programming mode.















#### If You Hear

 (long) means you have made an incorrect programming entry.

**Note:** In the event of an illegal entry, wait for the tones to stop and then try again. No data was accepted by the Controller for that entry.

## 2. GENERAL NOTES ON PROGRAMMING

### Example

DIAL	HEAR	DIAL	DIAL	HEAR	TO TELL THE CONTROLLER:
#0 *					TO ACCESS PROGRAMMING MODE
942 903					ERASE ALL PREVIOUSLY ENTERED NON-DEFAULT PROGRAMMING DATA AND RELOAD DEFAULT DATA
500		0 OR 1 OR 2 OR 3			LOOP START, ROTARY DIAL GROUND START, ROTARY DIAL LOOP START, DTMF GROUND START, DTMF
519		1			TURN ON OFF-HOOK TONE
523		8			WAIT FOR DIGITS TO BE DIALED BEFORE SENDING TO C.O.
601		USER'S AREA CODE	##		USERS AREA CODE - 3 DIGITS ONLY
621		LONG DISTANCE CARRIER ACCESS NUMBER	##		OCC's ACCESS NUMBER - USUALLY SEVEN DIGITS
622		CUSTOMER'S AUTHORIZATION CODE	##		USUALLY A 3 TO 10 DIGIT AUTHORIZATION CODE

To exit programming, hang-up (go on-hook).

### 2. 4. Typical Resulting Controller Action

When the user dials a destination number the Controller will (due to the 625 Access Control Sequence see page 2.41):

- Detect dial tone.
- Dial the OCC Access Number (621).
- Detect dial tone from the OCC.
- Dial the Authorization Code (622).
- Dial the Destination Number.
- Connect the Caller to the line.

## 2. GENERAL NOTES ON PROGRAMMING

### 2. 5. Terminating A Variable Length Entry

Because some commands that you will give to the Controller require variable length information (after them) that only you will know, a terminator is required to indicate the end of an entry. Generally this occurs with Speed Call information, 8XX and 6RX parameters. This terminator is ##. When using a terminal you can substitute the letter A for the \* and B for the #. You can exit programming mode by dialing 999, or idle for more than 2 minutes while in programming mode.

### 2. 6. Programming With a Terminal

Programming can be done using a terminal (does not apply to Chain Programming, for Chain Programming see MANUAL 3). The default programming code is <CR> (a carriage return). When you enter a carriage return the following screen appears:

```

REV XX-YY ENTERING PROG MODE
>
    
```

### 2. 7. Changing Terminal Program Security Code

At this time you may wish to change the terminal programming access code by:


```

604 MMM##
>
    
```


Where MMM is the new programming code and ## is the termination indicator. The DTMF telephone access (#0\*) will not be affected.

### 2. 8. Legal and Illegal Entries

Each time you enter a legal command e.g. 005, from a terminal, the Controller will automatically space to the next entry point waiting for more input. For example:



Should you make an illegal entry, you will receive:



## 2. GENERAL NOTES ON PROGRAMMING

### 2. 9. Tandem Mode (942 908)

The Controller can be programmed from a remote site by using a personal computer or terminal connected to a Tandem-capable unit. This configuration allows you to dial up and access Controllers in the customer's premise. Programming is done using DTMF tones supplied by the Controller as instructed by the terminal. For further information see **MANUAL 4**.

### 2. 10. Cloning (942 906)

A Controller can be programmed to operate identically to another Controller by using a method called "Cloning". One Controller is programmed (referred to as the Master) and then connected to another Controller you wish to program, using a Cloning cable. For further information see **MANUAL 4**.

### 2. 11. Data Verification (902)

Data Verification is a convenient and fast way to confirm the contents of a Controller's database. You must use a terminal to use this mode and data will be displayed for each parameter entered. Data Verification does not alter the contents of the Controller's database. For further information see **MANUAL 4**.

### 2. 12. Special Functions


Special Function Commands are commands that allow access to specific data in the Controller. If you are using DTMF Chaining, consult **CHAINING PARAMETERS AND COMMANDS** in **MANUAL 3** before using these commands, as they are not functional in a chained access programming session. This is especially true when using 942 903, 942 906, 942 908. There should never be a requirement to use these commands when a Controller is in a Chain. **Note:** the commands are valid, however, on Chained Controllers as long as Chain Programming has not been accessed.

You must be in the programming mode to use these commands.

COMMANDS	DEFINITION
902	DATA CONFIRMATION MODE: AFTER EACH 2 OR 3 DIGIT PREFIX THE CONTROLLER WILL DISPLAY PROGRAMMED DATA
942 903	LOAD DEFAULT DATA. DELETES ALL OTHER EXISTING INFORMATION, RELOADS DEFAULTS
942 904	CLEAR ALL SEARCH TABLES (801-815, 821-835)
942 906	ENTER CLONE MASTER CODE.
907	RETURN TO DATA PROGRAMMING MODE FROM DATA CONFIRMATION MODE.
942 908	ENTER TANDEM MODE (FOR PROGRAMMING REMOTE CONTROLLERS)
999	EXIT PROGRAMMING MODE
980MMDDHHMM	SET THE INTERNAL CLOCK WHERE MM = MONTH, DD = DAY, HH = HOURS, MM = MINUTES.

## 2. GENERAL NOTES ON PROGRAMMING

Figure 2.1 Programming The Controller



**Warning:** When programming Dial Plan/Search Templates, care should be taken to not affect calls that are dialed for emergency, e.g. 911 calls. After programming a Controller, check that the operation of emergency dialing has not been adversely affected.

### 3. SELECTING THE CONTROLLER TYPE

#### 3. 1. Specifying the Unit As A Call Controller Or A PAV Controller

As it defaults to a regular Controller when initialized, you must specify the Controller as a PAV Controller if you wish to use it as a Positive Account Code Verifier. This can be done by setting 011 to 1 as shown below:

REGISTER 011	DESCRIPTION	DEFAULT
<i>ENTER 011T</i>	T = 0 FOR REGULAR CONTROLLER OPERATION T = 1 FOR PAV CONTROLLER	0

## 4. SYSTEM WIDE DATA

### 4. 1. General

You may want to change System Wide Data, because the default data does not meet your requirements. For example, all telephone lines are specified as loop start when default data is loaded. If you are using ground start lines, this must be changed.

There is a series of Charts in APPENDIX 2 that will aid you in recording the information that you enter.

### 4. 2. Programming Speed Calls

Speed Calls apply on a SYSTEM wide basis, but access can be restricted. There is a SPEED CALL Chart in APPENDIX 2 that will aid you in recording the speed calls used and the numbers assigned to them.

### 4. 3. Defining The Maximum Number Of Speed Calls

You can define the maximum number of Speed Calls by:


REGISTER 000	DESCRIPTION	DEFAULT
ENTER 000T	T = 1 FOR 100 SPEED CALLS MAXIMUM T = 2 FOR 1000 SPEED CALLS MAXIMUM	1

Note: An additional programming change will be necessary if you selected 2 for 1,000 Speed Calls, if the Speed Call trigger is to be recognized by the Primary Search Table and acted on.

1. The information in the 803 register (\*#9#9#2) must be deleted by entering 803 \*#9#9#9.
2. A new value must be added to the 804 register as 804 \*#9#9#9#2.
3. This changes the Speed Call trigger range from \*NN to \*NNN. The \* can be a different digit if required.

### 4. 4. Setting up a Speed Call Method 1

Speed Call can be programmed in one of two ways. The first is generally done at the time of installation programming and has the following format:



## 4. SYSTEM WIDE DATA

When you programmed 000T (see page 2.13), you selected either 100 or 1000 speed calls available. To program a speed call use one of the formats in the following Chart:

REGISTER (FORMAT)	DEFINITION																																				
<b>FOR 100 SPEED CALLS</b> 7NNDKMM...MM## OR 7NNDKMM...MM* P..PP##	FORMAT FOR UP TO 100 ENTRIES. NN IS THE SERVICE CODE TO BE DIALED BY THE SUBSCRIBER AND MM...MM IS THE NUMBER TO WHICH THE CODE IS TRANSLATED																																				
<b>FOR 1000 SPEED CALLS</b> 7NNNDKMM...MM## OR 7NNNDKMM...MM* P..PP##	FORMAT FOR UP TO 1000 ENTRIES. NNN IS THE SERVICE CODE TO BE DIALED BY THE SUBSCRIBER AND MM...MM IS THE NUMBER TO WHICH THE CODE IS TRANSLATED																																				
<b>D is the key that selects the lines to access the call number</b> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>DIGIT</th> <th>SELECTS TRUNK</th> <th>DIGIT</th> <th>SELECTS TRUNK</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ALL</td> <td>7</td> <td>TRUNK 1,2,3</td> </tr> <tr> <td>1</td> <td>TRUNK 1</td> <td>8</td> <td>TRUNK 4</td> </tr> <tr> <td>2</td> <td>TRUNK 2</td> <td>9</td> <td>TRUNK 1,4</td> </tr> <tr> <td>3</td> <td>TRUNK 1,2</td> <td>*</td> <td>TRUNK 2,4</td> </tr> <tr> <td>4</td> <td>TRUNK 3</td> <td>#</td> <td>TRUNK 1,2,4</td> </tr> <tr> <td>5</td> <td>TRUNK 1,3</td> <td>C</td> <td>TRUNK 3,4</td> </tr> <tr> <td>6</td> <td>TRUNK 2,3</td> <td>D</td> <td>TRUNK 1,3,4</td> </tr> <tr> <td></td> <td></td> <td>E</td> <td>TRUNK 2,3,4</td> </tr> </tbody> </table>		DIGIT	SELECTS TRUNK	DIGIT	SELECTS TRUNK	0	ALL	7	TRUNK 1,2,3	1	TRUNK 1	8	TRUNK 4	2	TRUNK 2	9	TRUNK 1,4	3	TRUNK 1,2	*	TRUNK 2,4	4	TRUNK 3	#	TRUNK 1,2,4	5	TRUNK 1,3	C	TRUNK 3,4	6	TRUNK 2,3	D	TRUNK 1,3,4			E	TRUNK 2,3,4
DIGIT	SELECTS TRUNK	DIGIT	SELECTS TRUNK																																		
0	ALL	7	TRUNK 1,2,3																																		
1	TRUNK 1	8	TRUNK 4																																		
2	TRUNK 2	9	TRUNK 1,4																																		
3	TRUNK 1,2	*	TRUNK 2,4																																		
4	TRUNK 3	#	TRUNK 1,2,4																																		
5	TRUNK 1,3	C	TRUNK 3,4																																		
6	TRUNK 2,3	D	TRUNK 1,3,4																																		
		E	TRUNK 2,3,4																																		
MUST BE ENTERED FROM A TERMINAL																																					
<b>K specifies how routing will be accomplished</b> <table border="1" style="margin-left: auto; margin-right: auto;"> <tbody> <tr> <td>0 - 7</td> <td>Force on Route 0 - 7</td> </tr> <tr> <td>8</td> <td>Use the screening table to determine routing</td> </tr> <tr> <td>9</td> <td>Dial immediate, no Route # (transparent)</td> </tr> </tbody> </table>		0 - 7	Force on Route 0 - 7	8	Use the screening table to determine routing	9	Dial immediate, no Route # (transparent)																														
0 - 7	Force on Route 0 - 7																																				
8	Use the screening table to determine routing																																				
9	Dial immediate, no Route # (transparent)																																				
<b>PP is an Account Code and is separated from the destination number by the * . The * and the Account Code are optional.</b>																																					
<b>## Enters the information into memory</b>																																					

**Speed Call Programming Example 1:** Since the screen 803 \*#9#9#2 already exists by default, up to 100 Speed Calls with the \*NN format can be programmed:

Enter 722 085551818## will cause 555-1818 to be dialed out whenever a user dials \*22.

**Speed Call Programming Example 2:** To program 411 calls to go to 1-555-1212 you must set 000T to 0002. Then:

Enter 803 411 #2##, sets 411 as a Speed Call trigger digit.

Enter 7411 08 15551212## enters the Speed Call digit.

The unit is now set to dial out 1-555-1212 whenever 411 is dialed into any trunk.



## 4. SYSTEM WIDE DATA

### 4. 5. Setting up a Speed Call Method 2

Generally, this method of programming Speed Call is used by a user after an installation is complete. All trunks will have access to the Speed Calls and all calls will be screened because DK as outlined previously is automatically set to 08. By default the user Speed Call programming code is ###.

STEP	DIAL	DESCRIPTION
1	###	IS THE USER SPEED CALL PROGRAMMING CODE
2	NN(N)	IS THE LOCATION 00 THROUGH 99 OR 000 THROUGH 999
3	MM...	IS THE TELEPHONE NUMBER TO BE DIALED
4	##	ENTERS THE INFORMATION
5		REPEAT STEPS 2 - 4 UNTIL ALL NUMBERS ARE ENTERED
6		HANG UP TO EXIT. DO NOT DIAL 999

### 4. 6. To Use A Speed Call Number From a DTMF Phone

1. Dial \* NN(N), where NN(N) is the two or three digit location number. The number entered at the Speed Call location specified will be dialed out, if it exists. If it does not exist, or the particular trunk being accessed is not allowed access, re-order tone will be supplied to the user.

### 4. 7. To Change the Speed Call So It Can Be Accessed From a Rotary Dial Phone

To change the Speed Call Access Code to 11NN instead of \*NN:

1. Dial # 0 \*, or the current programming access code.
2. Dial 80411#9#9#2## add new Speed Call access code, which will be 11NN in this case.
3. Hang-up to exit program mode if done programming.

### 4. 8. If You Wish To Delete The Old Speed Call Access Code

1. While in programming mode Dial 803 \* #9#9#9## to delete the old access code of \*NN.
2. Hang-up to exit program mode if done programming.

### 4. 9. To Use The New Number From a Rotary Dial Phone

1. Dial 11NN where NN is the two digit location number. The number entered at the Speed Call location specified will be dialed out, if it exists. If it does not exist, or the particular trunk being accessed is not allowed access, re-order tone will be supplied to the user.

## 4. SYSTEM WIDE DATA

### 4. 10. Re-Order Tone Supplied By the Controller

REGISTER 001	DESCRIPTION	DEFAULT
<i>ENTER 001T</i>	WHERE T IS: 0 = 400HZ, INTERRUPTED AT 180 IPM 1 = 400 HZ CONTINUOUS	0

### 4. 11. Trunks To Be Monitored For Call Detail Recording

You can control which trunk(s) are to be monitored for Call Detail Recording (CDR see page 2.17) by:

REGISTER 005	DESCRIPTION	DEFAULT
<i>ENTER 005T</i>	WHERE T IS: 0 FOR ALL 1 FOR 1 2 FOR 2 3 FOR 1,2 4 FOR 3 5 FOR 1,3 6 FOR 2,3 7 FOR 1,2,3 8 FOR 4 9 FOR 1,4 * FOR 2,4 # FOR 1,2,4 C FOR 3,4 D FOR 1,3,4 E FOR 2,3,4	0

Note: C, D, E can only be entered from a terminal.

### 4. 12. RS-232 Baud Rate

REGISTER 006	DESCRIPTION	DEFAULT
<i>ENTER 006T</i>	T = 1 FOR 110 T = 2 FOR 300 T = 3 FOR 600 T = 4 FOR 1200 T = 5 FOR 2400 T = 6 FOR 4800 T = 7 FOR 9600	4

### 4. 13. Nulls After A Carriage Return

REGISTER 007	DESCRIPTION	DEFAULT
<i>ENTER 007T</i>	T = THE NUMBER OF NULLS (0-9)	2

### 4. 14. Print Out Incoming Calls

You can control the printing of records of incoming calls in Call Detail Recording (CDR see page 2.17) by:

REGISTER 008	DESCRIPTION	DEFAULT
<i>ENTER 008T</i>	T = 0 FOR NO T = 1 FOR YES	CHAIN 0 PAV 1

## 4. SYSTEM WIDE DATA

### 4. 15. Print Format For CDR

You can change Call Detail Recording (CDR) format as required:

- The MITEL format was developed for PBX applications (specifically MITEL PBXs). Some fields are used for call transfers, attendants, etc., and are not supplied by the Controller.
- The SMART format is similar to the MITEL format, however it has reduced the printing width to fit in 80 columns and the R field is in ASCII instead of numeric.

For further information on the print format see APPENDIX 1 (page 2.50). The print format can be changed by:

REGISTER 009	DESCRIPTION	DEFAULT	
<i>ENTER 009T</i>	T = 0 FOR OFF	1	
	T = 1 FOR MITEL T = 2 FOR SMART		PROVIDE A CARRIAGE RETURN LINE FEED AT START OF RECORD
	T = 5 FOR MITEL T = 6 FOR SMART		PROVIDE A CARRIAGE RETURN LINE FEED AT START OF RECORD AND END

### 4. 16. Route to Monitor for CDR

You can specify which route(s) are to be monitored for CDR by:

REGISTER 010	DESCRIPTION	DEFAULT
<i>ENTER 010T</i>	T = 0 FOR ROUTE 1 T = 1 FOR ROUTE 2 T = 2 FOR ROUTE 3 T = 3 FOR ROUTE 4 T = 4 FOR ROUTE 5 T = 5 FOR ROUTE 6 T = 6 FOR ROUTE 7 T = 7 FOR ROUTE 8 T = 8 ROUTED CALLS AND OUTSIDE CENTREX CALLS ONLY T = 9 ALL CALLS	9

### 4. 17. Route Progress Tone Length

REGISTER 015	DESCRIPTION	DEFAULT
<i>ENTER 015T</i>	T = 0 400 MS    T = 1 100 MS	0

## 5. LINE AND TRUNK OPTIONS

### 5. 1. General

When programming line and trunk options you should remember Trunk 1 is not related to Route 1, or Trunk 2 is not related to Route 2, etc.

Line and Trunk refer to the physical line that is supplied by your telephone company. Route refers to the way the Controller will attempt to route the call through the Public Switched Telephone Network.

For example: 1-800 numbers may be routed on Route 0, while a 1-201 is routed to a common carrier via Route 1. Any trunk may access any Route depending on how you program the Controller.

All entries in this part are of a predetermined length. When you have entered the correct number of digits, the Controller will automatically accept the entry (informing as to the correctness as outlined on page 2.7).

### 5. 2. Type Of Dialing And Trunk

You can specify the type of trunk as loop or ground start, and the type of dialing as DTMF or rotary by:

REGISTER X00	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 00T</i>	T = 0 FOR LOOP START, ROTARY T = 1 GROUND START, ROTARY T = 2 FOR LOOP START, DTMF T = 3 FOR GROUND START, DTMF	2
<i>ENTER 2 FOR LINE 2 + 00T</i>		
<i>ENTER 3 FOR LINE 3 + 00T</i>		
<i>ENTER 4 FOR LINE 4 + 00T</i>		
<i>ENTER 5 FOR ALL + 00T</i>		

### 5. 3. Rotary Dialing Rates

REGISTER X01	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 01T</i>	T = 2 FOR OUTPULSE AT 30/20 MS 20 PPS WHICH EQUATES TO 60% BREAK  T = 4 FOR OUTPULSE AT 60/40 MS 10 PPS WHICH EQUATES TO 60% BREAK	4
<i>ENTER 2 FOR LINE 2 + 01T</i>		
<i>ENTER 3 FOR LINE 3 + 01T</i>		
<i>ENTER 4 FOR LINE 4 + 01T</i>		
<i>ENTER 5 FOR ALL + 01T</i>		

## 5. LINE AND TRUNK OPTIONS

### 5. 4. DTMF Dialing Rates


REGISTER X02	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 02T	T = 0 40 MS(fast)	1
ENTER 2 FOR LINE 2 + 02T	T = 1 50 MS	
ENTER 3 FOR LINE 3 + 02T	T = 2 60 MS	
ENTER 4 FOR LINE 4 + 02T	T = 3 70 MS	
ENTER 5 FOR ALL + 02T	T = 4 80 MS	
	T = 5 90 MS	
	T = 6 100 MS	
	T = 7 110 MS	
	T = 8 120 MS	
	T = 9 130 MS(slow)	

### 5. 5. On Hook Time

You can specify the on-hook recognition time by:

REGISTER X03	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 03T	T = 0 FOR 80 MS	6
ENTER 2 FOR LINE 2 + 03T	T = 1 FOR 100 MS	
ENTER 3 FOR LINE 3 + 03T	T = 2 FOR 150 MS	
ENTER 4 FOR LINE 4 + 03T	T = 3 FOR 200 MS	
ENTER 5 FOR ALL + 03T	T = 4 FOR 300 MS	
	T = 5 FOR 500 MS	
	T = 6 FOR 750 MS	
	T = 7 FOR 1000 MS	
	T = 8 FOR 1330 MS	
	T = 9 FOR 1660 MS	
	T = * FOR 2 S	
	T = # FOR 2.5S	

Note: There is a relationship between X03 and X04 (see page 2.20). If X03 is less than X04, all switch-hook flashes will be recognized as on-hooks as outlined below:



## 5. LINE AND TRUNK OPTIONS

### 5. 6. Flash Allowed Time

REGISTER X04	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 04T</i>	T = 0 FOR 80 MS	1
<i>ENTER 2 FOR LINE 2 + 04T</i>	T = 1 FOR 100 MS	
<i>ENTER 3 FOR LINE 3 + 04T</i>	T = 2 FOR 150 MS	
<i>ENTER 4 FOR LINE 4 + 04T</i>	T = 3 FOR 200 MS	
<i>ENTER 5 FOR ALL + 04T</i>	T = 4 FOR 300 MS	
	T = 5 FOR 500 MS	
	T = 6 FOR 750 MS	
	T = 7 FOR 1000 MS	
	T = 8 FOR 1330 MS	
	T = 9 FOR 1660 MS	
	T = * FOR 2 S	
	T = # FOR 2.5 S	
TO DISABLE THE FLASH SPECIFY A TIME THAT IS GREATER THAN X03T		

Note: This feature should generally be set to #, except in those cases where you require the ability to use conference features. This is usually required for C.O. conference feature, or when between the user's equipment (telephone or Key system) and a PBX.

### 5. 7. Time Between Trunk Release And Next Attempt to Connect

REGISTER X05	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 05T</i>	T = 0 FOR 500 MS	5
<i>ENTER 2 FOR LINE 2 + 05T</i>	T = 1 FOR 650 MS	
<i>ENTER 3 FOR LINE 3 + 05T</i>	T = 2 FOR 800 MS	
<i>ENTER 4 FOR LINE 4 + 05T</i>	T = 3 FOR 950 MS	
<i>ENTER 5 FOR ALL + 05T</i>	T = 4 FOR 1100 MS	
	T = 5 FOR 1250 MS	
	T = 6 FOR 1400 MS	
	T = 7 FOR 1550 MS	
	T = 8 FOR 1700 MS	
	T = 9 FOR 1850 MS	

### 5. 8. Ground Start Attempts

If you have a ground start trunk, you can specify the number of ground start attempts. In most cases this should not have to be changed.

REGISTER X06	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 06T</i>	T = THE NUMBER OF TIMES THE CONTROLLER WILL ATTEMPT TO CONNECT TO A GROUND START TRUNK BEFORE STOPPING	3
<i>ENTER 2 FOR LINE 2 + 06T</i>		
<i>ENTER 3 FOR LINE 3 + 06T</i>		
<i>ENTER 4 FOR LINE 4 + 06T</i>		
<i>ENTER 5 FOR ALL + 06T</i>		

## 5. LINE AND TRUNK OPTIONS

### 5. 9. Ground Start Attempt Timer

If you have a ground start trunk, you can specify ground start attempt time, which in most cases should not have to be changed:

REGISTER X07	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 07T ENTER 2 FOR LINE 2 + 07T ENTER 3 FOR LINE 3 + 07T ENTER 4 FOR LINE 4 + 07T ENTER 5 FOR ALL + 07T	T = THE AMOUNT OF TIME IN SECs. CONTROLLER WILL ATTEMPT TO CONNECT TO A GROUND START TRUNK BEFORE STOPPING	3

### 5. 10. Off-Hook Digit Refusal Time

You can specify the time between a user going off-hook and when the Controller will accept digits on a per trunk basis. The time can be set by:

REGISTER X08	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 08T ENTER 2 FOR LINE 2 + 08T ENTER 3 FOR LINE 3 + 08T ENTER 4 FOR LINE 4 + 08T ENTER 5 FOR ALL + 08T	T = 0 FOR NONE      T = 5 FOR .5 SEC T = 1 FOR .1 SEC    T = 6 FOR .6 SEC T = 2 FOR .2 SEC    T = 7 FOR .7 SEC T = 3 FOR .3 SEC    T = 8 FOR .8 SEC T = 4 FOR .4 SEC    T = 9 FOR .9 SEC	3

Note: In the PAV Controller, if X19T (see page 2.23) Off-Hook Progress Tone is set to a 1 or enabled, the progress tone will not occur until the X08T (see page 2.16) timer has expired or reached 700 ms. The off-hook progress tone is 200 ms in duration.

### 5. 11. User Dial Tone

You can specify the dial tone supplied, and what the caller will hear while the Controller is dialing as silent, or ticking by:

REGISTER X09	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 09T ENTER 2 FOR LINE 2 + 09T ENTER 3 FOR LINE 3 + 09T ENTER 4 FOR LINE 4 + 09T ENTER 5 FOR ALL + 09T	SILENT DIALOUT      TICKING DIALOUT T = 0 NONE            T = 2 NONE T = 1 INTERNAL*      T = 3 INTERNAL* T = 4 FROM C.O.      T = 6 FROM C.O.	4

\*You should note that internal dial tone interacts with the X19 (see page 2.23) feature.

## 5. LINE AND TRUNK OPTIONS

### 5. 12. Interdigit Time Out Subscriber Side

REGISTER X11	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 11T</i>	T = 0 FOR NO TIMEOUT	3
<i>ENTER 2 FOR LINE 2 + 11T</i>	T = 1 FOR 2 SEC      T = 6 FOR 12 SEC	
<i>ENTER 3 FOR LINE 3 + 11T</i>	T = 2 FOR 4 SEC      T = 7 FOR 14 SEC	
<i>ENTER 4 FOR LINE 4 + 11T</i>	T = 3 FOR 6 SEC      T = 8 FOR 16 SEC	
<i>ENTER 5 FOR ALL + 11T</i>	T = 4 FOR 8 SEC      T = 9 FOR 18 SEC T = 5 FOR 10 SEC    T = * FOR 20 SEC T = # FOR 22 SEC	

### 5. 13. Interdigit Time Out On 0+ Calls

REGISTER X12	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 12T</i>	T = 0 FOR NO TIMEOUT	2
<i>ENTER 2 FOR LINE 2 + 12T</i>	T = 1 FOR 2 SEC      T = 6 FOR 12 SEC	
<i>ENTER 3 FOR LINE 3 + 12T</i>	T = 2 FOR 4 SEC      T = 7 FOR 14 SEC	
<i>ENTER 4 FOR LINE 4 + 12T</i>	T = 3 FOR 6 SEC      T = 8 FOR 16 SEC	
<i>ENTER 5 FOR ALL + 12T</i>	T = 4 FOR 8 SEC      T = 9 FOR 18 SEC T = 5 FOR 10 SEC    T = * FOR 20 SEC T = # FOR 22 SEC	

### 5. 14. Interdigit Time Out On 01+ Calls

REGISTER X13	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 13T</i>	T = 0 FOR NO TIMEOUT	2
<i>ENTER 2 FOR LINE 2 + 13T</i>	T = 1 FOR 2 SEC      T = 6 FOR 12 SEC	
<i>ENTER 3 FOR LINE 3 + 13T</i>	T = 2 FOR 4 SEC      T = 7 FOR 14 SEC	
<i>ENTER 4 FOR LINE 4 + 13T</i>	T = 3 FOR 6 SEC      T = 8 FOR 16 SEC	
<i>ENTER 5 FOR ALL + 13T</i>	T = 4 FOR 8 SEC      T = 9 FOR 18 SEC T = 5 FOR 10 SEC    T = * FOR 20 SEC T = # FOR 22 SEC	

### 5. 15. Rotary Interdigit Pause On Calls On Outgoing Dialing

REGISTER X14	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 14T</i>	T = 0 400 MS      T = 4 800 MS	4
<i>ENTER 2 FOR LINE 2 + 14T</i>	T = 1 500 MS      T = 5 900 MS	
<i>ENTER 3 FOR LINE 3 + 14T</i>	T = 2 600 MS      T = 6 1 SEC	
<i>ENTER 4 FOR LINE 4 + 14T</i>	T = 3 700 MS      T = 7 1.1 SEC	
<i>ENTER 5 FOR ALL + 14T</i>	T = 8 1.2 SEC	



## 5. LINE AND TRUNK OPTIONS

### 5. 16. Off-Hook Tone

You can specify whether, or not, a caller will receive an Off-Hook Tone. The tone is 200 mS in duration, and if enabled, will occur after the X08T timer (see page 2.21) has expired, or reached 700 mS. Note: If the Off-Hook Tone is enabled and internal dialtone has been programmed, the Off-Hook Tone will be 300 mS long, followed by NO dialtone. The Off-Hook Tone is controlled on a per trunk basis by:

REGISTER X19	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 19T</i>	WHERE T IS: 0 FOR DISABLED 1 FOR ENABLED	1
<i>ENTER 2 FOR LINE 2 + 19T</i>		
<i>ENTER 3 FOR LINE 3 + 19T</i>		
<i>ENTER 4 FOR LINE 4 + 19T</i>		
<i>ENTER 5 FOR ALL + 19T</i>		

### 5. 17. Incoming Call Detection

You can specify the Controller's sensitivity to incoming ringing on a scale of 0 to 9 (where 0 is the most sensitive and 9 the least). If the setting is too sensitive you will receive false incoming calls. If the setting is not sensitive enough, you may miss incoming calls as the Controller will not detect them. It should not be necessary to change the default value for normal operation, but you can by:

REGISTER X20	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 20T</i>	WHERE T IS ENTERED AS 0 THROUGH 9, WHERE 9 IS LEAST SENSITIVE AND 0 IS MOST SENSITIVE	2
<i>ENTER 2 FOR LINE 2 + 20T</i>		
<i>ENTER 3 FOR LINE 3 + 20T</i>		
<i>ENTER 4 FOR LINE 4 + 20T</i>		
<i>ENTER 5 FOR ALL + 20T</i>		

### 5. 18. Controller Operation On Off-Hook

When the Controller loads default data, it will not yet screen or route digits dialed by a user. You change this for each trunk by:

REGISTER X23	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 23T</i>	T = 0 IMMEDIATELY DIAL DEFAULT ROUTE (HOT LINE OPERATION) SEE X24T (SEE PAGE 2.24)  T = 8 WAIT FOR DIGITS AND SCREEN AND ACT ON THEM AS PROGRAMMED  T = 9 CUT THROUGH; NO SCREENING, ROUTING, ETC	9
<i>ENTER 2 FOR LINE 2 + 23T</i>		
<i>ENTER 3 FOR LINE 3 + 23T</i>		
<i>ENTER 4 FOR LINE 4 + 23T</i>		
<i>ENTER 5 FOR ALL + 23T</i>		

## 5. LINE AND TRUNK OPTIONS

### 5. 19. Specify Default Route

You can specify a default route for a trunk (see also #8 Action Digit) by:

REGISTER X24	DESCRIPTION ‡	DEFAULT
ENTER 1 FOR LINE 1 + 24T ENTER 2 FOR LINE 2 + 24T ENTER 3 FOR LINE 3 + 24T ENTER 4 FOR LINE 4 + 24T ENTER 5 FOR ALL + 24T	WHERE T IS THE DEFAULT ROUTE 0 TO 7.	0

‡ For the Route specified here to be in effect, X23 (see page 2.23) must be set to X230 or a #8 (Action Digit) must occur in the Primary Search Table (after the number dialed has been matched). This will cause the Controller to use a specific Route. If a Route 0-3 has been selected (through programming) all calls will be routed on the Primary Route. If a Route 4-7 has been selected (through programming) all calls will be routed on the Alternate Route.

### 5. 20. Specify The Digit For Centrex Access

You can specify the digit to be used for outgoing centrex access. This usually occurs when the Controller is placed behind a Centrex or PBX unit and you are required to dial a digit - typically a 9 - to access the outside line. If the Controller detects a Centrex Access Digit it will screen the remaining digits and process the call. If the Controller does not detect a Centrex Access Digit it will not screen and just dial.

REGISTER X25	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 25T ENTER 2 FOR LINE 2 + 25T ENTER 3 FOR LINE 3 + 25T ENTER 4 FOR LINE 4 + 25T ENTER 5 FOR ALL + 25T	WHERE T IS THE CENTREX DIGIT. IF X26T = X261 (BELOW) THEN ALL INTRA CENTREX CALLS ARE DIALED IMMEDIATELY	9

### 5. 21. Centrex Enable/Disable

You can enable or disable the Centrex by:

REGISTER X26	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 26T ENTER 2 FOR LINE 2 + 26T ENTER 3 FOR LINE 3 + 26T ENTER 4 FOR LINE 4 + 26T ENTER 5 FOR ALL + 26T	WHERE T IS: 0 FOR DISABLE 1 FOR ENABLE	0

## 5. LINE AND TRUNK OPTIONS

### 5. 22. Time To Auto-Answer

You can specify the time the Controller waits before answering an incoming call after the detection of ringing by:

REGISTER X27	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 27T</i>	T = 0 FOR DISABLE	0
<i>ENTER 2 FOR LINE 2 + 27T</i>	T = 1 FOR 10 S      T = 6 FOR 60 S	
<i>ENTER 3 FOR LINE 3 + 27T</i>	T = 2 FOR 20 S      T = 7 FOR 70 S	
<i>ENTER 4 FOR LINE 4 + 27T</i>	T = 3 FOR 30 S      T = 8 FOR 80 S	
<i>ENTER 5 FOR ALL + 27T</i>	T = 4 FOR 40 S      T = 9 FOR 90 S T = 5 FOR 50 S      T = * FOR 100 S T = # FOR 120 S	

### 5. 23. Wait For Security Code Timer

This parameter specifies the time in which a security code (603 Parameter see 7. 3. on page 2.33) must be entered on a trunk after the Controller auto-answers. If timeout occurs or an incorrect password is entered, the trunk will be locked as specified in the X29 parameter (next parameter discussed). The time to wait for password can be changed by:

REGISTER X28	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 28T</i>	T = 0 FOR DISABLE	6
<i>ENTER 2 FOR LINE 2 + 28T</i>	T = 1 FOR 10 S      T = 6 FOR 60 S	
<i>ENTER 3 FOR LINE 3 + 28T</i>	T = 2 FOR 20 S      T = 7 FOR 70 S	
<i>ENTER 4 FOR LINE 4 + 28T</i>	T = 3 FOR 30 S      T = 8 FOR 80 S	
<i>ENTER 5 FOR ALL + 28T</i>	T = 4 FOR 40 S      T = 9 FOR 90 S T = 5 FOR 50 S      T = * FOR 100 S T = # FOR 120 S	

### 5. 24. Incorrect/Failed Security Code Trunk Lockout Timer

Failure to enter the correct programming password during the time specified by the X28 parameter enables this timer. You can specify the time a trunk is locked out. If the timeout occurs, or an incorrect password is entered, the trunk will be locked out as specified, or until on the user side of the line goes off-hook. The time for password can be changed by:

REGISTER X29	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 29T</i>	T = 0 FOR DISABLE	9
<i>ENTER 2 FOR LINE 2 + 29T</i>	T = 1 FOR 10 S      T = 6 FOR 60 S	
<i>ENTER 3 FOR LINE 3 + 29T</i>	T = 2 FOR 20 S      T = 7 FOR 70 S	
<i>ENTER 4 FOR LINE 4 + 29T</i>	T = 3 FOR 30 S      T = 8 FOR 80 S	
<i>ENTER 5 FOR ALL + 29T</i>	T = 4 FOR 40 S      T = 9 FOR 90 S T = 5 FOR 50 S      T = * FOR 100 S T = # FOR 120 S	

## 5. LINE AND TRUNK OPTIONS

### 5. 25. Off-Hook Recognition Timer

REGISTER X30	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 30T</i>	WHERE T IS: 0 = 20 MS    4 = 80 MS    8 = 160 MS 1 = 20 MS    5 = 100 MS    9 = 180 MS 2 = 40 MS    6 = 120 MS    * = 200 MS 3 = 60 MS    7 = 140 MS    # = 220 MS	3
<i>ENTER 2 FOR LINE 2 + 30T</i>		
<i>ENTER 3 FOR LINE 3 + 30T</i>		
<i>ENTER 4 FOR LINE 4 + 30T</i>		
<i>ENTER 5 FOR ALL + 30T</i>		

### 5. 26. Tip Ground Application Recognition Timer

This command selects the time that a tip ground must be applied on a ground start trunk, for that application to be recognized. If you are using a terminal you can substitute the letter A for the \* and B for the #.

REGISTER X31	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 31T</i>	T = 0 FOR 40 MS    T = 6 FOR 240 MS T = 1 FOR 40 MS    T = 7 FOR 280 MS T = 2 FOR 80 MS    T = 8 FOR 320 MS T = 3 FOR 120 MS    T = 9 FOR 360 MS T = 4 FOR 160 MS    T = * FOR 400 MS T = 5 FOR 200 MS    T = # FOR 440 MS	3
<i>ENTER 2 FOR LINE 2 + 31T</i>		
<i>ENTER 3 FOR LINE 3 + 31T</i>		
<i>ENTER 4 FOR LINE 4 + 31T</i>		
<i>ENTER 5 FOR ALL + 31T</i>		

### 5. 27. Digit Recognition On Outgoing Calls

REGISTER X32	DESCRIPTION	DEFAULT
<i>ENTER 1 FOR LINE 1 + 32T</i>	T = 0 FOR ALLOW DTMF, 10 OR 20 PPS T = 1 IGNORE ALL ROTARY T = 2 IGNORE ALL DTMF T = 3 IGNORE ALL DIGITS T = 5 FOR GO TO REORDER ON ROTARY T = 6 FOR GO TO REORDER ON DTMF T = 7 FOR GO TO REORDER ANY DIGITS	0
<i>ENTER 2 FOR LINE 2 + 32T</i>		
<i>ENTER 3 FOR LINE 3 + 32T</i>		
<i>ENTER 4 FOR LINE 4 + 32T</i>		
<i>ENTER 5 FOR ALL + 32T</i>		

## 5. LINE AND TRUNK OPTIONS

### 5. 28. Digit Recognition On Incoming Calls

REGISTER X33	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 33T ENTER 2 FOR LINE 2 + 33T ENTER 3 FOR LINE 3 + 33T ENTER 4 FOR LINE 4 + 33T ENTER 5 FOR ALL + 33T	T = 0 FOR ACCEPT DTMF, 10 OR 20 PPS T = 1 IGNORE ALL ROTARY T = 2 IGNORE ALL DTMF T = 3 IGNORE ALL DIGITS T = 5 FOR GO TO REORDER ON ROTARY T = 6 FOR GO TO REORDER ON DTMF T = 7 FOR GO TO REORDER ANY DIGITS T = 8 ALLOW DTMF OR 10 PPS ROTARY, IGNORE 20 PPS ROTARY T = A ALLOW 10 PPS ROTARY, IGNORE DTMF AND 20 PPS ROTARY T = D GO TO REORDER ON 10 PPS ROTARY, IGNORE 20 PPS ROTARY T = E GO TO REORDER ON DTMF, ALLOW 10 PPS ROTARY, IGNORE 20 PPS ROTARY	0

Note: The A, D and E can only be programmed from a terminal.

### 5. 29. Tip Ground Removal Timer

This command selects the time period for the tip ground removal detection. If you are using a terminal you can substitute the letter A for the \* and B for the #.

REGISTER X34	DESCRIPTION	DEFAULT
ENTER 1 FOR LINE 1 + 34T ENTER 2 FOR LINE 2 + 34T ENTER 3 FOR LINE 3 + 34T ENTER 4 FOR LINE 4 + 34T ENTER 5 FOR ALL + 34T	T = 0 FOR 100 MS T = 1 FOR 100 MS T = 2 FOR 180 MS T = 3 FOR 260 MS T = 4 FOR 340 MS T = 5 FOR 420 MS T = 6 FOR 500 MS T = 7 FOR 580 MS T = 8 FOR 660 MS T = 9 FOR 740 MS T = * FOR 820 MS T = # FOR 900 MS T = C FOR 980 MS T = D FOR 1060 MS T = E FOR 1140 MS T = F FOR 1220 MS	6

## 6. PRIMARY SEARCH TABLES

### 6. 1. General

### 6. 2. Primary Search Tables

Primary Search Tables consist of a three digit prefix always starting with an '8' as the first digit followed by two digits that indicate how long the digit string will be. The following digits specify the number for the Controller to monitor for, followed by an action digit telling the Controller what to do once the string has been detected. For example:

803 611#6##  
 ↑    ↑    ↑    ↑  
 MONITOR FOR 611    TERMINATOR  
 LAST DIGIT OF PHONE NUMBER HAS BEEN DIALED  
 PRIMARY TABLE NUMBER IS 8 AND 03 MEANS EXPECT THREE DIGITS

Primary Search Tables are used to provide call control (Toll Control) and routing information. Digits dialed by a caller are screened from 1 to 15 digits, depending on the Primary Search Table you select. They can be subject to an action (as described in Figure 2.2 ). The Controller provides 30 Search Tables - 15 PRIMARY and 15 ALTERNATE. These Tables are numbered 801 - 815 for PRIMARY and 821 to 835 for ALTERNATE. If you require ALTERNATE Search Tables consult MANUAL 4.

There is a SEARCH TABLE form in APPENDIX 2 that will help you to record the digits you enter in each Primary Search Table.

### 6. 3. Warning

When programming Search Tables, care should be taken to not affect calls that are dialed for emergency, e.g. 911 calls. After programming a Controller, check that the operation of emergency dialing has not been adversely affected.

### 6. 4. Digits In A Table

When selecting a Primary Search Table you must enter enough digits to fill the Search Template in the Primary Search Table you have selected. For example, if you select Primary Search Table 815, you must enter 15 digits to fill the Search Template. Consult the following table as to the number of digits you must enter in each Primary Search Table.

## 6. PRIMARY SEARCH TABLES

<p><b>PRIMARY SEARCH TABLE</b></p> <p>801 802 803 804 805 806 807 808 809 810 811 812 813 814 815</p>	<p><b>YOU MUST ENTER THIS NUMBER OF DIGITS IN THE TABLE PLUS AN ACTION DIGIT</b></p> <p>↓</p> <p>1 2 3 4 5 6 7 8 9 10 11 12 13 14 15</p> <p>THE CONTROLLER WILL EXPECT TO SCREEN THE NUMBER OF DIGITS THE TABLE SPECIFIES AND YOU MUST ENTER ENOUGH DIGITS TO FILL THE TABLE. FOR EXAMPLE: 803 MUST HAVE THREE DIGITS TO SCREEN. HENCE 803 WILL USUALLY BE USED TO SCREEN THREE DIGIT CODES LIKE CENTRAL OFFICE CODES AND AREA CODES.</p>
---	---

The actual Search Templates structure of the Primary Search Table is shown in Figure 2.2 . This figure also includes the Action codes that are applicable to the Search Templates.

## 6. PRIMARY SEARCH TABLES

Figure 2.2 Search Table Format and Action Codes

815	NNNNNNNNNNNNNNNNNN	A	##
REGISTER NUMBER	DIGITS YOU EXPECT THE CALLER TO DIAL	ACTION CODE	END OF ENTRY
<p>815 IS THE REGISTER NUMBER. WHERE THE 8 INDICATES A SEARCH TABLE FOLLOWING TWO DIGITS INDICATE THE NUMBER OF DIGITS TO BE SCREENED, IN THIS CASE THE CONTROLLER SCREENS 15 DIGITS.</p> <p>NNN ARE DIGITS YOU WANT THE CONTROLLER TO MATCH TO            N MAY BE ANY DIGIT 0 - 9 AND * WHICH WILL BE MATCHED AGAINST THE DIGITS DIALED BY THE SUBSCRIBER. N CAN ALSO BE: #0 COMPARE AGAINST A USER DIALED #            #1 COMPARE AGAINST A USER DIALED 1 OR 0            #4 COMPARE AGAINST ANY USER DIALED DIGIT 2 - 9            #9 COMPARE AGAINST ANY USER DIALED DIGIT</p> <p>A REPRESENTS THE ACTION DIGITS INSTRUCTING THE ACTION TO BE TAKEN WHEN A MATCH OR ENOUGH DIGTS HAS OCCURED. FURTHER INFORMATION SEE BELOW</p> <p>## INDICATES THE END OF THE ENTRY</p>			
A ACTION CODE DIGITS			
CODE	DESCRIPTION		
0	PREFER ROUTE #0	TO 'PREFER' A ROUTE, MEANS THAT IT WILL DIAL THE	
1	PREFER ROUTE #1	DIAL OUT PATTERN 6R5 ON THE PREFERRED ROUTE.	
2	PREFER ROUTE #2	THE ROUTE SELECTED COULD BE CHANGED LATER ON	
3	PREFER ROUTE #3	IN THE DIALING SEQUENCE, AS MORE DIGITS ARE	
		RECEIVED	
4	FORCE ROUTE #0	THESE CODES WILL FORCE THE CALL ONTO	
5	FORCE ROUTE #1	THE ROUTE SPECIFIED. ONCE A ROUTE IS	
6	FORCE ROUTE #2	FORCED, NO CHANGE OF ROUTES MAY OCCUR	
7	FORCE ROUTE #3		
8	SELECT ROUTE #0	THESE WILL NOT DIAL OUT THE 'SELECT'	
9	SELECT ROUTE #1	DIGITS AND WILL START THE COMPARISONS	
*	SELECT ROUTE #2	OVER AGAIN FROM THE FIRST DIGIT	
#0	SELECT ROUTE #3	FOLLOWING THE 'SELECT' DIGITS	
#1	DENY		
#2	SPEED CALL - ACCESS 7NN ENTRY		
#3	DIAL WHAT HAS BEEN ENTERED AND CUT THROUGH(NO ROUTING)		
#4	PROGRAMMING SECURITY CODE		
#5	ABSORB WHAT HAS BEEN ENTERED AND CUT THROUGH(BY-PASS CONTROLLER)		
#6	LAST DIGIT OF THE PHONE NUMBER HAS BEEN DIALED. FURTHER DIGITS DIALED ARE ACCOUNT CODES, UNLESS R54T = 1 IF ACCOUNT CODES ARE ENABLED; OTHERWISE FURTHER DIGITS ARE IGNORED. DIALING INFORMATION MUST HAVE BEEN SCREENED PRIOR TO ENCOUNTERING A SEARCH TABLE WITH THIS CODE TO PROVIDE A ROUTE ON WHICH TO DIAL		
#7	DO-NOTHING(WAIT FOR MORE DIGITS)		
#8	PREFER DEFAULT ROUTE SPECIFIED IN X24T		
#9	WHEN ENTERED AS A PROGRAMMING ACTION THE ENTRY IS REMOVED (I.E. 803#00 * #9) REMOVES THE PROGRAMMING CODE # 0*		
#C †	SUBSCRIBER SIDE ONLY, LIMITED ACCESS SPEED CALL PROGRAMMING CODE. THIS PERMITS A USER TO ENTER SPEED CALL NUMBERS IN THE 7NN08MM...MM## FORMAT., BY JUST DIALING THE NNMMM...MM DIGITS BY DIALING THE SPEED CALL LOCATION NUMBER AND THE NUMBERS		
##	END OF THIS ENTRY, BUT YOU WILL REMAIN IN PROGRAMMING		

† The digit C can only be entered from a terminal. The # is used as a shift character where #0, #1, #2, etc. would be considered as one digit.



## 6. PRIMARY SEARCH TABLES

### 6. 5. Default Data

The following outlines the default data that is loaded into each Primary Search Table (as a Search Template) and a brief explanation of each piece of data.

### 6. 6. Search Tables 801

Note 1		Note 2		Note 3	
1	#7	*	#7	#9	0

Note 1: If the first digit dialed by the user is a 1 the Controller will do nothing.

Note 2: If the first digit dialed by the user is a \* the Controller will do nothing.

Note 3: If the first digit dialed by the user is not a 1 or \* the Controller will prefer route 0.

### 6. 7. Search Tables 803

Note 1				Note 2				Note 3				Note 4				Note 5				Note 6			
1	1	9	#C	9	1	1	#6	*	#9	#9	#2	#0	0	*	#4	#0	*	*	#*	#0	#0	#0	#C

Note 1: Alternate end-user speed dial programming access code, used in a situation where the Controller is behind a device that will not pass ### (see Note 6).

Note 2: If the digits dialed by the user are 911 the Controller will stop searching, dial 911 and cut-through.

Note 3: A \* + two more digits specify a speed call number to be dialed.

Note 4: This specifies the Programming Access Security Code as # 0 \*.

Note 5: Specifies the PAV List Maintenance Access Security Code as # \* \*.

Note 6: Specifies the end-user as speed dial programming access code ###.

### 6. 8. Search Tables 804

Note 1				Note 2				Note 3				Note 4				Note 5								
1	4	1	1	#3	1	5	5	5	0	1	8	0	0	0	1	#4	#9	#9	1	#9	#0	0	*	#4

Note 1: Dial and cut-through after 1411.

Note 2: Prefer to place 1555 calls on Route 0.

Note 3: Prefer to place 1800 calls on Route 0.

Note 4: Prefer to place 1NXX calls on Route 1.

Note 5: Alternate program access code (any digit plus #0\*).

## 6. PRIMARY SEARCH TABLES

### 6. 9. Search Tables 807

Note 1								Note 2							
1	#4	#1	#9	5	5	5	0	#4	#4	#9	#9	#9	#9	#9	#6

Note 1: Place 1+N(0 or 1)X-555-XXXX (XXXX not in screen) calls on route 0.

Note 2: Stop searching after receipt of NNX-XXXX (local call).

### 6. 10. Search Tables 808

Note 1								
#1	#4	#4	#9	#9	#9	#9	#9	#6

Note 1: Stop searching after receipt of (0 or 1) NNX-XXXX (long distance inside the area code).

### 6. 11. Search Tables 810

Note 1										
#4	#1	#9	#9	#9	#9	#9	#9	#9	#9	#6

Note 1: Stop searching after receipt of N (0 or 1) X-XXX-XXXX (long distance outside the area code).

### 6. 12. Search Tables 811

Note 1											
#1	#4	#1	#9	#9	#9	#9	#9	#9	#9	#9	#6

Note 1: Stop searching after receipt of 0 or 1 +N (0 or 1) X -XXX-XXXX (long distance outside the area code).

### 6. 13. Special Note

To enable OCC dialing, 621 (OCC access code), and 622 (authorization code) values must be programmed. The 601 (area code) should be programmed.

### 6. 14. Warning

When programming Dial Plan/Search Templates, care should be taken to not affect calls that are dialed for emergency, e.g. 911 calls. After programming a Controller, check that the operation of emergency dialing has not been adversely affected.

## 7. COMMON OPTION DATA

Common Option Data refers to data that is common to all aspects of the Controller. Each entry must be terminated with a "##".

### 7. 1. User Area Code

You can define the user area code and it can be output automatically for calls in that area code:

REGISTER 601	DESCRIPTION	DEFAULT
ENTER 601 XXX	THIS AREA CODE IS INSERTED INTO THE DIGITS BEING DIALED OUT WHENEVER THE DESTINATION NUMBER FORMAT (R50T) CALLS FOR THE ADDITION OF THE AREA CODE FOR THAT SPECIFIED ROUTE.	000

### 7. 2. Machine Identifier

Every Controller may be assigned a unique ID. This is especially useful when using chaining or RS-232 multiplexer, as it keeps the machines identified in their CDR outputs (see also A1. 2 ).

REGISTER 602	DESCRIPTION	DEFAULT
ENTER 602 XXX	THIS ID MUST BE ENTERED AS ASCII AND CAN'T BE MORE THAN 15 CHARS., BUT ONLY THE FIRST THREE CHARS. APPEAR ON THE CDR. THIS MUST BE ENTERED IN ASCII HEX. SEE APPENDIX 1.	43484E (CHN)

**Note:** If you are using a PAV Controller (non-chaining) the default will be 504156 (PAV).

### 7. 3. Auto-Answer Security Code

You can enter a security code that must be dialed by an incoming caller to program the Controller. The Controller will auto-answer the incoming call and the security code must be entered at that time (see 5. 22. , 5. 23. and 5. 24. on page 2.25). To enter a code:

REGISTER 603	DESCRIPTION	DEFAULT
ENTER 603 XX	WHERE XX REPRESENTS THE DIGITS TO BE DIALED TO ENTER PROGRAMMING MODE WHEN THE CONTROLLER AUTO-ANSWERS. (MAXIMUM 33 DIGITS)	# 0 *

### 7. 4. Terminal Program Security Code

You can and should enter a unique security code for terminal programming access to the Controller. This can be done by:

REGISTER 604	DESCRIPTION	DEFAULT
ENTER 604 XX	WHERE XX REPRESENTS THE ASCII CODE EQUIVALENT ENTERED FROM A TERMINAL TO ENTER PROGRAMMING MODE. THIS CODE MUST BE ENTERED IN ASCII HEX (MAXIMUM 15 CHARS.) SEE APPENDIX 1.	0D (<CR>)

## 8. ROUTE PARAMETER PROGRAMMING

### 8. 1. General

Routing allows you to specify a route. A route will specify a common carrier (based on the digits dialed), for a call to be routed. Either a complete number, or a digit stream can be acted on.

### 8. 2. Primary And Alternate Routes

Route numbering starts at 0 and ends at 7. In the REGISTERS that follow R = 1 through 8 for Routes 0 to 7 respectively.

You can select either a Primary or Alternate Route for each trunk as outlined by the X24 parameter (see page 2.24).

### 8. 3. Primary And Alternate Destination Number Format

You can specify the number of digits and the format which will be dialed out by the Controller when it executes the "dialed destination number" command in the 6R5 Access Control Sequence. This can be done for either PRIMARY, or ALTERNATE routes by:









REGISTER R50	DESCRIPTION	DEFAULT
<b>PRIMARY</b>	T = THE DESTINATION NUMBER FORMAT	ROUTE
<i>ENTER 1 FOR</i> ROUTE 0 + 50T	T = 0 ANY NUMBER OF DIGITS	0 IS 0
<i>ENTER 2 FOR</i> ROUTE 1 + 50T	T = 1 FOR 10 DIGITS (ADDS USER AREA CODE ON SEVEN DIGITS)	1 IS 1
<i>ENTER 3 FOR</i> ROUTE 2 + 50T	T = 2 FOR 1 + 10 DIGITS (ADDS USER AREA CODE, IF 7 DIGITS DIALED)	2 IS 1
<i>ENTER 4 FOR</i> ROUTE 3 + 50T	T = 4 FOR 1 + 10 DIGITS OR 1 + 7 DIGITS	3 IS 1
<i>ENTER 5 FOR</i> ALL + 50T	T = 8 FOR 10 OR 7 DIGITS	









REGISTER R70	DESCRIPTION	DEFAULT
<b>ALTERNATE</b>	T = THE DESTINATION NUMBER FORMAT	ROUTE
<i>ENTER 1 FOR</i> ROUTE 4 + 70T	T = 0 ANY NUMBER OF DIGITS	4 IS 0
<i>ENTER 2 FOR</i> ROUTE 5 + 70T	T = 1 FOR 10 DIGITS (ADDS USER AREA CODE ON SEVEN DIGITS)	5 IS 1
<i>ENTER 3 FOR</i> ROUTE 6 + 70T	T = 2 FOR 1 + 10 DIGITS (ADDS USER AREA CODE, IF 7 DIGITS DIALED)	6 IS 1
<i>ENTER 4 FOR</i> ROUTE 7 + 70T	T = 4 FOR 1 + 10 DIGITS OR 1 + 7 DIGITS	7 IS 1
<i>ENTER 5 FOR</i> ALL + 70T	T = 8 FOR 10 OR 7 DIGITS	

## 8. ROUTE PARAMETER PROGRAMMING

### 8. 4. Route Progress Tones

You can specify tones to be supplied to a caller, that keep the caller informed as to the progress of a call (being routed). The tones are 400 ms long with a 400 ms space of silence in between by default ( 015 see page 2.17 for information to change these tones to 100 ms long with a 100 ms space of silence in between). These tones are heard by the caller before the Controller cuts-through to the C.O.. This can be done for either PRIMARY, or ALTERNATE routes by:

REGISTER R51	DESCRIPTION	DEFAULT
<b>PRIMARY</b>	WHERE T IS:	
<i>ENTER 1 FOR</i> ROUTE 0 + 51T	0 = NONE	ROUTE
<i>ENTER 2 FOR</i> ROUTE 1 + 51T	1 = 	0 IS 0
<i>ENTER 3 FOR</i> ROUTE 2 + 51T	2 = 	1 IS 9
<i>ENTER 4 FOR</i> ROUTE 3 + 51T	3 = 	2 IS 9
<i>ENTER 5 FOR</i> ALL + 51T	4 = 	3 IS 9
	5 = 	
	6 = 	
	7 = 	
	8 = 	

REGISTER R71	DESCRIPTION	DEFAULT
<b>ALTERNATE</b>	WHERE T IS:	
<i>ENTER 1 FOR</i> ROUTE 4 + 71T	0 = NONE	0
<i>ENTER 2 FOR</i> ROUTE 5 + 71T	1 = 	
<i>ENTER 3 FOR</i> ROUTE 6 + 71T	2 = 	
<i>ENTER 4 FOR</i> ROUTE 7 + 71T	3 = 	
<i>ENTER 5 FOR</i> ALL + 71T	4 = 	
	5 = 	
	6 = 	
	7 = 	
	8 = 	

## 8. ROUTE PARAMETER PROGRAMMING

### 8. 5. Number of Account Code Digits

You can specify the number of account code digits you expect the caller to dial before accessing each route. This can be done for either PRIMARY, or ALTERNATE routes by:

REGISTER R52	DESCRIPTION	DEFAULT
<b>PRIMARY</b> <i>ENTER 1 FOR</i> ROUTE 0 + 52T <i>ENTER 2 FOR</i> ROUTE 1 + 52T <i>ENTER 3 FOR</i> ROUTE 2 + 52T <i>ENTER 4 FOR</i> ROUTE 3 + 52T <i>ENTER 5 FOR</i> ALL + 52T	T = THE NUMBER OF ACCOUNT DIGITS, WHERE T = 1 TO 9	4

REGISTER R72	DESCRIPTION	DEFAULT
<b>ALTERNATE</b> <i>ENTER 1 FOR</i> ROUTE 4 + 72T <i>ENTER 2 FOR</i> ROUTE 5 + 72T <i>ENTER 3 FOR</i> ROUTE 6 + 72T <i>ENTER 4 FOR</i> ROUTE 7 + 72T <i>ENTER 5 FOR</i> ALL + 72T	T = THE NUMBER OF ACCOUNT DIGITS, WHERE T = 1 TO 9	4

### 8. 6. Account Code Entry Inter-Digit Timer

You can specify the time within which you expect the caller to enter each digit of an account code when accessing each route. If this timer expires and R54/R74 is set for flexible Account Codes, the Account Code is then considered complete. If this timer expires and R54/R74 is set for fixed length Account Codes, and if the proper number of digits was not dialed for the Account Code, re-order tone is supplied to the user. This can be done for either PRIMARY, or ALTERNATE routes by:

REGISTER R53	DESCRIPTION	DEFAULT
<b>PRIMARY</b> <i>ENTER 1 FOR</i> ROUTE 0 + 53T <i>ENTER 2 FOR</i> ROUTE 1 + 53T <i>ENTER 3 FOR</i> ROUTE 2 + 53T <i>ENTER 4 FOR</i> ROUTE 3 + 53T <i>ENTER 5 FOR</i> ALL + 53T	T = 0 FOR NO TIMEOUT T = 1 FOR 2 S                    T = 6 FOR 12 S T = 2 FOR 4 S                    T = 7 FOR 14 S T = 3 FOR 6 S                    T = 8 FOR 16 S T = 4 FOR 8 S                    T = 9 FOR 18 S T = 5 FOR 10 S                  T = * FOR 20 S T = # FOR 22 S	3

REGISTER R73	DESCRIPTION	DEFAULT
<b>ALTERNATE</b> <i>ENTER 1 FOR</i> ROUTE 4 + 73T <i>ENTER 2 FOR</i> ROUTE 5 + 73T <i>ENTER 3 FOR</i> ROUTE 6 + 73T <i>ENTER 4 FOR</i> ROUTE 7 + 73T <i>ENTER 5 FOR</i> ALL + 73T	T = 0 FOR NO TIMEOUT T = 1 FOR 2 S                    T = 6 FOR 12 S T = 2 FOR 4 S                    T = 7 FOR 14 S T = 3 FOR 6 S                    T = 8 FOR 16 S T = 4 FOR 8 S                    T = 9 FOR 18 S T = 5 FOR 10 S                  T = * FOR 20 S T = # FOR 22 S	3

# 8. ROUTE PARAMETER PROGRAMMING

## 8. 7. Account Code Type

You can specify the type of account code you expect on each route. The following programming applies only if you set 011 to 0110 (see page 2.12). If a redial situation occurs due to a failure (as set out in the Access Control Sequence), as defined on page 2.38. The action to be taken is defined by R58 (see page 2.38). This can be done for either PRIMARY, or ALTERNATE routes by:

REGISTER R54		REGISTER R74		DEFAULT
<b>PRIMARY</b>		<b>ALTERNATE</b>		1
<i>ENTER 1 FOR ROUTE 0 + 54T</i>		<i>ENTER 1 FOR ROUTE 0 + 74T</i>		
<i>ENTER 2 FOR ROUTE 1 + 54T</i>		<i>ENTER 2 FOR ROUTE 1 + 74T</i>		
<i>ENTER 3 FOR ROUTE 2 + 54T</i>		<i>ENTER 3 FOR ROUTE 2 + 74T</i>		
<i>ENTER 4 FOR ROUTE 3 + 54T</i>		<i>ENTER 4 FOR ROUTE 3 + 74T</i>		
<i>ENTER 5 FOR ALL + 54T</i>		<i>ENTER 5 FOR ALL + 74T</i>		
DESCRIPTION				
INITIAL ACCOUNT CODE FOR CALL		NEW ACCOUNT CODE ON REDIAL		
T = 0	FOR FLEXIBLE WAIT FOR TIMEOUT THEN CONTINUE	T = 6.		
T = 1	NO ACCOUNT CODE	T = 7		
T = 2	FIXED LENGTH, WAIT FOR TIMEOUT THEN RE-ORDER	T = 8		
T = 3	FIXED LENGTH, WAIT FOR TIMEOUT THEN ENTER DUMMY ACCOUNT CODE	T = 9		
T = 4	FIXED LENGTH OF 10 + THE NUMBER OF DIGITS SPECIFIED BY R52/R72 FOR T = 2 AND 3 ABOVE. WAIT FOR TIMEOUT THEN RE-ORDER	T = *		
T = 5	FIXED LENGTH OF 10 + THE NUMBER OF DIGITS SPECIFIED BY R52/R72 FOR T = 2 AND 3 ABOVE. WAIT FOR TIMEOUT THEN ENTER DUMMY ACCOUNT CODE	T = #		

**Note:** Flexible account codes and dummy account codes are not supported when PAV is enabled.

## 8. ROUTE PARAMETER PROGRAMMING

### 8. 8. Action on Call Failure

You can specify the type you expect due to a call failure (as set out in the Access Control sequence, see 9. 3. ). This can be done for either PRIMARY, or ALTERNATE routes by:

REGISTER R58	DESCRIPTION	DEFAULT
<b>PRIMARY</b>	T = 0 FOR REDIAL ON ROUTE 0	ROUTE 0 IS 4 1 IS 6 2 IS 6 3 IS 6
<i>ENTER 1 FOR ROUTE 0 + 58T</i>	T = 1 FOR REDIAL ON ROUTE 1	
<i>ENTER 2 FOR ROUTE 1 + 58T</i>	T = 2 FOR REDIAL ON ROUTE 2	
<i>ENTER 3 FOR ROUTE 2 + 58T</i>	T = 3 FOR REDIAL ON ROUTE 3	
<i>ENTER 4 FOR ROUTE 3 + 58T</i>	T = 4 FOR REORDER	
<i>ENTER 5 FOR ALL + 58T</i>	T = 5 REDIAL SAME ROUTE ONCE, THEN REORDER	
	T = 6 REDIAL SAME ROUTE TWICE, THEN REORDER	
	T = 7 REDIAL SAME ROUTE THREE TIMES, THEN REORDER	
	T = 8 REDIAL SAME ROUTE AGAIN, THEN ROUTE 0	
	T = 9 REDIAL SAME ROUTE TWICE, THEN ROUTE 0	
	T = * REDIAL SAME ROUTE THREE TIMES THEN ROUTE 0	









REGISTER R78	DESCRIPTION	DEFAULT
<b>ALTERNATE</b>	T = 0 FOR REDIAL ON ROUTE 0	ROUTE 0 IS 4 1 IS 6 2 IS 6 3 IS 6
<i>ENTER 1 FOR ROUTE 0 + 78T</i>	T = 1 FOR REDIAL ON ROUTE 1	
<i>ENTER 2 FOR ROUTE 1 + 78T</i>	T = 2 FOR REDIAL ON ROUTE 2	
<i>ENTER 3 FOR ROUTE 2 + 78T</i>	T = 3 FOR REDIAL ON ROUTE 3	
<i>ENTER 4 FOR ROUTE 3 + 78T</i>	T = 4 FOR REORDER	
<i>ENTER 5 FOR ALL + 78T</i>	T = 5 REDIAL SAME ROUTE ONCE, THEN REORDER	
	T = 6 REDIAL SAME ROUTE TWICE, THEN REORDER	
	T = 7 REDIAL SAME ROUTE THREE TIMES, THEN REORDER	
	T = 8 REDIAL SAME ROUTE AGAIN, THEN ROUTE 0	
	T = 9 REDIAL SAME ROUTE TWICE, THEN ROUTE 0	
	T = * REDIAL SAME ROUTE THREE TIMES THEN ROUTE 0	











## 8. ROUTE PARAMETER PROGRAMMING

### 8. 9. Account Code Warning Tones

You can specify warning tones to be supplied to a caller that start after the expiration of the R53 (timer) for PRIMARY Routes, or R73 (timer) for ALTERNATE Routes. The tones are 400 ms long with a 400 ms space of silence in between. If the caller fails to enter a digit before the specified number of tones expires, the user will receive re-order tone (of 200 ms ON, 200 ms OFF), and will have to restart the call. This can be done by:

REGISTER R59	DESCRIPTION	DEFAULT
<b>PRIMARY</b>	WHERE T IS:	0
<i>ENTER 1 FOR ROUTE 0 + 59T</i>	0 = NONE	
<i>ENTER 2 FOR ROUTE 1 + 59T</i>	1 = 	
<i>ENTER 3 FOR ROUTE 2 + 59T</i>	2 = 	
<i>ENTER 4 FOR ROUTE 3 + 59T</i>	3 = 	
<i>ENTER 5 FOR ALL + 59T</i>	4 = 	
	5 = 	
	6 = 	
	7 = 	
	8 = 	

REGISTER R79	DESCRIPTION	DEFAULT
<b>ALTERNATE</b>	WHERE T IS:	0
<i>ENTER 1 FOR ROUTE 0 + 79T</i>	0 = NONE	
<i>ENTER 2 FOR ROUTE 1 + 79T</i>	1 = 	
<i>ENTER 3 FOR ROUTE 2 + 79T</i>	2 = 	
<i>ENTER 4 FOR ROUTE 3 + 79T</i>	3 = 	
<i>ENTER 5 FOR ALL + 79T</i>	4 = 	
	5 = 	
	6 = 	
	7 = 	
	8 = 	

## 8. ROUTE PARAMETER PROGRAMMING

### 8. 10. Account Code Confirmation And Reroute Tones

You can specify a reroute or confirmation tone to be supplied to a caller after a successfully entered Account Code, or on a failed route/reroute sequence. The tones are 200 ms in duration.

This can be done for PRIMARY routes by:

REGISTER R60	DESCRIPTION	DEFAULT
<b>PRIMARY</b> ENTER 1 FOR ROUTE 0 + 60T ENTER 2 FOR ROUTE 1 + 60T ENTER 3 FOR ROUTE 2 + 60T ENTER 4 FOR ROUTE 3 + 60T ENTER 5 FOR ALL + 60T	WHERE T IS: 0 FOR ACCOUNT CODE OFF AND REROUTE TONE OFF 1 FOR ACCOUNT CODE TONE ON AND REROUTE TONE OFF 2 FOR ACCOUNT CODE TONE OFF AND REROUTE TONE ON 3 FOR ACCOUNT CODE TONE ON AND REROUTE TONE ON	0

This can be done for ALTERNATE routes by:

REGISTER R80	DESCRIPTION	DEFAULT
<b>ALTERNATE</b> ENTER 1 FOR ROUTE 4 + 80T ENTER 2 FOR ROUTE 5 + 80T ENTER 3 FOR ROUTE 6 + 80T ENTER 4 FOR ROUTE 7 + 80T ENTER 5 FOR ALL + 80T	WHERE T IS: 0 FOR ACCOUNT CODE OFF AND REROUTE TONE OFF 1 FOR ACCOUNT CODE TONE ON AND REROUTE TONE OFF 2 FOR ACCOUNT CODE TONE OFF AND REROUTE TONE ON 3 FOR ACCOUNT CODE TONE ON AND REROUTE TONE ON	0

## 9. CALL CONTROL DATA ENTRY

### 9. 1. General

Call Control Data defines such system wide information as the Controller's access number and authorization code. Information entered here provides site specific information and each entry must be terminated with a ##.

### 9. 2. Route Strings

The following TABLE explains the Route relationship to 6R0, 6R1, 6R2, 6R3, 6R4 and 6R5. Note: if you program X24 (see page 2.24) to be: X240, X241, X242, X243 the trunk will access Primary Routes 0 - 3. If X24 is set to X244 or greater, the trunk will access Alternate Routes 4 - 7.

<u>6R0, 6R1, 6R2, 6R3, 6R4, 6R5</u>	
↓	<b>PRIMARY ROUTES</b>
	R = 1 WHEN USING ROUTE 0(ROC) LOCAL
	R = 2 WHEN USING ROUTE 1(VAC 1) LONG DISTANCE
	R = 3 WHEN USING ROUTE 2(VAC 2) LONG DISTANCE
	R = 4 WHEN USING ROUTE 3(VAC 3) LONG DISTANCE
	<b>ALTERNATE ROUTES</b>
	R = 5 WHEN USING ROUTE 4(ROC) LOCAL
	R = 6 WHEN USING ROUTE 5(VAC 1) LONG DISTANCE
	R = 7 WHEN USING ROUTE 6(VAC 2) LONG DISTANCE
	R = 8 WHEN USING ROUTE 7(VAC 3) LONG DISTANCE
	VAC Value Added Carrier ROC Regional Operating Company

### 9. 3. Access Control Sequences (6R5)

Access Control Sequences instruct the Controller on how to access a particular carrier telephone network.

Entries in this part control how the Controller will access the telephone network. Calls are routed here, after a match in the Search Tables. Each entry (6R5) can be any sequence of commands and there are a maximum of 33 characters per entry.

## 9. CALL CONTROL DATA ENTRY

REGISTER	DESCRIPTION	DEFAULT
6R5  WHERE R EQUALS 1-8 FOR ROUTES 0 - 7 RESPECTIVELY SEE Note 2  <i>62 ✓ access</i> <i>622 auth. code</i> <i>27622</i> <i>622</i> <i>1-8</i>	1,0 DIAL THAT DIGIT  #0 * DIAL A * #00 DIAL A # #01 IF THE PREVIOUS COMMAND WAS A 2 (SEE 2 BELOW) A # WILL BE DIALED, UNLESS THE LAST DIGIT DIALED OUT WAS A # THEN NO ACTION WILL BE TAKEN #02 WAIT FOR ACCOUNT CODE (IS NOT OUTPUT)  2 DIAL THE DESTINATION NUMBER 3 DIAL THE ROUTE OCC ACCESS NUMBER (6R1) 4 DIAL THE AUTHORIZATION CODE (6R2) 5 DIAL THE ACCOUNT CODE (6R3 UNLESS USER DIALED) 6 DIAL THE TRUNK NUMBER 7 CUT THROUGH. DIALING FINISHED 8 CHANGE TO DTMF DIAL-OUT 9 DIAL THE ROUTE CENTREX ACCESS NUMBER Note 3,  #2AB PAUSE. CONTINUE AFTER PAUSE IF A=5. SEE Note 1 #3AB 570-680 HZ DETECTOR SEE Note 1 #4AB 440 HZ DETECTOR SEE Note 1 #5AB 480 HZ RINGBACK DETECTOR SEE Note 1 #6AB 400 HZ DETECTOR SEE Note 1 #7AB 360-620 HZ ENERGY DETECTOR SEE Note 1 #8AB PRECISE DIAL TONE DETECTOR SEE Note 1 #DAB DTMF DETECTOR Note 1,4  ## END OF THIS CONTROL SEQUENCE PROGRAMMING	†
† 6R5 DEFAULTS: ENTRIES 615 & 655 TO #85327 and 625, 635, 645, 665, 675 AND 685 DEFAULTS: #8533#62*427  Note 1 Refer to Table on next page Note 2 The 6R5 Access Control Sequences are called as a result of a dialed digit match within the Search Tables. At some point in the Search Tables, a route is usually chosen. That route will be one of Routes 0 through 7, which pass control to the appropriate 6R5 Access Control. Note 3 Can be used for PBX outgoing access code (e.g. 9) Note 4 Can only be entered from a terminal		

### Example


#85327 is the default on Route 0 (615) this string translates to:

- #8 Wait for a minimum of precise dial tone for up to 6 seconds
- 53 Is from the A and B dial tone timers (next page) where 5 is the A value - wait for the minimum time for dial tone and 3 is the B value - 6 seconds
- 2 Dial destination number
- 7 Cut-through

## 9. CALL CONTROL DATA ENTRY

### 9. 4. A and B Dial Tone Timers

The Controller expects a certain minimum duration of dial tone to occur within a specified time, before attempting to dial. This is specified by A and B timers as shown below.



If the duration of dial tone does not occur (or does not occur within the time specified in B) the Controller will redial if the "A" value is 0-4, OR it can assume the dial tone is present, but can not be detected and will continue to dial out if the "A" value is 5-9.

### A CODES - MINIMUM DIAL TONE DURATION

A	MINIMUM TONE DURATION	A	MINIMUM TONE DURATION
0	MIN. REDIAL PER R58 OR R78	5	MIN. THEN CONTINUE TO DIALOUT
1	200 MS REDIAL PER R58 OR R78	6	200 MS THEN CONTINUE TO DIALOUT
2	400 MS REDIAL PER R58 OR R78	7	400 MS THEN CONTINUE TO DIALOUT
3	1.0 SEC REDIAL PER R58 OR R78	8	1.0 SEC THEN CONTINUE TO DIALOUT
4	2.55 SEC REDIAL PER R58 OR R78	9	2.55 SEC THEN CONTINUE TO DIALOUT

### B CODES - TIME DIAL TONE MUST BE DETECTED IN

B	SEARCH TIME	B	SEARCH TIME
0	0 SECONDS	5	10 SECONDS
1	2 SECONDS	6	12 SECONDS
2	4 SECONDS	7	14 SECONDS
3	6 SECONDS	8	16 SECONDS
4	8 SECONDS	9	18 SECONDS
		*	20 SECONDS

## 9. CALL CONTROL DATA ENTRY

### 9. 5. Name Of Route

You can program a name for a route from a terminal that will appear on CDR records. This provides rapid identification of the carrier used as a word represents the name of the carrier. The default is 444444 for routes 0 and 4 (typically DDD on 610, 650) and 524F55544544 for routes 1, 2, 3, 5, 6 and 7 (ROUTED calls on value added carriers, 620, 630, 640, 660, 670, 680). The R (1 through 8) specifies the route number and all entries must be terminated with a ##.

REGISTER 6R0	DESCRIPTION	DEFAULT
6R0	THIS IS THE NAME OF ROUTE IN THE CDR AND CAN NOT EXCEED 16 CHARS. (ONLY 6 WILL BE RPINTED) MUST BE ENTERED IN ASCII. SEE APPENDIX 1.	444444 524F555 44544

### 9. 6. Access Number For OCC Telephone Network

When programmed this access number will be output on calls routed as an OCC connection requiring an access number to be dialed out before allowing access. The default value for all Routes is blank. This entry can be a maximum of 33 digits. This can be done by:

REGISTER 6R1	DESCRIPTION	DEFAULT
6R1 621	WHERE R IS THE ROUTE NUMBER	BLANK

### 9. 7. Authorization Number

You can enter an authorization number that can be output automatically, to access an OCC, or value added carrier. The default value for all Routes is blank. This entry can be a maximum of 33 digits. This can be done by:

REGISTER 6R2	DESCRIPTION	DEFAULT
6R2 622	WHERE R IS THE ROUTE NUMBER	BLANK

## 9. CALL CONTROL DATA ENTRY

### 9. 8. Dummy Account Code

You can program a Dummy Account Code that will act as an account code, if a complete Account Code is not dialed by the user. This entry can be a maximum of 33 digits. This can be done by:

REGISTER 6R3	DESCRIPTION	DEFAULT
6R3	WHERE R IS THE ROUTE NUMBER	BLANK

### 9. 9. Centrex Number

You can program a number to be used as the Centrex Access Code. This entry can be a maximum of 33 digits. This can be done by:

REGISTER 6R4	DESCRIPTION	DEFAULT
6R4	WHERE R IS THE ROUTE NUMBER	9

## 10. POSITIVE ACCOUNT CODE OPTIONS

### 10. 1. Description

The SMART-1 PAV Controller provides most of the functions of the regular Controller. The PAV Controller does not allow the Alternate Search Tables to be used for screening destination numbers, as it is reserved for the Account Codes in the PAV list. In addition, the PAV Controller provides the ability to verify user dialed Account Codes. Other differences from the standard Controller are:

The maximum Verifiable Account Code length is 15 digits as dictated by the Search Tables 821 through 835.

### 10. 2. Specifying the Unit As A Controller Or PAV

If you have not done so, you must specify the Controller as a PAV controller if you wish to use it as a Positive Account Code Verifier. The programming in this part applies only if you set 011 to 0111. This can be done by:

REGISTER 011	DESCRIPTION	DEFAULT
ENTER 011T	T = 0 FOR REGULAR CONTROLLER OPERATION T = 1 FOR PAV CONTROLLER	0

### 10. 3. Number Of Account Codes

The number of Account Codes that can be programmed, depends on the table selected. For example if you select:

Table 823, you can program 3 digit Account Codes in the range 000 to 999 (equal to 1000 Account Codes) or,

Table 827, you can program 7 digit Account Codes in the range 0000000 to 9999999 (equal to 1,000,000 Account Codes).

Of course, the PAV does not have enough memory to program 1,000,000 or more Account Codes, but the PAV does have enough memory to satisfy most situations.

The following table indicates the number of digits that must be entered in each Account Code table.



## 10. POSITIVE ACCOUNT CODE OPTIONS

ACCOUNT CODE TABLE	YOU MUST ENTER THIS NUMBER OF DIGITS IN THE TABLE PLUS AN ACTION DIGIT	
821	1	THE CONTROLLER WILL EXPECT TO SCREEN THE NUMBER OF DIGITS THE TABLE SPECIFIES AND YOU MUST ENTER ENOUGH DIGITS TO FILL THE TABLE. FOR EXAMPLE: 823 MUST HAVE THREE DIGITS TO SCREEN.
822	2	
823	3	
824	4	
825	5	
826	6	
827	7	
828	8	
829	9	
830	10	
831	11	
832	12	
833	13	
834	14	
835	15	

### 10. 4. PAV List Maintenance Code

When you configure the Controller as a PAV Controller an additional default entry is enabled in the Primary Search Tables to allow the use of the PAV List Maintenance Code. The PAV List Maintenance Code is always present (see page 2.31), but is not active unless you set 011 to 0111 (see page 2.46). This code is dialed by a user who maintains the Positive Account Code List.

TABLE	TEMPLATE	ACTION	DESCRIPTION
803	#0 **	# *	DTMF # ** IS THE PAV LIST MAINTENANCE CODE

### 10. 5. Action Digits

When you configure the Controller as a PAV Controller an additional Action Digit is added to the Primary Search Tables (Figure 2.2 ) to allow the use of the PAV List Maintenance Code.

ACTION DIGIT	DESCRIPTION
# *	ACTION CODE DIGIT FOR (PAV) SEARCH TABLE MAINTENANCE

## 10. POSITIVE ACCOUNT CODE OPTIONS

### 10. 6. String Data

When you configure the Controller as a PAV Controller the following Action Digits are available for the Alternate Search Tables only. Each Account Code you enter must have an Action Digit associated with it.

ACTION DIGIT	DESCRIPTION
0	RETURN USER RE-ORDER TONE. DENY CALL
1	VALID ACCOUNT CODE. ALLOW CALL
*	VALID ACCOUNT CODE. ALLOW CALL
#9	DELETE SPECIFIED ACCOUNT CODE

### 10. 7. Programming Positive Account Codes


To program the Controller with the Positive Account Codes accomplish the following steps and write the information in the Positive Account Code Form in APPENDIX 2:


1. Select the users that will have access to the Positive Account Code feature and write their names down under the "Account User's Name".
2. Select unique Account Codes for each of the users and write them down beside the user's name under "Account Code".
3. Select the action digit to be associated with the user's Account Code. Write down the Action Code beside the user's Account Code.
4. Use a DTMF phone that can access the PAV Controller and go off-hook.
5. Dial the PAV Maintenance Access Code. The default Access Code is # \* \*.

**Note:** The procedure outlined in step 5 needs only be repeated once for each programming session. It does not have to be repeated for each Account Code being entered into the PAV Controller's memory.

6. Start by entering the Account Code for the first user. Next the Action Code for the Account Code, and a terminating "##".

For example if the the first Account Code is 386261 the dialing sequence would be:

Dial # \* \* and a single  will be heard.

Dial 386261 \* # # and  will be heard.

**Note:** The single beep indicates that you have successfully entered the Account Code Maintenance Mode, and the double beep indicates that the Account Code has successfully been entered.

7. Enter all of the Account Codes from the worksheet. Ensure that the double beep is returned each time an Account Code is entered.

## 10. POSITIVE ACCOUNT CODE OPTIONS

**Note:** Once one line that is connected to the Controller has been programmed, all lines connected to that particular Controller are programmed with these same Account Codes. If there are multiple Controllers in an installation, each Controller must be programmed separately to use the Account Codes from all lines that are connected to the them.

8. After entering all the Account Codes from the worksheet, simply hang up the phone. This action terminates the programming session, and the Controller is now programmed with the Account Codes.



# APPENDIX 1- SYSTEM INFORMATION

## LEGAL CONTROLLER INPUTS

FROM STANDARD DTMF PHONE	FROM TERMINAL	CONTROLLER INTERPRETATION
0 through 9	0 through 9	0 through 9
#, *	#, *	#, *
-	A or a	*
-	B or b	#
-	BB or bb	##
-	C or C	C
-	D or d	D
-	E or e	E
-	F or f	F it is within a string. SPACE if it is the last character of string.
-	FF or ff	##
-	Period	#
-	Comma	#
-	Hyphen	#
-	LF	#
-	CR	#
-	Space	#
999	999	Exit PROGRAM MODE
-	X or x	Exit PROGRAM MODE
Go ON-HOOK		Exit PROGRAM MODE

# APPENDIX 1- SYSTEM INFORMATION

## ASCII CODES

CHAR.	HEX CODE	CHAR.	HEX CODE	CHAR.	HEX CODE	CHAR.	HEX CODE
NUL	00	SP	20	@	40	'	60
SOH	01	!	21	A	41	a	61
STX	02	”	22	B	42	b	62
ETX	03	#	23	C	43	c	63
EOT	04	\$	24	D	44	d	64
ENQ	05	%	25	E	45	e	65
ACK	06	&	26	F	46	f	66
BEL	07	'	27	G	47	g	67
BS	08	(	28	H	48	h	68
HT	09	)	29	I	49	i	69
LF	0A	*	2A	J	4A	j	6A
VT	0B	+	2B	K	4B	k	6B
FF	0C	,	2C	L	4C	l	6C
CR	0D	-	2D	M	4D	m	6D
SO	0E	.	2E	N	4E	n	6E
SI	0F	/	2F	O	4F	o	6F
DLE	10	0	30	P	50	p	70
DC1	11	1	31	Q	51	q	71
DC2	12	2	32	R	52	r	72
DC3	13	3	33	S	53	s	73
DC4	14	4	34	T	54	t	74
NAK	15	5	35	U	55	u	75
SYN	16	6	36	V	56	v	76
ETB	17	7	37	W	57	w	77
CAN	18	8	38	X	58	x	78
EM	19	9	39	Y	59	y	79
SUB	1A	:	3A	Z	5A	z	7A
ESC	1B	;	3B	[	5B	{	7B
FS	1C	<	3C	\	5C		7C
GS	1D	=	3D	]	5D	}	7D
RS	1E	>	3E	^	5E	~	7E
US	1F	?	3F	_	5F	DEL	7F

## **APPENDIX 2 – SITE INFORMATION**

For your convenience APPENDIX 2 consists of the following site forms:

**CONTROLLER SITE FORM**

**SEARCH TABLE FORM**

**SPEED CALL FORM**

**POSITIVE ACCOUNT CODE FORM**

These forms are designed to help you document your customer's site information. When calling for technical assistance you should have these forms available to you. The information contained will aid the technical assistance personnel in resolving difficulties you may encounter.

# APPENDIX 2 - SITE INFORMATION

## CONTROLLER SITE FORM

CUSTOMER NAME: \_\_\_\_\_ DATE: \_\_\_\_\_

REGISTER	DEFAULT	DESCRIPTION	SEE PAGE	SITE INFO
000 T	1	Speed Call Numbers	2.13	_____
001 T	0	Reorder Tone	2.16	_____
005 T	0	Trunks Monitored For CDR	2.16	_____
006 T	4	RS-232 Baud Rate	2.16	_____
007 T	2	Nulls After A Carriage Return	2.16	_____
008 T	0,1†	Print Out Incoming Calls	2.16	_____
009 T	1	Print Format	2.17	_____
010 T	9	Route to Monitor for CDR	2.17	_____
015 T	0	Route Progress Tone Length	2.17	_____
X00 T	2	Type Of Central Office	2.18	_____
X01 T	4	Rotary Dialing Rate	2.18	_____
X02 T	1	DTMF Dialing Rate	2.19	_____
X03 T	6	On-Hook Timing	2.19	_____
X04 T	1	Flash Allowed/Time	2.20	_____
X05 T	5	Time Between Release And Reseizure	2.20	_____
X06 T	3	T = Number Of Ground Start Tries	2.20	_____
X07 T	3	T = Ground Start Timeout In Seconds	2.21	_____
X08 T	3	Off-Hook Digit Refusal Time	2.21	_____
X09 T	4	User Dial Tone	2.21	_____
X11 T	3	Inter-Digit Timeout On Subscriber Side	2.22	_____
X12 T	2	Inter-Digit Timeout On 0+ Calls	2.22	_____
X13 T	2	Inter-Digit Timeout On 01+ Calls	2.22	_____
X14 T	4	Rotary Inter-Digit Pause	2.22	_____
X19 T	1	Beep Options	2.23	_____
X20 T	2	Ringing Sensitivity	2.23	_____
X23 T	9	Activation Of Controller	2.23	_____
X24 T	0	Default Route	2.24	_____
X25 T	9	Centrex Outgoing Digit	2.24	_____
X26 T	0	Centrex Enable Code	2.24	_____
X27 T	0	Auto-Answer Timer In Tens Of Secs	2.25	_____
X28 T	6	Auto-Answer Wait-for-Security-Code	2.25	_____
X29 T	9	Auto-Answer Lockout Timer	2.25	_____
X30 T	3	Off-Hook Recognition Time	2.26	_____
X31 T	3	Tip Ground Application Timer	2.26	_____
X32 T	0	Subscriber Outgoing Digit Recognition	2.26	_____
X33 T	0	Subscriber Incoming Digit Recognition	2.27	_____
X34 T	6	Tip Ground Removal Timer	2.27	_____
R50 T	0,1,1,1	Destination Number Format	2.34	_____
R51 T	0	PAV Route Progress Tones	2.35	_____
R52 T	4	Account Code Number Of Digits	2.36	_____
R53 T	3	Account Code Wait Timer In Seconds	2.36	_____

† In Generic 14 the default is 1. In Generic 40 the default is 0.



# APPENDIX 2 – SITE INFORMATION

## CONTROLLER SITE FORM

REGISTER	DEFAULT	DESCRIPTION	SEE PAGE	SITE INFO
R54 T	1	Account Code Type	2.37	_____
R58 T	4,6,6,6	Action As A Result Of Call Failure	2.38	_____
R59 T	0	Account Code Warning Tones	2.39	_____
R60 T	0	Account Code Confirm/Reroute Tones	2.40	_____
R70 T	0,1,1,1	Destination Number Format	2.34	_____
R71 T	0	PAV Route Progress Tones	2.35	_____
R72 T	4	Account Code Number Of Digits	2.36	_____
R73 T	3	Account Code Wait Timer In Seconds	2.36	_____
R74 T	1	Account Code Type	2.37	_____
R78 T	4,6,6,6	Action As A Result Of Call Failure	2.38	_____
R79 T	0	Account Code Warning Tones	2.39	_____
R80 T	0	Account Code Confirm/Reroute Tones	2.40	_____
601	000	User Area Code	2.33	_____
602	43484E	Machine Identifier	2.33	_____
603	#0*	Auto-Answer Security Code	2.33	_____
604	0D	Terminal Program Security Code	2.33	_____
610, 650	444444	Name Of Route	2.44	_____
620-640, 660-680	524F55544544	Name Of Route	2.44	_____
6R1	Blank	Access Number	2.44	_____
6R2	Blank	Authorization Number	2.44	_____
6R3	Blank	Dummy Account Code	2.45	_____
6R4	9	Centrex Number	2.45	_____
<hr/>				
6R5	Access Control Sequences			_____
615	#85327		2.41	_____
625	#8533#62*427		2.41	_____
635	#8533#62*427		2.41	_____
645	#8533#62*427		2.41	_____
655	#85327		2.41	_____
665	#8533#62*427		2.41	_____
675	#8533#62*427		2.41	_____
685	#8533#62*427		2.41	_____
<hr/>				
700-799	Blank	100 Speed Call	2.13	_____
7000-7999	Blank	1000 Speed Call	2.13	_____
<hr/>				
801-815	Search Tables			_____
801	1#7*#7#90		2.31	_____
803	119#C911#6*#9#9#2#00*#4#0*#*#0#0#0#C		2.31	_____
804	1411#315550180001#4#9#91#9#00*#4		2.31	_____
807	1#4#1#95550#4#4#9#9#9#9#6		2.32	_____
808	#1#4#4#9#9#9#9#6		2.31	_____
810	#4#1#9#9#9#9#9#9#6		2.32	_____
811	#1#4#1#9#9#9#9#9#9#6		2.31	_____

## APPENDIX 2 - SITE INFORMATION

### SEARCH TABLE

815	NNNNNNNNNNNNNNNNNN	A	##
REGISTER NUMBER	DIGITS YOU EXPECT THE CALLER TO DIAL	ACTION CODE	END OF ENTRY
<p>815 IS THE REGISTER NUMBER. WHERE THE 8 INDICATES A SEARCH TABLE FOLLOWING TWO DIGITS INDICATE THE NUMBER OF DIGITS TO BE SCREENED, IN THIS CASE THE CONTROLLER SCREENS 15 DIGITS.</p> <p>NNN ARE DIGITS YOU WANT THE CONTROLLER TO MATCH TO            N MAY BE ANY DIGIT 0 - 9 AND * WHICH WILL BE MATCHED AGAINST THE DIGITS DIALED BY THE SUBSCRIBER. N CAN ALSO BE: #0 COMPARE AGAINST A USER DIALED #            #1 COMPARE AGAINST A USER DIALED 1 OR 0            #4 COMPARE AGAINST ANY USER DIALED DIGIT 2 - 9            #9 COMPARE AGAINST ANY USER DIALED DIGIT</p> <p>A REPRESENTS THE ACTION DIGITS INSTRUCTING THE ACTION TO BE TAKEN WHEN A MATCH OR ENOUGH DIGTS HAS OCCURED. FURTHER INFORMATION SEE BELOW.</p> <p>## INDICATES THE END OF THE ENTRY</p>			
A ACTION CODE DIGITS			
CODE	DESCRIPTION		
0	PREFER ROUTE #0	TO 'PREFER' A ROUTE, MEANS THAT IT WILL DIAL THE DIAL OUT PATTERN 6R5 ON THE PREFERRED ROUTE.	
1	PREFER ROUTE #1	THE ROUTE SELECTED COULD BE CHANGED LATER ON	
2	PREFER ROUTE #2	IN THE DIALING SEQUENCE, AS MORE DIGITS ARE RECEIVED	
3	PREFER ROUTE #3		
4	FORCE ROUTE #0	THESE CODES WILL FORCE THE CALL ONTO	
5	FORCE ROUTE #1	THE ROUTE SPECIFIED. ONCE A ROUTE IS	
6	FORCE ROUTE #2	FORCED, NO CHANGE OF ROUTES MAY OCCUR	
7	FORCE ROUTE #3		
8	SELECT ROUTE #0	THESE WILL NOT DIAL OUT THE 'SELECT'	
9	SELECT ROUTE #1	DIGITS AND WILL START THE COMPARISONS	
*	SELECT ROUTE #2	OVER AGAIN FROM THE FIRST DIGIT	
#0	SELECT ROUTE #3	FOLLOWING THE 'SELECT' DIGITS	
#1	DENY		
#2	SPEED CALL - ACCESS 7NN ENTRY		
#3	DIAL WHAT HAS BEEN ENTERED AND CUT THROUGH(NO ROUTING)		
#4	PROGRAMMING SECURITY CODE		
#5	ABSORB WHAT HAS BEEN ENTERED AND CUT THROUGH(BY-PASS CONTROLLER)		
#6	LAST DIGIT OF THE PHONE NUMBER HAS BEEN DIALED. FURTHER DIGITS DIALED ARE ACCOUNT CODES, UNLESS R54T = 1 IF ACCOUNT CODES ARE ENABLED; OTHERWISE FURTHER DIGITS ARE IGNORED. DIALING INFORMATION MUST HAVE BEEN SCREENED PRIOR TO ENCOUNTERING A SEARCH TABLE WITH THIS CODE TO PROVIDE A ROUTE ON WHICH TO DIAL		
#7	DO NOTHING(WAIT FOR MORE DIGITS)		
#8	PREFER DEFAULT ROUTE SPECIFIED IN X24T		
#9	WHEN ENTERED AS A PROGRAMMING ACTION THE ENTRY IS REMOVED (I.E. 803#00 * #9) REMOVES THE PROGRAMMING CODE # 0 *		
#C †	SUBSCRIBER SIDE ONLY, LIMITED ACCESS SPEED CALL PROGRAMMING CODE. THIS PERMITS A USER TO ENTER SPEED CALL NUMBERS IN THE 7NN08MM...MM## FORMAT., BY JUST DIALING THE NNNMM...MM DIGITS BY DIALING THE SPEED CALL LOCATION NUMBER AND THE NUMBERS		
##	END OF THIS ENTRY, BUT YOU WILL REMAIN IN PROGRAMMING		

† The digit C can only be entered from a terminal. The # is used as a shift character where #0, #1, #2, etc. would be considered as one digit. #\* is the PAV list maintenance code, and is active only when parameter 011 is set to 0111.



## APPENDIX 2 - SITE INFORMATION

### SPEED CALL

#### Setting up a Speed Call Method 1

REGISTER (FORMAT)	DEFINITION																																				
<b>FOR 100 SPEED CALLS</b> 7NNDKMM...MM## OR 7NNDKMM...MM* P..PP##	FORMAT FOR UP TO 100 ENTRIES. NN IS THE SERVICE CODE TO BE DIALED BY THE SUBSCRIBER AND MM...MM IS THE NUMBER TO WHICH THE CODE IS TRANSLATED																																				
<b>FOR 1000 SPEED CALLS</b> 7NNNDKMM...MM## OR 7NNNDKMM...MM* P..PP##	FORMAT FOR UP TO 1000 ENTRIES. NNN IS THE SERVICE CODE TO BE DIALED BY THE SUBSCRIBER AND MM...MM IS THE NUMBER TO WHICH THE CODE IS TRANSLATED																																				
<b>D is the key that selects the lines to access the call number</b>																																					
<table border="1"> <thead> <tr> <th>DIGIT</th> <th>SELECTS TRUNK</th> <th>DIGIT</th> <th>SELECTS TRUNK</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ALL</td> <td>7</td> <td>TRUNK 1,2,3</td> </tr> <tr> <td>1</td> <td>TRUNK 1</td> <td>8</td> <td>TRUNK 4</td> </tr> <tr> <td>2</td> <td>TRUNK 2</td> <td>9</td> <td>TRUNK 1,4</td> </tr> <tr> <td>3</td> <td>TRUNK 1,2</td> <td>*</td> <td>TRUNK 2,4</td> </tr> <tr> <td>4</td> <td>TRUNK 3</td> <td>#</td> <td>TRUNK 1,2,4</td> </tr> <tr> <td>5</td> <td>TRUNK 1,3</td> <td>C</td> <td>TRUNK 3,4</td> </tr> <tr> <td>6</td> <td>TRUNK 2,3</td> <td>D</td> <td>TRUNK 1,3,4</td> </tr> <tr> <td></td> <td></td> <td>E</td> <td>TRUNK 2,3,4</td> </tr> </tbody> </table>		DIGIT	SELECTS TRUNK	DIGIT	SELECTS TRUNK	0	ALL	7	TRUNK 1,2,3	1	TRUNK 1	8	TRUNK 4	2	TRUNK 2	9	TRUNK 1,4	3	TRUNK 1,2	*	TRUNK 2,4	4	TRUNK 3	#	TRUNK 1,2,4	5	TRUNK 1,3	C	TRUNK 3,4	6	TRUNK 2,3	D	TRUNK 1,3,4			E	TRUNK 2,3,4
DIGIT	SELECTS TRUNK	DIGIT	SELECTS TRUNK																																		
0	ALL	7	TRUNK 1,2,3																																		
1	TRUNK 1	8	TRUNK 4																																		
2	TRUNK 2	9	TRUNK 1,4																																		
3	TRUNK 1,2	*	TRUNK 2,4																																		
4	TRUNK 3	#	TRUNK 1,2,4																																		
5	TRUNK 1,3	C	TRUNK 3,4																																		
6	TRUNK 2,3	D	TRUNK 1,3,4																																		
		E	TRUNK 2,3,4																																		
MUST BE ENTERED FROM A TERMINAL																																					
<b>K specifies how routing will be accomplished</b>																																					
<table border="1"> <tbody> <tr> <td>0 - 7</td> <td>Force on Route 0 - 7</td> </tr> <tr> <td>8</td> <td>Use the screening table to determine routing</td> </tr> <tr> <td>9</td> <td>Dial immediate, no Route # (transparent)</td> </tr> </tbody> </table>		0 - 7	Force on Route 0 - 7	8	Use the screening table to determine routing	9	Dial immediate, no Route # (transparent)																														
0 - 7	Force on Route 0 - 7																																				
8	Use the screening table to determine routing																																				
9	Dial immediate, no Route # (transparent)																																				
<b>PP is an Account Code and is separated from the destination number by the* . The * and the Account Code are optional.</b>																																					
<b>## Enters the information into memory</b>																																					

#### Setting up a Speed Call Method 2

STEP	DIAL	DESCRIPTION
1	###	IS THE USER SPEED CALL PROGRAMMING CODE
2	NN(N)	IS THE LOCATION 00 THROUGH 99 OR 000 THROUGH 999
3	MM...	IS THE TELEPHONE NUMBER TO BE DIALED
4	##	ENTERS THE INFORMATION
5		REPEAT STEPS 2 - 4 UNTIL ALL NUMBERS ARE ENTERED
6		HANG UP TO EXIT. DO NOT DIAL 999



## APPENDIX 2 – SITE INFORMATION


### POSITIVE ACCOUNT CODE


#### Programming Positive Account Codes

To program the Controller with the Positive Account Codes accomplish the following steps and write the information in the Positive Account Code Form:

1. Select the users that will have access to the Positive Account Code feature and write their names down under the "Account User's Name".
2. Select unique Account Codes for each of the users and write them down beside the user's name under "Account Code".
3. Select the action digit to be associated with the user's Account Code. Write down the Action Code beside the user's Account Code.
4. Use a DTMF phone that can access the PAV Controller and go off-hook.
5. Dial the PAV Maintenance Access Code. The default Access Code is # \* \*.
6. Start by entering the Account Code for the first user. Next the Action Code for the Account Code, and a terminating "##".

For example if the the first Account Code is 386261 the dialing sequence would be:

Dial # \* \* and a single  will be heard.

Dial 386261 \* # # and  will be heard.

7. Enter any and all of the Account Codes from the worksheet in the same manner. Ensure that the double beep is returned each time an Account Code is entered.
8. After entering all the Account Codes from the worksheet, simply hang up the phone. This action terminates the programming session, and the Controller is now programmed with the Account Codes.

**Note:** The procedure outlined in step 5 needs only be repeated once for each programming session. It does not have to be repeated for each Account Code being entered into the PAV Controller's memory.

**Note:** The single beep indicates that you have successfully entered the Account Code Maintenance Mode, and the double beep indicates that the Account Code has successfully been entered.

**Note:** Once one line that is connected to the Controller has been programmed, all lines connected to that particular Controller are programmed with these same Account Codes. If there are multiple Controllers in an installation, each Controller must be programmed separately to use the Account Codes from all lines that are connected to the them.

**Note:** Each Account Code you enter must have an Action Digit associated with it.

ACTION DIGIT	DESCRIPTION
0	RETURN USER RE-ORDER TONE. DENY CALL
1	VALID ACCOUNT CODE. ALLOW CALL
*	VALID ACCOUNT CODE. ALLOW CALL
#9	DELETE SPECIFIED ACCOUNT CODE



# INDEX

## A

A&B Dial Tone Timers, 2.43  
Account Code Type, 2.37  
Account Coude Warning Tones, 2.39  
Acknowledgement Tones, 2.7  
ASCII CODES, 2.52  
Authorization Number, 2.44

## C

Centrex, 2.24, 2.45  
CHAINING, 2.10  
Changing Terminal Program Security Code, 2.9  
Cloning, 2.10  
CONTROLLER SITE FORM, 2.54, 2.55  
Controller Operation On Off-Hook, 2.23

## D

Data Verification, 2.10  
Defining the Number Of Speed Calls, 2.13  
Dialing Rates, 2.18, 2.19  
Digit Recognition, 2.26, 2.27  
Dummy Account Code, 2.45

## G

Ground Start, 2.20, 2.21

## I

Interdigit Time Out, 2.22

## L

LEGAL CONTROLLER INPUTS, 2.51  
Legal and Illegal Entries, 2.9

## M

Machine ID, 2.33  
MITEL PRINT FORMAT, 2.50

## N

Nulls After A Carriage Return, 2.16

## O

Off-Hook Tone, 2.23

## P

PAV LIST, 2.47  
Positive Account Codes, 2.48  
PRINT FORMAT, 2.50  
Primary And Alternate Routes  
  Destination Number Format, 2.34  
  Route Progress Tones, 2.35  
Primary Search Tables, 2.28  
Print Format, 2.17  
Print Out Incoming Calls, 2.16  
Programming With A DTMF Telephone, 2.7  
Programming With A Terminal, 2.9

## R

Re-Order Tone From The Controller, 2.16  
Rotary Dialing, DTMF Dialing, Type Of  
  Trunk, 2.18  
Route Name, 2.44  
Route Strings, 2.41  
Route To Monitor For CDR, 2.17  
RS-232 Baud Rate, 2.16



## INDEX

### S

SEARCH TABLE RECORD, 2.57  
Search Table Default Data, 2.31  
Search Table Format, 2.30  
Security Code, 2.25, 2.33  
Setting Up A Speed Call, 2.13, 2.15  
SMART PRINT FORMAT, 2.50  
SPEED CALL FORM, 2.59  
SPEED CALL PROGRAMMING, 2.13  
Special Functions, 2.10  
Specifying PAV, 2.12

### T

Tandem Mode, 2.10  
Terminating A Variable Length Entry, 2.7  
Terminating A Variable Length Entry, 2.9  
Tip Ground, 2.26, 2.27

### U


User Area Code, 2.33  
User Dial Tone, 2.21

### W

Wakeup The Controller, 2.6

SMART-1

**SMART-1 CALL CONTROLLER**  
**MANUAL 3**  
**CHAINING INSTALLATION**  
**AND PROGRAMMING**



© Copyright 1988 MITEL INC. All rights reserved.  
® Registered Trademark of MITEL Corporation

PRINTED IN CANADA

HEADING .....	PAGE
1. INTRODUCTION .....	3.2
1. 1. Chaining .....	3.2
2. SETTING UP A CHAIN .....	3.3
3. INSTALLATION OF A RECORDING UNIT .....	3.5
3. 1. Flow Control .....	3.6
4. CHAINING PARAMETERS AND COMMANDS .....	3.7
5. TONES SUPPLIED BY THE CONTROLLER .....	3.8
5. 1. Acknowledge DTMF Tones .....	3.8
6. CHAIN PROGRAMMING .....	3.9
6. 1. Entering Programming .....	3.9
6. 2. Exiting Programming .....	3.9
7. PROGRAMMING AN INDIVIDUAL CONTROLLER .....	3.10
8. REMOVING A CONTROLLER FROM A CHAIN .....	3.11
8. REMOVING A CONTROLLER FROM A CHAIN .....	3.12
9. CHAINING DATA VERIFICATION .....	3.13
10. CDR AND CHAINING .....	3.14
10. 1. Polling Scheme .....	3.14
10. 2. CDR Buffering .....	3.15
10. 3. Suspending the CDR .....	3.15
10. 4. Enabling CDR .....	3.15
11. CHAINING CONDITIONS .....	3.17
11. 1. Parameter 013 .....	3.17
11. 2. Parameter 014 .....	3.17
11. 3. Chains .....	3.17
11. 4. Other Notes .....	3.17
INDEX .....	3.19

# 1. INTRODUCTION


## 1. 1. Chaining

This feature allows multiple Controllers to be "Chained" through their RS-232 port via cabling supplied with each unit (Figure 3.1 ). This Chaining feature provides two distinct features:

1. The units which are chained together via their RS-232 ports (cable supplied) may be addressed remotely or locally with DTMF instruments which can access any port on a Controller in a Chain. From that access point any combination of units within the set, may be programmed with DTMF signals. The recommended methods of access might be either a DTMF instrument itself, or a "Tandem" (see MANUAL 4) access from a remote location.

2. With the addition of an optional cable, a printing device may be connected to the Chain. This allows the collection of call records from all units in the Chain, to be output to one printing device without the need for a data concentrator or multiplexer. The call detail records of the units within the chained set will be output one at a time to the printing device. Programming from this device through the printer Chaining cable is not supported.

Figure 3.1 Setting up a Chain



## 2. SETTING UP A CHAIN

1. *Install and power all the Controllers up individually (maximum of ten), they must not be connected to each other (see MANUAL 1).*
2. *You should have initialized each Controller (MANUAL 1).*
3. *At each Controller individually enter the programming access code (default # 0 \* see Note 1) and turn the CDR off, by entering 0090.*
4. *Make sure that all the Controllers are programmed to the same Baud rate (maximum 1200 Baud when the Chaining Cable is attached). Leave the programming mode by either entering 999, or by going On-Hook.*
5. *Connect a DTMF telephone to a telephone port on a Controller that has not been programmed for an ID (013T).*
6. *Enter the programming access code of # 0 \* from the DTMF telephone.*
7. *Specify the Controller number by entering 013T where T is the Controller number (see Note 2). Go On-Hook.*
8. *Repeat steps 5 through 7 for each remaining Controller except the Tail Controller.*
9. *Power all the Controllers down.*
10. *Attach the Chaining Cable to each of the Controllers in the Chain per Figure 3.2 .*
11. *This step should only be done for the Tail Controller (which must be programmed last). Note: Do not do this until the Chaining cables are connected. Connect a DTMF telephone to a telephone port on the Tail Controller. Then power the unit up, and enter programming mode. Enter 013T where T is the number of the Tail Controller (largest number). Enter 014T where T is the number of Controllers in the Chain. T must be the same in both 013T and 014T.*
12. *To exit programming completely enter 999 or go on-hook.*

If you are using the Optional Printer Chaining Cable, see 3. INSTALLATION OF A RECORDING UNIT.

### A GOOD IDEA


As you install the Controllers in a Chain, it is a good idea to label each Controller and cable, with the labels provided, for programming identification.

**Note 1:** *You can not use a terminal to program in a Chain unless you are in tandem mode (see MANUAL 4).*

**Note 2:** *Before doing Chain programming on any of the Controllers in the Chain you must assign each controller in the Chain a specific number - ID (1 - 9 or \*). The first Controller is referred to as the Head and is numbered 1 and the remaining units are numbered and programmed sequentially (e.g. Controller 2, then 3, 4, etc.). The last unit is referred to as the Tail, and is programmed with the highest number in the Chain.*

## 2. SETTING UP A CHAIN


Figure 3.2 Setting up a Chain



### 3. INSTALLATION OF A RECORDING UNIT

The recording device you use must meet the requirements and be installed as indicated in Figure 3.3 .

Figure 3.3 Connecting a Terminal or Printer



You can not program the Controllers with a terminal unless you are using tandem mode.

## 3. INSTALLATION OF A RECORDING UNIT

### 3. 1. Flow Control

While in the programming mode, to turn CDR on, *enter* 009X (See Table on page 3.16). X-ON/X-OFF flow control from the receiving device connected to the printer cable is not supported by the Controller. The Controller Chain may be programmed to temporarily suspend output by setting 014T in the Tail Controller to a 0140.



## 4. CHAINING PARAMETERS AND COMMANDS

The following is a list of Chaining Commands and Parameters specific to Controllers in a Chain:

- 013 t      Number of this Controller in Chain (1-9, \* = 10; 1=Head; 0=not in Chain)
- 014 t      Total number of Controllers in Chain (programmed in Tail Controller only; 1-9, \* =10, 0=not Tail Controller).
- 950        Enter DTMF Chain Programming mode.
- 944 n      Select Controller number "n" in Chain to accept DTMF Chain Programming. You can enter more than one 944n to select more than one Controller at a time.†
- 945        Select all Controllers in Chain to accept DTMF Chain Programming at the same time.†
- 946 n      Deselect Controller number "n" in Chain from accepting DTMF Chain Programming.†
- 947        Deselect all Controllers in Chain from accepting DTMF Chain Programming.†
- 952 n      Select Controller number "n" in Chain for data verification, and deselect all others (multiple 952-n's may be used in succession without using 957).†
- 957        Exit Chain verification mode and remain in Chain programming mode, with all Controllers selected.†
- 959        Exit DTMF Chain Programming mode, remaining in "normal" program mode in the unit you are connected to.†

† To use these commands you must be in Chain programming mode.

The following commands (normally used in programming mode) do not work in the DTMF Chain Programming mode:

- 902            Normal data verify (use 952 n)
- 942 903       Initialize Controller to defaults
- 942 906       Clone
- 907            Normal exit verify (use 957)
- 942 908       Tandem access of another Controller

**Note:** You can use tandem mode on a remote Controller to call into a Controller in the Chain for programming and/or verification using a terminal.


**Note:** The command 980, if entered in DTMF Chain programming mode, sets the time and date in all the Controllers even if you have not selected them all.

## 5. TONES SUPPLIED BY THE CONTROLLER

### 5. 1. Acknowledge DTMF Tones

While programming the Controller in Chain mode you will receive audible indications as to correct, incorrect entries and programming timeouts. In general, after each entry, the Controller will respond with a double tone.

If You Hear 


A single DTMF  means the command you have entered has been recognized as legal(correct), i.e. you entered # 0 \*.

For Example

Parameters: After the three digit parameter prefix has been dialed, the Controller will respond a single short tone.



Strings: After the three digit string prefix has been dialed, the Controller will respond a single short tone.


Search Tables: After the three digit search table prefix, the Controller will respond a short tone.


You will hear  upon entering commands, 952, 946, and 944.


If You Hear 

If you hear a double tone it means the entry you have made has been accepted. This occurs after a parameter has all the digits it needs to make it legal or you entered ## on a variable length parameter. For example:


- If you enter 942 you will hear . Then enter 903 and you will hear .
- If you enter 957 to exit Chain data verification mode you will still be in Chain programming mode.

In this case when you enter a valid parameter you will hear a ,

and when valid data is entered for that parameter you will hear .

- You will hear  at the end of a string, or a parameter that needs a single digit, 950, 947, or after 952 followed by a digit you wish to look at.

If You Hear 

Four long DTMF  means you have made an incorrect programming entry. Note: In the event of an illegal entry, wait for the tones to stop and then try again.

## 6. CHAIN PROGRAMMING

### 6. 1. Entering Programming

You must have given each Controller in the Chain an ID and entered the number of Controllers in the chain in the Tail Controller. By leaving the DTMF telephone connected to a telephone port on any one of the Controllers, you can program all Controllers simultaneously with the same information. It is not necessary to use DTMF Chain Programming if a Chaining Cable is connected to a Controller; "normal" DTMF programming may still be done for that Controller as before, if desired. If command 950 is entered at a Controller during regular program mode, it (and the rest of the Chain) enters the DTMF Chain Programming mode. After the programming access code and the 950 command have been entered, programming may be done per normal except for the following:

- While in the Chaining mode, the Controller does NOT give the one-minute warning as it does in "normal" programming mode; after two minutes of no activity, the Controller will exit programming.
- Only one line, on one Controller, per Chain, may do DTMF Chain Programming at a time. Additional access attempts will be refused.
- Chaining operations can not be done any faster than 1200 baud. Don't change 006 (RS-232 Baud Rate) with the Chaining Cable attached, and make sure that all the Controllers are set to the same Baud rate when the Chaining Cable is attached. You can not change the baud rate or set the ID of a Controller while it is in a Chain.

### 6. 2. Exiting Programming

To exit programming completely *enter 999 or go on-hook*.

Enter 959, to exit Chain programming mode, but remain in normal programming mode for the Controller you are connected to. Warning:

If you are doing a remote access you must enter 999 before hanging up, or you will leave the trunk locked up until it times out.

## 7. PROGRAMMING AN INDIVIDUAL CONTROLLER

To program an individual Controller while using Chaining (you must make sure you address the correct Controller(s) you wish to program) you can:

1. *Connect a DTMF telephone to a telephone port on any Controller which is in the Chain and enter the programming access code followed by 950. This starts Chain Programming mode and selects all the Controllers in the Chain for programming.*
2. *If you want to program all the Controllers in the Chain with the same information, go to step 4. Otherwise, enter 947 which deselects all Controllers in Chain.*
3. *Enter 944 n which selects a specific Controller where n is the unique ID (1 - 9 or \* for 10). This command may be repeated to select more than one Controller in the Chain for programming.*
4. *Enter the individual programming information for the Controller(s).*
5. *To exit programming completely enter 999 or go on-hook. Enter 959, to exit Chain programming mode, but remain in normal programming mode for the Controller you are connected to.*

## 8. REMOVING A CONTROLLER FROM A CHAIN


Should the requirement occur, you can remove a Controller from a Chain. The example in Figure 3.4 shows a four controller Chain for simplicity. However, there can be any number of Controllers in the Chain (up to 10) and any number may be removed. Essentially, the easiest method of removing a Controller is to remove it, put the Tail Controller in its place and reprogram to the removed Controller's ID, then reprogram the last Controller in the Chain to be the new Tail Controller. The following steps outline this technique in greater detail.

1. *Connect a DTMF telephone to a telephone port on the Controller that has been selected for removal. Enter the programming access code.*
2. *Enter 0130 (this removes the Controller from the Chain).*
3. *Go on-hook.*
4. *Connect a DTMF telephone to the Tail Controller and enter the programming access code. Enter 0140 (deselects this Controller as the Tail, turns off Chaining activity, and suspends CDR output if it was enabled). Go on-hook. Power all Controllers down.*
5. *Move the Tail Controller into the position indicated in Figure 3.4 .*
6. *Power up all Controllers.*
7. *Connect a DTMF telephone to a telephone port on the old Tail Controller.*
8. *Program 013T on the old Tail Controller to match its new position in the Chain. Go on-hook. Connect a DTMF telephone to a telephone port on the new Tail Controller.*
9. *Reprogram 014T on the new Tail Controller with the new total number of Controllers in the Chain. This turns on Chaining activity, and starts CDR output if it was enabled.*
10. *To exit programming completely enter 999 or go on-hook. Enter 959, to exit Chain programming mode, but remain in normal programming mode for the Controller you are connected to.*

**Note:** Any CDR records which have not been output by a Controller are lost if that Controller is powered down.

## 8. REMOVING A CONTROLLER FROM A CHAIN

Figure 3.4 Removing A Controller From A Chain



### Notes

Don't attach or detach the Chaining Cable from any of the Controllers unless Register 014T in the Tail Controller has been set to 0140. You should also turn off the CDR by setting Register 009T to 0090. To suspend CDR (for a short time) you can set 014T to 0140.

### WARNING:

If you wish to discontinue, or take down a Chain, *DO NOT* attempt to use the sequence: # 0 \* 950 013 0. The Controller will refuse this command if it is in Chain programming mode.

The command to remove the Controller from the Chain, must be entered separately, for each Controller in the Chain.

## 9. CHAINING DATA VERIFICATION

There are three ways to verify the data in Controllers in a Chain:

- A. Use a DTMF telephone on the subscriber side of one line of one of the chained Controllers and a DTMF digit decoder/collector on the C.O. side of the same line;
- B. Call in to one of the chained Controllers from a remotely-located DTMF telephone which has a DTMF digit decoder/collector connected in parallel (remote programming);
- C. Use a terminal with another Controller in its Tandem mode to call in to one of the chained Controllers.

Using any of these three methods, go into program mode on one of the chained Controllers.

1. Enter the 950 command to enter the Chaining mode.
2. Enter 952 n, where n is the number of the Controller in the Chain which you desire to examine.
3. Enter the number of the parameter for which you wish to verify the value. The value appears on the terminal (tandem mode) or DTMF digit decoder/collector.
4. Continue entering parameter numbers until you have all your desired information. You may then verify another Controller by entering 952 n, where n is the number of the next Controller to be verified.
5. To leave the verification mode and remain in the Chaining mode, enter the command 957.

Alternatively, the commands 959 or 999 may be used to exit from Chaining mode and from programming mode respectively, with the expected results.

# 10. CDR AND CHAINING

## 10. 1. Polling Scheme

In the Chain, the Tail Controller queries the other Controllers for their CDR status. The Controller with the most records sends its call records first, through the Chain, to the Tail Controller, which passes them out to the printer cable. This process continues until each Controller has sent all available records.

There is a set of printable and non-printable characters used to perform the polling scheme. These characters are also sent to the printer cable. Characters used were chosen with care to prevent interface problems with popular printers, SMDA equipment, and other call recording devices. A list of characters sent by the Controllers is listed below:


FUNCTION	HEX	ASCII	CONTROL CODES
CDR ENQUIRY (COMMAND TO SEND CDR BUFFER STATUS)	01	SOH	^A
START OF BUFFER STATUS REPORT	1E	RS (note 2)	--
END OF BUFFER STATUS REPORT	1C	FS (note 2)	^\
DUMP CDR COMMAND (START OF BINARY DUMP NR)	7E	- (note 1)	-
ELEMENT OF BINARY DUMP NUMBER	01	SOH	^A
ELEMENT OF BINARY DUMP NUMBER	00	NUL	^@
END OF BINARY DUMP NUMBER SEQUENCE	7E	- (note 1)	-
START OF CDR DUMP	3B	; (note 1)	;
END OF CDR DUMP	04	EOT	^D
DTMF CHAIN PROG. ENTRY CODE INTRODUCTION CHAR	10	DLE	^P
"REGULAR" DTMF CHAIN PROG. ENTRY CHAR	21	! (note 1)	!

**Notes:**

1. This is a printing character, but it does not normally appear in a CDR record.
2. This character is not sent to the printer.

**Example 1**

A line in Controller 3 in a Chain goes on-hook.



As a printout, the output from the above would be:

```
... (previous CDR record)... --;
01/27 09:49 00:02:34 1315393121 T3 ROUTED CHN
```


The - may be missing from a multiple-CDR output of consecutive records from one Controller.



## 10. CDR AND CHAINING

### Example 2

Someone enters DTMF Chain Programming Mode at Controller 5 in a Chain, programs "523 8 980 01270945 009 2" and then goes on-hook.



On paper, the output (†) from the above would be:

```
... (previous CDR record).....CHN!5238980012709450092X--;
05/22 08:37 00: 1:57 #0* T3 DDD CHN--;
... (next CDR record )....
```

† The recording of your programming does not include carriage returns in its output. If your recording device does not have an auto wrap function, you may lose some of the output beyond the right side of your page. However, the next call record will start in column 1 as normal, since each call record begins with a carriage return – line feed sequence.

### 10. 2. CDR Buffering

Sufficient RAM has been dedicated to the storage of the call records until they can be printed. If the buffer becomes full, newest records will not be stored. There is sufficient memory allocated to store at least 12 call records in each Controller.

### 10. 3. Suspending the CDR

The CDR can be temporarily suspended by:

1. *Entering* the programming mode using a DTMF telephone connected to the Chain or accessing the Chain remotely through Tandem mode.
2. *Selecting* the Tail Controller.
3. *Entering* 0140.

**Note:** Collection of call records will continue in all Controllers which have call recording enabled.

## 10. CDR AND CHAINING

### 10. 4. Enabling CDR

You can change Call Detail Recording (CDR) format as required:

- The MITEL format was developed for PBX applications (specifically MITEL PBXs). Some fields are used for call transfers, attendants, etc., and are not supplied by the Controller.
- The SMART format is similar to the MITEL format, however it has reduced the printing width to fit in 80 columns and the R field is in ASCII instead of numeric.

For further information on the print format see APPENDIX 1 of MANUAL 2. The print format can be changed or disabled by:

REGISTER 009	DESCRIPTION	DEFAULT
ENTER 009T	T = 0 FOR OFF	3
	T = 1 FOR MITEL PROVIDE A CARRIAGE T = 2 FOR SMART RETURN LINE FEED AT T = 3† START OF RECORD	
	T = 5 FOR MITEL PROVIDE A CARRIAGE T = 6 FOR SMART RETURN LINE FEED T = 7† AT START OF RE- CORD AND END	

† Note: Please go to your Manual 2 for an explanation of additional options for this parameter.

## 11. CHAINING CONDITIONS

Certain conditions and restrictions apply to Controllers and Chaining. This part outlines those restrictions under these headings:

Parameter 013

Parameter 014

Chains

Other Notes

### 11. 1. Parameter 013

A Controller may be in one Chain only, and the Controller must have a unique ID as set by 013T.

The Controller must be programmed such that 013T is the same as the number you labeled the RS-232 connector, on the Chaining Cable.

The Head Controller is always Controller number 1 in a Chain (013=1).

If 013T is set to anything other than 0130 the RS-232 port can not be used for terminal programming.

### 11. 2. Parameter 014

Parameter 014T is always set to 0140 on each Controller, except on the Tail Controller, where it is set to the same value as 013T.

### 11. 3. Chains

The number of Controllers in a Chain must be exactly equal to the number of Controller ports in the Chaining Cable you are using (i.e. if you leave any of the Controller ports in the Chaining Cable open, or do not have a unit programmed as a Head, or do not have sequential ID numbers, it won't work).

Chains can not be hooked together. A Controller may be in one Chain only.

No Controller in a Chain may be programmed locally from any device other than a DTMF source.

The maximum number of Controllers in a Chain is 10.

The Controller in the Chain with the highest Controller number is always the Tail.

### 11. 4. Other Notes

When DTMF Chain Programming mode is first entered, all the Controllers are considered "selected" for the purpose of DTMF Chain Programming.

User speed call programming and user PAV programming work around the Chain just as they do in a non-Chained Controller. If either is invoked, the software checks 013T to see if the Controller is in a Chain. If so, it automatically sends the proper commands around the Chain. If not in a Chain, it doesn't try to send the commands out to the RS-232 port.

When setting up a Chain, program the Tail Controller with its 013T and 014T LAST. When taking down a Chain, take the Tail Controller out of the Chain FIRST by programming its 014 to 0, 013 to 0, 009 to 0, then do the others, then take the cable off.

## 11. CHAINING CONDITIONS

It is not necessary to use DTMF Chain Programming if a Chaining Cable is connected to a Controller; "normal" DTMF programming may still be done for that Controller as before, if desired; only if command 950 is dialed will that Controller (and the rest of the Chain) enter the DTMF Chain Programming mode.

A printer is NOT necessary to perform DTMF Chain Programming. If a printer is attached to the printer port of a Chaining Cable, DTMF Chain Programming activity will be shown on it.

The baud rate on the RS-232 port is defaulted to 1200 (006T = 0064). Make sure that the printer or terminal you use is set to the same baud rate as you have set in 006T, and make sure that all the Controllers are set to the same baud rate when the Chaining Cable is attached.

You may use a terminal with a keyboard on the printer port of the Chaining Cable, but the keyboard will have no effect; this port is for a Receive Only device.

After a Chain is set up, it will stay set up even if the power to the Controllers is lost. Any CDR which had accumulated but had not yet printed out before the power outage is lost. Any call activity during the power outage, of course, generates no call records.

# INDEX

## C

CDR AND CHAINING, 3.14  
CHAINING CONDITIONS, 3.17, 3.18  
CHAINING DATA VERIFICATION, 3.13  
CDR buffering, 3.15

## F

FIGURE, 3.2

## P

Parameter 013, 3.17  
Parameter 014, 3.17

## S

SETTING UP A CHAIN, 3.3  
Suspending CDR. *See* CDR buffering

PET. DUGAN MITEL

415 933-2164

# SMART-1™

COMMON CARRIER ACCESS DIALER  
AND CALL CONTROLLER  
GENERAL INFORMATION



MITEL®

© - Copyright of MITEL DATACOM INC. 1985  
™ - Trademark of MITEL DATACOM INC.  
® - Registered Trademark of MITEL CORPORATION

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**NOTICE TO U.S. CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The SMaRT-1™ Common Carrier Access and Call Controller generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.



--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**NOTICE TO CANADIAN CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The Department does not guarantee that the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground connections to the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**CAUTION**

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as required.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load, to be connected to a telephone loop, that is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all of the devices doesn't exceed 100. An alphabetic suffix is also specified in the Load Number and designates the appropriate ringing type (A or B), if applicable. For example, LN = 20 A designates a Load Number of 20 and an 'A' type ringer.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**IMPORTANT NOTES**

Please note that MITEL DATACOM INC. has set up a National Field Service number for technical and installation assistance located in Dallas, Texas. This number is [214] 386-9400 for U.S. customers only (outside of normal working hours, a telephone answering service has been established for your convenience at this same number). For Canadian customers, please contact your local MITEL Regional Office.

The SMarT-1™ Dialer includes an on-board battery back-up system to prevent the loss of customer database. Besides protecting against loss of data during momentary power outages, this battery back-up should also provide sufficient memory retention to allow the Dialer to be programmed by the distributor and then transported to the customer's site for installation. This battery back-up, however, is not intended for long storage periods and cannot be guaranteed to support memory for long periods of time.

As received from the factory, the Dialer battery is not guaranteed to have a full charge applied to it. In fact, the battery is likely to be only partially charged in view of the time in transit, and distributor storage time. No guarantee of any battery charge status can be made until the Dialer has been powered up for a period of time. A period of 24 hours is necessary to achieve a full charge on the battery.

Upon removal from its shipping carton, the Dialer should be powered up for a period of time and then "✖ INITIALIZED" to load the operating system and default database into memory. Initialization may only be performed with a DTMF telephone set and requires connection to a working telephone line or an acceptable substitute. Never rely on programming entered into a Dialer until it has been "✖ INITIALIZED" (see Page 10, para. 3.05). Note that there is a short tone burst heard in the earpiece of the phone upon initialization. This tone indicates a successful initialize sequence has occurred.

Once initialized, the Dialer should seldom ever have to be initialized again. There is a "903" Load Default Data Command that will restore memory to the initialized state once a "✖ INITIALIZE" has been performed. Once initialized, the Dialer will also respond to input via the RS-232 Input.

**REASONS FOR ADDITIONAL "✖ INITIALIZE" OPERATIONS**

Dialer has just been removed from storage or shipping carton.

No toneburst upon release of the ✖ Key. Maybe the tone was missed - check carefully.

The program access codes have been deleted accidentally or the access codes have been changed and forgotten.

The Dialer has just been repaired.

Long storage times.

Loss of data retention. Investigate for reason!

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**smart-1****COMMON CARRIER ACCESS DIALER AND CALL CONTROLLER****GENERAL INFORMATION**

CONTENTS	PAGE
<b>1. INTRODUCTION</b> .....	<b>1</b>
<b>GENERAL</b> .....	<b>1</b>
<b>OVERVIEW OF THIS MANUAL</b> .....	<b>1</b>
<b>INTENDED AUDIENCE</b> .....	<b>1</b>
<b>2. GENERAL DESCRIPTION</b> .....	<b>3</b>
<b>FEATURES</b> .....	<b>3</b>
<b>DEFINITION OF TERMS</b> .....	<b>3</b>
<b>Trunk Side Dialer</b> .....	<b>3</b>
<b>Store and Forward</b> .....	<b>4</b>
<b>User Transparent</b> .....	<b>4</b>
<b>Ground Start/Loop Start</b> .....	<b>4</b>
<b>DTMF/Rotary Dial</b> .....	<b>4</b>
<b>Power Failure Conditions</b> .....	<b>4</b>
<b>Area Code/Office Code/Call Searching</b> .....	<b>5</b>
<b>Lines</b> .....	<b>5</b>
<b>Two (2) Models Available</b> .....	<b>5</b>
<b>Adaptive Call Routing</b> .....	<b>5</b>
<b>Call Recording/RS-232 Port</b> .....	<b>5</b>
<b>Versatile Programming</b> .....	<b>5</b>
<b>Power</b> .....	<b>6</b>
<b>Least Cost Routing</b> .....	<b>6</b>
<b>Speed Call</b> .....	<b>6</b>
<b>Centrex Compatible</b> .....	<b>6</b>
<b>3. INSTALLATION</b> .....	<b>7</b>
<b>INTRODUCTION</b> .....	<b>7</b>
<b>UNPACKING</b> .....	<b>7</b>
<b>MOUNTING</b> .....	<b>7</b>
<b>CONNECTIONS</b> .....	<b>7</b>
<b>SIMPLIFIED PROGRAMMING</b> .....	<b>10</b>
<b>Initializing the Dialer</b> .....	<b>10</b>
<b>Action on Dialing</b> .....	<b>10</b>
<b>Simplified OCC Programming</b> .....	<b>11</b>
<b>4. OPERATION</b> .....	<b>13</b>
<b>INTRODUCTION</b> .....	<b>13</b>
<b>GENERAL DESCRIPTION</b> .....	<b>13</b>

CONTENTS	PAGE
DETAILED DESCRIPTION .....	13
Options .....	13
Searching .....	14
TEMPLATE DESCRIPTION .....	14
OTHER COMPARISONS .....	16
ROUTES .....	16
SEARCH EXAMPLES .....	17
ADDITIONAL SEARCH INFORMATION .....	18
ROUTE SELECTION .....	19
SPEED CALLS .....	22
NOT ON NETWORK (NON) CHECKING .....	22
CALL RECORDS .....	23
CENTREX OPERATION .....	23
CALL RECORDING OPERATION .....	23
Connecting a Storage Device .....	24
CALL RECORD FORMAT .....	25
MITEL Format .....	26
SMarT-1™ Format .....	28
EXAMPLES .....	30,31
WIRING CONSIDERATIONS .....	31
<b>5. DETAILED PROGRAMMING .....</b>	<b>33</b>
INTRODUCTION .....	33
PROGRAMMING METHOD 1 (Terminal or Computer) .....	33
PROGRAMMING METHOD 2 (DTMF PHONE) .....	33
PROGRAMMING METHOD 3 (TANDEM MODE) .....	33
PROGRAMMING METHOD 4 (CLONING) .....	33
DETAILED PROGRAMMING INSTRUCTIONS .....	34
METHOD 1 .....	34
VT-100 Compatible Terminal .....	34
METHOD 2 .....	36
Entering Programming Mode .....	37
ENTERING DATA .....	37
Parameters .....	38
Strings .....	48
EXAMPLE 1: .....	48
EXAMPLE 2: .....	48
Speed Call Entries .....	51
Search Tables .....	52
EXAMPLE 1: .....	52
EXAMPLE 2: .....	52
EXAMPLE 3: .....	52
Special Functions .....	56
ACKNOWLEDGE TONES .....	57
Parameters .....	57
Strings .....	57
Search Tables .....	57
METHOD 3 .....	58
Tandem Mode .....	58

CONTENTS	PAGE
METHOD 4 .....	59
Cloning .....	59
Procedure .....	60
6. SPECIFICATIONS .....	63
HARDWARE .....	63
RS-232 PORT .....	65
ELECTRICAL/MECHANICAL .....	65
7. MAINTENANCE .....	67
GENERAL .....	67
8. ORDERING INFORMATION .....	69
GENERAL .....	69
9. TROUBLESHOOTING .....	71
GENERAL .....	71
APPENDIX A .....	A-1
GLOSSARY OF TERMS .....	A-1
APPENDIX B .....	B-1
FCC INTERCONNECTION REQUIREMENTS .....	B-1
General .....	B-1
CONNECTION LIMITATIONS .....	B-1
NETWORK CHANGES .....	B-1
MAINTENANCE LIMITATIONS .....	B-1
TROUBLE CORRECTIONS .....	B-2
DISCONNECTION .....	B-2
APPENDIX C .....	C-1
DIAGRAMS AND ASCII TABLE .....	C-1
LEGAL DIALER PROGRAMMING INPUT CHARACTERS .....	C-5
APPENDIX D .....	D-1
OVERALL INDEX .....	D-1
 FIGURES	 PAGE
1: SMarT-1™ COMMON CARRIER ACCESS DIALER AND CALL CONTROLLER .....	1
2: CONNECTOR PANEL .....	8
3: RS232 INTERFACE CONNECTOR (Viewed from outside Dialer) .....	8
4: USOCRJ31X JACK AND CABLE ASSY. ....	9
C1: SMarT-1™ SYSTEM BLOCK DIAGRAM .....	C-2
C2: SMarT-1™ SIMPLIFIED ELECTRICAL DIAGRAM .....	C-3



TABLES	PAGE
1: TEMPLATE DIGITS .....	15
2: ACTION DIGITS .....	15
3: ACCESS CONTROL SEQUENCE (ACS) CODES .....	20
4a: DETECTOR/TIMEOUT (a) CODES .....	21
4b: DETECTOR/TIMEOUT (b) CODES .....	21
5: GENERAL PURPOSE STRINGS .....	22
6: MITEL CALL RECORD FORMAT FIELDS .....	27
7: SMarT-1™ CALL RECORD FORMAT FIELDS .....	29
8: PARAMETERS .....	39-47
9: STRING DATA ENTRY .....	49-50
9a: DETECTOR/TIMEOUT (a) CODES .....	50
9b: DETECTOR/TIMEOUT (b) CODES .....	50
10: SPEED CALL ENTRIES .....	51
11: SEARCH TABLE ENTRIES .....	53-54
12: SPECIAL FUNCTIONS .....	57
13: SMarT-1™ HARDWARE SPECIFICATIONS .....	63-64
14: RS-232 PORT SPECIFICATIONS .....	65
15: ELECTRICAL/MECHANICAL SPECIFICATIONS .....	65
16: SMarT-1™ ORDERING INFORMATION .....	69
17: TROUBLESHOOTING CHART .....	71-74
C1: ASCII CODES .....	C-4
C2: LEGAL DIALER PROGRAMMING CHARACTERS .....	C-5

## 1. INTRODUCTION

### GENERAL


**1.01** This document contains all information that relates to the SMarT-1™ Common Carrier Access Dialer and Call Controller. This particular section (Section 1) is an overview of the contents of the document and outlines the intended audience.

**1.02** From this point forward, the SMarT-1™ Common Carrier Access Dialer and Call Controller will be referred to in text as the 'Dialer'.

### OVERVIEW OF THIS MANUAL

**1.03** The manual consists of nine sections and four appendices. Sections one through four provide both general and detailed descriptions of the Dialer features and functions while section five provides detailed program data entry information. Sections six through nine provide engineering information and the appendices provide additional information that may be of general use to the reader.

**1.04** For an abbreviated installation and/or programming description, refer to the **INSTALLATION AND ABBREVIATED PROGRAMMING GUIDE**, P/N 8350-953-001-NA.



**FIGURE 1: SMarT-1™ COMMON CARRIER ACCESS DIALER AND CALL CONTROLLER**

**INTENDED AUDIENCE**

**1.05** This document is intended for use as a general reference document for the installer and user of the SMarT-1™ and SMarT-1A™ Common Carrier Access and Call Controller.

**HISTORY**

**1.06** This is the second issue of the SMarT-1™ Common Carrier Access Dialer and Call Controller General Information Manual. It replaces all manuals previously issued (Issue 1, March 1985). The reason for re-issue was to bring the manual up to the requirements of the present software level (G10 R05 and later) of the Dialer.

## 2. GENERAL DESCRIPTION

### FEATURES

**2.01** The SMarT-1™ Common Carrier Access Dialer and Call Controller is a self-contained electronic unit that provides:

- Compliance with FCC Parts 68 and 15
- 4 Line capacity for the SMarT-1™ unit
- 2 Line capacity for the SMarT-1A™ unit
- Call recording output
- Call searching to select features
- Versatile programming either locally, remotely, or limited
- Automatic placement of selected calls through Other Common Carrier (OCC) facilities
- Speed calling of up to 100 numbers, accessible by all users, unless denied on a trunk basis
- Several convenience features:
  - Useable with Centrex Lines
  - Useable behind a PBX
  - Can be configured as a hot line
- Full tenant split that allows completely separate call screening patterns for two groups
- Computer (RS-232) Input/Output port for either call recording or programming
- Non-volatile memory
- No loss of Memory during Power Failure

### DEFINITION OF TERMS

**2.02** The SMarT-1™ Dialer is a versatile unit, and as such, can appear to be complex to the user. It is hoped that, with the following explanations, it can be shown that the Dialer is indeed simple and versatile and that programming is quite simple. To further this concept, a glossary of terms and general information is included in the paragraphs below, that will familiarize the user with the terminology and ideas presented in this document.

**2.03** For those who are interested in more complex uses of the Dialer, refer the last sections of this manual that detail complete programming instructions and tables of codes.

### **Trunk Side Dialer**

**2.04** The SMarT-1™ Dialer is installed on the customer's premises. The unit may be connected between any of the customer's equipment and the Central Office. When the customer's Trunks/Lines are connected to the SMarT-1™ Dialer, all of the telephones within that system may (if selected) have access to their 'Other Common Carrier' (OCC)/Reseller's Network, providing that they have access to those Trunks/Lines.

### **Store and Forward**

**2.05** The SMarT-1™ Dialer can be preprogrammed with the OCC/Reseller's access telephone number and the customer's authorization code. This eliminates the dialing of extra digits by the customer. It also provides a security factor, since the authorization code can be used on a 'need to know' basis. This information is 'stored' while programming. When the customer places a long distance call, it is dialed as normally done for a Direct Distance Dialing (DDD) call. The SMarT-1™ Dialer 'forwards' not only the long distance number desired, but all of the 'stored' data to the OCC/Reseller's system.

### **User Transparent**

**2.06** This term means that the user is unaware (hears nothing) of the 'Store and Forward' process because the routing is completed with no pauses. However, there is an 'ending tone' that the caller will hear. This tone means that the Dialer has completed its routing through the system (Central Office to OCC/Reseller's Switch).

### **Ground Start/Loop Start**

**2.07** These are the two types of Trunks/Lines that are available from a CO. The SMarT-1™ Dialer will function with either type.

### **DTMF/Rotary Dial**

**2.08** These are the types of dialing that are available. DTMF uses tones to dial while the Rotary system uses pulses. The SMarT-1™ Dialer will operate with either type.

### **Power Failure Conditions**

**2.09** In the event of a commercial power outage, the SMarT-1™ Dialer will assume a "power down cut-through mode". In this state, the Dialer appears to the network as a metallic path from its tip and ring inputs to the tip and ring outputs. Even though the telephone system may not be operational, the Dialer will not interfere with any telephone operations that may be available (i.e., incoming calls). The battery back up feature inherent in the Dialer allows the customers

stored data to be retained. There is no requirement for reprogramming the Dialer once power is restored.

#### **Area Code/Office Code/Call Searching**

**2.10** The SMarT-1™ Dialer can be programmed to 'look up' the Area Code (NPA) and Office Code (NXX) numbers and perform routing decisions (i.e., route through OCC/Reseller Switch, route DDD, or restrict) depending on the OCC/Reseller's capabilities and the customer's requests.

#### **Lines**

**2.11** There are four independent lines in the Dialer. They all share the same search tables. Results of the searching will select a route (in actuality, a 'routing method'). The routing data (the four alternatives) is shared among the lines.

#### **Two (2) Models Available**

**2.12** The SMarT-1™ Dialer services four independent telephone lines, while the SMarT-1A™ services two lines. Both are compact and powerful systems that provide simplified access to the common carrier network. The calling side of the connection may be a telephone, key system line card, or a PBX trunk card. The called side of the connection may be a central office or a PBX line circuit. Operation may be completely transparent to the user.

#### **Adaptive Call Routing**

**2.13** All calls are made over predetermined routes, with the required authorization codes and account codes being inserted automatically by the Dialer at the appropriate time. The Adaptive Call Routing (ACR) feature allows the SMarT-1™ and SMarT-1A™ to automatically detect, remember and re-route all numbers not available on the OCC over the DDD Network.

#### **Call Recording/RS-232 Port**

**2.14** The call recording output, via the computer (RS-232) port with programmable Baud rate, provides a complete record of numbers dialed and on-hook/off-hook times for all calls dialed on the lines served by the system. This information can be used by the Common Carrier or user for traffic studies, usage analysis, call costing, etc..

#### **Versatile Programming**

**2.15** The Dialer requires some programming before use. Four programming options are provided which allow the installer to choose the best method for the appropriate situation. Programming can be performed locally or remotely using a DTMF or butt-in station,

and is protected against unauthorized changes by a log-on access code. Programs can also be copied from one Dialer to another by simply interconnecting the systems. In addition, programming can be performed very quickly via the computer (RS-232) port, from selected lap or personal computers, using an available software package.

#### **Power**

**2.16** Power is supplied from a small transformer provided with the system. Battery back-up prevents memory loss in the event of power failure.

#### **Least Cost Routing**

**2.17** This will allow alternate routing of long distance calls through various OCC facilities. Since toll calls placed through OCC networks are typically less expensive than DDD routes, choosing the most economical medium (i.e., DDD or whatever OCC) will enable the user to capitalize on OCC network rate benefits.

#### **Speed Call**

**2.18** These are preprogrammed telephone numbers which allow the users to have the capability of simplified dialing. Up to 100 numbers can be stored in the Speed Call area and are accessible for all users. Speed dial telephone numbers are activated by dialing a three digit number. A limited program access code is provided to allow subscriber entry of speed dials.

#### **Centrex Compatible**

**2.19** In this mode, the SMarT-1™ Dialer will recognize the 'outside line' access code (e.g., digit '9') and will route all internal calls transparently. In addition, the Dialer can be programmed to recognize certain area codes, and direct calls to those areas over an alternate route. This also provides Least Cost Routing capability.

### 3. INSTALLATION

#### INTRODUCTION

**3.01** The word 'Installation' as used in this section means the electrical and mechanical connection to the wires of the user and the associated Central Office along with simplified steps to place the unit into operation.

#### UNPACKING

**3.02** The SMarT-1™ Dialer is packaged in a box along with the Power Supply and Mounting Bracket. Simply open the box and remove the contents while checking for damage. Check the contents against the packing list. If any items are missing or appear to be defective, notify the vendor for further instructions.

#### MOUNTING

**3.03** The SMarT-1™ Dialer is housed in a compact plastic enclosure that measures 10.625 inches (26.99cm) X 7.625 inches (19.37cm) X 1.375 inches (3.49cm). The unit may be operated in any physical orientation, although wall-mount installation by use of the enclosed bracket is recommended. Simply mount the bracket to a surface with screws, and mount the Dialer housing to the bracket by matching the four holes on the rear of the case with the mounting pins of the bracket. Press into place.

#### CONNECTIONS

**3.04** Seven connections are required for operation. These are made to the connectors located along one edge of the housing (refer to Figure 2). Make the connections as follows:

- 1) Earth Ground **MUST** be connected to the screw mount provided on the bottom connector strip. The unit will not function properly without this connection.
- 2) Power is fed to the Dialer via a three wire cord with jack from the accompanying Power Pack. Simply plug the cord of the Power Pack into the Dialer power jack. Plug the Power Pack AC Cord into a source of 110V at 60 Hz (normal AC wall outlet).
- 3) Telephone signals are connected through four standard RJ31X non-shorting jacks. Four cables with appropriate connectors are supplied with the Dialer for this purpose. Insert one end of the supplied cable into each of the four jacks on the Dialer. The other end of this cable is to be connected to the Telco-supplied jack.
- 4) The last connection, which is optional, is an RS-232 female connector configured as "DCE". Only the TxD (pin 3), the RxD






FIGURE 2: CONNECTOR PANEL

(pin 2), and the GND (pin 1) lines are used by the Dialer. Pins 4 through 6, 8 and 20 are shorted internally for the convenience of the user. This port is used for Programming Methods 1, 3, and 4 and also for Call Recording Output. If the latter is desired, simply connect a serial printer to this connector with an appropriate cable wired to the pin-outs as specified above.




FIGURE 3: RS232 INTERFACE CONNECTOR (Viewed from outside Dialer)




FIGURE 4: USOCRJ31X JACK AND CABLE ASSY.

## SIMPLIFIED PROGRAMMING

### Initializing the Dialer

**3.05** Before using the Dialer for the first time, it must be initialized by the procedure listed below. This provides the Dialer with simple operating instructions. This data default base can be later modified by the customer if required, by the use of one of the methods outlined in the Detailed Programming section that appears at the end of this manual or by the simplified OCC programming in the following paragraph. The simplified programming procedure is:

- With the RJ31 Cable connected:
  - 1) Connect either a DTMF station or DTMF Butt-set unit to the subscriber Tip and Ring of Line 1 of the Dialer. For Butt-set units, the connections must be made external to the Dialer. If the Dialer is opened, the Warranty Seal will be broken, voiding the unit warranty. It is suggested that the Butt-set be connected at the Telco supplied connections.
  - 2) With the DTMF station or butt-set off-hook, disconnect power from the Dialer.
  - 3) While holding the \* Key, reconnect the power.
  - 4) Continue to hold the \* Key down for 10 seconds or more. A tone should be audible in the earpiece of the handset.
  - 5) When the \* Key is released, the unit will acknowledge with a short tone burst that is audible in the earpiece of the handset. Default programming is now loaded and the Dialer is in the cut-through mode (no Dialer activity - digits are passed straight through the Dialer).
  - 6) Go back On-hook.

**3.06** The x23 parameter (see page 43) is used to 'wake up' the Dialer. To 'wake up' the Dialer, simply go off-hook. Enter the program mode by dialing #0\*. After dialing #0\*, a beep should be heard in the receiver. Then dial 523 (wait for beep). Dial 8 (wait for two (2) beeps), then go on hook. The SMarT-1™ Dialer is now configured as follows:

- All Trunks are Loop Start.
- A single tone (or beep) is used to notify the user that the Dialer is functioning.
- There are no Speed Call numbers.
- The Security Access Code is #0\* from a DTMF telephone.

### Action on Dialing

**3.07** At this point, there are some default actions that will occur

when a number is dialed. The paragraphs that follow describe the action that will result when specific digits are dialed. These may be changed later when more detailed programming is accomplished. The paragraphs are structured by listing the dialed digits in bold at the beginning, followed by a description of the action taken by the Dialer.

**3.08 1st Digit 0 and 2nd Digit 1:** This indicates that the call is to an international destination, and, as such, the length or number of digits to be dialed is not known. After the last desired digit is dialed by the user, the Dialer will wait for six seconds before assuming that dialing has been completed. The Dialer will also assume that dialing is completed if a "#" is dialed.

**3.09 1st Digit 0 or 1, 3rd Digit 0 or 1:** This indicates to the Dialer that the call destination is within North America, and, as such, only eleven digits will be dialed. The Dialer assumes that the number is complete after the eleventh digit and does not wait for or recognize any further digits.

**3.10 1st Digit 0 or 1, 3rd Digit NOT 0 or 1:** This indicates to the Dialer that the call is a local area long distance call, and, as such, only eight digits will be dialed. Once again, the Dialer assumes that the number is complete after the eighth digit and does not wait for more digits.

**3.11 1st Digit NOT 0 or 1:** This call is a local call and will be complete after the seventh dialed digit. The Dialer does not wait for more digits.

**3.12 911 and 1411:** If these digits are dialed, the Dialer will assume that the call is complete after these digits. It will complete the call on the DDD Network immediately.

**3.13 All Other:** The Dialer will wait for the timeout period of six seconds after the last digit is dialed before assuming that the number is complete.

#### **Simplified OCC Programming**

**3.14** The programming that follows is a simplified version for immediate change to the default data base loaded in paragraph 3.05 above. It allows the Dialer to be programmed for general use with most OCC/Reseller systems. If the Dialer has never been used before, the steps outlined under paragraph 3.05 above must be accomplished. Then follow the steps listed below:

- 1) By using the DTMF station or Butt-set connected to the subscriber side of any Dialer trunk, go off-hook and dial the Security Access Code, #0\*. A short tone will be sent to the earpiece of the handset (after the \* is dialed) that indicates access to programming mode. Programming parameter entries will be punctuated with acknowledge tones.

- 2) Dial '903'. This string of dialed digits will cause the Dialer to load Default data, thus deleting all previous non-default data.
- 3) At this point, the default types of Trunk and Dialing are Loop Start and DTMF respectively. If other than these types are desired, select the appropriate dialing string:

TRUNK/DIALING TYPE	STRING
Loop Start, Rotary Dialing	5000
Ground Start, Rotary Dialing	5001
Loop Start, DTMF Dialing	5002 (Default Setting)
Ground Start, DTMF Dialing	5003

and dial the selected string on the station. This will change the trunk/dialing data base to the desired type.

- 4) Dial '5238'. This will change the operating mode of the Dialer from the Cut-through mode to the 'Wait for digits' mode. In other words, the Dialer will wait until digits are dialed before sending these digits to the CO rather than immediately passing the digits onto the CO Line.
- 5) Dial '601' followed by the user's three digit area code and then dial '##'. This will enter the user's area code in the data base to be used when the OCC is automatically accessed. For example, if the user's area code was 603, the string would be dialed as:

**601603##**

- 6) Dial '621' followed by the carrier's access number and '##'. The carrier's access number is the telephone number that must be dialed by the user to access the OCC. For example, if the access number is 257-7838, the entry will be:

**6212577838##**

- 7) Dial '622' followed by the user's authorization code for the carrier. This authorization code is the special code used by an OCC to identify, bill, and allow access to the OCC/Reseller's services. For example, if the carrier authorization code for a particular user is 2219876, the string would be dialed as:

**6222219876##**

- 8) To end the programming session, simply hang-up or dial '999', then hang-up (on-hook).

**Note:** This completes the Simplified OCC Programming. For a more detailed description of the programming, refer to the appropriate sections at the rear of this document.

## 4. OPERATION

### INTRODUCTION

**4.01** The descriptions below outline the typical operation of the SMarT-1™ Dialer. They do not include all possible operations or features that can be selected by programming.

### GENERAL DESCRIPTION

**4.02** The SMarT-1™ Dialer controls the dialed access on four trunks simultaneously. The activities on the line are controlled by the information that the installer has entered during programming (see Section 5, page 33). Each of the trunks may be programmed to operate differently, or they may be programmed to be identical in operation.

**4.03** Each trunk of the Dialer is connected in series with the Tip and Ring leads of a standard loop start or ground start, DTMF or rotary telephone line (refer to Figure 4 on Page 9). This line can be connected between:

- A telephone and a central office, or
- A key system line card and a central office, or
- A PBX trunk card and a central office, or
- A telephone and a PBX line card.

**4.04** In any mode except cut-through, the Dialer monitors the line for activity. When the user lifts the handset, the Dialer notes the beginning of an outgoing call. The detailed operation of the Dialer, at this point, depends on the information programmed into the Dialer by the installer. The following paragraphs describe how this programming is used.

### DETAILED DESCRIPTION

#### Options

**4.05** There are several programmable options that may be used to originate a call. These include 'hot line' (dial and cut-through automatically on Off-hook), 'OCC hot line', normal operation, or immediate reconnect to the line. In all cases except the latter, the Dialer will 'split the line' (subscriber pair electrically separated from the Central Office (CO) pair) by use of a relay.

**4.06** Along with the above options, there are two possible Dial Tone options. These are: a) The Dialer will pass the CO generated Dial Tone back to the subscriber so that the normal CO tones are heard, or b) An internally generated Dial Tone is passed back to the subscriber. The internal Dial tone is a single tone that may be used in cases where the Central Office generates non-precise Dial tone.

### Searching

**4.07** The Dialer monitors for rotary or DTMF dialing on its subscriber side and compares any subscriber dialed digits against one of two data bases that may be programmed into the Dialer. This comparison is called "searching". The data base in use is made up of 15 "search tables". After comparison, the Dialer will decide on one of the following actions:

- 1) Call must go on DDD Network.
- 2) Call must go on OCC Network.
- 3) Call is preferred to go on OCC Network, but failing that, will go on DDD Network.
- 4) Call is denied.
- 5) Dialer is "cut-through" (i.e., no dialer activity—digits pass through directly).
- 6) The dialed sequence will access the speed call directory stored in the SMarT-1™ Dialer, and, as a result, it will output the telephone number stored in that location.

**4.08** In the 'wait for digits' mode, all dialed digits are processed through the 'search tables'. The results of the comparison will be a trigger to perform one of the above actions. There are two sets of 15 tables in all and they can be used to compare against up to 15 dialed digits. For example, the first table (one digit table) is checked after the first dialed digit. If a match is found, the searching for the first digit stops. The second table (two digit table) is checked after the second digit, and so on, until a match is found with an action that terminates the comparisons.

**Note:** The two sets of search tables mentioned above are known as the Primary and Alternate search tables. Each trunk in the Dialer may be programmed to use either the Primary or the Alternate search tables for examination of a dialed digit string. Primary search tables (the normal default setting) are assumed in remaining text.

**4.09** Each entry in a search table consists of a group of digits (called for ease of reference, a 'template') that is compared to the dialed sequence along with an additional single digit (called the 'action'). The action is a single digit that represents a specific 'action' to be taken by the Dialer when dialing is completed. The action digits are collected, and, on completion of dialing, are performed according to the programming.

### TEMPLATE DESCRIPTION

**4.10** The 'template' section of a table may consist of ordinary digits or special digits as listed in Table 1 below. The single digits

used for 'actions' and their meanings are listed in Table 2 below. One 'action' digit must be used with each template.

**Note:** MNEM. In the Table below means mnemonic and is used to describe templates in the paragraphs that follow below.

TABLE 1: TEMPLATE DIGITS

DIGIT		DESCRIPTION
0 - 9, *		To be matched against the same digit in the dialed sequence.
#0		Compare against '#'. Compare against '1' or '0'.
DIGIT	MNEM.	DESCRIPTION
#1	1/0	Compare against '1' or '0'.
#4	n	Compare against any digit from 2 through 9.
#9	x	Compare against any digit.

TABLE 2: ACTION DIGITS

DIGIT	DESCRIPTION
0	PREFER ROUTE 0 (PRO)
1	PREFER CALL TO GO ON ROUTE 1
2	PREFER CALL TO GO ON ROUTE 2
3	PREFER CALL TO GO ON ROUTE 3
4	FORCE CALL TO GO ON ROUTE 0 (FR0)†
5	FORCE CALL TO GO ON ROUTE 1†
6	FORCE CALL TO GO ON ROUTE 2†
7	FORCE CALL TO GO ON ROUTE 3†
8	SELECT CALL TO GO ON ROUTE 0 (SR0)††
9	SELECT CALL TO GO ON ROUTE 1††
*	SELECT CALL TO GO ON ROUTE 2††
#0	SELECT CALL TO GO ON ROUTE 3††
#1	DENY
#2	SPEED CALL
#3	DIAL ALL DIGITS THAT USER DIALED AND CUT THROUGH (NO ROUTING)
#4	SECURITY ACCESS CODE
#5	ABSORB WHAT HAS BEEN ENTERED AND CUT THROUGH (BYPASS)
#6	ALL DIGITS HAVE BEEN DIALED IN PHONE NUMBER. AN ACTION MUST BE ENCOUNTERED (e.g., ROUTE SELECTED) BEFORE THE #6 ACTION
#7	DO NOTHING
#8	PREFER DEFAULT ROUTE (x24)
#9	DELETE THIS TEMPLATE FROM SEARCHING TABLE
#C	LIMITED PROGRAM ACCESS CODE FOR SPEED CALL PROGRAMMING BY SUBSCRIBER



**Note:** † These will force the call onto the selected route if possible. If not possible, the call will not be completed. Redial and retry attempts will be directed to the same selected route.

†† These will not dial out the 'select' digits and will start comparisons over again from the first digit.

Dialer begins dialing out upon encountering any of the above search table actions with the exception of #1, #4 through #7, and #9.

### OTHER COMPARISONS

**4.11** In addition to comparing the dialed digits to the search tables, three other comparisons are made. The first digit dialed is checked for a match against the Centrex Access digit. Every digit after the first dialed digit (prior to call completion) is checked to see if it is the 'restart' character (i.e., the restart character allows the user to start dialing again to correct mistakes). Lastly, after the Dialer has finished dialing, any further digits dialed by the user are compared to the 'redial on Route #0' and 'redial on the same route' digits. If a match occurs in this case, the call will be dropped and redialed while the telephone remains off-hook (i.e., the Dialer releases and re-seizes the line).

**4.12** This allows extreme flexibility in the use of the Dialer. It also means that any mode of operation (other than the cut-through mode on initialization) requires some programming.

### ROUTES

**4.13** The four routes (listed in Table 2) are called ROUTE #0 through ROUTE #3. These can be assigned either to the DDD Network or the OCC Network. Each route can be selected by programming the search tables accordingly, and each has its own access method. For example, to access the DDD Network, the user waits for the dial tone and then dials. To access the OCC Network, the user would perform the following steps:

- 1) Wait for dial tone
- 2) Dial the 'access code' (OCC phone number)
- 3) Wait for further dial tone
- 4) Dial the 'authorization code'
- 5) Dial the 'destination number' (called party)

**4.14** All of the above steps can easily be associated with a route and dialed automatically by use of the access control sequences (see 4.25).

**SEARCH EXAMPLES**

**4.15** The following paragraphs describe the typical uses of the search tables when combined with routing data. Not all possibilities are discussed since programming is very flexible. This example presumes that Route #0 is used for the DDD Network and Route #1 is used for the OCC private carrier.

**4.16** The examples associated with these descriptions list the digit to be entered in the template, followed by the action and a description. Digit definition and mnemonic use in the examples is defined in Tables 1 and 2 above.

**EXAMPLE 1: 1+ CALLS TO CARRIER**

TEMPLATE	ACTION	DESCRIPTION
1	5 (FR1)	Any call starting with digit 1 will be forced onto Route #1.
x	4 (FR0)	Don't care; any other first digit will force the call onto Route #0

**4.17** In the example above, FR1 (Force on Route #1) is selected over PR1 (Prefer Route #1) so that if the call fails (say, due to an OCC network problem), the call can only be retried on the same route. The retry is directed to another route only when the 'action' used is PR1.

**EXAMPLE 2: 1+ CALLS TO CARRIER, 1+800 TO DDD**

TEMPLATE	ACTION	DESCRIPTION
1800	4 (FR0)	This is the fourth digit search table. All 1+800 calls will go on the DDD Network.
1 x x x	5 (FR1)	All other 1+ calls will go on Route #1 (OCC).
x x x x	4 (FR0)	After the fourth digit, any other call will go on the DDD.

**4.18** The Dialer makes a pass through the search tables after every digit. Once it finds an explicit match, it stops. Therefore, the entry "1 x x x" stops the search before it arrives at the "x x x x" case. Notice that, in the example above, the Dialer holds off dialing until the fourth digit IN ALL CASES. To cause the Dialer to begin dialing after the first digit of a non 1+ call, example 3 below would have to be programmed.

**EXAMPLE 3: BEGIN DIALING AFTER 1ST DIGIT**

TEMPLATE	ACTION	DESCRIPTION
1	#7 (Nothing)	First digit search table.
x	4 (FR0)	Also in first digit table; this <b>point accessible on non 1+ calls only.</b>
1800	4 (FR0)	Fourth digit table; put call on DDD.
1 x x x	5 (FR1)	All other 1+ calls go to Route #1.

**4.19** If the Dialer is programmed to assume that a 1+ call will go on Route #1, it will begin dialing immediately after the first '1'. If the user, in fact, then dials 1+800, the Dialer will drop the call and use the Route #0 access method (i.e., DDD) instead. This action is covered in Example 4 below.

**EXAMPLE 4: 1+ CALLS TO CARRIER, 1+800 TO DDD**

TEMPLATE	ACTION	DESCRIPTION
1	1 (PR1)	First digit table; Assume Route #1, begin dialing (actually, begins accessing the OCC network).
x	4 (FR0)	Not a long distance number, route over DDD.
1800	4 (FR0)	Fourth digit table; since this action indicates the DDD route, the call will be dropped and restarted on the DDD network.

**4.20** The paragraphs above have covered PRn (prefer route) and FRn (force route). SRn (select route) is different in that the digits dialed to trigger the SRn are absorbed (not dialed out). The preferred method would be to have 'x1' to select Route #0 and 'x2' to select Route #1.

**ADDITIONAL SEARCH INFORMATION**

**4.21** A Speed Call 'trigger' code also exists. All digits dialed up to the speed dial 'trigger' are absorbed. The last one or two digits are used to select a speed call. For example, 11nn could be used to select from 100 speed call entries where the 11 is the 'trigger' and is absorbed, while the 'nn' is the number of the speed call in memory to be dialed (nn = 00 to 99). Sequences can also be denied.

**4.22** The entry in Table 2 on page 15 for digit '#6' called 'ALL DIGITS DIALED' causes an action that tells the Dialer that the user has finished dialing the called party, is ready to dial the 'account code', etc. Before encountering the #6, a previous search table must have selected a route and thus activated an Access Control Sequence (ACS).

**4.23** There are two exception actions. These are the 'cut-through' and 'do nothing' action digits. The 'cut-through' does exactly as it says. Whatever dialing is taking place finishes. The line is then reconnected. Screening stops at the search table containing the 'cut-through' action (#3) and no Access Control Sequence is used. This action will quite often result in incompleting calls as only a few digits may have been dialed. It is not recommended for general use. The 'dial and cut-through' action will cause the SMarT-1™ to begin dialing, reproducing the user dialed digits until it catches up with the last entry dialed, and then cut through. This method will access the DDD Network in most applications and may be used instead of the Route #0 in the above examples. However, once a call has been made in this manner, it may not be redialed. The method is not recommended for Centrex applications, or applications that require redialing or DTMF to rotary conversions.

**4.24** The 'do nothing' action allows the building of templates that match to any digit. This action stops the searching process until the next digit.

#### ROUTE SELECTION

**4.25** There are six groups of data that control the route selection (or define the access method). These consist of the destination, access, authorization, account, Centrex numbers, and the Access Control Sequence (ACS). These are defined as:

- 1) **DESTINATION NUMBER:** The destination number is the called party number and is dialed by the user (1 to 23 digits).
- 2) **ACCESS NUMBER:** This is the telephone number of the OCC, and is dialed by the SMarT-1™ unit (1 to 34 digits).
- 3) **AUTHORIZATION NUMBER:** The authorization number is the user's special code for access to the Carrier services and is dialed by the Dialer (1 to 34 digits).
- 4) **ACCOUNT NUMBER:** The account number may be used to identify the calling party and is also dialed by the user (1 to 23 digits).
- 5) **CENTREX NUMBER:** The Centrex number is the sequence usually used to access the desired Centrex service (1 to 34 digits).
- 6) **ACCESS CONTROL SEQUENCE (ACS):** The ACS is a sequence of codes that instruct the Dialer on the details of accessing a particular route. These details include such items as 'what to dial first', 'when to wait for dial tone', etc.. The codes and their

meanings used in the construction of an ACS are listed in Table 3 below. This sequence may contain up to 34 characters.

**TABLE 3: ACCESS CONTROL SEQUENCE (ACS) CODES**

CODE	DESCRIPTION
1,0	Dial that digit.
#0*	Dial a '*'.
#00	Dial a '#'.
#01	Dial a '#' if the last dial digit was not '#'.
#02	Wait for account code (does not dial account code).
#2ab	Pause. Continue after pause if a = 5. Fail to x58, x78 if a = 0.
#3ab	High tone (570-680 Hz tone detector).
#4ab	440 Hz tone detector.
#5ab	480 Hz ringback tone detector.
#6ab	400 Hz tone detector.
#7ab	350-620 Hz energy detector.
#8ab	Precise dialtone/425 Hz detector.
#9ab	Wait for Not On Network (NON) tone.
#Dab	DTMF Detector
2	Dial the destination number.
3	Dial the access number.
4	Dial the authorization code.
5	Dial the account code.
6	Dial the Trunk number (1-4 on the SMarT-1™ Dialer, 1 or 2 on the SMarT-1A™ Dialer).
7	Cut through. Reconnect line. Dialing completed.
8	Change to DTMF signaling.
9	Dial the Centrex access code (may be different for each Route).
##	End (used while programming).

TABLE 4a: DETECTOR/TIMEOUT (a) CODES

a	MIN. TONE DURATION	a	MIN. TONE DURATION
0	MIN. Fail to x58 or x78	5	MIN. then continue
1	200ms Fail to x58 or x78	6	200ms then continue
2	400ms Fail to x58 or x78	7	400ms then continue
3	1.0 Fail to x58 or x78	8	1.0 then continue
4	2.55 Fail to x58 or x78	9	2.55 then continue

TABLE 4b: DETECTOR/TIMEOUT (b) CODES

b	TIMEOUT/TONE NOT RCVD.	b	TIMEOUT/TONE NOT RCVD.
0	0 Seconds	6	12 Seconds
1	2 Seconds	7	14 Seconds
2	4 Seconds	8	16 Seconds
3	6 Seconds	9	18 Seconds
4	8 Seconds	*	20 Seconds
5	10 Seconds		

**4.26** For example, the standard procedure for accessing the DDD is:

- 1) Wait for dial tone
- 2) Dial the destination number
- 3) Wait for call connection, then talk

This can be accomplished by programming the ACS with '#80327'. This group of digits translates to:

- 1) **#803** Wait for minimum duration of precise dial tone for up to 6 seconds
- 2) **2** Dial destination number
- 3) **7** Cut through

Since the dialer starts in the split condition, the cut through code must be entered to restore the connection so that talking can occur.

**4.27** An example for access to a typical carrier may require programming as outlined by the digits '#8033#625427'. These translate to:

- 1) **#803** Wait for minimum duration of precise dial tone for up to 6 seconds
- 2) **3** Dial access number
- 3) **#625** Wait for 400 ms of tone from OCC for up to 10 seconds
- 4) **4** Dial the authorization code
- 5) **2** Dial the destination number
- 6) **7** Cut through

The arrangement above allows for all sorts of combinations. In order to appreciate the range of possibilities, the five strings that can be dialed are named to coincide with typical applications. These names are really general purpose and have the properties as outlined in Table 5 below.

**TABLE 5: GENERAL PURPOSE STRINGS/NUMBERS**

STRING	PROPERTY
DESTINATION	First digits dialed by the user; passed through the search tables.
ACCOUNT	Second item dialed by the user; can be substituted; can hold up dialing.
ACCESS	Entered at programming time.
AUTHORIZATION	Entered at programming time.
CENTREX	Entered at programming time.

**4.28** It is evident that these strings can be assembled in any order in the ACS. They do not have to function in the manner that their titles suggest. For instance, a private carrier network requires an authorization code of 1234xxx5678, where the xxx is a code entered by the user to identify the account. 1234 could be assigned to the authorization string, 5678 to the Centrex string, and the route programmed to accept a three digit fixed length account code. Then part of the ACS would be programmed with '459' that translates to 'Dial authorization, dial account, and dial Centrex'.

#### **SPEED CALLS**

**4.29** The speed call entries have two associated parameters. These are the key and the route override. The key is a single digit that can selectively block dialing to any line. Note that all lines share the same speed call directory, and that any lines can be blocked from dialing any speed call number. The route override can force the call onto any of the four routes, or process the call through the search tables, or force the call to go out without any route selection (transparent).

#### **NOT ON NETWORK (NON) CHECKING**

**4.30** Some networks return specific tones if the number requested is 'Not on Network'. The ACS has a programmable parameter that, if set, will make the Dialer wait for the programmed number of seconds, and, if a tone is detected, the call will be dropped. The destination number will then be dialed using the Route #0 access method. In addition, the destination string is automatically entered in the search tables as FR0 (Force Route 0), along with an expiry date tag. The date tag can be from 0 to 90 days in increments of ten days. Once

entered, all entries in the search tables that have expiry tags are decremented at midnight. Those tags that return to zero on decrement are cancelled. This means that, after the programmed number of days, the search tables would return to their original state.

**4.31** There is no parameter in the programming that controls DTMF to pulse conversion. If the Central Office type is programmed as rotary dialing, then any route access will start the call with rotary dialing. The ACS can have a 'change to DTMF' code that will instruct the Dialer that the signalling to the private carrier is to be performed in DTMF. Calls that have been 'cut-through' or 'dial and cut-through' due to a searching action will not perform DTMF to pulse conversion.

**4.32** Paragraphs 4.30 and 4.31 illustrate why Route #0 is recommended for use in accessing the DDD Network.

#### CALL RECORDS

**4.33** Every time a call is terminated, the Dialer will output a call record to the Computer (RS-232) port. This output consists of a string of ASCII characters that describe the call. The format for the output is fixed so that the port can be connected to either a printer or to an external processor. The latter can use the data to generate statistics or call costing data. The printout can label the routes that are selected by using the appropriate programming.

#### CENTREX OPERATION

**4.34** If the Centrex access digit is programmed, the Dialer will recognize the 'outside line' access code, routing all internal calls transparently. Note that all of the ACSs should be programmed to include the 'dial the Centrex' code. Each route has a separate Centrex string that would allow one to access WATS or FX groups, instead of regular trunks.

#### CALL RECORDING OPERATION

**4.35** The SMarT-1™ Common Carrier Access Dialer and Call Controller can easily be programmed to send a printable call record to a variety of electronic storage devices. The call record indicates the originator of the call, the call duration, the dialed numbers, and other data.

**WARNING:** THIS CALL RECORD SHOULD NOT BE CONSIDERED A PERFECT RECORD OF THE CALL, NOR SHOULD IT BE CONSIDERED AS A LEGAL ENTITY. THERE ARE MANY CASES IN WHICH THE CALL RECORD PRODUCED BY THE SMarT-1™ DIALER MAY DIFFER FROM THAT PRODUCED BY THE OCC.



### Connecting a Storage Device

**4.36 TERMINAL:** Almost any CRT or paper-based (e.g., Silent 700† or Brother†) terminal may be connected to the SMarT-1™ unit. Using a terminal as a storage device also has the extra advantage in that the terminal keyboard may be used to program the Dialer (refer to Programming Section). When connecting the terminal, the user should be aware that the Dialer is wired as a DCE, so that a normal RS-232 Cable can be used. Refer to the WIRING CONSIDERATIONS on page 30. Telephone digit programming may be used to select the Baud rate and other features. For example, 300 Baud can be chosen as the Dialer operating rate by entering the following from any line of the Dialer:

#### GO OFF-HOOK, THEN DIAL:

**#0\*** To enter programming mode.

**0062** To select 300 Baud.

**999** To exit programming.

**Note:** Once the default data has been loaded, the Dialer is automatically set for 1200 Baud.

**4.37 PRINTER:** Almost any serial printer may be connected to the Dialer. The printer allows the user to maintain a permanent (depending on amount of paper) record of the calls placed through the Dialer. Connection of the printer is made via normal RS-232 Cable to the same port that may be used for a terminal. The Dialer must be programmed for the printer baud rate desired. This is accomplished by using one of the four Dialer programming methods.

**4.38** Some printers require a modified data stream to handle exceptions (such as Line Feed). There are three main techniques that are used to modify the data stream. These are:

- 1) The printer may manipulate the Clear to Send (CTS) and Data Terminal Ready (DTR) wires.

**Note:** Method 1) above will not work with the SMarT-1™ Dialer. See WIRING CONSIDERATIONS on page 31.

- 2) The printer may transmit XOFF (DC3) to stop the data source, and XON (DC1) to restart the data source. The Dialer accepts this protocol and requires no additional programming to enable this feature.
- 3) The SMarT-1™ Dialer may be configured to add a variable number of NULLS (no character spaces) after the carriage return function, anticipating the time required by the printer. Use Program parameter 007n to enter the required number of nulls.

† Silent 700 is a Trademark of Texas Instruments  
Brother is a Trademark of Brother International Corp.

**Note:** The XON/XOFF feature is provided to cover cases where the printer must slow the data stream down to handle functions such as carriage returns and line feeds. It is not intended for use in handling "paper out" and "off line" pauses. The print buffer that is on board the Dialer contains only three call records at any one time. The size of this buffer is adequate for most slow speed printers. It is not adequate for storing data during long pauses such as may arise when the paper runs out on the printer.

**4.39 CALL COSTING UNIT:** Most of the call costing units are nothing more than modified personal computers that estimate the cost of the calls made. Some of these units also provide statistics on traffic. If the software of the Call Costing Unit is compatible, the Dialer may be connected to the unit via a normal RS-232 cable. If the unit has multiple inputs, multiple Dialers may be connected.

**4.40 CONCENTRATOR:** If a site has a lot of Dialers, it may be economical to funnel the output of several Dialers through an electronic "concentrator" into a single printer or call costing unit for call recording.

**4.41** When using a concentrator, the call record from each Dialer must be made to appear individual or different. String 602n can be programmed (using ASCII Codes) to print a unique three character field for each Dialer. For example, Dialer #1 at a site may be programmed:

**602 202331##**

which will cause the printer to print "#1" at the end of each line. The second Dialer may then be programmed:

**602 202332##**

which will cause the number "#2" to be printed at the end of each line. The three character field set by 602 is printed in both the MITEL Format and SMarT-1™ Format discussed below.

**Note:** If the Dialers are programmed using the "cloning" technique, ensure that 602 is modified after cloning. If not, the Clone Master and the Clone Slave will have the same "name".

#### **CALL RECORD FORMAT**

**4.42** The Dialer can print call records in one of two formats. These formats are the MITEL Format and the SMarT-1™ Format. Selection of the appropriate format is made by programming 009n. The MITEL Format is very similar to the call record that was pioneered by MITEL Inc. for use in its line of small PABXs. The call record is up to 86 characters in length and includes all of the information about a call.

The SMarT-1™ Format is a new format that was developed specifically for this product. It summarizes the call completely within 80 columns and provides an easy to read printout. In either case, the call record will show the digits that are dialed by the user and not the dialer-assembled digits as in an Access Control Sequence.

**MITEL Format**

**4.43** Since this format was developed for use in PABX applications, there are fields that only pertain to transferred calls. The SMarT-1™ has no use for this information and, as a result, these fields are left blank. Otherwise, the format is very similar to the call record produced by MITEL PABXs.

**4.44** Several call costing machines can process the original MITEL Format. For more information on tested systems, call MITFI.

The record is 86 characters long with the following fields:

- **M** - Month/Day
- **B** - Start time (BB.BB means that the clock is wrong)  
(Note the period instead of a colon)
- **C** - Call duration
- **IIII** - Incoming line
- **D** - User dialed digits
- **T** - Denied
- **S** - Speed dialed
- **L** - Line number
- **R** - Route (8 = Internal in Centrex mode)
- **A** - Account code
- **N** - System identification

The above named fields are printed in a line as below:

MM/MM BB:BB CC:CC:CC IIII DDDDDDDDDDDDDDDDDDDDD TSLRR AAAAAAAAAA NNN

where the fields are as described in Table 6:

**4.45** Each line is ended with a CARRIAGE RETURN (ASCII 13) and LINE FEED (ASCII 10) and a programmable number of NULLS (ASCII 0). All alphabetic fields are in upper case. The dialed number and the dialed account code fields will be numbers 0 through 9, \*, and #.

TABLE 6: MITEL CALL RECORD FORMAT FIELDS

FIELD	COLUMN	NR. CHARS.	FORMAT MEANING
M	1	1	"SPACE"
	2-6	5	MONTH; "/"; DATE
	7	1	"SPACE"
B	8-12	5	HOURS; ":"; MINUTES (This is the time of the start of call rounded out to nearest minute) See note 1.
C	13-14	2	"SPACES"
	15-22	8	HOURS; ":"; MINUTES; ":"; SECONDS (Call duration)
I	23	1	"SPACE"
	24-27	4	"Tn00" (Printed on incoming calls only; blank on outgoing calls. n is the Line Number [1-4])
D	28-33	6	"SPACES"
	34-56	23	This is the number that was dialed as the "destination". See note 2.
T	57-59	3	"SPACES"
	60	1	"T" if the call was denied; "SPACE" otherwise.
S	61	1	"S" if the call was speed called; "SPACE" otherwise.
L,R	62-65	4	"Tn0r" (Printed on outgoing calls only; blank on incoming calls. n is the Line Number [1-4]. r is the route chosen [8 = no route].)
A	66-72	7	"SPACES"
	73-84	12	Dialed account code. See note 3.
N	85-88	3	System Identification (first three characters of parameter 602).

See NOTES on next page.

**Note:1.** Time Display Field: If the separating character in the start of call field is a period (.), the time has not been programmed into the Dialer. Use parameter 980 to program the time. When a Dialer is powered on, it will continue to use the last time that was programmed (time at power down) but will mark the call record with a period (.). If the loss of power is only a few seconds, it will not significantly affect the timekeeping.

**Note:2.** Dialed Number Field: This field contains the phone number that was dialed as the "destination". The number of digits in this field will be set by: 1) The search tables. If a #6 action ("enough digits") is encountered, the "destination buffer" is marked as full. Only those digits so far received will be printed, or 2) An inter-digit timeout. If the user pauses while dialing, exceeding the inter-digit pause time, the "destination buffer" is marked as full. Only those digits received so far will be dialed.

If there is further dialing, these digits may be collected in the "account code". If Centrex mode is being used, the user-dialed Centrex Access Code (usually a "9") is not printed. The way to tell internal calls from external calls is to look at the route character (0-7 means a route was used, which probably dialed another "9" for the user; 8 means that the call was not routed, and the Dialer only forwarded the digits as displayed).

If a speed call is accessed, the speed call number will appear in this field. The sequence that was dialed to get the speed call (i.e., \*11) is NOT displayed. Denied calls are marked with a "T" in column 59.

**Note:3.** Dialed Account code: This field shows the digits that were dialed by the user for the account code. If the Dialer substituted a "dummy account code", this field still shows the user-dialed digits (not the "dummy"). It can be told by the number of digits that the "dummy" was substituted. This is done intentionally to allow monitoring for account code fraud attempts.

Only the first 12 digits are displayed, even though the SMarT-1™ unit can handle 23 digit account codes.

#### **SMarT-1™ Format**

**4.46** Most of the explanations noted above also apply to the SMarT-1™ Format with the exception that the "R" field is in ASCII instead of Numeric. The format was developed to allow the printing to fit within 80 columns and to take advantage of the ability of the Dialer to print ASCII (see note 4 below). A typical line entry would appear as:

MM/MM BB:BB CC:CC:CC DDDDDDDDDDDDDDDDDDDDD TSL RRRRRRAAAAAAAAAA NNN

where the fields are as described in Table 7 below:

**TABLE 7: SMarT-1™ CALL RECORD FORMAT FIELDS**

FIELD	COLUMN	NR. CHARS.	FORMAT MEANING
M	1-5	5	MONTH; "/"; DATE
	6	1	"SPACE"
B	7-11	5	HOURS; ":"; MINUTES (This is the time of the start of call rounded out to nearest minute) See note 1.
	12-13	2	"SPACES"
C	14-21	8	HOURS; ":"; MINUTES; ":"; SECONDS (Call duration)
	22	1	"SPACE"
D	23-45	23	This is the number that was dialed as the "destination". See note 2.
	46-48	3	"SPACES"
T	49	1	"T" if the call was denied; "SPACE" otherwise.
S	50	1	"S" if the call was speed called; "SPACE" otherwise.
L	51-52	2	"Tn" (n is the Line Number [1-4].)
	53	1	"SPACE"
R	54-59	6	Up to six character route name. See note 4.
A	60-71	12	Dialed account code. See note 3.
	72	1	"SPACE"
N	73-75	3	System Identification (first three characters of parameter 602).

**Note:4.** Name of route: This field is up to six characters in length. Normally, the name of the route chosen is printed. The name of each route can be programmed into the Dialer by entering 6x0, where x is 1+ the route number. For instance, the following may be common:

```

610 41542654## "AT&T"
620 4D4349## "MCI"
630 535052494E54## "SPRINT"

```

Any ASCII character may be inserted in a 6x0 string (although only printable characters are recommended). If the call was sent "no route" (i.e., without being routed by the Dialer), the string "THRU" will be printed. For an incoming call, the string "INWARD" will be printed.

**EXAMPLES**

**MITEL FORMAT**

MM/MM	BB:BB	CC:CC:CC	IIII	DDDDDDDDDDDDDDDDDDDDDDDD	TSLLRR	AAAAAAAAAAAA	NNN
11/02	07:15	00:00:03	T100				NTW
11/02	07:15	00:00:02		5926032	T100		NTW
11/02	07:15	00:00:04		5926	T100	501	NTW
11/02	07:15	00:00:28		#0*	T100		NTW
11/02	00:00	07:15:28		#0*	T100		NTW
11/02	21:15	00:01:37		13153931212	T101		NTW
11/02	21:19	00:05:02		18064553325	ST401	4400	NTW

- Note:**
- 1) Line 1 above indicates an incoming call on Line 1.
  - 2) Line 2 shows a normal outgoing call on Line 1. It lasted two seconds and was user dialed. The call went on Route #0 (usually the DDD network).
  - 3) Line 3 indicates an incorrect outgoing call on Line 1. It lasted four seconds and appears that whoever programmed the call had put something wrong in the fourth digit search table (804). Note that seven digits were dialed, but some of the digits were recorded in the account code. This line indicates that the Dialer should be reprogrammed.
  - 4) Line 4 shows an outgoing call that lasted 28 seconds. By looking at the dialed digits, we can see that this was, in fact, a programming session as shown by the "#0\*" dialed digit printout.
  - 5) Line 5 of the examples shows a call of an extremely long duration after setting the time by programming parameter 980. This may occur and should only happen once after setting the time.
  - 6) Line 6 is an example of an outgoing call that lasted one and a half minutes. It went over Route #1 (normally other than DDD).
  - 7) Line 7 is an example of a five minute speed dialed call over Line 4 with a user entered account code of "4400".

**SMarT-1™ FORMAT**

MM/MM	BB:BB	CC:CC:CC	DDDDDDDDDDDDDDDDDDDDDDDD	TSLL	RRRRRRRAAAAAAAAAAAAA	NNN
01/01	00:09	00:00:05	14049602327	T1	AT&T	SMT
11/02	00:09	19:21:25	#0*	T1	AT&T	SMT
11/02	07:16	00:00:04	911	T1	AT&T	SMT
11/02	07:17	00:00:11	959255	T1	AT&T	SMT
11/02	07:18	00:00:17	5926032	T1	ROUTED	SMT
11/02	07:18	00:00:04	9	T1	INWARD	SMT
11/02	07:19	00:00:11	5922122	ST1	AT&T	SMT
11/02	07:20	00:00:05	411	T T1	AT&T	SMT

**Note:** 1) Line 1 is a five second call. The time has not yet been set. It was sent via route #0.

2) Line 2 was a programming session to probably set the time. Note the incorrect 'duration'.

3) Line 3 was a test of the '911' case. It was sent via route #0. Note that the programmer must have changed the default that would have routed 911 transparently.

4) Line 4 was an incomplete call. The Dialer has no way of determining that the call was not completed. This must be deduced from that fact that only six digits were dialed.

5) Line 5 was a normal (7 second) telephone call on Line 1 at 7:18 AM. The programmer has labeled this route 'ROUTED' by use of 620.

6) Line 6 was an incoming call that lasted four seconds after answer. Either the local or the distant party dialed a 9.

7) Line 7 was another normal call routed via the Telco.

8) Line 8 is an example of a denied call. The duration is the time from off-hook to on-hook.

**WIRING CONSIDERATIONS**

**4.47** The SMarT-1™ Dialer uses a subset of the RS-232 cable for communications with a printer or a terminal. Contemporary devices will function properly with the interface. Only pins 1, 2, and 3 of the RS-232 cable are used by the Dialer.



- 4.48** Pin 1 is the ground for the Dialer. The wire is connected to pin 7 of the connector and to the grounding bolt. If any of the lines are Ground Start, there may be moderate (0.5A) ground currents. To prevent this current from entering the user's terminal or printer, ensure that the ground bolt is connected to a good earth ground.
- 4.49** Pin 2 is the data input to the Dialer. Any voltage from +0.5 to +30V is considered as high while any voltage from -0.5 to -30V is considered as a low.
- 4.50** Pin 3 is the data output from the Dialer. The transmitted high level is from +3 to +8V while the low is from -12 to -14V into an open circuit. There may be up to 1 Volt of 60 Hz noise superimposed on the logic level. The output impedance of this line is  $1.5K\Omega \pm 5\%$ .
- 4.51** Pin 4 is connected to Pin 5. This causes the RTS to be echoed back to the CTS (request to send echoed to clear to send).
- 4.52** Pin 6 is connected to pin 8 and, in turn, to pin 20. This echoes the DTR (data terminal ready) back to the CD (carrier detect) and the DSR (data set ready).
- 4.53** These lines will allow direct connection of the Dialer to a terminal using a one to one cable. If the desired printer can also connect directly to the terminal, it can be connected to the Dialer by use of a "NULL MODEM" cable. This only involves pins 1, 2, and 3.

---

## 5. DETAILED PROGRAMMING

### INTRODUCTION

**5.01** There are four ways to enter data into the Dialer: These methods are listed below.

#### PROGRAMMING METHOD 1

##### Terminal or Computer

**5.02** The Dialer may be easily connected to a personal computer via the RS-232 port, and, with an appropriate program, be completely programmed by responding to a series of questions and prompts presented by the personal computer. If a personal computer and a program are unavailable, the Dialer may be connected to a 'dumb' terminal' via the RS-232 port, and, by entering data, be programmed via this terminal. The default program access code for this method is <CR>.

#### PROGRAMMING METHOD 2

##### DTMF Telephone

**5.03** The Dialer also has a manual entry mode. Programming is accomplished by keying DTMF sequences on a DTMF telephone. The tones may be on either side of the trunk interface (i.e., remote or local programming). For example, Trunk #2 may be configured as Ground Start by dialing "2 0 0 3". The default program access code for this method is #0\*.

#### PROGRAMMING METHOD 3

##### Tandem Mode

**5.04** The Dialer may be remotely programmed by using a personal computer or a dumb terminal, and a second Dialer, both remotely located. The remote Dialer will dial up and access the Dialer to be programmed. To the user, this method appears identical to programming Method 1 with the exception that the default program access code is #0\*.

#### PROGRAMMING METHOD 4

##### Cloning

**5.05** Several Dialers can be programmed to operate identically. This can be accomplished by "cloning". One Dialer is programmed by any of the methods above. The other Dialers are "cloned" by connecting their computer ports together. The data exchange takes less than five seconds, and is initiated by dialing an access code from a set plugged into the Dialer unit whose program is to be copied.

**5.06** Several other techniques may be used and are derivatives of the above. For instance, a cloned unit may have a few parameters changed via method 2. The time saved, compared to complete programming, is substantial.

**5.07** An additional feature is an "auto-answer" mode which, if enabled, allows remote programming of an unattended Dialer while maintaining the security of unauthorized access via a series of parameters. There is also a separate limited access code for subscriber entry of speed calls.

#### **DETAILED PROGRAMMING INSTRUCTIONS**

**Caution:**

Consideration should be given to the programming of **411** and **911** numbers. This is mentioned because of concern that the possibility of having the 411 or 911 codes programmed to be non-functional. In some geographic locations, this consideration extends to '0'. Test the Dialer thoroughly for the correct operation of these numbers after installation and programming.

#### **METHOD 1**

**5.08** The Dialer, in all cases, is simple to program. The programming consists basically of two steps. Step one is to put the Dialer into the programming mode. Step two is to enter the programming information by using one of the four methods previously mentioned.

**5.09** If Method 1 is the selected data entry method, the computer, attached to the Dialer via the Computer (RS-232) port, will present the user with screens of information. These screens may be easily modified by following the instructions also included on the screen. The computer will automatically communicate with the SMarT-1™ Dialer by using ASCII characters.

#### **ASCII Compatible Terminal**

**5.10** A second procedure under programming method 1 allows the user to program the SMarT-1 Dialer by using an ASCII compatible 'dumb' terminal. It requires no program to provide screens of information, but has the advantage of visual feedback for the programmer, as well as, access to the "data confirmation" mode. The reference to 'dumb' terminal means that there are no programs resident to make it 'smart' such as a personal computer.

**5.11** This method requires an ASCII terminal such as a DEC VT-50† or DEC VT-100† (or compatible unit). If the terminal has an RS-232 port output and can be connected to the Dialer via an RS-232 (NULL MODEM) cable, in most cases, the terminal will support this procedure.

† VT-50/VT-100 are Trademarks of Digital Equipment Corporation

**5.12** The Dialer will accept input from the terminal as follows:

- 1) Characters are 0 through 9 and A through F.
- 2) Characters a through f are converted to characters A through F.
- 3) Characters X, x, 999, and <ESC> are used to exit the program mode.
- 4) Characters \* and a are the same as character A.
- 5) Characters #, B, <LF>, <CR>, <SPACE>, <PERIOD>, <COMMA> and <HYPHEN> are all considered to be the character #.
- 6) **ALL OTHER CHARACTERS ARE IGNORED.**

**5.13** The Terminal and the Dialer must be set to the same Baud rate (the default rate for the Dialer is 1200) with no parity, eight bits per character with one stop bit and bit 8 sense set to space. The terminal must operate on-line in full duplex mode. The Dialer must already have been \* initialized at least once.

**5.14** Once the Dialer has been powered up, enter the security code. The terminal security code is defaulted to <CR> (carriage return). This will cause the Dialer to display a sign-on message similar to:

```
REV nn ENTERING PROG. MODE
>
```

**5.15** The field 'nn' in the example above is the Revision number of the software that is contained in the Dialer.

**5.16** Once this display appears on the screen, the Dialer can be programmed. An example of a simple programming session is included below. The left hand column shows the screen with the operator keyed information included in brackets []. This is done so that the reader will not become confused with the Dialer responses. The right hand column includes any comments or notes for the particular line.

```
REV nn ENTERING PROG. MODE
```

```
>[902]
```

Enter "data confirmation" mode (display memory mode).

```
>[801] 1#7*#7#90
```

Display the contents of the 801 search table.

```
>[907]
```

Re-enter normal programming mode.

```
>[801] 1#9##]
```

Delete the first entry in 801 (#9 = delete).

```
>[902]
```

Enter data confirmation mode.

```
>[801] *#7#90
```

Display contents of 801.

```
>[999]X or >[ESC]
```

Exit programming.

**Note:** Since this is operation with a dumb terminal, the contents of search tables will be displayed as one long string. It is up to the user to determine where the actual string entry ends or begins. This is accomplished by counting from the start of the Dialer display for the required number of characters particular to a search table.

**5.17** If an invalid entry is made, the terminal will display a '?' and proceed to the next line with a new prompt. If the Dialer is left in the programming mode for more than a minute without making an entry on the terminal, a warning will be displayed saying that 60 seconds are left before exiting.

**5.18** Further programming is accomplished by reading the applicable sections under programming Method 2 and applying this information by use of the Terminal keyboard.

## METHOD 2

**5.19** The following paragraphs deal with the programming of the Dialer from a telephone set. **All of the character sequences are identical to those used in the data exchange between the Dialer and the computer when using Method 1.** These paragraphs will allow a user that is conversant with computer programming to fashion any kind of 'up-load', 'down-load', or interactive control program.

**Caution:**

Consideration should be given to the programming of 411 and 911 numbers. This is mentioned because of concern that the possibility of having the 411 or 911 codes programmed to be non-functional. In some geographic locations, this consideration extends to '0'. Test the Dialer thoroughly for the correct operation of these numbers after installation and programming.

**5.20** Before using the Dialer for the first time, a default base of data must be loaded into the unit by a special programming mode. This is accomplished by the procedure outlined below:

- 1) Connect a DTMF telephone set to Line 1 of the unit.
- 2) Disconnect the power from the Dialer.
- 3) Using the telephone set, go off-hook. Push and Hold the \* Key.
- 4) While holding the \* Key, power the unit up.
- 5) Continue to hold the \* Key for ten seconds or more.
- 6) Upon release of the \* key, the unit will acknowledge with a short tone burst, audible in the earpiece. Default programming is now loaded and the Dialer is in the cut-through mode.

7) Place the DTMF telephone set on-hook.

**5.21** The Dialer is now configured as:

- All trunks loop start
- A single beep is used to notify the user that the Dialer is functioning
- There are no speed call numbers in the "700" speed call tables
- The program security access code is #0\*

### **Entering Programming Mode**

#### **First Time (New Dialer)**

**5.22** If this is the first time that the Dialer is to be programmed, a special method is required to put the Dialer into the programming mode. This method is outlined by the steps listed under paragraph 5.20 above.

**5.23** After completing the steps outlined in paragraph 5.20, the first entry must be the security access code #0\* so that the user may continue with the programming steps under 'Data Area' below.

#### **Other Than First Time**

**5.24** To enter the programming mode, enter the security access code that was used in paragraph 5.23 above or #0\* if default code is used.

### **ENTERING DATA**

**5.25** There are three distinct types of data that may be entered. These are PARAMETERS, STRINGS and SEARCH-TEMPLATES.

- 1) PARAMETERS consist of a four digit sequence where the first digit specifies the data area to be programmed, the next two digits specify the parameter to be programmed, and the fourth digit selects the specific information of interest such as number of seconds to wait, number of lines per page, etc.. In the case of the first digit of the four digit sequence, the meaning is:

**0** = System Wide Data and Printer Related Data.

**1** = Parameters relating to Trunk 1, Route #0, or Alternate Route # 0.

**2** = Parameters relating to Trunk 2, Route #1, or Alternate Route # 1.

**3** = Parameters relating to Trunk 3, Route #2, or Alternate Route # 2.

**4** = Parameters relating to Trunk 4, Route #3, or Alternate Route # 3.

**5** = Entry of data that is common to all four Trunks, Routes, or Alternate Routes. For example, '502t' will program the DTMF Dialing Rate for all four trunks.

- 2) STRINGS consist of a three digit prefix with the first digit always a '6' or '7', followed by an arbitrary number of digits (24 maximum), and ending with '##'.
- 3) SEARCH TEMPLATES consist of a three digit prefix with the first digit always an '8', followed by a sequence of digits. The three digit prefix selects the search table for data entry. The entry process is closed by entering a '##'.

#### Parameters

**5.26** Table 8 below lists the four digit parameter codes for the Dialer. The letter 'x' or 'r' in the code represents a single user selectable character for entry to select a specific specification of the parameter. The letter 't' represents a digit for entry.

**5.27** After programming is completed, the unit should be checked to insure programming has accomplished the desired dialing characteristics and activities. Ensure that the new program access code (if used) functions and then delete the default program access codes as follows:

#### GO OFF-HOOK

#### ENTER PROGRAM MODE using new access code

Delete the default accesses as follows:

**803** #0 0 x #9

**804** #9 #0 0 x #9

#### HANG UP

**5.28** If default program access codes are to be used, do not perform the above deletions.

TABLE 8: PARAMETERS

FIRST DIGIT = 0 SYSTEM WIDE DATA																																						
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION																																				
000t	1	Use 10 or 100 Speed Call Numbers, where: 0 = use 10, 1 = use 100																																				
001t	0	Reorder Tone, where: 0 = 400 Hz, 180 ipm, 1 = 400 Hz, Continuous																																				
005t	0	Number of Trunk to monitor for SMDR where:  <table border="1"> <thead> <tr> <th>DIGIT</th> <th>ALLOWED TRUNKS</th> <th>DIGIT</th> <th>ALLOWED TRUNKS</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ALL</td> <td>8</td> <td>TRUNK 4</td> </tr> <tr> <td>1</td> <td>TRUNK 1</td> <td>9</td> <td>TRUNKS 1,4</td> </tr> <tr> <td>2</td> <td>TRUNK 2</td> <td>*</td> <td>TRUNKS 2,4</td> </tr> <tr> <td>3</td> <td>TRUNKS 1,2</td> <td>#</td> <td>TRUNKS 1,2,4</td> </tr> <tr> <td>4</td> <td>TRUNK 3</td> <td>C</td> <td>TRUNKS 3,4</td> </tr> <tr> <td>5</td> <td>TRUNKS 1,3</td> <td>D</td> <td>TRUNKS 1,3,4</td> </tr> <tr> <td>6</td> <td>TRUNKS 2,3</td> <td>E</td> <td>TRUNKS 2,3,4</td> </tr> <tr> <td>7</td> <td>TRUNKS 1,2,3</td> <td></td> <td></td> </tr> </tbody> </table> NOTE: The C, D, and E entries above may be made from a terminal.	DIGIT	ALLOWED TRUNKS	DIGIT	ALLOWED TRUNKS	0	ALL	8	TRUNK 4	1	TRUNK 1	9	TRUNKS 1,4	2	TRUNK 2	*	TRUNKS 2,4	3	TRUNKS 1,2	#	TRUNKS 1,2,4	4	TRUNK 3	C	TRUNKS 3,4	5	TRUNKS 1,3	D	TRUNKS 1,3,4	6	TRUNKS 2,3	E	TRUNKS 2,3,4	7	TRUNKS 1,2,3		
DIGIT	ALLOWED TRUNKS	DIGIT	ALLOWED TRUNKS																																			
0	ALL	8	TRUNK 4																																			
1	TRUNK 1	9	TRUNKS 1,4																																			
2	TRUNK 2	*	TRUNKS 2,4																																			
3	TRUNKS 1,2	#	TRUNKS 1,2,4																																			
4	TRUNK 3	C	TRUNKS 3,4																																			
5	TRUNKS 1,3	D	TRUNKS 1,3,4																																			
6	TRUNKS 2,3	E	TRUNKS 2,3,4																																			
7	TRUNKS 1,2,3																																					
006t	4	Baud rate of printer, where: 2 = 300 Baud 3 = 600 Baud 4 = 1200 Baud 6 = 9600 Baud 7 = 19200 Baud																																				
007t	2	Number of nulls after a CARRIAGE RETURN <CR>.																																				
008t	1	Print out IC calls, where: 0 = no 1 = yes																																				
009t	2	Print Format, where: 0 = Print off 1 = MITEL Format 2 = SMarT Format																																				
010t	9	Route to monitor, where: 0 - 3 = Route number (4 - 7 = Alternate routes) 8 = Routed calls and outside Centrex only 9 = All																																				



TABLE 8 CON'T: PARAMETERS

FIRST DIGIT (x) = 1,2,3,4, or 5 (ALL) DATA FOR TRUNKS 1,2,3,4, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
		<p><b>NOTE:</b> Trunk #1 and Route #1 are unrelated. The former controls the operation of the trunk hardware with respect to starting, ending, and dialing a call. This controls things such as the type of CO trunk connected, the type of dial tone and whether the Trunk is DTMF or rotary, i.e., anything that deals with the physical aspects of the Trunk. Route refers to the characteristics of the carrier network. The codes for each are merged below only for convenience sake. Any trunk may access any Route.</p>
x00t	2	<p>Type of Central Office, where:  t = 0 = Loop Start, Rotary Dialing  1 = Ground Start, Rotary Dialing  2 = Loop Start, DTMF Dialing  3 = Ground Start, DTMF Dialing</p>
x01t	4	<p>Rotary dialing, where:  t = 3 = outpulse at 40/30 ms  4 = outpulse at 60/40 ms</p>
x02t	1	<p>DTMF dialing rate, where:  t = 0 = 40 ms    5 = 90 ms  1 = 50 ms    6 = 100 ms  2 = 60 ms    7 = 110 ms  3 = 70 ms    8 = 120 ms  4 = 80 ms    9 = 130 ms</p>
x03t	6	<p>On-hook timing, where t = 0 - 9, or:  t = 0 = 80 ms    5 = 500 ms    * = 2000 ms  1 = 100 ms    6 = 750 ms    # = 2500 ms  2 = 150 ms    7 = 1000 ms  3 = 200 ms    8 = 1330 ms  4 = 300 ms    9 = 1660 ms</p>
x04t	3	<p>Flash allowed/time, where t = 0 - 9, or:  t = 0 = 80 ms    5 = 500 ms    * = 2000 ms  1 = 100 ms    6 = 750 ms    # = 2500 ms  2 = 150 ms    7 = 1000 ms  3 = 200 ms    8 = 1330 ms  4 = 300 ms    9 = 1660 ms</p> <p>If flash allowed/time is longer than the on-hook timing, then flash is not allowed.</p>

TABLE 8 CON'T: PARAMETERS

FIRST DIGIT (x) = 1,2,3,4, or 5 (ALL) DATA FOR TRUNKS 1,2,3,4, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
x05t	0	Time between release and reseizure, where t = 0 - 9, or: t = 0 = 500 ms    5 = 1250 ms 1 = 650 ms    6 = 1400 ms 2 = 800 ms    7 = 1550 ms 3 = 950 ms    8 = 1700 ms 4 = 1100 ms    9 = 1850 ms
x06t	3	t = Number of ground start tries (failure goes to reorder tone).
x07t	3	t = Ground start timeout in seconds (Wait for TIP GND).
x08t	3	Off-hook digit refusal time, where t = 1 - 9, or: t = 0 = None    5 = .5 Sec. 1 = .1 Sec.    6 = .6 Sec. 2 = .2 Sec.    7 = .7 Sec. 3 = .3 Sec.    8 = .8 Sec. 4 = .4 Sec.    9 = .9 Sec.
x09t	4	User dial tone, where:  <u>Silent Dialout</u> <u>Ticking Dialout</u> t = 0 = None                              2 = None 1 = Internal *                            3 = Internal * 4 = From C.O.                            6 = From C.O. * - Interacts with x19 Beep Options.
x10t	-	Reserved for future use.
x11t	3	t = Inter-digit timeout on subscriber side, where t = 1 - 9, * and #, or: t = 0 = No timeout    6 = 12 seconds 1 = 2 seconds    7 = 14 seconds 2 = 4 seconds    8 = 16 seconds 3 = 6 seconds    9 = 18 seconds 4 = 8 seconds    * = 20 seconds 5 = 10 seconds    # = 22 seconds
x12t	2	t = Inter-digit timeout on 0+ calls. Same as x11t above.
x13t	2	t = Inter-digit timeout on 01+ calls. Same as x11t above.

TABLE 8 CON'T: PARAMETERS

FIRST DIGIT (x) = 1,2,3,4, or 5 (ALL) DATA FOR TRUNKS 1,2,3,4, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
x14t	4	t = Rotary inter-digit pause on the Central Office side (outgoing dialing), where t = 0 - 8, or: 0 = 400 ms    5 = 900 ms 1 = 500 ms    6 = 1 second 2 = 600 ms    7 = 1.1 seconds 3 = 700 ms    8 = 1.2 seconds 4 = 800 ms
x15t	0	t = Character used for restart during dialing. Use * or # only. 0 = disable.
x16t	0	t = Character used for forcing redial on Route #0. Use * or # only. 0 = disable.
x17t	0	t = Character used for forcing redial on the same route as used the first time. Use * or # only. 0 = disable.
x18t	1	t = Redial timeout, where t = 0 - 9, or: 0 = No timeout    5 = 40 seconds 1 = 08 seconds    6 = 48 seconds 2 = 16 seconds    7 = 56 seconds 3 = 24 seconds    8 = 64 seconds 4 = 32 seconds    9 = 72 seconds
x19t	1	t = Beep options, where: 0 = No beep tones enabled. 1 = Off-hook beep (see note 1). 2 = Account code beep. 1 before account code/2 after. (See note 2). 3 = Account code beep and off-hook beep. 4 = OCC beep. 1 for Route #0 after destination number, 2 for all routes other than 0 after destination number. (See note 3). 5 = OCC beep and off-hook beep. 6 = OCC beep and account code beep. (See note 4). 7 = OCC beep, account code beep, and off-hook beep. (See note 4).

TABLE 8 CONT: PARAMETERS

FIRST DIGIT (x) = 1,2,3,4, or 5 (ALL) DATA FOR TRUNKS 1,2,3,4, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
		<p><b>NOTE 1:</b> If the off-hook beep options is chosen by itself (i.e., x191) or in conjunction with the other beep options, a beep will be heard when the telephone handset is lifted off the cradle, regardless of whatever route the call is dialed on.</p> <p><b>NOTE 2:</b> If the account code beep option is chosen (i.e., x192), the SMarT-1™ Dialer will insert a beep at the end of the destination number (which is before the account code is to be dialed). After the account code is entered, the second account code beep is heard.</p> <p><b>NOTE 3:</b> If the OCC beep option is chosen (i.e., x194), the SMarT-1™ Dialer will insert one beep after the destination number if the call is dialed on Route #0 (DDD). If the call is dialed on any other route, the OCC beep option will insert two beeps after the destination number.</p> <p><b>NOTE 4:</b> If the OCC beep option and the account code beep option are employed (i.e., x196 or x197) and the call is dialed on Route #0 (DDD), one beep after the destination number and one beep after the account code will be heard. If dialed on any other route, two beeps will be heard after the destination number and one beep after the account code.</p> <p><b>NOTE:</b> If parameter x54t has the t value set to 1 (i.e., no account code), then account code beeps are disabled regardless of the x19t options chosen.</p>
x20t	2	t = Ringing sensitivity, where t = 0 - 9 (0 is the most sensitive, and decreasing to 9, the least sensitive).
x21t	6	t = Inter-ring timing, in seconds.
x22t	0	t = Use primary or alternate search tables. 0 = Primary, 1 = Alternate
x23t	9	t = Activation of Dialer (what is done immediately after off-hook), where: 0 = Immediately dial Default Route (Hotline Operation) 8 = Wait for digits; use search tables 9 = Cut-through (Pass all digits directly through Dialer). (No Call-processing).

TABLE 8 CONT: PARAMETERS

FIRST DIGIT (x) = 1,2,3,4, or 5 (ALL) DATA FOR TRUNKS 1,2,3,4, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
x24t	0	t = Default route, see search tables for action digit. This 'action' is accomplished if x23t = 0 or #8 used in Table 11.
x25t	9	t = Centrex outgoing trunk access digit. If enabled via x26t, then all Intra-Centrex calls are dialed immediately.
x26t	0	t = Centrex enable code where 0 = off and 1 = on.
x27t	0	Auto-Answer Timer in tens of seconds. t = 0 = No Auto-Answer.
x28t	6	Auto-Answer Wait-for-Security-Code Timer in tens of seconds. This is the time period in which the Security Code (603 Parameter) must be entered. If the timer expires or an erroneous security code is entered, Auto-Answer control for the associated trunk drops through to the x29t Lockout Timer.
x29t	9	Auto-Answer Lockout Timer in tens of seconds. Failure to enter Program Mode during the x28 parameter time enables this timer. The associated trunk will hold the seizure for this length of time (barring further Auto-Answer activity on that trunk) until the timer expires or the subscriber goes off-hook (which cancels the lock-out).
x30t	3	OFF-HOOK Recognition Time. t = 0 = 20 ms 1 = 20 ms 2 = 40 ms 3 = 60 ms 4 = 80 ms 5 = 100 ms 6 = 120 ms 7 = 140 ms 8 = 160 ms 9 = 180 ms * = 200 ms # = 220 ms

TABLE 8 CON'T: PARAMETERS

FIRST DIGIT (x) = 1,2,3,4, or 5 (ALL) DATA FOR TRUNKS 1,2,3,4, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
x31t	3	<p>A common timer for:            TIP GND Application Recognition (GND START),            TIP GND Removal Recognition (GND START)            and during GND START Seizure, time between SPLIT and            TERMINATE action during RING GND Application.</p> <p>t = 0 = 40 ms            1 = 40 ms            2 = 80 ms            3 = 120 ms            4 = 160 ms            5 = 200 ms            6 = 240 ms            7 = 280 ms            8 = 320 ms            9 = 360 ms            * = 400 ms            # = 440 ms</p>
x32t	0	<p>Subscriber Outgoing Digit Recognition</p> <p>t = 0 = DTMF, 10 or 20 PPS (normal operation)            1 = Ignore all ROTARY            2 = Ignore all DTMF            3 = Ignore all DIGITS            4 = Not Used            5 = Go to REORDER on ROTARY digits            6 = Go to REORDER on DTMF digits            7 = Go to REORDER on any type digits            8 = Not Used</p> <p><b>NOTE:</b> To cause the Dialer to ignore 20 PPS dialing (both            Incoming and Outgoing), add 8 (hexadecimal) to the cur-            rent value of x33t and set x33t to that new value. DO NOT            add the 8 (hexadecimal) to x32t.</p>
x33t	0	<p>Subscriber Incoming Digit Recognition Type</p> <p>t = 0 = DTMF, 10 or 20 PPS (normal operation)            1 = Ignore all ROTARY            2 = Ignore all DTMF            3 = Ignore all DIGITS            4 = Not Used            5 = Go to REORDER on ROTARY digits            6 = Go to REORDER on DTMF digits            7 = Go to REORDER on any type digits</p> <p><b>NOTE:</b> To cause the Dialer to ignore 20 PPS dialing (both            Incoming and Outgoing), add 8 (hexadecimal) to the cur-            rent value of x33t and set x33t to that new value.</p>

TABLE 8 CONT: PARAMETERS

FIRST DIGIT (r) = 1,2,3,4, or 5 (ALL) DATA FOR ROUTES 0,1,2,3, or ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
r50t: 150t 250t 350t 450t	0 1 1 1	t = Destination number format where t = 0 - 9, or: 0 = Any number of digits (for Route #0) 1 = ten digits (adds user area code on seven digits) 2 = 1+ ten digits (as above) 4 = 1+ ten digits or 1+ seven digits 8 = ten or seven digits
r51t	-	Reserved for future use.
r52t	4	t = Account code number of digits, where t = 1 - 9
r53t	3	t = Account code wait timer in seconds (0 = No time-out).
r54t	1	t = Account code type, where t = 0 - 5, or: 0 = Flexible length account code. Wait for timeout (previous entry) and then continue. 1 = No account code. x53t is not checked if x54t = 1. 2 = Fixed length. Wait for timeout. If not entered, then reorder tone. 3 = Fixed length. Wait for timeout. If not entered, then substitute the 'dummy account code'. 4 = Same as 2 above, except that the number of digits in the account code is 10+ x52t above. 5 = Same as 3 above, except that the number of digits in the account code is 10+ x52t above.
r55t	*	t = Not On Network (NON) trigger character.
r56t	3	t = The length of time that a NON entry stays in the temporary search table (in tens of days).
r57t	7	t = Number of digits stored in the search tables when NON is detected.
r58t: 158t 258t 358t 458t	4 6 6 6	t = Action as a result of call failure, where t = 0 - 9, * or: 0 = Redial on Route #0 1 = Redial on Route #1 2 = Redial on Route #2 3 = Redial on Route #3 4 = Reorder 5 = Redial same route once, then reorder 6 = Redial same route twice, then reorder 7 = Redial same route three times, then reorder 8 = Redial same route again, then Route 0 9 = Redial same route twice, then Route 0 * = Redial same route three times, then Route 0

TABLE 8 CON'T: PARAMETERS

FIRST DIGIT (r) = 1,2,3,4, or 5 (ALL) DATA FOR ALTERNATE ROUTES 4,5,6,7 OR ALL		
DIAL	DEFAULT/ RECOMMENDED	DEFINITION/PARAMETER INFORMATION
r70t: 170t 270t 370t 470t	0 1 1 1	t = Destination number format where t = : 0 = Any number of digits (for Route #4) 1 = ten digits (adds user area code on seven digits) 2 = 1+ ten digits (as above) 4 = 1+ ten digits or 1+ seven digits 8 = ten or seven digits
r72t	4	t = Account code number of digits, where t = 123456789
r73t	3	t = Account code wait timer in seconds X 2.
r74t	1	t = Account code type, where t = 0 - 5, or: 0 = Flexible length account code. Wait for timeout (previous entry) and then continue. 1 = No account code. 173t is not checked if 174t = 1. 2 = Fixed length. Wait for timeout. If not entered, then reorder tone. 3 = Fixed length. Wait for timeout. If not entered, then substitute the 'dummy account code'. 4 = Same as 2 above, except that the number of digits in the account code is 10+ 152t above. 5 = Same as 3 above, except that the number of digits in the account code is 10+ 152t above.
r75t	*	t = Not On Network (NON) trigger character.
r76t	3	t = The length of time that a NON entry stays in the temporary search table (in tens of days).
r77t	7	t = Number of digits stored in the search tables when NON is detected.
r78t: 178t 278t 378t 478t	4 6 6 6	t = Action as a result of call failure, where t = 0 - 9, * or: 0 = Redial on Route #0 1 = Redial on Route #1 2 = Redial on Route #2 3 = Redial on Route #3 4 = Reorder 5 = Redial same route once, then reorder 6 = Redial same route twice, then reorder 7 = Redial same route three times, then reorder 8 = Redial same route again, then Route 0 9 = Redial same route twice, then Route 0 * = Redial same route three times, then Route 0



### Strings

**5.29** Strings are entered as in Table 9 below. Where 'number' appears after the initial three digits, a valid string of digits may be entered. The string entry is terminated by the characters '##'. If the '##' is not entered, an 'Automatic Entry' Timer will automatically complete the parameter entry after expiration of the Inter-Digit Timer (x11t). Examples of string entries are included below.

**EXAMPLE 1:**

**# 8 0 3 2 7**

The string above is the default on Route #0 (615). This string translates to:

- #803 Wait for minimum duration of precise dial tone for up to six seconds;
- 2 Dial destination number;
- 7 Cut-through.

**EXAMPLE 2:**

**# 8 0 3 3 # 6 x5 4 2 7**

The string above is the default on Route #1 (625). It translates to:

- #803 Wait for minimum duration of precise dial tone for up to six seconds.
- 3 Dial access number.
- #625 Wait for 400 ms of 400 Hz tone from OCC for up to ten seconds.
- 4 Dial authorization code.
- 2 Dial destination number.
- 7 Cut-through.

**5.30** These strings are entered as (refer to Table 8):

**615 #80327## for Route 0 and  
625 #8033#625427## for Route 1.**

The 615 and 625 strings are constructed from the 6r5 Parameter in Table 9.

TABLE 9: STRING DATA ENTRY

FIRST DIGIT = 6 STRINGS (where: r = 1 to 8 for Routes #0 to #7)	
DIAL	DEFINITION/STRING INFORMATION
600number##	Reserved for future use.
601number##	User area code (must be three digits, must always be entered).
602title##	MACHINE IDENTIFIER (15 digits maximum and must be entered as ASCII codes).
603title##	Auto-Answer Security Code (34 digits maximum). Default = #0*
604title##	Terminal Program Security Code (15 digits maximum). Default = <CR> (must be entered as ASCII Codes).
6r0title##	Name of Route (Six characters maximum). (Must be entered as ASCII codes).
6r1number##	Access number (OCC phone number) (34 digits maximum).
6r2number##	Authorization number (34 digits maximum).
6r3number##	Dummy account number (34 digits maximum). (If this is empty, the dialer will wait for an account number to be dialed in until timeout occurs).
6r4number##	Centrex number. (Default = 9) (34 digits maximum, if desired).
6r5number##	Access control sequence. This instructs the Dialer on how to access a particular network. All Route access control codes are sequences of digits as follows (and may be combined in any order):
615 and 655 Defaults: #80327	1,0 Dial that digit.
625, 635, 645, 665,	#0* Dial a '*'. #00 Dial a '#'. #01 Dial a '#' if the last dial digit was not '#'. #02 Wait for account code (does not dial account code).
675 and 685 Defaults: #8033#62*427	#2ab Pause. Continue after pause if a = 5. Fail to x58, x78 if a = 0 (see note 1).
To program 601 and 6r0 through 6r5 for DIAL-OUT of 4th column DTMF, see Table C2 'SPECIALS' on Page C-5.	#3ab High tone (570-680 detector) (see note 1). #4ab 440 Hz detector (see note 1). #5ab 480 Hz/Ringback detector (see note 1). #6ab 400 Hz detector (see note 1). #7ab 350-620 Hz energy detector (see note 1). #8ab Precise dialtone/425 Hz detector (see note 1). #9ab Wait for Not On Network (NON) tone (see note 1). #Dab DTMF Detector.

(Continued on next page)

**TABLE 9 CON'T: STRING DATA ENTRY**

<b>FIRST DIGIT = 6 STRINGS (where: r = 1 to 8 for Routes #0 to #7)</b>	
<b>DIAL</b>	<b>DEFINITION/STRING INFORMATION</b>
	2 Dial the destination code 3 Dial the route access code 4 Dial the authorization code 5 Dial the account code 6 Dial the Trunk number (1-4) 7 Cut-through (done) 8 Change to DTMF 9 Dial the Centrex access code (may be different for each Route) ## End (Used while programming)

**Note:1:** Refer to Tables 9a and 9b respectively for an elaboration of the a and b values.

**TABLE 9a: DETECTOR/TIMEOUT (a) CODES**

<b>a</b>	<b>MIN. TONE DURATION</b>	<b>a</b>	<b>MIN. TONE DURATION</b>
0	MIN. Redial per x58 or x78	5	MIN. then continue Dialout
1	200ms Redial per x58 or x78	6	200ms then continue Dialout
2	400ms Redial per x58 or x78	7	400ms then continue Dialout
3	1.0 Redial per x58 or x78	8	1.0 then continue Dialout
4	2.55 Redial per x58 or x78	9	2.55 then continue Dialout

**TABLE 9b: DETECTOR/TIMEOUT (b) CODES**

<b>b</b>	<b>TIMEOUT/TONE NOT RCVD.</b>	<b>b</b>	<b>TIMEOUT/TONE NOT RCVD.</b>
0	0 Seconds	6	12 Seconds
1	2 Seconds	7	14 Seconds
2	4 Seconds	8	16 Seconds
3	6 Seconds	9	18 Seconds
4	8 Seconds	*	20 Seconds
5	10 Seconds		

### Speed Call Entries

**5.31** Table 10 below lists digits required for Speed Call entries. 'nn' is the number of the entry, while 'd' is the key that is used to determine which trunk or trunks have access to the particular speed call number. 'k' is a Network override and is used to select the allowed routing for the particular speed call number. 'mmmmmm' is the phone number to be dialed.

**TABLE 10: SPEED CALL ENTRIES**

FIRST DIGIT = 7 SPEED CALL																																									
DIAL	DEFINITION																																								
7nndkmmmmmm##	<p>Speed call entry where:            nn is the number of the speed call entry.</p> <p>d is the key that selects the trunks to access the call number as follows:</p> <table border="1"> <thead> <tr> <th>DIGIT</th> <th>ALLOWED TRUNKS</th> </tr> </thead> <tbody> <tr><td>0</td><td>ALL</td></tr> <tr><td>1</td><td>TRUNK 1</td></tr> <tr><td>2</td><td>TRUNK 2</td></tr> <tr><td>3</td><td>TRUNKS 1,2</td></tr> <tr><td>4</td><td>TRUNK 3</td></tr> <tr><td>5</td><td>TRUNKS 1,3</td></tr> <tr><td>6</td><td>TRUNKS 2,3</td></tr> <tr><td>7</td><td>TRUNKS 1,2,3</td></tr> <tr><td>8</td><td>TRUNK 4</td></tr> <tr><td>9</td><td>TRUNKS 1,4</td></tr> <tr><td>*</td><td>TRUNKS 2,4</td></tr> <tr><td>#</td><td>TRUNKS 1,2,4</td></tr> <tr><td>C</td><td>TRUNKS 3,4</td></tr> <tr><td>D</td><td>TRUNKS 1,3,4</td></tr> <tr><td>E</td><td>TRUNKS 2,3,4</td></tr> </tbody> </table> <p><b>NOTE:</b> The C, D, and E entries above may be made from a terminal.</p> <p>k is the network override:</p> <table border="1"> <tbody> <tr><td>0 - 3</td><td>Force on Route #0 - #3</td></tr> <tr><td>4 - 7</td><td>Force on Route #0a - 3a</td></tr> <tr><td>8</td><td>Use search table</td></tr> <tr><td>9</td><td>Dial immediate, no Route # (transparent).</td></tr> </tbody> </table> <p>mmmmmm is the phone number.</p> <p><b>NOTE:</b> See Search Table Action '#C' for limited access to Speed Call Programming.</p>	DIGIT	ALLOWED TRUNKS	0	ALL	1	TRUNK 1	2	TRUNK 2	3	TRUNKS 1,2	4	TRUNK 3	5	TRUNKS 1,3	6	TRUNKS 2,3	7	TRUNKS 1,2,3	8	TRUNK 4	9	TRUNKS 1,4	*	TRUNKS 2,4	#	TRUNKS 1,2,4	C	TRUNKS 3,4	D	TRUNKS 1,3,4	E	TRUNKS 2,3,4	0 - 3	Force on Route #0 - #3	4 - 7	Force on Route #0a - 3a	8	Use search table	9	Dial immediate, no Route # (transparent).
DIGIT	ALLOWED TRUNKS																																								
0	ALL																																								
1	TRUNK 1																																								
2	TRUNK 2																																								
3	TRUNKS 1,2																																								
4	TRUNK 3																																								
5	TRUNKS 1,3																																								
6	TRUNKS 2,3																																								
7	TRUNKS 1,2,3																																								
8	TRUNK 4																																								
9	TRUNKS 1,4																																								
*	TRUNKS 2,4																																								
#	TRUNKS 1,2,4																																								
C	TRUNKS 3,4																																								
D	TRUNKS 1,3,4																																								
E	TRUNKS 2,3,4																																								
0 - 3	Force on Route #0 - #3																																								
4 - 7	Force on Route #0a - 3a																																								
8	Use search table																																								
9	Dial immediate, no Route # (transparent).																																								
7nn##	Delete speed dial entry nn.																																								

**Search Tables**

**5.32** Table 11 below lists the breakdown of the digits in the search tables to be used for programming. There are four examples that are also included, that, with the use of Table 11, should provide sufficient information for programming.

**EXAMPLE 1:**

Force all 411 and 1+411 calls to Dial and Cut-Through immediately.

<b>803 411 #3</b>	Force 411 to Dial and Cut-Through immediately.
<b>##</b>	finished

<b>804 1411 #3</b>	Force 1+411 to Dial and Cut-Through immediately (this is one of the defaults).
<b>##</b>	finished

**EXAMPLE 2:**

Start the Dialer (begin executing 6r5) if the first three digits dialed are an 'Area Code':

<b>803 #4#1#9 1</b>	Prefer Route #1.
<b>##</b>	finished

**EXAMPLE 3:**

Deny all calls to 555-1212 or 1-555-1212 or 1-(NPA)-555-1212:

<b>803 555 #1</b>	Deny 555.
<b>##</b>	finished programming 803.

<b>804 1555 #1</b>	Deny 1+555.
<b>##</b>	finished programming 804.

<b>807 1#4#1#9555 #1</b>	Deny 1-N1/OX-555.
	N = 2-9 and X = 0-9
<b>##</b>	finished.

**Note:** The searches that are not controlled by these tables are: a) first digit Centrex access, b) restart any time before end of dialed digits, and c) redial after dialed digits.

TABLE 11: SEARCH TABLE ENTRIES

FIRST DIGIT = 8 SEARCH TABLES																																											
DIAL	DEFINITIONS/DESCRIPTIONS																																										
<p>Primaries:</p> <p>801na 802nna 803nnna 804nnnna 805nnnnna 806nnnnnna etc. to 815</p> <p>ALTERNATES:</p> <p>821na 822nna</p> <p>823nnna 824nnnna 825nnnnna 826nnnnnna etc. to 835</p> <p>TO ACCESS ALTERNATE SEARCHES, SEE x22t Parameter</p>	<p>Where n are the user dialed digits for a match, and a is the 'action' that is performed in the case of a match.</p> <p>n may be any digit from 0 through 9 and *, to be matched against the same digit in the dialed sequence. n may also be:</p> <p>#0 Compare against a dialed '#'. #1 Compare against a dialed '1' or '0'. #4 Compare against any digit dialed from 2 through 9. #9 Compare against any digit dialed.</p> <p>After the match string is entered, one 'action' (a) is entered, as follows:</p> <table> <tr> <td>0</td> <td>Prefer Route #0 (PRO)</td> <td rowspan="3">NOTE: A 601 entry is required when accessing routes 1,2,3 and 5,6,7.</td> </tr> <tr> <td>1</td> <td>Prefer Route #1</td> </tr> <tr> <td>2</td> <td>Prefer Route #2</td> </tr> <tr> <td>3</td> <td>Prefer Route #3</td> <td></td> </tr> <tr> <td>4</td> <td>Force Route #0 (FRO)</td> <td rowspan="4">These will force the call onto that route if possible; redial and retry cannot change the selection.</td> </tr> <tr> <td>5</td> <td>Force Route #1</td> </tr> <tr> <td>6</td> <td>Force Route #2</td> </tr> <tr> <td>7</td> <td>Force Route #3</td> </tr> <tr> <td>8</td> <td>Select Route #0 (SRO)</td> <td rowspan="5">These will not dial out the 'select' digits, and will start the comparisons over again from the first digit following the 'select' digits.</td> </tr> <tr> <td>9</td> <td>Select Route #1</td> </tr> <tr> <td>*</td> <td>Select Route #2</td> </tr> <tr> <td>#0</td> <td>Select Route #3</td> </tr> <tr> <td>#1</td> <td>Deny</td> </tr> <tr> <td>#2</td> <td>Speed Call - Access 7nn entry, Table 10.</td> <td></td> </tr> <tr> <td>#3</td> <td>Dial what has been entered and cut through (no routine).</td> <td></td> </tr> <tr> <td>#4</td> <td>Security access code.</td> <td></td> </tr> <tr> <td>#5</td> <td>Absorb what has been entered and cut through (bypass).</td> <td></td> </tr> </table>	0	Prefer Route #0 (PRO)	NOTE: A 601 entry is required when accessing routes 1,2,3 and 5,6,7.	1	Prefer Route #1	2	Prefer Route #2	3	Prefer Route #3		4	Force Route #0 (FRO)	These will force the call onto that route if possible; redial and retry cannot change the selection.	5	Force Route #1	6	Force Route #2	7	Force Route #3	8	Select Route #0 (SRO)	These will not dial out the 'select' digits, and will start the comparisons over again from the first digit following the 'select' digits.	9	Select Route #1	*	Select Route #2	#0	Select Route #3	#1	Deny	#2	Speed Call - Access 7nn entry, Table 10.		#3	Dial what has been entered and cut through (no routine).		#4	Security access code.		#5	Absorb what has been entered and cut through (bypass).	
0	Prefer Route #0 (PRO)	NOTE: A 601 entry is required when accessing routes 1,2,3 and 5,6,7.																																									
1	Prefer Route #1																																										
2	Prefer Route #2																																										
3	Prefer Route #3																																										
4	Force Route #0 (FRO)	These will force the call onto that route if possible; redial and retry cannot change the selection.																																									
5	Force Route #1																																										
6	Force Route #2																																										
7	Force Route #3																																										
8	Select Route #0 (SRO)	These will not dial out the 'select' digits, and will start the comparisons over again from the first digit following the 'select' digits.																																									
9	Select Route #1																																										
*	Select Route #2																																										
#0	Select Route #3																																										
#1	Deny																																										
#2	Speed Call - Access 7nn entry, Table 10.																																										
#3	Dial what has been entered and cut through (no routine).																																										
#4	Security access code.																																										
#5	Absorb what has been entered and cut through (bypass).																																										

(Continued on next page)

TABLE 11 CON'T: SEARCH TABLE ENTRIES

FIRST DIGIT = 8 SEARCH TABLES	
DIAL	DEFINITIONS/DESCRIPTIONS
	<p>#6 This is the last digit of the phone number; any other dialed digits are the account code unless 154t = 1. A route must have been chosen prior to encountering a search table with #6 as an action.</p> <p>#7 Do nothing (wait for more digits).</p> <p>#8 Prefer default route (see x24t).</p> <p>#9 When entered as an action, that template entry is removed from the search table (i.e., 803#00*#9).</p> <p>#C Subscriber side only, Limited Access Security Code. Access for programming speed calls only with a format of 7nn08mm.....mm##. Once this mode is accessed, entry consists of nn mm.....mm##. If the subscriber does not have the capability of dialing the ##, a short wait for a timer expiration will automatically complete the entry (see Table 10 for format description).</p> <p>## End of entry, return to programming.  <b>NOTE:</b> One (and only one) action must be programmed for each template entered.</p>

**5.33** The following paragraphs list the default settings and their descriptions that are included in the search tables when default data is first loaded.

#### SEARCH TABLE 801 AND 821

DEFAULT: 

1	#7
---	----

If the first digit is a 1, do nothing.

DEFAULT: 

*	#7
---	----

If the first digit is a \*, do nothing.

DEFAULT: 

#9	0
----	---

If the first digit is not a 1 or a \*, force the call onto Route #0.

#### SEARCH TABLE 803 AND 823

DEFAULT: 

9	1	1	#6
---	---	---	----

Stop searching after the receipt of 911. 801 search above will force onto Route #0.

DEFAULT: 

*	#9	#9	#2
---	----	----	----

\* and two more digits is a speed dial number.

DEFAULT: 

#0	0	*	#4
----	---	---	----

DTMF '#0\*' is the program access code.

DEFAULT: 

#0	#0	#0	#c
----	----	----	----

DTMF '###' is the Speed Dial Programming Access Code.

#### SEARCH TABLE 804 AND 824

DEFAULT: 

1	4	1	1	#3
---	---	---	---	----

Dial and cut through after 1+411.

DEFAULT: 

1	5	5	5	0
---	---	---	---	---

Place 1+555 calls on Route #0.

DEFAULT: 

1	8	0	0	0
---	---	---	---	---

Place 1+800 calls on Route #0.

DEFAULT: 

1	#4	#9	#9	1
---	----	----	----	---

Place 1+NXX calls on Route #1.

DEFAULT: 

#9	#0	0	*	#4
----	----	---	---	----

Alternate program access code.



**SEARCH TABLE 807 AND 827**

**DEFAULT:**

1	#4	#1	#9	5	5	5	0
---	----	----	----	---	---	---	---

Place 1+N(0 or 1)X-555-XXXX calls on Route #0.

**DEFAULT:**

#4	#4	#9	#9	#9	#9	#9	#6
----	----	----	----	----	----	----	----

Stop searching after receipt of NNX-XXXX (local call).

**SEARCH TABLE 808 AND 828**

**DEFAULT:**

#1	#4	#4	#9	#9	#9	#9	#9	#6
----	----	----	----	----	----	----	----	----

Stop searching after receipt of 1+NNX-XXXX (long distance call within the same area code).

**SEARCH TABLE 810 AND 830**

**DEFAULT:**

#4	#1	#9	#9	#9	#9	#9	#9	#9	#9	#6
----	----	----	----	----	----	----	----	----	----	----

Stop searching after receipt of N(0 or 1)X-XXX-XXXX (long distance, outside of local area code).

**SEARCH TABLE 811 AND 831**

**DEFAULT:**

#1	#4	#1	#9	#9	#9	#9	#9	#9	#9	#9	#6
----	----	----	----	----	----	----	----	----	----	----	----

Stop searching after receipt of a 1+N(0 or 1)X-XXX-XXXX (long distance, non-international call).

**Note:** To enable OCC dialing parameters, the 601 (area code), 621 (OCC access), and 622 (authorization code) values must be programmed.

**Note:** The search tables for the Alternate Routes are programmed by using numbers 821 through 835. These are used in the same manner as the numbers in the primary search tables. The 'a's used for 821 through 835 remain the same as the definitions for the ones used for 801 through 815. Alternate search tables can be accessed via x22t.

**Special Functions**

**5.34** Table 12 (on the following page) contains the description of the programming entries required to invoke some special functions. Modes 903, 904, 906 and 908 will affect calls in progress.

TABLE 12: SPECIAL FUNCTIONS

FIRST DIGIT = 9	
DIAL	DEFINITION/DESCRIPTION
902	Data confirmation mode: After each three digit prefix described above, the Dialer will display the data if programming method 1 is employed, or if using methods 2 or 3, the Dialer will wait for 0.5 seconds, then send the data out in DTMF format.
903	Load default data - delete all non-default data.
904	Clear all searches (including defaults, primary and alternate).
906	Enter clone master mode.
907	Return to normal programming mode from data confirmation mode.
908	Enter tandem operation mode (ASCII - DTMF conversion).
980mmddhhmm	Set the internal clock where mm = month, dd = day, hh = hours, mm = minutes.
999 (or go on-hook)	Exit programming.

**ACKNOWLEDGE TONES**

**5.35** In general, after each entry, the Dialer will respond with a double tone. During programming, the Dialer will 'punctuate' the entry with short tones as follows:

**Parameters**

**5.36** After the three digit parameter prefix has been dialed, the Dialer will insert a single short tone. After the fourth digit, the Dialer will send a double tone that indicates the Dialer is ready to continue programming.

**Strings**

**5.37** After the three digit string prefix has been dialed, the Dialer will insert a single short tone. After the '###' has been dialed, the Dialer will send a double tone indicating Dialer is ready to continue programming.

**Search Tables**

**5.38** After the three digit search table prefix, the Dialer will send a short tone. After the '###' has been dialed, the Dialer will send a double tone indicating the Dialer is ready to continue programming.

**Note:** In the event of an illegal entry, the Dialer will send four long, slow beeps to indicate that the entry has been ignored. Wait for the tones to stop and then try again.

### **METHOD 3**

#### **Tandem Mode**

**5.39** Remote programming may be accomplished using a PC or dumb terminal in conjunction with a Dialer. The local Dialer will perform as an ASCII to DTMF convertor in this mode and also has the advantage of visual feedback while programming a remote Dialer. This mode is also useful for data confirmation of a problem remote Dialer.

**5.40** The network connection between the local and remote Dialer must be of reasonable quality with not more than a 20 dB loss.

**5.41** To initiate TANDEM MODE, enter the PROGRAM MODE, then enter 502 9 (for a more reliable DTMF transmission) and then enter the TANDEM MODE with the 908 command. The Dialer will be self-prompting on the screen. It will ask which line to use, will acknowledge receipt of the dial tone and will prompt for the phone number to dial. The user may pick up the associated phone at this point to converse with someone at the remote location. Once the remote Dialer has answered, enter the program access code. Upon receipt of the remote acknowledge tone, the remote phone will be split away and may be hung up.

**5.42** The first command issued to the remote Dialer should be 502 9 (130 ms DTMF tones for more reliable data transmission) unless it has been pre-set. At this point, standard terminal programming techniques may be used.

**5.43** For data confirmation (902 mode), the TANDEM 'T' turn-around mode is most convenient. This places the local and remote digits on separate lines on the screen which makes the data confirmation much easier to read. Use 'X' to return to regular mode from the turn-around mode.

**5.44** The next to last command to the remote Dialer should be to return the x09t parameter to its original setting before programming.

**5.45** The **\*\* LAST \*\*** command to the remote Dialer should be 999 in order to exit the program mode in the remote Dialer. Failure to do so will result in the remote Dialer trunk having to time-out of the program mode which essentially, results in that trunk being locked-up for the duration of the time-out.

**METHOD 4****Cloning**

**5.46** "Cloning" is a programming method whereby several Dialers can be programmed to operate identically once one Dialer has been set to the desired functions by another programming method. The Dialer that has the pre-programmed instructions and is used to 'clone' another is called the 'Master'. The unit to be programmed by this method is called the 'Slave'.

**5.47** This method must be accomplished by meeting the following conditions:

1. The Master unit cannot be processing any calls.
2. The Slave unit(s) must be fully operational and programmable from either a terminal or a DTMF handset.
3. Both the Master and the Slave units must be set for the same Baud rate.
4. This procedure will work correctly only if one Slave is connected to one Master at any one time during the cloning.
5. The Master unit must not be allowed to exit the program mode and no off-hook to on-hook transitions may occur in either unit while the RS-232 Cloning Cable is connected between the units.

**Note:** These transitions will cause an SMDR output that will confuse the units and possibly corrupt the programming of both units.

6. The Slave unit must be powered down, then up after cloning and before attempting to use it. The Cloning Cable must be disconnected prior to powering the Slave unit up.

**5.48** The following is a list of required equipment that is needed to accomplish this method of programming:

1. Pre-programmed, dedicated Master unit.
2. DTMF handset or other DTMF source that will allow the Master unit to seize the line and generate tones.
3. A method of audibly detecting clone acknowledge tones on the Master Unit. A DTMF handset is allowable, or any other means of monitoring the audio on the subscriber side of the Master unit.
4. A battery or dummy CO source for the Master unit.
5. A power pack for each Dialer.
6. RS-232 Cloning Cable. The Dialer requires pins 1, 2, and 3 only. It is a NULL MODEM type with pins 2 and 3 reversed at one end.

**Procedure**

**5.49** The following steps are the procedure to be accomplished to clone a Dialer:

1. Ensure that the Dialers have been x initialized (see Page 10, para. 3.05).
2. Power up the Master unit.
3. Verify that the desired programming is already resident in the Master unit.
4. Power up the Slave unit.
5. Match the Master and Slave Baud rates.
6. Connect the Master and Slave RS-232 port connectors together with the Cloning Cable.
7. Go off-hook on the Master unit.
8. Dial the program access code (# 0 \* unless it has been changed).
9. Dial '906' to start the Clone procedure.
10. In approximately four to five seconds, one of two responses will occur. These are:
  - a) A double beep that indicates a successful clone has taken place and data has been transferred, or
  - b) Four long, slow beeps that indicate a failure of the cloning process. If this occurs, check the cable, the Baud rates, and the power connections, etc., to determine the cause of the failure.
11. After successful cloning, disconnect the Cloning Cable and power down the Slave unit.
12. DO NOT attempt to make the Slave unit function while the Cloning Cable is connected or prior to this power down.

**5.50** Upon the next power up of the Slave unit, it will be functional and ready for operation with its data base being a copy of the Master unit data base. If more units are to be cloned, repeat steps 2 through 11 for each unit.

**Note:** The '906' Clone Command may be repeated at the Master unit any number of consecutive times until the desired number of units are cloned.

**Caution:**

Do not allow the Master to time out of the program mode or otherwise exit the program mode while the units are connected via the RS-232 Cloning Cable. The resulting SMDR output could cause data corruption of both units. The user may wish to turn the Master SMDR off (009 = 0) during the cloning and later restore it to its original setting if needed to minimize this error. A good rule to follow is to only have the Cloning Cable connected while actually cloning the unit.

**Note:** The cloning process occurs at a 19,200 Baud rate in order to proceed quickly (four to five seconds). The length of the Cloning Cable should be kept to a minimum and not coiled to allow uncorrupted transfer of data. The Master unit reverts to the programmed Baud rate upon completion of cloning and the Slave unit returns to its programmed Baud rate on the first power-up transition.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**6. SPECIFICATIONS****HARDWARE**

**6.01** Table 13 lists all of the hardware specifications for the SMarT-1™ Common Carrier Access Dialer and Call Controller. These specifications also apply to the SMarT-1A™ unit unless otherwise noted.

**TABLE 13: SMarT-1™ HARDWARE SPECIFICATIONS**

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>FCC RINGER EQUIVALENCE</b>			0.7B	
<b>IDLE LINE, LOOP START</b>				
RINGER IMPEDANCE: 15-60 Hz, 70-110V	10		20	K $\Omega$
20-3500 Hz, 10V	1			M $\Omega$
RINGING SENSITIVITY: 15-60 Hz	40			Volts
LEAKAGE: Tip to Ring, 100V	20			M $\Omega$
Tip to Earth, 100V	20			M $\Omega$
OFF HOOK CURRENT	15		80	mA
<b>IDLE LINE, GROUND START</b>				
SENSING RESISTANCE: Tip to Earth	36	40	45	K $\Omega$
OPEN CIRCUIT VOLTAGE: Tip	-22	-25	-28	Volts
GROUNDING VOLTAGE	-5	0	+10	Volts
TIME TO RECOGNIZE TIP-GROUND	10		150	ms
RESISTANCE: Sending Ring-Ground		n/a		
<b>BATTERY FEED</b>				
OPEN CIRCUIT VOLTAGE	22	24	26	Volts
FEED RESISTANCE	550	600	650	$\Omega$
BALANCE: DC	36	40		dB
SHORT CIRCUIT CURRENT			50	mA
<b>TERMINATION</b>				
RESISTANCE: DC, 20 mA	200		300	$\Omega$
DC, 40 mA	200		300	$\Omega$
AC, 300-3000 Hz	550	600	650	$\Omega$
RETURN LOSS: 600 ohms, 20mA	20	26		dB
OPERATING CURRENT	13		80	mA



TABLE 13 CON'T: SMarT-1™ HARDWARE SPECIFICATIONS

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>DIAL TONE</b>				
CO SIDE FEED: Gain 300 Hz	-2	0	+2	dB
INTERNAL FEED: 350 Hz		n/a		
<b>DTMF RECEIVER</b>				
LEVEL	-20		+3	dBm†
LEVEL DIFFERENCE	-6		+6	dB
FREQ: To receive	-1.5		+1.5	%
To not receive	-3.5		+3.5	%
DURATION	40			ms
TIME BETWEEN TONES	30			ms
<b>ROTARY RECEIVER</b>				
MAKE IMPEDANCE			700	Ω
MAKE DURATION	20		100	ms
BREAK IMPEDANCE	8			KΩ
BREAK DURATION	20		100	ms
RATE	7		20	pps
<b>DTMF SENDER</b>				
LEVEL	-8	-6	-3	dBm†
FREQUENCY	-1.3		+1.3	%
DURATION (Programmable)	40	60	130	ms
<b>ROTARY SENDER</b>				
TIMING (Programmable)	40/30	60/40	60/40	ms/ms
TIMING (At 60/40):				
Make	35		45	ms
Break	55		65	ms
RATE (At 60/40)	9.9	10	10.1	pps
INTERDIGIT PAUSE (Programmable)	400	800	1300	ms
<b>OPERATING RANGE</b>				
TEMPERATURE	0		55	°C
HUMIDITY	0		85	%
ALLOWABLE VOLTAGE: connected to any point			300	Volts

† With reference to 600Ω Termination.

**RS-232 PORT**

**6.02** Table 14 below contains the specifications for the SMarT-1™ Common Carrier Access Dialer and Call Controller RS-232 Auxiliary Port. This port may be used for programming or for SMDR Output.

**TABLE 14: RS-232 PORT SPECIFICATIONS**

PARAMETER	SPECIFICATION
BAUD RATE:	300 to 19200 Baud programmable; default = 1200 Baud
PARITY:	None
BITS PER CHARACTER:	Eight bits per character with one stop bit.
BIT EIGHT SENSE:	Space
MODE:	On line.
OPERATION:	Full duplex mode.

**ELECTRICAL/MECHANICAL**

**6.03** Table 15 contains the Electrical and Mechanical specifications for the SMarT-1™ Common Carrier Access Dialer and Call Controller. These specifications also apply to the SMarT-1A™ unit unless otherwise noted.

**6.04** This section does not contain all of the specifications for the Dialer at present. Other specifications will be added as they are received.

**TABLE 15: ELECTRICAL/MECHANICAL SPECIFICATIONS**

PARAMETER	SPECIFICATION
DIMENSIONS:	7.625" (19.37cm) Wide X 10.625" (26.99cm) H X 1.375" (3.49cm) D
WEIGHT: Dialer	2 lbs (0.907 kg)
Power Supply	1 lb (0.453 kg) (Approximately)
MOUNTING:	Wall Mount with Supplied Bracket
POWER:	115 Volts AC, 60 Hz @ 300 mA
Range:	103.5 to 126.5 VAC
CONNECTIONS:	Standard RJ31X Network Connections

**6.05** The specifications in the Tables above are subject to change without notice. The inclusion of 'n/a' for a specific parameter means that the specification is not available at the time of this publication. It will be added at a later date.

## 7. MAINTENANCE

### GENERAL

**7.01** The Dialer, as is evident, is a fully self-contained unit. As such, it has no user repairable parts. If the warranty seal over the unit fasteners is broken, the warranty is void. In case of failure, replace the Dialer as follows:

- 1) Power down the unit. This will cut-through the subscriber side to the CO side.
- 2) Remove the RJ31 plug from the Telco supplied socket. The shorting bars in the RJ31X will cut-through to the line. Then,
- 3) Replace the Dialer and re-connect.
- 4) Proceed as if a new installation.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**8. ORDERING INFORMATION****GENERAL**

**8.01** Table 16 below lists the part numbers and descriptions of items that can be ordered from MITEL DATACOM INC.

**TABLE 16: SMarT-1™ ORDERING INFORMATION**

<b>PART NO.</b>	<b>DESCRIPTION</b>
8350-001	SMarT-1: 4 Line Common Carrier Access Dialer and Call Controller. Includes Power Pack, RJ31 Cables, and Wall Mount Bracket.
8350-002	SMarT-1A: 2 Line Common Carrier Access Dialer and Call Controller. Includes Power Pack, RJ31 Cables, and Wall Mount Bracket.
<b>SPARES</b>	
8350-010	Wall Mount Bracket for SMarT-1™ and SMarT-1A™ units.
8350-011	Power Pack for SMarT-1™ and SMarT-1A™ units.
8350-012	Power Pack for SMarT-1™ and SMarT-1A™ units.
8350-013	RJ31X Cable for SMarT-1™ and SMarT-1A™ units.
8350-015	Cloning Cable
8350-953-001-NA	Installation and Abbreviated Programming Guide
8350-047-100-NA	General Information Manual

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**9. TROUBLESHOOTING****GENERAL**

**9.01** The following pages are a troubleshooting chart to assist the technician in locating problems on installation. It is presented in the form of trouble followed by a description of a probable cause. Figures C1 and C2 on pages C2, C3, along with Section 3 and Figures 2 and 3 will aid in locating the problem.

**TABLE 17: TROUBLESHOOTING CHART**

<b>PROBLEM</b>	<b>PROBABLE CAUSE</b>
<p>Cannot be programmed from remote location.</p> <p>Cannot program a remote unit.</p> <p>No Ground Start operation.</p> <p>Intermittent Dial-out.</p> <p>Failure to recognize incoming call (one-way voice path or internal dialtone on incoming call).</p> <p>SMDR errors.</p> <p>Failure to properly detect dial tones.</p>	<p>Caused by faulty or missing Earth Ground connection.</p>
<p>No Ground Start operation.</p> <p>Incoming calls recorded on SMDR as outgoing (Ground Start trunks only).</p>	<p>Caused by CO side Tip-Ring reversal.</p>
<p>Failure to access program mode</p>	<p>Access code has been preceded by an action code, causing cessation of searching before reaching the access code string.</p> <p>Improper access code.</p> <p>Missing or erased access code.</p> <p>A "904" erase search command was issued without re-entering an access code.</p> <p>Missing or faulty Earth Ground connection.</p> <p>If a unit has been stored for a period of time, batteries may have been discharged. "Cold" initialization required.</p>



TABLE 17 CON'T: TROUBLESHOOTING CHART

PROBLEM	PROBABLE CAUSE
No Dial out. Progress tones are okay, but are followed by dialtone.	Unit has been programmed to output DTMF while CO is Rotary type.  Programmed for Loop Start while CO is Ground Start.
No Dial out after programming.	Improper programming.  Dialer in Cut Through mode (x23 = 9).  If remotely programmed, programmer may have neglected to exit program mode upon completion. Dialer will time out of program mode automatically after about two minutes.
No speed dials.	Speed dial trigger not defined in searches.  7nn speed call entry calls for an "8" action (use search table) but no table exists for the number in the speed dial.  The trunk being used is not programmed to speed dial in the 7nn "D" key.
No SMDR output.	Output turned off (parameter 009 = 0).  Connecting cable is not NULL MODEM (pins 2 and 3 in contention).  Dialer baud rate does not match printer baud rate.  Printer inoperative.  Dialer output has been suspended with a <CTRL>S (stop) command. Issue <CTRL>Q to restart output.
Faulty or incorrect SMDR output.	Faulty or missing Earth Ground.  Dialer/Printer baud rates do not match.  Printer requires more nulls after Carriage Return (parameter 007).  "No parity", two stop bits, or 8-bit word not set on printer.

TABLE 17 CON'T: TROUBLESHOOTING CHART

PROBLEM	PROBABLE CAUSE
Call waiting signal or flash-hook for hold drops call.	On-hook timing too short (x03). Flash allowed timing too short (x04). Flash allowed timing set for a longer period than on-hook timing.
Failure to acquire dialtone on redial functions.	x05 time between release and re seize is too short for the particular CO.
Dialer re-order tone during slow dialing.	x11 inter-digit timeout too short.
No Centrex operation.	Not enabled (parameter x26 = 0). x25 Centrex digit not programmed to desired digit. Parameter 6R4 not programmed if occurring on auto dialing.
Improper OCC dialing.	601 area code not programmed (must be programmed to something even if not used in access control sequence). 6R5 access control sequence not programmed for dial tones present, or wrong route programmed (615 = route 0, 625 = 1, etc.). Access number not programmed for that route (6R1). No cut through (7) code in 6R5 parameter. No #6 code in 8xx search; results in delay before cut through. Carefully check 800 searches and access control sequences. Improper destination number format (x70).
911 Emergency number, or 411, etc., will not work.	One of the 800 searches has superseded it. Always be sure to check the function of emergency numbers. 911, 411, etc., not available on that exchange.

TABLE 17 CON'T: TROUBLESHOOTING CHART

PROBLEM	PROBABLE CAUSE
<p>Alternate search tables not being accessed.</p>	<p>Unit has been defaulted with a 903 command.</p> <p>Alternate search tables not selected in parameter x22.</p> <p>Improper programming of alternate search tables (821 through 835).</p> <p>Alternate access, authorization, area code, etc., not programmed.</p>
<p>Correctly programmed OCC number is going out over DDD.</p> <p>Three long spaced beeps on off-hook.</p>	<p>May be normal if NON detection is enabled (see 6R5); the destination may have been automatically placed in the temporary search tables for the pre-programmed length of time.</p> <p>Memory checksum error has occurred. Check all Dialer functions as soon as possible to ensure their integrity. If all functions are in tact, a power-down, then power-up may clear the problem. A recurrence of this symptom is a sign of Dialer memory problems.</p> <p>An illegal entry has been made and was not accepted by the Dialer. Re-enter the preceding data.</p>
<p>Dialer always cut through.</p>	<p>Power supply module not plugged in.</p> <p>Power cord not fully seated in Dialer connector.</p> <p>Line cords disconnected.</p> <p>Power supply module defective.</p> <p>Parameter x23 set to 9.</p> <p>Internal failure, return for repair.</p>

## APPENDIX A

## GLOSSARY OF TERMS

**A1.01** The following pages include a Glossary of Common Terminology that might be encountered in this manual. It is presented in the tabular format of 'term' followed by definition. It does not include all possible terms that may be encountered, but tries to include those that may not be common knowledge to the reader.

## GLOSSARY OF TERMS

TERM	DEFINITION
<b>ACCESS NUMBER</b>	The telephone number used to access the Other Common Carrier (OCC).
<b>AREA CODE (NPA)</b>	A three digit code used to designate the geographical numbering plan area used in nationwide dialing.
<b>ASCII</b>	The American Standard Code for Information Interchange. It is an eight bit alphanumeric transmission code. The first seven bits represent one of 128 standard ASCII characters. The eighth bit is a parity bit for error checking.
<b>AUTHORIZATION NUMBER</b>	Other Common Carrier (OCC) required authorization number.
<b>BAUD</b>	A term used to define the data transfer rate between a computer and a printer, data cassette, floppy disk drive, etc.. It is the reciprocal of the length in seconds of the shortest element of the digital code used in transmission.
<b>BUFFER</b>	An area in the computer's memory (RAM) that is used for temporary storage of data.
<b>CALL RECORDING</b>	The process of sending dialing information to an external printer (via the RS-232 Computer Port).
<b>CALL SEARCHING</b>	The process of comparing dialed digits (one by one) to data stored in the search tables. The result of the comparison usually results in some action being taken by the Dialer.

**SECTION MITL8350-047-100-NA**

TERM	DEFINITION
<p><b>CENTRAL OFFICE (CO)</b></p>	<p>A telephone switching system used to interconnect subscribers together. It is usually located at a point that is central to the subscribers.</p>
<p><b>CENTRAL PROCESSING UNIT</b></p>	<p>The circuitry in a computer that controls the computer's operation by interpreting and manipulating the information stored in the computer's memory (RAM or ROM).</p>
<p><b>CENTREX</b></p>	<p>Service providing direct inward and outward dialing for PABX extensions. The PABX is assigned a distinct Central Office code, and made part of the numbering plan. A main listed number will give access to the PABX operator.</p>
<p><b>CUT THROUGH MODE</b></p>	<p>All digits passed directly through the Dialer (no Dialer activity).</p>
<p><b>DATA TRANSMISSION RATE</b></p>	<p>See BAUD.</p>
<p><b>DDD</b></p>	<p>Direct Distance Dialing that allows long distance calls to be dialed direct, rather than going through an operator.</p>
<p><b>DOT MATRIX PRINTER</b></p>	<p>A printer whose printer head forms its characters by the use of numerous metal pins that punch out the image required on paper. Another method would use jets of ink to form the image. Any method that uses a matrix of dots to form a character on paper.</p>
<p><b>DTMF DIALING</b></p>	<p>A system of dialing that uses tones to transmit the dialed number to the Central Office.</p>
<p><b>END OFFICE</b></p>	<p>A local central office arranged for terminating subscriber lines and provided with trunks for establishing connections to and from other central offices and toll offices.</p>
<p><b>EXTENDED AREA SERVICE (EAS)</b></p>	<p>Telephone service that allows subscribers in one area to call subscribers in another area without a toll charge.</p>

TERM	DEFINITION
<b>FOREIGN EXCHANGE (FX)</b>	A classification of subscriber service that indicates service from any other central office other than the central office that would normally serve a subscriber. For example, a telephone in N.Y. has a Washington number assigned to it.
<b>GROUND START</b>	A method of signaling to the Central Office. This signaling requires that a ground be applied to the RING side of the Line to indicate an Off-hook condition.
<b>HERTZ (Hz)</b>	A term adapted as a unit of frequency preferred for world wide standardization and replacing "cycles per second". 1000 Hz = 1000 cycles per second.
<b>INTERCONNECT</b>	Companies other than the main telephone companies that supply telecommunications service and equipment.
<b>KEY SYSTEM</b>	A versatile switching system located on the customer's premises consisting of one or more multi-button telephone sets and associated equipment. Permits the mutual access to and control of several central office lines.
<b>LINE</b>	An installed telephone with its associated wiring and auxiliary equipment. Also referred to as a station or extension.
<b>LOOP START</b>	A method of signaling the Central Office. This signaling requires that a termination be placed across the Tip and Ring to indicate an off-hook condition to the Central Office.
<b>MAIN DISTRIBUTION FRAME</b>	A frame where cables terminate for cross-connecting to a central office or private automatic branch exchange, equipment and connections to lines.
<b>MEMORY</b>	The part of a computer where information can be stored, in binary form, and retrieved at any time.
<b>OFF PREMISE EXTENSION (OPX)</b>	A line connected to the PABX that is at a location other than the location of the PABX.

TERM	DEFINITION
<b>OFFICE CODE (NNX)</b>	Any of the 792 codes that can be used as an address for a 10,000 line unit of Central Office.
<b>OTHER COMMON CARRIER (OCC)</b>	A telephone system that provides long distance calls via other than normal carrier facilities, usually at a lower rate.
<b>PRIVATE AUTOMATIC BRANCH EXCHANGE (PABX)</b>	A telephone system located on the customer's premises (Private Exchange), that allows calling between extensions without the assistance of an operator (Automatic), and having trunks going to the central office (Branch).
<b>PRIVATE BRANCH EXCHANGE (PBX)</b>	The same as PABX above, with the exception that an attendant (operator) is required to process calls.
<b>ROM</b>	Read Only Memory, a memory storage chip that may be programmed by someone other than the manufacturer. This chip can only be programmed once, and becomes a permanent modification when the process is completed.
<b>RAM</b>	Random Access Memory, a section of memory that can be written to or read from at any point in time.
<b>RESERVE POWER</b>	A backup DC battery system used to maintain normal switch operations in the event of a power failure.
<b>ROTARY DIAL</b>	A dialing system that uses pulses to transmit the dialed number to the Central Office.
<b>SEQUENTIAL ACCESS</b>	A manner in which to read or write data as complete blocks of information, with each byte accessed in the exact order in which it was stored.
<b>SOFTWARE</b>	Electrically stored memory, either on a permanent basis (ROM) or for a short time (RAM), that causes a computer type system to operate (a set of instructions).
<b>SPEED CALLING</b>	A method of automatically completing a call to a subscriber by use of Speed Dialing.

TERM	DEFINITION
<b>SPEED DIALING</b>	The automatic dialing of a stored number by a microprocessor or similar unit. The process presupposes that the user will dial a single digit to cause the unit to dial many digits automatically, saving time and effort.
<b>STATIC</b>	Interference caused by electrical disturbances in the atmosphere, or any man-made electromagnetic device.
<b>SWITCHING SYSTEM</b>	A device that interconnects two or more subscriber circuits.
<b>TANDEM MODE</b>	When used with reference to the SMarT-1™ Dialer, this means that the dialer is used as an interface between a centralized personal computer and the telephone line (i.e., the Dialer becomes a TONE-to-ASCII converter to allow the display of received tones to the screen, and an ASCII-to-TONE converter to allow the remote programming of another Dialer (or any other device that can be programmed by the use of DTMF).
<b>TIE TRUNK</b>	A trunk between two PABX's.
<b>TIP &amp; RING</b>	Indicates each side of a pair of wires used throughout the telephone industry. The first wire is the tip and the second wire is the ring. Normally, the tip is ground and the ring is battery.
<b>TOLL OFFICE</b>	The office that handles toll calls (calls where there are additional charges).
<b>TRUNK</b>	A telephone circuit or channel between two Central Offices, or between a Central Office and a PBX or PABX.
<b>VOICE FREQUENCY</b>	The sound waves produced by the vibration of the voice box when speaking.
<b>WIDE AREA TELEPHONE SERVICE (WATS)</b>	For a basic monthly charge, the customer is allowed to make calls within a specific region without any additional charges. A WATS line can be incoming or outgoing, but not both. Outgoing WATS is OUTWATS and incoming WATS is INWATS.



--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**APPENDIX B****FCC INTERCONNECTION REQUIREMENTS****General**

**B1.01** This equipment has been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines through the standard connection cabling provided with the unit. This section is applicable to telephone interconnection in the United States.

**B1.02** Prior to the interconnection of this equipment, the local telephone company is to be notified; inform the company that you have FCC-registered equipment that you wish to connect to their trunks. Give them the following information:

- The telephone number of the line that will connect to the unit.
- The equipment being connected is a MITEL DATACOM INC. model SMarT-1™ or model SMarT-1A Common Carrier Access Dialer and Call Controller.
- The FCC Registration Number for the SMarT-1™ or SMarT-1A™ is EMP 85B-14558-LR-E
- The FCC Ringer Equivalence Number (REN) which is 0.7B.
- The Connector Jacks required are RJ31X.

**CONNECTION LIMITATIONS**

**B1.03** Due to the FCC Part 68 Rule, no connection can be made to party lines and to coin telephone service. This unit is designed to be used on standard-device telephone lines. If there are any questions about the telephone line, such as how many pieces of equipment may be connected to it, the telephone company will provide this information upon request.

**NETWORK CHANGES**

**B1.04** The telephone company may make changes to its communication service; such changes may include the change of trunk circuits, changes in the operational characteristics of its trunks, etc. Before doing this, however, the company shall provide official notification, so that the operation of the Dialer service will not be interrupted.

**MAINTENANCE LIMITATIONS**

**B1.05** This equipment has been registered with the FCC for direct connection to the telephone network. Under the FCC program, the user is restricted from making any changes or repairs and from performing any maintenance operations other than those specifically included in this document.

**B1.06** There are no user repairable parts within the unit. It is sealed against user maintenance. If opened, all warranties are voided.

**B1.07** No cabling or wiring changes within the unit are permitted by the user. Plug-ended cables, as detailed in this document, are to be used for all external connections between the unit and the telephone company interface jack.

**B1.08** Power supply components and cabling is only to be changed or maintained by MITEL DATACOM INC. or by an authorized agent of MITEL DATACOM INC.

**TROUBLE CORRECTIONS**

**B1.09** For all malfunctions, appropriate field service is provided by MITEL DATACOM INC. or its authorized agents.

**DISCONNECTION**

**B1.10** If it is ever decided to permanently disconnect the SMarT-1™ or SMarT-1A™ Dialer from the present line, please notify the telephone company of this change.

**APPENDIX C**

**DIAGRAMS AND ASCII TABLE**

**C1.01** Figures C1 and C2 on the following pages are a block diagram and a simplified electrical diagram for the SMarT-1™ Dialer. Table C1 is a listing of the standard 7-bit ASCII codes followed by the code equivalents. Table C2 contains Legal Dialer Programming Input Characters.




FIGURE C1: SMarT-1™ SYSTEM BLOCK DIAGRAM




FIGURE C2: SMarT-1™ SIMPLIFIED ELECTRICAL DIAGRAM

TABLE C1: ASCII CODES

CHAR.	HEX. CODE	CHAR.	HEX. CODE	CHAR.	HEX. CODE	CHAR.	HEX. CODE
NUL	00	SP	20	@	40	'	60
SOH	01	!	21	A	41	a	61
STX	02	"	22	B	42	b	62
ETX	03	#	23	C	43	c	63
EOT	04	\$	24	D	44	d	64
ENQ	05	%	25	E	45	e	65
ACK	06	&	26	F	46	f	66
BEL	07	'	27	G	47	g	67
BS	08	(	28	H	48	h	68
HT	09	)	29	I	49	i	69
LF	0A	*	2A	J	4A	j	6A
VT	0B	+	2B	K	4B	k	6B
FF	0C	,	2C	L	4C	l	6C
CR	0D	-	2D	M	4D	m	6D
SO	0E	.	2E	N	4E	n	6E
SI	0F	/	2F	O	4F	o	6F
DLE	10	0	30	P	50	p	70
DC1	11	1	31	Q	51	q	71
DC2	12	2	32	R	52	r	72
DC3	13	3	33	S	53	s	73
DC4	14	4	34	T	54	t	74
NAK	15	5	35	U	55	u	75
SYN	16	6	36	V	56	v	76
ETB	17	7	37	W	57	w	77
CAN	18	8	38	X	58	x	78
EM	19	9	39	Y	59	y	79
SUB	1A	:	3A	Z	5A	z	7A
ESC	1B	;	3B	[	5B		7B
FS	1C	<	3C	\	5C		7C
GS	1D	=	3D	]	5D		7D
RS	1E	>	3E	^	5E	~	7E
US	1F	?	3F	-	5F	DEL	7F

**Note:** Due to Dialer processing necessities, ASCII entries in the 602, 6r0 and 604 paramters of FF or BB will be treated as ## (end the string entry) and can not be entered. Similarly, the last character of the string may not be B, F or #. However, a single F or B within a string is allowed. If the last character of a string must be B, then it must be followed with a non-printing character such as a space (hexadecimal 20). If necessary, the LF, FF, CR, BEL and so on may also be used within a string.

TABLE C2: LEGAL DIALER PROGRAMMING INPUT CHARACTERS

FROM STANDARD DTMF PHONE	FROM TERMINAL	DIALER INTERPRETATION
0 through 9	0 through 9	0 through 9
#, *	#, *	#, *
-	A or a	*
-	B or b	#
-	BB or bb	##
-	C or c	C
-	D or d	D
-	E or e	E
-	F or f	F if it is within a string. SPACE if it is last character of a string.
-	FF or ff	##
-	Period	#
-	Comma	#
-	Hyphen	#
-	LF	#
-	CR	#
-	Space	#
-	999	Exit PROGRAM mode
999	<ESC>	Exit PROGRAM mode
-	X or x	Exit PROGRAM mode
Go ON-HOOK	-	Exit PROGRAM mode
<b>SPECIALS</b>		
-	C0	For L1H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5
-	C1	For L2H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5
-	C2	For L3H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5
-	C3	For L4H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5

**Note:** The fourth column DTMF (L1H4 through L4H4) can only be programmed for dial-out via the terminal. The Dialer can not recognize these Tone Pairs (per se) and therefor can not be programmed via any 16-button DTMF keypad.



--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## APPENDIX D OVERALL INDEX

CONTENTS	PAGE	CONTENTS	PAGE
ACCESS CODE		ASCII CODES	
SEE GLOSSARY OF TERMS	A-1	SEE APPENDIX C	C-1
ACCESS CONTROL SEQUENCE (ACS)		SEE TABLE C1	C-4
DEFINITION	19	ASCII COMPATIBLE TERMINAL	
ROUTE ACCESS	19	CONNECTIONS	34
SEE ROUTE SELECTION	19	ERRORS	36
SEE TABLE 3	20	PROCEDURE	35
ACCESS CONTROL SEQUENCE CODES		PROGRAMMING EXAMPLE	35
SEE TABLE 3	20	PROTOCOL	34
ACCESS METHOD NUMBER		SEE METHOD 1	34
SEE ROUTE SELECTION	19	ASCII TABLE	
ACCESS NUMBER		SEE APPENDIX C	C-4
SEE STORE AND FORWARD	4	AUTHORIZATION CODE	
SEE ROUTE SELECTION	19	SEE STORE AND FORWARD	4
ACCOUNT NUMBER		AUTHORIZATION NUMBER	
DEFINITION	22	DEFINITION	19
SEE ROUTE SELECTION	19	SEE ROUTE SELECTION	19
ACKNOWLEDGE TONES		BASIC PROGRAMS	
PARAMETERS	57	SEE DETAILED PROGRAMMING	33
SEARCH TABLES	57	BATTERY BACK-UP	
SEE DETAILED PROGRAMMING INSTRUCTIONS	57	SEE POWER	6
STRINGS	57	SEE POWER FAILURE CONDITIONS	4
ACTION DIGITS		BAUD	
SEE TABLE 2	15	SEE GLOSSARY OF TERMS	A-1
SEE TEMPLATE DESCRIPTION	14	BEGIN DIALING AFTER 1ST DIGIT	
ACTION ON DIALING		SEE EXAMPLE 3	18
SEE SIMPLIFIED PROGRAMMING	10	SEE SEARCH EXAMPLES	18
ADAPTIVE CALL ROUTING		BUITER	
SEE DEFINITION OF TERMS	5	SEE GLOSSARY OF TERMS	A-1
ADDITIONAL SEARCH INFORMATION		CABLING	
CUT-THROUGH	19	SEE CONNECTIONS	7
DO NOTHING	19	CALL COSTING	
ENOUGH DIGITS	19	SEE CALL RECORDING	5
SEE OPERATION	18	CALL COSTING UNIT	
SPEED CALL	18	SEE CALL RECORDING OPERATION	23
SPEED CALL TRIGGER	18	SEE CONNECTING A STORAGE DEVICE	25
ALTERNATE ROUTES		CALL RECORD FORMAT	
SEE PARAMETERS	47	ASCII CHARACTERS	29
ALTERNATE ROUTING		MTEL FORMAT	26
SEE LEAST CALL ROUTING	6	RECORD EXAMPLES	30,31
APPENDIX A		SEE CALL RECORDING OPERATION	23
GLOSSARY OF TERMS	A-1	SMarT-1 FORMAT	28
APPENDIX B		SMarT-1 CALL RECORD FORMAT	29
CONNECTION LIMITATIONS	B-1	CALL RECORDING	
CONNECTOR JACKS	B-1	CONNECTING A STORAGE DEVICE	24
DISCONNECTION	B-2	SEE DEFINITION OF TERMS	5
FCC INTERCONNECTION REQUIREMENTS	B-1	SEE GLOSSARY OF TERMS	A-1
FCC REGISTRATION NUMBER	B-1	CALL RECORDING OPERATION	
MAINTENANCE LIMITATIONS	B-1	CALL COSTING UNIT	25
NETWORK CHANGES	B-1	CALL RECORD FORMAT	25
RINGER EQUIVALENCE NUMBER	B-1	CALL RECORDS	23
TROUBLE CORRECTIONS	B-2	CONCENTRATOR	25
APPENDIX C		CONNECTING A STORAGE DEVICE	24
ASCII CODES	C-1	MODEM	25
ASCII TABLE	C-4	SEE OPERATION	23
DIAGRAMS	C-1	CALL RECORDS	
LEGAL DIALER PROGRAMMING INPUT CHARACTERS	C-5	ASCII	22
SMarT-1 SIMPLIFIED ELECTRICAL DIAGRAM	C-3	PAGE TITLE	22
SMarT-1 SYSTEM BLOCK DIAGRAM	C-2	PRINTER	22
APPENDIX D		RS-232 PORT	22
OVERALL INDEX	D-1	SEE CALL RECORDING OPERATION	23
AREA CODE		SEE OPERATION	23
SEE DEFINITION OF TERMS	5	CALL SEARCHING	
SEE GLOSSARY OF TERMS	A-1	SEE DEFINITION OF TERMS	5
AREA CODE (NPA)		SEE GLOSSARY OF TERMS	A-1
SEE GLOSSARY OF TERMS	A-1	CENTRAL OFFICE (CO)	
ASCII		SEE GLOSSARY OF TERMS	A-2
SEE CALL RECORDS	23		
SEE GLOSSARY OF TERMS	A-1		
ASCII CHARACTERS			
SEE CALL RECORD FORMAT	29		

**SECTION MITL8350-047-100-NA**

CONTENTS	PAGE	CONTENTS	PAGE
CENTRAL PROCESSING UNIT (CPU)		DATA FOR ROUTES	
SEE GLOSSARY OF TERMS	A-2	SEE TABLE 8	46
CENTREX		DATA FOR TRUNKS	
SEE GLOSSARY OF TERMS	A-2	SEE TABLE 8	40-45
CENTREX ACCESS DIGIT		DATA TRANSMISSION RATE	
SEE CENTREX OPERATION	23	SEE GLOSSARY OF TERMS	A-2
SEE OTHER COMPARISONS	16	DATA TYPES	
CENTREX COMPATIBLE		PARAMETERS	38
SEE DEFINITION OF TERMS	6	SEARCH TEMPLATES	38
CENTREX NUMBER		SEE ENTERING DATA	37
SEE ROUTE SELECTION	19	STRINGS	38
CENTREX OPERATION		DCE	
CENTREX ACCESS DIGIT	23	SEE RS-232 PORT	7
CENTREX STRING	23	DDD	
SEE OPERATION	23	SEE GLOSSARY OF TERMS	A-2
CENTREX STRING		DDD ACCESSING PROCEDURE	
DEFINITION	19	SEE ROUTE SELECTION	19
SEE CENTREX OPERATION	23	DDD ACCESSING USING ACS	
SEE ROUTE SELECTION	19	SEE ROUTE SELECTION	19
CHANGES TO DEFAULT DATA BASE		DDD NETWORK	
SEE SIMPLIFIED OCC PROGRAMMING	11	SEE ROUTES	16
CLONING		DEFAULT ACTIONS	
CONDITIONS	59	SEE SIMPLIFIED PROGRAMMING	10
PROCEDURE	59	DEFAULT CONFIGURATION	
REQUIRED EQUIPMENT	59	SEE METHOD 2	36
SEE METHOD 4	59	SEE SIMPLIFIED PROGRAMMING	10
SEE PROGRAMMING METHOD 4	33	DEFAULT DATA BASE	
CLONING TIME		SEE METHOD 2	36
SEE PROGRAMMING METHOD 4	33	SEE SIMPLIFIED PROGRAMMING	10
CO		DEFAULT DATA BASE CHANGE	
SEE GLOSSARY OF TERMS	A-2	SEE SIMPLIFIED PROGRAMMING	11
CO GENERATED DIAL TONE		DEFAULT DATA BASE LOADING PROCEDURE	
SEE OPTIONS	13	SEE METHOD 2	36
COMPARISON		DEFAULT SETTINGS	
SEE SEARCHING	14	SEE TABLE 11	53-54
COMPARISON RESULTS		DEFAULT TRUNK AND DIALING	
SEE SEARCHING	14	SEE SIMPLIFIED OCC PROGRAMMING	11
COMPUTER		DEFINITION OF TERMS	
SEE PROGRAMMING METHOD 1	33	ADAPTIVE CALL ROUTING	5
COMPUTER CONNECTION		AREA CODE	5
SEE RS-232 PORT	7	CALL RECORDING	5
CONCENTRATOR		CALL SEARCHING	5
SEE CALL RECORDING OPERATION	25	CENTREX COMPATIBLE	6
SEE CONNECTING A STORAGE DEVICE	25	DTMF/ROTARY DIAL	4
CONFIGURATION		GROUND START/LOOP START	4
SEE CALL RECORDING OPERATION	23	LEAST COST ROUTING	6
SEE SIMPLIFIED PROGRAMMING	10	LINES	5
CONNECTING A STORAGE DEVICE		MODELS	5
CALL COSTING UNIT	25	OFFICE CODE	5
PRINTER	24	POWER	6
SEE CALL RECORDING OPERATION	24	POWER FAILURE CONDITIONS	4
TERMINAL	24	RS-232 PORT	5
CONNECTION LIMITATIONS		SEE GENERAL DESCRIPTION	3
SEE APPENDIX B	B-1	SPEED CALL	6
CONNECTIONS		STORE AND FORWARD	4
EARTH GROUND	7	TRUNK SIDE DIALER	4
POWER	7	TWO (2) MODELS AVAILABLE	5
RS-232 PORT	7	USER TRANSPARENT	4
SEE FIGURE 2	8	VERSATILE PROGRAMMING	5
SEE FIGURE 3	8	DESTINATION NUMBER	
SEE FIGURE 4	9	DEFINITION	19
SEE INSTALLATION	7	SEE ROUTE SELECTION	19
SEE MODELS AVAILABLE	5	DETAILED DESCRIPTION	
SEE TELEPHONE LINES	7	OPTIONS	13
CONNECTOR JACKS		SEARCHING	14
SEE APPENDIX B	B-1	SEE OPERATION	13
CONNECTOR PANEL		DETAILED PROGRAMMING	
SEE FIGURE 2	8	ACKNOWLEDGE TONES	57
CUT-THROUGH MODE		DETAILED PROGRAMMING INSTRUCTIONS	34
SEE ADDITIONAL SEARCH INFORMATION	18	ENTERING DATA	37
SEE GLOSSARY OF TERMS	A-2	INTRODUCTION	33
DAMAGED GOODS		METHOD 1	34
SEE UNPACKING	7	METHOD 2	36
DATA FOR ALTERNATE ROUTES		PROGRAMMING METHOD 1	33
SEE TABLE 8	47	PROGRAMMING METHOD 2	33
		PROGRAMMING METHOD 3	33
		PROGRAMMING METHOD 4	33

CONTENTS	PAGE	CONTENTS	PAGE
DETECTOR/TIMEOUT CODES		EXTENDED AREA SERVICE (EAS)	
SEE TABLE 4a	21	SEE GLOSSARY OF TERMS	A-2
SEE TABLE 4b	21		
SEE TABLE 9a	50	FCC INTERCONNECTION REQUIREMENTS	
SEE TABLE 9b	50	GENERAL	B-1
DIAGRAMS		SEE APPENDIX B	B-1
SEE APPENDIX C	C-1	FCC REGISTRATION NUMBER	
DIAL TONE OPTIONS		SEE APPENDIX B	B-1
SEE OPTIONS	13	FEATURES	
DIALER CONNECTIONS		SEE GENERAL DESCRIPTION	3
SEE GENERAL DESCRIPTION	13	FIELD FORMAT EXAMPLE	
DIALER OPERATION		MITEL FORMAT	30
SEE GENERAL DESCRIPTION	13	SMarT-1 FORMAT	31
DIALER PROGRAMMING		FIRST TIME	
SEE METHOD 2	36	SEE ENTERING PROGRAMMING MODE	37
DIALER REPLACEMENT		FORCE ON ROUTE	
SEE MAINTENANCE	67	SEE SEARCH EXAMPLES	17
DIALING TYPES		FORCE ROUTE	
SEE DTMF/ROTARY DIAL	4	SEE SEARCH EXAMPLES	18
DIGIT 9		FOREIGN EXCHANGE (FX)	
SEE CENTREX COMPATIBLE	6	SEE GLOSSARY OF TERMS	A-3
DISCONNECTION		FORWARD	
SEE APPENDIX B	B-2	SEE STORE AND FORWARD	4
DO NOTHING		FX	
SEE ADDITIONAL SEARCH INFORMATION	18	SEE GLOSSARY OF TERMS	A-3
DOCUMENT SECTIONS		FX GROUPS	
SEE INTRODUCTION	1	SEE CENTREX OPERATION	23
DOT MATRIX			
SEE GLOSSARY OF TERMS	A-2	GENERAL	
DOT MATRIX PRINTER		SEE FIGURE 1	1
SEE GLOSSARY OF TERMS	A-2	SEE INTRODUCTION	1
DTMF DIAL		GENERAL DESCRIPTION	
SEE DEFINITION OF TERMS	4	DEFINITION OF TERMS	3
SEE GLOSSARY OF TERMS	A-4	FEATURES	3
DTMF DIALING		SEE OPERATION	13
SEE GLOSSARY OF TERMS	A-2	GENERAL INFORMATION	
DTMF TELEPHONE		SEE DEFINITION OF TERMS	3
SEE PROGRAMMING METHOD 2	33	GENERAL PURPOSE STRINGS	
DTMF TO PULSE CONVERSION		SEE ROUTE SELECTION	21
SEE NON CHECKING	22	SEE TABLE 5	22
		GENERAL USE	
EARTH GROUND		SEE SIMPLIFIED OCC PROGRAMMING	11
SEE CONNECTIONS	7	GLOSSARY OF TERMS	
EAS		SEE APPENDIX A	A-1
SEE GLOSSARY OF TERMS	A-2	SEE DEFINITION OF TERMS	3
ECONOMICAL USAGE		GROUND START	
SEE LEAST CALL ROUTING	5	SEE DEFINITION OF TERMS	4
ELECTRICAL SPECIFICATIONS		SEE GLOSSARY OF TERMS	A-3
SEE SPECIFICATIONS	65		
SEE TABLE 15	65	HARDWARE	
ELECTRICAL/MECHANICAL		SEE SPECIFICATIONS	63
SEE SPECIFICATIONS	65	HARDWARE SPECIFICATIONS	
ELECTRICAL/MECHANICAL SPECIFICATIONS		SEE TABLE 13	63,64
SEE TABLE 15	65	SMarT-1 HARDWARE SPECIFICATIONS	63
END OFFICE		HERTZ (Hz)	
SEE GLOSSARY OF TERMS	A-2	SEE GLOSSARY OF TERMS	A-3
ENDING TONE		HISTORY	
SEE USER TRANSPARENT	4	SEE INTRODUCTION	2
ENOUGH DIGITS		HOT LINE	
SEE ADDITIONAL SEARCH INFORMATION	18	SEE OPTIONS	13
ENTERING DATA			
DATA TYPES	37	IMMEDIATE RECONNECT	
PARAMETER CODES	38	SEE OPTIONS	13
PARAMETERS	39-47	INITIALIZATION	
SEARCH TABLES	52	SEE SIMPLIFIED PROGRAMMING	10
SEARCH TEMPLATE	38	INITIALIZING THE DIALER	
SEE DETAILED PROGRAMMING INSTRUCTIONS	34	SEE SIMPLIFIED PROGRAMMING	10
SPECIAL FUNCTIONS	56	INSTALLATION	
SPEED CALL ENTRIES	51	CONNECTIONS	7
STRINGS	38,48	DEFINITION	7
ENTERING PROGRAMMING MODE		INTRODUCTION	7
FIRST TIME	37	MOUNTING	7
OTHER THAN FIRST TIME	37	SIMPLIFIED PROGRAMMING	10
SEE METHOD 2	37		
EXPIRY DATE TAG			
SEE NON CHECKING	22		

**SECTION MITL8350-047-100-NA**

CONTENTS	PAGE
UNPACKING	7
INTENDED AUDIENCE	
SEE INTRODUCTION	2
INTERCONNECT	
SEE GLOSSARY OF TERMS	A-3
INTERNAL DIAL TONE	
SEE OPTIONS	13
INTRODUCTION	
DOCUMENT SECTIONS	1
GENERAL	1
HISTORY	2
INTENDED AUDIENCE	2
OVERVIEW	1
JAGKS	
SEE APPENDIX B	B-1
KEY	
SEE SPEED CALLS	22
KEY SYSTEM	
SEE GLOSSARY OF TERMS	A-3
LEAST CALL ROUTING	
SEE DEFINITION OF TERMS	6
LEAST COST ROUTING	
SEE CENTREX COMPATIBLE	6
SEE DEFINITION OF TERMS	6
LEGAL DIALER PROGRAMMING INPUT CHARACTERS	
SEE APPENDIX C	C-1
SEE TABLE C2	C-5
LINE	
SEE DEFINITION OF TERMS	5
SEE GLOSSARY OF TERMS	A-3
LINE SPLIT	
SEE OPTIONS	13
LINE TYPES	
SEE GROUND START/LOOP START	4
LINES	
OPERATION	5
SEE DEFINITION OF TERMS	5
LOADING DEFAULT DATA	
SEE SIMPLIFIED OCC PROGRAMMING	11
LOCAL PROGRAMMING	
SEE PROGRAMMING METHOD 2	33
LOGIC LEVELS	
SEE RS-232 CABLE	31
LOOP START	
SEE DEFINITION OF TERMS	4
SEE GLOSSARY OF TERMS	A-3
SEE GROUND START/LOOP START	4
MAIN DISTRIBUTION FRAME	
SEE GLOSSARY OF TERMS	A-3
MAINTENANCE	
DIALER REPLACEMENT	67
GENERAL	67
MAINTENANCE LIMITATIONS	
SEE APPENDIX R	B-1
MANUAL ENTRY MODE	
SEE PROGRAMMING METHOD 2	33
MECHANICAL SPECIFICATIONS	
SEE SPECIFICATIONS	65
SEE TABLE 15	65
MEMORY	
SEE GLOSSARY OF TERMS	A-3
MEMORY RETENTION	
SEE POWER FAILURE CONDITIONS	4
METHOD 1	
SEE DETAILED PROGRAMMING	34
ASCII COMPATIBLE TERMINAL	34
METHOD 2	
411 AND 911 PROGRAMMING	36
DEFAULT CONFIGURATION	36

CONTENTS	PAGE
DEFAULT DATA BASE	36
DEFAULT DATA BASE LOADING PROCEDURE	36
DIALER PROGRAMMING	36
ENTERING PROGRAMMING MODE	37
SEE DETAILED PROGRAMMING	36
METHOD 3	
SEE ENTERING DATA	58
TANDEM MODE	58
METHOD 4	
CLONING	59
PROCEDURE	60
SEE DETAILED PROGRAMMING INSTRUCTIONS	34
SEE ENTERING DATA	59
MITEL FORMAT	
EXAMPLE	30
SEE CALL RECORD FORMAT	26
SEE TABLE 6	27
MODELS AVAILABLE	
SEE DEFINITION OF TERMS	5
MODEM	
SEE CALL RECORDING OPERATION	24
MOUNTING	
SEE INSTALLATION	7
MOUNTING BRACKET	
SEE MOUNTING	7
NETWORK CHANGES	
SEE APPENDIX B	B-1
NNX	
SEE GLOSSARY OF TERMS	A-4
NON CHECKING	
SEE NOT ON NETWORK (NON) CHECKING	22
NOT ON NETWORK (NON) CHECKING	
DTMF TO PULSE CONVERSION	22
EXPIRY DATE TAG	22
NON TONE	22
SEARCH TABLES	57
SEE OPERATION	22
NON TONE	
SEE NOT ON NETWORK (NON) CHECKING	22
NORMAL OPERATION	
SEE OPTIONS	13
NPA	
SEE GLOSSARY OF TERMS	A-1
NPA NUMBERS	
SEE AREA CODE	5
NUMBER OF LINES	
SEE MODELS AVAILABLE	5
NNX NUMBERS	
SEE GLOSSARY OF TERMS	A-4
SEE OFFICE CODE	5
OCC	
SEE GLOSSARY OF TERMS	A-4
OCC HLOT LINE	
SEE OPTIONS	13
OCC NETWORK	
SEE ROUTES	16
OFF PREMISE EXTENSION (OPX)	
SEE GLOSSARY OF TERMS	A-3
OFFICE CODE (NNX)	
SEE DEFINITION OF TERMS	5
SEE GLOSSARY OF TERMS	A-4
OPERATION	
ADDITIONAL SEARCH INFORMATION	18
CALL RECORDING OPERATION	23
CALL RECORD FORMAT	25
CALL RECORDS	23
CENTREX OPERATION	23
DETAILED DESCRIPTION	13
GENERAL DESCRIPTION	13
INTRODUCTION	13
NOT ON NETWORK (NON) CHECKING	22
OTHER COMPARISONS	16
ROUTE SELECTION	19

CONTENTS	PAGE	CONTENTS	PAGE
ROUTES	16	PRIVATE BRANCH EXCHANGE	
SEARCH EXAMPLES	17	SEE GLOSSARY OF TERMS	A-4
SEE ADAPTIVE CALL ROUTING	5	PROCEDURE	
SEE LINES	5	SEE METHOD 4	60
SPEED CALLS	22	PROGRAMMING COPIES	
TEMPLATE DESCRIPTION	14	SEE VERSATILE PROGRAMMING	5
WIRING CONSIDERATIONS	31	PROGRAMMING EXAMPLE	
OPTIONS		SEE ASCII COMPATIBLE TERMINAL	34
SEE DETAILED DESCRIPTION	13	PROGRAMMING METHOD 1	
OPX		COMPUTER	33
SEE GLOSSARY OF TERMS	A-3	SEE DETAILED PROGRAMMING	33
ORDERING INFORMATION		TERMINAL	33
GENERAL	69	PROGRAMMING METHOD 2	
SEE TABLE 16	69	DTMF TELEPHONE	33
SMarT-1 ORDERING INFORMATION	69	LOCAL PROGRAMMING	33
ORIENTATION		MANUAL ENTRY MODE	33
SEE MOUNTING	7	REMOTE PROGRAMMING	33
OTHER COMMON CARRIER (OCC)		SEE DETAILED PROGRAMMING	33
SEE GLOSSARY OF TERMS	A-4	PROGRAMMING METHOD 3	
OTHER COMPARISONS		REMOTE PROGRAMMING	33
CENTREX ACCESS DIGIT	16	SEE DETAILED PROGRAMMING	33
REDIAL	16	TANDEM MODE	33
RESTART CHARACTER	16	PROGRAMMING METHOD 4	
SEE OPERATION	13	CLONING	33
OTHER TECHNIQUES		SEE DETAILED PROGRAMMING	33
SEE DETAILED PROGRAMMING	33	PROGRAMMING METHODS	
OTHER THAN FIRST TIME		SEE DETAILED PROGRAMMING	33
SEE ENTERING PROGRAMMING MODE	37	PROGRAMMING OPTIONS	
OUTGOING CALL		SEE VERSATILE PROGRAMMING	5
SEE GENERAL DESCRIPTION	13	PROGRAMMING SECURITY	
OVERALL INDEX		SEE VERSATILE PROGRAMMING	5
SEE APPENDIX D	D-1	PULSES	
OVERVIEW		SEE DTMF/ROTARY DIAL	4
SEE INTRODUCTION	1		
		RAM	
PABX		SEE GLOSSARY OF TERMS	A-4
SEE GLOSSARY OF TERMS	A-4	RECORD EXAMPLES	
PACKAGE CONTENTS		MITEL FORMAT	30
SEE UNPACKING	7	SEE CALL RECORD FORMAT	29
PACKING LIST		SMarT-1 FORMAT	31
SEE UNPACKING	7	REDIAL	
PAGE TITLE		SEE OTHER COMPARISONS	16
SEE CALL RECORDS	23	REMOTE PROGRAMMING	
PARAMETER		SEE PROGRAMMING METHOD 2	33
DATA TYPES	37	SEE PROGRAMMING METHOD 3	33
PARAMETER CODES		RESERVE POWER	
SEE ENTERING DATA	37	SEE GLOSSARY OF TERMS	A-4
PARAMETERS		RESTART CHARACTER	
ALTERNATE ROUTES	47	SEE OTHER COMPARISONS	16
DEFINITION	37	RINGER EQUIVALENCE NUMBER	
SEE ACKNOWLEDGE TONES	57	SEE APPENDIX B	B-1
SEE ENTERING DATA	38	RJ31X JACKS	
SEE TABLE 8	39	SEE TELEPHONE LINES	7
TRUNKS	40-45	SEE FIGURE 4	9
PBX		ROM	
SEE GLOSSARY OF TERMS	A-4	SEE GLOSSARY OF TERMS	A-4
PERSONAL COMPUTER		ROTARY DIAL	
SEE PROGRAMMING METHOD 1	33	SEE DEFINITION OF TERMS	4
POWER		SEE DTMF/ROTARY DIAL	4
SEE CONNECTIONS	7	SEE GLOSSARY OF TERMS	A-4
SEE DEFINITION OF TERMS	6	ROUTE ACCESS	
POWER FAILURE CONDITIONS		OCC NETWORK STEPS	16
SEE DEFINITION OF TERMS	4	SEE ACCESS CONTROL SEQUENCE	19
POWER OUTAGE		SEE ROUTES	16
SEE POWER FAILURE CONDITIONS	4	ROUTE OVERRIDE	
POWER PACK		SEE SPEED CALLS	22
SEE POWER	7	ROUTE SELECTION	
PREFER ROUTE		ACCESS CONTROL SEQUENCE (ACS)	19
SEE SEARCH EXAMPLES	17,18	ACCESS NUMBER	19
PRINTER		ACCOUNT NUMBER	19
SEE CALL RECORDS	23	AUTHORIZATION NUMBER	19
SEE CONNECTING A STORAGE DEVICE	24	CENTREX NUMBER	19
PRINTER CONNECTION		DDD ACCESSING PROCEDURE	21
SEE RS-232 PORT	7	DDD ACCESSING USING ACS	22
PRIVATE AUTOMATIC BRANCH EXCHANGE (PBX)		DESTINATION NUMBER	19
SEE GLOSSARY OF TERMS	A-4	GENERAL PURPOSE STRINGS	22

**SECTION MITL8350-047-100-NA**

CONTENTS	PAGE	CONTENTS	PAGE
SEE OPERATION	19	SEARCH TEMPLATE	
SEE TABLE 3	20	DEFINITION	38
SEE TABLE 4a	21	SEE ENTERING DATA	36
SEE TABLE 4b	21	SEARCH-TEMPLATES	
SEE TABLE 5	22	DATA TYPES	38
TYPICAL CARRIER ACCESS EXAMPLE	21	SEARCHING	
ROUTES		COMPARISON	14
DDD NETWORK	16	COMPARISON RESULTS	14
OCC NETWORK	16	SEARCH TABLES	14
ROUTE ACCESS	16	SEARCHING ACTION	14
SEE OPERATION	16	SEE DETAILED DESCRIPTION	14
SEE PARAMETERS	38	SEARCHING ACTION	
ROUTING		SEE SEARCHING	14
SEE LINES	5	SECURITY	
ROUTING DATA		SEE STORE AND FORWARD	4
SEE LINES	5	SECURITY ACCESS CODE	
ROUTING DECISIONS		SEE SIMPLIFIED OCC PROGRAMMING	11
SEE CALL SEARCHING	5	SELECT ROUTE	
RS-232 CABLE		SEE SEARCH EXAMPLES	17
SEE LOGIC LEVELS	32	SEQUENTIAL ACCESS	
SEE WIRING CONSIDERATIONS	31	SEE GLOSSARY OF TERMS	A-4
RS-232 INTERFACE CONNECTOR		SERVICE	
SEE FIGURE 3	6	SEE MODELS	5
RS-232 PIN-OUT		SIMPLIFIED DIALING	
SEE RS-232 INTERFACE CONNECTOR	8	SEE SPEED CALL	6
RS-232 PORT		SIMPLIFIED ELECTRICAL DIAGRAM	
SEE CALL RECORDS	23	SEE FIGURE C2	C-3
SEE CONNECTIONS	7	SIMPLIFIED OCC PROGRAMMING	
SEE DEFINITION OF TERMS	5	SEE SIMPLIFIED PROGRAMMING	11
SEE SPECIFICATIONS	63	ACTION ON DIALING	10
RS-232 PORT SPECIFICATIONS		SEE INSTALLATION	10
SEE SPECIFICATIONS	63	SEE SIMPLIFIED OCC PROGRAMMING	7
SEE TABLE 14	65	SIMPLIFIED PROGRAMMING	
SEARCH ACTION		ACTION ON DIALING	10
SEE SEARCHING	14	INITIALIZING THE DIALER	10
SEE SEARCH TABLES	53,54	SEE INSTALLATION	10
SEARCH EXAMPLES		SIMPLIFIED OCC PROGRAMMING	11
1+ CALLS TO CARRIER (EXAMPLE 1)	17	SMarT-1 CALL RECORD FORMAT FIELDS	
1+ CALLS TO CARRIER, 1+800 TO DDD (EXAMPLE 2)	17	SEE TABLE 7	29
1+ CALLS TO CARRIER, 1+800 TO DDD (EXAMPLE 4)	18	SMarT-1 FORMAT	
BEGIN DIALING AFTER 1ST DIGIT (EXAMPLE 3)	16	EXAMPLE	31
FORCE ROUTE	18	SEE CALL RECORD FORMAT	28
PREFER ROUTE	18	SEE TABLE 7	29
SEE OPERATION	17	SMarT-1 HARDWARE SPECIFICATIONS	
SELECT ROUTE	18	SEE TABLE 13	63,64
TRIGGER CODE	18	SMarT-1 ORDERING INFORMATION	
SEARCH TABLE		SEE ORDERING INFORMATION	69
DESCRIPTION	14	SMarT-1 SIMPLIFIED ELECTRICAL DIAGRAM	
SEARCH TABLE CODING		SEE APPENDIX C	C-1
EXAMPLES	52	SEE FIGURE C2	C-3
SEARCH TABLE ENTRIES		SMarT-1 SYSTEM BLOCK DIAGRAM	
SEE TABLE 11	53,54	SEE APPENDIX C	C-1
SEARCH TABLE 801 AND 802		SEE FIGURE C1	C-2
SEE ENTERING DATA	55	SOFTWARE	
SEARCH TABLE 803 AND 823		SEE GLOSSARY OF TERMS	A-4
SEE ENTERING DATA	55	SPECIAL FUNCTIONS	
SEARCH TABLE 804 AND 824		CODING	55
SEE ENTERING DATA	55	SEE ENTERING DATA	56
SEARCH TABLE 807 AND 827		SEE TABLE 12	57
SEE ENTERING DATA	56	SPECIFICATIONS	
SEARCH TABLE 808 AND 828		ELECTRICAL	65
SEE ENTERING DATA	56	ELECTRICAL/MECHANICAL	65
SEARCH TABLE 810 AND 830		HARDWARE	63
SEE ENTERING DATA	56	MECHANICAL	65
SEARCH TABLE 811 AND 831		RS-232 PORT	65
SEE ENTERING DATA	56	SPEED CALL	
SEARCH TABLES		SEE ADDITIONAL SEARCH INFORMATION	18
CODES	52	SEE DEFINITION OF TERMS	6
DEFAULT SETTINGS	55,56	SPEED CALL ACTIVATION	
SEE ACKNOWLEDGE TONES	57	SEE SPEED CALL	6
SEE ENTERING DATA	52	SPEED CALL AREA SIZE	
SEE NON CHECKING	22	SEE SPEED CALL	6
SEE SEARCHING	14	SPEED CALL ENTRIES	
SEE TABLE 11	53,54	CODES	51
		SEE ENTERING DATA	51
		SEE TABLE 10	51

CONTENTS	PAGE	CONTENTS	PAGE
SPEED CALL TRIGGER		TROUBLE CORRECTIONS	
SEE ADDITIONAL SEARCH INFORMATION	18	SEE APPENDIX B	B-2
SPEED CALLING		TROUBLESHOOTING	
SEE GLOSSARY OF TERMS	A-4	GENERAL	71
SPEED CALLS		TROUBLESHOOTING CHART	
KEY	22	SEE TABLE 17	71-74
ROUTE OVERRIDE	22	SEE TROUBLESHOOTING	71
SEE OPERATION	22	TRUNK	
SPEED DIALING		SEE GLOSSARY OF TERMS	A-5
SEE GLOSSARY OF TERMS	A-5	TRUNK ACCESS	
STATIC		SEE GENERAL DESCRIPTION	13
SEE GLOSSARY OF TERMS	A-5	TRUNK PROGRAMMING	
STORAGE DEVICE		SEE GENERAL DESCRIPTION	13
PRINTER	24	TRUNK SIDE DIALER	
TERMINAL	24	CONNECTIONS	4
STORE		SEE DEFINITION OF TERMS	4
SEE STORE AND FORWARD	4	TRUNK TYPES	
STORE AND FORWARD		SEE GROUND START/LOOP START	4
SEE DEFINITION OF TERMS	4	TRUNKS	
STRING		SEE TABLE 8	39-45
DEFINITION	38	TYPE OF LINES	
STRING DATA ENTRY		SEE GENERAL DESCRIPTION	13
SEE TABLE 9	49,50	TYPE OF UNIT	
STRING ENTRY EXAMPLE		SEE APPENDIX B	B-1
SEE STRINGS	48	TYPICAL CARRIER ACCESS EXAMPLE*	
STRINGS		SEE ROUTE SELECTION	21
DATA TYPES	37	UNIT SIZE	
SEE ACKNOWLEDGE TONES	57	SEE MOUNTING	7
SEE ENTERING DATA	48	UNPACKING	
SEE TABLE 9	50	SEE INSTALLATION	7
SEE TABLE 9a	50	USER TRANSPARENT	
SEE TABLE 9b	50	SEE DEFINITION OF TERMS	4
STRING ENTRY EXAMPLE	48	USOCRJ31X JACK AND CABLE ASSEMBLY	
SWITCHING SYSTEM		SEE FIGURE 4	9
SEE GLOSSARY OF TERMS	A-5	VERSATILE PROGRAMMING	
SYSTEM BLOCK DIAGRAM		SEE DEFINITION OF TERMS	5
SEE FIGURE C1	C-4	VOICE FREQUENCY	
SYSTEM WIDE DATA PARAMETERS		SEE GLOSSARY OF TERMS	A-5
SEE TABLE 8	39	VOLTAGE REQUIREMENTS	
TANDEM MODE		SEE POWER	7
SEE GLOSSARY OF TERMS	A-5	WATS	
SEE METHOD 3	58	SEE CENTREX OPERATION	23
SEE PROGRAMMING METHOD 3	33	SEE GLOSSARY OF TERMS	A-5
TELEPHONE LINES		WIDE AREA TELEPHONE SERVICE (WATS)	
SEE CONNECTIONS	7	SEE GLOSSARY OF TERMS	A-5
TEMPLATE		WIRING CONSIDERATIONS	
SEE TEMPLATE DESCRIPTION	14	RS-232 CABLE	31
TEMPLATE DESCRIPTION		SEE OPERATION	31
SEE OPERATION	14	1+ CALLS TO CARRIER	
TEMPLATE DIGITS		SEE EXAMPLE 1	17
SEE TABLE 1	15	SEE SEARCH EXAMPLES	17
SEE TEMPLATE DESCRIPTION	14	1+ CALLS TO CARRIER, 1+800 TO DDD	
TERMINAL		SEE EXAMPLE 2	17
SEE CONNECTING A STORAGE DEVICE	24	SEE SEARCH EXAMPLES	17
SEE PROGRAMMING METHOD 1	33	1+ CALLS TO CARRIER, 1+800 TO DDD	
TIE TRUNK		SEE EXAMPLE 3	18
SEE GLOSSARY OF TERMS	A-5	SEE SEARCH EXAMPLES	18
TIP & RING		411 AND 911 PROGRAMMING	
SEE GLOSSARY OF TERMS	A-5	SEE METHOD 2	34
TOLL OFFICE			
SEE GLOSSARY OF TERMS	A-5		
TONES			
SEE DTMF/ROTARY DIAL	4		
TRAFFIC STUDIES			
SEE CALL RECORDING	5		
TRANSFORMER			
SEE POWER	6		
TRIGGER CODE			
SEE SEARCH EXAMPLES	18		



**NOTES**

---

**SUPPLEMENT TO  
GENERAL INFORMATION MANUAL**

**smart-1™**

**COMMON CARRIER ACCESS DIALER  
AND CALL CONTROLLER  
WITH  
POSITIVE ACCOUNT VERIFICATION**



**MITEL®**

© - Copyright of MITEL DATACOM INC. 1986

™ - Trademark of MITEL DATACOM INC.

® - Registered Trademark of MITEL CORPORATION

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**NOTICE TO U.S. CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The SMarT-1™ Common Carrier Access and Call Controller (PAV) generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**NOTICE TO CANADIAN CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The Department does not guarantee that the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground connections to the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**CAUTION**

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as required.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load, to be connected to a telephone loop, that is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all of the devices doesn't exceed 100. An alphabetic suffix is also specified in the Load Number and designates the appropriate ringing type (A or B), if applicable. For example, LN = 20 A designates a Load Number of 20 and an 'A' type ringer.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**IMPORTANT NOTES**

Please note that MITEL DATACOM INC. has set up a National Field Service number for technical and installation assistance located in Dallas, Texas. This number is [214] 386-9400 for U.S. customers only (outside of normal working hours, a telephone answering service has been established for your convenience at this same number). For Canadian customers, please contact your local MITEL Regional Office.

The SMarT-1™ Dialer includes an on-board battery back-up system to prevent the loss of customer database. Besides protecting against loss of data during momentary power outages, this battery back-up should also provide sufficient memory retention to allow the Dialer to be programmed by the distributor and then transported to the customer's site for installation. This battery back-up, however, is not intended for long storage periods and cannot be guaranteed to support memory for long periods of time.

As received from the factory, the Dialer battery is not guaranteed to have a full charge applied to it. In fact, the battery is likely to be only partially charged in view of the time in transit, and distributor storage time. No guarantee of any battery charge status can be made until the Dialer has been powered up for a period of time. A period of 24 hours is necessary to achieve a full charge on the battery.

Upon removal from its shipping carton, the Dialer should be powered up for a period of time and then "✕ INITIALIZED" to load the operating system and default database into memory. Initialization may only be performed with a DTMF telephone set and requires connection to a working telephone line or an acceptable substitute. Never rely on programming entered into a Dialer until it has been "✕ INITIALIZED" (see Page 19, para. 5.04). Note that there is a short tone burst heard in the earpiece of the phone upon initialization. This tone indicates a successful initialize sequence has occurred.

Once initialized, the Dialer should seldom ever have to be initialized again. There is a Load Default Data Command that will restore memory to the initialized state once a "✕ INITIALIZE" has been performed. Once initialized, the Dialer will also respond to input via the RS-232 Input.

**REASONS FOR ADDITIONAL "✕ INITIALIZE" OPERATIONS**

Dialer has just been removed from storage or shipping carton.

No toneburst upon release of the ✕ Key. Maybe the tone was missed - check carefully.

The program access codes have been deleted accidentally or the access codes have been changed and forgotten.

The Dialer has just been repaired.

Long storage times.

Loss of data retention. Investigate for reason!



--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**smart-1™****COMMON CARRIER ACCESS DIALER AND CALL CONTROLLER****WITH POSITIVE ACCOUNT VERIFICATION**

CONTENTS	PAGE
1. INTRODUCTION .....	1
DOCUMENT OBJECTIVES .....	1
DOCUMENT OVERVIEW .....	1
INTENDED AUDIENCE .....	2
DOCUMENT HISTORY .....	2
READER COMMENTS .....	2
DOCUMENT CONVENTIONS .....	2
2. GENERAL DESCRIPTION .....	3
FEATURES AND CAPABILITIES .....	3
DIALER DESCRIPTION .....	3
3. SPECIFICATIONS .....	5
HARDWARE .....	5
RS-232 PORT .....	7
ELECTRICAL/MECHANICAL .....	7
4. UNPACKING, INSTALLATION AND ORDERING INFORMATION ..	9
SHIPPING AND RECEIVING .....	9
Unpacking .....	9
Repacking .....	9
INSTALLATION REQUIREMENTS .....	9
POWER REQUIREMENTS .....	12
MOUNTING .....	12
CONNECTIONS .....	12
RS-232 Port Configuration .....	16
RJ31X USOC Jack and Cable .....	16
ORDERING INFORMATION .....	16
5. OPERATING DESCRIPTION .....	19
GENERAL .....	19
INITIALIZING THE DIALER .....	19
SPECIFIC DEFAULTS .....	20
903 Default Command - Standard O.C.C. Dialer .....	20
DEFAULT LISTING .....	20
USER OPERATION .....	22
6. DETAILED PROGRAMMING .....	23
INTRODUCTION .....	23

CONTENTS	PAGE
SPECIAL FUNCTIONS .....	23
SYSTEM WIDE PARAMETERS .....	26
TRUNK RELATED PARAMETERS .....	27
ROUTE RELATED PARAMETERS .....	29
SEARCH TABLE ZERO CHANGES .....	35
Default Addition .....	35
Action Digit Addition .....	35
SEARCH TABLE ONE .....	35
Action Digit Changes .....	35
STRING DATA ENTRY CHANGES .....	35
PROGRAMMING EXAMPLES .....	36
Assumptions .....	36
PAV LIST MAINTENANCE EXAMPLE .....	37
ENTERING SPEED CALLS .....	37
SEARCH TABLE PROGRAMMING CONSIDERATIONS .....	39
Parameter 000t .....	39
7. CONTROLLER MEMORY CAPACITY .....	41
MEMORY SPACE ESTIMATING METHOD .....	41
8. TECHNICAL CIRCUIT DESCRIPTION .....	47
INTRODUCTION .....	47
9. PHYSICAL MAINTENANCE AND TROUBLESHOOTING .....	49
PHYSICAL MAINTENANCE .....	49
TROUBLESHOOTING .....	49
APPENDIX A .....	A-1
FCC INTERCONNECTION REQUIREMENTS .....	A-1
CONNECTION LIMITATIONS .....	A-1
NETWORK CHANGES .....	A-1
MAINTENANCE LIMITATIONS .....	A-1
TROUBLE CORRECTIONS .....	A-2
DISCONNECTION .....	A-2
APPENDIX B .....	B-1
OVERALL TOPICAL INDEX .....	B-1
FIGURES	PAGE
4-1, Equipment Unpacking and Repacking .....	10
4-2, Multi-Unit Packing and Repacking .....	11
4-3, Controller I/O Connections .....	13
4-4, Typical Controller Installation Configuration .....	13
4-5, Typical Connection Configuration .....	14
4-6, RS-232 Interface Connector .....	14
4-7, USOC RJ31X Jack and Cable Assy .....	15
6-1, Terminal Data Verification Example .....	25
7-1, Calculation Sht. 1 .....	44
7-2, Calculation Sht. 2 .....	44
7-3, Calculation Sht. 3 .....	45

---

<b>TABLES</b>	<b>PAGE</b>
<b>3-1, SMarT-1 Hardware Specifications</b> .....	<b>5,6</b>
<b>3-2, RS-232 Port Specifications</b> .....	<b>7</b>
<b>3-3, Electrical/Mechanical Specifications</b> .....	<b>7</b>
<b>4-1, SMarT-1 Ordering Information</b> .....	<b>17</b>
<b>5-1, Listing of 903 Defaults</b> .....	<b>21</b>
<b>6-1, System Special Parameters</b> .....	<b>23,24</b>
<b>6-2, System Wide Parameters</b> .....	<b>26</b>
<b>6-3, Trunk Related Parameters</b> .....	<b>27,28</b>
<b>6-4, Primary Route Related Parameters</b> .....	<b>30,31</b>
<b>6-5, Alternate Route Related Parameters</b> .....	<b>31,32</b>
<b>6-6, Search Table 1 Action Digit Changes</b> .....	<b>35</b>
<b>6-7, String Data Entry Changes</b> .....	<b>36</b>
<b>6-8, Programming Examples (PAV)</b> .....	<b>36,37</b>
<b>6-9, PAV List Maintenance Example</b> .....	<b>37</b>
<b>6-10, Speed Call Entries</b> .....	<b>38,39</b>

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## 1. INTRODUCTION

### DOCUMENT OBJECTIVES

**1.01** This document contains all information that relates to the SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification. The title of the Section is 'Supplement to General Information Manual, SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification'. For ease of reference, the Section can be noted by its MITEL Part Number 'MITL8350-047-102-NA'. This part of the Section is an overview of the contents of the document and outlines the intended audience.

**1.02** From this point forward and for ease of understanding, the SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification will be referred to in text as the 'Dialer'. Positive Account Verification will be referred to in text as 'PAV'.

### DOCUMENT OVERVIEW

**1.03** The document contains important notices to customers at the front on pages i through v. The first notice is for U.S. customers. The second is for Canadian customers. The third is general in nature and applies to all customers. If a particular notice does not apply, that page containing the notice may simply be removed from the manual.

**1.04** Following the notices is a general Table of Contents. This table lists the major parts of the Section, along with subheadings in the order that they appear within the Section. The manual is divided into 9 parts and two appendices.

**1.05** This part is a general overview of the manual. The second part is a description of the features and capabilities of the Dialer. The third lists all specifications for the Dialer.

**1.06** The fourth part describes in detail, all procedures for receiving, shipping, unpacking, installation and connection for the Dialer. This part is followed by an operating description. The sixth part outlines programming of the Dialer for use as PAV. The seventh part describes the memory space of the Dialer, while the eighth part is intended to be a technical circuit description. The ninth and final part describes physical maintenance and troubleshooting.

**1.07** The appendices provide additional information that may be of some use to the installer, programmer, or user of the Dialer. The first appendix includes FCC information, while the second contains an overall index listing topics in alphanumeric order. This index is included to provide an easy reference guide in locating specific information.

**INTENDED AUDIENCE**

**1.08** This document is intended for use as a general information manual for the installer, programmer, and user of the SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification. The document does not attempt to teach programming concepts. It is assumed that the reader has some programming experience.

**DOCUMENT HISTORY**

**1.09** This is the first formal issue of this document. It is a supplement to the 'SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller, General Information' manual, MITEL P/N 'MITL8350-047-100-NA'. Subsequent issues will be provided as information is changed or upgraded. These subsequent issues will replace any previous issue.

**READER COMMENTS**

**1.10** If the user has any comments or corrections that pertain to this document, please forward a reply in writing to MITEL Documentation Control in Ogdensburg, N.Y., U.S.A., quoting document number 'SECTION MITL8350-047-102-NA'.

**DOCUMENT CONVENTIONS**

**1.11** Throughout this manual, the following conventions will be used:

<b>SYMBOL</b>	<b>MEANING</b>
...	A horizontal ellipsis means that the preceding item may be repeated one or more times.
.	A vertical ellipsis means that not all of the statements in a figure or an example are shown; their content is not important to the example.
[[ ]]	Double square brackets in statement and format descriptions enclose items that are optional.
{ }	Braces enclose lists from which the user must choose one item. Each item is separated from the other by a comma ','.
< >	The less than and greater than signs, used in statement and format descriptions, usually enclose a special key to be pressed, such as a carriage return <CR> key.
>	The greater than sign, when appearing alone, indicates the terminal prompt as shown on the terminal display.  Terminal lines use two conventions. If the characters are printed in capitalized characters (upper case), the words are typed as listed. If they are printed in small characters (lower case), they require that some character(s) be entered in their place.

## 2. GENERAL DESCRIPTION

### FEATURES AND CAPABILITIES

**2.01** The SMarT-1™ Dialer has the following features and capabilities:

- Compliance with FCC Parts 68 and 15
- Four Line capacity for the SMarT-1™ unit (MITEL P/N 8350-005)
- Two Line capacity for the SMarT-1A™ unit (MITEL P/N 8350-006)
- CDR Output
- Versatile Programming
- Automatic Route Selection (ARS)
- Up to 1,000 Speed Calls, depending on length of Speed Call
  - Installer programmable, or
  - Customer programmable
- Tone to Pulse Conversion
- Pulse to Tone Conversion
- Each Speed Call entry may contain its own unique Account Code
- Account Code Verification (PAV) on a System wide basis
- Programmable selection of Routes to use PAV
- Safeguarding of Customer's database program against inadvertent erasure
- Separate program entry to allow customer update and maintenance of PAV lists
- Progress tones programmable on a route by route basis
- Programmable for Account Code change on Route change
- SMDR Indication of Speed Call and its related Account Code number
- In addition, the unit has the following convenience features:
  - Useable with Centrex Lines
  - Useable behind a PBX/PABX
  - Hot Line operation

### DIALER DESCRIPTION

**2.02** The SMarT-1™ PAV Dialer is a self-contained electronics unit that provides most of the functions of the standard SMarT-1™ Dialer with four times the amount of memory. The Dialer with PAV does not allow search table #1 to be used for screening destination numbers. It is reserved for the PAV list. For a description of the



standard Dialer, refer to the General Information Manual (P/N 8350-047-100-NA). In addition, the PAV Dialer provides the ability to verify user dialed account codes. Other notable differences from the standard Dialer are:

1. The unit verifies Account Codes on a System wide basis.
2. Only routes that have Account Codes enabled use the verifiable code list. This allows the Dialer to be programmed to do tasks such as to force the verification of account codes on toll routed calls only.
3. The PAV Dialer reserves search table #1 for the entry of account codes only. This table cannot be used to screen destination digits.
4. A two step operation is required to accomplish major database changes such as default database loads, search table flushes, etc. This safeguards against the inadvertent erasure of a customer's database program by programmers or installers.
5. The unit includes a separate programming access code so that the end-user or customer can update and maintain the PAV list.
6. The unit has provisions for the addition of programmable Progress Tones (beeps heard in the user's telephone receiver) on a route by route basis. These progress tones are 100ms in duration and can be programmed in any number from none to eight for a specified event.

**Note:** The standard Dialer has progress tones (beeps). These tones mentioned above, are in addition to the standard Dialer tones.

7. The number of Account Code warning tones (similar to progress tones, but 400ms in duration instead of 100ms) can be programmed on a route by route basis. The warning tones can be programmed in any number from 1 to 8 tones. These tones are issued to the user if an Account Code is not entered within the programmable timeout period.
8. The Dialer can be programmed to prompt the caller for a new Account Code if the primary carrier is unavailable and the call overflows to another route or carrier. This feature is valid for both automatic and user forced redials. If the call fails to the same route, the user will not be required to reenter the Account Code.

**3. SPECIFICATIONS****HARDWARE**

**3.01** Table 3-1 lists all of the hardware specifications for the SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification (PAV). These specifications apply to all models of the Controller (4- or 2-line units) unless otherwise noted.

**Table 3-1, SMarT-1<sup>™</sup> Hardware Specifications**

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>FCC RINGER EQUIVALENCE</b>			0.7B	
<b>IDLE LINE, LOOP START</b>				
RINGER IMPEDANCE: 15-60 Hz, 70-110V	10		20	K $\Omega$
20-3500 Hz, 10V	1			M $\Omega$
RINGING SENSITIVITY: 15-60 Hz	40			Volts
LEAKAGE: Tip to Ring, 100V	20			M $\Omega$
Tip to Earth, 100V	20			M $\Omega$
OFF HOOK CURRENT	15		80	mA
<b>IDLE LINE, GROUND START</b>				
SENSING RESISTANCE: Tip to Earth	36	40	45	K $\Omega$
OPEN CIRCUIT VOLTAGE: Tip	-22	-25	-28	Volts
GROUNDING VOLTAGE	-5	0	+10	Volts
TIME TO RECOGNIZE TIP-GROUND	10		150	ms
RESISTANCE: Sending Ring-Ground		n/a		
<b>BATTERY FEED</b>				
OPEN CIRCUIT VOLTAGE	22	24	26	Volts
FEED RESISTANCE	550	600	650	$\Omega$
BALANCE: DC	36	40		dB
SHORT CIRCUIT CURRENT			50	mA
<b>TERMINATION</b>				
RESISTANCE: DC, 20 mA	200		300	$\Omega$
DC, 40 mA	200		300	$\Omega$
AC, 300-3000 Hz	550	600	650	$\Omega$
RETURN LOSS: 600 ohms, 20mA	20	26		dB
OPERATING CURRENT	13		80	mA

Table 3-1 (Cont'd), SMarT-1™ Hardware Specifications

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>DIAL TONE</b>				
CO SIDE FEED: Gain 300 Hz	-2	0	+2	dB
INTERNAL FEED: 350 Hz		n/a		
<b>DTMF RECEIVER</b>				
LEVEL	-20		+3	dBm†
LEVEL DIFFERENCE	-6		+6	dB
FREQ: To receive	-1.5		+1.5	%
To not receive	-3.5		+3.5	%
DURATION	40			ms
TIME BETWEEN TONES	30			ms
<b>ROTARY RECEIVER</b>				
MAKE IMPEDANCE			700	$\Omega$
MAKE DURATION	20		100	ms
BREAK IMPEDANCE	8			K $\Omega$
BREAK DURATION	20		100	ms
RATE	7		20	pps
<b>DTMF SENDER</b>				
LEVEL	-8	-6	-3	dBm†
FREQUENCY	-1.3		+1.3	%
DURATION (Programmable)	40	60	130	ms
<b>ROTARY SENDER</b>				
TIMING (Programmable)	40/30	60/40	60/40	ms/ms
TIMING (At 60/40):				
Make	35		45	ms
Break	55		65	ms
RATE (At 60/40)	9.9	10	10.1	pps
INTERDIGIT PAUSE (Programmable)	400	800	1300	ms
<b>OPERATING RANGE</b>				
TEMPERATURE	0		55	°C
HUMIDITY	0		85	%
ALLOWABLE VOLTAGE: connected to any point			300	Volts

† With reference to 600 $\Omega$  Termination.

**RS-232 PORT**

**3.02** Table 3-2 below contains the specifications for the SMarT-1™ Dialer RS-232 Auxiliary Port. This port may be used for programming or for SMDR Output.

**Table 3-2, RS-232 Port Specifications**

PARAMETER	SPECIFICATION
BAUD RATE:	110 to 9600 Baud programmable; default = 1200 Baud
PARITY:	None
BITS PER CHARACTER:	Eight bits per character with one stop bit.
BIT EIGHT SENSE:	Space
MODE:	On line.
OPERATION:	Full duplex mode.

**ELECTRICAL/MECHANICAL**

**3.03** Table 3-3 contains the Electrical and Mechanical specification for the SMarT-1™ Dialer with PAV. These specifications apply to all models of the Controller (4- or 2-line units) unless otherwise noted.

**3.04** This section does not contain all of the specifications for the Controller at present. Other specifications will be added as they are received.

**Table 3-3, Electrical/Mechanical Specifications**

PARAMETER	SPECIFICATION
DIMENSIONS:	7.625" (19.37cm) Wide X 10.625" (26.99cm) H X 1.375" (3.49cm) D
WEIGHT: Dialer	2 lbs (0.907 kg)
Power Supply	1 lb (0.453 kg) (Approximately)
MOUNTING:	Wall Mount with Supplied Bracket
POWER:	115 Volts AC, 60 Hz @ 300 mA
Range:	103.5 to 126.5 VAC
CONNECTIONS:	Standard RJ31X Network Connections

**3.05** The specifications in the Tables above are subject to change without notice. The inclusion of 'n/a' for a specific parameter means that the specification is not available at the time of this publication. It will be added at a later date.

## 4. UNPACKING, INSTALLATION AND ORDERING INFORMATION

### SHIPPING AND RECEIVING

**4.01** The SMarT-1™ Dialer with PAV is shipped in a single carton that contains the Dialer, the Power Supply, a Wall Mounting Bracket, four RJ31X Cables and appropriate documentation. All of these items are protected within the carton by styrofoam inserts.

**Note:** Some production units do not require the wall mounting brackets since these units are mounted to a wall by use of keyslots included on the unit case.

**4.02** In some instances where more than one unit is shipped, a larger carton may be used that would contain five of the smaller cartons. Each of the smaller cartons would contain the items listed in 4.01 above.

### Unpacking

**4.03** The procedure below lists steps to take when unpacking the equipment (refer to Figures 4-1 and 4-2):

- 1) Open carton and remove contents.
- 2) Check each item removed for damage.
- 3) Check each item against the packing list.
- 4) Notify the vendor if any items are missing or appear to be damaged or defective.

### Repacking

**4.04** If an item is found to be defective or damaged and is to be returned to the vendor, it should be tagged and packaged to prevent damage. If units are to be shipped from one location to another, these units should also be packaged in such a manner as to prevent damage. Figure 4-1 shows how the equipment was originally packed. This method of packaging should be followed as closely as possible.

**4.05** If the original packaging material is no longer available, the returned parts should be wrapped in several layers of air-cushion type of wrap, placed in a suitable container, and surrounded with paper to minimize the movement of the items.

### INSTALLATION REQUIREMENTS

**4.06** The SMarT-1™ Dialer is position independent. It may be mounted anywhere that will accommodate the unit size as listed in the specifications in Table 3-3 on Page 7.

**4.07** The Dialer will operate within a 0-55°C temperature and a




Figure 4-1, Equipment Unpacking and Repacking




Figure 4-2, Multi-Unit Packing and Repacking



0-85% humidity range.

#### POWER REQUIREMENTS

**4.08** The customer must provide a single phase power receptacle with the following recommendations:

- 115V, 60Hz fused and capable of delivering 350mA per unit installed.
- The power receptacle should be wired and fused independently from all other receptacles that are not controller related.
- A warning tag should be attached to circuit breaker type fuses to prevent unauthorized manual operation.
- The power receptacle should not be controlled by a switch.
- The live and neutral conductors at the receptacle should be wired to their proper respective connections.
- The power receptacle must be a 3-wire type, with the ground wire connected to the ground of the electrical system.
- The receptacle should be easily accessible for the removal of the plug for maintenance.
- The receptacle location should be selected to prevent accidental removal of the power cord.
- The power cord between the receptacle and the unit should not present a hazard to the user.

#### MOUNTING

**4.09** If the unit requires the wall mounting bracket, simply mount the bracket to a surface with screws. Mount the Dialer housing to the bracket by matching the four holes on the rear of the case with the mounting pins of the bracket. Press firmly into place.

**4.10** If the unit is the keyslot type, mount by using the provided template to find screw locations. Insert #6 X  $\frac{3}{4}$  wood or self-tapping screws in these locations, leaving approximately 1/8 inch gap between the surface and the cap-head. Mount the Dialer by positioning the keyslots over the screw heads, pressing toward and then down from the mounting surface.

#### CONNECTIONS

**Note:** The Dialer with PAV should be initialized prior to accomplishing any connections. Refer to Part 6, paragraph 6.06 for the initialization procedure.

**4.11** Connections to the Dialer are made at the Connector Panel located along the bottom edge of the housing. Figure 4-1 illustrates the connection panel. The steps below outline the connection procedure:




Figure 4-3, Controller I/O Connections




Figure 4-4, Typical Controller Installation Configuration




Figure 4-5. Typical Connection Configuration




Figure 4-6, RS-232 Interface Connector (Viewed from outside Dialer)




Figure 4-7, USOC RJ31X Jack and Cable Assy.

- 1) Refer to Figure 4-3. Connect a suitable Earth Ground to the screw mount [A] provided on the connector panel. This connection **MUST** be made for the unit to function properly.
- 2) Plug the Power Pack jack into the Dialer power connection [B].
- 3) Plug the Power Pack AC line cord into a suitable (110V-60Hz) AC receptacle.
- 4) Using the supplied RJ31X cables, insert one end of a cable in a jack on the Dialer [C].
- 5) Connect the other end of the cable used in step 4 to the Telco-supplied jack.
- 6) Repeat steps 4 and 5 above for the appropriate number of times depending upon the model of Dialer being installed (4- or 2-line units).
- 7) Connect a suitable terminal to the RS-232 Computer Port [D] via a suitable cable. Configuration of this cable is described in paragraph 4.13 below.

**4.12** This completes the mechanical installation of the SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller. Continue by programming the unit from a DTMF telephone attached to the Dialer or from the terminal.

#### **RS-232 Port Configuration**

**4.13** The RS-232 Computer Port connector (refer to Figure 4-6) is a female connector configured as "DCE". Only the TxD (pin 3), the RxD (pin 2), and the GND (pin 1) lines are used by the Controller. Pins 4 through 6, 8, and 20 are shorted internally for the convenience of the user. This port is used for programming and call recording output.

**4.14** During programming, a suitable terminal may be connected to this port. For call recording output, a suitable printer is connected in place of the terminal. Refer to General Information Manual, Part 6 paragraph 6.02 for the configuration of the terminal or the printer.

#### **RJ31X USOC Jack and Cable**

**4.15** Figure 4-7 illustrates the USOC RJ31X Connector and cable assembly as used by the Dialer. Figure 4-5 illustrates the installation wiring of the Telco-supplied RJ31X USOC jack and other connections from the Central Office. For the unit to operate properly, the bridge clips at the "split" type station block must be removed.

#### **ORDERING INFORMATION**

**4.15** Table 4-1 on the following page lists the part numbers and descriptions of items that can be ordered from MITEL DATA-COM INC.

Table 4-1, SMarT-1™ Ordering Information 4-1, SMarT-1 Ordering Information

PART NO.	DESCRIPTION
8350-005	SMarT-1™: 4 Line Common Carrier Access Dialer and Call Controller (PAV). Includes Power Pack, RJ31 Cables, and Mounting Hardware.
8350-006	SMarT-1A™: 2 Line Common Carrier Access Dialer and Call Controller (PAV). Includes Power Pack, RJ31 Cables, and Mounting Hardware.
<b>SPARES</b>	
8350-010	Wall Mount Bracket for SMarT-1™ Common Carrier Access Dialer and Call Controller (PAV).
8350-012	Power Pack for SMarT-1™ Common Carrier Access Dialer and Call Controller (PAV).
8350-013	RJ31X Cable for SMarT-1™ Common Carrier Access Dialer and Call Controller (PAV).
8350-047-102-NA	General Information Manual Supplement for Dialer with PAV.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## 5. OPERATING DESCRIPTION

### GENERAL

**5.01** The primary function of the SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification is to provide the ability to verify user dialed account codes when the Dialer is used as described in the General Information Manual (SECTION MITL8350-047-100-NA). This feature can be enabled or disabled by programming.

**5.02** The PAV function provided by the Dialer lies in three distinct areas. These areas are:

- Expanded memory enabling the Dialer to have up to 1000 Speed Calls and depending on memory use, storage of Account Codes.
- The inclusion of additional programmable progress tones on a route by route basis and Account Code warning tones for the user.
- Account Code verification against programmed Account Codes to eliminate unauthorized use of the facility. This verification also includes Call Detail Recording output.

**5.03** The following descriptions outline typical operating modes for the SMarT-1<sup>™</sup> Dialer with Positive Account Verification. These operating modes are unique to this unit. Except as noted below, the General Information Manual applies in its entirety.

### INITIALIZING THE DIALER

**5.04** The Dialer is initialized in the same manner as the standard SMarT-1<sup>™</sup> Dialer. The procedure for initialization listed below is repeated from the General Information Manual to reduce cross referencing and to include the default command upon completion of initialization.

- 1) Connect an earth ground to the Dialer.
- 2) Connect a DTMF telephone or butt set to the subscriber side Tip & Ring leads of the Dialer.
- 3) Connect a standard telephone line or network to the C.O. side of the Dialer.
- 4) With the power to the Dialer disconnected, go off-hook.
- 5) While holding down the \* key on the DTMF set, connect the power to the Dialer. A DTMF tone should be audible in the handset receiver.
- 6) Continue to hold the \* key for 10 seconds or more after applying power to the Dialer.
- 7) Release the \* key. The unit should respond immediately with a short tone from the handset receiver. If the tone is not heard,



return to step 1 above and start over. The tone burst indicates that the Dialer is initialized and defaulted to its "standard" configuration. It also indicates that it is in the programming mode and awaiting a command.

**5.05** Once the above listed procedure has been completed, the user has only one option available. This is:

- 1) **GO ON-HOOK:** The Dialer is defaulted as a standard O.C.C. Dialer as noted in the General Information Manual. The only difference is that it is capable of up to 1,000 Speed Calls (with account codes). All of the programming information in the General Information Manual applies to the Dialer in this configuration.

### SPECIFIC DEFAULTS

**5.06** The paragraphs that follow list specific defaults and values for the Dialer with PAV. Any parameters that are not listed appear in the General Information Manual. They are also the same defaults as for the standard SMarT-1™ Dialer. For more information on these defaults, refer to the General Information Manual, Section 5.

#### **903 Default Command - Standard O.C.C. Dialer**

**5.07** All defaults are unchanged from the standard SMarT-1™ unit defaults except that there are no Alternate Search Table entries. Refer to the General Information Manual, Section 5, for a complete listing. Also refer to Table 5-3 of this manual for Speed Call and Account Code enhancements that are provided in the Expanded Memory unit under the 903 default.

### DEFAULT LISTING

**5.08** Table 5-3 is a listing of the 903 defaults. In this listing, the reader will note that there are some enhancements that are possible with the 903 defaults that are not included or possible with the "standard" SMarT-1™ Dialer. Once again, the General Information Manual (MITEL P/N 8350-047-100-NA) is applicable to all parameters and functions for the 903 command, but with the addition of the listed enhanced operation capabilities. Specifically, **in the 903 "standard" mode, up to 1,000 Speed Call positions** are now possible. Each Speed Call may now contain its own unique Account Code, if desired.

Table 5-3, Listing of 903 Defaults

903 DEFAULTED	
<b>PARAMETER 000t:</b>	0 = 10 SPEED CALLS 1 = 100 SPEED CALLS 2 = Maximum 1000 possible speed calls (3 digit address)
<p><b>NOTE:</b> To use Selection 2, the default 803 Speed Call trigger search table entry must be deleted and replaced in the 804 Table or other table as desired. The recommended Speed Call trigger is: 804 = *#9 #9 #9 #2 (user dialed as *nnn).</p>	
<p><b>SPEED CALL PARAMETER DIGITS:</b> The number of digits that must be dialed into the Speed Call parameter slot is two or three, depending on 000t above.</p>	
<p><b>SPEED CALL PROGRAMMING FORMAT:</b> The Speed Call programming format is: 7nn or 7nnn, followed by dk mm . . . mm##.</p>	
<p><b>NOTE:</b> If 000t is set to 0, the programming slot number is still two digits. This must be within the range of 00 through 09. A single-digit Speed Call trigger (i.e., 802 *#9#2) is possible for the Search Tables, but must be programmed in the range of 700 through 709 in the Speed Call slots.</p>	
<p>If a * is entered as a part of the mm . . . mm sequence above, all of the digits placed before the * are entered into the destination buffer. The digits after the * are entered into the account code buffer. The * is not dialed out. It is ignored in the dial-out procedure and only notes the beginning of the account code number.</p>	
<p>This means that a * may not be a part of a destination number, but if multiple *'s are entered in the Speed Call format, the second and succeeding *'s will be made a part of the account code. They will also appear in the Call Recording output.</p>	
<p>The * separating the Speed Call and the Account Code may be positioned anywhere in the "mm . . . mm" string, or left out entirely. If it is left out entirely, the entire entry will be considered as a destination number.</p>	
<p>The maximum length of the field is 30 characters (29 digits and a *). The maximum length of a Speed Call or Account Code field alone within the 30-character limit is 23 digits.</p>	
<p>In the 903 Mode, the 6r5 Access Control Strings, of course, must be programmed to dial out the Account Codes, if desired.</p>	
<p>The User Speed Call programming access code is ###. All trunks are allowed access and speed calls go to search tables (dk = 08).</p>	

**Note:** For installations not capable of transmitting the "#" sign to the dialer, the program access may be changed to any desired series of digits via search table programming. Waiting for expiration of the interdigit time-out will automatically complete the entry, thus avoiding the ## terminating entry.

## USER OPERATION

**5.09** Once installed and programmed, the user will have to follow a predefined procedure when making telephone calls. The steps below outline the procedure to be followed when using the telephone and provide important operational notes:

- 1) When a user desires to place a call from a telephone, it will be necessary to dial in an account code that is unique to the user. It does not matter which telephone connected to the SMarT-1™ is used. It is the responsibility of the user to dial his/her particular account code after dialing a telephone number.
  - a) The person responsible for maintaining and assigning the account codes will issue a code to the user. It will be the user's responsibility to retain and secure this code.
- 2) The Dialer is preprogrammed with certain dialing information for local and long distance calls. This information may be customized at the time of installation. If so, the person in charge of maintenance and programming should provide the user with specific dialing information.
  - a) This information may consist of dialing details when making certain types of calls. For instance, an account code may or may not be required when making a local call.
- 3) When using Account Codes when dialing numbers, do the following steps:
  - a) Go off-hook on the telephone set.
  - b) Obtain dialtone from the Dialer.
  - c) Dial the desired telephone number.

**Note:** The Dialer may now prompt with a series of tones (beeps) that indicate either the type of call that is being placed, or requesting an account code be dialed, or both.

- d) Dial your account code.

**Note:** The Dialer may or may not be programmed to return a single confirmation tone (beep) that indicates the account code was valid. The Dialer may or may not be programmed to return a series of slow tones when the account code is not dialed within a certain time period. If the account code is not dialed or is invalid, the user will receive a fast busy (reorder) tone. The call should be tried again. If still unsuccessful, the user should contact the appropriate person in charge to ascertain what problem has occurred.

## 6. DETAILED PROGRAMMING

### INTRODUCTION

**6.01** The SMarT-1<sup>™</sup> Common Carrier Access Dialer and Call Controller with Positive Account Verification (PAV) should be programmed according to normal site specific information. Refer to Section 5 of the General Information Manual for detailed programming information and procedures in accomplishing programming. It is assumed that the user or programmer has read these sections and understands the programming methods.

**6.02** Only those areas of special interest to Positive Account Verification or those registers that are affected by PAV software will be dealt with in the following tables and paragraphs.

### SPECIAL FUNCTIONS

**6.03** Table 6-1 below lists System Special Parameters along with descriptions of each parameter. Special Function commands that are preceded with a '942' are actually two step operations. These commands require the entry of the '942' followed by three more digits (903, 904, etc.) to select the command parameter. When '942' is dialed, it is followed by a double progress tone (two beeps) in the receiver of the DTMF telephone, or by a <CR> (carriage return) on the display of the terminal. Dialing the next three digits will cause the receiver to emit another double progress tone, or the terminal to display another <CR>.

**Table 6-1, System Special Parameters**

ENTER	DESCRIPTION
999	Exit program mode.
980mmddhhmm	Enter Date and Time for Call Detail Record and Time-of-Day Access Control.
902	Enter Data Confirmation Mode. This parameter allows programmed data to be read back for verification.
907	Exit Data Confirmation Mode. Return to program mode.
942903	Load Factory Installed Default Database. This command will re-install all default database parameter settings and will delete any other programmed data.
942904	Delete All Search Table Entries. <b>CAUTION</b> - This command deletes all data resident in the 801 through 835 Search Tables. The Controller cannot operate without data entered in these tables. The only reason for erasing this data is if the user wishes to restart with an entirely new data program

(continued)

Table 6-1 (Cont'd), System Special Parameters

ENTER	DESCRIPTION
<p>942906</p> <p>942908</p>	<p>and where it is not convenient to delete the old data one piece at a time.</p> <p>Enter Clone Master Mode.</p> <p>Enter Tandem Operation Mode. <b>CAUTION</b> - This command will affect other traffic on the Dialer. The command puts the Dialer into the ASCII to DTMF conversion mode for Dialer Remote Maintenance.</p>

**6.04 999** - This command causes the Dialer to exit from the programming mode. If the command is entered from a DTMF telephone, there will be no progress tones following the dialing of the command. If the command is entered from a terminal attached to the RS-232 Computer Port, the terminal will display one space after the command, the notice 'QUITTING PROG. MODE'. When using a DTMF telephone to program, another method of exiting the programming mode is to simply hang up the receiver (on-hook).

**6.05 980** - The 980 command programs the Dialer for the current date and time to set the clock. The date and time will be printed in the Call Detail Record (current date and time) and will also be used for time-of-day access control. The data string associated with the command must be entered in two digit groups such as:

[980mmddhhmm]

where 'mm' is the two digit month, 'dd' is the two digit day, 'hh' is the two digit hour (24 hour base), and 'mm' is the two digit minute. For example, if the Dialer was being programmed on Tuesday, February 11, 1986 at 01:00 PM, the entry would be:

[98002111300]

**6.06 902** - This command causes the Dialer to enter the data confirmation mode. Once in this mode, the programmer may check to ensure that all previous data entered was done correctly. It is the method used for verification of data. If a terminal is used to program the Dialer, the data is displayed on the terminal screen. If a telephone is used to program the Dialer, the unit will wait for 0.5 seconds after a parameter entry, then will output the data associated with the entry in DTMF format over the C.O. side of the Dialer.

**6.07** For example, if it is desired to verify the Baud Rate of the Dialer that would have been entered by the use of the '006t' parameter for 4800 Baud (0066), the terminal display would appear as in Figure 6-1 on the next page:

```
> [902]
> [006] 6
> [907]
>
```

Figure 6-1, Terminal Data Verification Example

**6.08** The > character is the Dialer prompt that requires the programmer to enter some data. The digits in the square brackets [ ] are the digits entered by the programmer where '902' is enter data verification mode, '006' is the parameter for setting the Baud rate, and '907' is exit data verification mode. The '6' in the second line is the parameter qualifier returned by the Dialer for the '006' parameter and equates to 4800 Baud for the RS-232 Port.

**6.09** If the same example were verified by use of the DTMF telephone, the programmer would simply dial the numbers. After the '006' entry, the Dialer would wait for 0.5 seconds, then send '6' out in DTMF format over the Central Office side of the Dialer. Each of the command entries would be followed by a double progress tone in the DTMF receiver. This method is not recommended for use in verification but may be used for remote maintenance.

**Note:** All 9XX parameters are considered to be commands and therefore, are not verifiable.

**6.10 907** - This command causes the Dialer to exit the verification mode as described in paragraph 5.06 above. The Dialer returns to the programming mode after this command is received from either the terminal or the DTMF telephone.

**6.11 942903** - The '942903' command causes the Dialer to load a Factory installed Default Database. The command will re-install all default parameter settings as listed in the parameter tables of this manual and the General Information Manual. This load will delete any other previously programmed data.

**6.12 942904** - This command causes the Dialer to delete **ALL SEARCH TABLE ENTRIES. CAUTION** - This command will delete all information contained in the 801 through 835 Search Tables that tells the Dialer what to do when routing a call. The Dialer cannot operate without some basic information entered in these tables. The only reason for using this command to erase the data is when the user wishes to restart with an entirely new data program and where it is not convenient to delete or change old data one piece at a time.

**Note:** After deleting all search table entries with the 942904 command, the default data base can be reloaded by entering a 942903 command.

**6.13 942908** - This command causes the Dialer to enter the Tandem Operation Mode. The command should only be issued if the Dialer is not in service for users as it will affect all other traffic on the

Dialer. This mode causes the Dialer to become an interface between a centralized terminal and the telephone line (i.e., the Dialer becomes a Tone-to-ASCII converter to allow the display of received tones to the screen, and an ASCII-to-Tone converter to allow the remote programming of another Dialer (or any other device that can be programmed by the use of DTMF (Tone)).

**SYSTEM WIDE PARAMETERS**

6.14 Table 6-2 below lists the System Wide Parameters that are programmable and different from the General Information Manual. Note the addition of the '011t' parameter for Positive Account Verification.

**Table 6-2, System Wide Parameters**

ENTER	DEFAULT	DESCRIPTION
000t	1	Number of Speed Call Number Entries Available, where 't' equals: 0 = 10 Speed Call entries 1 = 100 Speed Call entries (default) 2 = 1000 Speed Call entries
006t	4	Baud Rate or RS-232 Computer Port, where 't' equals: 1 = 110 Baud 2 = 300 Baud 3 = 600 Baud 4 = 1200 Baud (default) 5 = 2400 Baud 6 = 4800 Baud 7 = 9600 Baud
011t	0	Positive Account Verification, where 't' equals: 0 = Disabled (default) 1 = Enabled  <b>NOTE:</b> Enabling PAV forces Search Table #1 to be used for storing the user dialed account codes.

6.15 System Wide Parameters, if entered by DTMF telephone, will cause a single progress tone (beep) to be heard after dialing the first three digits. After dialing the fourth digit to select the action of the parameter, a double progress tone (two beeps) will be heard indicating that the Dialer is ready for more programming.

6.16 If these parameters are programmed from a terminal, the three digit parameter group and the fourth digit selection is entered as one group after the Dialer prompt > with no spaces. The terminal will display the code group followed by a carriage return. For example, if it is desired to program the Dialer for 10 speed call entries, the display would appear as:

```
> [0000]
>
```

where the brackets [ ] enclose the parameter digits to be entered on the terminal keyboard by the user. The brackets will not be displayed on the screen.

**6.17 000t** – This parameter tells the Dialer the number of entries to be entered in the Speed Call tables (7nnn). Any number of speed calls up to the maximum selected number may be entered after programming this parameter. For the method of programming Speed Calls, refer to paragraph 6.43 of this part. The only allowable selections for this command is 10, 100, or 1000 speed call entries. 100 entries is the default that will be loaded if a factory default load command is issued.

**6.18 006t** – This parameter selects the Baud rate that the RS-232 Computer Port will use in communications to either a terminal or a CDR unit. The default rate is 1200 Baud and is loaded at unit initialization. The parameter will only take effect after exiting the programming mode. Selection of rates from 110 to 9600 Baud may be made in seven steps.

**6.19 011t** – This parameters enables or disables the Positive Account Verification feature of the Dialer. The default selection is 'disabled'. When disabled, the unit functions as a standard SMarT-1™ Dialer without PAV (refer to the General Information Manual for more information). In the enabled state, the Dialer forces Search Table #1 to be used for the storage of user dialed Account Codes for verification. With the PAV enabled, note that the r54t and r74t Route Related parameters have different meanings from each other.

#### TRUNK RELATED PARAMETERS

**6.20** Table 6-3 below lists the Trunk Related Parameters that are programmable and different from the 'General Information Manual'.

**Table 6-3, Trunk Related Parameters**

ENTER	DEFAULT	DESCRIPTION
x04t	1	Flash Allowed Time, where 't' equals: 1 = 100ms
x08t	3	Off-Hook Digit Refusal Time, where 't' equals: 0 = None 1 = 100ms 2 = 200ms 3 = 300ms 4 = 400ms 5 = 500ms 6 = 600ms 7 = 700ms 8 = 800ms 9 = 900ms

(continued)



Table 6-3 (Cont'd), Trunk Related Parameters

ENTER	DEFAULT	DESCRIPTION												
		<p><b>NOTE:</b> If 'x19t' Off-Hook Progress Tone is set to a '1' or enabled, the progress tone will not occur until 'x08t' timer has expired or reached 700ms. The Off-Hook Progress Tone is 200ms in duration.</p>												
x19t	1	<p>Off-Hook Progress Tone, where 't' equals:  0 = Off-Hook Progress Tone Disabled  1 = Off-Hook Progress Tone Enabled</p>												
x22t		<p>Reserved (See 011t)</p> <p><b>NOTE:</b> Whether System Option 'x11t' (PAV Enabled/Disabled) is set to a '0' or a '1'. Search Table 1 is always dedicated to the PAV list and cannot be used for destination searching purposes.</p>												
x31t	3	<p>TIP GND Application Recognition (GND START), where "t" equals:</p> <table> <tbody> <tr> <td>0 = 40ms</td> <td>6 = 240ms</td> </tr> <tr> <td>1 = 40ms</td> <td>7 = 280ms</td> </tr> <tr> <td>2 = 80ms</td> <td>8 = 320ms</td> </tr> <tr> <td>3 = 120ms</td> <td>9 = 360ms</td> </tr> <tr> <td>4 = 160ms</td> <td>* = 400ms</td> </tr> <tr> <td>5 = 200ms</td> <td># = 440ms</td> </tr> </tbody> </table>	0 = 40ms	6 = 240ms	1 = 40ms	7 = 280ms	2 = 80ms	8 = 320ms	3 = 120ms	9 = 360ms	4 = 160ms	* = 400ms	5 = 200ms	# = 440ms
0 = 40ms	6 = 240ms													
1 = 40ms	7 = 280ms													
2 = 80ms	8 = 320ms													
3 = 120ms	9 = 360ms													
4 = 160ms	* = 400ms													
5 = 200ms	# = 440ms													
x34t	6	<p>Tip Ground Removal Timer, where 't' equals:</p> <table> <tbody> <tr> <td>0 = 40ms</td> <td>6 = 240ms</td> </tr> <tr> <td>1 = 40ms</td> <td>7 = 280ms</td> </tr> <tr> <td>2 = 80ms</td> <td>8 = 320ms</td> </tr> <tr> <td>3 = 120ms</td> <td>9 = 360ms</td> </tr> <tr> <td>4 = 160ms</td> <td>* = 400ms</td> </tr> <tr> <td>5 = 200ms</td> <td># = 440ms</td> </tr> </tbody> </table>	0 = 40ms	6 = 240ms	1 = 40ms	7 = 280ms	2 = 80ms	8 = 320ms	3 = 120ms	9 = 360ms	4 = 160ms	* = 400ms	5 = 200ms	# = 440ms
0 = 40ms	6 = 240ms													
1 = 40ms	7 = 280ms													
2 = 80ms	8 = 320ms													
3 = 120ms	9 = 360ms													
4 = 160ms	* = 400ms													
5 = 200ms	# = 440ms													

**6.21 x04t** - The x04t command programs the Flash Allowed Timing. If the Flash Allowed Time is longer than the On-Hook Timing (x03t), then flash is not allowed. The default for the command is 100ms. For more information, refer to the General Information Manual.

**6.22 x08t** - This command programs the Off-Hook Digit refusal time. The default for the command is 0.3 seconds. The programmable time period ranges from 0.1 to 0.9 seconds and is selectable by entering a number from 0 to 9 respectively, for the 't' in the command line. For example, if it was desired to program all trunks for a 0.5 second Off-Hook Digit Refusal Time, the command would appear as:

```
> [5085]
>
```

on the programming terminal, or when programming with a DTMF telephone, simply dial the '5085' as follows:

DIAL	HEAR	DIAL	HEAR
508	♪	5	♪♪

where ♪ indicates a single progress tone and ♪♪ indicates a double progress tone (two beeps) as heard in the telephone receiver.

**6.23 x19t** - This command programs the Controller to use or not use Off-Hook Progress tone when the user lifts the receiver. The default for the command is disable Off-Hook Progress tone. For example, if it is desired to program trunk 1 for an Off-Hook Progress tone, the command would appear as shown below:

```
> [1191]
>
```

on the programming terminal, or when programming with a DTMF telephone, simply dial the '1191' as shown below:

DIAL	HEAR	DIAL	HEAR
119	♪	1	♪♪

**6.24 x34t** - The x34t command selects the time period for the Tip Ground Removal Timer. A period within the range of 0 to 440 ms can be selected by substituting a number from 0 to 9, or \*, or # for 't' in the command line when programming with a DTMF telephone. If programming is accomplished from a terminal, the \* becomes the letter 'A' and the # becomes the letter 'B'. The default for the command is 240 ms (6). For example, to program all trunks for a 120 ms Tip Ground Removal Time, the command would appear as:

```
> [5343]
>
```

on the programming terminal, or when programming with a DTMF telephone, simply dial the '5343' as shown below:

DIAL	HEAR	DIAL	HEAR
534	♪	3	♪♪

#### ROUTE RELATED PARAMETERS

**6.25** Tables 6-4 and 6-5 that follow are the Primary Route Parameters and Alternate Route Parameters respectively, that are programmable and different from the 'General Information Manual'.

Table 6-4, Primary Route Related Parameters

ENTER	DEFAULT	DESCRIPTION																												
r51t	0	<p>Route Progress Tones (beeps - ♪), where 't' equals:</p> <table border="0"> <tr> <td>0 = None</td> <td>3 = ♪ ♪ ♪</td> <td>6 = ♪ ♪ ♪ ♪ ♪ ♪</td> </tr> <tr> <td>1 = ♪</td> <td>4 = ♪ ♪ ♪ ♪</td> <td>7 = ♪ ♪ ♪ ♪ ♪ ♪ ♪</td> </tr> <tr> <td>2 = ♪ ♪</td> <td>5 = ♪ ♪ ♪ ♪ ♪</td> <td>8 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</td> </tr> </table> <p><b>NOTE:</b> These Route Progress Tones are 100ms in duration with 100ms of silence between them. Route Progress tones will be given to the user before the Dialer cuts the Central Office audio through.</p>	0 = None	3 = ♪ ♪ ♪	6 = ♪ ♪ ♪ ♪ ♪ ♪	1 = ♪	4 = ♪ ♪ ♪ ♪	7 = ♪ ♪ ♪ ♪ ♪ ♪ ♪	2 = ♪ ♪	5 = ♪ ♪ ♪ ♪ ♪	8 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪																			
0 = None	3 = ♪ ♪ ♪	6 = ♪ ♪ ♪ ♪ ♪ ♪																												
1 = ♪	4 = ♪ ♪ ♪ ♪	7 = ♪ ♪ ♪ ♪ ♪ ♪ ♪																												
2 = ♪ ♪	5 = ♪ ♪ ♪ ♪ ♪	8 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪																												
r54t	1	<p>Account Code Type where 't' in System option '011t' is set to a '0' or disabled. 't' equal to 0 through 5 apply to using initial account code, while 't' equal to 6 through # apply to using new account code, where 't' equals:</p> <table border="0"> <thead> <tr> <th data-bbox="527 808 909 840">Initial Acct. Code</th> <th data-bbox="933 808 1315 840">New Acct. Code</th> </tr> </thead> <tbody> <tr> <td>0 = Flexible, wait for timeout, then continue.</td> <td>6 = Flexible, wait for timeout, then continue.</td> </tr> <tr> <td>1 = No Account Code.</td> <td>7 = No Account Code.</td> </tr> <tr> <td>2 = Fixed length, wait for timeout, then reorder.</td> <td>8 = Fixed length, wait for timeout, then reorder.</td> </tr> <tr> <td>3 = Fixed length, wait for timeout, then enter 'dummy account code'.</td> <td>9 = Fixed length, wait for timeout, then enter 'dummy account code'.</td> </tr> <tr> <td>4 = Same as '2' plus 10 more digits.</td> <td>* = Same as '8' plus 10 more digits.</td> </tr> <tr> <td>5 = Same as '3' plus 10 more digits.</td> <td># = Same as '9' plus 10 more digits.</td> </tr> </tbody> </table> <p>PAV Code Type, where 't' in System option '011t' (PAV) is set to a '1' or enabled, and where 't' equals:</p> <table border="0"> <thead> <tr> <th colspan="2" data-bbox="738 1291 1079 1323">Use Initial Account Code</th> </tr> </thead> <tbody> <tr> <td>1 =</td> <td>No Account Code.</td> </tr> <tr> <td>2 =</td> <td>Fixed length of one to nine digits. Send all gathered digits to Search Table 1.</td> </tr> <tr> <td>4 =</td> <td>Same as '2' with the fixed length being from 10 to 15 digits.</td> </tr> <tr> <th colspan="2" data-bbox="747 1491 1071 1522">Use New Account Code</th> </tr> <tr> <td>8 =</td> <td>Fixed length of one to nine digits. Send all gathered digits to Search Table 1.</td> </tr> <tr> <td>* =</td> <td>Same as '8' with the fixed length being 10 to 15 digits.</td> </tr> </tbody> </table> <p><b>NOTE:</b> Flexible Account Codes and Dummy Account Codes are not supported when PAV is enabled.</p>	Initial Acct. Code	New Acct. Code	0 = Flexible, wait for timeout, then continue.	6 = Flexible, wait for timeout, then continue.	1 = No Account Code.	7 = No Account Code.	2 = Fixed length, wait for timeout, then reorder.	8 = Fixed length, wait for timeout, then reorder.	3 = Fixed length, wait for timeout, then enter 'dummy account code'.	9 = Fixed length, wait for timeout, then enter 'dummy account code'.	4 = Same as '2' plus 10 more digits.	* = Same as '8' plus 10 more digits.	5 = Same as '3' plus 10 more digits.	# = Same as '9' plus 10 more digits.	Use Initial Account Code		1 =	No Account Code.	2 =	Fixed length of one to nine digits. Send all gathered digits to Search Table 1.	4 =	Same as '2' with the fixed length being from 10 to 15 digits.	Use New Account Code		8 =	Fixed length of one to nine digits. Send all gathered digits to Search Table 1.	* =	Same as '8' with the fixed length being 10 to 15 digits.
Initial Acct. Code	New Acct. Code																													
0 = Flexible, wait for timeout, then continue.	6 = Flexible, wait for timeout, then continue.																													
1 = No Account Code.	7 = No Account Code.																													
2 = Fixed length, wait for timeout, then reorder.	8 = Fixed length, wait for timeout, then reorder.																													
3 = Fixed length, wait for timeout, then enter 'dummy account code'.	9 = Fixed length, wait for timeout, then enter 'dummy account code'.																													
4 = Same as '2' plus 10 more digits.	* = Same as '8' plus 10 more digits.																													
5 = Same as '3' plus 10 more digits.	# = Same as '9' plus 10 more digits.																													
Use Initial Account Code																														
1 =	No Account Code.																													
2 =	Fixed length of one to nine digits. Send all gathered digits to Search Table 1.																													
4 =	Same as '2' with the fixed length being from 10 to 15 digits.																													
Use New Account Code																														
8 =	Fixed length of one to nine digits. Send all gathered digits to Search Table 1.																													
* =	Same as '8' with the fixed length being 10 to 15 digits.																													

(continued)

Table 6-4 (Cont'd), Primary Route Related Parameters


























ENTER	DEFAULT	DESCRIPTION
r59t	0	<p>Account Code Warning Tones (beeps - ♪) where 't' equals:</p> <p>0 = None                      3 = ♪ ♪ ♪                      6 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</p> <p>1 = ♪                              4 = ♪ ♪ ♪ ♪                      7 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</p> <p>2 = ♪ ♪                            5 = ♪ ♪ ♪ ♪ ♪                      8 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</p> <p><b>NOTE:</b> Warning tones are 400ms ON and 400ms OFF. The warning tones start after expiration of r53t Timer. If the user fails to enter a digit before the specified number of tones expires, the user is returned a re-order tone of 200ms ON and 200ms OFF.</p>
r60t	0	<p>Account Code Confirmation and Reroute Tones, where 't' equals:</p> <p>0 = A/C tone OFF and Reroute tone OFF</p> <p>1 = A/C tone ON and Reroute tone OFF</p> <p>2 = A/C tone OFF and Reroute tone ON</p> <p>3 = A/C tone ON and Reroute tone ON</p> <p>The account code confirmation tone is 200ms in duration.</p>

Table 6-5, Alternate Route Related Parameters

ENTER	DEFAULT	DESCRIPTION										
r71t	0	<p>Route Progress Tones (beeps - ♪), where 't' equals:</p> <p>0 = None                      3 = ♪ ♪ ♪                      6 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</p> <p>1 = ♪                              4 = ♪ ♪ ♪ ♪                      7 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</p> <p>2 = ♪ ♪                            5 = ♪ ♪ ♪ ♪ ♪                      8 = ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪ ♪</p> <p><b>NOTE:</b> These Route Progress Tones are 100ms in duration with 100ms of silence between them. Route Progress tones will be given to the user before the Dialer cuts the Central Office audio through.</p>										
r74t	1	<p>Account Code Type where 't' in System option '011t' is set to a '0' or disabled. 't' equal to 0 through 5 apply to using initial account code, while 't' equal to 6 through # apply to using new account code, where 't' equals:</p> <table> <thead> <tr> <th>Initial Acct. Code</th> <th>New Acct. Code</th> </tr> </thead> <tbody> <tr> <td>0 = Flexible, wait for timeout, then continue.</td> <td>6 = Flexible, wait for timeout, then continue.</td> </tr> <tr> <td>1 = No Account Code.</td> <td>7 = No Account Code.</td> </tr> <tr> <td>2 = Fixed length, wait for timeout, then reorder.</td> <td>8 = Fixed length, wait for timeout, then reorder.</td> </tr> <tr> <td>3 = Fixed length, wait for timeout, then enter 'dummy account code'.</td> <td>9 = Fixed length, wait for timeout, then enter 'dummy account code'.</td> </tr> </tbody> </table>	Initial Acct. Code	New Acct. Code	0 = Flexible, wait for timeout, then continue.	6 = Flexible, wait for timeout, then continue.	1 = No Account Code.	7 = No Account Code.	2 = Fixed length, wait for timeout, then reorder.	8 = Fixed length, wait for timeout, then reorder.	3 = Fixed length, wait for timeout, then enter 'dummy account code'.	9 = Fixed length, wait for timeout, then enter 'dummy account code'.
Initial Acct. Code	New Acct. Code											
0 = Flexible, wait for timeout, then continue.	6 = Flexible, wait for timeout, then continue.											
1 = No Account Code.	7 = No Account Code.											
2 = Fixed length, wait for timeout, then reorder.	8 = Fixed length, wait for timeout, then reorder.											
3 = Fixed length, wait for timeout, then enter 'dummy account code'.	9 = Fixed length, wait for timeout, then enter 'dummy account code'.											

(continued)

Table 6-5 (Cont'd), Alternate Route Related Parameters

ENTER	DEFAULT	DESCRIPTION									
		<p style="text-align: center;"><b>Initial Acct. Code</b>                      <b>New Acct. Code</b></p> <p>4 = Same as '2' plus 10 more digits.                      * = Same as '8' plus 10 more digits.</p> <p>5 = Same as '3' plus 10 more digits.                      # = Same as '9' plus 10 more digits.</p> <p>PAV Code Type, where 't' in System option '011t' (PAV) is set to a '1' or enabled, and where 't' equals:</p> <p style="text-align: center;"><b>Use Initial Account Code</b></p> <p>1 = No Account Code.</p> <p>2 = Fixed length of one to nine digits. Send all gathered digits to Search Table 1.</p> <p>4 = Same as '2' with the fixed length being from 10 to 15 digits.</p> <p style="text-align: center;"><b>Use New Account Code</b></p> <p>8 = Fixed length of one to nine digits. Send all gathered digits to Search Table 1.</p> <p>* = Same as '8' with the fixed length being 10 to 15 digits.</p> <p><b>NOTE:</b> Flexible Account Codes and Dummy Account Codes are not supported when PAV is enabled.</p> <p>Account Code Warning Tones (beeps - ) where 't' equals:</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;">0 = None</td> <td style="width: 33%;">3 = </td> <td style="width: 33%;">6 = </td> </tr> <tr> <td>1 = </td> <td>4 = </td> <td>7 = </td> </tr> <tr> <td>2 = </td> <td>5 = </td> <td>8 = </td> </tr> </table> <p><b>NOTE:</b> Warning tones are 400ms ON and 400ms OFF. The warning tones start after expiration of r73t Timer. If the user fails to enter a digit before the specified number of tones expires, the user is returned a re-order tone of 200ms ON and 200ms OFF.</p>	0 = None	3 = 	6 = 	1 = 	4 = 	7 = 	2 = 	5 = 	8 = 
0 = None	3 = 	6 = 									
1 = 	4 = 	7 = 									
2 = 	5 = 	8 = 									
r79t	0	<p>Account Code Confirmation and Reroute Tones, where 't' equals:</p> <p>0 = A/C tone OFF and Reroute tone OFF</p> <p>1 = A/C tone ON and Reroute tone OFF</p> <p>2 = A/C tone OFF and Reroute tone ON</p> <p>3 = A/C tone ON and Reroute tone ON</p> <p>The account code confirmation tone is 200ms in duration.</p>									

**6.26** Since the descriptions for the Primary and Alternate Routes are similar, no differentiation will be made in the paragraphs that follow. The descriptions will apply to both Tables 6-4 and 6-5 equally, unless otherwise noted.

**6.27** r51t, r71t - These parameters select the Route Progress Tones. These tones will be 100 ms long with a 100 ms silence period

between tones. The tones will be present in the telephone receiver before the Dialer cuts the Central Office audio through. The default selection for all eight routes is '0' or no progress tones. A maximum of eight tones can be selected by entering a number from 1 to 8 for 't'. 'r' is a number from 1 to 4 to select the route for the tones. For example, if it is desired to program Route 2 for four progress tones by use of a terminal, the command would be entered as:

```
> 3514
>
```

When using a DTMF telephone to program, simply dial '3514' as illustrated below:

DIAL	HEAR	DIAL	HEAR
351	♪	4	♪♪

**Note:** Reroute tones are used in conjunction with registers r51t and r71t (routing tones). If r51t and r71t are set to '0', there will be no reroute tones if the call changes routes.

**6.28 r54t, r74t** – This parameter selects the Account Code Type when Positive Account Verification (011t) parameter is disabled. The default selection for this parameter is '1' or no account code. The only time that the type of account code would come into prominence with PAV disabled, would be if the Controller changes routes or defaults to another route on call failure. The controller, depending upon the account code type selected would then either use the 'initial account code' or request a 'new account'. In this case, no account code verification would be performed. If '011t' is enabled, depending on programming, verification will be performed. For example, if it is desired to program Route 3 for an initial account code of fixed length, wait for timeout, then reorder, with PAV disabled, programming from a terminal would appear as:

```
> [0110]
> [4512]
>
```

When a DTMF telephone is used to program the same example, simply dial the '0110' and '4512' as shown below:

DIAL	HEAR	DIAL	HEAR
011	♪	0	♪♪
451	♪	2	♪♪

**6.29 r59t, r79t** – This parameter selects the use of Account Code Warning Tones. These tones start after the end of the Account Code Wait Timer period (i.e., the amount of time that a user has to enter an account code, r53t, r73t). Once the tones have started, the user has to enter a digit before the specified number of tones have

been received, or the user is returned a re-order tone. Warning tones are 400 ms ON and 400 ms OFF. The re-order tone is 200 ms ON and 200 ms OFF. The default selection for this parameter is '0' or no tones.

**6.30** For a programming example, if it was desired to program Alternate Route 3 for eight warning tones, the command during a terminal programming period would be displayed as:

```
> [4798]
>
```

Or if a DTMF telephone were used to program the same example, simply dial '4798' as illustrated below:

DIAL	HEAR	DIAL	HEAR
479	♪	8	♪♪

**6.31 r60t, r80t** - These parameters select the Account Code Confirmation and Reroute Tones. The tones are 200 ms in duration. If enabled, the user will receive a tone in the telephone receiver after entering a a valid account code, and/or upon call failure and rerouting. Either or both of the parameters may be selected by programming a number from 1 to 3 when entering the parameter. The default for the parameter is 0 which disables both tones.

**6.32** If routing progress tones are disabled and the Account Code Confirmation tones are enabled, the user will receive one tone before entering the Account Code, and one tone to confirm that all digits have been entered.

**6.33** If routing tones and Account Code tones are both enabled, the user will receive the routing tones after the destination number. A tone will also be received at the end of the Account Code entry.

**6.34** If the routing and Account Code tones are both disabled, and r54t is disabled and expects a new Account Code on rerouting, the user will receive the Account Code progress tones.

**6.35** For a programming example, if it is desired to program Primary Route 3 for both Account Code Confirmation tone and Reroute tone, the parameter during a terminal programming session would be:

```
> [4603]
>
```

Or if a DTMF telephone were used to program the same example, simply dial '4603' as illustrated below:

DIAL	HEAR	DIAL	HEAR
460	♪	3	♪♪

**SEARCH TABLE ZERO CHANGES****Default Addition**

**6.36** An additional default entry has been added to Search Table Zero to allow the use of a PAV List Maintenance Code. This code is dialed by the user when maintaining the Positive Account Code list. It is only valid when PAV is enabled by selection of parameter 011t where 't' equals '1'.

Table	Template	Action	Description
803	#0xx	#xx	DTMF '#xx' is the PAV List Maintenance Code

**Action Digit Addition**

**6.37** One action digit has been added to the action digit list as shown in the General Information Manual, part 4. This action digit is only valid when the PAV is enabled by selection of the parameter 011t where 't' equals '1'. It allows the maintenance of Search Table 1.

Action Digit	Description
#*	Action code for (PAV) Search Table 1 Maintenance

**SEARCH TABLE ONE****Action Digit Changes**

**6.38** Table 6-6 below lists changes to the action digits used when programming Search Table 1. When programming other search tables, the normal action digits listed in the General Information Manual still apply. The action digits listed in 6-6 are only valid when the PAV is enabled by selection of parameter 011t where 't' equals a '1' and ONLY apply to Search Table 1.

**Table 6-6, Search Table 1 Action Digit Changes**

Action Digit	Description
0	Return user reorder tone, Deny call
1	Valid Account Code, allow call
*	Valid Account Code, allow call
#9	Delete specific Account Code

**STRING DATA ENTRY CHANGES**

**6.39** Table 6-7 on the next page lists the changes to the string data entry as listed in the General Information Manual, part 5.



**Table 6-7, String Data Entry Changes**

Register	Default	Description
602	504156	Machine Identifier (PAV in ASCII)
615 & 655	#85327	Access Control Sequences for Routes 0 and 4
625, 635, 645, 665, 675, and 685	#8533#62*427	Access Control Sequences for Routes 1, 2, 3, 5, 6, and 7 respectively.

**PROGRAMMING EXAMPLES**

**6.40** Table 6-8 below lists some programming examples. These examples only cover programming of the registers necessary to enable the Positive Account Verification portion of the Dialer. For other programming examples, refer to the General Information Manual.

**Assumptions**

**6.41** The examples in Table 6-8 are shown with the following assumptions in mind:

- 1) The Dialer has been initialized and the Default Program has been loaded.
- 2) The programming security code is '#0\*'.
- 3) Route 1 is used for long distance dialing.
- 4) Account Codes are required on long distance calls only.
- 5) Users are required to dial in a six digit Account Code after the long distance telephone number.
- 6) Site specific Dialer information has been programmed.

**Table 6-8, Programming Examples (PAV)**

Dial	Hear	Dial	Hear	Description
#0*	♪			Enter programming mode.
011	♪	1	♪♪	Enable Positive Account Verification.
252	♪	6	♪♪	Verified Account Code length of 6 digits for Route 1 only.
254	♪	2	♪♪	Enable Verified Account Codes for Route 1 only.
625	♪	#02 plus rest of sequence to make up the Access Control Sequence followed by ##.	♪♪	Program Access Control for Route 1. The #02 causes the Dialer to delay outpulsing until the Account Code has been verified.

Table 6-8 (Cont'd), Programming Examples (PAV)

Dial	Hear	Dial	Hear	Description
826	♪	123456*##	♪♪	Allows a user dialed Account Code of 123456.
826	♪	654321*##	♪♪	Allows a user dialed Account Code of 654321.
826	♪	626262*##	♪♪	Allows a user dialed Account Code of 626262. Repeat the 826 sequence until all of the employees 6 digit codes have been added.

**PAV LIST MAINTENANCE EXAMPLE**

6.42 Table 6-9 below lists an End-user PAV List Maintenance Example. This example illustrates the method to be used to update the Account Codes list. It has been entered with the following assumptions:

- 1) The Dialer has been programmed as in Table 6-8 above.
- 2) Valid user Account Codes are 123456, 654321, and 626262.
- 3) Employees with PAV codes 123456 and 626262 have been fired and two new employees have been hired. The new employees' codes will be 980934 and 348609.
- 4) The default Maintenance Access Code is the DTMF code '\*##'.

Table 6-9, PAV List Maintenance Example

Dial	Hear	Dial	Hear	Description
*##	♪	123456#9##	♪♪	Deletes employee PAV code 123456.
		626262#9##	♪♪	Deletes employee PAV code 626262.
		980934*##	♪♪	Enable employee PAV code 980934.
		348609*##	♪♪	Enable employee PAV code 348609.
				Go back On-Hook.

**ENTERING SPEED CALLS**

6.43 Speed Calls may be entered by using one of the formats listed below when programming the Dialer:

10 Speed Call Entries = 7nn dk mm . . . mm \* (if used) mm . . . ##  
 100 Speed Call Entries = 7nn dk mm . . . mm \* (if used) mm . . . ##  
 1000 Speed Call Entries = 7nnn dk mm . . . mm \* (if used) mm . . . ##

6.44 Table 6-10 below lists the digits required for Speed Call entries where 'n' is the number or location (bin) of the Speed Call Number. If 10 Speed Call entries are used, 'nn' is 00 through 09. If 100 Speed Call entries are used, 'nn' is 00 through 99. If 1000 Speed Call entries are used, 'nnn' is 000 through 999. 'd' is the key used to determine the trunk(s) that have access to the particular Speed Call Number. 'k' is the Network Override Key that is used to select the allowed routing for the particular Speed Call Number. 'mm . . . mm' is the telephone number to be dialed. 'x' is the delimiter used to tell the Dialer that if any other digits are entered, they will be considered Account Code Digits as illustrated by the 'p' entries. '##' is the Speed Call number entry terminator and will cause the number to be entered into the Dialer memory.

**Table 6-10, Speed Call Entries**

FIRST DIGIT = 7 SPEED CALL																																	
DIAL	DEFINITION																																
7nndkmm...mm## or 7nndkmm...mmxpp...pp##  7nndkmm...mm## or 7nndkmm...mmxpp...pp##  7nnndkmm...mm## or 7nnndkmm...mmxpp...pp##	<p>Format for 10 Speed Call entries where:                      nn is the number of the Speed Call entry (00 - 09).</p> <p>Format for 100 Speed Call entries where:                      nn is the number of the Speed Call entry (00 - 99).</p> <p>Format for 1000 Speed Call entries where:                      nnn is the number of the Speed Call entry (000 - 999).</p> <p>d is the key that selects the trunks to access the call number as follows:</p> <table style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">DIGIT</th> <th style="text-align: center;">ALLOWED TRUNKS</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0</td><td>ALL</td></tr> <tr><td style="text-align: center;">1</td><td>TRUNK 1</td></tr> <tr><td style="text-align: center;">2</td><td>TRUNK 2</td></tr> <tr><td style="text-align: center;">3</td><td>TRUNKS 1,2</td></tr> <tr><td style="text-align: center;">4</td><td>TRUNK 3</td></tr> <tr><td style="text-align: center;">5</td><td>TRUNKS 1,3</td></tr> <tr><td style="text-align: center;">6</td><td>TRUNKS 2,3</td></tr> <tr><td style="text-align: center;">7</td><td>TRUNKS 1,2,3</td></tr> <tr><td style="text-align: center;">8</td><td>TRUNK 4</td></tr> <tr><td style="text-align: center;">9</td><td>TRUNKS 1,4</td></tr> <tr><td style="text-align: center;">x</td><td>TRUNKS 2,4</td></tr> <tr><td style="text-align: center;">#</td><td>TRUNKS 1,2,4</td></tr> <tr><td style="text-align: center;">C</td><td>TRUNKS 3,4</td></tr> <tr><td style="text-align: center;">D</td><td>TRUNKS 1,3,4</td></tr> <tr><td style="text-align: center;">E</td><td>TRUNKS 2,3,4</td></tr> </tbody> </table> <p><b>NOTE:</b> The C, D, and E entries above may be made from a terminal.</p>	DIGIT	ALLOWED TRUNKS	0	ALL	1	TRUNK 1	2	TRUNK 2	3	TRUNKS 1,2	4	TRUNK 3	5	TRUNKS 1,3	6	TRUNKS 2,3	7	TRUNKS 1,2,3	8	TRUNK 4	9	TRUNKS 1,4	x	TRUNKS 2,4	#	TRUNKS 1,2,4	C	TRUNKS 3,4	D	TRUNKS 1,3,4	E	TRUNKS 2,3,4
DIGIT	ALLOWED TRUNKS																																
0	ALL																																
1	TRUNK 1																																
2	TRUNK 2																																
3	TRUNKS 1,2																																
4	TRUNK 3																																
5	TRUNKS 1,3																																
6	TRUNKS 2,3																																
7	TRUNKS 1,2,3																																
8	TRUNK 4																																
9	TRUNKS 1,4																																
x	TRUNKS 2,4																																
#	TRUNKS 1,2,4																																
C	TRUNKS 3,4																																
D	TRUNKS 1,3,4																																
E	TRUNKS 2,3,4																																

Table 6-10 (Cont'd), Speed Call Entries

DIAL	DEFINITION
<p>7nn## 7nnn##</p>	<p>k is the network override:            0 - 3 Force on Route #0 - #3.            4 - 7 Force on Route #4 - 7.            8 Use search table to determine routing.            9 Dial immediate, no Route # (transparent).</p> <p>mm...mm is the phone number. If the * is entered, the digits after the * are considered to be Account Code ('p's).</p> <p>## enters the Speed Call Number into the Dialer's memory.</p> <p>Delete speed dial entry nn (100 entries).            Delete speed dial entry nnn (1000 entries).</p>

- 1) After entering all Speed Calls, exit the programming mode by going On-Hook; or by dialing '999' on the DTMF Handset or, if using a terminal, typing an 'X'.
- 2) If it is necessary to re-enter the program mode, the default access codes are the same as those of a standard Dialer. They are: a) #0\* from the DTMF Handset, or b) ### from a user Speed Call entry viewpoint, or c) Carriage Return (<CR>) from a terminal.
- 3) Data confirmation may be accomplished from the programming mode with the use of a terminal. The '902' command will enter the data confirmation mode and allow the reading back of Speed Call entries (or any other parameter). The '907' command is used to exit the data confirmation mode.

#### SEARCH TABLE PROGRAMMING CONSIDERATIONS (FOR SPEED CALL)

##### Parameter 000t

6.45 Parameter '000t' selects the number of Speed Call entries allowed where 't' equals:

- 0 = 10 Speed Call Entries
- 1 = 100 Speed Call Entries
- 2 = 1000 Speed Call Entries

6.46 To use 1000 Speed Call entries, the default Speed Call Trigger in Table 803 must be deleted. It must be placed in Table 804 (or higher). The recommended Speed Call Trigger is the digit \*. If this digit is used, a Speed Call is dialed by pressing the \* followed by the location (bin) of the Speed Call. To set up the 803 and 804 tables when programming, enter:

**803** \*#9#9#9## Deletes defaulted \*nn

**804** \*#9#9#9#2## Programs \*nnn into Dialer

**6.47** If '000t' is set to '0', the programming slot number is still two digits. This must be within the range of 00 through 09. A single digit Speed Call Trigger (i.e., 802 \*#9#2) is possible for the Search Tables, but must be programmed within the range of 700 through 709 in the Speed Call slots.

**6.48** The maximum length of the Speed Call field is 30 characters (29 digits and a \*). The maximum length of a Speed Call or an Account Code field alone within the 30 character limit is 23 digits.

## 7. CONTROLLER MEMORY CAPACITY

**7.01** The PAV useable memory consists of an 8K X 8 bit battery backed up Random Access Memory (RAM) chip that is capable of holding approximately 14,500 characters. This memory area is available for the storage of parameters and data at programming time. The rest of the available space is used for program execution overhead.

**7.02** It is unlikely that a programmer will completely fill the RAM area with data. In the event that memory space becomes a matter of concern, the ground rules for estimating memory usage are discussed in the paragraphs to follow starting with paragraph 7.04.

**7.03** If a programmer runs out of space while programming the Controller, none of the previously programmed data will be lost. The controller simply refuses any more programming after complete memory usage by displaying a question mark (?) on the terminal screen at the termination of each data entry on the keyboard. If it is suspected that RAM space has been completely used up, contact the distributor or the MITEL DATACOM Field Service Office. Once contacted, these personnel can verify that all RAM space has been used, and can possibly recommend more efficient programming techniques that can remedy the situation. As previously mentioned, the programmer should almost never run out of RAM space for parameters and data.

**7.04** Estimates of the memory space required versus the available memory space are possible. The programmer can, therefore, estimate the memory space required before programming and can determine if the available space is insufficient.

### MEMORY SPACE ESTIMATING METHOD

**7.05** The simplest way to determine if the the intended data base will fit into available memory is to calculate the space required by the data. This space is then compared to the space available according to the following rules:

- 1) There are approximately 14,500 available data spaces in a freshly initialized Dialer. These spaces are used to store programmed data. All data to be programmed into the Dialer will use this space with the exception of default settings. If a default setting is used, it will not decrease the available space. Space is mainly consumed by the parameters which are defined as 'string' entries and require the ## terminator for entry. Entries that do not require the ## terminator may be ignored in calculations.
- 2) A Search Table entry (parameters 801 through 815) occupies a number of spaces equal to the length of the template plus the action digits. For example, an 804 Search Table entry such as '804 1315 0 ##' is four digits plus one action digit for a total of five memory spaces. The '804' and '##' entries are not counted.

An entry of '803 #9#9#9#2' is six digits plus two action digits for a total of eight memory spaces.

- 3) An Account Code entry (parameters 821 through 835) occupies the number of spaces equal to the length of the template (account code) plus the action digits. The account code '12345' with an action of 'valid account code, allow call' would be programmed as '825 12345 \*###' and would require six spaces. The '825' and '###' entries are not counted.
- 4) A Speed Call entry occupies a number of spaces equal to the length of the Speed Call plus six (an internal Controller requirement) spaces. This number must be rounded off to the next larger even number if the result is odd. For example, a Speed Call programmed as '7nnn 8 139311212 ##' requires 14 spaces in memory. The eight digits of the telephone number plus six additional for the Controller equals 14. The '7nnn' and '##' entries are not counted.
- 5) Access Control strings, OCC Access Numbers, OCC Authorization Codes, etc., all count, but in general require so little space that they may be neglected for the purpose of space estimations.

**Note:** Deleting a Speed Call with the '7nnn##' command does not reclaim all memory previously occupied by that entry. After deletion, the memory space increase only by the number of digits in the removed speed call number and not by the '+ 6' factor that was added in the calculation in 4) above.

**7.06** Figures 7-1 through 7-3 are calculation worksheets that have been included to assist in memory space calculations. Figure 7-1 is to be used in calculating Search Table space. Figure 7-2 is to be used in calculating Account Code space, and Figure 7-3 is to be used in calculating Speed Call number space. These figures are located at the end of this part.

**7.07** The sum of the Search Tables + Account Codes + Speed Call Numbers must be less than approximately 14,500 spaces. Using the assumption that there will be one speed call number for each password, and that the 801 through 815 search tables are not required to be programmed (as is the usual case), the following generalizations can be made:

$$\begin{array}{l}
 \text{Let } X = \text{QUANTITY} \\
 \text{ACCT. CODES} \qquad \qquad \qquad \text{SPEED CALLS} \\
 (\text{Length} + 2) X \quad + \quad (\text{Length} + 6) X \quad = \quad 14,500
 \end{array}$$

**7.08** For example, assume that the unit is programmed with all 5 digit Account Codes and 7 digit Speed Call numbers. Using the equation under paragraph 7.07 above, the amount of space used would be 725 spaces as shown below:

$$(5 + 2)X + (7 + 6)X = 14,500$$

$$7X + 13X = 14,500$$

$$20X = 14500$$

$$X = \frac{14500}{20}$$

$$X = 725$$

Therefore, 725 five digit account codes and 725 seven digit speed calls numbers may be safely stored in the RAM memory.

**7.09** Another example would be to assume that there will be twice as many account codes as speed call numbers. Account codes are still 5 digits long and speed call numbers are 7 digits long:

$$(5 + 2)2X + (7 + 6)X = 14,500$$

$$(7)2X + 13X = 14,500$$

$$14X + 13X = 14500$$

$$27X = 14500$$

$$X = \frac{14500}{27}$$

$$X = 537$$

Therefore, 1,074 five digit account codes (2X) and 537 seven digit speed call numbers may safely be stored in the RAM memory.

**7.10** If the extreme case were considered and based on the formula above, up to 381 15-digit account codes and 381 15-digit speed call numbers could be stored in the RAM memory. For those who demand more detailed calculations, simultaneous solutions using X and Y unknowns would allow calculation of uneven numbers of account code/speed call quantities. Calculus formulae would allow both lengths and quantities to be varied, but for simplicity, it is easier to use the charts included, with known intentions.



SEARCH TABLES Parameters 801 - 815			
Length+1	X	Qty.	Subtotal
Total Space			

Figure 7-1, Calculation Sht. 1

ACCOUNT CODES Parameters 821 - 835			
Length+2	X	Qty.	Subtotal
Total Space			

Figure 7-2, Calculation Sht. 2



--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## 8. TECHNICAL CIRCUIT DESCRIPTION

### INTRODUCTION

**8.01** This part will be added at a later date. For the present, refer to Appendix C, Figures C-1 and C-2 of the General Information Manual for an overall block diagram, and a simplified electrical diagram of the Controller, respectively.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## 9. PHYSICAL MAINTENANCE AND TROUBLESHOOTING

### PHYSICAL MAINTENANCE

**9.01** The SMarT-1<sup>™</sup> PAV, as is evident, is a fully self-contained unit. As such, it has no user repairable parts. If the warranty seal over the unit fasteners is broken, the warranty is void. In case of failure, replace the Controller as follows:

- 1) Power down the unit. This will cut-through the subscriber side to the CO side.
- 2) Remove the RJ31/CA31 plug from the Telco supplied socket. The shorting bars in the RJ31X/CA31A will cut-through to the line. Then,
- 3) Replace the Controller and re-connect.
- 4) Proceed as if a new installation.

### TROUBLESHOOTING

**9.02** This part will be added at a later date.

**--- THIS PAGE INTENTIONALLY LEFT BLANK ---**

**APPENDIX A****FCC INTERCONNECTION REQUIREMENTS**

**A1.01** This equipment has been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines through the standard connection cabling provided with the unit. This section is applicable to telephone interconnection in the United States.

**A1.02** Prior to the interconnection of this equipment, the local telephone company is to be notified; inform the company that you have FCC-registered equipment that you wish to connect to their trunks. Give them the following information:

- The telephone number of the line that will connect to the unit.
- The equipment being connected is a MITEL DATACOM INC. model SMarT-1™ or SMarT-1A™ with PAV Common Carrier Access Dialer and Call Controller.
- The FCC Registration Number for the SMarT-1™ units is EMP 85B-14558-LR-E.
- The FCC Ringer Equivalence Number (REN) which is 0.7B.
- The Connector Jacks required are RJ31X.

**CONNECTION LIMITATIONS**

**A1.03** Due to the FCC Part 68 Rule, no connection can be made to party lines and to coin telephone service. This unit is designed to be used on standard-device telephone lines. If there are any questions about the telephone line, such as how many pieces of equipment may be connected to it, the telephone company will provide this information upon request.

**NETWORK CHANGES**

**A1.04** The telephone company may make changes to its communication service; such changes may include the change of trunk circuits, changes in the operational characteristics of its trunks, etc. Before doing this, however, the company shall provide official notification, so that the operation of the Dialer service will not be interrupted.

**MAINTENANCE LIMITATIONS**

**A1.05** This equipment has been registered with the FCC for direct connection to the telephone network. Under the FCC program, the user is restricted from making any changes or repairs and from performing any maintenance operations other than those specifically included in this document.



**A1.06** There are no user repairable parts within the unit. It is sealed against user maintenance. If opened, all warranties are voided.

**A1.07** No cabling or wiring changes within the unit are permitted by the user. Plug-ended cables, as detailed in this document, are to be used for all external connections between the unit and the telephone company interface jack.

**A1.08** Power supply components and cabling is only to be changed or maintained by MITEL DATACOM INC. or by an authorized agent of MITEL DATACOM INC.

#### **TROUBLE CORRECTIONS**

**A1.09** For all malfunctions, appropriate field service is provided by MITEL DATACOM INC. or its authorized agents.

#### **DISCONNECTION**

**A1.10** If it is ever decided to permanently disconnect the SMarT-1™ Common Carrier Access Dialer and Call Controller with PAV from the present line, please notify the telephone company of this change.

## APPENDIX B OVERALL TOPICAL INDEX

CONTENTS	PAGE	CONTENTS	PAGE
ACCOUNT CODE CONFIRMATION/REROUTE TONES		CONTROLLER MEMORY CAPACITY	
SEE ROUTE RELATED PARAMETERS	38	CALCULATION SHEETS	48
SEE TABLE 6-4	35	MEMORY SPACE ESTIMATING METHOD	45
SEE TABLE 6-5	36	SEE DETAILED PROGRAMMING	45
ACCOUNT CODE TYPE			
SEE ROUTE RELATED PARAMETERS	37		
SEE TABLE 6-4	34	DATA CONFIRMATION	
SEE TABLE 6-5	35	SEE SPEED CALL ENTRY	21
ACCOUNT CODE VERIFICATION		DATA CONFIRMATION MODE	
SEE OPERATING DESCRIPTION	19	SEE TABLE 5-2	22
ACCOUNT CODE WARNING TONES		DC BALANCE	
SEE DIALER DESCRIPTION	4	SEE HARDWARE SPECIFICATIONS	5
SEE ROUTE RELATED PARAMETERS	37	DEFAULT ADDITION	
SEE TABLE 6-4	35	SEE SEARCH TABLE ZERO CHANGES	39
SEE TABLE 6-5	36	DEFAULT LISTING	
ACCOUNT CODES		SEE OPERATING DESCRIPTION	22
SEE DIALER DESCRIPTION	4	SEE TABLE 5-3	22
SEE OPERATING DESCRIPTION	19	DEFAULT SEARCH TABLE	
ACTION DIGIT ADDITION		SEE TABLE 6-3	32
SEE SEARCH TABLE ZERO CHANGES	39	SEE TRUNK RELATED PARAMETERS	33
ACTION DIGIT CHANGES		DETAILED PROGRAMMING	
SEE SEARCH TABLE ONE	39	CONTROLLER MEMORY CAPACITY	45
APPENDIX A		ENTERING SPEED CALLS	41
CONNECTION LIMITATIONS	A-1	INTRODUCTION	27
CONNECTOR JACKS	A-1	PAV LIST MAINTENANCE EXAMPLE	41
DISCONNECTION	A-2	PROGRAMMING EXAMPLES	40
FCC INTERCONNECTION REQUIREMENTS	A-1	ROUTE RELATED PARAMETERS	33
FCC REGISTRATION NUMBER	A-1	SEARCH TABLE ONE	39
MAINTENANCE LIMITATIONS	A-1	SEARCH TABLE PROGRAMMING CONSIDERATIONS	43
NETWORK CHANGES	A-1	SEARCH TABLE ZERO CHANGES	39
RINGER EQUIVALENCE NUMBER	A-1	SPECIAL FUNCTIONS	27
TROUBLE CORRECTIONS	A-2	STRING DATA ENTRY CHANGES	39
		SYSTEM WIDE PARAMETERS	30
BATTERY FEED		TRUNK RELATED PARAMETERS	31
SEE HARDWARE SPECIFICATIONS	5	DIALER DESCRIPTION	
BAUD RATE		SEE GENERAL DESCRIPTION	3
SEE RS-232 PORT SPECIFICATIONS	7	DIALTONE	
BAUD RATE/RS-232 PORT		SEE HARDWARE SPECIFICATIONS	6
SEE SYSTEM WIDE PARAMETERS	31	DIMENSIONS	
SEE TABLE 6-2	30	SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	7
BIT EIGHT SENSE		DISCONNECTION	
SEE RS-232 PORT SPECIFICATIONS	7	SEE APPENDIX A	A-2
BITS PER CHARACTER		DOCUMENT CONVENTIONS	
SEE RS-232 PORT SPECIFICATIONS	7	SEE INTRODUCTION	2
		DOCUMENT HISTORY	
CALCULATION SHEETS		SEE INTRODUCTION	2
SEE CONTROLLER MEMORY CAPACITY	48	DOCUMENT NUMBERING	
SEE FIGURE 7-1	48	SEE INTRODUCTION	1
SEE FIGURE 7-2	48	DOCUMENT OBJECTIVES	
SEE FIGURE 7-3	49	SEE INTRODUCTION	1
CLEAR ALL SEARCH TABLES		DOCUMENT OVERVIEW	
SEE TABLE 5-2	22	SEE INTRODUCTION	1
CLEAR SEARCH TABLES		DTMF RECEIVER	
SEE SPECIAL FUNCTIONS	29	SEE HARDWARE SPECIFICATIONS	6
SEE TABLE 6-1	27	DTMF SENDER	
CLONE MASTER MODE		SEE HARDWARE SPECIFICATIONS	6
SEE TABLE 5-2	22		
CONNECTION LIMITATIONS		ELECTRICAL/MECHANICAL SPECIFICATIONS	
SEE APPENDIX A	A-1	SEE SPECIFICATIONS	7
CONNECTION PROCEDURE		SEE TABLE 3-3	7
SEE CONNECTIONS	16	ENTER DATA CONFIRMATION MODE	
CONNECTIONS		SEE SPECIAL FUNCTIONS	28
RJ31X USOC JACK AND CABLE	16	SEE TABLE 6-1	27
RS-232 PORT CONFIGURATION	16	ENTER DATE AND TIME	
SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	7	SEE SPECIAL FUNCTIONS	28
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	12	SEE TABLE 6-1	27
CONNECTOR JACKS		ENTER TANDEM MODE	
SEE APPENDIX A	A-1	SEE TABLE 5-2	22
		SEE TABLE 6-1	28
		ENTERING PROGRAM MODE	
		SEE SPEED CALL ENTRY	21

**SECTION MITL8350-047-102-NA**

CONTENTS	PAGE	CONTENTS	PAGE
ENTERING SPEED CALLS		SEE TABLE 5-2	22
SEE DETAILED PROGRAMMING	41	SEE TABLE 6-1	27
SEE OPERATING DESCRIPTION	20		
SPEED CALL FORMAT	20		
EXIT DATA CONFIRMATION		MAINTENANCE LIMITATIONS	
SEE SPECIAL FUNCTIONS	29	SEE APPENDIX A	A-1
SEE TABLE 6-1	27	MAKING TELEPHONE CALLS	
EXIT PROGRAM MODE		SEE USER OPERATION	24
SEE SPECIAL FUNCTIONS	28	MEMORY SPACE ESTIMATING METHOD	
SEE TABLE 6-1	27	CONTROLLER MEMORY CAPACITY	45
EXIT PROGRAMMING		MODE OF OPERATION	
SEE TABLE 5-2	22	SEE RS-232 PORT SPECIFICATIONS	7
EXITING PROGRAM MODE		MOUNTING	
SEE SPEED CALL ENTRY	21	SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	7
EXPANDED MEMORY AREA		SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	12
SEE OPERATING DESCRIPTION	19		
FCC INTERCONNECTION REQUIREMENTS		NETWORK CHANGES	
GENERAL	1	SEE APPENDIX A	A-1
SEE APPENDIX A	A-1	NETWORK OVERRIDE	
FCC REGISTRATION NUMBER		SEE TABLE 5-1	20
SEE APPENDIX A	A-1	NEW ACCOUNT CODE	
FCC RINGER EQUIVALENCE		SEE DIALER DESCRIPTION	4
SEE HARDWARE SPECIFICATIONS	5	NUMBER OF SPEED CALL ENTRIES	
FEATURES AND CAPABILITIES		SEE SYSTEM WIDE PARAMETERS	31
SEE GENERAL DESCRIPTION	3	SEE TABLE 6-2	30
FEED RESISTANCE			
SEE HARDWARE SPECIFICATIONS	5	OFF-HOOK CURRENT	
FLASH ALLOWED TIME		SEE HARDWARE SPECIFICATIONS	5
SEE TABLE 6-3	31	OFF-HOOK DIGIT REFUSAL TIME	
SEE TRUNK RELATED PARAMETERS	32	SEE TABLE 6-3	31
		SEE TRUNK RELATED PARAMETERS	32
GENERAL DESCRIPTION		OFF-HOOK PROGRESS TONE	
DIALER DESCRIPTION	3	SEE TABLE 6-3	32
FEATURES AND CAPABILITIES	3	SEE TRUNK RELATED PARAMETERS	33
GROUNDING VOLTAGE		OPEN CIRCUIT VOLTAGE	
SEE HARDWARE SPECIFICATIONS	5	SEE HARDWARE SPECIFICATIONS	5
		OPERATING CURRENT	
HARDWARE SPECIFICATIONS		SEE HARDWARE SPECIFICATIONS	5
SEE SPECIFICATIONS	5	OPERATING DESCRIPTION	
SEE TABLE 3-1	5.6	DEFAULT LISTING	22
HUMIDITY		ENTERING SPEED CALLS	20
SEE HARDWARE SPECIFICATIONS	6	GENERAL	19
		INITIALIZING THE DIALER	19
INITIALIZING PROCEDURE		SPECIFIC DEFAULTS	22
SEE INITIALIZING THE DIALER	19	USER OPERATION	24
INITIALIZING THE DIALER		OPERATING RANGE	
PROCEDURE	19	SEE HARDWARE SPECIFICATIONS	6
SEE OPERATING DESCRIPTION	19	ORDERING INFORMATION	
INSTALLATION REQUIREMENTS		SEE TABLE 4-1	16
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	9	SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	16
INTENDED AUDIENCE		OVERALL TOPICAL INDEX	
SEE INTRODUCTION	2	SEE APPENDIX B	B-1
INTRODUCTION			
DOCUMENT CONVENTIONS	2	PARAMETER 000T	
DOCUMENT HISTORY	2	SEE SEARCH TABLE PROGRAMMING CONSIDERATIONS	43
DOCUMENT OBJECTIVES	1	PARITY	
DOCUMENT OVERVIEW	1	SEE RS-232 PORT SPECIFICATIONS	7
INTENDED AUDIENCE	2	PART NUMBERS	
READER COMMENTS	2	SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	16
		PAV LIST MAINTENANCE EXAMPLE	
JACKS		SEE DETAILED PROGRAMMIN	41
SEE APPENDIX A	A-1	SEE TABLE 6-9	41
		PHYSICAL MAINTENANCE	
KEYSLOT MOUNTING		SEE PHYSICAL MAINTENANCE AND TROUBLESHOOTING	53
SEE MOUNTING	12	PHYSICAL MAINTENANCE AND TROUBLESHOOTING	
		PHYSICAL MAINTENANCE	53
LEAKAGE		TROUBLESHOOTING	53
SEE HARDWARE SPECIFICATIONS	5	POSITIVE ACCOUNT VERIFICATION	
LOAD DEFAULT DATABASE		SEE SYSTEM WIDE PARAMETERS	31
SEE SPECIAL FUNCTIONS	29	SEE TABLE 6-2	30
		POWER	
		SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	7
		POWER RECEPTACLE RECOMMENDATIONS	
		SEE POWER REQUIREMENTS	12
		POWER REQUIREMENTS	

CONTENTS	PAGE	CONTENTS	PAGE
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	12	SEARCH TABLE ONE	
PROGRAMMABLE PROGRESS TONES		ACTION DIGIT CHANGES	39
SEE DIALER DESCRIPTION	4	SEE DETAILED PROGRAMMING	39
SEE OPERATING DESCRIPTION	19	SEE TABLE 6-6	39
PROGRAMMING ACCESS CODE		SEARCH TABLE PROGRAMMING CONSIDERATIONS	
SEE DIALER DESCRIPTION	4	PARAMETER 000T	43
PROGRAMMING EXAMPLES		SEE DETAILED PROGRAMMING	43
SEE DETAILED PROGRAMMING	40	SEARCH TABLE ZERO CHANGES	
PROGRAMMING EXAMPLES (PAV)		ACTION DIGIT ADDITION	39
SEE TABLE 6-8	40	DEFAULT ADDITION	39
PROGRESS TONES		SEE DETAILED PROGRAMMING	39
SEE DIALER DESCRIPTION	4	SENSING RESISTANCE	
		SEE HARDWARE SPECIFICATIONS	5
R51T		SET INTERNAL CLOCK	
SEE ROUTE RELATED PARAMETERS	36	SEE TABLE 5-2	22
SEE TABLE 6-4	34	SHIPPING	
R54T		SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	9
SEE ROUTE RELATED PARAMETERS	37	SHIPPING AND RECEIVING	
SEE TABLE 6-4	34	REPACKING	9
R59T		UNPACKING	9
SEE ROUTE RELATED PARAMETERS	37	SHORT CIRCUIT CURRENT	
SEE TABLE 6-4	35	SEE HARDWARE SPECIFICATIONS	5
R60T		SPECIAL FUNCTIONS	
SEE ROUTE RELATED PARAMETERS	38	SEE DETAILED PROGRAMMING	27
SEE TABLE 6-4	35	SPECIAL FUNCTIONS AND COMMANDS	
R71T		SEE TABLE 5-2	22
SEE ROUTE RELATED PARAMETERS	36	SPECIFIC DEFAULTS	
SEE TABLE 6-5	35	903 DEFAULT COMMAND	22
R74T		SFF OPERATING DESCRIPTION	22
SEE ROUTE RELATED PARAMETERS	37	STANDARD OCC DIALER	22
SEE TABLE 6-5	35	SPECIFIC RESPONSIBILITIES	
R79T		SEE USER OPERATION	24
SEE ROUTE RELATED PARAMETERS	37	SPECIFICATIONS	
SEE TABLE 6-5	36	ELECTRICAL/MECHANICAL SPECIFICATIONS	7
R80T		HARDWARE SPECIFICATIONS	5
SEE ROUTE RELATED PARAMETERS	38	RS-232 PORT	7
SEE TABLE 6-5	36	SPEED CALL ENTRIES	
READER COMMENTS		SEE TABLE 6-10	42,43
SEE INTRODUCTION	2	SPEED CALL FORMAT	
RECEIVING		SEE ENTERING SPEED CALLS	20,41,42
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	9	SEE TABLE 5-1	20
RECOGNITION TIME, TIP TO GND		SPEED CALL KEY	
SEE HARDWARE SPECIFICATIONS	5	SEE TABLE 5-1	20
REPACKING		SPEED CALL NUMBER	
SEE SHIPPING AND RECEIVING	9	SEE TABLE 5-1	20
RETURN LOSS		STANDARD DIALER	
SEE HARDWARE SPECIFICATIONS	5	SEE DIALER DESCRIPTION	3
RETURN TO NORMAL PROGRAMMING		STANDARD OCC DIALER	
SEE TABLE 5-2	22	SEE SPECIFIC DEFAULTS	22
RINGER EQUIVALENCE NUMBER		STRING DATA ENTRY CHANGES	
SEE APPENDIX A	A-1	SEE DETAILED PROGRAMMING	39
RINGER IMPEDANCE		SEE TABLE 6-7	40
SEE HARDWARE SPECIFICATIONS	5	SYSTEM PARAMETERS	
RINGING SENSITIVITY		SEE TABLE 5-2	22
SEE HARDWARE SPECIFICATIONS	5	SYSTEM WIDE PARAMETERS	
RJ31X USOC JACK AND CABLE		SEE DETAILED PROGRAMMING	30
SEE CONNECTIONS	16		
ROTARY RECEIVER		TECHNICAL CIRCUIT DESCRIPTION	
SEE HARDWARE SPECIFICATIONS	6	INTRODUCTION	51
ROTARY SENDER		TEMPERATURE	
SEE HARDWARE SPECIFICATIONS	6	SEE HARDWARE SPECIFICATIONS	6
ROUTE PROGRESS TONES		TERMINATION	
SEE ROUTE RELATED PARAMETERS	36	SEE HARDWARE SPECIFICATIONS	5
SEE TABLE 6-4	34	TERMINATION ENTRY	
SEE TABLE 6-5	35	SEE SPEED CALL FORMAT	20
ROUTE RELATED PARAMETERS		TIP GROUND REMOVAL TIMER	
SEE DETAILED PROGRAMMING	33	SEE TABLE 6-3	32
SEE TABLE 6-4	34	SEE TRUNK RELATED PARAMETERS	33
RS-232 PORT CONFIGURATION		TROUBLE CORRECTIONS	
SEE CONNECTIONS	16	SEE APPENDIX A	A-2
RS-232 PORT SPECIFICATIONS		TROUBLESHOOTING	
SEE SPECIFICATIONS	7	SEE PHYSICAL MAINTENANCE AND TROUBLESHOOTING	53
SEE TABLE 3-2	7	TRUNK RELATED PARAMETERS	
		SEE DETAILED PROGRAMMING	31
SEARCH TABLE 1		SEE TABLE 6-3	31
SEE DIALER DESCRIPTION	4	TYPE OF UNIT	
		SEE APPENDIX A	A-1

**SECTION MITL8350-047-102-NA**

CONTENTS	PAGE	CONTENTS	PAGE
UNPACKING		006T	
SEE SHIPPING AND RECEIVING . . . . .	9	SEE SYSTEM WIDE PARAMETERS . . . . .	31
UNPACKING PROCEDURE		SEE TABLE 6-2 . . . . .	30
SEE UNPACKING . . . . .	9	U111	
UNPACKING, INSTALLATION AND ORDERING INFORMATION		SEE SYSTEM WIDE PARAMETERS . . . . .	31
CONNECTIONS . . . . .	12	SEE TABLE 6-2 . . . . .	30
INSTALLATION REQUIREMENTS . . . . .	9		
MOUNTING . . . . .	12	902	
ORDERING INFORMATION . . . . .	16	SEE SPECIAL FUNCTIONS . . . . .	28
POWER REQUIREMENTS . . . . .	12	SEE TABLE 5-2 . . . . .	22
SHIPPING AND RECEIVING . . . . .	9	SEE TABLE 6-1 . . . . .	27
USER OPERATION		903	
SEE OPERATING DESCRIPTION . . . . .	24	SEE SPECIAL FUNCTIONS . . . . .	29
		SEE TABLE 5-2 . . . . .	22
WALL MOUNTING BRACKET		SEE TABLE 6-1 . . . . .	27
SEE MOUNTING . . . . .	12	SEE SPECIFIC DEFAULTS . . . . .	22
WEIGHT		904	
SEE ELECTRICAL/MECHANICAL SPECIFICATIONS . . . . .	7	SEE SPECIAL FUNCTIONS . . . . .	29
		SEE TABLE 5-2 . . . . .	22
		SEE TABLE 6-1 . . . . .	27
X04T		906	
SEE TABLE 6-3 . . . . .	31	SEE TABLE 5-2 . . . . .	22
SEE TRUNK RELATED PARAMETERS . . . . .	32	907	
X08T		SEE SPECIAL FUNCTIONS . . . . .	29
SEE TABLE 6-3 . . . . .	31	SEE TABLE 5-2 . . . . .	22
SEE TRUNK RELATED PARAMETERS . . . . .	32	SEE TABLE 6-1 . . . . .	27
X19T		908	
SEE TABLE 6-3 . . . . .	32	SEE TABLE 5-2 . . . . .	22
SEE TRUNK RELATED PARAMETERS . . . . .	33	SEE TABLE 6-1 . . . . .	28
X22T		980	
SEE TABLE 6-3 . . . . .	32	SEE SPECIAL FUNCTIONS . . . . .	28
SEE TRUNK RELATED PARAMETERS . . . . .	33	SEE TABLE 5-2 . . . . .	22
X34T		SEE TABLE 6-1 . . . . .	27
SEE TABLE 6-3 . . . . .	32	999	
SEE TRUNK RELATED PARAMETERS . . . . .	33	SEE SPECIAL FUNCTIONS . . . . .	28
		SEE TABLE 5-2 . . . . .	22
000T		SEE TABLE 6-1 . . . . .	27
SEE SYSTEM WIDE PARAMETERS . . . . .	31		
SEE TABLE 6-2 . . . . .	30		

**SECTION MITL8350-047-102-NA**

---

**NOTES**

---



MITEL DATACOM INC.  
P.O. BOX 17266  
DULLES INTERNATIONAL AIRPORT  
WASHINGTON, D.C., U.S.A., 20041  
TELEPHONE: (703)-661-6600



# **smart-1™**

**SECURITY ACCESS CONTROLLER (SAC)**

**GENERAL INFORMATION**



© - Copyright of MITEL DATACOM INC. 1986  
™ - Trademark of MITEL DATACOM INC.  
® - Registered Trademark of MITEL CORPORATION

**WARRANTY NOTICE**

**THIS PRODUCT IS WARRANTED FOR ONE (1) YEAR AGAINST DEFECTS IN MATERIAL AND WORKMANSHIP. MITEL DATACOM'S LIABILITY IS LIMITED TO REPAIR AND RETURN OF DEFECTIVE GOODS.**

**MITEL DATACOM MAKES NO EXPRESS OR IMPLIED WARRANTIES REGARDING THE QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE BEYOND THOSE WHICH APPEAR ABOVE. MITEL DATACOM SHALL NOT BE RESPONSIBLE FOR CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, DAMAGE TO BUSINESS OR OWNER'S COMPUTER SYSTEM, OR OTHER BUSINESS RELATIONS. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES.**



**NOTICE TO U.S. CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The SMarT-1™ Security Access Controller generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**NOTICE TO CANADIAN CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**NOTICE**

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The Department does not guarantee that the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground connections to the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**CAUTION**

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as required.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load, to be connected to a telephone loop, that is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all of the devices does not exceed 100. An alphabetic suffix is also specified in the Load Number and designates the appropriate ringing type (A or B), if applicable. For example, LN = 20 A designates a Load Number of 20 and an 'A' type ringer.

**--- THIS PAGE INTENTIONALLY LEFT BLANK ---**

**IMPORTANT NOTES**

Please note that MITEL DATACOM INC. has set up a National Field Service number for technical and Installation assistance located in Dallas, Texas. This number is [214] 386-9400 for U.S. customers only (outside of normal working hours, a telephone answering service has been established for your convenience at this same number). For Canadian customers, please contact your local MITEL Regional Office.

The SMaRT-1™ Security Access Controller includes an on-board battery back-up system to prevent the loss of customer database. Besides protecting against loss of data during momentary power outages, this battery back-up should also provide sufficient memory retention to allow the Controller to be programmed by the distributor and then transported to the customer's site for installation. This battery back-up, however, is not intended for long storage periods and cannot be guaranteed to support memory for long periods of time.

As received from the factory, the Controller battery is not guaranteed to have a full charge applied to it. In fact, the battery is likely to be only partially charged in view of the time in transit, and distributor storage time. No guarantee of any battery charge status can be made until the Controller has been powered up for a period of time. A period of 24 hours is necessary to achieve a full charge on the battery.

Upon removal from its shipping carton, the Controller should be powered up for a period of time and then "INITIALIZED" to load the operating system and default database into memory. Initialization is most easily accomplished via the RS-232 port using 1200 Baud communications from a terminal. Never rely on programming entered into a Controller until it has been "INITIALIZED" (see Part 6, page 29).

Once initialized, the Controller should seldom ever have to be initialized again. From this point, programming may be only accomplished by use of a suitable terminal. There is a "942903" Load Default Data Command that will restore memory to the initialized state once an "INITIALIZE" has been performed. Once initialized, the Controller will only respond to input via the RS-232 port at the default 1200 Baud rate for programming purposes.

**REASONS FOR ADDITIONAL "INITIALIZE" OPERATIONS**

The Controller has just been removed from storage or shipping carton.

The program access codes have been deleted accidentally or the access codes have been changed and forgotten.

The Controller has just been repaired.

Long storage times.

Loss of data retention. Investigate for reason!

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**smart-1****SECURITY ACCESS CONTROLLER (SAC)****GENERAL INFORMATION**

<b>CONTENTS</b>	<b>PAGE</b>
<b>1. INTRODUCTION</b> .....	<b>1</b>
DOCUMENT OBJECTIVES .....	1
DOCUMENT OVERVIEW .....	1
INTENDED AUDIENCE .....	2
DOCUMENT HISTORY .....	2
READER COMMENTS .....	2
DOCUMENT CONVENTIONS .....	2
<b>2. GENERAL DESCRIPTION</b> .....	<b>3</b>
FEATURES AND CAPABILITIES .....	3
CONTROLLER DESCRIPTION .....	3
Network Compatibility .....	5
System Power .....	5
Lines/Models .....	5
Area Code/Office Code/Call Searching .....	6
Adaptive Call Routing .....	6
Least Cost Routing .....	6
Call Recording/RS-232 Port .....	6
VERSATILE PROGRAMMING .....	6
Description .....	6
Initialization .....	6
Programming .....	7
<b>3. SPECIFICATIONS</b> .....	<b>9</b>
HARDWARE .....	9
RS-232 PORT .....	11
ELECTRICAL/MECHANICAL .....	11
<b>4. UNPACKING, INSTALLATION AND ORDERING INFORMATION</b> .	<b>13</b>
SHIPPING AND RECEIVING .....	13
Unpacking .....	13
Repacking .....	13
INSTALLATION REQUIREMENTS .....	13
POWER REQUIREMENTS .....	16
MOUNTING .....	16
CONNECTIONS .....	16
RS-232 Port Configuration .....	20
RJ31X/CA31A USOC Jack and Cable .....	20
ORDERING INFORMATION .....	21

CONTENTS	PAGE
<b>5. OPERATING DESCRIPTION</b> .....	<b>23</b>
SECURITY .....	23
OPERATIONAL SEQUENCES .....	23
DETAILED OPERATING DESCRIPTION .....	25
With Modems .....	25
Other Operational Procedures .....	28
<b>6. INITIALIZATION</b> .....	<b>29</b>
INTRODUCTION .....	29
PROCEDURE .....	30
<b>7. PROGRAMMING</b> .....	<b>33</b>
INTRODUCTION .....	33
PROGRAMMING FOR CALLBACK OPERATION .....	34
Procedural Steps .....	35
TESTING THE CONTROLLER INSTALLATION .....	37
Modem Setup .....	37
Theory of the Test .....	37
Actual Testing .....	38
PROGRAMMING FOR USER-ENTERED CALLBACK NUMBER OPERATION .....	39
Program Verification .....	41
DTMF CUT-THROUGH ACCESS .....	42
DETAILED PROGRAMMING DESCRIPTIONS .....	42
System Parameters .....	43
Trunk Related Parameters .....	49
Non-Controller Pertinent Parameters .....	55
PASSWORD PROGRAMMING .....	59
Password Programming Examples .....	62
Example 1 .....	62
Example 2 .....	62
Example 3 .....	62
AUTOMATIC CALLBACK (SPEED CALL) PROGRAMMING .....	63
SEARCH TABLE PROGRAMMING .....	64
Action Digit Definitions .....	64
Programming Examples .....	66
Search Table Defaults .....	66
PROGRAMMING ROUTING PARAMETERS .....	67
6r5 Access Route, Access Control Sequences .....	67
Programming Examples .....	69
CALL DETAIL RECORD (CDR) PROGRAMMING .....	71
CDR Description .....	71
Call Detail Record Format .....	71
Examples .....	72
MITEL Format .....	73
CONTROLLER MEMORY CAPACITY .....	75
Memory Space Estimating Method .....	76



<b>CONTENTS</b>	<b>PAGE</b>
<b>8. TECHNICAL CIRCUIT DESCRIPTION</b> .....	<b>81</b>
INTRODUCTION .....	81
<b>9. MAINTENANCE AND TROUBLESHOOTING</b> .....	<b>83</b>
MAINTENANCE .....	83
TROUBLESHOOTING .....	83
<b>APPENDIX A</b> .....	<b>A-1</b>
FCC INTERCONNECTION REQUIREMENTS .....	A-1
CONNECTION LIMITATIONS .....	A-1
NETWORK CHANGES .....	A-1
MAINTENANCE LIMITATIONS .....	A-1
TROUBLE CORRECTIONS .....	A-2
DISCONNECTION .....	A-2
<b>APPENDIX B</b> .....	<b>B-1</b>
GLOSSARY OF TERMS .....	B-1
<b>APPENDIX C</b> .....	<b>C-1</b>
ADDITIONAL INFORMATION .....	C-1
<b>APPENDIX D</b> .....	<b>D-1</b>
OVERALL TOPICAL INDEX .....	D-1
 <b>FIGURES</b>	 <b>PAGE</b>
2-1, SMarT-1 Security Access Controller .....	4
4-1, Equipment Unpacking and Repacking .....	14
4-2, Multi-Unit Packing and Repacking .....	15
4-3, Controller I/O Connections .....	17
4-4, Typical Controller Installation Configuration .....	17
4-5, Typical Connection Configuration .....	18
4-6, RS-232 Interface Connector .....	18
4-7, USOC RJ31X/CA31A Jack and Cable Assy. ....	19
7-1, Terminal Display of Data Entry Check .....	37
7-2, Typical Callback Operation, SAC and Modem Timing .....	40
7-3, Terminal Display, User-Entered Callback Number .....	42
7-4, Password Format .....	60
7-5, Incoming Call Detail Record Examples .....	72
7-6, Outgoing Call Detail Record Examples .....	73
7-7, Calculation Sht. 1 .....	79
7-8, Calculation Sht. 2 .....	79
7-9, Calculation Sht. 3 .....	80
C-1, SMarT-1 System Block Diagram .....	C-2
C-2, SMarT-1 Simplified Electrical Diagram .....	C-3

TABLES	PAGE
3-1, SMarT-1 Hardware Specifications .....	9,10
3-2, RS-232 Port Specifications .....	11
3-3, Electrical/Mechanical Specifications .....	11
4-1, SMarT-1 Ordering Information .....	21
7-1, Initialization/Default Programming Parameters .....	33,34
7-2, System Special Parameters .....	44
7-3, System Wide Operational Parameters .....	47,48
7-4, Trunk Related Parameters .....	50-52
7-5, Non-Controller Pertinent Parameters .....	55-57
7-6, Password Table Descriptions .....	61
7-7, Password Action Digits (a) .....	61
7-8, Time-Of-Day Codes (t) .....	61
7-9, Network Override Codes .....	63,64
7-10, Search Table Descriptions .....	65
7-11, Action Digt Descriptions .....	65,66
7-12, 6r5 Parameter Codes .....	67,68
7-13, Dialtone Detector Codes .....	68
7-14, 'a' Codes .....	69
7-15, 'b' Codes .....	69
7-16, Additional Route Parameters .....	70
7-17, MITEL Call Record Format Fields .....	74
C-1, ASCII Codes .....	C-4
C-2, Legal Controller Programming Input Characters .....	C-5
C-3, Default Parameter Summary .....	C-6 to C-8

## 1. INTRODUCTION

### DOCUMENT OBJECTIVES

**1.01** This document contains all information that relates to the SMarT-1™ Security Access Controller. The title of the Section is the 'SMarT-1™ SECURITY ACCESS CONTROLLER (SAC), General Information' and can be referred to as 'SECTION MITL8350-048-100-NA' or by its title. This part of the Section is an overview of the contents of the document and outlines the intended audience.

**1.02** From this point forward and for ease of understanding, the SMarT-1™ Security Access Controller (SAC) will be referred to in text as the 'Controller' or as the 'SAC'.

### DOCUMENT OVERVIEW

**1.03** The document contains important notices to customers at the front on pages i through v. The first is for U.S. customers. The second is for Canadian customers, while the third is general in nature. It is advisable to read the applicable notices prior to reading this manual or operating the Controller. If a particular notice does not apply, it may be removed from the manual.

**1.04** Following the notices is a general Table of Contents. This Table lists all of the major parts of the manual, along with sub-headings in the order that they appear. The manual is divided into 9 parts, with four appendices. The last Appendix is an overall index in alphanumeric order.

**1.05** The first part is a general introduction and overview of the manual. The second is a description of the features and capabilities of the SAC followed by a general unit description. The third lists all specifications of the unit.

**1.06** The fourth part describes in detail, all procedures for receiving, shipping, unpacking, installation and connection of the Controller. This is followed by a detailed operating description. The sixth part outlines unit initialization, while the seventh describes detailed programming. The eighth includes a technical circuit description, while the ninth lists maintenance and troubleshooting procedures.

**1.07** The four appendices provide supplementary information that may be of some use to the user/programmer. The first appendix describes FCC interconnection requirements and should be read by all installers. The second and third appendices contain a glossary of terms and additional information, respectively.

**1.08** The last Appendix is an overall topical index listed in alphanumeric order. This index lists a topic and the page where the topic is discussed. It is included to provide an easy reference guide in locating specific information.

**INTENDED AUDIENCE**

**1.09** This document is intended for use as a general information manual for the installer and user of the SMarT-1™ Security Access Controller (SAC). It is also intended to be a technical description of the SAC for programmers and other interested parties. The document does not attempt to teach programming concepts. It is assumed that the user has some programming experience.

**DOCUMENT HISTORY**

**1.10** This is the second formal issue of the 'SMarT-1™ Security Access Controller (SAC), General Information'. Subsequent issues will be provided as information is changed or upgraded. These subsequent issues will replace any previous issue.

**READER COMMENTS**

**1.11** If the user has any comments or corrections pertaining to this document, please forward a reply in writing to MITEL Documentation Control in Ogdensburg, N.Y. quoting document number 'SECTION MITL8350-048-001-NA'.

**DOCUMENT CONVENTIONS**

**1.12** Throughout this manual, the following conventions will be used:

<b>SYMBOL</b>	<b>MEANING</b>
...	A horizontal ellipsis means that the preceding item may be repeated one or more times.
.	A vertical ellipsis means that not all of the statements in a figure or an example are shown; their content is not important to the example.
[[ ]]	Double square brackets in statement and format descriptions enclose items that are optional.
{ }	Braces enclose lists from which the user must choose one item. Each item is separated from the other by a comma ','.
< >	The less than and greater than signs, used in statement and format descriptions, usually enclose a special key to be pressed, such as a carriage return <CR> key.
>	The greater than sign, when appearing alone, indicates the terminal prompt as shown on the terminal display.  Terminal lines use two conventions. If the characters are printed in capitalized characters (upper case), the words are typed as listed. If they are printed in small characters (lower case), they require that some character(s) be entered in their place.

## 2. GENERAL DESCRIPTION

### FEATURES AND CAPABILITIES

**2.01** The SMarT-1™ Security Access Controller has the following features and capabilities:

- Compliance with FCC Parts 68 and 15
- 4-, 2-, or 1-Line capacity
- A Stand Alone Device
- Interfaces with Modems that are compatible with the Public Switched Network
- Intercepts incoming calls without presenting a Modem Answer Tone
- Verifiable password protection ranging from 2 to 15 digits in length
- Callback feature allows password to be associated to a specific dial back telephone number
- Bypass of Callback feature (if required)
- Manual entry of Callback number available through Class of Service
- A maximum of 1000 Passwords/Callback numbers
- Two sets of 4 carriers can be utilized to automatically process outgoing calls
- Compatible with both Loop Start and Ground Start lines
- Compatible with DTMF and Rotary Dial Central Offices
- RS-232 Serial Data Port for administrative and maintenance purposes
- Monitors activity on all lines to provide Call Detail Records (if required)
- Non-Volatile Memory
- Optional Progress Tones
- Automatic disconnect on invalid codes
- Time of day restriction
- Optional use of Other Common Carriers (OCCs) for Callback

### CONTROLLER DESCRIPTION

**2.02** The SMarT-1™ Security Access Controller (SAC) is a powerful and compact system that provides advanced callback security to most existing Modems without replacement of equipment. Through the use of password protection, the SAC provides the ability to secure




Figure 2-1, SMarT-1™ Security Access Controller

a data system and to allow access only to authorized personnel.

**2.03** The Controller (see Figure 2-1) prevents unauthorized access to a data base that is typically gained through "hackers" utilizing dial-up telephone circuits and randomly searching for authorization codes. The SAC security features include the disconnection of invalid access attempts and callback technology to protect the integrity of a network.

**2.04** The Controller is typically installed on the telephone line between the telephone company interface jack and the Modem of the user's system. This installation enables the SAC to prevent connection to the called Modem until it has a chance to verify the validity of the caller.

#### **Network Compatibility**

**2.05** Telephone Trunks or Lines available to the user from the Central Office can be one of two types. These types are either Ground Start or Loop Start. The Controller can be programmed to function with either type.

**2.06** The available dialing types are typically DTMF or Rotary Dial. DTMF uses tones to dial while the Rotary system uses pulses. The Controller can be programmed to function with either type on dial out. However, DTMF dialing is required for incoming calls.

#### **System Power**

**2.07** Power is supplied from a small transformer that is provided with the system. In the event of a commercial power outage, the SMarT-1™ Security Access Controller will assume a "power down cut-through mode". In this state, the Controller appears to the network as a metallic path from its tip and ring inputs to its tip and ring outputs. In essence, the Controller in this mode will appear to not be present and allows all calls to pass.

**2.08** Battery back up prevents memory loss in the event of a power failure. This feature, inherent in the Controller, allows the customer's stored data to be retained. There is no requirement for re-programming the Controller once power is restored.

#### **Lines/Models**

**2.09** There are up to four independent lines in the Controller depending on the model used (4-, 2-, or 1-line units). These lines all share the same search tables. Results of searching through a table will select a route (in actuality, a 'routing method'). The routing data (the four alternatives) is shared among the lines, thus providing powerful systems that gain simplified access to either a Modem or the common carrier network.

### **Area Code/Office Code/Call Searching**

**2.10** The SMarT-1™ SAC can be programmed to 'look up' the Area Code (NPA) and Office Code (NXX) numbers and perform routing decisions (i.e., route through OCC/Reseller Switch, or route through DDD) depending on the OCC/Reseller's capabilities and the customer's requests.

### **Adaptive Call Routing**

**2.11** All calls are made over predetermined routes, with the required authorization codes being inserted automatically by the Controller at the appropriate time. The Adaptive Call Routing (ACR) feature allows the Controller to automatically detect, remember and re-route all numbers not available on the OCC over to the DDD Network.

### **Least Cost Routing**

**2.12** Least Cost Routing allows the alternate routing of long distance calls through various OCC facilities. Since toll calls placed through OCC networks are typically less expensive than DDD routes, choosing the most economical medium (i.e., DDD or whatever OCC) will enable the user to capitalize on OCC network rate benefits.

### **Call Recording/RS-232 Port**

**2.13** Call recording output is accomplished via the RS-232 (computer) port with a programmable Baud rate. This output provides a complete record of numbers dialed and the on-hook/off-hook times for all calls on the lines served by the system. This information can be utilized by the user for traffic studies, usage analysis, call costing, etc..

## **VERSATILE PROGRAMMING**

### **Description**

**2.14** The SMarT-1™ Security Access Controller (SAC), as delivered from the factory, will require some programming before actual use. In addition, the Controller may not have been initialized and may not have sufficient charge on the internal NI-CAD battery backup to ensure memory retention. This lack of charge may be due to storage and transit times from the factory to the user.

**2.15** To ensure that the unit is ready for operation, it should first be powered up for a period of time, then initialized followed by any additional programming that may be required. The paragraphs that follow briefly describe this initialization procedure. For the complete and detailed initialization description, refer to Part 6, page 29.

### **Initialization**

**2.16** The SAC is initialized via the RS-232 port by use of a suitable



terminal. Upon power on, the SAC monitors the RS-232 port for 7 seconds. During this time period, the unit expects to receive an initialize command at a rate of 1200 Baud. This command consists of the two characters 'AA' and must be entered from the keyboard (in upper case only).

**2.17** If, after 7 seconds, the initialize command is not received, the SAC will check its internal memory for the programmed Baud rate (1200 Baud by default) and switch to that Baud rate.

**2.18** Initialization of the SAC will load a database for automatic callback operation. The SAC will have the following communications requirements:

- 1) 1200 Baud Rate
- 2) No Parity
- 3) 8 bit Characters with one Stop Bit
- 4) Bit 8 Sense = SPACE
- 5) Full Duplex Communications at the RS-232 Port.

**Note:** Refer to Part 4, page 16 for a complete description of the RS-232 Port connection and communications requirements.

### **Programming**

**2.19** The Controller will require some programming after initialization. The unit will not require re-initialization except under fault conditions. For a complete description of programming, refer to Part 7, page 33. If the 'default' programming is desired, it may be selected by entering a 'load default' command after initialization. This command is '942903'. The command will restore all defaults as listed in Part 7. For specific programming, refer to Part 7, page 42.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**3. SPECIFICATIONS****HARDWARE**

**3.01** Table 3-1 lists all of the hardware specifications for the SMaRT-1<sup>™</sup> Security Access Controller (SAC). These specifications apply to all models of the Controller (4-, 2-, and 1-line units) unless otherwise noted.

**Table 3-1, SMaRT-1<sup>™</sup> Hardware Specifications**

<b>SPECIFICATION</b>	<b>MIN.</b>	<b>TYP.</b>	<b>MAX.</b>	<b>UNITS</b>
<b>FCC RINGER EQUIVALENCE</b>			0.7B	
<b>IDLE LINE, LOOP START</b>				
RINGER IMPEDANCE: 15-60 Hz, 70-110V	10		20	K $\Omega$
20-3500 Hz, 10V	1			M $\Omega$
RINGING SENSITIVITY: 15-60 Hz	40			Volts
LEAKAGE: Tip to Ring, 100V	20			M $\Omega$
Tip to Earth, 100V	20			M $\Omega$
OFF HOOK CURRENT	15		80	mA
<b>IDLE LINE, GROUND START</b>				
SENSING RESISTANCE: Tip to Earth	36	40	45	K $\Omega$
OPEN CIRCUIT VOLTAGE: Tip	-22	-25	-28	Volts
GROUNDING VOLTAGE	-5	0	+10	Volts
TIME TO RECOGNIZE TIP-GROUND	10		150	ms
RESISTANCE: Sending Ring-Ground		n/a		
<b>BATTERY FEED</b>				
OPEN CIRCUIT VOLTAGE	22	24	26	Volts
FEED RESISTANCE	550	600	650	$\Omega$
BALANCE: DC	36	40		dB
SHORT CIRCUIT CURRENT			50	mA
<b>TERMINATION</b>				
RESISTANCE: DC, 20 mA	200		300	$\Omega$
DC, 40 mA	200		300	$\Omega$
AC, 300-3000 Hz	550	600	650	$\Omega$
RETURN LOSS: 600 ohms, 20mA	20	26		dB
CURRENT	13		80	mA

Table 3-1 (Cont'd), SMarT-1<sup>tm</sup> Hardware Specifications

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>DIAL TONE</b>				
CO SIDE FEED: Gain 300 Hz	-2	0	+2	dB
INTERNAL FEED: 350 Hz		n/a		
<b>DTMF RECEIVER</b>				
LEVEL	-20		+3	dBm†
LEVEL DIFFERENCE	-6		+6	dB
FREQ: To receive	-1.5		+1.5	%
To not receive	-3.5		+3.5	%
DURATION	40			ms
TIME BETWEEN TONES	30			ms
<b>ROTARY RECEIVER</b>				
MAKE IMPEDANCE			700	$\Omega$
MAKE DURATION	20		100	ms
BREAK IMPEDANCE	8			K $\Omega$
BREAK DURATION	20		100	ms
RATE	7		20	pps
<b>DTMF SENDER</b>				
LEVEL	-8	-6	-3	dBm†
FREQUENCY	-1.3		+1.3	%
DURATION (Programmable)	40	60	130	ms
<b>ROTARY SENDER</b>				
TIMING (Programmable)	40/30	60/40	60/40	ms/ms
TIMING (At 60/40):				
Make	35		45	ms
Break	55		65	ms
RATE (At 60/40)	9.9	10	10.1	pps
INTERDIGIT PAUSE (Programmable)	400	800	1300	ms
<b>OPERATING RANGE</b>				
TEMPERATURE	0		55	$^{\circ}\text{C}$
HUMIDITY	0		85	%
ALLOWABLE VOLTAGE: connected to any point			300	Volts

† With reference to 600 $\Omega$  Termination.

**RS-232 PORT**

**3.02** Table 3-2 below contains the specifications for the SMarT-1™ Security Access Controller RS-232 Auxiliary Port. This port may be used for programming or for SMDR Output.

**Table 3-2, RS-232 Port Specifications**

PARAMETER	SPECIFICATION
BAUD RATE:	300 to 9600 Baud programmable; default = 1200 Baud
PARITY:	None
BITS PER CHARACTER:	Eight bits per character with one stop bit.
BIT EIGHT SENSE:	Space
MODE:	On line.
OPERATION:	Full duplex mode.

**ELECTRICAL/MECHANICAL**

**3.03** Table 3-3 contains the Electrical and Mechanical specifications for the SMarT-1™ Security Access Controller. These specifications apply to all models of the Controller (4-, 2-, and 1-line units) unless otherwise noted.

**3.04** This section does not contain all of the specifications for the Controller at present. Other specifications will be added as they are received.

**Table 3-3, Electrical/Mechanical Specifications**

PARAMETER	SPECIFICATION
DIMENSIONS:	7.625" (19.37cm) Wide X 10.625" (26.99cm) H X 1.375" (3.49cm) D
WEIGHT: Dialer	2 lbs (0.907 kg)
Power Supply	1 lb (0.453 kg) (Approximately)
MOUNTING:	Wall Mount with Supplied Bracket
POWER:	115 Volts AC, 60 Hz @ 300 mA
Range:	103.5 to 126.5 VAC
CONNECTIONS:	Standard RJ31X/CA31A Network Connections

**3.05** The specifications in the Tables above are subject to change without notice. The inclusion of 'n/a' for a specific parameter means that the specification is not available at the time of this publication. It will be added at a later date.

## 4. UNPACKING, INSTALLATION AND ORDERING INFORMATION

### SHIPPING AND RECEIVING

**4.01** The SMarT-1<sup>™</sup> Security Access Controller is shipped in a single carton that contains the Controller, the Power Supply, a Wall Mounting Bracket, four RJ31X/CA31A Cables and appropriate documentation. All of these items are protected within the carton by styro-foam inserts.

**Note:** Some production units do not require the wall mounting brackets since these units are mounted to a wall by use of keyslots included on the unit case.

**4.02** In some instances where more than one unit is shipped, a larger carton may be used that would contain five of the smaller cartons. Each of the smaller cartons would contain the items listed in 4.01 above.

### Unpacking

**4.03** The procedure below lists steps to take when unpacking the equipment (refer to Figures 4-1 and 4-2):

- 1) Open carton and remove contents.
- 2) Check each item removed for damage.
- 3) Check each item against the packing list.
- 4) Notify the vendor if any items are missing or appear to be damaged or defective.

### Repacking

**4.04** If an item is found to be defective or damaged and is to be returned to the vendor, it should be tagged and packaged to prevent damage. If units are to be shipped from one location to another, these units should also be packaged in such a manner as to prevent damage. Figure 4-1 shows how the equipment was originally packed. This method of packaging should be followed as closely as possible.

**4.05** If the original packaging material is no longer available, the returned parts should be wrapped in several layers of air-cushion type of wrap, placed in a suitable container, and surrounded with paper to minimize the movement of the items.

### INSTALLATION REQUIREMENTS

**4.06** The SMarT-1<sup>™</sup> SAC is position independent. It may be mounted anywhere that will accommodate the unit size as listed in the specifications in Table 3-3 on Page 11.




Figure 4-1, Equipment Unpacking and Repacking






Figure 4-2, Multi-Unit Packing and Repacking

- 4.07 The SAC will operate within a 0–55°C temperature and a 0–85% humidity range.

#### POWER REQUIREMENTS

- 4.08 The customer must provide a single phase power receptacle with the following recommendations:
- 115V, 60Hz fused and capable of delivering 350mA per unit installed.
  - The power receptacle should be wired and fused independently from all other receptacles that are not controller related.
  - A warning tag should be attached to circuit breaker type fuses to prevent unauthorized manual operation.
  - The power receptacle should not be controlled by a switch.
  - The live and neutral conductors at the receptacle should be wired to their proper respective connections.
  - The power receptacle must be a 3-wire type, with the ground wire connected to the ground of the electrical system.
  - The receptacle should be easily accessible for the removal of the plug for maintenance.
  - The receptacle location should be selected to prevent accidental removal of the power cord.
  - The power cord between the receptacle and the unit should not present a hazard to the user.

#### MOUNTING

- 4.09 If the unit requires the wall mounting bracket, simply mount the bracket to a surface with screws. Mount the Controller housing to the bracket by matching the four holes on the rear of the case with the mounting pins of the bracket. Press firmly into place.
- 4.10 If the unit is the keyslot type, mount by using the provided template to find screw locations. Insert #6 X  $\frac{3}{4}$  wood or self-tapping screws in these locations, leaving approximately 1/8 inch gap between the surface and the cap-head. Mount the Controller by positioning the keyslots over the screw heads, pressing toward and then down from the mounting surface.

#### CONNECTIONS

**Note:** The Security Access Controller should be initialized prior to accomplishing any connections. Refer to Part 6, paragraph 6.06 for the initialization procedure.

- 4.11 Connections to the Controller are made at the Connector Panel located along the bottom edge of the housing. Figure 4-3 illustrates the connection panel. The steps below outline the connection




Figure 4-3, Controller I/O Connections




Figure 4-4, Typical Controller Installation Configuration




Figure 4-5, Typical Connection Configuration




Figure 4-6, RS-232 Interface Connector (Viewed from outside Dialer)




Figure 4-7, USOC RJ31X/CA31A Jack and Cable Assy.

procedure:

- 1) Refer to Figure 4-3. Connect a suitable Earth Ground to the screw mount [A] provided on the connector panel. This connection **MUST** be made for the unit to function properly.
- 2) Plug the Power Pack jack into the Controller power connection [B].
- 3) Plug the Power Pack AC line cord into a suitable (110V-60Hz) AC receptacle.
- 4) Using the supplied RJ31X/CA31A cables, insert one end of a cable in a jack on the Controller [C].
- 5) Connect the other end of the cable used in step 4 to the Telco-supplied jack.
- 6) Repeat steps 4 and 5 above for the appropriate number of times depending upon the model of Controller being installed (4-, 2-, or 1-line units).
- 7) Connect a suitable terminal to the RS-232 Computer Port [D] via a suitable cable. Configuration of this cable is described in paragraph 4.13 below.

**4.12** This completes the mechanical installation of the SMaRT-1™ Security Access Controller. Continue by programming the unit from the terminal.

#### **RS-232 Port Configuration**

**4.13** The RS-232 Computer Port connector (refer to Figure 4-6) is a female connector configured as "DCE". Only the TxD (pin 3), the RxD (pin 2), and the GND (pin 1) lines are used by the Controller. Pins 4 through 6, 8, and 20 are shorted internally for the convenience of the user. This port is used for programming and call recording output.

**4.14** During programming, a suitable terminal must be connected to this port. For call recording output, a suitable printer is connected in place of the terminal. Refer to Part 6 paragraph 6.05 for the configuration of the terminal or the printer.

#### **RJ31X/CA31A USOC Jack and Cable**

**4.15** Figure 4-7 illustrates the USOC RJ31X/CA31A Connector and cable assembly as used by the SAC. Figure 4-5 illustrates the installation wiring of the Telco-supplied RJ31X/CA31A USOC jack and other connections from the Central Office through to the Modem or other protected equipment. For the unit to operate properly, the bridge clips at the "split" type station block must be removed.

**ORDERING INFORMATION**

**4.15** Table 4-1 on the following page lists the part numbers and descriptions of items that can be ordered from MITEL DATA-COM INC.

**Table 4-1, SMarT-1™ Ordering Information 4-1, SMarT-1 Ordering Information**

<b>PART NO.</b>	<b>DESCRIPTION</b>
8350-007	SMarT-1™: 4 Line Security Access Controller. Includes Power Pack, RJ31 Cables, and Mounting Hardware.
8350-008	SMarT-1™: 2 Line Security Access Controller. Includes Power Pack, RJ31 Cables, and Mounting Hardware.
8350-009	SMarT-1™: 1 Line Security Access Controller. Includes Power Pack, RJ31 Cables, and Mounting Hardware.
<b>SPARES</b>	
8350-010	Wall Mount Bracket for SMarT-1™ Security Access Controllers.
8350-012	Power Pack for SMarT-1™ Security Access Controllers.
8350-013	RJ31X/CA31A Cable for SMarT-1™ Security Access Controllers.
8350-048-100-NA	General Information Manual.
8350-953-003-NA	SAC Maintenance Programming Guide.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---



## 5. OPERATING DESCRIPTION

### SECURITY

**5.01** The primary function of the SMarT-1<sup>™</sup> Security Access Controller (SAC) is to provide security to connected systems such as Modems and to protect these systems from unauthorized telephone access. The security provided by the SAC lies in three distinct areas. These areas are:

- The use of optional progress tones, or lack thereof, to make it difficult for an unauthorized caller to recognize that there is protected equipment connected to the telephone line.
- The inclusion of the callback feature to assure that only those individuals with valid passwords are called back at an assigned number associated with that particular password.
- Finally, the provision of a call detail record that is available at the RS-232 Computer Port to record the time and duration of the call, along with the number that was called back.

**5.02** While it is not recommended, the SAC may also be programmed to allow instant access (circumvention of the call back feature) upon the receipt of a particular password.

**5.03** Passwords must be Dual-Tone Multifrequency (DTMF) digit strings that range from 1 to 15 digits in length. Only a DTMF type of telephone can be used to access the SAC. Rotary dial telephones cannot be used since rotary digits can only be received by, but not transmitted through, a Central Office.

### OPERATIONAL SEQUENCES

**5.04** The steps listed below show the operational sequences of the Controller:

**Note:** A single progress tone as used in the steps below indicates that the user will hear a single 'beep' in the receiver earpiece of the telephone. In a like manner, a double progress tone means two 'beeps' and a triple progress tone means three 'beeps'.

- 1) The user dials the directory telephone number of the protected device with a DTMF type telephone.
- 2) The SAC detects the incoming call, disconnects the protected equipment from the line, and answers the call. The SAC may then optionally provide the user with a single progress tone.
- 3) The user enters his/her password by keying the correct digits on the telephone. This password may be from 1 to 15 digits in length and consists of any of the 12 standard DTMF digits.
- 4) If an exact match for the password cannot be found in the SAC

internal memory, the Controller drops the line (hangs up) and may optionally "busy out" that particular line for a programmable length of time. The unsuccessful password will be printed in the Call Detail Record.

- 5) If an exact match for the password is found in the SAC internal memory, the Controller will check for the type of access that the password permits, including the time-of-day period assigned for that particular access.
- 6) Upon verification of a valid password during the particular time-of-day period, the SAC will then execute its programmed action for that particular password. One of three series of events will occur:

Automatic Callback Access:

- a) The password action is deemed to be an automatic callback. For this instance, the SAC will hang up the telephone line, re seize the line and dial back to the user by using a preprogrammed call back number associated with this particular password. The user must know that he has to hang up, or may optionally be requested to hang up by receipt of a triple progress tone from the Controller. This method of access is considered to be the most secure making it nearly impossible for someone to gain unauthorized access to the protected equipment.

User Entered Callback Access:

- b) The password action is deemed to be a user controlled callback type. This means that the user must manually tell the controller the telephone number to be used for the callback. The user either must know when to enter his telephone number and hang up, or may optionally be requested to input his telephone number by receipt of a double progress tone, and to hang up on receipt of a triple progress tone. As before, the SAC will then hang up and re seize the line. It will dial out using the user entered telephone number. This action is less secure than the previous action since the user provides the telephone number. However, the call detail record will contain the telephone number that the user has entered and was called back at.

Cut-Through Access:

- c) The password action is deemed to be a 'cut-through' type of access. In this case, there will be no progress tones received or any other SAC activity. At the expiration of the 'wait for password' time period, the SAC will connect the caller to the protected device. This action is the least secure of the three actions. While the password must be entered exactly and the access attempt made

during the allowed time-of-day, there will be no record of the call with the exception of the time and duration of the access and the optional printing of the successful password.

## DETAILED OPERATING DESCRIPTION

### With Modems

**5.05** The following assumptions are taken into consideration when describing the detailed operating procedures that will follow in paragraph 5.06:

- 1) There are correctly installed and known functional Modem connections for the Central Processing Unit (CPU) and the remote access. Any installation should first be capable of functioning without the SAC device present to cut down on non-SAC related operational questions.
- 2) If installation problems are encountered at any time, the SAC device should be removed to prove that connections are possible without the device. Otherwise, considerable effort could be expended when the problem is in other areas of the system.
- 3) Persons accessing the system (users) have been previously advised of any necessary sequence of events required in order to establish a valid Modem connection. In some instances, specialized sequences will be required.

### Automatic Callback Access

**5.06** The following steps outline the operations of the Security Access Controller that occur when using automatic callback access:

- 1) The caller dials the host system over the telephone lines.
- 2) The protected Modem senses ringing and seizes the line. With proper programming, the SAC then splits the line while the protected Modem is waiting for the line to settle (about 2 seconds). The Modem (at the end of the line settling period) places an answer tone on its output to the SAC. The SAC emits a single progress tone to the caller. No Modem tones are supplied to the caller.
- 3) The caller, after hearing the progress tone (unless disabled), must enter the assigned password via DTMF dialing. Two conditions must be satisfied at this point. The first is that the protected Modem must be capable of answering in the answer mode for a programmable period of time that is sufficient to allow the callback to occur. The second is that the called back Modem must be capable of being forced into the originate mode upon receipt of the callback.

**Note:** A more efficient variation of the above description would be that the protected Modem answer the incoming call in the

originate mode (waiting for answer tone) for a period of time long enough to allow the callback to occur, as previously mentioned. In this case, the callback could be automatically answered by the Modem that is accessing the host system. These events depend upon the sophistication of the Modems and the ingenuity of the user.

- 4) After a programmable period of time, the SAC will drop the line. The SAC will re seize the line if the password is valid, and will dial back the caller via the use of speed dialing.
- 5) If the protected Modem is waiting for an originate tone (via programming), the calling Modem may simply answer the call automatically, thus establishing the connection. The SAC will cut-through upon the completion of it's call back and connect the two Modems.
- 6) If the called Modem is waiting in the answer mode (most common used mode), the caller must place his Modem into the originate mode upon receipt of the callback.
- 7) Once connection is established, the SAC 'goes to sleep' and appears as a direct through connection to the two Modems. Call disconnection is accomplished as per normal operation, or at a loss of carrier detect at either Modem.

**Note:** In the 2- and 4-line models, the SAC is continually monitoring the other unused lines while the above procedure is taking place.

#### User-Entered Callback Access

**5.07** The following steps outline the operations of the Security Access Controller that occur when using user entered callback access:

- 1) The caller dials the host system over the telephone lines.
- 2) The protected Modem senses ringing and seizes the line. With proper programming, the SAC then splits the line while the protected Modem is waiting for the line to settle (about 2 seconds). The Modem (at the end of the line settling period) places an answer tone on its output to the SAC. The SAC emits a single progress tone to the caller. No Modem tones are supplied to the caller. Two conditions must be satisfied at this point. The first is that the protected Modem must be capable of answering in the answer mode for a programmable period of time that is sufficient to allow the callback to occur. The second is that the called back Modem must be capable of being forced into the originate mode upon receipt of the callback.
- 3) The caller, after hearing the progress tone (unless disabled), must enter the assigned password via DTMF dialing. Upon validation of the password, the SAC will emit a double progress tone to the caller.
- 4) The caller, after hearing the double progress tone (unless dis-

abled), must enter the telephone number for callback by DTMF dialing. Two conditions must be satisfied at this point. The first is that the protected Modem must be capable of answering in the answer mode for a programmable period of time that is sufficient to allow the callback to occur. The second is that the called back Modem must be capable of being forced into the originate mode upon receipt of the callback.

**Note:** A more efficient variation of the above description would be that the protected Modem answer the incoming call in the originate mode (waiting for answer tone) for a period of time long enough to allow the callback to occur, as previously mentioned. In this case, the callback could be automatically answered by the Modem that is accessing the host system. These events depend upon the sophistication of the Modems and the ingenuity of the user.

- 5) After a programmable period of time, the SAC will drop the line. The SAC will re seize the line if the password is valid, and will dial back the caller using the number just accessed.
- 6) If the protected Modem is waiting for an originate tone (via programming), the calling Modem may simply answer the call automatically, thus establishing the connection. The SAC will cut-through upon the completion of it's call back and connect the two Modems.
- 7) If the called Modem is waiting in the answer mode (most common used mode), the caller must place his Modem into the originate mode upon receipt of the callback.
- 8) Once connection is established, the SAC 'goes to sleep' and appears as a direct through connection to the two Modems. Call disconnection is accomplished as per normal operation, or at a loss of carrier detect at either Modem.

**Note:** In the 2- and 4-line models, the SAC is continually monitoring the other unused lines while the above procedure is taking place.

#### Cut Through Access

**5.08** The following steps outline the operations of the Security Access Controller that occur when using access via Cut Through Access:

- 1) The caller dials the host system via the telephone line.
- 2) The protected Modem senses ringing and seizes the line.
- 3) With proper programming, the SAC splits the line while the protected Modem is waiting for the line to settle (approximately 2 seconds). After line settling, the protected Modem places an answer tone at its output. No Modem tones are supplied to the caller.
- 4) The answering Modem must remain on the line while the caller,

after hearing the single progress tone (unless disabled) enters his assigned password via DTMF dialing.

- 5) Upon verification of the password, the SAC will cut-through (connect the caller to the protected Modem). The calling Modem will respond with an originate tone that establishes the connection. Except for the slight pause required to enter the caller's password, this is a standard access and requires no special considerations. The only constraint is that a valid password must be entered within a predetermined length of time. Failure to enter the password within this time frame (determined by the answering Modem and/or SAC constraints programmed as desired) would result in the line being dropped and the access failing.
- 6) Once the connection is established, the SAC device 'goes to sleep' and appears as a direct connection between the two Modems. Modem disconnection is established as per normal routines or at a loss of carrier detect at either Modem.

#### **Other Operational Procedures**

**5.08** Other operational procedures or applications depend on the type of equipment being protected and the related operating conditions. In all applications, the three basic modes of access in descending order of security are:

- Automatic Callback on Valid Password
- Callback to User Entered Number on Valid Password
- Connection upon Receipt of Valid Password.

## 6. INITIALIZATION

### INTRODUCTION

**6.01** Initialization is the procedure that readies the SMarT-1™ Security Access Controller for initial programming. This procedure has been detailed previously in Part 2 of this document. Since it is a very important procedure, it will be listed again in this part in detail.

**6.02** There are several reasons for accomplishing initialization of the SAC. These are a) that the Controller has just been removed from storage or has just been received, or b) the program access codes have been deleted accidentally or the access codes have been changed and forgotten, or c) the Controller has just been repaired, or d) the Controller has been stored for a long period of time, or e) the Controller has had a loss of data retention.

**Note:** If the reason for initialization is e) above, it is recommended that the reason for loss of data retention be found and corrected.

**6.03** Once initialized, the Controller should seldom require re-initialization. After initialization, the Controller may be programmed by use of a suitable terminal. A default data base may be loaded by issuing a command via this terminal.

**6.04** Prior to initialization, ensure that the Controller has been powered on for a sufficient period of time to allow the internal NI-CAD battery to be charged. This period should be approximately 24 hours long. The battery protects the memory against loss of data during power outages and will sustain the memory for several days, once charged.

**6.05** Initialization is accomplished by use of a suitable terminal connected to the RS-232 Computer Port. A suitable terminal is defined as one that meets the following criteria:

- 1) Capable of transmitting and receiving at 1200 Baud.
- 2) No parity
- 3) 8 bit characters with one stop bit
- 4) Bit 8 sense = SPACE
- 5) Full Duplex communications
- 6) Connection to the RS-232 Computer Port with a suitable cable configured as "DCE" with the following pin connections:
  - a) Pins 1 and 7 = GROUND
  - b) Pin 2 = RxD (Signal in)
  - c) Pin 3 = TxD (Signal out)
  - d) Pins 4 and 5 = Tied together
  - e) Pins 6, 8, and 20 = Tied together.

**Note:** The Security Access Controller does not respond to DTR, RTS, etc..

**PROCEDURE**

**6.06** The steps below show the procedure to be followed to initialize the Controller:

- 1) Power the SAC off.
- 2) Connect a suitable terminal to the RS-232 Computer Port.
- 3) Power the terminal on and set for the required parameters (if required).
- 4) Power the SAC on. Once on, the Controller will monitor the RS-232 Computer Port for a period of 7 seconds.
- 5) During this 7 second period, enter the characters 'AA' from the terminal keyboard (in upper case only). Within another 7 second period, the SAC should respond with:

**REV xx-xx ENTERING PROG. MODE**

where 'xx-xx' is the revision of the software resident in the controller. Once this message has appeared, the SAC is in the programming mode.

**Note:** The SAC should not be powered down while it is in the programming mode as it will cause the unit to print checksum errors on the next power up sequence.

**6.07** If, after 7 seconds, the initialize command is not received, the SAC will check its internal memory for the programmed Baud rate (1200 Baud by default) and switch the RS-232 Computer Port to that rate.

**6.08** Initialization of the SAC will load a complete database for automatic callback operation with the following communications parameters:

- 1) 1200 Baud Rate
- 2) No Parity
- 3) 8 bit Characters with one Stop Bit
- 4) Bit 8 Sense = SPACE
- 5) Full Duplex Communications

**6.09** Once initialized, programming may be immediately started via the terminal. The user may elect to exit the programming mode by entering '999' on the terminal keyboard. If '999' is entered, the SAC will respond on the terminal display with:

**QUITTING PROG. MODE..**



**Note:** Pressing <CR> on the keyboard will not allow programming if the default Terminal Program Access Code (<CR>) has been changed. Refer to Part 7, Programming for more details.

**6.10** If nothing is entered on the terminal keyboard for a period of 1 minute, the SAC will automatically print on the terminal display:

**WARNING . . . LOGOUT IN 60S.**

and 1 minute later, the SAC will automatically exit the programming mode.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## 7. PROGRAMMING

### INTRODUCTION

**7.01** Prior to using the SMarT-1™ Security Access Controller, some basic programming must be entered into the unit. This basic programming provides the Controller with the date, time, passwords, and other fundamental information that is pertinent to the operation of the unit. The parameters to be programmed depend on the type of operation that is expected of the Controller.

**Note:** Before programming the unit, ensure that it has been initialized and powered on long enough to charge the internal battery. For more information on initializing, refer to Part 6, page 29.

**7.02** Initializing the SMarT-1™ Security Access Controller will provide the unit with part of the basic programming that is pertinent to the operation. This initialization procedure will cause the unit to be programmed as listed in Table 7-1 below. The table also lists the associated parameter label that applies to the default data.

**Table 7-1, Initialization/Default Programming Parameters**

DEFAULT DESCRIPTION	ASSOCIATED PARAMETER LABEL
<b>INTERNAL CLOCK</b> = No time or date entered	980
<b>PASSWORD DATA</b> = No passwords present	821 thru 835
<b>ACCESS CONTROL SEQUENCE</b> = Callbacks are dialed to the DDD Network	6r5
<b>CALLBACK NUMBER DATA</b> = No callback numbers present	7nnn
<b>TYPE OF CENTRAL OFFICE</b> = Loop Start DTMF Digit output	x00t x00t
<b>PRINTER BAUD RATE</b> = 1200 Baud RS-232 Communications <b>Fixed:</b> No parity 8-bit words Bit 8 Sense = SPACE Full duplex On line	006t
<b>PRINT FORMAT</b> = Call Detail Record in SMART Format	009t
<b>AUTO ANSWER TIMER</b> = Automatically answer incoming calls in 3 seconds	x27t
<b>WAIT FOR PASSWORD TIMER</b> = Wait 8 seconds for password entry	x28t

(Continued)

Table 7-1 (Cont'd), Initialization/Default Programming Parameters

DEFAULT DESCRIPTION	ASSOCIATED PARAMETER LABEL
<b>AUTO ANSWER LOCKOUT TIMER</b> = "Busy Out" line for 20 seconds on invalid password	x29t
<b>TOE OPTIONS</b> = Single tone to request password "ON"	x35t
Double tone to request callback number "ON"	x35t
Triple tone to request caller hang up "ON"	x35t
<b>DIALBACK TIMER</b> = Wait for 5 seconds before initiating callback	x36t
<b>MACHINE IDENTIFIER</b> = "SAC"	602
<b>TERMINAL PROGRAM SECURITY CODE</b> = "<CR>"	604
<b>NAME OF ROUTE</b> = "DDD"	6r0

No "Other Common Carrier" programming is in default.

**Note:** The letter 'x' or 'r' in the parameter label represents a single user selectable character for entry to select a specific part of the parameter. The letter 't' represents a digit that selects a specific operation of the parameter.

**7.03** While the default parameters listed in the Table 7-1 above is not a complete listing of all of the parameters that are resident in the Controller, they are the ones that are the most pertinent to unit operation. The remaining parameters (not listed in the table) are set to defaults that will work in nearly all applications. These other parameters are programmable for those times when "standard" conditions of the telephone lines or dialing patterns are not present.

**PROGRAMMING FOR CALLBACK OPERATION**

**7.04** Programming is accomplished from a terminal attached to the RS-232 Computer Port of the Controller. Programming consists of entering a parameter identifier consisting of three or more digits, followed by a data string and an entry terminator (if required). For example, if the unit were in the programming mode and it is desired to program the time and date, the parameter '980' would be entered. This parameter would be followed by the month, day, hour, and minutes entered as a digit string. The string would be composed of four, two digit groups for the date and time. This string does not require a terminator and the Controller would automatically accept and enter the terminal data.

TERMINAL	USER		
	PARAMETER	DATA	TERMINATOR
>	[980]	[mmddhhmm]	(none)

---

NOTES ON DATA ENTRY

Whenever the Controller knows the length of a parameter entry, the entry will automatically be accepted by the SAC without the need of following the entry with a terminator. For string type entries of unknown length (to the SAC), a terminator of 'BB' or 'FF' must be entered to identify the end of the entry. Technically, 'BB', 'FF', and '.' are all internally interpreted as the same digit (see Table C-2, page C-5). The last character of an ASCII string may not be 'B'. However, a single 'B' within a string is allowed. If the last character of an ASCII string must be 'B', then it must be followed with a nonprinting character such as a <SPACE> (hexadecimal 20). If necessary, the <LF>, <FF>, <CR>, <BEL> and so on may also be used within an ASCII string.

The greater than sign (>) on the terminal display indicates that the SAC is ready to receive a parameter number followed by data. This character is called the 'prompt' character.

If an error is made and noticed during data entry, simply press the carriage return (<CR>) key until the > prompt returns to the screen. In this case, the input string will be ignored.

NOTES ON ORDER OF PASSWORD PROGRAMMING

In general, passwords with automatic callback actions either should be programmed into the unit first, or a specific block of numbers with the last three digits being used to address passwords should be set up. The same password may not be used with different action digits.

- 7.05** Prior to accomplishing the programming for callback operation, the following conditions are assumed to exist:
- 1) The terminal access code will still be '<CR>'.
  - 2) The Central Office is capable of DTMF dialing input.
  - 3) The Central Office is a Loop Start type of office (the most common in Modem applications).
  - 4) 1200 Baud communications will suffice.
  - 5) The protected Modem remains **ON LINE** for 45 seconds after ringing detection.
  - 6) Callback is to take place on the standard DDD Network.

**Procedural Steps**

- 7.06** To program the SMarT-1<sup>™</sup> Security Access Controller for Callback Operation, accomplish the steps listed below:

**Note:** User entered data will be enclosed in square brackets. For more information on conventions used in this manual, refer to Part 1, paragraph 1.12.

- 1) Ensure that the Controller has been powered up and initialized in accordance with Part 6, paragraph 6.06.
- 2) Press carriage return (<CR>) on the terminal keyboard to start the programming session. The terminal display should respond with:

**REV xx-xx ENTERING PROG. MODE**  
>

- 3) Enter the time and date by pressing:

> [980mmddhhmm]

where 980 = the time/date parameter, mm = the two digit month, dd = the two digit day, hh = the two digit hour, and mm = the two digit minutes. Note that single digit entries for mm, dd, hh, mm should be prefixed with a '0' to make them double digit entries.

- 4) Enter the machine identifier as 'Tom' by pressing:

> [602546F6DBB]

where 602 = the machine identifier parameter, 54 = ASCII 'T', 6F = ASCII 'o', 6D = ASCII 'm', and 'BB' = the data terminator.

- 4) Enter the password, callback code, and the time-of-day access code by pressing:

> [8251234520BB]

where 825 = the parameter for a five digit password, 12345 = the actual password, 2 = the action digit to be performed (in this case, go to speed call callback location), 0 = the time-of-day code (all day, 24 hour access), and BB = the data terminator.

- 5) Enter the callback number for the above password by pressing:

> [734583931212BB]

where 7 = the register prefix, 345 = the 'bin' number of the callback number and is equal to the last three digits of the password, 8 = the network override and indicates to use the search tables, 393 1212 = the callback number, and BB = the data terminator.

**7.07** The last entry above is the end of this example of programming. The user should now proceed with the example listed to show how to check the entered data as given below:

ENTER	SAC RESPONSE	DESCRIPTION
[902]	<CR> <LF> >	Data confirmation mode entered.
[602]	546F6D	ASCII for 'Tom'.

[825]	1234520	The password and its action digits.
[7345]	83931212	'Use search table' code followed by the telephone number to call back.
[907]	<CR> <LF> >	Returned to programming mode.
[999]	QUITTING PROG. MODE	Programming session ended.

**7.08** Figure 7-1 below shows the typical terminal display for the above actions.

```
>902
>602 546F6D
>825 1234520
>7345 83931212
>907
>999
QUITTING PROG. MODE
```

**Figure 7-1. Terminal Display of Data Entry Check**

**7.09** The Controller is now ready to be placed into service for the purposes of the above example. Assuming that the power has been applied for a sufficient length of time, it is safe to unplug the Controller and to install it on a telephone line between a Modem and the outside telephone wires. No programmed data will be lost. For more information on installation, refer to Part 4, page 13. For a more detailed explanation of programming, refer to page 42 of this Part.

#### **TESTING THE CONTROLLER INSTALLATION**

**7.10** Some of the activity as described in the Theory steps below is caused by additional default data that is resident in the Controller. More complete details of operation are described in later paragraphs. Prior to proceeding with the testing, install the Controller as outlined in paragraphs 7.06 through 7.09 above.

#### **Modem Setup**

**7.11** Ensure that the protected Modem is set up with the following parameters:

- 1) Answer at the end of the first ring (i.e., after 2 seconds of ringing).
- 2) To look for originate tone for 45 seconds (this parameter may require fine tuning).
- 3) To disconnect on loss of carrier.

#### **Theory of the Test**

**7.12** The Modem will answer the line within 2 seconds. In an additional 2 seconds later (after line settling time), the Modem will

begin transmitting an answer tone. In 3 seconds, however, the Controller will electrically separate the Modem from the line and take over the telephone call. Thus, the Modem is split away from the telephone line before it can begin transmitting the answer tone. The Controller supplies the loop current to the Modem during this split mode. This loop current allows the Modem to believe that the telephone call is still present.

**7.13** Upon answering, the Controller transmits a progress tone (one beep, if enabled), indicating that the caller should enter a password. The Controller will remain in the 'waiting for password' state for 8 seconds (programmable). At the end of the 8 second waiting period and the acceptance of DTMF digits, the Controller will stop accepting digits. The Controller will then analyze what it has received, and, if it was a valid password (12345 in our example above), will emit a triple progress tone (three beeps, if enabled) indicating that the password has been accepted. This indicates that the caller should terminate the call and should wait for the callback to his telephone line. The Controller will remain on the line for 5 more seconds (programmable). It will then hang up and initiate its own telephone call as determined by the '7345' coding (3931212 in the example above).

**7.14** As the Controller dials the last digit of the callback number, it reconnects the Modem to the telephone and drops off the line. From this point, and on until the call is terminated, there is no further activity or interference by the Controller.

**7.15** When the Modem drops the line (hangs up), a Call Detail Record will be made available at the RS-232 Computer Port. This record will show the time of the call, the duration of the call, and the password that was entered. The password field may be turned off (disabled from printing the password) by programming if desired. Refer to Paragraph 7.85.

**7.16** On callback to the user (when the user's telephone rings), the user's Modem must be placed in the ON-LINE and ORIGINATE modes. On answering the incoming call from the Controller, an answer tone will be received from the protected Modem. Once the user's Modem senses this answer tone and responds to it with an originate tone, the Modem connection will be established.

**7.17** Termination of the call will occur on the loss of carrier (hang-up). This loss of carrier will cause the protected Modem to drop the telephone line. The Controller will detect the termination of call as a loss of line current. At this time, the Controller will prepare to accept further accesses.

#### **Actual Testing**

**7.18** The steps listed below describe the actual testing of the Controller as installed for Callback Operation:

1. Place a call to the protected Modem without entering a password. The Controller should time out in approximately 11 sec-



onds after ringing. This 11 second period includes 3 seconds after start and 8 seconds of waiting for the password digits. After time out, the Controller will keep the Modem separated from the line and holds the line busy for an additional 20 seconds. The controller should return to the 'waiting for ringing' mode. If this occurs, the call has been successfully denied.

2. Place a call to the protected Modem and enter an INVALID password. Once again, the Controller will keep the Modem separated from the line and holds the line busy for an additional 20 seconds. The controller should time out in 11 seconds and return to the 'waiting for ringing' mode. If this occurs, the call has again been successfully denied.
3. Place a call to the protected Modem. The Modem should answer the call within 2 seconds. The Controller should split the Modem away from the line in 3 seconds and send a progress tone (beep). Enter a valid password. In approximately 15 seconds, the Controller should begin dialing out the digits of the callback number. This last 15 second period includes 8 seconds of waiting for password digits, 5 seconds to allow the caller to hang up, and approximately 2 seconds for the Controller to drop and reseat the line.

Approximately 18 seconds should elapse between the protected Modem ringing and the initiation of the Callback function. Allowing 10 seconds for the acquisition of dialtone, dialing the number, and for ringing to start at the user's telephone, this leaves the user with approximately 17 seconds to answer the call with the user's Modem in the ON-LINE and ORIGINATE modes. This time period occurs since the protected Modem has been programmed to drop the line in 45 seconds.

**7.19** If it is found to be undesirable to allow the caller to hear the protected Modem's answer tone before the line split occurs, it may be necessary to fine tune the Controller and the Modem answer timing until the Controller takes over the control of the line within 2 seconds after the Modem answers the line.

**7.20** In general, the Controller timing can be programmed to adapt to most situations encountered as long as the protected Modem is capable of remaining ON-LINE for a long enough period to allow call completion. Refer to Figure 7-2 for a graphic representation of the Modem and Controller timing.

#### **PROGRAMMING FOR USER-ENTERED CALLBACK NUMBER OPERATION**

**7.21** User entered Callback number means that the caller will, upon entry of a valid password, be requested to enter the telephone number (and the '#' terminator to indicate end of number) that the Controller will use to call back. This method differs from the previously described method in that the SAC does not determine the callback number from the interpretation of the password. The password, in this




Figure 7-2, Typical Callback Operation, SAC and Modem Timing

case, does not address a callback memory location.

**Caution:**

The programmer must take care to avoid assigning a password that has been already assigned and classed as an automatic callback password. The same password cannot be used for both methods of operation.

TERMINAL	USER		
	PARAMETER	DATA	TERMINATOR
>	[<CR>]	(none)	(none)
>	[825]	[7627810]	[BB]

**Note:** The first carriage return in the description above causes the Controller to enter the programming mode. The second line of the description is the entry of the password, callback code, and time-of-day access code. For the purposes of this discussion, the password will be '76278' and the access code of '10' is wait for the caller to enter the password and access is granted 24 hours a day, respectively. Refer to page 60 for a complete description of password entry.

**7.22** This completes the necessary programming for a user entered callback number. The Controller will now wait for 16 seconds after the 8 second wait for password period, to allow the caller to enter the callback number.

**7.23** The caller **MUST** enter the callback number followed by the '#' terminator to indicate end of number, in the same exact manner as if it were being dialed from the protected Modem. This is particularly true if the callback number is a long distance number. Informing the callers of the procedures to use is left up to the Controller manager.

**7.24** There will be a single progress tone heard in the receiver to inform the caller to enter the password. A double progress tone (two beeps) will be heard to request entry of the callback number. Finally, a triple progress tone will be issued to request that the caller hang up. The timing sequence for the events is the same as those in Figure 7-2 except for the addition of a 16 second period to wait while the Controller waits for the caller to enter the callback number.

**7.25** Any or all of the request progress tones may be disabled if desired by programming. Refer to Page 51 for more information on disabling progress tones.

#### Program Verification

**7.26** The steps shown below allow the user to verify that the programming data was entered correctly for User-Entered Callback Number Operation:

ENTER	SAC RESPONSE	DESCRIPTION
[902]	<CR> <LF> >	Data confirmation mode entered.
[825]	12345207627810	This data string is the Password and its Action Digits. Note that the '1234520' is still present as entered in the example under 'Programming for Callback Operation'.

**7.27** The next two lines of data were entered in the preceding example under 'Programming for Callback Operation'. These are checked in the same manner as the lines above. The last two lines illustrate the end of the programming session.

ENTER	SAC RESPONSE	DESCRIPTION
[7345]	83931212	'Use Search Table' code followed by the Telephone Number to call back (from preceding example).
[602]	546F6D	ASCII for 'Tom' (from preceding example).
[907]	<CR> <LF> >	Returned to programming mode.
[999]	QUITTING PROG. MODE	Programming session ended.

**7.28** Figure 7-3 on the next page shows a typical terminal display for the above actions.

```
>902
>825 12345207627810
>7345 83931212
>602 546F6D
>907
>999 QUITTING PROG. MODE
```

**Figure 7-3, Terminal Display, User-Entered Callback Number**

**7.29** If the Controller was left installed while it was being programmed, the programmer may go directly to testing the user-entered callback password. It is not necessary to remove the Controller from service while it is being programmed.

#### **DTMF CUT-THROUGH ACCESS**

**7.30** This is the least secure method of access to the Controller. The method provides no callback number, automatic or otherwise. Depending on the action digits programmed, the time and date of access and password may optionally be printed in the Call Detail Record.

**7.31** Programming simply consists of entering the password along with the proper action digit, along with the time of day access code. Refer to Page 60 for a complete description of passwords and action digits. When the dialed password has been analyzed (approximately 8 seconds after answering the call), the Controller will immediately connect the caller to the protected Modem, if the password is valid.

#### **DETAILED PROGRAMMING DESCRIPTIONS**

**7.32** The following paragraphs outline the parameter descriptions in the order that they appear in later parts. These parameters help to describe the complete Controller capabilities and show its versatility. They are:

1. **SYSTEM PARAMETERS** - System parameters are those that affect the system-wide operation of the Controller. They include:
  - a. **SPECIAL PARAMETERS** - These parameters allow data confirmation, the setting of time and date, and the loading of default data base, etc.
  - b. **OPERATIONAL PARAMETERS** - These parameters affect the Baud rate, the Call Detail Recording format, etc.
2. **TRUNK RELATED PARAMETERS** - These parameters affect individual trunk activity and capabilities such as the type of Central Office, and dialing type.

3. **PASSWORD PROGRAMMING** - This part includes the programming of the password itself. It also describes the accompanying codes that will control whether or not the password is printed in the Call Detail Record, the time of day that the password will be accepted, and the action to perform upon acceptance of the password. Programming is required in this area for either automatic callback operation, user-entered callback numbers, or cut through access.
4. **AUTOMATIC CALLBACK PROGRAMMING (SPEEDCALLS)** - This programs the area where the numbers to be dialed out for an automatic callback triggered by the password are stored. This area includes the programming of a selected 'route', if desired. For other modes of operation, no programming is required in this area.
5. **SEARCH TABLES** - Callback numbers are normally passed through the 'Search Tables' in order to decide which 'route' the callback will be placed on. If the standard DDD route is used for callbacks (no 'Other Common Carrier' used), it will probably not be necessary to program these parameters. The default entries will handle most cases, whether the calls are long distance or local.

This area, if programmed properly, could be used to prevent callbacks to certain geographical areas or to prevent any long distance calls whatsoever, or to determine what types of dial out will be allowed in general (user-entered in particular). Both automatic and user-entered callback numbers may pass through these search tables prior to the controller dialing. An instruction to deny calls to a particular area code at this point would not allow the call to that area code even if it were entered in the Automatic Callback Programming data.

6. **ROUTE RELATED PARAMETERS** - Routes, as defined for the Controller, are dialing sequences, control of dialtone detection, the sequence of digits to be dialed out, and other related details. A route is actually better defined as the instructions that the Controller uses in accomplishing the callback function.

The default programming that is resident in the Controller will place all callbacks on the DDD Route (normal dialing through ATT or whatever standard service is being used). In the event that a customer is using an 'Other Common Carrier (OCC)' such as SPRINT, MCI, etc., these 'routes' may be programmed contain the information for automatic entry of the authorization codes, etc.

### System Parameters

**7.33** Table 7-2 on the next page contains System Special Parameters while Table 7-3 (page 47) contains System Operational Parameters. These parameters include default, if applicable, and a description of the options available when entering the parameters.

Table 7-2, System Special Parameters

ENTER	DESCRIPTION
<p><b>X, x, 999</b></p> <p><b>980mmddhhmm</b></p> <p><b>902</b></p> <p><b>907</b></p> <p><b>942903</b></p> <p><b>942904</b></p>	<p>Exit program mode.</p> <p>Enter Date and Time for Call Detail Record and Time-of-Day Access Control.</p> <p>Enter Data Confirmation Mode. This parameter allows programmed data to be read back for verification.</p> <p>Exit Data Confirmation Mode. Return to program mode.</p> <p>Load Factory Installed Default Database. This command will re-install all default database parameter settings and will delete any other programmed data.</p> <p>Delete All Search Table Entries. <b>CAUTION</b> - This command deletes all callback instructions that are resident in the 801 through 815 and 821 through 835 Search Tables. The Controller cannot operate without data entered in these tables. The only reason for erasing this data is if the user wishes to restart with an entirely new data program and where it is not convenient to delete the old data one piece at a time.</p>
<p><b>601 {Number}BB</b></p> <p><b>602 {ASCII}BB</b></p> <p><b>604 {ASCII}BB</b></p>	<p>Area Code of Other Common Carrier (if used). The default for this entry is '000'. The entry must always be 3 digits, if used.</p> <p>Machine Identifier for Call Detail Recording Output. The default for this entry is 'SAC'. A maximum of three characters will be printed.</p> <p>Terminal Program Security Code. The default for this entry is '&lt;CR&gt;' where &lt;CR&gt; = Carriage Return. A maximum of 15 characters may be used for the entry.</p>

**7.34 X, x, 999** - Exit program mode. These commands may be used to exit from a programming session. Either the 'X' or 'x' command may be used anywhere in string entry to cause the Controller to immediately exit from the programming mode. The '999' command is only used to exit from a programming session when all programming has been completed. The terminal display will reply with the message:

**> [999] QUITTING PROG. MODE**

**Note:** If 'X' or 'x' are used to exit programming, the message will be printed, but the [999] entry in the example above will be either [X] or [x] respectively. In the example above and in the examples to follow, user entered data is enclosed in the brackets [ ]. All other data not enclosed in the brackets is data that the Controller sends to the terminal display.

**7.35** The Controller, after sending the message to the display, exits programming mode. To re-enter the programming mode, the user must type a <CR> on the terminal keyboard.

**7.36 980** - Enter Date and Time for Call Detail Record and Time-of-Day Access Control. This command must be followed by the two digit groups for the current month, day, hour, and minutes (format mmddhhmm). The command sets the internal clock of the Controller. This internal clock is used for the time printout on the Call Detail Record. It is also used to determine if access is allowed due to the time-of-day programming by comparing the actual time of call against the preprogrammed time-of-day parameter.

**7.37** A typical entry for a '980' parameter for January 28, 09:26 AM would be:

```
> [98001280926]  
>
```

**7.38 902** - Enter Data Confirmation Mode. This command causes the controller to leave the programming mode and enter the data confirmation mode. This mode allows the programmer to verify that the Controller has received the programming data correctly into the internal memory. Once entered, the command causes the Controller to return the > prompt to the display. The Controller then expects the programmer to enter a parameter to be checked. Once entered, the controller will space on the display and show the characteristics of that particular parameter. For example, if a check were made of the machine identifier as entered in paragraph 7.06, the following steps would be accomplished:

```
> [902]  
> [602] 546F6D  
> [907]  
>
```

**Note:** 9xx parameters are commands and therefore, not verifiable.

**7.39 907** - Exit Data Confirmation Mode. The '907' command causes the Controller to exit from a data confirmation session and to return to the programming mode. A typical example of this is shown above where the '602' parameter was checked for accuracy.

**7.40 942903** - Load Factory Installed Default Database. This command should be used with caution. It will cause the Controller to delete all previous programming data and to install all default database parameter settings. In Tables that follow, these default parameter settings are listed in column 2. The example below shows the manner of entry.

```
> [942]  
> [903]  
>
```

**7.41 942904** - Delete All Search Table Entries. This is another command that should be used with extreme caution. It causes the Controller to delete all data that has been entered in the 801 through

815 and 821 through 835 Search Tables. If only a few entries in these tables are to be changed, it is recommended that the parameters to be changed be programmed singularly. This command should only be used if there are too many parameters to be changed one at a time and it is desired to re-enter the complete programming for all the Search Tables. Note that the Controller cannot function properly without data in these tables.

**Note:** After deleting all search table entries with the 942904 command, the default data base can be reloaded by entering a 942903 command.

```
> [942]
> [904]
>
```

**7.42 601 - Area Code of Other Common Carrier (OCC).** If the OCC requires an area code entry for dialing, it should be entered with this command. Command data entry should be followed with the end of entry indicators 'BB'. The data to be entered must be 3 digits in length, if used. If not used, the default data for this entry is '000'. For example, if the area code for the OCC was '613', it would be entered as follows:

```
> [601613BB]
>
```

**7.43 602 - Machine Identifier for Call Detail Record Output.** This command allows the programmer to enter a character or group of characters that will be printed on the Call Detail Record. It appears on the far right side of the printout. Note that only three characters will be printed, regardless of the length of the identifier over three characters. If the identifier is under four characters, all will be printed. The identifier must be entered as ASCII characters. Refer to Appendix C, Table C-1 for ASCII equivalents. The command data must be terminated with the 'BB' terminator. The default for this command is 'SAC'. For example, if the Controller is to be identified as 'CHICAGO' (only 'CHI' will appear in CDR output), it would be programmed as:

```
> [6024348494341474FBB]
>
```

**7.44 604 - Terminal Program Security Code.** This command allows the programmer to change the security code required for entry into programming. The security code default on initialization is '<CR>'. Once initialized, the unit enters immediately into the programming mode if the security code has not been changed. The data for this entry is limited to 15 characters maximum and must be entered in ASCII format. The data string entered must be followed by the 'BB' data entry terminator. Refer to Appendix C, Table C-1 for the ASCII equivalents. For example, if a programmer wished to change the security code to 'BOB', the entry would appear as:



```
> [604424F42BB]
>
```

- 7.45 After entering this command as shown above, and **after exiting the programming mode**, access to programming can **only** be gained by entering 'BOB' on the terminal keyboard as shown below:

```
[BOB]
REV xx-xx ENTERING PROG. MODE
>
```

where xx-xx is the revision of the software that is resident in the Controller.

**Note:** The password 'BOB' is entered on the keyboard, but is not displayed on the terminal for security reasons.

Table 7-3, System Wide Operational Parameters

ENTER	DEFAULT	DESCRIPTION																																				
001t	0	Re-Order Tone, where 't' equals: 0 = OFF 1 = ON																																				
005t	0	Number of Trunk to monitor for Call Detail Record where 't' equals: <table border="1"> <thead> <tr> <th>Digit</th> <th>Allowed Trunk(s)</th> <th>Digit</th> <th>Allowed Trunk(s)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>All (default)</td> <td>8</td> <td>4</td> </tr> <tr> <td>1</td> <td>1</td> <td>9</td> <td>1,4</td> </tr> <tr> <td>2</td> <td>2</td> <td>A</td> <td>2,4</td> </tr> <tr> <td>3</td> <td>1,2</td> <td>B</td> <td>1,2,4</td> </tr> <tr> <td>4</td> <td>3</td> <td>C</td> <td>3,4</td> </tr> <tr> <td>5</td> <td>1,3</td> <td>D</td> <td>1,3,4</td> </tr> <tr> <td>6</td> <td>2,3</td> <td>E</td> <td>2,3,4</td> </tr> <tr> <td>7</td> <td>1,2,3</td> <td></td> <td></td> </tr> </tbody> </table>	Digit	Allowed Trunk(s)	Digit	Allowed Trunk(s)	0	All (default)	8	4	1	1	9	1,4	2	2	A	2,4	3	1,2	B	1,2,4	4	3	C	3,4	5	1,3	D	1,3,4	6	2,3	E	2,3,4	7	1,2,3		
Digit	Allowed Trunk(s)	Digit	Allowed Trunk(s)																																			
0	All (default)	8	4																																			
1	1	9	1,4																																			
2	2	A	2,4																																			
3	1,2	B	1,2,4																																			
4	3	C	3,4																																			
5	1,3	D	1,3,4																																			
6	2,3	E	2,3,4																																			
7	1,2,3																																					
006t	4	Baud Rate of RS-232 Computer Port, where 't' equals: 0 = 1200 Baud 1 = 110 Baud 2 = 300 Baud 3 = 600 Baud 4 = 1200 Baud (Default) 5 = 2400 Baud 6 = 4800 Baud 7 = 9600 Baud																																				
007t	2	Number of Nulls to follow after a Carriage Return during Call Detail Recording Output. The default entry is 2. Any digit from 0 through 9 may be entered when programming this parameter.																																				

(continued)

Table 7-3 (Cont'd), System Wide Operational Parameters

ENTER	DEFAULT	DESCRIPTION
009t	2	Selection of Print Format for Call Detail Recording Output, where 't' equals: 0 = Call Detail Recording Disabled. 1 = MITEL Format selected. 2 = SMarT Format selected.
010t	9	Route to Monitor, where 't' equals: 0 thru 3 = Primary Routes 1,2,3, and 4. 4 thru 7 = Alternate Routes 5,6,7, and 8. 8 = Monitor routed calls only. 9 = All Routes (default).

**7.46 001t** - Re-order Tone. This command enables or disables the re-order tone that is supplied to the caller on an unsuccessful access attempt. The default for the command is OFF ('t' = 0). Maximum security is obtained by using the default setting. For example, if it is desired to program the Controller to supply the re-order tone, the command would be entered as:

```
> [0011]
>
```

**7.47 005t** - Number of Trunk to monitor for Call Detail Record. In this command, the letter t designates a digit from 1 through 9 or a letter from A to E must be entered in its place. This character selects the trunks that may be monitored for data output to the Call Detail Record. If '0' is entered, or if no command entry is made (default), all trunks will send data to the Call Detail Record. For example, if it is desired to monitor activity on Trunks 1 through 3, a typical command entry would be:

```
> [0057]
>
```

**7.48 006t** - This command selects the Baud rate of the RS-232 Computer Port. This allows the programmer to choose a rate for transmission to the attached device (terminal, printer, etc.) that will be acceptable by the chosen device. This change does not take effect until after exiting the programming mode. The default rate is 1200 Baud and need not be programmed if acceptable. The rate ranges from 110 to 9600 Baud in seven steps. Each step is associated with a particular number. For example, if a terminal that operates at 4800 Baud were to be attached to the RS-232 port after programming, the programming would be entered as:

```
> [0066]
>
```

**WARNING:** Do NOT set the Baud Rate to a value which is not supported by the device that is connected to the RS-232 Computer Port. Doing so will prevent any further programming of any kind, including any efforts to change the value of this parameter in any way. If this is done, the only way to do any further programming of any kind is to follow the initialization procedure detailed in paragraph 6.06 (page 30), which will delete all programming done to this point and will reload the default data base.

**7.49 007t** – This command selects the number of Nulls to be sent to a device attached to the RS-232 port following the transmission of a <CR> to the device. The default entry for this command is '2' where two Nulls will be sent. Any digit from 0 to 9 may be entered. The purpose of this command is to allow some adjustment in the timing of device display where required. For example, if a printer is attached to the port and this device prints in one direction only, it may not have enough time to execute a carriage return before printing additional data sent to it. The nulls allow the carriage to be returned to the start print position before receiving more data. For example, if this period required 4 nulls to accomplish the desired affect, it would be programmed as:

```
> [0074]
>
```

**7.50 009t** – The 009 command selects the print format to be used when outputting data to the RS-232 Computer Port for Call Detail Recording. The only numbers allowed for selection and entry for 't' are 0, 1, and 2 where 2 is the default selection. '0' disables Call Detail Recording. '1' selects the MITEL Format while '2' selects the SMarT-1<sup>tm</sup> Format. For a description of the format, refer to para. 7.124. An example of programming to select the SMarT-1<sup>tm</sup> Format is:

```
> [0092]
>
```

**7.51 010t** – This command selects the route to monitor for Call Detail Recording. Appropriate entries for 't' are a single digit from 0 through 9, where the numbers 0 through 3 equate to routes 1 through 4 respectively, and numbers 4 through 7 equate to alternate routes 5 through 8 respectively. 8 equates to enabling monitor of routed calls only, while 9 equates to enabling all routes and is the default for this command. A sample programming entry for route 4 would be:

```
> [0104]
>
```

#### Trunk Related Parameters

**7.52** Table 7-4 on the next page lists the Trunk related programming parameters. Detailed descriptions of the parameters follow the

table. The letter 'x' preceding the command digits indicates that a trunk select number be entered to choose the particular trunk to be programmed for the command. These numbers equate to:

- 1 = program only Trunk 1
- 2 = program only Trunk 2
- 3 = program only Trunk 3
- 4 = program only Trunk 4
- 5 = program all trunks simultaneously

**7.53** For example, if it is desired to program ALL Trunks simultaneously for a Loop Start Central Office using Rotary dial, the programmer would enter:

```
> [5000]
>
```

**7.54** To program only Trunk 2 for a Loop Start Central Office using DTMF dial, the programmer would enter:

```
> [2002]
>
```

**Note:** The parameters listed in Table 7-4 below may appear at first glance to be entered out of sequence. This sequence was used to list all pertinent parameters for the Controller first, followed by less relevant/less used parameters.

**Table 7-4, Trunk Related Parameters**

ENTER	DEFAULT	DESCRIPTION
x00t	2	Type of Central Office, where t equals: 0 = Loop Start, Rotary Dialout 1 = Ground Start, Rotary Dialout 2 = Loop Start, DTMF Dialout 3 = Ground Start, DTMF Dialout
x01t	4	Rotary Dialing Rate, where t equals: 3 = 40/30 ms Outpulse 4 = 60/40 ms Outpulse
x02t	2	DTMF Dialing Rate, where t equals: 0 = 40ms 1 = 50ms 2 = 60ms 3 = 70ms 4 = 80ms 5 = 90ms 6 = 100ms 7 = 110ms 8 = 120ms 9 = 130ms

(continued)

Table 7-4 (Cont'd), Trunk Related Parameters

ENTER	DEFAULT	DESCRIPTION																
x05t	5	<p>Time period between Line Drop and Reseizure, where t equals:</p> <table> <tr> <td>0 = 500ms</td> <td>5 = 1250ms</td> </tr> <tr> <td>1 = 650ms</td> <td>6 = 1400ms</td> </tr> <tr> <td>2 = 800ms</td> <td>7 = 1550ms</td> </tr> <tr> <td>3 = 950ms</td> <td>8 = 1700ms</td> </tr> <tr> <td>4 = 1100ms</td> <td>9 = 1850ms</td> </tr> </table>	0 = 500ms	5 = 1250ms	1 = 650ms	6 = 1400ms	2 = 800ms	7 = 1550ms	3 = 950ms	8 = 1700ms	4 = 1100ms	9 = 1850ms						
0 = 500ms	5 = 1250ms																	
1 = 650ms	6 = 1400ms																	
2 = 800ms	7 = 1550ms																	
3 = 950ms	8 = 1700ms																	
4 = 1100ms	9 = 1850ms																	
x27t	1	<p>Call Answer Timer, where if t = 0, The Controller is 'OFF' and all SAC activity is disabled. Calls into the protected Modem will not be processed or interfered with. Other values for t are:</p> <table> <tr> <td>1 = 3 seconds</td> <td>9 = 27 seconds</td> </tr> <tr> <td>2 = 6 seconds</td> <td>A = 30 seconds</td> </tr> <tr> <td>3 = 9 seconds</td> <td>B = 33 seconds</td> </tr> <tr> <td>4 = 12 seconds</td> <td>C = 36 seconds</td> </tr> <tr> <td>5 = 15 seconds</td> <td>D = 39 seconds</td> </tr> <tr> <td>6 = 18 seconds</td> <td>E = 42 seconds</td> </tr> <tr> <td>7 = 21 seconds</td> <td>F = 45 seconds</td> </tr> <tr> <td>8 = 24 seconds</td> <td></td> </tr> </table>	1 = 3 seconds	9 = 27 seconds	2 = 6 seconds	A = 30 seconds	3 = 9 seconds	B = 33 seconds	4 = 12 seconds	C = 36 seconds	5 = 15 seconds	D = 39 seconds	6 = 18 seconds	E = 42 seconds	7 = 21 seconds	F = 45 seconds	8 = 24 seconds	
1 = 3 seconds	9 = 27 seconds																	
2 = 6 seconds	A = 30 seconds																	
3 = 9 seconds	B = 33 seconds																	
4 = 12 seconds	C = 36 seconds																	
5 = 15 seconds	D = 39 seconds																	
6 = 18 seconds	E = 42 seconds																	
7 = 21 seconds	F = 45 seconds																	
8 = 24 seconds																		
x28t	1	<p>Wait for Password Timer (after Answer), and Wait for User-Entered Callback Number (if called for in the password action digits). The first entry for t below is for the Password Timer, while the second entry is for the User-Entered Callback Number (if used). t equals:</p> <table> <tr> <td>0 = 4/8 seconds</td> <td>8 = 36/72 seconds</td> </tr> <tr> <td>1 = 8/16 seconds</td> <td>9 = 40/80 seconds</td> </tr> <tr> <td>2 = 12/24 seconds</td> <td>A = 44/88 seconds</td> </tr> <tr> <td>3 = 16/32 seconds</td> <td>B = 48/96 seconds</td> </tr> <tr> <td>4 = 20/40 seconds</td> <td>C = 52/104 seconds</td> </tr> <tr> <td>5 = 24/48 seconds</td> <td>D = 56/112 seconds</td> </tr> <tr> <td>6 = 28/56 seconds</td> <td>E = 60/120 seconds</td> </tr> <tr> <td>7 = 32/64 seconds</td> <td></td> </tr> </table>	0 = 4/8 seconds	8 = 36/72 seconds	1 = 8/16 seconds	9 = 40/80 seconds	2 = 12/24 seconds	A = 44/88 seconds	3 = 16/32 seconds	B = 48/96 seconds	4 = 20/40 seconds	C = 52/104 seconds	5 = 24/48 seconds	D = 56/112 seconds	6 = 28/56 seconds	E = 60/120 seconds	7 = 32/64 seconds	
0 = 4/8 seconds	8 = 36/72 seconds																	
1 = 8/16 seconds	9 = 40/80 seconds																	
2 = 12/24 seconds	A = 44/88 seconds																	
3 = 16/32 seconds	B = 48/96 seconds																	
4 = 20/40 seconds	C = 52/104 seconds																	
5 = 24/48 seconds	D = 56/112 seconds																	
6 = 28/56 seconds	E = 60/120 seconds																	
7 = 32/64 seconds																		
x29t	2	<p>Lockout Timer. This timer will be invoked at the end of x28t if either no password has been entered, or if an invalid password has been entered. The timer will 'busy out' the affected trunk for the duration of the its time period, preventing multiple rapid succession access attempts by unauthorized callers. Values for t are:</p> <table> <tr> <td>0 = 10 seconds</td> <td>8 = 90 seconds</td> </tr> <tr> <td>1 = 20 seconds</td> <td>9 = 100 seconds</td> </tr> <tr> <td>2 = 30 seconds</td> <td>A = 110 seconds</td> </tr> <tr> <td>3 = 40 seconds</td> <td>B = 120 seconds</td> </tr> <tr> <td>4 = 50 seconds</td> <td>C = 130 seconds</td> </tr> <tr> <td>5 = 60 seconds</td> <td>D = 140 seconds</td> </tr> <tr> <td>6 = 70 seconds</td> <td>E = 150 seconds</td> </tr> <tr> <td>7 = 80 seconds</td> <td>F = 160 seconds</td> </tr> </table>	0 = 10 seconds	8 = 90 seconds	1 = 20 seconds	9 = 100 seconds	2 = 30 seconds	A = 110 seconds	3 = 40 seconds	B = 120 seconds	4 = 50 seconds	C = 130 seconds	5 = 60 seconds	D = 140 seconds	6 = 70 seconds	E = 150 seconds	7 = 80 seconds	F = 160 seconds
0 = 10 seconds	8 = 90 seconds																	
1 = 20 seconds	9 = 100 seconds																	
2 = 30 seconds	A = 110 seconds																	
3 = 40 seconds	B = 120 seconds																	
4 = 50 seconds	C = 130 seconds																	
5 = 60 seconds	D = 140 seconds																	
6 = 70 seconds	E = 150 seconds																	
7 = 80 seconds	F = 160 seconds																	

(continued)

Table 7-4 (Cont'd), Trunk Related Parameters

ENTER	DEFAULT	DESCRIPTION																																				
<b>x35t</b>	<b>0</b>	<p>Progress Tones (Beeps), where t equals:</p> <table border="1"> <thead> <tr> <th>t</th> <th>Request Password (1 Tone)</th> <th>Request Callback Nr. (2 Tones)</th> <th>Hang Up (3 Tones)</th> </tr> </thead> <tbody> <tr><td>0</td><td>ON</td><td>ON</td><td>ON</td></tr> <tr><td>1</td><td>ON</td><td>ON</td><td>OFF</td></tr> <tr><td>2</td><td>ON</td><td>OFF</td><td>ON</td></tr> <tr><td>3</td><td>ON</td><td>OFF</td><td>OFF</td></tr> <tr><td>4</td><td>OFF</td><td>ON</td><td>ON</td></tr> <tr><td>5</td><td>OFF</td><td>ON</td><td>OFF</td></tr> <tr><td>6</td><td>OFF</td><td>OFF</td><td>ON</td></tr> <tr><td>7</td><td>OFF</td><td>OFF</td><td>OFF</td></tr> </tbody> </table>	t	Request Password (1 Tone)	Request Callback Nr. (2 Tones)	Hang Up (3 Tones)	0	ON	ON	ON	1	ON	ON	OFF	2	ON	OFF	ON	3	ON	OFF	OFF	4	OFF	ON	ON	5	OFF	ON	OFF	6	OFF	OFF	ON	7	OFF	OFF	OFF
t	Request Password (1 Tone)	Request Callback Nr. (2 Tones)	Hang Up (3 Tones)																																			
0	ON	ON	ON																																			
1	ON	ON	OFF																																			
2	ON	OFF	ON																																			
3	ON	OFF	OFF																																			
4	OFF	ON	ON																																			
5	OFF	ON	OFF																																			
6	OFF	OFF	ON																																			
7	OFF	OFF	OFF																																			
<b>x36t</b>	<b>1</b>	<p>Time to wait after valid password determination before processing of the callback (drop and reseize parameter x05t) is initiated, where t equals:</p> <table border="1"> <tbody> <tr><td>0 = Callback Immediately</td><td>8 = 80 seconds</td></tr> <tr><td>1 = 10 seconds</td><td>9 = 90 seconds</td></tr> <tr><td>2 = 20 seconds</td><td>A = 100 seconds</td></tr> <tr><td>3 = 30 seconds</td><td>B = 110 seconds</td></tr> <tr><td>4 = 40 seconds</td><td>C = 120 seconds</td></tr> <tr><td>5 = 50 seconds</td><td>D = 130 seconds</td></tr> <tr><td>6 = 60 seconds</td><td>E = 140 seconds</td></tr> <tr><td>7 = 70 seconds</td><td>F = 150 seconds</td></tr> </tbody> </table>	0 = Callback Immediately	8 = 80 seconds	1 = 10 seconds	9 = 90 seconds	2 = 20 seconds	A = 100 seconds	3 = 30 seconds	B = 110 seconds	4 = 40 seconds	C = 120 seconds	5 = 50 seconds	D = 130 seconds	6 = 60 seconds	E = 140 seconds	7 = 70 seconds	F = 150 seconds																				
0 = Callback Immediately	8 = 80 seconds																																					
1 = 10 seconds	9 = 90 seconds																																					
2 = 20 seconds	A = 100 seconds																																					
3 = 30 seconds	B = 110 seconds																																					
4 = 40 seconds	C = 120 seconds																																					
5 = 50 seconds	D = 130 seconds																																					
6 = 60 seconds	E = 140 seconds																																					
7 = 70 seconds	F = 150 seconds																																					

**7.55 x00t** - This command configures the Controller for the type of Central Office that will be connected to the line. These types are either Loop Start or Ground Start. The command also selects the type of dialing to be used to access the Central Office when executing a callback sequence. The two types of dialing are either Rotary or DTMF dialout. The two selections are combined into one command allowing the programmer to select one of the four combinations listed in Table 7-4 above. If no command is programmed, the default selection of Loop Start, DTMF dialout will be in the Controller. For example, if the Controller were to be programmed for a Ground Start CO and to use DTMF dialout on Trunk 1, the command would be:

```
> [1003]
>
```

**7.56 x01t** - This command will select the Rotary Dialing rate if command x00t above were programmed for Rotary dialout. There are two options that are selectable. These are 40 ms Make/30 ms Break or 60 ms Make/40 ms Break. The latter selection is the default for the command and need not be programmed, if required. For example, if all trunks were to use the 40/30 ms Rotary Dialing Rate, the command would be entered as:

---

> [5013]  
>

**7.57 x02t** - This command will select the DTMF Dialing rate if command x00t above were programmed for DTMF dialout. The rate ranges from 40 to 130 ms in 10 ms steps. 60 ms is the default selection for this command. Selection is done by entering a number from 0 through 9 for the letter t in the command line. For example, if Trunk 3 were to use DTMF dialing at a rate of 100 ms, the command would be entered as:

> [3026]  
>

**7.58 x05t** - This command programs the time period length between the point where the Controller drops the line and reseizes the line for a callback execution. The default for this command is 1250 ms. The period length is selectable from 500 to 1850 ms in 150 ms steps. These periods equate to a number from 0 to 9 to be used to replace the letter 't' in the command line. For example, if a period of 1700 ms were required between drop and reseizure on Trunk 1 for the Controller, the command would be entered as:

> [1058]  
>

**7.59 x27t** - The x27t command programs the Call Answer Timer to wait for a period of time after detecting the first ring on the line, before answering the call. The default period of time is 3 seconds (i.e., after detecting ringing, the Controller will wait for 3 seconds before answering the call). The period selection ranges from 3 to 45 seconds in 3 second steps. These are designated by a number from 1 to 9, or a letter from A to F to replace the 't' in the command. For example, if all trunks were to be programmed to wait for 6 seconds after ringing detection before answering, the command would be entered as:

> [5272]  
>

**7.60 x28t** - This command performs two functions, if required. The first and most important is to wait for the password to be received. The second is to wait for a user entered callback number to be received (if called for in the password action digits). The command will cause the controller to perform the first wait period. If the password action digits indicate that a user entered callback number is to be received, the second wait period after entry of the password will be accomplished. For more information on the password action digits, refer to password programming on page 60. The wait period for the wait for password timer is programmable from 4 to 60 seconds in 4 second steps. These steps equate to the number from 0 to 9 or the letter from A to E to be used in place of 't'. The second timer is programmed automatically from the selection of the first timer. The second timer will always be (if used) two times the period of the first

timer. The default for this command is 8/16 seconds (i.e., the Controller will wait for 8 seconds for the caller to enter a valid password before timing out and terminating the call and 16 seconds for the caller to enter his callback number (if used). For example, if it is desired to have the Controller to wait 16 seconds for password entry by the caller on Trunk 2, the command would be entered as:

```
> [2283]
>
```

**7.61** The entry of the above command assumes that, if used, the period for waiting for callback number entry will be 32 seconds.

**7.62** **x29t** - The x29t command is used to program the Lockout Timer. This timer will start if, at the end of the x28t wait for password period expires and if either an invalid password, or no password has been received. During the period that this timer is in effect, the Controller will 'busy out' the affected trunk(s) for the period. This prevents multiple rapid succession access attempts by unauthorized users. The default period for this timer is 20 seconds. The period is programmable from 10 to 160 seconds in 10 second steps. To select a period, enter a number from 0 to 9 or a letter from A to F in place of 't'. For example, if minimum lockout is desired on Trunk 1 and 30 seconds of lockout were desired on Trunk 3, the commands would be entered as:

```
> [1290]
> [3292]
>
```

**7.63** This parameter should be set equal to or greater than the length of time that the Modem waits for Answer Tone. In addition, the SAC monitors for Modem loop current, and, if this timer should expire while the Modem is still on line, the presence of the Modem line state will continue to hold the 'busy out' state. The 'busy out' in this instance, will cease when the Modem goes off line.

**7.64** **x35t** - This command programs the use of progress tones to be sent back to the caller to indicate dialing progress. If '7' is entered into the command line for 't', all progress tones are disabled. The default for this command is '0' or all progress tones on. If '0' is entered, the caller will receive a single progress tone (1 beep) requesting entry of password, a double progress tone (2 beeps) to request entry of user entered callback number, and a triple progress tone (3 beeps) to request the caller to hang up for callback. For example, if all trunks were to be programmed for a single progress tone to indicate password entry, the command line would be typed as:

```
> [5353]
>
```

**7.65** **x36t** - The x36t command programs the amount of time to wait after valid password determination before initiating the callback process (i.e., time until initiation of the drop and reseize command





Table 7-5, Non-Controller Pertinent Parameters

ENTER	DEFAULT	DESCRIPTION
x07t	3	Time to wait for Tip Ground on Ground Start Try (Ground Start Timeout in seconds), where t equals number of seconds to wait until timeout.
x14t	4	Rotary Inter-digit Pause for Central Office (outgoing dialing), where t equals: 0 = 400 ms 1 = 500 ms 2 = 600 ms 3 = 700 ms 4 = 800 ms 5 = 900 ms 6 = 1 second 7 = 1.1 seconds 8 = 1.2 seconds
x20t	2	Incoming Ringing Sensitivity, where t nominally equals: 0 = 40 ms 1 = 50 ms 2 = 60 ms 3 = 80 ms 4 = 90 ms 5 = 100 ms 6 = 120 ms 7 = 130 ms 8 = 140 ms 9 = 160 ms A = 170 ms B = 180 ms C = 200 ms D = 210 ms E = 220 ms F = 240 ms
x21t	6	Inter-ring timing in seconds, where t equals the number of seconds to wait.
x24t	0	Select Default Route for use within one of two groups of four routes. If this command is set to either 0, 1, 2, or 3, the primary routes will be used. If it is set to either 4, 5, 6, or 7, the alternate routes will be used. 'Use Default Route' is an action digit that is included within the 801 through 815 Search Table action digits (for more information, refer to page 65 paragraph 7.106). 't' equals: 0 = Use Primary Routes 0 through 3 4 = Use Alternate Routes 4 through 7
x31t	3	Tip Ground Application Timer, where t equals: 0 = 40 ms 1 = 40 ms 2 = 80 ms 3 = 120 ms 4 = 160 ms 5 = 200 ms 6 = 240 ms 7 = 280 ms 8 = 320 ms 9 = 360 ms A = 400 ms B = 440 ms
x33t	0	Hit Timing, where t equals: 0 = 40 ms 8 = 20 ms

(continued)



> [2076]  
>

**7.71 x14t** - The x14t command programs the Rotary Dial Inter-Digit Pause time for the Central Office on outgoing dialing. The default for this command is 800 ms. The time period is programmable from 400 to 1200 ms in 100 ms steps. A period is selected by replacing the 't' in the command line with a number from 0 through 8. For example, if it is desired to program the Controller for an Inter-digit Pause time of 1200 ms on Trunk 3, the command would appear as:

> [3148]  
>

**7.72 x20t** -This command programs the Incoming Ringing Sensitivity. This sensitivity indicates a time period from the initial application of ringing to the line, to the first recognition of ringing by the Controller. These times are nominal and may be slightly different when actually measured. The period can range from 40 to 240 ms in 16 steps and is selected by substituting a number from 0 to 9, or a letter from A to F for 't' in the command line. For example, if Trunk 2 were to be programmed for a ringing sensitivity of 160 ms, the command would be entered as:

> [2209]  
>

**7.73 x21t** - This command programs the Inter-Ring Timing in seconds. The period may range from 0 to 9 as selected by substituting a number from 0 to 9 respectively for 't' in the command line. The default for the command is 6 seconds. For example, if it were desired to program all trunks for an 8 second Inter-Ring time period, the command would be entered as:

> [5218]  
>

**7.74 x24t** - The x24t command programs the Controller to Select Default Route when called for as an action digit in the Search Tables. This route is from within one of two groups of four routes. Routes are either primary or alternate and are numbered from 1 to 4 for the primary; from 5 to 8 for the alternate. Since one of these two groups is to be selected by this command, it is only necessary to enter a '0' (primary) or a '4' (alternate) in place of 't' in the command line. Any other number from 0 to 3 will also select primary routes, and any other number from 4 to 7 will select alternate routes. If the 'Use Default Route' is desired, it must be programmed as an action digit in the 801 through 815 Search Tables. The default for the command is '0' or use primary routes 1 through 4. An example of programming Trunk 2 to use alternate routes 4 through 7 would be entered as:

> [2244]  
>

**7.75 x31t** – This command programs the Tip Ground Application Timer for Tip Ground application recognition (GND START). The time period is selectable from 40 to 440 ms in 12 steps. The period is selected by substituting a number from 0 to 9, or the letter A or B that equates to the desired time period. The default for the command is 120 ms or '3'. For example, to program all trunks for a Tip Ground Application Timer of 440 ms, the command would be entered as:

```
> [531B]
>
```

**7.76 x33t** – This parameter controls the hit timing for the trunk. Hit timing is the minimum time that an on-hook, a line break, or a D C short must appear on the trunk before the Controller will recognize it. To change the Hit Timing to 20 ms, enter:

```
> [2338]
>
```

**7.77 x34t** – The x34t command programs the Controller for the Tip Ground Removal Timer. A period within the range of 0 to 440 ms can be selected by substituting a number from 0 to 9, or the letter A or B for 't' in the command line. These periods are listed in Table 7-5 above under the x34t command. The default for the command is 240 ms. For example, to program all trunks for a 120 ms Tip Ground Removal time, the command would be entered as:

```
> [5343]
>
```

#### PASSWORD PROGRAMMING

**7.78** Passwords can range from 2 to 15 digits in length, depending upon the desired usage. Refer to Figure 7-4 for an illustration of the password format. Password programming is accomplished by entering a password string in the 821 through 835 Search Tables.

**7.79** If the Controller is intended to provide an automatic callback function, the password can only range in length from 3 to 12 digits. The last three digits are used as the Speed Call Address which is a label that identifies the callback number to use. Therefore, in this case, the password will be from 3 to 15 digits in length.

**7.80** If the password action digit does not perform automatic callback, then the password may be from 1 to 15 digits in length. There is no need for a label to the speed call bin.

**7.81** Note that no two passwords may be identical regardless of the action digits that are associated with it. Entering a second identical password will overwrite the original password in the list.

**Note:** When comparing the Password Tables against the dialed in password, the last action encountered will be used. Refer to the password programming examples in later text.

**7.82** Figure 7-4 illustrates the password format showing the actual password (authorization code), speed call address (if used), action digit, time-of-day code, and terminator. Password data entry must always be terminated by the 'BB' code.

**7.83** Table 7-6 on the next page illustrates the various password entries for password tables 821 through 835, along with a description of each parameter that must be entered.

**7.84** Table 7-7 on the next page lists the password action digits along with a description of each action. If the digit in the first column is used as a password action digit, its use will cause the password to be printed in the Call Detail Record (CDR). If the digit in the second column is used, the password will not be printed on the CDR. The last entry describes the code for the action digit 'B9'. This 'B9' is considered by the Controller to be one hexadecimal character. Thus, the 'B9' has to be entered twice.

**7.85** Table 7-8 on the next page lists the time-of-day codes along with a description of each code. The times listed after the code show when a particular password entry that has the code will be allowed access. Times are entered in the 24 hour standard format. At the time of the call, the Controller will compare the current time against the allowable range of times for the password. If not within range, the call will be denied.




Figure 7-4, Password Format

Table 7-6, Password Table Descriptions

Table Entry	Description
821nat BB 822nnat BB 823nnnat BB 824nnnat BB 825nnnnat BB 826nnnnnat BB 827nnnnnat BB 828nnnnnat BB 829nnnnnat BB 830nnnnnat BB 831nnnnnat BB 832nnnnnat BB 833nnnnnat BB 834nnnnnat BB 835nnnnnat BB	<p>Where 'n . . . n' are the password digits to be used for comparisons to the user dialed password digits. n may be any quantity of digits between 2 and 15 corresponding to the size of the table selected, unless the action is accessing a speed call. In this case the minimum length would be 3 digits.</p> <p>n = any DTMF digit from 0 through 9 and *. n may also be:</p> <p>B0 = to search for digit '#' within the password, or B9 = to allow any DTMF digit in that particular location within the password. Refer to password programming examples.</p> <p>Where 'a' is the action digit to be performed upon expiration of the call answer timer (x27t) for the particular match found.</p> <p>Where 't' is the time-of-day code to be checked in determining if a particular password is allowed access at the current time.</p> <p>Where BB is the terminator used to indicate end of entry.</p>

Table 7-7, Password Action Digits (a)

PRINT PASSWORD	NO PRINT PASSWORD	DESCRIPTION
0	4	Deny call if this is last action encountered.
1	5	Accept Callback Number.
2	6	Go to Speed Call callback location determined by last 3 digits of the password, if this is the last action encountered.
3	7	Cut through, if this is the last action encountered.
B9 B9	B9 B9	Delete this password.

Table 7-8, Time-Of-Day Codes (t)

CODE	DESCRIPTION
0	All Day (24 Hour Access)
1	Daytime only (0800 to 1700)
2	Evening only (1700 to 2300)
3	Night only (2300 to 0800)
4	Day and Evening only (0800 to 2300)
5	Day and Night only (2300 to 1700)
6	Evening and Night only (1700 to 0800)

### Password Programming Examples

**7.86** The following paragraphs show examples of password programming. There are three examples listed. These examples, by no means include all possible programming methods, but they do illustrate some of the more basic password programming ways.

#### Example 1

**7.87** Example 1 shows a programming line to allow password '1111' to cause an automatic callback without printing the password in the Call Detail Record. This example allows 24 hour access to the protected Modem. Once in the programming mode, enter:

```
> [824111160BB]
>
```

**7.88** The password is 4 digits in length. Therefore, the '824' parameter must be used to enter the '1111' in the password tables. The '6' is the action digit that specifies 'go to Speed Call callback location '111' (last three digits of password indicate Speed Call bin number) without printing password on CDR'. The '0' is the time-of-day code for all day access (24 hours). 'BB' is the data entry terminator.

#### Example 2

**7.89** Example 2 shows a programming line to allow password '22222' to accept a user-entered callback number between 1700 to 2300 hours and to print the password in the Call Detail Record.

```
> [8252222212BB]
>
```

**7.90** The password is 5 digits in length, requiring the use of the '825' parameter for entry in the tables. The '1' is the action digit specifying accept callback. The '2' is the time-of-day code that specifies evening only (1700 - 2300). 'BB' is the entry terminator.

#### Example 3

**7.91** Example 3 shows a programming line to allow password '9999999999' to 'cut through' (no callback) between 0800 and 1700. The password is also printed in the Call Detail Record.

```
> [830999999999931BB]
>
```

**7.92** The password is 10 digits in length, requiring the use of the '830' parameter for entry. The '3' is the action digit that specifies cut through. It also specifies that the password be printed in the Call Detail Record. The '1' is the time-of-day code for day only (0800 - 1700). 'BB' is the data entry terminator.



**7.93** All of these examples may be programmed in one session. This is illustrated in the example below:

```
> [824111160BB]
> [8252222212BB]
> [830999999999931BB]
> [711183931212BB]
> [999] QUITTING PROG. MODE
>
```

**7.94** Note the fourth programming line from the top. This line programs the Speed Call bin number '111' for callback number '393-1212'. All Speed Call bins are 7nnn parameters where the 111 indicates the actual stored speed call. This was one of the requirements in example 1 above. It was required to make the '8241111' entry operational. If no speed call was entered in the '111' bin, no callback would be accomplished. Refer to paragraph 7.97 below for more information on Speed Calls and Callback Numbers.

**7.95** To delete a password, enter the password, followed by the action digits 'B9B9'. For example:

```
> [8252222212B9B9]
>
```

will delete the password '2222' and its associated action digits '12' from the '825' (five digit) password table.

#### AUTOMATIC CALLBACK (SPEED CALL) PROGRAMMING

**7.96** The example at the end of this paragraph shows the callback number data entry format where '7' is the register prefix and 'nnn' is the 'bin' number (address) of the callback number. Bin numbers must be the same as the last three digits of the assigned password that the caller must dial into the Controller. The 'nnn' may be any digits from 000 through 999. This allows the use of 1000 callback numbers.

**7nnn k mmm . . . mmm BB**

**7.97** The 'k' in the format example above is the network override code. This will normally be an '8' which commands the Controller to use Search Tables 801 through 815. All possible values of 'k' are listed in Table 7-9 below.

**Table 7-9, Network Override Codes**

CODE	DESCRIPTION
0	Force callback on Route 1
1	Force callback on Route 2
2	Force callback on Route 3
3	Force callback on Route 4

Table 7-9 (Cont'd), Network Override Codes

CODE	DESCRIPTION
4	Force callback on Route 5
5	Force callback on Route 6
6	Force callback on Route 7
7	Force callback on Route 8
8	Use Search Tables
9	Dial immediate, no route. This code is not recommended for use. Since no route is used, there is no check to ensure the presence of dialtone before performing the callback.

**7.98** 'mmm . . . mmm' in the format example is the telephone number to be used for callback. 'BB' is the terminator for the entry.

**7.99** All trunks of the Controller have access to all callback registers. This means that a user may call in on more than one line and receive a callback, in the event that a tried line is busy.

**7.100** Deletion of a callback Speed Call number consists of entering the Bin number with no callback number. For example, to delete the '7111' entry in example 1, simply program:

```
> [7111BB]
>
```

#### SEARCH TABLE PROGRAMMING

**7.101** Upon execution of callback, the numbers in the callback Speed Call bin or the user entered callback digits are compared against the Search Tables to determine the 'route' to use, and whether or not the call is allowed according to the programming previously entered.

**7.102** Default values are included in the factory programmed defaults that will place all callbacks on the DDD Network. If this is satisfactory, no programming will be required for the Search Tables.

**7.103** Some programming will be required if it is desired to limit callbacks from occurring to certain area codes or to limit long distance calls, or if an Other Common Carrier (OCC) is selected, etc.

**7.104** The sequence of digits programmed into these Search Table registers for comparison to automatic or user entered callback digits, is considered to be the Search Table 'template'. Table 7-10 on the next page illustrates the format for the 801 through 815 Search Table data entry.

#### Action Digit Definitions

**7.105** To 'Force' a route means that once the template match has been satisfied for the 'Force' action, no change of the routes

may occur. This mode of routing will be the usual action used for the Controller operation.

**Table 7-10, Search Table Descriptions**

Table Entry	Description
801na BB 802nna BB 803nnna BB 804nnnna BB 805nnnnna BB 806nnnnna BB 807nnnnnna BB 808nnnnnna BB 809nnnnnna BB 810nnnnnna BB 811nnnnnna BB 812nnnnnna BB 813nnnnnna BB 814nnnnnna BB 815nnnnnna BB	<p>Where 'n . . . n' are the digits to be used for comparisons to the user dialed digits or callback Speed Call Number. n = any DTMF digit from 0 through 9 and *. n may also be:</p> <p>B0 = to search for digit '#' within the password, or B1 = Compare against 1 or 0. B4 = Compare against any digit from 2 through 9. B9 = Compare against any digit (do not care).</p> <p>Where a is the action digit to be performed upon successful match of the digit 'template'. The series of n digits ('nnn . . . nnn') is considered the template. Where BB is the terminator used to indicate end of entry.</p>

**7.106** To 'Prefer' a route means to commence the dialout pattern in the preferred route. The route actually used could be changed later on in the dialing sequence as more dialed digits are received. This routing method is a faster means of dialout for commonly dialed or important numbers, usually associated with Other Common Carrier (OCC) programming. This method could allow, for instance, the first three digits of the callback number to cause the Carrier to be accessed, and, on a later dialed digit received, stop the dialout to proceed to a different route (dial a different series of digits). This routing method will probably be seldom used in Security Access Controller operations.

**7.107** Table 7-11 below provides a description of the action digits. Note that only one action may be programmed for a particular template. Re-entering a template with a different action overwrites the previous template and assigns the new action.

**Table 7-11, Action Digit Descriptions**

CODE	DESCRIPTION	x24t =	
		0-3	4-7
0	Prefer Route	1	5
1	Prefer Route	2	6
2	Prefer Route	3	7
3	Prefer Route	4	8

(continued)

Table 7-11 (Cont'd), Action Digit Descriptions

CODE	DESCRIPTION		
		x24t = 0-3	x24t = 4-7
4	Force Route	1	5
5	Force Route	2	6
6	Force Route	3	7
7	Force Route	4	8
B1	Deny - drop call.		
B6	Enough digits, stop searching. This action digit must be encountered in order to provide the Route parameter 6r5 permission to allow connection of the telephone lines. Otherwise, the connection will not occur until the expiration of the Inter-digit Time out.		
B7	Do nothing - wait for more digits.		
B8	Prefer Default Route (x24t).		
B9	Delete this template. B9 is used as an action digit in order to delete one particular template from the Search Tables (i.e., [803393B9] deletes the template '393' and its action digit from the Search Table register '803').		

#### Programming Examples

**7.108** The two examples included below illustrate the programming of the Search Tables. The first is used to deny all calls to Area Code 315. The second is used to force all 393 office codes to Route 1.

##### Example 1

```
> [803315B1BB]
>
```

**7.109** In the above example, the '803' is the designator for the 3-digit Search Table. '315' is the 3-digit template (Area Code). 'B1' is the action digit to deny the call. Finally, 'BB' is the entry terminator.

##### Example 2

```
> [8033934BB]
>
```

**7.110** In the above example, the '803' is the designator for the 3-digit Search Table. '393' is the 3-digit template (office code). '4' is the action digit to force the call to Route 1. Finally, 'BB' is the entry terminator.

#### Search Table Defaults

**7.111** Search Table Defaults are listed in Table C-3 starting on page C-6 in Appendix C at the rear of the manual.

**PROGRAMMING ROUTING PARAMETERS**

**7.112** The factory installed defaults are sufficient to place all callbacks on the DDD route. The routing parameters require no further programming if the use of the DDD route is sufficient.

**7.113** A 'Route' is defined as the instructions to the Controller with respect to the sequences to follow in performing automatic or user-entered callbacks. These parameters control dialtone detection, the order of digits that are dialed out, Centrex dialing if required, and the procedures to follow in the event of call failure. Other route information is also programmable, such as the route name to be used in the Call Detail Record, etc.

**7.114** The defaults that are resident in the routes are usually sufficient to detect dialtone and dial out the automatic or user-entered callback number. If 'Other Common Carrier (OCC)' is used, these parameters would also include the telephone number of the OCC, the authorization code for the OCC, and the detection of that particular carrier's dialtones and manipulation of the dialout digit order required.

**7.115** In the parameters to follow, 'r' is 1 through 8 to designate routes '1' through '8'. The routes to be used are chosen within the Search Tables upon a successful match of digits within the Search Tables. As each callback number is passed through the search tables, a particular route will be chosen after which control is passed to these route parameters.

**6r5 Access Route, Access Control Sequences**

**7.116** The Access Control Sequences instruct the Controller on the specific actions to perform for the dialout of digits. The route Access Control Sequences are a series of digits that indicate actions. These sequences may be repeated or combined in any order required, as long as the total number of characters in the command is less than 34.

**7.117** The 6r5 route is reached as a result of an action digit in the 801 to 815 Search Tables. A search table action of 'Force Route 1' for a Search Table template will send control to parameter 615 (r=1). Table 7-12 below lists the 6r5 parameter codes with descriptions.

**Table 7-12, 6r5 Parameter Codes**

CODE	DESCRIPTION
0	Dial the digit '0'.
1	Dial the digit '1'.
B0A	Dial the DTMF digit '*'.
B00	Dial the DTMF digit '#'.
B01	Dial a DTMF '#' if the last digit dialed was not a '#'.
2	Dial the Callback Number

Table 7-12 (Cont'd), 6r5 Parameter Codes

CODE	DESCRIPTION
3	Dial the OCC Telephone Number in parameter 6r1.
4	Dial the OCC Authorization Number in parameter 6r2.
6	Dial the Trunk number of the Controller processing this call.
7	Cut through - done. This <b>MUST</b> be the last command in the Route Access Control Sequence to instruct the SAC to connect the lines together (after split). If this command is not present, the Controller will wait for the expiration of the Inter-digit Timer before accomplishing cut through.
8	Change to DTMF dialing. Normally used with OCC programming. This command would be inserted into the Access Control Sequence when the Central Office being used by the Controller is Rotary only and the OCC requiring DTMF dialing only (parameter x00 would be set to 0 or 1). The code could then change the dialout from rotary to DTMF after dialing out the 6r1 OCC telephone number.
9	Dial the Centrex Access Code stored in 6r4.

7.118 Table 7-13 below lists the DIALtone Detector codes to be used when coding parameter 6r5. Descriptions of each code is included. 'a' in the code selects the minimum tone duration as listed in Table 7-14. 'b' in the code selects the time out for tones not received and are listed in Table 7-15.

Table 7-13, DIALtone Detector Codes

CODE	DESCRIPTION
B25b	Pause for 'b' seconds.
B3ab	Search for 'a' milliseconds of high tone (570-680 Hz) for 'b' seconds.
B4ab	Search for 'a' milliseconds of 440 Hz for 'b' seconds.
B5ab	Search for 'a' milliseconds of 480 Hz Ringback tone for 'b' seconds.
B6ab	Search for 'a' milliseconds of 400 Hz for 'b' seconds.
B7ab	Search for 'a' milliseconds of energy (350 to 620 Hz) for 'b' seconds.
B8ab	Search for 'a' milliseconds of precise dialtone (350+440 Hz) for 'b' seconds.
B9ab	Search for 'a' milliseconds of 'Not On Network (NON) tone (an OCC function) for 'b' seconds.
BDab	Search for 'a' milliseconds for any DTMF tones for 'b' seconds.
BB	Entry terminator

Table 7-14, 'a' Codes

a	STONE DURATION	ACTION IF NOT RECEIVED
0	Minimum	Redial per r58 or r78
1	200ms	Redial per r58 or r78
2	400ms	Redial per r58 or r78
3	1.0S	Redial per r58 or r78
4	2.55S	Redial per r58 or r78
5	Minimum	Then continue Dialout
6	200ms	Then continue Dialout
7	400ms	Then continue Dialout
8	1.0S	Then continue Dialout
9	2.55S	Then continue Dialout

Table 7-15, 'b' Codes

b	TIMEOUT/TONE NOT RCVD.
0	0 Seconds
1	2 Seconds
2	4 Seconds
3	6 Seconds
4	8 Seconds
5	10 Seconds
6	12 Seconds
7	14 Seconds
8	16 Seconds
9	18 Seconds
*	20 Seconds

**7.119** The default programming entry for all 6r5 Route Access Control Sequences is:

**B7 4 4 2 7**

Where 'B7' indicates that the Controller should search for 'a' milliseconds of wideband dialtone (350+620 Hz) for 'b' seconds. In this case, 'a' equals 2.55S tone duration, then fail to parameter r58. 'b' equals 8 seconds (i.e., the Controller will look for a minimum length of dialtone for 8 seconds). If the tone is detected, then '2' indicates that the Controller should dial the callback (Speed Call) or user entered callback number, and '7' indicates that the dialing is finished. The '7' also indicates that the Controller should cut through (reconnect the lines).

#### Programming Examples

**7.120** Programming the 6r5 Route Access Control Sequences consists of entering the 6r5 parameter after the terminal prompt > where 'r' selects the route number. This parameter is followed by a data string for the Access Control Sequence as selected from the previous tables. The entry is completed by typing the data terminator 'BB'.

#### Example 1

> [615B854347BB]

**7.121** Example 1 shows that this is the Route 1 Access Control Sequence (615). The 'B8' along with the '5' and '4' indicates that the Controller is to wait for a minimum duration of precise dialtone for up to 8 seconds. '3' indicates that if dialtone is detected, the Controller then dials the OCC telephone number that is listed in parameter 6r1. '4' indicates that the Controller should dial the OCC Authorization Number listed in 6r2 if '3' completes. '7' indicates cut through and completion after finishing with '4'. 'BB' terminates the string entry.

**7.122** Example 1 may not be a valid entry for the SAC, but does illustrate the manner in selecting and entering the 6r5 parameters.

**7.123** Table 7-16 below lists some additional Route Parameters that may be programmed to desired operation. Entry is similar to the 6r5 parameter described above for the 6xx parameters. For the r50t through r58t and the r70t through r78t parameters, entry consists of selecting a route number for 'r' and a parameter descriptor for 't'. These descriptors are listed in the table under the applicable parameter. The descriptor may be an action to be performed or a description of a format or register.

**Note:** r50t through r58t indicate primary routes (1-4) while r70t through r78t indicate alternate routes (1-4).

**Table 7-16, Additional Route Parameters**

ENTER		DESCRIPTION (r = 1-8)
6r4 {Number} BB		Centrex Number (Default = 9). Can be up to 33 digits in length for 'number'.
6r2 {Number} BB		OCC Authorization Number. 'number' can be up to 33 digits in length.
6r1 {Number} BB		OCC Telephone Number. 'number' can be up to 33 digits in length.
ENTER	DEFAULT	DESCRIPTION (r = 1-4)
r50t r70t	0 0	Automatic or User Entered Callback Number Format, where t equals: 0 = Any number of digits. 1 = Add Area Code stored in 601 to 7 digits. If 10 digits, do not add Area Code. 2 = Add 1+Area Code stored in 601 to 7 digits or 1+ to 10 digits. 4 = Dial '1' before 7 or 10 digits (do not add Area Code). 8 = 7 or 10 digits only.
r58t r78t	5 5	Action upon Call Failure. This entry is the action that is initiated upon call failure indicated by the 'a' code of parameter 6r5 if 'a' is less than '5', where 't' equals: 0 = Redial on Route 1 (or 5) 1 = Redial on Route 2 (or 6) 2 = Redial on Route 3 (or 7) 3 = Redial on Route 4 (or 8) 4 = Drop call (Deny) 5 = Redial on same route once, then drop 6 = Redial on same route twice, then drop 7 = Redial on same route three times, then drop 8 = Redial on same route once, then on Route 1 (or 5) 9 = Redial on same route twice, then on Route 1 (or 5) A = Redial on same route three times, then on Route 1 (or 5)



**CALL DETAIL RECORD (CDR) PROGRAMMING**

**7.124** The Call Detail Record (CDR) output of the RS-232 Computer Port is governed by parameters 006 (Baud Rate), 007 (Nulls after Carriage Return), 009 (Print Format), 010 (Route to Monitor), 602 (Machine Identifier), 6r0 (Route Name), and 821 through 835 (print or no print action digit for password). In addition, the CDR responds to the control characters <^S> and <^Q> (stop and start commands). The control-S command will suspend the CDR output, while the control-Q will restart the output. These commands are entered by pressing the <Control> and 'S' or 'Q' keys at the same time.


**CDR Description**

**7.125** The incoming call record will indicate the date, time, and duration of the access attempt. It will also indicate 'INWARD' on a callback access. It will print the 'INVALID' password of an unsuccessful access. In addition, it will indicate 'C-THRU' if the action was not a callback, and will print the successful password used if the password action digit was so programmed. It will not indicate a user entered callback number. The user entered callback number will be printed in the outgoing call record, instead.

**7.126** The outgoing call record will indicate the date, time and duration of the outgoing call along with printing the successful password used if the password action digit was so programmed. It will print the callback Speed Call 'bin' number ('nnn' of parameter '7nnn'). It will also print the user entered callback number if the password action digit indicates that it should do so.

**Call Detail Record Format**

SMarT-1 Format (009t = 2, Default)



'cut-through' action digit associated with the printed password in that call record. 'THRU' in an outgoing call indicates that no route was dialed. The dial immediate function has either been used on the Speed Call dialout or the SAC is programmed to the 'cut-through' mode and is asleep. 'DENIED' in this field will indicate an unsuccessful password entry and failure to access the host system.

- E) is the Password digits if enabled by the password action digit, or any invalid password received.
- F) is the Machine Identifier from programming in parameter 602.

**Examples**

7.127 Figure 7-5 below is an example of the SMaRT-1 Call Detail Record printout for incoming calls. There are 8 lines in the Figure and these are considered for discussion purposes to be examples 1 through 8, respectively, in the paragraphs that follow. The examples also assume that the 'print password' action digit has been used for each of the passwords. If it was not used, the password section of the printout would be blank.

00/99	00.09	00:00:15	T1 DENIED	SAC
11/02	10:55	00:00:28	T1 DENIED	SAC
11/02	11:25	00:01:06	T1 INWARD	76278663 SAC
11/02	11:53	01:13:49	T1 C-THRU	623348 SAC
11/02	13:31	00:01:57	T2 INWARD	22552225 SAC
11/03	21:50	00:01:22	T1 DENIED	10000000 SAC
11/03	21:22	00:01:22	T1 DENIED	10000001 SAC
11/03	22:01	00:01:30	T3 INWARD	76278664 SAC

**Figure 7-5, Incoming Call Detail Record Examples**

7.128 Line 1 of Figure 7-5 indicates that a test call was made to the unit. Note the '.' versus the ':' in the time field. The time is incorrect (not programmed into the unit or the unit has momentarily been powered down). Access was denied by virtue of the unit not having been programmed.

7.129 Line 2 of Figure 7-5 indicates that the unit has been programmed and that the first call was made into the unit without entering any password.

7.130 Line 3 of Figure 7-5 indicates that an incoming call was received with a successful password. Speed Call action digits are associated with the password. In Figure 7-6 (Outgoing Calls), Line 1 would be a printout for returning the call.

7.131 Line 4 of Figure 7-5 shows that an incoming call was received with a 'cut-through' action digit for the password. In this case, there is no corresponding outgoing call record.

**7.132** Line 5 of Figure 7-5 shows that an incoming call was received with a successful password. A request for a callback number action digit happens to have been used. Note that the incoming record shows only the successful password. In Figure 7-6, Line 2 shows the outgoing call record associated with the incoming call. It displays the user entered callback number along with the password.

**7.133** Lines 6 and 7 of Figure 7-5 are access denials. The Call Detail Record shows the password attempt.

**7.134** Line 8 of Figure 7-5 shows an incoming record with a successful password. Line 3 of Figure 7-6 shows the associated outgoing record. The call listed in the outgoing record was denied (T), possibly because the programmer denied calls to the 818 area code for some particular reason.

11/02	11:27	01:27:33	663	ST1 AT&T	76278663 SAC
11/02	13:33	00:32:45	3153931212	T1 OCC	22552225 SAC
11/03	22:03	00:00:05	8185451958	T T3 OCC	76278664 SAC

**Figure 7-6, Outgoing Call Detail Record Examples**

#### MITEL Format

**7.135** Since this format was developed for use in PABX applications, there are fields that only pertain to transferred calls. The SMarT-1<sup>™</sup> unit has no use for this information and, as a result, these fields are left blank. Otherwise, the format is very similar to the call record produced by MITEL PABXs.

**7.136** Several call costing machines can process the original MITEL Format. For more information on tested systems, call MITEL DATACOM.

The record is 86 characters long with the following fields:

- **M** - Month/Day
- **B** - Start time (BB.BB means that the clock is wrong)  
(Note the period instead of a colon)
- **C** - Call duration
- **IIII** - Incoming line
- **D** - User dialed digits
- **T** - Denied
- **S** - Speed dialed
- **L** - Line number
- **R** - Route (8 = Internal in Centrex mode)
- **A** - Account code
- **N** - System identification

The named fields on the previous page are printed in a line as illustrated by the line description below:

MITEL Format (009t = 1)

```

0           1           2           3           4           5           6           7           8
123456789012345678901234567890 1234567890123456789012345678901234567890123456789012345678
_MM/DD_BB:BB_CC:CC_IIII_-----DDDDDDDDDDDDDDDDDDDDDDDDDDDD_--TSLRR-----AAAAAAAAAAAA_NNN
    
```

where the fields are as described in Table 7-17.

**7.137** Each line is ended with a CARRIAGE RETURN (ASCII 13) and LINE FEED (ASCII 10) and a programmable number of NULLS (ASCII 0). All alphabetic fields are in upper case. The dialed number and the dialed account code fields will be numbers 0 through 9, \* and #.

**Table 7-17, MITEL Call Record Format Fields**

FIELD	COLUMN	NR. CHARS.	FORMAT MEANING
M	1	1	"SPACE"
	2-6	5	MONTH; "/"; DATE
B	7	1	"SPACE"
	8-12	5	HOURS; ":", MINUTES (This is the time of the start of call rounded out to nearest minute) See note 1.
C	13-14	2	"SPACES"
	15-22	8	HOURS; ":", MINUTES; ":", SECONDS (Call duration)
I	23	1	"SPACE"
	24-27	4	"Tn00" (Printed on incoming calls only; blank on outgoing calls. n is the Line Number [1-4])
D	28-33	6	"SPACES"
	34-56	23	This is the number that was dialed as the "destination". See note 2.
T	57-59	3	"SPACES"
	60	1	"T" = Denied outgoing callback. "D" = Denied incoming access. "C" = Incoming cut through access. "SPACE" = Otherwise.
S	61	1	"S" if the call was speed called; "SPACE" otherwise.
L,R	62-65	4	"Tn0r" (Printed on outgoing calls only; blank on incoming calls. n is the Line Number [1-4]. r is the route chosen [8 = no route] where r0 - r7 equals Route 1 - 8.)
A	66-72	7	"SPACES"
	73-84	12	Dialed account code. See note 3.
N	85	1	"SPACE"
	86-88	3	System Identification (first three characters of parameter 602).

**NOTE 1** Time Display Field: If the separating character in the start of call field is a period (.), the time has not been programmed into the Dialer. Use parameter 980 to program the time. When a Dialer is powered on, it will continue to use the last time that was programmed (time at power down) but will mark the call record with a period (.). If the loss of power is only a few seconds, it will not significantly affect the timekeeping.

**NOTE 2** Dialed Number Field: This field is the Speed Call Bin Number or Callback Number on outgoing calls. Nothing is printed in this field on incoming calls.

If there is further dialing, these digits may be collected in the "account code". If Centrex mode is being used, the user-dialed Centrex Access Code (usually a "9") is not printed. The way to tell internal calls from external calls is to look at the route character (0-7 means a route was used, which probably dialed another "9" for the user; 8 means that the call was not routed, and the Dialer only forwarded the digits as displayed).

If an automatic callback is accessed, the speed call 'bin' number will appear in this field.

**NOTE 3** Password Digits: This field displays the password digits that were entered by the user, provided that the password action digit allows 'print password' for a valid password. All invalid passwords are printed in this field. Only the first 12 digits are displayed, even though the SMarT-1™ unit can handle 23 digit passwords.

**7.138** This completes the description of programming for the Controller. All of the parameters described in the preceding paragraphs have been included in a handy reference table showing the default settings in Appendix C. This table is to be used for those programmers who have read and understood all of the descriptions, but wish to have a quick reference guide to the parameter numbers. The table also includes references to paragraphs that cover the particular parameter, if needed.

### CONTROLLER MEMORY CAPACITY

**7.139** The SAC useable memory consists of an 8K X 8 bit battery backed up Random Access Memory (RAM) chip that is capable of holding approximately 14,500 characters. This memory area is available for the storage of parameters and data at programming time. The rest of the available space is used for program execution overhead.

**7.140** It is unlikely that a programmer will completely fill the RAM area with data. In the event that memory space becomes a matter of concern, the ground rules for estimating memory usage are discussed in the paragraphs to follow starting with paragraph 7.143.

**7.141** If a programmer runs out of space while programming the Controller, none of the previously programmed data will be lost.

The controller simply refuses any more programming after complete memory usage by displaying a question mark (?) on the terminal screen at the termination of each data entry on the keyboard. If it is suspected that RAM space has been completely used up, contact the distributor or the MITEL DATACOM Field Service Office. Once contacted, these personnel can verify that all RAM space has been used, and can possibly recommend more efficient programming techniques that can remedy the situation. As previously mentioned, the programmer should almost never run out of RAM space for parameters and data.

**7.142** Estimates of the memory space required versus the available memory space are possible. The programmer can, therefore, estimate the memory space required before programming and can determine if the available space is insufficient.

#### **Memory Space Estimating Method**

**7.143** The simplest way to determine if the the intended data base will fit into available memory is to calculate the space required by the data. This space is then compared to the space available according to the following rules:

- 1) There are approximately 14,500 available data spaces in a freshly initialized SAC. These spaces are used to store programmed data. All data to be programmed into the SAC will use this space with the exception of default settings. If a default setting is used, it will not decrease the available space. Space is mainly consumed by the parameters which are defined as 'string' entries and require the 'BB' terminator for entry. Entries that do not require the 'BB' terminator may be ignored in calculations.
- 2) A Search Table entry (parameters 801 through 815) occupies a number of spaces equal to the length of the template plus the action digits. For example, an 804 Search Table entry such as '804 1315 0 BB' is four digits plus one action digit for a total of five memory spaces. The '804' and 'BB' entries are not counted. An entry of '803 B9B9B9B2' is six digits plus two action digits for a total of eight memory spaces.
- 3) A password entry (parameters 821 through 835) occupies the number of spaces equal to the length of the template (password) plus the action digits. The password '12345' with a speed call callback action and 24 hour access action would be programmed as '825 12345 20 BB' and would require seven spaces. The '825' and 'BB' entries are not counted.
- 4) A callback (Speed Call) entry occupies a number of spaces equal to the length of the Speed Call plus six (an internal Controller requirement) spaces. This number must be rounded off to the next larger even number if the result is odd. For example, a Speed Call programmed as '7nnn 8 139311212 BB' requires 14 spaces in memory. The eight digits of the telephone number plus six additional for the Controller equals 14. The

'7nnn' and 'BB' entries are not counted.

- 5) Access Control strings, OCC Access Numbers, OCC Authorization Codes, etc., all count, but in general require so little space that they may be neglected for the purpose of space estimations.

**Note:** Deleting a callback (Speed Call) with the '7nnnBB' command does not reclaim all memory previously occupied by that entry. After deletion, the memory space increase only by the number of digits in the removed callback number and not by the '+ 6' factor that was added in the calculation in 4) above.

**7.144** Figures 7-18 through 7-20 are calculation worksheets that have been included to assist in memory space calculations. Figure 7-18 is to be used in calculating Search Table space. Figure 7-19 is to be used in calculating password space, and Figure 7-20 is to be used in calculating callback number space. These figures are located at the end of this part.

**7.145** The sum of the Search Tables + Passwords + Callback Numbers must be less than approximately 14,500 spaces. Using the assumption that there will be one callback number for each password, and that the 801 through 815 search tables are not required to be programmed (as is the usual case), the following generalizations can be made:

Let X = QUANTITY

**PASSWORDS**

(Length + 2) X

**CALLBACKS**

(Length + 6) X

= 14,500

**7.146** For example, assume that the unit is programmed with all 5 digit passwords and 7 digit callback numbers. Using the equation under paragraph 7.146 above, the amount of space used would be 725 spaces as shown below:

$$(5 + 2)X + (7 + 6)X = 14,500$$

$$7X + 13X = 14,500$$

$$20X = 14500$$

$$X = \frac{14500}{20}$$

$$X = 725$$

Therefore, 725 five digit passwords and 725 seven digit callback numbers may be safely stored in the RAM memory.

**7.147** Another example would be to assume that there will be twice as many passwords as callback numbers (two people at each callback location but with different access allowances). Passwords are still 5 digits long and callback numbers are 7 digits long:

$$(5 + 2)2X + (7 + 6)X = 14,500$$

$$(7)2X + 13X = 14,500$$

$$14X + 13X = 14500$$

$$27X = 14500$$

$$X = \frac{14500}{27}$$

$$X = 537$$

Therefore, 1,074 five digit passwords (2X) and 537 seven digit callback numbers may safely be stored in the RAM memory.

**7.148** If the extreme case were considered and based on the formula above, up to 381 15-digit passwords and 381 15-digit callback numbers could be stored in the RAM memory. For those who demand more detailed calculations, simultaneous solutions using X and Y unknowns would allow calculation of uneven numbers of password/callback quantities. Calculus formulae would allow both lengths and quantities to be varied, but for simplicity, it is easier to use the charts included, with known intentions.







## 8. TECHNICAL CIRCUIT DESCRIPTION

### INTRODUCTION

**8.01** This part will be added at a later date. For the present, refer to Appendix C, Figures C-1 and C-2 for an overall block diagram, and a simplified electrical diagram of the Controller, respectively.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

## 9. MAINTENANCE AND TROUBLESHOOTING

### MAINTENANCE

**9.01** The SMarT-1™ Security Access Controller, as is evident, is a fully self-contained unit. As such, it has no user repairable parts. If the warranty seal over the unit fasteners is broken, the warranty is void. In case of failure, replace the Controller as follows:

- 1) Power down the unit. This will cut-through the subscriber side to the CO side.
- 2) Remove the RJ31/CA31 plug from the Telco supplied socket. The shorting bars in the RJ31X/CA31A will cut-through to the line. Then,
- 3) Replace the Controller and re-connect.
- 4) Proceed as if a new installation.

### TROUBLESHOOTING

**9.02** This part will be added at a later date.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

---

**APPENDIX A****FCC INTERCONNECTION REQUIREMENTS**

**A1.01** This equipment has been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines through the standard connection cabling provided with the unit. This section is applicable to telephone interconnection in the United States.

**A1.02** Prior to the interconnection of this equipment, the local telephone company is to be notified; inform the company that you have FCC-registered equipment that you wish to connect to their trunks. Give them the following information:

- The telephone number of the line that will connect to the unit.
- The equipment being connected is a MITEL DATACOM INC. model SMarT-1<sup>™</sup> Security Access Controller.
- The FCC Registration Number for the SMarT-1<sup>™</sup> is EMP 85B-14558-LR-E.
- The FCC Ringer Equivalence Number (REN) which is 0.7B.
- The Connector Jacks required are RJ31X.

**CONNECTION LIMITATIONS**

**A1.03** Due to the FCC Part 68 Rule, no connection can be made to party lines and to coin telephone service. This unit is designed to be used on standard-device telephone lines. If there are any questions about the telephone line, such as how many pieces of equipment may be connected to it, the telephone company will provide this information upon request.

**NETWORK CHANGES**

**A1.04** The telephone company may make changes to its communication service; such changes may include the change of trunk circuits, changes in the operational characteristics of its trunks, etc. Before doing this, however, the company shall provide official notification, so that the operation of the Dialer service will not be interrupted.

**MAINTENANCE LIMITATIONS**

**A1.05** This equipment has been registered with the FCC for direct connection to the telephone network. Under the FCC program, the user is restricted from making any changes or repairs and from performing any maintenance operations other than those specifically included in this document.

**A1.06** There are no user repairable parts within the unit. It is sealed against user maintenance. If opened, all warranties are voided.

**A1.07** No cabling or wiring changes within the unit are permitted by the user. Plug-ended cables, as detailed in this document, are to be used for all external connections between the unit and the telephone company interface jack.

**A1.08** Power supply components and cabling is only to be changed or maintained by MITEL DATACOM INC. or by an authorized agent of MITEL DATACOM INC.

#### **TROUBLE CORRECTIONS**

**A1.09** For all malfunctions, appropriate field service is provided by MITEL DATACOM INC. or its authorized agents.

#### **DISCONNECTION**

**A1.10** If it is ever decided to permanently disconnect the SMarT-1™ Security Access Controller from the present line, please notify the telephone company of this change.



## APPENDIX B

## GLOSSARY OF TERMS

**B1.01** The following pages include a Glossary of Common Terminology that might be encountered in this manual. It is presented in the tabular format of 'term' followed by definition. It does not include all possible terms that may be encountered, but tries to include those that may not be common knowledge to the reader.

## GLOSSARY OF TERMS

TERM	DEFINITION
<b>ACCESS NUMBER</b>	The telephone number used to access the Other Common Carrier (OCC).
<b>AREA CODE (NPA)</b>	A three digit code used to designate the geographical numbering plan area used in nationwide dialing.
<b>ASCII</b>	The American Standard Code for Information Interchange. It is an eight bit alphanumeric transmission code. The first seven bits represent one of 128 standard ASCII characters. The eighth bit is a parity bit for error checking.
<b>AUTHORIZATION NUMBER</b>	Other Common Carrier (OCC) required authorization number.
<b>BAUD</b>	A term used to define the data transfer rate between a computer and a printer, data cassette, floppy disk drive, etc.. It is the reciprocal of the length in seconds of the shortest element of the digital code used in transmission.
<b>BUFFER</b>	An area in the computer's memory (RAM) that is used for temporary storage of data.
<b>CALL RECORDING</b>	The process of sending dialing information to an external printer (via the RS-232 Computer Port).
<b>CALL SEARCHING</b>	The process of comparing dialed digits (one by one) to data stored in the search tables. The result of the comparison usually results in some action being taken by the Dialer.

TERM	DEFINITION
<b>CENTRAL OFFICE (CO)</b>	A telephone switching system used to interconnect subscribers together. It is usually located at a point that is central to the subscribers.
<b>CENTRAL PROCESSING UNIT</b>	The circuitry in a computer that controls the computer's operation by interpreting and manipulating the information stored in the computer's memory (RAM or ROM).
<b>CENTREX</b>	Service providing direct inward and outward dialing for PABX extensions. The PABX is assigned a distinct Central Office code, and made part of the numbering plan. A main listed number will give access to the PABX operator.
<b>CUT THROUGH MODE</b>	All digits passed directly through the Dialer (no Dialer activity).
<b>DATA TRANSMISSION RATE</b>	See BAUD.
<b>DDD</b>	Direct Distance Dialing that allows long distance calls to be dialed direct, rather than going through an operator.
<b>DOT MATRIX PRINTER</b>	A printer whose printer head forms its characters by the use of numerous metal pins that punch out the image required on paper. Another method would use jets of ink to form the image. Any method that uses a matrix of dots to form a character on paper.
<b>DTMF DIALING</b>	A system of dialing that uses tones to transmit the dialed number to the Central Office.
<b>END OFFICE</b>	A local central office arranged for terminating subscriber lines and provided with trunks for establishing connections to and from other central offices and toll offices.
<b>EXTENDED AREA SERVICE (EAS)</b>	Telephone service that allows subscribers in one area to call subscribers in another area without a toll charge.

TERM	DEFINITION
<b>FOREIGN EXCHANGE (FX)</b>	A classification of subscriber service that indicates service from any other central office other than the central office that would normally serve a subscriber. For example, a telephone in N.Y. has a Washington number assigned to it.
<b>GROUND START</b>	A method of signaling to the Central Office. This signaling requires that a ground be applied to the RING side of the Line to indicate an Off-hook condition.
<b>HERTZ (Hz)</b>	A term adapted as a unit of frequency preferred for world wide standardization and replacing "cycles per second". 1000 Hz = 1000 cycles per second.
<b>INTERCONNECT</b>	Companies other than the main telephone companies that supply telecommunications service and equipment.
<b>KEY SYSTEM</b>	A versatile switching system located on the customer's premises consisting of one or more multi-button telephone sets and associated equipment. Permits the mutual access to and control of several central office lines.
<b>LINE</b>	An installed telephone with its associated wiring and auxiliary equipment. Also referred to as a station or extension.
<b>LOOP START</b>	A method of signaling the Central Office. This signaling requires that a termination be placed across the Tip and Ring to indicate an off-hook condition to the Central Office.
<b>MAIN DISTRIBUTION FRAME</b>	A frame where cables terminate for cross-connecting to a central office or private automatic branch exchange, equipment and connections to lines.
<b>MEMORY</b>	The part of a computer where information can be stored, in binary form, and retrieved at any time.
<b>OFF PREMISE EXTENSION (OPX)</b>	A line connected to the PABX that is at a location other than the location of the PABX.

TERM	DEFINITION
<b>OFFICE CODE (NNX)</b>	Any of the 792 codes that can be used as an address for a 10,000 line unit of Central Office.
<b>OTHER COMMON CARRIER (OCC)</b>	A telephone system that provides long distance calls via other than normal carrier facilities, usually at a lower rate.
<b>PRIVATE AUTOMATIC BRANCH EXCHANGE (PABX)</b>	A telephone system located on the customer's premises (Private Exchange), that allows calling between extensions without the assistance of an operator (Automatic), and having trunks going to the central office (Branch).
<b>PRIVATE BRANCH EXCHANGE (PBX)</b>	The same as PABX above, with the exception that an attendant (operator) is required to process calls.
<b>ROM</b>	Read Only Memory, a memory storage chip that may be programmed by someone other than the manufacturer. This chip can only be programmed once, and becomes a permanent modification when the process is completed.
<b>RAM</b>	Random Access Memory, a section of memory that can be written to or read from at any point in time.
<b>RESERVE POWER</b>	A backup DC battery system used to maintain normal switch operations in the event of a power failure.
<b>ROTARY DIAL</b>	A dialing system that uses pulses to transmit the dialed number to the Central Office.
<b>SEQUENTIAL ACCESS</b>	A manner in which to read or write data as complete blocks of information, with each byte accessed in the exact order in which it was stored.
<b>SOFTWARE</b>	Electrically stored memory, either on a permanent basis (ROM) or for a short time (RAM), that causes a computer type system to operate (a set of instructions).
<b>SPEED CALLING</b>	A method of automatically completing a call to a subscriber by use of Speed Dialing.

TERM	DEFINITION
<b>SPEED DIALING</b>	The automatic dialing of a stored number by a microprocessor or similar unit. The process presupposes that the user will dial a single digit to cause the unit to dial many digits automatically, saving time and effort.
<b>STATIC</b>	Interference caused by electrical disturbances in the atmosphere, or any man-made electromagnetic device.
<b>SWITCHING SYSTEM</b>	A device that interconnects two or more subscriber circuits.
<b>TIE TRUNK</b>	A trunk between two PABX's.
<b>TIP &amp; RING</b>	Indicates each side of a pair of wires used throughout the telephone industry. The first wire is the tip and the second wire is the ring. Normally, the tip is ground and the ring is battery.
<b>TOLL OFFICE</b>	The office that handles toll calls (calls where there are additional charges).
<b>TRUNK</b>	A telephone circuit or channel between two Central Offices, or between a Central Office and a PBX or PABX.
<b>VOICE FREQUENCY</b>	The sound waves produced by the vibration of the voice box when speaking.
<b>WIDE AREA TELEPHONE SERVICE (WATS)</b>	For a basic monthly charge, the customer is allowed to make calls within a specific region without any additional charges. A WATS line can be incoming or outgoing, but not both. Outgoing WATS is OUTWATS and incoming WATS is INWATS.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**APPENDIX C**

**ADDITIONAL INFORMATION**

**C1.01** Figures C-1 and C-2 on the following pages are a block diagram and a simplified electrical diagram for the SMarT-1<sup>™</sup> Security Access Controller. Table C-1 is a listing of the standard 7-bit ASCII codes followed by the code equivalents. Table C-2 contains Legal Dialer Programming Input Characters.

**C1.02** Table C-3 lists the Parameter Defaults along with descriptions. The table also lists reference pages where the particular commands and descriptions may be found.




Figure C-1, SMarT-1™ System Block Diagram






Figure C-2. SMarT-1™ Simplified Electrical Diagram

Table C-1, ASCII Codes

CHAR.	HEX. CODE	CHAR.	HEX. CODE	CHAR.	HEX. CODE	CHAR.	HEX. CODE
NUL	00	SP	20	@	40	'	60
SOH	01	!	21	A	41	a	61
STX	02	"	22	B	42	b	62
ETX	03	#	23	C	43	c	63
EOT	04	\$	24	D	44	d	64
ENQ	05	%	25	E	45	e	65
ACK	06	&	26	F	46	f	66
BEL	07	'	27	G	47	g	67
BS	08	(	28	H	48	h	68
HT	09	)	29	I	49	i	69
LF	0A	*	2A	J	4A	j	6A
VT	0B	+	2B	K	4B	k	6B
FF	0C	,	2C	L	4C	l	6C
CR	0D	-	2D	M	4D	m	6D
SO	0E	.	2E	N	4E	n	6E
SI	0F	/	2F	O	4F	o	6F
DLE	10	0	30	P	50	p	70
DC1	11	1	31	Q	51	q	71
DC2	12	2	32	R	52	r	72
DC3	13	3	33	S	53	s	73
DC4	14	4	34	T	54	t	74
NAK	15	5	35	U	55	u	75
SYN	16	6	36	V	56	v	76
ETB	17	7	37	W	57	w	77
CAN	18	8	38	X	58	x	78
EM	19	9	39	Y	59	y	79
SUB	1A	:	3A	Z	5A	z	7A
ESC	1B	;	3B	[	5B	{	7B
FS	1C	<	3C	\	5C		7C
GS	1D	=	3D	]	5D	}	7D
RS	1E	>	3E	^	5E	~	7E
US	1F	?	3F	_	5F	DEL	7F

**Note:** The last character of an ASCII string may not be B. However, a single B within a string is allowed. If the last ASCII character of a string must be B, then it must be followed with a non-printing character such as a space (hexadecimal 20). If necessary, the LF, FF, CR, BEL and so on may also be used within a string.

Table C-2, Legal Controller Programming Input Characters

FROM TERMINAL	TERMINAL DISPLAY	SAC INTERPRETATION
0 through 9	0 through 9	0 through 9
#, *	#, *	#, *
A or a	A or a	*
B or b	B or b	#
BB or bb	BB or bb	##
C or c	C or c	C
D or d	D or d	D
E or e	E or e	E
F or f	F or f	F if it is within a string. SPACE if it is last character of a string.
FF or ff	FF or ff	##
Period <.>	Period <.>	#
Comma <,>	Comma <,>	#
Hyphen <->	Hyphen <->	#
<LF>	<LF>	#
<CR>	<CR>	#
<Space>	<Space>	#
999	999	Exit PROGRAM mode
X or x	X or x	Exit PROGRAM mode
<b>SPECIALS</b>		
C0		For L1H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5
C1		For L2H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5
C2		For L3H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5
C3		For L4H4 Tone Pair dial-out in parameters 601 and 6r0 through 6r5

Table C-3, Default Parameter Summary

Register	Default	Description	Reference
001 005 006 007 009 010	0 0 4 2 2 9	Reorder Tone OFF Trunk to Monitor for CDR 1200 Baud RS-232 Port 2 Nulls after Carriage Return SMarT-1 CDR Print Format Monitor All Routes for CDR	See Pages 47-49
x00 x01 x02 x03 x04 x05 x06 x07 x14 x20 x21 x24 x27 x28 x29 x31 x33 x34 x35 x36	2 4 2 6 1 5 3 3 4 2 6 0 1 1 2 3 0 6 0 1	Loop Start, DTMF Central Office 60/40 Rotary Dialing (Standard) 60 ms On/Off for DTMF Dialing 750 ms On-Hook Recognition Time 100 ms Flash Allowed Time 1.25 Second Drop & Reseize Time Max. 3 Ground Start Attempts Wait 3 Sec. for Ground Start Response 800 ms Rotary Interdigit Pause to CO Ringing Sensitivity 6 Sec. Inter-Ring Timing Default to Primary Routes Auto-Answer in 3 Seconds Wait 8 Sec. for Password and 16 Sec. for User- Entered Number (if used) Busy Out Trunk for 30 Sec. on Invalid Password 120 ms Ground Start Tip Ground Application Tim- er DTMF, 10 or 20 PPS Rotary Dial-in Tip Ground Removal Timer All Progress Tones Enabled Wait 10 Seconds before Initiating Callback	See Pages 50-59
r50x, r70x r55x, r75x r56x, r76x r57x, r77x r58x, r78x	0 * 3 7 5	Any Number of Digits in Callback Number Not On Network Trigger Digit 30 Days before NON Entry Delete 7 Digits stored upon NON Detection Redial Once, then Drop Call	See Page 71
601 602 604	000 SAC <CR>	Dummy Area Code Machine Identifier Terminal Program Access Code	See Pages 44 & 46
610,650 620-640 660-680 6r1 6r2 6r4 6r5	DDD 'ROUTED' 'ROUTED' 9 B74427	Name of Route for CDR Name of Route for CDR Name of Route for CDR OCC Telephone Number OCC Authorization Number Centrex Number Route Access Control Sequence	See Pages 65-72

(continued)

Table C-3 (Cont'd), Default Parameter Summary

Register	Default	Description	Reference
7nnn	Dialback Speed	Call Bin	See Pages 63 & 64
801	1B7 *B7 B90	If 1st digit = 1, do nothing If 1st digit = *, do nothing If 1st digit ≠ 1, *, prefer call on Route 1.	
802 803	911B6	Stop searching after receipt of 911. 801 search above will prefer call on Route 1.	
	*B9B9B2	*and 2 more digits = speed call number.	
804	1411B3	Dial and cut through after 1+411.	
	15550 18000 1B4B9B91	Place 1+555 calls on Route 1. Place 1+800 calls on Route 1. Place 1+NXX calls on Route 2.	
805 806 807	1B4B1B95550	Place 1+N(0 or 1)X-555-XXXX calls on Route 1.	See Pages
	B4B4B9B9B9B9B9B6	Stop searching after receipt of NNX-XXXX (local call).	59-65
808	B1B4B4B9B9B9B9B9B6	Stop searching after receipt of 1+NXX-XXXX (long distance call with same area code).	
809 810	B4B1B9B9B9B9B9B9B9B6	Stop searching after receipt of N(0 or 1)X-XXX-XXXX (long distance, outside of local call- ing area).	
811	B1B4B1B9B9B9B9B9B9B9B6	Stop searching after receipt of 1+N(0 or 1)X-XXX-XXXX (long distance, non international call).	
812 813 814 815			

(continued)

Table C-3 (Cont'd), Default Parameter Summary

Register	Default	Description	Reference
821-835		Password Tables	
902 907 980 942903 942904		Enter Data Confirmation Mode Exit Data Confirmation Mode Enter Date and Time Load Factory Default Database Erase all Search Table Data	See Pages 43-46

## APPENDIX D OVERALL TOPICAL INDEX

CONTENTS	PAGE	CONTENTS	PAGE
ACCESS CODE		SEE VERSATILE PROGRAMMING	6
SEE GLOSSARY OF TERMS	B-1	BAUD	
ACCESS CONTROL SEQUENCE		SEE GLOSSARY OF TERMS	B-1
SEE PROGRAMMING ROUTING PARAMETERS	67	BAUD RATE	
ACR		SEE CALL RECORDING/RS-232 PORT	6
SEE ADAPTIVE CALL ROUTING	6	SEE RS-232 PORT SPECIFICATIONS	11
ACTION DIGIT DEFINITIONS		BB	
SEE SEARCH TABLE PROGRAMMING	64	SEE NOTES ON DATA ENTRY	34
ACTION DIGIT DESCRIPTIONS		BIT EIGHT SENSE	
SEE TABLE 7-11	65,66	SEE RS-232 PORT SPECIFICATIONS	11
ADAPTIVE CALL ROUTING		BITS PER CHARACTER	
SEE CONTROLLER DESCRIPTION	6	SEE RS-232 PORT SPECIFICATIONS	11
ADDITIONAL ROUTE PARAMETERS		BRIDGE GLIPS	
SEE TABLE 7-16	70	SEE RJ31X/CA31A USOC JACK AND CABLE	20
ALLOWABLE VOLTAGE		BUFFER	
SEE HARDWARE SPECIFICATIONS	10	SEE GLOSSARY OF TERMS	B-1
ALTERNATE ROUTING		CALL ANSWER TIMER	
SEE LEAST COST ROUTING	6	SEE TABLE 7-4	51
APPENDIX A		SEE TRUNK RELATED PARAMETERS	52
CONNECTION LIMITATIONS	A-1	CALL DETAIL RECORD FORMAT	
CONNECTOR JACKS	A-1	SEE CALL DETAIL RECORD PROGRAMMING	71
DISCONNECTION	A-2	CALL DETAIL RECORD PROGRAMMING	
FCC INTERCONNECTION REQUIREMENTS	A-1	CALL DETAIL RECORD FORMAT	71
FCC REGISTRATION NUMBER	A-1	CDR DESCRIPTION	71
MAINTENANCE LIMITATIONS	A-1	SEE DETAILED PROGRAMMING DESCRIPTIONS	71
NETWORK CHANGES	A-1	CALL DETAIL RECORDING	
RINGER EQUIVALENCE NUMBER	A-1	SEE SECURITY	23
TROUBLE CORRECTIONS	A-2	CALL FAILURE ACTION	
APPENDIX B		SEE TABLE 7-16	70
GLOSSARY OF TERMS	B-1	CALL RECORDING	
APPENDIX C		SEE GLOSSARY OF TERMS	B-1
ASCII CODES	C-1	CALL RECORDING/RS-232 PORT	
ASCII TABLE	C-4	SEE CONTROLLER DESCRIPTION	6
DEFAULT PARAMETER SUMMARY	C-1	CALL SEARCHING	
DIAGRAMS	C-1	SEE GLOSSARY OF TERMS	B-1
LEGAL CONTROLLER PROGRAMMING INPUT CHARACTERS	C-5	CALLBACK FEATURE	
SMarT-1 SIMPLIFIED ELECTRICAL DIAGRAM	C-4	SEE SECURITY	23
SMarT-1 SYSTEM BLOCK DIAGRAM	C-4	CALLBACK NUMBER FORMAT	
AREA CODE		SEE TABLE 7-16	70
SEE GLOSSARY OF TERMS	B-1	CALLBACK OPERATION	
AREA CODE (NPA)		SEE PROGRAMMING	34
SEE GLOSSARY OF TERMS	B-1	CALLBACK PROGRAMMING TERMINAL DISPLAY	
AREA CODE/OFFICE CODE/CALL SEARCHING		SEE FIGURE 7-1	37
SEE CONTROLLER DESCRIPTION	6	CAPABILITIES	
ASCII		SEE FEATURES AND CAPABILITIES	3
SEE GLOSSARY OF TERMS	B-1	CDR DESCRIPTION	
ASCII CODES		SEE CALL DETAIL RECORD PROGRAMMING	71
SEE APPENDIX C	C-1	CDR PRINT FORMAT	
SEE TABLE C-1	C-4	SEE SYSTEM PARAMETERS	48
ASCII STRING		SEE TABLE 7-3	47,48
SEE NOTES ON DATA ENTRY	35	CENTRAL OFFICE (CO)	
ASCII TABLE		SEE GLOSSARY OF TERMS	B-2
SEE APPENDIX C	C-4	CENTRAL OFFICE CONNECTIONS	
AUTOMATIC CALLBACK ACCESS		SEE RJ31X/CA31A USOC JACK AND CABLE	20
SEE DETAILED OPERATING DESCRIPTIONS	25	CENTRAL PROCESSING UNIT (CPU)	
AUTOMATIC CALLBACK PROGRAMMING		SEE GLOSSARY OF TERMS	B-2
SEE DETAILED PROGRAMMING DESCRIPTIONS	43,63	CENTREX	
B		SEE GLOSSARY OF TERMS	B-2
SEE NOTES ON DATA ENTRY	34	CENTREX NUMBER	
BASIC PROGRAMMING		SEE TABLE 7-16	70
SEE INTRODUCTION	33	CO	
BATTERIES		SEE GLOSSARY OF TERMS	B-2
SEE INITIALIZATION	29	COMMUNICATIONS REQUIREMENTS	
SEE VERSATILE PROGRAMMING	6	SEE INITIALIZATION	29
BATTERY BACKUP		SEE VERSATILE PROGRAMMING	7
SEE SYSTEM POWER	5	CONNECTION LIMITATIONS	
BATTERY FEED		SEE APPENDIX A	A-1
SEE HARDWARE SPECIFICATIONS	9	CONNECTION PROCEDURE	
BATTERY TYPE		SEE CONNECTIONS	16,20
SEE INITIALIZATION	29	CONNECTIONS	

**SECTION MITL8350-048-100-NA**

CONTENTS	PAGE	CONTENTS	PAGE
RJ31X/CA31A USOC JACK AND CABLE	20	DISCONNECTION	
RS-232 PORT CONFIGURATION	20	SEE APPENDIX A	A-2
SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	11	DOCUMENT APPENDICES DESCRIPTION	
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	16	SEE DOCUMENT OVERVIEW	1
CONNECTOR JACKS		DOCUMENT CONVENTIONS	
SEE APPENDIX A	A-1	SEE INTRODUCTION	2
CONTROLLER DESCRIPTION		DOCUMENT HISTORY	
ADAPTIVE CALL ROUTING	6	SEE INTRODUCTION	2
AREA CODE/OFFICE CODE/CALL SEARCHING	6	DOCUMENT NUMBERING	
CALL RECORDING/RS-232 PORT	6	SEE DOCUMENT OBJECTIVES	1
LEAST COST ROUTING	6	DOCUMENT OBJECTIVES	
LINES/MODELS	5	SEE INTRODUCTION	1
NETWORK COMPATIBILITY	5	DOCUMENT OVERVIEW	
SEE GENERAL DESCRIPTION	3	SEE INTRODUCTION	1
SYSTEM POWER	5	DOCUMENT PART DESCRIPTIONS	
CONTROLLER MEMORY CAPACITY		SEE DOCUMENT OVERVIEW	1
MEMORY SPACE ESTIMATING METHOD	76	DOCUMENT TITLE	
SEE PROGRAMMING	75	SEE DOCUMENT OBJECTIVES	1
CURRENT		DOT MATRIX	
SEE HARDWARE SPECIFICATIONS	9	SEE GLOSSARY OF TERMS	B-2
CUT THROUGH ACCESS		DOT MATRIX PRINTER	
SEE OPERATIONAL SEQUENCES	24	SEE GLOSSARY OF TERMS	B-2
SEE DETAILED OPERATING DESCRIPTION	27	DTMF CUT THROUGH ACCESS	
CUT THROUGH MODE		SEE PROGRAMMING	42
SEE GLOSSARY OF TERMS	B-2	DTMF DIALING	
SEE SECURITY	23	SEE GLOSSARY OF TERMS	B-2
		DTMF DIALING RATE	
		SEE TABLE 7-4	50
		SEE TRUNK RELATED PARAMETERS	52
DATA STRING		DTMF RECEIVER	
SEE PROGRAMMING	34	SEE HARDWARE SPECIFICATIONS	10
DATA TRANSMISSION RATE		DTMF SENDER	
SEE GLOSSARY OF TERMS	B-2	SEE HARDWARE SPECIFICATIONS	10
DATA VERIFICATION			
SEE PROCEDURAL STEPS	36		
DC BALANCE			
SEE HARDWARE SPECIFICATIONS	9		
DCE		EAS	
SEE RS-232 PORT CONFIGURATION	20	SEE GLOSSARY OF TERMS	B-2
DDD		ELECTRICAL/MECHANICAL SPECIFICATIONS	
SEE AREA CODE/OFFICE CODE/CALL SEARCHING	6	SEE SPECIFICATIONS	11
SEE GLOSSARY OF TERMS	B-2	SEE TABLE 3-3	11
DEFAULT LOAD		ELLIPSIS	
SEE PROGRAMMING	7	SEE DOCUMENT CONVENTIONS	2
DEFAULT PARAMETER SUMMARY		END OFFICE	
SEE APPENDIX C	C-1	SEE GLOSSARY OF TERMS	B-2
DEFAULT PROGRAMMING PARAMETERS		ENTER DATA CONFIRMATION MODE	
SEE TABLE 7-1	33,34	SEE SYSTEM PARAMETERS	45
DEFECTIVE EQUIPMENT		SEE TABLE 7-2	44
SEE REPACKING	13	ENTER DATE AND TIME	
DELETE ALL SEARCH TABLE ENTRIES		SEE SYSTEM PARAMETERS	45
SEE SYSTEM PARAMETERS	45	ENTER DATE/TIME	
SEE TABLE 7-2	44	SEE SYSTEM PARAMETERS	44
DETAILED OPERATING DESCRIPTION		SEE TABLE 7-2	44
OTHER OPERATIONAL PROCEDURES	28	ENTERING CALLBACK NUMBER	
SEE OPERATING DESCRIPTION	25	SEE PROCEDURAL STEPS	36
WITH MODEMS	25	ENTERING DATE AND TIME	
DETAILED PROGRAMMING DESCRIPTIONS		SEE PROCEDURAL STEPS	36
AUTOMATIC CALLBACK PROGRAMMING	63	ENTERING MACHINE IDENTIFIER	
CALL DETAIL RECORD PROGRAMMING	71	SEE PROCEDURAL STEPS	36
NON-CONTROLLER PERTINENT PARAMETERS	55	ENTERING PASSWORD	
PASSWORD PROGRAMMING	59	SEE PROCEDURAL STEPS	36
PROGRAMMING ROUTING PARAMETERS	67	ENTERING PROGRAM MODE	
SEARCH TABLE PROGRAMMING	64	SEE INITIALIZATION PROCEDURE	30
SEE PROGRAMMING	42	ENTERING PROGRAMMING MODE	
SPEED CALL	63	SEE PROCEDURAL STEPS	36
SYSTEM PARAMETERS	43	ENTRY TERMINATOR	
TRUNK RELATED PARAMETERS	49	SEE PROGRAMMING	34
DETECTOR TIMEOUT CODES		EXIT DATA CONFIRMATION MODE	
SEE TABLE 7-14	69	SEE SYSTEM PARAMETERS	44,45
SEE TABLE 7-15	69	SEE TABLE 7-2	44
DIAGRAMS		EXIT PROGRAM MODE	
SEE APPENDIX C	C-1	SEE SYSTEM PARAMETERS	44
DIALTONE		SEE TABLE 7-2	44
SEE HARDWARE SPECIFICATIONS	10	EXITING PROGRAM MODE	
DIALTONE DETECTOR CODES		SEE INITIALIZATION PROCEDURE	30
SEE TABLE 7-13	68	EXTENDED AREA SERVICE (EAS)	
DIMENSIONS		SEE GLOSSARY OF TERMS	B-2
SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	11		



CONTENTS	PAGE	CONTENTS	PAGE
<b>F</b>		<b>INTERCONNECT</b>	
SEE NOTES ON DATA ENTRY	34	SEE GLOSSARY OF TERMS	B-3
<b>FCC INTERCONNECTION REQUIREMENTS</b>		<b>INTRODUCTION</b>	
GENERAL	1	DOCUMENT CONVENTIONS	2
SEE APPENDIX A	A-1	DOCUMENT HISTORY	20
<b>FCC REGISTRATION NUMBER</b>		DOCUMENT OBJECTIVES	1
SEE APPENDIX A	A-1	DOCUMENT OVERVIEW	1
<b>FCC RINGER EQUIVALENCE</b>		INTENDED AUDIENCE	2
SEE HARDWARE SPECIFICATIONS	9	READER COMMENTS	2
<b>FEATURES</b>		<b>JACKS</b>	
SEE FEATURES AND CAPABILITIES	3	SEE APPENDIX A	A-1
<b>FEATURES AND CAPABILITIES</b>		<b>KEY SYSTEM</b>	
SEE GENERAL DESCRIPTION	3	SEE GLOSSARY OF TERMS	B-3
<b>FEED RESISTANCE</b>		<b>KEYSLOT MOUNTING</b>	
SEE HARDWARE SPECIFICATIONS	9	SEE MOUNTING	16
<b>FF</b>		<b>LEAKAGE</b>	
SEE NOTES ON DATA ENTRY	34	SEE HARDWARE SPECIFICATIONS	9
<b>FLASH ALLOWED TIME</b>		<b>LEAST COST ROUTING</b>	
SEE NON-CONTROLLER PERTINENT PARAMETERS	57	SEE CONTROLLER DESCRIPTION	6
SEE TABLE 7-5	55	<b>LEGAL CONTROLLER PROGRAMMING INPUT CHARACTERS</b>	
<b>FOREIGN EXCHANGE (FX)</b>		SEE TABLE C-2	5
SEE GLOSSARY OF TERMS	B-3	<b>LEGAL DIALER PROGRAMMING INPUT CHARACTERS</b>	
<b>FX</b>		SEE APPENDIX C	C-1
SEE GLOSSARY OF TERMS	B-3	<b>LENGTH OF NON ENTRY</b>	
<b>GENERAL DESCRIPTION</b>		SEE TABLE 7-16	70
CONTROLLER DESCRIPTION	3	<b>LINE</b>	
FEATURES AND CAPABILITIES	3	SEE GLOSSARY OF TERMS	B-3
VERSATILE PROGRAMMING	6	<b>LINE DROP/RESEIZURE TIME</b>	
<b>GROUND START</b>		SEE TABLE 7-4	50
SEE GLOSSARY OF TERMS	B-3	SEE TRUNK RELATED PARAMETERS	52
<b>GROUND START TRIES NUMBER</b>		<b>LINES/MODELS</b>	
SEE NON-CONTROLLER PERTINENT PARAMETERS	57	SEE CONTROLLER DESCRIPTION	5
SEE TABLE 7-5	56	<b>LOAD DEFAULT DATABASE</b>	
<b>GROUNDING VOLTAGE</b>		SEE SYSTEM PARAMETERS	45
SEE HARDWARE SPECIFICATIONS	9	SEE TABLE 7-2	44
<b>HARDWARE SPECIFICATIONS</b>		<b>LOCKOUT TIMER</b>	
SEE SPECIFICATIONS	9	SEE TABLE 7-4	51
SEE TABLE 3-1	9,10	SEE TRUNK RELATED PARAMETERS	53
<b>HERTZ (Hz)</b>		<b>LOOP START</b>	
SEE GLOSSARY OF TERMS	B-3	SEE GLOSSARY OF TERMS	B-3
<b>HIT TIMING</b>		<b>LOSS OF DATA</b>	
SEE NON-CONTROLLER PERTINENT PARAMETERS	58	SEE INITIALIZATION	29
<b>HUMIDITY</b>		<b>MACHINE IDENTIFIER</b>	
SEE HARDWARE SPECIFICATIONS	10	SEE SYSTEM PARAMETERS	46
<b>IMPORTANT NOTICES</b>		SEE TABLE 7-2	44
SEE DOCUMENT OVERVIEW	1	<b>MAIN DISTRIBUTION FRAME</b>	
<b>INCOMING DIGIT RECOGNITION TYPE TIMER</b>		SEE GLOSSARY OF TERMS	B-3
SEE TABLE 7-5	56	<b>MAINTENANCE AND TROUBLESHOOTING</b>	
<b>INCOMING RINGING SENSITIVITY</b>		MAINTENANCE	83
SEE NON-CONTROLLER PERTINENT PARAMETERS	58	TROUBLESHOOTING	83
SEE TABLE 7-5	56	<b>MAINTENANCE LIMITATIONS</b>	
<b>INITIALIZATION</b>		SEE APPENDIX A	A-1
INTRODUCTION	29	<b>MAINTENANCE PROCEDURE</b>	
PROCEDURE	30	SEE MAINTENANCE	83
SEE PROGRAMMING	33	<b>MEMORY</b>	
SEE TABLE 7-1	33,34	SEE GLOSSARY OF TERMS	B-3
SEE VERSATILE PROGRAMMING	6	<b>MEMORY FULL</b>	
<b>INITIALIZATION PROCEDURE</b>		SEE CONTROLLER MEMORY CAPACITY	75
SEE INITIALIZATION	29,30	<b>MEMORY SPACE</b>	
<b>INSTALLATION</b>		PASSWORD ENTRIES	76
SEE CONTROLLER DESCRIPTION	5	SEARCH TABLE ENTRIES	76
<b>INSTALLATION PROBLEMS</b>		SPEED CALLS	77
SEE WITH MODEMS	25	STRING ENTRIES	77
<b>INSTALLATION REQUIREMENTS</b>		<b>MEMORY SPACE CALCULATION</b>	
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	13	SEE EXAMPLES	77
<b>INSTANT ACCESS</b>		<b>MEMORY SPACE ESTIMATING METHOD</b>	
SEE SECURITY	23	SEE CONTROLLER MEMORY CAPACITY	76
<b>INTENDED AUDIENCE</b>		<b>MITEL CALL RECORD FORMAT FIELDS</b>	
SEE INTRODUCTION	2	SEE TABLE 7-17	74
<b>INTER-RING TIMER</b>		<b>MITEL FORMAT</b>	
SEE NON-CONTROLLER PERTINENT PARAMETERS	58		
SEE TABLE 7-5	56		

**SECTION MTL8350-048-100-NA**

CONTENTS	PAGE	CONTENTS	PAGE
SEE CALL DETAIL RECORD FORMAT	73	AUTOMATIC CALLBACK ACCESS	24
<b>MODE OF OPERATION</b>		CUT-THROUGH ACCESS	24
SEE RS-232 PORT SPECIFICATIONS	11	SEE DETAILED OPERATING DESCRIPTION	27
<b>MODEM SETUP</b>		SEE OPERATING DESCRIPTION	23
SEE TESTING CONTROLLER INSTALLATION	37	SEE OPERATIONAL SEQUENCES	24
<b>MODEMS</b>		USER ENTERED CALLBACK ACCESS	24
SEE DETAILED OPERATING DESCRIPTION	25	<b>OPERATIONAL STEPS</b>	
<b>MOUNTING</b>		SEE DETAILED OPERATING DESCRIPTIONS	25,26
SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	11	<b>OPX</b>	
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	16	SEE GLOSSARY OF TERMS	B-3
<b>MOUNTING HARDWARE</b>		<b>ORDERING INFORMATION</b>	
SEE MOUNTING	16	SEE TABLE 4-1	21
<b>MOUNTING INFORMATION</b>		SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	21
ENVIRONMENTAL REQUIREMENTS	16	<b>OTHER COMMON CARRIER (OCC)</b>	
SEE INSTALLATION REQUIREMENTS	13,16	SEE GLOSSARY OF TERMS	B-4
<b>MULTI-UNIT PACKAGE</b>		<b>OTHER OPERATIONAL PROCEDURES</b>	
SEE SHIPPING AND RECEIVING	13	SEE DETAILED OPERATING DESCRIPTION	28
<b>NETWORK CHANGES</b>		<b>PABX</b>	
SEE APPENDIX A	A-1	SEE GLOSSARY OF TERMS	B-4
<b>NETWORK COMPATIBILITY</b>		<b>PACKING MATERIAL</b>	
SEE CONTROLLER DESCRIPTION	5	SEE REPACKING	13
<b>NETWORK OVERRIDE CODES</b>		<b>PARAMETER IDENTIFIER</b>	
SEE TABLE 7-9	63,64	SEE PROGRAMMING	34
<b>NON ENTRY PERIOD</b>		<b>PARITY</b>	
SEE TABLE 7-16	70	SEE RS-232 PORT SPECIFICATIONS	11
<b>NON-CONTROLLER PERTINENT PARAMETERS</b>		<b>PART NUMBERS</b>	
SEE DETAILED PROGRAMMING DESCRIPTIONS	55	SEE ORDERING INFORMATION	21
SEE TABLE 7-5	55	SEE TABLE 4-1	21
<b>NOT ON NETWORK TRIGGER DIGIT</b>		SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	21
SEE TABLE 7-16	70	<b>PASSWORD ACTION DIGITS</b>	
<b>NOTES ON DATA ENTRY</b>		SEE TABLE 7-7	61
SEE PROGRAMMING	34	<b>PASSWORD ENTRIES</b>	
<b>NOTES ON ORDER OF PASSWORD PROGRAMMING</b>		MEMORY SPACE	76
SEE PROGRAMMING	35	<b>PASSWORD FORMAT</b>	
<b>NPA</b>		SEE FIGURE 7-4	59
SEE AREA CODE/OFFICE CODE/CALL SEARCHING	6	<b>PASSWORD PROGRAMMING</b>	
SEE GLOSSARY OF TERMS	B-1	PASSWORD PROGRAMMING EXAMPLES	62
<b>NUMBER OF NULLS FOR CDR</b>		SEE DETAILED PROGRAMMING DESCRIPTIONS	43,59
SEE SYSTEM PARAMETERS	48	<b>PASSWORD PROGRAMMING EXAMPLES</b>	
<b>NXX</b>		EXAMPLE 1	62
SEE AREA CODE/OFFICE CODE/CALL SEARCHING	6	EXAMPLE 2	62
SEE GLOSSARY OF TERMS	B-4	EXAMPLE 3	62
<b>NXX NUMBERS</b>		SEE PASSWORD PROGRAMMING	62
SEE GLOSSARY OF TERMS	B-4	<b>PASSWORD PROTECTION</b>	
<b>OCC</b>		SEE CONTROLLER DESCRIPTION	3
SEE AREA CODE/OFFICE CODE/CALL SEARCHING	6	<b>PASSWORD TABLE DESCRIPTIONS</b>	
SEE GLOSSARY OF TERMS	B-4	SEE TABLE 7-6	61
<b>OCC AREA CODE</b>		<b>PASSWORD TYPE</b>	
SEE SYSTEM PARAMETERS	46	SEE SECURITY	23
SEE TABLE 7-2	44	<b>PASSWORD VERIFICATION</b>	
<b>OCC AUTHORIZATION NUMBER</b>		SEE DETAILED OPERATING DESCRIPTION	27
SEE TABLE 7-16	70	<b>PASSWORDS</b>	
<b>OCC TELEPHONE NUMBER</b>		SEE DETAILED OPERATING DESCRIPTIONS	26
SEE TABLE 7-16	70	SEE SECURITY	23
<b>OFF PREMISE EXTENSION (OPX)</b>		<b>PBX</b>	
SEE GLOSSARY OF TERMS	B-3	SEE GLOSSARY OF TERMS	B-4
<b>OFF-HOOK CURRENT</b>		<b>POWER</b>	
SEE HARDWARE SPECIFICATIONS	9	SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	11
<b>OFFICE CODE (NNX)</b>		<b>POWER DOWN CUT THROUGH MODE</b>	
SEE GLOSSARY OF TERMS	B-4	SEE SYSTEM POWER	5
<b>ON-HOOK RECOGNITION TIME</b>		<b>POWER OUTAGE</b>	
SEE NON-CONTROLLER PERTINENT PARAMETERS	57	SEE SYSTEM POWER	5
SEE TABLE 7-5	55	<b>POWER RECEPTACLE RECOMMENDATIONS</b>	
<b>OPEN CIRCUIT VOLTAGE</b>		SEE POWER REQUIREMENTS	16
SEE HARDWARE SPECIFICATIONS	9	<b>POWER REQUIREMENTS</b>	
<b>OPERATING DESCRIPTION</b>		SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	16
DETAILED OPERATING DESCRIPTION	25	<b>PRINTER CONNECTION</b>	
OPERATIONAL SEQUENCES	23	SEE RS-232 PORT CONFIGURATION	20
SECURITY	23	<b>PRIVATE AUTOMATIC BRANCH EXCHANGE (PBX)</b>	
<b>OPERATING RANGE</b>		SEE GLOSSARY OF TERMS	B-4
SEE HARDWARE SPECIFICATIONS	10	<b>PRIVATE BRANCH EXCHANGE</b>	
<b>OPERATIONAL PARAMETERS</b>		SEE GLOSSARY OF TERMS	B-4
SEE DETAILED PROGRAMMING DESCRIPTIONS	42	<b>PROGRAM ACCESS CODES</b>	
<b>OPERATIONAL SEQUENCES</b>		SEE INITIALIZATION	29
		<b>PROGRAM VERIFICATION</b>	
		USER ENTERED CALLBACK OPERATION	41

CONTENTS	PAGE	CONTENTS	PAGE
<b>PROGRAMMING</b>		<b>SEE NON-CONTROLLER PERTINENT PARAMETERS</b>	58
CONTROLLER MEMORY CAPACITY	75	SEE TABLE 7-5	56
DETAILED PROGRAMMING DESCRIPTIONS	42	<b>ROTARY RECEIVER</b>	
DTMF CUT THROUGH ACCESS	42	SEE HARDWARE SPECIFICATIONS	10
FOR USER ENTERED CALLBACK NUMBER	39	<b>ROTARY SENDER</b>	
INTRODUCTION	33	SEE HARDWARE SPECIFICATIONS	10
NOTES ON ORDER OF PASSWORD PROGRAMMING	35	<b>ROUTE RELATED PARAMETERS</b>	
PROGRAMMING FOR CALLBACK OPERATION	34	SEE DETAILED PROGRAMMING DESCRIPTIONS	43
SEE VERSATILE PROGRAMMING	7	<b>ROUTE TO MONITOR</b>	
TESTING CONTROLLER INSTALLATION	37	SEE SYSTEM PARAMETERS	49
<b>PROGRAMMING EXAMPLES</b>		SEE TABLE 7-3	48
SEE PROGRAMMING ROUTING PARAMETERS	69	<b>ROUTING</b>	
SEE SEARCH TABLE PROGRAMMING	66	SEE LINES/MODELS	5
<b>PROGRAMMING FOR CALLBACK OPERATION</b>		<b>RS-232 BAUD RATE</b>	
PROCEDURAL STEPS	35	SEE SYSTEM PARAMETERS	48
SEE PROGRAMMING	34	SEE TABLE 7-3	47
<b>PROGRAMMING ROUTING PARAMETERS</b>		<b>RS-232 CONNECTOR</b>	
6R5 ACCESS ROUTE	67	SEE RS-232 PORT CONFIGURATION	20
ACCESS CONTROL SEQUENCES	67	<b>RS-232 PORT</b>	
PROGRAMMING EXAMPLES	69	SEE CALL RECORDING/RS-232 PORT	6
SEE DETAILED PROGRAMMING DESCRIPTIONS	67	<b>RS-232 PORT CONFIGURATION</b>	
<b>PROGRAMMING TIMEOUT</b>		SEE CONNECTIONS	20
SEE INITIALIZATION PROCEDURE	31	<b>RS-232 PORT SPECIFICATIONS</b>	
<b>PROGRAMMING TRUNKS</b>		SEE SPECIFICATIONS	12
SEE TRUNK RELATED PARAMETERS	50	SEE TABLE 3-2	
<b>PROGRAMMING USER ENTERED CALLBACK</b>		<b>r50t</b>	
PROGRAM VERIFICATION	41	SEE TABLE 7-16	70
SEE PROGRAMMING	39	<b>r55t</b>	
<b>PROGRESS TONES</b>		SEE TABLE 7-16	70
SEE DETAILED OPERATING DESCRIPTIONS	25	<b>r56t</b>	
SEE OPERATIONAL SEQUENCES	23	SEE NON ENTRY PERIOD	70
SEE SECURITY	23	<b>r57t</b>	
SEE TABLE 7-4	51, 52	SEE LENGTH OF NON ENTRY	70
SEE TRUNK RELATED PARAMETERS	54	<b>r58t</b>	
<b>RAM</b>		SEE CALL FAILURE ACTION	70
SEE CONTROLLER MEMORY CAPACITY	75	<b>SEARCH TABLE DEFAULTS</b>	
SEE GLOSSARY OF TERMS	B-4	SEE SEARCH TABLE PROGRAMMING	66
<b>RE-INITIALIZATION</b>		<b>SEARCH TABLE DESCRIPTIONS</b>	
SEE INITIALIZATION	29	SEE TABLE 7-10	65
<b>RE-ORDER TONE</b>		<b>SEARCH TABLE ENTRIES</b>	
SEE SYSTEM PARAMETERS	48	MEMORY SPACE	6
SEE TABLE 7-3	47	<b>SEARCH TABLE PROGRAMMING</b>	
<b>READER COMMENTS</b>		ACTION DIGIT DEFINITIONS	44
SEE INTRODUCTION	2	PROGRAMMING EXAMPLES	66
<b>REASONS FOR INITIALIZATION</b>		SEARCH TABLE DEFAULTS	65
SEE INITIALIZATION	29	SEE DETAILED PROGRAMMING DESCRIPTIONS	64
<b>RECEIVING</b>		<b>SEARCH TABLES</b>	
SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	13	SEE DETAILED PROGRAMMING DESCRIPTIONS	43
<b>RECOGNITION TIME, TIP TO GND</b>		SEE LINES/MODELS	5
SEE HARDWARE SPECIFICATIONS	9	<b>SECURITY</b>	
<b>REPACKING</b>		SEE CONTROLLER DESCRIPTION	23
SEE SHIPPING AND RECEIVING	13	SEE OPERATING DESCRIPTION	23
<b>REPAIRED UNIT</b>		<b>SELECT DEFAULT ROUTE</b>	
SEE INITIALIZATION	29	SEE NON-CONTROLLER PERTINENT PARAMETERS	58
<b>REQUIREMENTS PRIOR TO INITIALIZATION</b>		SEE TABLE 7-5	56
SEE INITIALIZATION	29	<b>SENSING RESISTANCE</b>	
<b>RESERVE POWER</b>		SEE HARDWARE SPECIFICATIONS	9
SEE GLOSSARY OF TERMS	B-4	<b>SEQUENTIAL ACCESS</b>	
<b>RETURN LOSS</b>		SEE GLOSSARY OF TERMS	B-4
SEE HARDWARE SPECIFICATIONS	9	<b>SHIPPING</b>	
<b>RINGER EQUIVALENCE NUMBER</b>		SEE UNPACKING, INSTALLATION AND ORDERING INFORMATION	13
SEE APPENDIX A	A-1	<b>SHIPPING AND RECEIVING</b>	
<b>RINGER IMPEDANCE</b>		REPACKING	13
SEE HARDWARE SPECIFICATIONS	9	UNPACKING	13
<b>RINGING SENSITIVITY</b>		<b>SHORT CIRCUIT CURRENT</b>	
SEE HARDWARE SPECIFICATIONS	9	SEE HARDWARE SPECIFICATIONS	9
<b>RJ31X/CA31A USOC JACK AND CABLE</b>		<b>SIMPLIFIED ELECTRICAL DIAGRAM</b>	
SEE CONNECTIONS	20	SEE FIGURE C-2	40
<b>ROM</b>		<b>SINGLE UNIT PACKAGE</b>	
SEE GLOSSARY OF TERMS	B-4	SEE SHIPPING AND RECEIVING	13
<b>ROTARY DIAL</b>		<b>SMART-1 FORMAT</b>	
SEE GLOSSARY OF TERMS	B-4	EXAMPLES	72
<b>ROTARY DIALING RATE</b>		SEE CALL DETAIL RECORD FORMAT	71
SEE TABLE 7-4	50	<b>SMART-1 SIMPLIFIED ELECTRICAL DIAGRAM</b>	
SEE TRUNK RELATED PARAMETERS	52	SEE APPENDIX C	C-1
<b>ROTARY INTER-DIGIT PAUSE</b>		SEE FIGURE C-2	40

**SECTION MITL8350-048-100-NA**

CONTENTS	PAGE	CONTENTS	PAGE
SMarT-1 SYSTEM BLOCK DIAGRAM		SEE TRUNK RELATED PARAMETERS	54
SEE APPENDIX C	C-1	TIP & RING	
SEE FIGURE C-1	4	SEE GLOSSARY OF TERMS	B-5
SOFTWARE		TIP GROUND APPLICATION TIMER	
SEE GLOSSARY OF TERMS	B-4	SEE NON-CONTROLLER PERTINENT PARAMETERS	58
SPECIAL PARAMETERS		SEE TABLE 7-5	56
SEE DETAILED PROGRAMMING DESCRIPTIONS	42	TIP GROUND REMOVAL TIMER	
SPECIFICATIONS		SEE NON-CONTROLLER PERTINENT PARAMETERS	58
ELECTRICAL/MECHANICAL SPECIFICATIONS	11	SEE TABLE 7-5	57
HARDWARE SPECIFICATIONS	9	TIP GROUND TIMER	
RS-232 PORT	11	SEE NON-CONTROLLER PERTINENT PARAMETERS	57
SPEED CALL PROGRAMMING		SEE TABLE 7-5	56
SEE AUTOMATIC CALLBACK PROGRAMMING	63	TOLL OFFICE	
SPEED CALLING		SEE GLOSSARY OF TERMS	B-5
SEE GLOSSARY OF TERMS	B-4	TROUBLE CORRECTIONS	
SPEED CALLS		SEE APPENDIX A	A-2
MEMORY SPACE	77	TRUNK	
SPEED DIALING		SEE GLOSSARY OF TERMS	B-5
SEE GLOSSARY OF TERMS	B-5	TRUNK RELATED PARAMETERS	
SPEEDCALLS		SEE DETAILED PROGRAMMING DESCRIPTIONS	42
SEE DETAILED PROGRAMMING DESCRIPTIONS	43	SEE DETAILED PROGRAMMING DESCRIPTIONS	49
STATIC		SEE TABLE 7-4	50
SEE GLOSSARY OF TERMS	B-5	SEE TRUNK RELATED PARAMETERS	52
STRING ENTRIES		TRUNK TO MONITOR FOR CDR	
MEMORY SPACE	76	SEE SYSTEM PARAMETERS	48
SUITABLE TERMINAL		SEE TABLE 7-3	47
SEE INITIALIZATION	29	TYPE OF CENTRAL OFFICE	
SWITCHING SYSTEM		SEE TABLE 7-4	50
SEE GLOSSARY OF TERMS	B-5	SEE TRUNK RELATED PARAMETERS	52
SYSTEM BLOCK DIAGRAM		TYPE OF UNIT	
SEE FIGURE C-1	4	SEE APPENDIX A	A-1
SYSTEM MAINTENANCE		TYPES OF CO LINES	
SEE MAINTENANCE AND TROUBLESHOOTING	83	SEE NETWORK COMPATIBILITY	5
SYSTEM PARAMETERS		TYPES OF DIALING	
SEE DETAILED PROGRAMMING DESCRIPTIONS	42,43	SEE NETWORK COMPATIBILITY	5
SEE TABLE 7-2	43	UNAUTHORIZED ACCESS	
SYSTEM POWER		SEE CONTROLLER DESCRIPTION	5
SEE CONTROLLER DESCRIPTION	5	UNIT STORAGE	
SYSTEM TROUBLESHOOTING		SEE INITIALIZATION	29
SEE MAINTENANCE AND TROUBLESHOOTING	83	UNPACKING	
SYSTEM WIDE OPERATION PARAMETERS		SEE SHIPPING AND RECEIVING	13
SEE TABLE 7-3	47,48	UNPACKING PROCEDURE	
TECHNICAL CIRCUIT DESCRIPTION		SEE UNPACKING	13
INTRODUCTION	81	UNPACKING, INSTALLATION AND ORDERING INFORMATION	
TEMPERATURE		CONNECTIONS	16
SEE HARDWARE SPECIFICATIONS	10	INSTALLATION REQUIREMENTS	13
TERMINAL ACCESS CODE		MOUNTING	16
SEE PROGRAMMING FOR CALLBACK OPERATION	35	ORDERING INFORMATION	21
TERMINAL CONNECTION		POWER REQUIREMENTS	16
SEE RS-232 PORT CONFIGURATION	20	SHIPPING AND RECEIVING	13
TERMINAL DISPLAY USER ENTERED CALLBACK PROGRAMMING		USER ENTERED CALLBACK ACCESS	
SEE FIGURE 7-3	42	SEE DETAILED OPERATING DESCRIPTIONS	26
TERMINAL PROGRAM SECURITY CODE		SEE OPERATIONAL SEQUENCES	24
SEE TABLE 7-2	44	USER ENTERED CALLBACK PROGRAMMING	
TERMINAL PROMPT		TERMINAL DISPLAY	42
SEE DOCUMENT CONVENTIONS	2	VERSATILE PROGRAMMING	
SEE NOTES ON DATA ENTRY	35	DESCRIPTION	6
TERMINAL SECURITY PROGRAM CODE		INITIALIZATION	6
SEE SYSTEM PARAMETERS	46	PROGRAMMING	7
TERMINATION		SEE GENERAL DESCRIPTION	6
SEE HARDWARE SPECIFICATIONS	9	VOICE FREQUENCY	
TERMINATOR		SEE GLOSSARY OF TERMS	B-5
SEE NOTES ON DATA ENTRY	35	WAIT FOR PASSWORD TIMER	
TESTING CONTROLLER INSTALLATION		SEE TABLE 7-4	51
ACTUAL TESTING	38	SEE TRUNK RELATED PARAMETERS	53
MODEM SETUP	37	WALL MOUNTING BRACKET	
SEE PROGRAMMING	37	SEE MOUNTING	16
THEORY OF TEST	37	WATS	
THEORY OF TEST		SEE GLOSSARY OF TERMS	B-5
SEE TESTING CONTROLLER INSTALLATION	37	WEIGHT	
TIE TRUNK		SEE ELECTRICAL/MECHANICAL SPECIFICATIONS	11
SEE GLOSSARY OF TERMS	B-5	WIDE AREA TELEPHONE SERVICE (WATS)	
TIME-OF-DAY CODES			
SEE TABLE 7-8	61		
TIMER BEFORE PROCESSING CALLBACK			
SEE TABLE 7-4	52		

CONTENTS	PAGE
SEE GLOSSARY OF TERMS	B-5
x00t	
SEE TABLE 7-4	50
SEE TYPE OF CENTRAL OFFICE	52
x01t	
SEE ROTARY DIALING RATE	52
SEE TABLE 7-4	50
x02t	
SEE DTMF DIALING RATE	52
SEE TABLE 7-4	50
x03t	
SEE ON-HOOK RECOGNITION TIME	57
SEE TABLE 7-5	55
x04t	
SEE FLASH ALLOWED TIME	57
SEE TABLE 7-5	55
x05t	
SEE LINE DROP/RESEIZURE TIME	52
SEE TABLE 7-4	50
x06t	
SEE GROUND START TRIES NUMBER	57
SEE TABLE 7-5	55
x07t	
SEE TABLE 7-5	56
SEE TIP GROUND TIMER	57
x14t	
SEE ROTARY INTER-DIGIT PULSE	58
SEE TABLE 7-5	56
x20t	
SEE INCOMING RINGING SENSITIVITY	58
SEE TABLE 7-5	56
x21t	
SEE INTER-RING TIMER	58
SEE TABLE 7-5	56
x24t	
SEE SELECT DEFAULT ROUTE	58
SEE TABLE 7-5	56
x27t	
SEE CALL ANSWER TIMER	52
SEE TABLE 7-4	51
x28t	
SEE TABLE 7-4	51
SEE WAIT FOR PASSWORD TIMER	53
x29t	
SEE LOCKOUT TIMER	53
SEE TABLE 7-4	51
x31t	
SEE TABLE 7-5	56
SEE TIP GROUND APPLICATION TIMER	58
x33t	
SEE HIT TIMING	58
SEE TABLE 7-5	56
x34t	
SEE PROGRESS TONES	54
SEE TABLE 7-5	57
SEE TIP GROUND REMOVAL TIMER	58
x35t	
SEE TABLE 7-4	51
SEE TABLE 7-4	52
x36t	
SEE TABLE 7-4	52
SEE TIMER BEFORE PROCESSING CALLBACK	54
001t	
SEE RE-ORDER TONE	48

CONTENTS	PAGE
SEE TABLE 7-3	47
005t	
SEE TABLE 7-3	47
SEE TRUNK TO MONITOR FOR CDR	48
006t	
SEE RS-232 BAUD RATE	48
SEE TABLE 7-3	47
007t	
SEE NUMBER OF MILLS FOR CDR	48
SEE TABLE 7-3	47
009t	
SEE CDR PRINT FORMAT	48
SEE TABLE 7-3	48
010t	
SEE ROUTE TO MONITOR	49
SEE TABLE 7-3	48
601	
SEE AREA CODE OF OCC	46
SEE TABLE 7-2	44
602	
SEE MACHINE IDENTIFIER FOR CDR	46
SEE PROCEDURAL STEPS	46
SEE TABLE 7-2	44
604	
SEE TABLE 7-2	44
SEE TERMINAL PROGRAM SECURITY CODE	46
6R5 ACCESS ROUTE	
SEE PROGRAMMING ROUTING PARAMETERS	67
6R5 PARAMETER CODES	
SEE TABLE 7-12	67,68
6r1	
SEE TABLE 7-16	70
6r2	
SEE TABLE 7-16	70
6r4	
SEE TABLE 7-16	70
7345	
SEE PROCEDURAL STEPS	36
825	
SEE PROCEDURAL STEPS	36
902	
SEE ENTER DATA CONFIRMATION MODE	45
SEE TABLE 7-2	44
907	
SEE EXIT DATA CONFIRMATION MODE	45
SEE TABLE 7-2	44
942903	
SEE LOAD FACTORY DEFAULT DATABASE	45
SEE TABLE 7-2	44
942904	
SEE DELETE ALL SEARCH TABLE ENTRIES	45
SEE TABLE 7-2	44
980	
SEE ENTER DATE AND TIME	45
SEE PROCEDURAL STEPS	36
SEE TABLE 7-2	44
999	
SEE EXIT PROGRAM MODE	44
SEE TABLE 7-2	44

NOTES

---



MITEL DATACOM INC.  
P.O. BOX 17266  
DULLES INTERNATIONAL AIRPORT  
WASHINGTON, D.C., U.S.A., 20041  
TELEPHONE: (703)-661-6600



SUPPLEMENT TO  
GENERAL INFORMATION MANUAL

**smart-1™**

EXPANDED MEMORY UNIT  
COMMON CARRIER ACCESS DIALER  
AND CALL CONTROLLER  
GENERAL INFORMATION



**MITEL®**

© - Copyright of MITEL DATACOM INC. 1985  
™ - Trademark of MITEL DATACOM INC.  
® - Registered Trademark of MITEL CORPORATION

SECTION MITL8350-101-100-NA

---

--- THIS PAGE INTENTIONALLY LEFT BLANK ---



**NOTICE TO U.S. CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The SMarT-1™ Common Carrier Access and Call Controller generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures may be required to correct the interference.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**NOTICE TO CANADIAN CUSTOMERS**

The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates or subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

**WARNING**

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The Department does not guarantee that the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground connections to the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**CAUTION**

Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as required.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load, to be connected to a telephone loop, that is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the Load Numbers of all of the devices doesn't exceed 100. An alphabetic suffix is also specified in the Load Number and designates the appropriate ringing type (A or B), if applicable. For example, LN = 20 A designates a Load Number of 20 and an 'A' type ringer.

--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**IMPORTANT NOTES**

Please note that MITEL DATACOM INC. has set up a National Field Service number for technical and installation assistance located in Dallas, Texas. This number is [214] 386-9400 for U.S. customers only (outside of normal working hours, a telephone answering service has been established for your convenience at this same number). For Canadian customers, please contact your local MITEL Regional Office.

The SMarT-1™ Dialer includes an on-board battery back-up system to prevent the loss of customer database. Besides protecting against loss of data during momentary power outages, this battery back-up should also provide sufficient memory retention to allow the Dialer to be programmed by the distributor and then transported to the customer's site for installation. This battery back-up, however, is not intended for long storage periods and cannot be guaranteed to support memory for long periods of time.

As received from the factory, the Dialer battery is not guaranteed to have a full charge applied to it. In fact, the battery is likely to be only partially charged in view of the time in transit, and distributor storage time. No guarantee of any battery charge status can be made until the Dialer has been powered up for a period of time. A period of 24 hours is necessary to achieve a full charge on the battery.

Upon removal from its shipping carton, the Dialer should be powered up for a period of time and then "✕ INITIALIZED" to load the operating system and default database into memory. Initialization may only be performed with a DTMF telephone set and requires connection to a working telephone line or an acceptable substitute. Never rely on programming entered into a Dialer until it has been "✕ INITIALIZED" (see Page 4, para. 4.03). Note that there is a short tone burst heard in the earpiece of the phone upon initialization. This tone indicates a successful initialize sequence has occurred.

Once initialized, the Dialer should seldom ever have to be initialized again. There is a Load Default Data Command that will restore memory to the initialized state once a "✕ INITIALIZE" has been performed. Once initialized, the Dialer will also respond to input via the RS-232 Input.

**REASONS FOR ADDITIONAL "✕ INITIALIZE" OPERATIONS**

Dialer has just been removed from storage or shipping carton.

No toneburst upon release of the ✕ Key. Maybe the tone was missed - check carefully.

The program access codes have been deleted accidentally or the access codes have been changed and forgotten.

The Dialer has just been repaired.

Long storage times.

Loss of data retention. Investigate for reason!


--- THIS PAGE INTENTIONALLY LEFT BLANK ---

**SMART-1™****COMMON CARRIER ACCESS DIALER AND CALL CONTROLLER****GENERAL INFORMATION**

CONTENTS	PAGE
1. INTRODUCTION .....	1
GENERAL .....	1
OVERVIEW OF THIS MANUAL .....	1
INTENDED AUDIENCE .....	1
HISTORY .....	2
2. GENERAL DESCRIPTION .....	2
3. INSTALLATION .....	3
4. OPERATION .....	3
GENERAL .....	3
INITIALIZING THE DIALER .....	4
ENTERING SPEED CALLS .....	5
SPECIFIC DEFAULTS .....	7
903 Default Command - Standard O.C.C. Dialer .....	7
909 Default Command - Speed Dialer Mode .....	7
Specific 909 Command Defaults .....	8
DEFAULT COMPARISON .....	9
5. PROGRAMMING EXAMPLES AND USE .....	11
"909" SOPHISTICATED SPEED DIALER PROGRAMMING .....	11
#0*SYSTEM PROGRAM ACCESS .....	11
USER PROGRAMMING OF SPEED CALLS .....	12
"903" STANDARD O.C.C. DIALER PROGRAMMING .....	12
DIALING SPEED CALLS .....	13
6. SPEED CALL VERSUS SCREENING CAPABILITIES .....	13
Ground Rules .....	13
Methods .....	13
Calculation Examples .....	15
7. SPECIFICATIONS .....	17
HARDWARE .....	17
RS-232 PORT .....	19
ELECTRICAL/MECHANICAL .....	19
APPENDIX A .....	1
FCC INTERCONNECTION REQUIREMENTS .....	1
General .....	1

CONTENTS	PAGE
CONNECTION LIMITATIONS .....	1
NETWORK CHANGES .....	1
MAINTENANCE LIMITATIONS .....	1
TROUBLE CORRECTIONS .....	2
DISCONNECTION .....	2
APPENDIX B .....	1
OVERALL INDEX .....	1
FIGURES	PAGE
1: SMarT-1™ EXPANDED MEMORY UNIT .....	1
2: TYPICAL 800 RESALE SERVICE INSTALLATION .....	3
3: CALCULATION WORKSHEET .....	16
TABLES	PAGE
1: SPEED CALL ENTRIES .....	5,6
2: SPECIAL FUNCTIONS AND COMMANDS .....	7
3: SPECIFIC 909 DEFAULTS .....	9
4: COMPARISON OF 903 VERSUS 909 DEFAULTS .....	10,11
5: SPEED CALLS (With no Search Tables present) .....	14
6: SEARCH TABLE SCREENS (with no Speed Calls present) ..	15
7: SMarT-1™ SPECIFICATIONS .....	17,18
8: RS-232 PORT SPECIFICATIONS .....	19
9: ELECTRICAL/MECHANICAL SPECIFICATIONS .....	19





**FIGURE 1: SMarT-1™ EXPANDED MEMORY UNIT**

## 1. INTRODUCTION

### GENERAL

**1.01** This document contains all information that relates to the SMarT-1™ Expanded Memory Unit Common Carrier Access Dialer and Call Controller. This particular section (Section 1) is an overview of the contents of the document and outlines the intended audience.

**1.02** From this point forward, the SMarT-1™ Common Carrier Access Dialer and Call Controller will be referred to in text as the 'Dialer'.

### OVERVIEW OF THIS MANUAL

**1.03** The manual consists of seven sections and two appendices. Sections one through four provide both general and detailed descriptions of the Dialer features and functions while section five provides detailed program data entry information. Sections six and seven provide engineering information and the appendices provide additional information that may be of general use to the reader.

### INTENDED AUDIENCE

**1.04** This document is intended for use as a general reference document for the installer and user of the SMarT-1™ and SMarT-1A™ Expanded Memory Unit Common Carrier Access and Call Controller.

## HISTORY

**1.05** This is the first issue of the SMarT-1™ Expanded Memory Unit Common Carrier Access Dialer and Call Controller General Information Manual. The reason for issue was to supplement the General Information Manual with the Expanded Memory Unit and includes requirements of the present software level (Generics 11 and 21, Rev. 07 and later) of the Dialer.


## 2. GENERAL DESCRIPTION

**2.01** The SMarT-1™ Expanded Memory Unit Common Carrier Access Dialer and Call Controller is a self-contained electronics unit that provides all functions of the standard SMarT-1™ Dialer plus four times the amount of memory. The standard 2K of RAM Memory has been expanded to 8K. It also has the capability to assume the function of a sophisticated speed dialer for applications such as 800 Service Resale, special DISA, or 1-800 service.

**2.02** The SMarT-1™ Expanded Memory Unit Dialer provides the following features and functions:

- FCC Parts 15 and 68 compliance
- Four Line capability for the SMarT-1™ unit (MITEL P/N 8350-654)
- Two Line capability for the SMarT-1A™ unit (MITEL P/N 8350-652)
- SMDR Output
- Versatile programming
- Automatic Route Selection (ARS)
- Up to 1,000 Speed Calls, depending on length of Speed Call
  - Installer-programmable
  - Customer-programmable
- Tone to Pulse conversion
- Pulse to Tone conversion
- Each Speed Dial entry may contain its own unique account code
- SMDR indication of Speed Call and its related account code number
- In addition, the unit has the following convenience features:
  - Useable with CENTREX Lines
  - Useable behind a PBX/PABX
  - Hot Line operation
  - Multi-Tenant service.

**2.03** Instead of operating in the dedicated Speed Dialer mode, the operational mode can be programmed to assume that of the



**FIGURE 2: TYPICAL 800 RESALE SERVICE INSTALLATION**

standard O.C.C. Dialer, but with four times the memory capability.

**2.04** If the unit is used in the dedicated Speed Dialer mode, the unit dial-out is defaulted as follows:

- 1) Dial digit 1 (Parameter 6r4 – may be changed if needed)
- 2) Pause.
- 3) Dial seven digit Destination Number.
- 4) Detect dialtone.
- 5) Dial seven digit Account Code, if programmed.

### 3. INSTALLATION

**3.01** Refer to the General Information Manual (MITEL P/N 8350-047-100-NA) for unpacking, mounting and connection details.

### 4. OPERATION

#### GENERAL

**4.01** The following descriptions outline typical operating modes for the SMarT-1™ Dialer with Expanded Memory. These operating modes are unique to this unit. Except as noted below, the General Information Manual applies in its entirety.

**4.02** The Expanded Memory Unit may be programmed for either of two modes of operation. These are; a) an 800 Service Resale Dialer with an account code associated with each speed dial, or b) as a

standard O.C.C. Dialer with enhanced search table quantity capabilities and capable of up to 1,000 speed calls (still with an account code associated with each speed dial, if desired).

#### INITIALIZING THE DIALER

**4.03** The Dialer is initialized in the same manner as the standard SMarT-1™ Dialer with the exception of the default command to be given upon initialization completion. The procedure for initialization listed below is repeated from the General Information Manual to reduce cross referencing and to include the default command upon completion of initialization.

- 1) Connect an earth ground to the Dialer.
- 2) Connect a DTMF telephone or butt set to the subscriber side Tip & Ring leads of the Dialer.
- 3) Connect a standard telephone line or network to the C.O. side of the Dialer.
- 4) With the power to the Dialer disconnected, go off-hook.
- 5) While holding down the \* key on the DTMF set, connect the power to the Dialer. A DTMF tone should be audible in the handset receiver.
- 6) Continue to hold the \* key for 10 seconds or more after applying power to the Dialer.
- 7) Release the \* key. The unit should respond immediately with a short tone from the handset receiver. If the tone is not heard, return to step 1 above and start over. The tone burst indicates that the Dialer is initialized and defaulted to its "standard" configuration. It also indicates that it is in the programming mode and awaiting a command.

**Note:** If the Dialer is to be used as an 800 Service Resale Dialer, the user need not be concerned with further programming other than referenced for this use below. If the Dialer is to be used as a standard O.C.C. Dialer, then programming may be accomplished by the use of any of the methods listed in the General Information Manual, Section 5.

**4.04** Once the above listed procedure has been completed, the user has two options available. These are:

- 1) **GO ON-HOOK:** The Dialer is defaulted as a standard O.C.C. Dialer as noted in the General Information Manual. The only difference is that it is capable of up to 1,000 Speed Calls (with account codes). All of the programming information in the General Information Manual applies to the Dialer in this configuration. This configuration will also be assumed if a '903' command is issued in the Program Mode.
- 2) **DIAL '909' ON THE DTMF SET:** This action defaults the Dialer to the Speed Dialer Mode (800 Service Resale Dialer with account

code associated with each Speed Call).

#### ENTERING SPEED CALLS

4.05 Once the Dialer has been initialized by using the procedure listed above, Speed Calls may be entered by using the procedure below:

- 1) Dial in Speed Calls in the format:

**7nnn dk mm . . . mm \* (if used), mm . . . mm ##**

Table 1 below lists digits required for Speed Call entries. 'nnn' is the number of the entry, while 'd' is the key that is used to determine which trunk or trunks have access to the particular speed call number. 'k' is a Network override and is used to select the allowed routing for the particular speed call number. 'mmmmmm' is the phone number to be dialed. If a \* is used in the Speed Call entry, an account code must be entered following the \*. The Speed Call entry is terminated by using '##'.

**TABLE 1: SPEED CALL ENTRIES**

FIRST DIGIT = 7    SPEED CALL																																	
DIAL	DEFINITION																																
<p>7nnndkmm...mm## or 7nnndkmm..mm*mm..mm##</p>	<p>Speed call entry where: nnn is the number of the speed call entry. d is the key that selects the trunks to access the call number as follows:</p> <table style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;"><u>DIGIT</u></th> <th style="text-align: center;"><u>ALLOWED TRUNKS</u></th> </tr> </thead> <tbody> <tr><td style="text-align: center;">0</td><td>ALL</td></tr> <tr><td style="text-align: center;">1</td><td>TRUNK 1</td></tr> <tr><td style="text-align: center;">2</td><td>TRUNK 2</td></tr> <tr><td style="text-align: center;">3</td><td>TRUNKS 1,2</td></tr> <tr><td style="text-align: center;">4</td><td>TRUNK 3</td></tr> <tr><td style="text-align: center;">5</td><td>TRUNKS 1,3</td></tr> <tr><td style="text-align: center;">6</td><td>TRUNKS 2,3</td></tr> <tr><td style="text-align: center;">7</td><td>TRUNKS 1,2,3</td></tr> <tr><td style="text-align: center;">8</td><td>TRUNK 4</td></tr> <tr><td style="text-align: center;">9</td><td>TRUNKS 1,4</td></tr> <tr><td style="text-align: center;">*</td><td>TRUNKS 2,4</td></tr> <tr><td style="text-align: center;">#</td><td>TRUNKS 1,2,4</td></tr> <tr><td style="text-align: center;">C</td><td>TRUNKS 3,4</td></tr> <tr><td style="text-align: center;">D</td><td>TRUNKS 1,3,4</td></tr> <tr><td style="text-align: center;">E</td><td>TRUNKS 2,3,4</td></tr> </tbody> </table>	<u>DIGIT</u>	<u>ALLOWED TRUNKS</u>	0	ALL	1	TRUNK 1	2	TRUNK 2	3	TRUNKS 1,2	4	TRUNK 3	5	TRUNKS 1,3	6	TRUNKS 2,3	7	TRUNKS 1,2,3	8	TRUNK 4	9	TRUNKS 1,4	*	TRUNKS 2,4	#	TRUNKS 1,2,4	C	TRUNKS 3,4	D	TRUNKS 1,3,4	E	TRUNKS 2,3,4
<u>DIGIT</u>	<u>ALLOWED TRUNKS</u>																																
0	ALL																																
1	TRUNK 1																																
2	TRUNK 2																																
3	TRUNKS 1,2																																
4	TRUNK 3																																
5	TRUNKS 1,3																																
6	TRUNKS 2,3																																
7	TRUNKS 1,2,3																																
8	TRUNK 4																																
9	TRUNKS 1,4																																
*	TRUNKS 2,4																																
#	TRUNKS 1,2,4																																
C	TRUNKS 3,4																																
D	TRUNKS 1,3,4																																
E	TRUNKS 2,3,4																																

(Continued on next page)

TABLE 1 Con't: SPEED CALL ENTRIES

FIRST DIGIT = 7 SPEED CALL	
DIAL	DEFINITION
7nnn##	<p><b>NOTE:</b> The C, D, and E entries above may be made from a terminal.</p> <p>k is the network override:</p> <p>0 - 3 Force on Route #0 - #3            4 - 7 Force on Route #0a - 3a            8 Use search table            9 Dial immediate, no Route # (transparent).</p> <p>mmmmmm is the phone number. If a * is entered, the digits after the * are considered to be an account code.</p> <p>## is the end of Speed Call entry.</p> <p><b>NOTE:</b> See Search Table Action '#C' for limited access to Speed Call Programming.</p> <p>Delete speed dial entry nnn.</p>

- 2) After entering all Speed Calls, exit the programming mode by going On-Hook; or by dialing '999' on the DTMF Handset or, if using a terminal, typing an 'X'.
- 3) If it is necessary to re-enter the program mode, the default access codes are the same as those of a standard Dialer. They are: a) #0\* from the DTMF Handset, or b) ### from a user Speed Call entry viewpoint, or c) Carriage Return (<CR>) from a terminal.
- 4) Data confirmation may be accomplished from the programming mode with the use of a terminal. The '902' command will enter the data confirmation mode and allow the reading back of Speed Call entries (or any other parameter). The '907' command is used to exit the data confirmation mode.
- 5) Table 2 below lists System Parameters that are present and contains a description of the programming entries required to invoke special functions. Commands 903, 904, 906, and 908 will affect calls in progress.

TABLE 2: SPECIAL FUNCTIONS AND COMMANDS

FIRST DIGIT = 9	
DIAL	DEFINITION/DESCRIPTION
902	Data confirmation mode: After each three or four digit prefix described above, the Dialer will display the data if programming method 1 is employed, or if using methods 2 or 3, the Dialer will wait for 0.5 seconds, then send the data out on the C.O side in DTMF format. See General Information Manual, Section 5 for a description of programming methods 1, 2, and 3.
903	Load O.C.C. default data - delete all non-default data.
904	Clear all search tables (including defaults, primary and alternate).
906	Enter clone master mode.
907	Return to normal programming mode from data confirmation mode.
908	Enter tandem operation mode (ASCII - DTMF conversion).
909	Default the Dialer to 800 Service Resale mode of operation with an account code associated with each Speed Call.
980mmddhhmm	Set the internal clock where mm = month, dd = day, hh = hours, mm = minutes.
999 (or go on-hook)	Exit programming.

#### SPECIFIC DEFAULTS

**4.06** The paragraphs that follow list specific defaults and values for the Expanded Memory Dialer. Any parameters that are not listed appear in the General Information Manual. They are also the same defaults as for the standard SMarT-1™ Dialer and are identical for either modes of operation of the Expanded Memory Dialer. For more information on these defaults, refer to the General Information Manual, Section 5.

#### 903 Default Command - Standard O.C.C. Dialer

**4.07** All defaults are unchanged from the standard SMarT-1™ unit defaults. Refer to the General Information Manual, Section 5, for a complete listing. Also refer to Table 4 of this manual for Speed Call and Account Code enhancements that are provided in the Expanded Memory unit under the 903 default.

#### 909 Default Command - Speed Dialer Mode

**4.08** In the Speed Dialer Mode, the following defaults are present:

- 1) It is not necessary to enter the '523 8' parameter that commands the Dialer to wait for dialed digits and use the search tables. This parameter is already activated for all trunks.
- 2) The intended and recommended Route for Speed Calls is 'Route

3'. This Route is the least likely to be used route for O.C.C. activity (should it be desired) and allows Route 0 to remain as the default route. If this parameter is used in this manner and it is decided to add call routing capabilities at a later date along with the Speed Call function, it may be programmed as with the standard Dialer without disturbing Speed Call programming.

- 3) The system default Program Access Code is #0\*. The Subscriber (User) Speed Call Program Access Code is ###. All trunks have access to all subscriber entered Speed Calls. These subscriber entered Speed Calls are forced to dial out on Route 3.
- 4) Speed Call triggers are any combination of three digits ranging from '000' to '999' (1,000 possible combinations). As defaulted, no \* or similar prefix need be dialed to trigger a Speed Call. All digits entered (or dialed) are considered as a part of the Speed Call trigger (location) up to a maximum of three digits.
- 5) There are no O.C.C. Search Tables present. The only Search Tables present are those for DTMF Program Access and the Speed Call action.
- 6) The Call Recording output will indicate "S.C." for Speed Call, along with the destination number dialed, and the account code, if entered.
- 7) The Speed Call programming format from the system #0\* access is:

**7nnn dk mm . . . mm##**

(If ## is not entered, interdigit time-out will complete the entry) while the subscriber Speed Call programming format from the ### access is:

**nnn dk mm . . . mm## (or timeout)**

(if ## is not entered, interdigit time-out will complete the entry) where all trunks are allowed access and the Speed Calls are forced out on Route 3 (equivalent to dk=03).

#### **Specific 909 Command Defaults**

**4.09** Table 3 below lists the specific defaults for the 909 Command that causes the unit to act as a sophisticated Speed Dialer (800 Service Resale Dialer). The letter 'x' or 'r' in the code, represents a single user selectable character for entry to select a specific trunk or route number for the parameter. The letter 't' represents a digit for entry. For more information on specific uses of these letters, refer to the specific command description in the General Information Manual, Section 5 and Table 8.



TABLE 3: SPECIFIC 909 DEFAULTS

PARAMETER	DEFAULT/ RECOMMENDED	COMMENTS/INFORMATION
000	(not applicable)	(Use 10 or 100 Speed Calls) <b>IGNORED.</b>
x19t	0	No Beep Tones.
x23t	8	Wait for digits, use Search Tables.
r50t & r70t	0	Any number of digits in destination number.
r58t & r78t	4	Go to reorder on call failure.
602	SMT	Machine identifier (must be programmed in ASCII).
644 & 684	1	Centrex Number for Route 3 (Primary and Alternate).
645 & 685	9 #250 2 #833 5 7	Dial Centrex, Pause, Dial Destination number, Wait for 6 seconds for 400 ms of Precise Dialtone (fail to re-order if not detected), Dial Account code, Cut-through (primary and alternate Route #3).
615, 625, 635, 655, 665, & 675	#803 2 7	These are the remaining Route Access Control Sequences. The default is: Wait for minimum duration of Precise Dialtone, Dial Destination number, Cut-through (unused as defaulted).
803 Search Table	#0 0 * #4 #0 #0 #0 #C #9 #9 #9 #2	Program Access (dialed by user as #0*). Subscriber Speed Call Access (dialed by user as ###). Go to Speed Call Tables (on any 3 dialed digits). All other Search Tables are empty.
620, 630, 660, & 670	-	Route Names are empty.
610 & 650	DDD	Name of Route (Routes #0 and #4).
640 & 680	S.C.	Name of Route (Speed Call, Routes #3 and #7).

**Note:** 602, 610 through 680 programming data entry must be ASCII code.

#### DEFAULT COMPARISON

**4.10** Table 4 is a comparison of the 903 versus the 909 defaults. In these comparisons, the reader will note that there are some enhancements that are possible with the 903 defaults that are not included or possible with the "standard" SMarT-1™ Dialer. Once again, the General Information Manual (MITEL P/N 8350-047-100-NA) is applicable to all parameters and functions for the 903 command, but with the addition of the listed enhanced operation capabilities. Specifically, in the 903 "standard" mode, up to 1,000 Speed Call positions are

now possible. Each Speed Call may now contain its own unique Account Code, if desired.

TABLE 4: COMPARISON OF 903 VERSUS 909 DEFAULTS

903 DEFAULTED	909 DEFAULTED
<p>PARAMETER 000t:                      0 = 10 SPEED CALLS                      1 = 100 SPEED CALLS                      2 = Maximum 1000 possible speed calls (3 digit address)</p> <p><b>NOTE:</b> To use Selection 2, the default 803 Speed Call trigger search table entry must be deleted and replaced in the 804 Table or other table as desired. The recommended Speed Call trigger is: 804 = * #9 #9 #9 #2 (user dialed as *nnn).</p> <p>The number of digits that must be dialed into the Speed Call parameter slot is two or three, depending on 000t above.</p> <p>The Speed Call programming format is: 7nn or 7nnn, followed by dk mm . . . mm ##.</p> <p><b>NOTE:</b> The appropriate Speed Call trigger must be entered in the search tables for 7nnn type entries.</p> <p><b>NOTE:</b> If 000t is set to 0, the programming slot number is still two digits. This must be within the range of 00 through 09. A single-digit Speed Call trigger (i.e., 802 *#9#2) is possible for the Search Tables, but must be programmed in the range of 700 through 709 in the Speed Call slots.</p>	<p>PARAMETER 000t IGNORED                      1,000 Speed Calls maximum consisting of three digit slots numbered from 000 to 999.</p> <p><b>NOTE:</b> The default trigger is: 803 = #9 #9 #9 #2. There is no "*" prefix in this default. If one is added, be sure to delete the present 803 Search Table entry.</p> <p>The number of digits that must be dialed into the Speed Call parameter slot is fixed at three digits. Parameter 000t is not functional.</p> <p>The Speed Call programming format is: 7nnn followed by dk mm . . . mm ##.</p>
<p><b>The following applies to both defaults:</b></p> <p>If a * is entered as a part of the mm . . . mm sequence above, all of the digits placed before the * are entered into the destination buffer. The digits after the * are entered into the account code buffer. The * is not dialed out. It is ignored in the dial-out procedure and only notes the beginning of the account code number.</p> <p>This means that a * may not be a part of a destination number, but if multiple *'s are entered in the Speed Call format, the second and succeeding *'s will be made a part of the account code. They will also appear in the Call Recording output.</p> <p>The * separating the Speed Call and the Account Code may be positioned anywhere in the "mm . . . mm" string, or left out entirely. If it is left out entirely, the entire entry will be considered as a destination number.</p>	

(Continued on next page)

TABLE 4 Con't: COMPARISON OF 903 VERSUS 909 DEFAULTS

903 DEFAULTED	909 DEFAULTED
<p>The maximum length of the field is 30 characters (29 digits and a *). The maximum length of a Speed Call or Account Code field alone within the 30-character limit is 23 digits.</p> <p>In the 903 Mode, the 6r5 Access Control Strings, of course, must be programmed to dial out the Account Codes, if desired.</p> <p>Speed Dialing may be done on any route in either default format. Note that Route #3 is the recommended route for the 909 Speed Dialer Mode.</p>	
<p>The User Speed Call programming access code is ###.</p> <p>There is no change. In other words, all trunks are allowed access and speed calls go to search tables (dk = 08).</p>	<p>The User Speed Call programming access code is ###.</p> <p>Speed Calls are routed to Route #3. All trunks are allowed access (dk = 03).</p>

**Note:** For installations not capable of transmitting the "#" sign to the dialer, the program access may be changed to any desired series of digits via search table programming. Waiting for expiration of the interdigit time-out will automatically complete the entry, thus avoiding the ## terminating entry.

## 5. PROGRAMMING EXAMPLES AND USE

### "909" SOPHISTICATED SPEED DIALER PROGRAMMING

**5.01** The following paragraphs show examples of specific programming for Speed Calls for both the system programming and the User programming viewpoints. It should be noted that the "0" portion of the "03" strings below may be chosen differently, if desired, to allow differing combinations of trunks to have access to the Speed Call (see Table 1 'dk'). The "3" portion of the "03" string, however, should remain "3" each time. This forces all Speed Calls to Route #3. Using other routes may require additional programming (refer to the General Information Manual).

#### #0\* SYSTEM PROGRAM ACCESS

- 1) Go Off-Hook.
- 2) Dial #0\*.
- 3) Wait for the confirming tone.
- 4) Dial 909. This defaults the Dialer to the sophisticated Speed Dialer data base.
- 5) The examples that follow on the next page show entries which will not use Account Codes:



- 4) When programming from the User Program Access Code (###), all Speed Calls programmed are routed through the Search Tables (dk = 08).

### DIALING SPEED CALLS

**5.04** Once the Dialer has been installed and depending upon the type of programming, the user may dial Speed Calls. The method to access Speed Calls differs depending on unit usage. If 909 Default programming was used, there are no special instructions required to dial a Speed Call. Simply dial the three-digit number of the desired Speed Call and all else is transparent to the user. If the unit has been programmed with the 903 Default, there will be a default Speed Call "trigger" character. This trigger exists in the 803 Search Table. If parameter 000t is either 0 or 1 (10 or 100 Speed Calls), the trigger exists in the 803 Search Table and is, by default, \*. If parameter 000t is 2 (1,000 Speed Calls), the trigger in table 803 must be deleted and replaced in table 804, for example (by programming). Once again, it is recommended that the \* character be used as the trigger. In the case of the 903 default, to access a Speed Call (default programming), simply dial \*nn to access a given Speed Call, where 'nn' is from 00-99 for a specific stored Speed Call.

**Note:** For more details, refer to the General Information Manual.

## 6. SPEED CALL VERSUS SCREENING CAPABILITIES

**6.01** There are several ways in which to calculate the maximum quantity of Speed Calls and Screen Quantities capable of being programmed into the Dialer. Since both Speed Call and Search Table screens may be of varying length, depending upon the application, graphs are not practical. Some simple methods of determining the capabilities are possible.

### Ground Rules

**6.02** There are two basic ground rules that are applicable. These are:

- 1) After a 909 default command, there are 15,000 spaces in memory left for data.
- 2) After a 903 default command, there are 14,500 spaces in memory left for data.

### Methods

**6.03** The simplest method used to determine if the intended data base will fit into memory (almost all will), is to calculate the space required by the data. Then compare this space to the space available according to the following formulae:

- 1) A search table entry occupies a number of spaces equal to the length of the template plus the action digit(s). An 804 Search Table entry such as '804 1315 0', for example, is four digits plus

one action digit for a total of five. The "804" is not counted. An entry of 803 #9#9#9#2 is six plus two, for a total of eight.

- 2) A speed call entry occupies a number of spaces equal to the length of the speed call plus 6 (an internal Dialer requirement), and must be rounded up to the next even number if the total is odd. Thus, a Speed Call programmed as "7nn 08 13931212##" requires 14 spaces in memory (8 digits + 6 = 14). The "\*", if used to partition an account code into the Speed Call, counts as one digit. The "##" does not count.
- 3) As long as the total of the Speed Call plus the Search Table entries does not exceed the available space, the intended program will fit into memory. If, by some chance, memory capacity is exceeded, the Dialer will return error tones in the DTMF set (or a question mark if using a terminal), at the point where data is no longer being accepted.

**Note:** Deleting Speed Calls with the 7nnn## command does not reclaim all memory. After the deletion, memory space increases only by the number of digits in the number being removed, and not by the +6 factor that was added to the Speed Call. Therefore, in the rare event that memory space becomes critical, and several numbers are deleted, the offset in memory space regained must be considered. Total memory space is only reclaimed with a default command. Search tables, on the other hand, reclaim all occupied memory space upon deletion.

6.04 Figure 3 on page 16 is a worksheet that has been included to ease the calculations. For those who are less inclined to do the calculations, Tables 5 and 6 below may be helpful. The quantities listed are rounded downward to allow for entry of route names, longer access control sequences, etc., that would seriously complicate calculations. Therefore, the actual calculations on a defaulted Dialer would show slightly higher quantities available than listed.

**TABLE 5: SPEED CALLS (With no Search Tables present)**

QTY.	NUMBER OF DIGITS IN SPEED CALL
1,000	3 through 8 digit Speed Calls
900	9 or 10 digit Speed Calls
800	11 or 12 digit Speed Calls
700	13 or 14 digit Speed Calls
650	15 digit Speed Calls

**Note:** All digit counts include the "\*" account code separator, if used.

**TABLE 6: SEARCH TABLE SCREENS (with no Speed Calls present)**

<b>QTY.</b>	<b>LENGTH OF SCREEN (No Speed Calls Present)</b>
2,900	4 Digit Screens
2,400	5 Digit Screens
1,800	6 Digit Screens
1,600	7 Digit Screens
1,300	10 Digit Screens
1,200	11 Digit Screens
900	15 Digit Screens

**Calculation Examples**

## Example 1

<b>SPEED DIALS PROGRAMMED</b>	<b>QUANTITY SCREEN SPACE REMAINING</b>
100 8-DIGIT	1,600 7-DIGIT SCREENS OR 1,450 8-DIGIT SCREENS OR 1,150 10-DIGIT SCREENS OR 1,000 11-DIGIT SCREENS
1,000 8-DIGIT	90 7-DIGIT SCREENS OR 80 8-DIGIT SCREENS OR 60 10-DIGIT SCREENS OR 55 11-DIGIT SCREENS

SPEED CALLS				SCREENS IN SEARCH TABLES			
(Note 1) LENGTH+6	X	QTY.	SUBTOT.	LENGTH+1	X	QTY.	SUBTOT.
<b>TOTAL SPEED CALL SPACE</b>				<b>TOTAL SCREEN SPACE</b>			

**TOTAL SPEED CALL SPACE + TOTAL SCREEN SPACE MUST BE LESS THAN:  
15,000 FOR 909 DEFAULTED DIALER AND  
14,500 FOR 903 DEFAULTED DIALER.**

**Note 1:** IF LENGTH+6 IS AN ODD NUMBER, ROUND UP TO NEXT EVEN NUMBER.

FIGURE 3: CALCULATION WORKSHEET



## 7. SPECIFICATIONS

## HARDWARE

7.01 Table 7 lists all of the hardware specifications for the SMarT-1™ Common Carrier Access Dialer and Call Controller. These specifications also apply to the SMarT-1A™ unit unless otherwise noted.

TABLE 7: SMarT-1™ HARDWARE SPECIFICATIONS

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>FCC RINGER EQUIVALENCE</b>			0.7B	
<b>IDLE LINE, LOOP START</b>				
RINGER IMPEDANCE: 15-60 Hz, 70-110V	10		20	K $\Omega$
20-3500 Hz, 10V	1			M $\Omega$
RINGING SENSITIVITY: 15-60 Hz	40			Volts
LEAKAGE: Tip to Ring, 100V	20			M $\Omega$
Tip to Earth, 100V	20			M $\Omega$
OFF HOOK CURRENT	15		80	mA
<b>IDLE LINE, GROUND START</b>				
SENSING RESISTANCE: Tip to Earth	36	40	45	K $\Omega$
OPEN CIRCUIT VOLTAGE: Tip	-22	-25	-28	Volts
GROUNDING VOLTAGE	-5	0	+10	Volts
TIME TO RECOGNIZE TIP-GROUND	10		150	ms
RESISTANCE: Sending Ring-Ground		n/a		
<b>BATTERY FEED</b>				
OPEN CIRCUIT VOLTAGE	22	24	26	Volts
FEED RESISTANCE	550	600	650	$\Omega$
BALANCE: DC	36	40		dB
SHORT CIRCUIT CURRENT			50	mA
<b>TERMINATION</b>				
RESISTANCE: DC, 20 mA	200		300	$\Omega$
DC, 40 mA	200		300	$\Omega$
AC, 300-3000 Hz	550	600	650	$\Omega$
RETURN LOSS: 600 ohms, 20mA	20	26		dB
OPERATING CURRENT	13		80	mA

TABLE 7 CONT: SMarT-1™ HARDWARE SPECIFICATIONS

SPECIFICATION	MIN.	TYP.	MAX.	UNITS
<b>DIAL TONE</b>				
CO SIDE FEED: Gain 300 Hz	-2	0	+2	dB
INTERNAL FEED: 350 Hz		n/a		
<b>DTMF RECEIVER</b>				
LEVEL	-20		+3	dBm†
LEVEL DIFFERENCE	-6		+6	dB
FREQ: To receive	-1.5		+1.5	%
To not receive	-3.5		+3.5	%
DURATION	40			ms
TIME BETWEEN TONES	30			ms
<b>ROTARY RECEIVER</b>				
MAKE IMPEDANCE			700	Ω
MAKE DURATION	20		100	ms
BREAK IMPEDANCE	8			KΩ
BREAK DURATION	20		100	ms
RATE	7		20	pps
<b>DTMF SENDER</b>				
LEVEL	-8	-6	-3	dBm†
FREQUENCY	-1.3		+1.3	%
DURATION (Programmable)	40	60	130	ms
<b>ROTARY SENDER</b>				
TIMING (Programmable)	40/30	60/40	60/40	ms/ms
TIMING (At 60/40):	Make		45	ms
Break	55		65	ms
RATE (At 60/40)	9.9	10	10.1	pps
INTERDIGIT PAUSE (Programmable)	400	800	1300	ms
<b>OPERATING RANGE</b>				
TEMPERATURE	0		55	°C
HUMIDITY	0		85	%
ALLOWABLE VOLTAGE: connected to any point			300	Volts

† With reference to 600Ω Termination.

**RS-232 PORT**

**7.02** Table 8 below contains the specifications for the SMaRT-1™ Common Carrier Access Dialer and Call Controller RS-232 Auxiliary Port. This port may be used for programming or for SMDR Output.

**TABLE 8: RS-232 PORT SPECIFICATIONS**

PARAMETER	SPECIFICATION
BAUD RATE:	300 to 19200 Baud programmable; default = 1200 Baud
PARITY:	None
BITS PER CHARACTER:	Eight bits per character with one stop bit.
BIT EIGHT SENSE:	Space
MODE:	On line.
OPERATION:	Full duplex mode.

**ELECTRICAL/MECHANICAL**

**7.03** Table 9 contains the Electrical and Mechanical specifications for the SMaRT-1™ Common Carrier Access Dialer and Call Controller. These specifications also apply to the SMaRT-1A™ unit unless otherwise noted.

**7.04** This section does not contain all of the specifications for the Dialer. Other specifications may be added.

**TABLE 9: ELECTRICAL/MECHANICAL SPECIFICATIONS**

PARAMETER	SPECIFICATION
DIMENSIONS:	7.625" (19.37cm) Wide X 10.625" (26.99cm) H X 1.375" (3.49cm) D
WEIGHT: Dialer	2 lbs (0.907 kg)
Power Supply	1 lb (0.453 kg) (Approximately)
MOUNTING:	Wall Mount with Supplied Bracket
POWER:	115 Volts AC, 60 Hz @ 300 mA
Range:	103.5 to 126.5 VAC
CONNECTIONS:	Standard RJ31X Network Connections

**7.05** The specifications in the Tables above are subject to change without notice. The inclusion of 'n/a' for a specific parameter means that the specification is not available at the time of this publication.

**APPENDIX A**

**FCC INTERCONNECTION REQUIREMENTS**

**General**

**A1.01** This equipment has been approved by the Federal Communications Commission (FCC) as not being harmful to the telephone network when connected directly to the telephone lines through the standard connection cabling provided with the unit. This section is applicable to telephone interconnection in the United States.

**A1.02** Prior to the interconnection of this equipment, the local telephone company is to be notified; inform the company that you have FCC-registered equipment that you wish to connect to their trunks. Give them the following information:

- The telephone number of the line that will connect to the unit.
- The equipment being connected is a MITEL DATACOM INC. model SMarT-1™ or model SMarT-1A Common Carrier Access Dialer and Call Controller.
- The FCC Registration Number for the SMarT-1™ or SMarT-1A™ is EMP 85B-14558-LR-E
- The FCC Ringer Equivalence Number (REN) which is 0.7B.
- The Connector Jacks required are RJ31X.

**CONNECTION LIMITATIONS**

**A1.03** Due to the FCC Part 68 Rule, no connection can be made to party lines and to coin telephone service. This unit is designed to be used on standard-device telephone lines. If there are any questions about the telephone line, such as how many pieces of equipment may be connected to it, the telephone company will provide this information upon request.

**NETWORK CHANGES**

**A1.04** The telephone company may make changes to its communication service; such changes may include the change of trunk circuits, changes in the operational characteristics of its trunks, etc. Before doing this, however, the company shall provide official notification, so that the operation of the Dialer service will not be interrupted.

**MAINTENANCE LIMITATIONS**

**A1.05** This equipment has been registered with the FCC for direct connection to the telephone network. Under the FCC program, the user is restricted from making any changes or repairs and from performing any maintenance operations other than those specifically included in this document.

**A1.06** There are no user repairable parts within the unit. It is sealed against user maintenance. If opened, all warranties are voided.

**A1.07** No cabling or wiring changes within the unit are permitted by the user. Plug-ended cables, as detailed in this document, are to be used for all external connections between the unit and the telephone company interface jack.

**A1.08** Power supply components and cabling is only to be changed or maintained by MITEL DATACOM INC. or by an authorized agent of MITEL DATACOM INC.

#### **TROUBLE CORRECTIONS**

**A1.09** For all malfunctions, appropriate field service is provided by MITEL DATACOM INC. or its authorized agents.

#### **DISCONNECTION**

**A1.10** If it is ever decided to permanently disconnect the SMarT-1™ or SMarT-1A™ Dialer from the present line, please notify the telephone company of this change.

## APPENDIX B OVERALL INDEX

CONTENTS	PAGE	CONTENTS	PAGE
<b>APPENDIX A</b>		<b>FEATURES</b>	
CONNECTION LIMITATIONS .....	A-1	SEE GENERAL DESCRIPTION .....	2
CONNECTOR JACKS .....	A-1	<b>FUNCTIONS</b>	
DISCONNECTION .....	A-2	SEE GENERAL DESCRIPTION .....	2
FCC INTERCONNECTION REQUIREMENTS .....	A-1	<b>GENERAL</b>	
FCC REGISTRATION NUMBER .....	A-1	SEE INTRODUCTION .....	1
MAINTENANCE LIMITATIONS .....	A-1	<b>GENERAL DESCRIPTION</b>	
NETWORK CHANGES .....	A-1	CONVENIENCE FEATURES .....	2
RINGER EQUIVALENCE NUMBER .....	A-1	DESCRIPTION .....	2
TROUBLE CORRECTIONS .....	A-2	FEATURES .....	2
<b>APPENDIX B</b>		FUNCTIONS .....	2
OVERALL INDEX .....	B-1	<b>GENERAL OPERATION</b>	
		SEE OPERATION .....	3
<b>CALCULATION EXAMPLES</b>		<b>GROUND RULES</b>	
SEE SPEED CALL VERSUS SCREENING CAPABILITIES .....	15	SEE SPEED CALL VERSUS SCREENING CAPABILITIES .....	13
<b>CALCULATION METHODS</b>			
SEE SPEED CALL VERSUS SCREENING CAPABILITIES .....	13		
<b>CALCULATION WORKSHEET</b>			
SEE SPEED CALL VERSUS SCREENING CAPABILITIES .....	16		
<b>CONNECTION LIMITATIONS</b>		<b>HARDWARE</b>	
SEE APPENDIX A .....	A-1	SEE SPECIFICATIONS .....	17
<b>CONNECTOR JACKS</b>		<b>HARDWARE SPECIFICATIONS</b>	
SEE APPENDIX A .....	A-1	SEE SPECIFICATIONS .....	17
<b>CONVENIENCE FEATURES</b>		SEE TABLE 7 .....	17
SEE GENERAL DESCRIPTION .....	2	SEE TABLE 7 .....	18
		SMART-1 HARDWARE SPECIFICATIONS .....	17
		<b>HISTORY</b>	
		SEE INTRODUCTION .....	2
<b>DATA CONFIRMATION</b>			
SEE ENTERING SPEED CALLS .....	6	<b>INITIALIZATION PROCEDURE</b>	
<b>DEDICATED SPEED DIALER MODE</b>		SEE INITIALIZING THE DIALER .....	4
DEFAULT .....	2	<b>INITIALIZING THE DIALER</b>	
<b>DEFAULT COMPARISON</b>		SEE OPERATION .....	4
SEE OPERATION .....	9	<b>INSTALLATION</b>	
SEE TABLE 4 .....	10	DESCRIPTION .....	3
SEE TABLE 4 .....	11	<b>INSTALLATION DESCRIPTION</b>	
<b>DESCRIPTION</b>		SEE INSTALLATION .....	3
SEE GENERAL DESCRIPTION .....	2	<b>INTENDED AUDIENCE</b>	
<b>DIALING SPEED CALLS</b>		SEE INTRODUCTION .....	1
SEE PROGRAMMING EXAMPLES AND USE .....	13	<b>INTRODUCTION</b>	
<b>DISCONNECTION</b>		GENERAL .....	1
SEE APPENDIX A .....	A-2	HISTORY .....	2
		INTENDED AUDIENCE .....	1
		OVERVIEW .....	1
<b>ELECTRICAL SPECIFICATIONS</b>			
SEE SPECIFICATIONS .....	19	<b>JACKS</b>	
SEE TABLE 9 .....	19	SEE APPENDIX A .....	A-1
<b>ELECTRICAL/MECHANICAL</b>			
SEE SPECIFICATIONS .....	19	<b>MAINTENANCE LIMITATIONS</b>	
<b>ELECTRICAL/MECHANICAL SPECIFICATIONS</b>		SEE APPENDIX A .....	A-1
SEE TABLE 9 .....	19	<b>MAXIMUM MEMORY SPACE (903 DEFAULT)</b>	
<b>ENTERING DATA</b>		SEE GROUND RULES .....	13
SPEED CALL ENTRIES .....	5	<b>MAXIMUM MEMORY SPACE (909 DEFAULT)</b>	
<b>ENTERING SPEED CALLS</b>		SEE GROUND RULES .....	13
DATA CONFIRMATION .....	6	<b>MECHANICAL SPECIFICATIONS</b>	
EXIT PROGRAMMING .....	6	SEE SPECIFICATIONS .....	19
FORMAT .....	5	SEE TABLE 9 .....	19
RE-ENTER PROGRAM MODE .....	6		
RE-ORDER TONE .....	7	<b>NETWORK CHANGES</b>	
SEE OPERATION .....	5	SEE APPENDIX A .....	A-1
SYSTEM PARAMETERS .....	6		
<b>EXIT PROGRAMMING</b>		<b>OPERATING MODES</b>	
SEE ENTERING SPEED CALLS .....	6	SEE OPERATION .....	3
		<b>OPERATION</b>	
<b>FCC INTERCONNECTION REQUIREMENTS</b>		DEFAULT COMPARISON .....	9
GENERAL .....	1		
SEE APPENDIX A .....	A-1		
<b>FCC REGISTRATION NUMBER</b>			
SEE APPENDIX A .....	A-1		

**SECTION MITL8350-101-100-NA**

CONTENTS	PAGE	CONTENTS	PAGE
ENTERING SPEED CALLS	5	ELECTRICAL/MECHANICAL	19
GENERAL	3	HARDWARE	17
INITIALIZING THE DIALER	4	MECHANICAL	19
SPECIFIC DEFAULTS	7	RS-232 PORT	19
OVERALL INDEX		SPEED CALL ENTRIES	
SEE APPENDIX B	B-1	CODES	5
OVERVIEW		SEE ENTERING DATA	5
SEE INTRODUCTION	1	SEE TABLE 1	5
PROGRAMMING EXAMPLES		SPEED CALL ENTRY SIZE	
903 STANDARD OCC DIALER PROGRAMMING	12	SEE METHODS	13
USER PROGRAMMING OF SPEED CALLS	12	SPEED CALL FORMAT	
PROGRAMMING EXAMPLES AND USE		SEE TABLE 1	5
0 MAJOR PROGRAM ACCESS	11	SEE TABLE 1	6
DESCRIPTION	11	SPEED CALL QUANTITY CALCULATION	
DIALING SPEED CALLS	13	SEE SECTION 6	13
RE-ENTER PROGRAM MODE		SPEED CALL VERSUS SCREENING	
SEE ENTERING SPEED CALLS	6	DESCRIPTION	13
RE-ORDER TONE		SPEED CALL VERSUS SCREENING CAPABILITIES	
SEE ENTERING SPEED CALLS	7	CALCULATION EXAMPLES	15
RECOMMENDED ROUTE		CALCULATION WORKSHEET	16
SEE 909 COMMAND - SPEED DIALER MODE	7	GROUND RULES	13
RINGER EQUIVALENCE NUMBER		METHODS	13
SEE APPENDIX A	A-1	SPEED CALLS '523 8' PARAMETER	
RS-232 PORT		SEE 909 COMMAND - SPEED DIALER MODE	7
SEE SPECIFICATIONS	17	SPEED CALLS (WITH NO SEARCH TABLES)	
RS-232 PORT SPECIFICATIONS		SEE TABLE 5	14
SEE SPECIFICATIONS	19	SPEED DIALER MODE PROGRAMMING EXAMPLES	
SEE TABLE 8	19	SEE PROGRAMMING EXAMPLES AND USE	11
SEARCH TABLE SCREEN QUANTITY CALCULATION		SPEED DIALER WITH ACCOUNT CODE PROGRAMMING EXAMPLES	
SEE SECTION 6	13	SEE PROGRAMMING EXAMPLES AND USE	11
SEARCH TABLE SCREEN SIZE		SYSTEM PARAMETERS	
SEE METHODS	13	SEE ENTERING SPEED CALLS	6
SEARCH TABLES (WITH NO SPEED CALLS)		SEE TABLE 2	7
SEE TABLE 6	15	TROUBLE CONNECTIONS	
SMART-1 HARDWARE SPECIFICATIONS		SEE APPENDIX A	A-2
SEE TABLE 7	17	TYPE OF UNIT	
SEE TABLE 7	18	SEE APPENDIX A	A-1
SMART-1 UNIT		USER PROGRAMMING OF SPEED CALLS	
SEE FIGURE 1	1	SEE PROGRAMMING EXAMPLES	12
SOFTWARE LEVEL		0 MAJOR PROGRAM ACCESS	
SEE HISTORY	2	SEE PROGRAMMING EXAMPLES AND USE	11
SOFTWARE REVISIONS		800 RESALE SERVICE INSTALLATION	
SEE SPEED CALL VERSUS SCREENING CAPABILITIES	13	SEE FIGURE 2	2
SPECIAL FUNCTIONS AND COMMANDS		903 COMMAND - STANDARD OCC DIALER	
SEE TABLE 2	7	SEE SPECIFIC DEFAULTS	7
SPECIFIC 909 COMMAND DEFAULTS		903 STANDARD OCC DIALER PROGRAMMING	
SEE SPECIFIC DEFAULTS	8	SEE PROGRAMMING EXAMPLES	12
SEE TABLE 3	9	909 COMMAND - SPEED DIALER MODE	
SPECIFIC DEFAULTS		SEE SPECIFIC DEFAULTS	7
903 COMMAND - STANDARD OCC DIALER	7		
909 COMMAND - SPEED DIALER MODE	7		
SEE OPERATION	7		
SPECIFIC 909 COMMAND DEFAULTS	8		
SPECIFICATIONS			
ELECTRICAL	19		



**SECTION MITL8350-101-100-NA**

---

**NOTES**

---





# SMaRT - 1<sup>TM</sup>

## CALL

## CONTROLLER



## MITEL DATACOM FIELD SERVICE

MITEL DATACOM INC. has set up a National Field Service number for technical and installation assistance (214)386-9400 during normal working hours, for U.S. customers. Outside normal working hours a telephone answering service has been established. For Canadian customers, contact your local MITEL Regional Office.

### NOTICE TO CUSTOMERS


The information contained in this document is believed to be accurate in all respects but is not warranted by MITEL DATACOM INC. The information is subject to change without notice and should not be construed in any way as a commitment by MITEL DATACOM INC. or any of its affiliates and subsidiaries. MITEL DATACOM INC. and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

- ™ Trademark of Mitel Datacom Inc.
- © Copyright 1986 Mitel Corporation
- ® Registered trademark of MITEL Corporation

Printed in U.S.A.



# SMART-1™ INSTALLATION



POWER  
SUPPLY


GROUND  
REQUIRED

RJ - 31  
JACKS






# SMART-1™ RJ-31 INSTALLATION





# SMart-1™ WIRING TEST







# SMART-1™ OPERATION



CUSTOMER EQUIPMENT



CENTRAL OFFICE LINES

## PHASE 1

CUSTOMER DIALED DIGITS ARE COLLECTED

### RELATED REGISTERS

X03	R51
X08	R71
X09	R59
X19	R79
X23	R60
	R80

## PHASE 2

INTERPRETATION OF TELEPHONE NUMBER, SELECTION OF A ROUTE, TRANSLATION OF TELEPHONE NUMBER

### RELATED REGISTERS

601  
801 TO 815  
821 TO 835  
R50 R70  
R50 R70  
R52 R72  
R54 R74

## PHASE 3

DIALING TAKES PLACE ON SELECTED ROUTE



### RELATED REGISTERS

6R1 R58  
6R2 R78  
6R4  
6R5





# SMaRT-1™

## PROGRAMMING PROCEDURE - DTMF PHONE

DIAL	HEAR	DIAL	HEAR
523		8	

OR


DIAL	HEAR	DIAL	HEAR
601		214 ##	





# SMART-1™

## PROGRAMMING PROCEDURE - TERMINAL




TYPE: 523

TERMINAL RESPONSE: <SPACE>

TYPE: 8

TERMINAL RESPONSE: <LF><CR>

TERMINAL RESPONSE: >



TYPE: 601

TERMINAL RESPONSE: <SPACE>

TYPE: 214##


TERMINAL RESPONSE: <LF><CR>

TERMINAL RESPONSE: >



# SMart - 1™

## REMOTE PROGRAMMING METHOD 1





# SMart-1™

## REMOTE PROGRAMMING METHOD 2

