When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- 1. Read and understand all instructions.
- 2. Follow all warnings and instructions marked on the product.
- 3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
- 4. Do not use this product near water (for example, near a bath tub, kitchen sink, or swimming pool).
- 5. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
- 6. Slots and openings in the cabinet and the back or bottom are provided for ventilation. To protect it from overheating, these openings must not be blocked by placing the product on the bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation where proper ventilation is not provided.
- 7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- 8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.
- 9. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
- 10. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing cabinet parts other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the appliance is subsequently used.
- 11. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.
- 12. Unplug this product from the wall outlet and contact VTECH under the following conditions:
 - A. When the power supply cord or plug is damaged or frayed.
 - B. If liquid has been spilled into the product.
 - C. If the product has been exposed to rain or water.
 - D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, because improper adjustment of other controls may result in damage and will often require extensive work to restore the product to normal operation.
 - E. If the product has been dropped and the cabinet has been damaged.
 - F. If the product exhibits a distinct change in performance.
- 13. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

Important Safety Instructions

14. Do not use this or any cordless telephone to report a gas leak in the vicinity of the leak.

VTECH COMMUNICATIONS INC.

CUSTOMER SERVICE: 1-800-595-9511. In Canada, call VTech Telecommunications Canada Ltd. at 1-800-267-7377.

BEFORE USING YOUR ip 5825 SYSTEM, CAREFULLY PEEL OFF THE PROTECTIVE FILM COVERING THE DISPLAYS.

Introduction

The **ip 5825** is an advanced cordless telephone set, capable of supporting 2 Handsets.

This manual is designed to familiarize you with this cordless telephone. We strongly recommend you read the manual before using your phone.


Parts Check List

- 1. Base Unit
- 2. Handsets
- 3. Handset Charger
- 4. Base AC Power Adapter
- 5. Telephone Line Cord


- 6. Belt Clips
- 7. Base Wall Mounting Bracket
- 8. Charger Wall Mounting Bracket
- 9. User's Manual
- 10. Battery Cells

To purchase replacement batteries, visit us on the web at www.vtechphones.com or call VTech Communications, Inc. at 1-800-595-9511. In Canada, call VTech Telecommunications Canada Ltd. at 1-800-267-7377.

Note: Use only VTech batteries (part number 80-5380-00-00) or equivalent AAA NiMH rechargeable batteries.




The Handset Layout



- 1. Antenna
- 2. Earpiece
- 3. Volume Control
- 4. CID (Scroll Down)
- 5. On (Flash)
- 6. Dialing Keys (0-9, *, #)
- 7. Redial (Pause)

- 8. Speakerphone
- 9. LCD Display
- 10. Select (Menu)
- 11. Phonebook(Scroll Up)
- 12. Headset jack (2.5mm)
- 13. Off (Clear)
- 14. Intercom
- 15. Mute (Delete)




- 1. In Use LED
- Charging LED
 Message Waiting LED
- 4. Page key
- 5. DC Connector Jack
- 6. Telephone Jack


Setup

Connecting power to Base Unit/Handset Charger

1. Plug the AC power adapter into an electrical outlet, and the DC connector into the DC connector jack at the bottom of the Base Unit.




2. Choose the location for your Handset Charger, and plug its power supply into an electrical outlet.



AC Adapter

Setup

Installation of Battery Cells in Handset



Follow the steps below:


- 1. Place the new battery cells in the Handset with the positive and negative poles aligned in the battery compartment.
- 2. Replace the battery cover by sliding it upwards.
- 3. If the new battery cells are not already charged, place the Handset in its Charger or Base Unit, and allow it to charge for 10-12 hours. After initial charge, a maintenance charge of 8 hours should be sufficient.

WARNING: Alkaline batteries must NOT be used in your ip 5825 cordless telephone. Use only the batteries that came with your phone, or contact our Customer Support Center (contact information on page 2) to order additional batteries.

Charging of the Handset Battery Cells

The Handset of your cordless telephone is powered by rechargeable battery cells. It charges automatically whenever the Handset is in its charger or Base Unit.

You should charge the battery pack for 10-12 hours when you first receive your phone. You will know the battery pack needs charging when:



- The low battery message is displayed:
- The Handset seems completely dead, the LCD is completely clear and does not activate when you press the keys.

NOTE: When in **LOW BATTERY** mode, the keypad sounds, backlighting and speakerphone features will not work. When your battery has been charged, your features will return to their normal function.

IMPORTANT:

- 1. Do not dispose of battery cell in a fire, the cell may explode.
- 2. Do not open or mutilate the battery cell. Toxic substances may be released, causing harm to eyes or skin.
- 3. Exercise care in handling battery cell in order to prevent an accidental short of the charge contacts, potentially causing the battery pack to overheat.

Setup

- 4. Do not dispose of this battery cell into household garbage. Please refer to the information concerning proper battery recycling.
- 5. Do not charge the battery cell with other electrical devices.

Check Battery Indicator

If you receive a check battery warning, it indicates one of the following:

1. There are no battery cells in your Handset. You'll need to install battery cells into your Handset (see Installation and Charge of Battery Cells in Handset section on the previous page.)



2. You have accidentally installed alkaline batteries into the Handset. (Alkaline batteries must NEVER be used in this phone. See the warning on the previous page for additional information about batteries for this telephone.)

3. The rechargeable batteries in your Handset need to be replaced by new batteries.

4. The batteries have been installed incorrectly. Please reinstall (see Installation of Battery Cells in Handset) and/or the diagram in the battery compartment on

of Battery Cells in Handset) and/or the diagram in the battery compartment on the Handset.

Connecting to Phone Line

Plug one end of the telephone line cord into the jack on the back of the Base Unit. Then plug the other end of this cord into the wall jack.

Checking for Dial Tone

After the battery is charged, press **ON** on the Handset. The LCD displays **PHONE** and shows a call timer, and you will hear a dial tone. If not, see **In Case of Difficulty**.

Tone/Pulse selection


Your phone is preset for tone dialing. See **Handset Settings** for details.

CAUTION: Use only the VTech power supply provided with your telephone.

IMPORTANT:

FOR MAXIMUM PERFORMANCE OF YOUR CORDLESS TELEPHONE SYSTEM:


- 1. Choose a central location for your Base Unit.
- Install your Base Unit and Extension Handsets away from electronic equipment, such as personal computers, television sets and microwave ovens.
- In locations where there are multiple cordless telephones, separate the Base Units as far away as possible.
- Install your telephone equipment away from heat sources and sunlight.
- 5. Avoid excessive moisture, dust or extreme cold.



Wall Mounting

The Wall Mount brackets are designed for use on standard wall mount plates only. Wall mounting is optional.

- 1. Plug the AC adapters into an electrical outlet, and the DC connector to the bottom of the Base Unit.
- 2. Connect the telephone line cord to the jack at the bottom of the Base Unit, and the other end to the wall jack.
- 3. Line up the tabs on the wall mount adapters with the holes at the bottom of the Base Unit/back of the Handset Charger. Snap the wall mount bracket firmly in place.
- 4. Mount the Base Unit/Handset Charger on the wall. Position the Base Unit/Handset Charger so the mounting studs will fit into the holes on the wall mount bracket. Slide Base Unit/Handset Charger down on the mounting studs until it locks into place.



Handset and Base Indicators

Handset Icons

Icon	Description		
MUTE	• Turns on when the microphone is muted.		
NEW	• Turns on when there are new call log enteries.		
Ď	• Turns on when the ringer is muted.		
	Low battery indicator and charging indicator.		

Handset LEDs

LED	Description
SPEAKER	• LED is on when in handsfree mode.

Base LEDs

LED	Description
	• On when the phone is off hook.
IN USE	 Flashes when an extension phone is off hook.
CHARGING	 On when the Handset is charging in the cradle.
MESSAGE WAITING	 Flashes when the visual message waiting signal has been detected. Service must be subscribed through your local telephone company.

Making Calls

- Press ON (or, SPEAKER to use the Handset Speakerphone feature). Dial the phone number.
 -OR-
- Dial the phone number first; then press **ON** (or **SPEAKER**).
- Press **OFF** to end your call.

Answering Calls

- Press any key except OFF, INT, MUTE, REDIAL/ PAUSE and the softkeys.
- Press OFF to end your call.

How to Adjust the Handset Volume (also applies to the Handset Speakerphone and Headset)

The volume control is on the left edge of the Handset. During a call, press ▲or ▼ key to adjust the listening volume to a comfortable level. When you reach the maximum or minimum setting, a double-beep will sound.

NOTE: The procedure is the same for the Handset earpiece, Speakerphone and Headset.


Flash Function


 You can use your ip 5825 with services such as Call Waiting. When you receive a call-waiting signal, simply press the ON/FLASH key to switch to the new call. Press ON/FLASH again to switch back to the original call.


NOTE: Use **ON/FLASH** to access other phone company subscriber services, as described by your provider.

Redial Funtion

- Press REDIAL/PAUSE to display the last telephone number dialed from the Handset (up to 32 digits).
 Use ▲ or ▼ to scroll through the 5 previously dialed numbers. When the beginning or the end of the redial list is reached, a double-beep will sound.
- When the desired number is reached, press **ON** or **SPEAKER** to dial.
- Pressing **OFF** will exit the redial review list.
- **NOTE**: When the redial memory is empty, and **REDIAL** is pressed, a double-beep will sound.
- When the desired entry displays, press DELETE to delete it. A confirmation tone will sound.







REDIAL	
	595-9511

Handset Operation

Mute Function

- During an active call, pressing the **MUTE.DELETE** key will disable the microphone. MICROPHONE MUTED will display briefly. The screen will display:
- Press MUTE.DELETE again to return to normal 2-way conversation. MICRO-PHONE ON will display briefly.

Intercom Call

- From the idle (OFF) mode, press **INT**. The Handset will display:
- The other Handset will ring and the screen will display:
- Press INT or SPEAKER to answer the intercom call. The screens will display:
- Press INT or OFF on either Handset to end the call.
- NOTE: If the other Handset is out of range, or on an external call, when the first handset attempts to intercom it, the display of the first handset will show:

Call Forward and Call Transfer

An external call can be forwarded or transferred from one Handset to the other Handset. The difference between forward and transfer depends on if the sending Handset needs to talk with the receiving Handset, before the external call is actually sent to the other Handset. PHONE 00:00:15 MICROPHONE MUTED

MUTE

CALLING OTHER HANDSET

OTHER HANDSET IS CALLING

INTERCOM

INTERCOM ENDED

UNABLE TO CALL TRY AGAIN

Handset Operation

Call Forward

- A Handset (HS1), on an external call can forward it to the other Handset (HS2), by pressing and holding the INT key. The display of HS1 will initially show:
- HS2 can press **ON** to answer the call.

NOTE: If HS2 does not respond in about 30 seconds, the external call will be returned to HS1 and the display will show:

If the returned call is not answered within 30 seconds, the external call will end automatically.

CALL FORWARDED
CALL BACK

Call Transfer

• A Handset (HS1) on an external call can forward it to the other Handset (HS2) by pressing the **INT** key.

NOTE: The external call is put on hold automatically.

- HS2 will ring, showing an intercom call.
- HS2 can answer the intercom call by pressing ON.
- HS1 and HS2 can discuss the external call.
- Press OFF on HS1 to transfer the external call to the other Handset.
- HS2 is now on the external call. CALL TRANSFERRED will display on HS1 briefly.

NOTE: If there is no answer on HS2, then HS1 can be reconnected to the held call by pressing **ON** to reconnect to the external call.

Conference Call


It is possible to establish a conference between two Handsets and the external line.

If a Handset already has a connection to the external line, and the other Handset goes offhook, a conference is immediately established. Both Handsets will show:

Base Operation

From the Base Unit, you can use the **PAGE** key to locate the Handsets.

- When the Handset is in idle, press **PAGE**. The Handsets will display:
- To end the page at the Base, press **PAGE** again.
- To Mute the page Tone at the Handset, press **OFF**.



BASE IS PAGING

Phonebook Operation

Your **ip 5825** can store up to 50 numbers with names in memory. Each memory location can hold up to 32 digits for the number and 16 characters for the name.

NOTE: The Handsets share a common phonebook, which is stored in the Base. This means that entries inserted by one Handset are available for both Handsets, and if one deletes a phonebook entry, it will disappear from both Handsets.

When one Handset is accessing the phonebook, the other Handset cannot access it at the same time. If this is attempted, **NOT AVAILABLE AT THIS TIME** will display on the second Handset.

Storing a New Entry

- Press SEL.
- With Phonebook selected, press SEL again.
- Press ▼ to select STORE. Press SEL.
- You will be prompted to ENTER NUMBER. Use the dialing keys to enter the number you wish to store in the phonebook. Press the MUTE. DEL key to backspace and make corrections. Press SEL.
- You will then be prompted to ENTER NAME. Use the dialing keys to spell the name. Press SEL.
- You will hear a confirmation tone, and the new phonebook entry will display briefly.

NOTES:

- If the phonebook is full, the Handset will display **PHONEBOOK IS FULL**.
- You can also press REDIAL.PAUSE then ▲ or ▼ to scroll to the previously dialed number from the redial list you want to store in the phonebook. Press SEL.
- While entering numbers, press and hold REDIAL.PAUSE to add pauses if necessary.
- If there is a duplicate number in the phonebook, the display will show:

>STORE REVIEW

ENTER NUMBER 800-595-9511

ENTER NAME

PHONE BOOK

NUMBER ALREADY IN PHONE BOOK Each press of a particular key causes characters to be displayed in the following order:

Kau	Characters by number of key presses								
Key	1	2	3	4	5	6	7	8	9
1	space	1							
2	Α	В	С	2	а	b	с		
3	D	Е	F	3	d	е	f		
4	G	Н	1	4	g	h	i		
5	J	К	L	5	j	k	I		
6	М	Ν	0	6	m	n	0		
7	Р	Q	R	S	7	р	q	r	s
8	Т	U	V	8	t	u	v		
9	W	Х	Y	Z	9	w	х	у	z
0	0								
		?	!	/	()			
#	#	'	,	-		&			

Reviewing/Dialing from the Phonebook

• Press SEL. With Phonebook in the first line, press SEL again. With the REVIEW in the first line, press SEL again.

- OR -

With the Handset idle, press **A** and the Handset jumps directly into the phonebook review mode. The first phonebook entry will be displayed.

 Scroll through the phonebook entries using ▲ or ▼ keys or enter first character of the name to be searched (using the digit keys) and continue navigating using the ▲ or ▼ as scroll keys, until you reach the entry to be dialed.

NOTE: When reviewing the phonebook, the second line of the display will show the phone number, up to 16 digits. For numbers longer than 16 digits, only the first 13 digits will be shown. Press \star or # to scroll the phone number to see the additional digits.

• Press **ON** or **SPEAKERPHONE**, to dial the number.

NOTE: If there are no entries in the phonebook,

VTech

595-9511

VTech Com 800-595-9511

PHONE 00: 00: 10 VTech Com

VTech Com 800-595-9511 when it is accessed, **PHONEBOOK IS EMPTY** will display.

Editing a Phonebook Entry

phonebook. Press SEL.

- Follow the two steps in **Reviewing/Dialing** from the phonebook (on page 16) to reach the entry to be edited.
- Press SEL.
- Press MUTE.DEL to backspace then enter the correct number. Press and hold REDIAL.PAUSE to add pauses if necessary. You can also press REDIAL.PAUSE, then ▲ or ▼ to scroll to the previously dialed number from redial list which you want to store in the
- Press SEL to confirm the number and enter name edit mode.
- Press **MUTE.DEL** to backspace and use the digit keys to enter the correct name.
- Press **SEL** to confirm the change. A confirmation tone will sound.

Delete a Phonebook Entry

- Follow the two steps in **Reviewing/Dialing** from the Phone Book (on page 16) to reach the entry to be deleted.
- Press **MUTE.DEL** to delete the entry. A confirmation tone will sound.
- The Handset will then move to the next entry, if any.

EDI T NUMBER 800-595-9511

EDIT NAME VTech

> VTech 595-9511

VTech Com 800-595-9511

> VTech 595-9511

Calls Log (Caller ID - Call Waiting)

Caller ID - Call Waiting ID

Your **ip 5825** is capable of displaying the name and/or number of the party calling before you answer the phone (**Caller ID**). It is also capable of displaying Caller ID information in conjunction with a Call Waiting alert signal (**Call Waiting Caller ID**). With Call Waiting Caller ID, the Caller ID data is displayed so you can decide whether to answer the incoming call, or continue with your current conversation. Your **ip 5825** can hold up to 50 CID entries.

NOTES ABOUT CALLER ID & CALL WAITING CALLER ID

These are subscription services, provided by most regional telephone service providers. You must subscribe to these services to get the benefits of these features. If you do not subscribe to Caller ID services, you can still use your **ip 5825** and the other features it offers.

Due to regional incompatibilities, Caller ID information may not be available for every call you receive. In addition, the calling party may intentionally block their name and/or phone number from being sent.

- As new Caller ID/Call Waiting ID records are received, your Handset displays will alert you to the new Caller ID records, for example:
- After you review all new Caller ID records, the **NEW** call indication will be turned off and the screen will show:
- If the call log is full, the oldest entry is deleted to make room for the new call. If the call log is empty when you try to enter to Call Log review, a message of the following message is displayed:

Reviewing Caller ID

You can review the caller ID record via the menu, as described below or by pressing the \checkmark key in idle (quick access key) whereby the Handset jumps directly to the Caller ID review.

- In idle mode, press **SEL** to enter the menu.
- Press **v** key to scroll to **CALL LOG** option.

XCALL LOG RINGER VOLUME

UTech 5 NEW CALLS NEH

UTech CALL LOG IS EMPTY

Calls Log (Caller ID - Call Waiting)

- Press **SEL** again. Use ▲ or ▼ to scroll through the Call Log entries.
- When the beginning or the end of the Call Log is reached, a happy tone will sound.

NOTE: '!' symbol in the right hand side of the first line indicates the call is not yet reviewed.

Storing a Caller ID

- Follow the steps in **Reviewing Caller ID** to scroll to the record to be stored.
- To view alternate dialing sequences, press the # key repeatedly. The screen will cycle through the various dialing options (1 + area code + number, area code + number, 1 + number, number only.) Press SEL to store the displayed number.
- If the Caller ID does not contain a name, you will be prompted to **EDIT NAME**. Use the digit keys to spell the name. If you make a mistake, press the **DELETE** key to backspace. When finished, press **SEL**.
- You will hear a happy tone then the screen will display:
- If the Caller ID isn't able to detect a name, ENTER NAME will be prompted. If unable to detect the number, ENTER NUMBER will be prompted. You will then need to add the name or the number.
- If the phone number already exists in the phonebook, the entry will not be stored, and the screen will show:
- If the phonebook is full, the screen will show:
- If both name and number are missing, for example as in a private listing, the request will be rejected with the message:

Dialing from Caller ID

• Follow the steps in **Reviewing Caller ID** to scroll to the entry to be dialed.

UTech Com 800-595-9511 NEW 2/23 11:59^m

EDIT NAME

ADDED TO PHONE BOOK

NUMBER ALREADY IN PHONE BOOK

> PHONE BOOK IS FULL

UNABLE TO SAVE IN PHONE BOOK

UTech Com 800-595-9511

NEW 2/23 11:59^{pm}

Basic Operation

Calls Log (Caller ID - Call Waiting)

 To change how the number will be dialed, (1 + area code + number, area code + number, 1 + number, number only.) press # repeatedly. The screen will cycle through the dialing options. Press ON or SPEAKER key to dial the number.

Deleting Caller ID

- Follow the steps in **Reviewing Caller ID** to scroll to the record to be deleted.
- Press **DELETE** key to delete the desired record. A confirm tone will sound and the previous Caller ID record will be displayed on the screen.
- To delete all the Caller ID records, press and hold the DELETE key. The screen will ask you DELETE ALL CALLS? Press SEL for confirmation. Or, press OFF to return to the CID record previously displayed.

VTech Com 800-595-9511					
NEW	2/23	11:59 ^{8M}			

DELETE ALL CALLS?

Handset Settings

Ringer Volume

- From the idle (OFF) mode, press SEL then ▲ or ▼ key to RINGER VOLUME.
- Press **SEL** again. The current ringer volume will be shown:
- Press ▲ and ▼ keys or enter digit 0-6 to the desired ringer volume. The current ring tone is played and the volume bar is increased/decreased each time the setting is adjusted. At the lowest setting, display will show:
- The Handset will not ring when a call comes in if Ringer Volume is setted to the lowest setting.
- Press SEL to confirm the setting.

Ringer Tone

- From the idle (OFF) mode, press SEL then ▲ or ▼ key to RINGER TONE.
- Press SEL. You will then be prompted to choose INTERCOM CALL or OUTSIDE CALL. Press ▲ or ▼ keys to select the desired option.
- Press SEL again. You can then use ▲ or ▼ keys or enter digit 0-9 to sample the ring tones. The screen, will show:
- Press **SEL** to confirm your setting.

Key Tone (preset to ON)

- From the idle (OFF) mode, press SEL then
 ▲ or ▼ key to KEY TONE.
- Press SEL again. The current setting will be shown. Press ▲ or ▼ keys to scroll to ON or OFF. When set to ON, the Handset will emit a beep whenever a key is pressed.
- When the desired option is shown, press **SEL** to confirm your selection.



Handset Settings

Handset Name (preset as 'VTECH')

- It is possible to give each Handset its own unique name. The name is shown in the first line when the Handset is idle. The name can be a maximum of 16 characters in length.
- From the idle (OFF) mode, press SEL then ▲ or ▼ key to HANDSET NAME.
- Press **SEL** again. The display will show the current setting, for example:
- Press **DEL** to backspace then 'spell' the desired name.

NOTE: The characters are entered in the same way as for the phone book, see the table in page 15.

• Press **SEL** to confirm the setting.

Language (preset to English)

- From the idle (OFF) mode, press SEL then
 ▲ or ▼ key to LANGUAGE.
- Press SEL to select this option. Press ▲ or
 ▼ keys to scroll from English to French or Spanish.
- Press **SEL** to confirm the setting.

Message Waiting

Your telephone can detect a Visual Message Waiting signal, generated by many telephone service providers. If you subscribe to Voice Mail service from your local telephone company (fee required), and a Visual Message Waiting signal is provided, the Handset will display **MESSAGE WAITING**, alerting you to new messages.

Once you have reviewed all new messages, the Message Waiting alert will automatically be turned off.

HANDSET NAME VTech_

HANDSET NAME Kitchen_

>LANGUAGE CLEAR MSG WAIT

LANGUAGE FRENCH

Clear Message Waiting

If, after reviewing all new voice mail messages, the Message Waiting alert still remains on the screen and the **MESSAGE WAITING** LED on Base is still flashing, you can manually remove the indication from the screen and turn the LED off.

- From the idle (OFF) mode, press SEL then ▲or
 ▼ key to CLEAR MSG WAIT.
- Press SEL then the display will ask you TURN INDICATOR OFF? Press SEL again to confirm. To exit, press OFF.

Dial Type (preset to Tone)

- From the idle (OFF) mode, press SEL then ▲ or ▼ key to DIAL TYPE.
- Press SEL then use ▲ or ▼ key to scroll from TONE to PULSE.
- Press **SEL** to confirm your setting.

NOTE: When the phone is set for PULSE dial mode, it is possible to switch to temporary TONE mode during an ongoing call by pressing *. Once pressed, TONE will be used for rest of the call. After you hang up, the phone will return to pulse dialing for the next call.

>CLEAR MSG WAIT DIAL TYPE

TURN INDICATOR

>DIAL TYPE PHONE BOOK

DIAL TYPE PULSE


Headset Operation

Headset Operation

Your **ip 5825** Handset is equipped with a 2.5mm Headset Jack for use with an optional accessory Headset for hands-free operation. If you choose to use the Headset option, you must obtain an optional accessory Headset, which is compatible with the **ip 5825**.

To purchase a Headset, call VTech Customer Service at 1-800-595-9511.

Once you have a compatible 2.5mm Headset, locate the Headset Jack on the **ip 5825** Handset. Connect the plug on the Headset cord to the jack (under a small rubber flag) on the cordless Handset. The plug should fit securely. Do not force the connection.




Advanced Operation

NOTE:

• Whenever a compatible Headset is connected to the cordless Handset, the microphone on the Handset will be muted. This is done to limit the effect of background noise.

• When a compatible Headset is connected to the cordless Handset, your Speakerphone feature will be disabled. To use your Speakerphone feature, simply disconnect the Headset from the Handset.



Belt Clip

The **ip 5825** is also equipped with a detachable belt clip. Align the pins on the inside edge of the clip with the notches on the sides of the Handset. The belt clip should snap securely into place. Do not force the connection.

In Case Of Difficulty

If you have difficulties in operating your phone, the suggestions below should solve the problem. If you still have difficulties after trying these suggestions, call VTECH Communications at 1-800-595-9511. In Canada, call VTECH Telecommunications Canada Ltd. at 1-800-267-7377.

The Phone Doesn't Work At All

- Make sure the Power Cord is plugged in.
- Make sure the telephone line cord is plugged firmly into the Base Unit and the telephone wall jack.
- Make sure the batteries are properly charged. If you get a 'LOW BATTERY' message or indication, the battery cells needs charging.

No Dial Tone

• First check all the suggestions above.

• If you still don't hear a dial tone, disconnect the Base Unit from the telephone jack and connect a different phone. If there is no dial tone on that phone either, the problem is in your wiring or local service. Contact your local telephone company.

You Get Noise, Static, Or A Weak Signal Even When You're Near The Base Unit

• Household appliances plugged into the same circuit as the Base Unit can sometimes cause interference. Try to move the appliance or the Base Unit to another outlet.

You Get Noise, Static, Or A Weak Signal When You're Away From The Base Unit

• You may be out of range. Either move closer to the Base, or relocate the Base Unit.

• The layout of your home may be limiting the range. Try to move the Base Unit to another position.

The Handset Does Not Ring When You Receive A Call

• Make sure you have the ringers activated. Refer to the section(s) on **Ringer Volume** in this User's Manual.

- Make sure the telephone line cord is plugged firmly into the Base Unit and the telephone jack. Make sure the power cord is plugged in.
- You may be too far from the Base Unit.

• You may have too many extension phones on your telephone line to allow all of them to ring. Try to unplug some of the other phones.

You Hear Other Calls While Using Your Phone

• Disconnect your Base Unit from the telephone jack, and plug in a corded telephone. If you still hear other calls, the problem is probably in your wiring or local service. Call your local telephone company.

In Case Of Difficulty

You Hear Noise In The Handset, And None Of The Keys Or Buttons Work

• Make sure the power cord is plugged in.

Common Cure For Electronic Equipment

If the unit does not seem to be responding normally, then try to put the Handset in the cradle. If it does not seem to respond, do the following (in the order listed):

- 1. Disconnect the power to the Base.
- 2. Disconnect the Handset battery.
- 3. Wait a few minutes.
- 4. Connect power to the Base.
- 5. Re-install the battery pack (s)
- 6. Watch for Handset to display: "VTECH" or your own handset name.

SEARCHING

Your telephone can be damaged if it gets wet. Do not use the Handset outdoors in the rain, or handle it with wet hands. Do not install your Base Unit near a sink, bathtub or shower.

Electrical storms

Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, use caution when using electric appliances during storms.

Cleaning your telephone

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or a mild soap. Do not use excess water or cleaning solvents of any kind.

Remember that electrical appliances can cause serious injury if used when you are wet or standing in water. If your Base Unit should fall into water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORDS FROM THE WALL. Then pull the unit out by the unplugged cords.

Taking Care Of Your Telephone

Your cordless telephone contains sophisticated electronic parts, so it must be treated with care.

Avoid rough treatment

Place the Handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

Avoid water

What does this limited warranty cover?

• The manufacturer of this VTech product, VTech Communications, warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the product and all accessories provided by VTech in the sales package ("Product") are free from material defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with operation instructions, This limited warranty extends only to the Consumer for Products purchased and used in the United States of America.

What will VTech Communications do if the Product is not free from material defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?

• During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair this product, we may use new or refurbished replacement parts. If we choose to replace this product, we may replace it with a new or refurbished product of the same or similar design. VTech will return repaired or replace ment products to you in working condition. VTech will retain defective parts, modules, or equipment. Repair or replacement of Product, at VTech's option, is your exclusive remedy. You should expect the repair or replacement to take approximately 30 days.

How long is the limited warranty period?

• The limited warranty period for the product extends for ONE(1) YEAR from the date of purchase if we repair or replace a Materially Defective Product under the terms of this limited warranty. This limited warranty also applies to repaired or replacement Products for a period of either (a) 90 days from the date the repaired or replacement Product is shipped to you or (b) the time remaining on the original one-year warranty; whichever is longer.

What is not covered by this limited warranty?

This limited warranty does not cover

1. Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, negligent, inundation, fire, water or other liquid intrusion; or

2. Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of VTech; or

3. Product to the extent that the problem experienced is caused by signal conditions, network reliability or cable or antenna systems; or

4. Product to the extent that the problem is caused by use with non-VTech electrical accessories; or

5. Product whose warranty/quality stickers, Product serial numbers plates or electronic serial numbers have been removed, altered or rendered illegible; or

6. Product purchased, used, serviced, or shipped for repair from outside the United States, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or

7. Product returned without valid proof of purchase (see 2 below); or

8. Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

How do you get warranty service?

• To obtain warranty service in the United States of America, call 1- 800-595-9511 for instructions regarding where to return the Product. Before calling for service, please check the user's manual. A check of the Product controls and features may save you a service call.

• Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of Product(s) to the service location. VTech will return repaired or replaced product under this limited warranty to you, transportation, delivery or handling charges prepaid. VTech assumes no risk for damage or loss of the Product in transit.

• If the Product failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, VTech will notify you and will request that you authorize the cost of repair and return shipping costs for the repair of Products that are not covered by this limited warranty.

What must you return with the Product to get warranty service?

1. Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty;

2. Include "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and

3. Provide your name, complete and correct mailing address, and telephone number.

Other Limitations

• This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this product. The warranty exclusively describes all of VTech's responsibilities regarding the product.

There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

State Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the product is fit for ordinary use)

Warranty Statement

are limited to one year from date of purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

• In <u>no</u> event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the product, or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this product, some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

FCC, ACTA and IC Regulations

This equipment complies with Parts 15 of the Federal Communications Commission (FCC) rules for the United States. It also complies with regulations RSS210 and CS-03 of Industry and Science Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

A label is located on the underside of the Base Unit containing either the FCC registration number and Ringer Equivalence Number (REN) or the IC registration number and Load Number. You must, upon request, provide this information to your local telephone company.

This equipment is compatible with inductively coupled hearing aids. Should you experience trouble with this telephone equipment, please contact:

VTech Communications Inc

CUSTOMER SERVICE at 1-800-595-9511. In Canada, call VTech Telecommunications Canada Ltd. at 1-800-267-7377.

For repair/warranty information. The telephone company may ask you to disconnect this equipment from the line network until the problem has been corrected.

FCC Part 15

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The equipment has been tested and found to comply with part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet or on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to

FCC, ACTA, and IC Regulations

the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The handset has such a low power that it does not require testing. It may be safely held against the ear of the user. The base unit shall be installed & used such that parts of the user's body other than the hands should be maintained at a comfortable distance of approximately 20 cm or more.

FCC Part 68 and ACTA

If this equipment was approved for connection to the telephone network prior to July 23, 2001, it complies with Part 68 of the Federal Communications Commission (FCC) rules. If the equipment was approved after that date, it complies with the Part 68 rules and with Technical Requirements for Connection of Equipment to the Telephone Network adopted by the Administrative Council for Terminal Attachments (ACTA). We are required to provide you with the following information.

1. Product identifier and REN information

The label on the back or bottom of this equipment contains, among other things, an identifier indicating product approval and the Ringer Equivalence Number (REN). This information must be provided to your local telephone company upon request. For equipment approved prior to July 23, 2001, the product identifier is preceded by the phrase "FCC Reg No." and the REN is listed separately. For equipment approved after that date, the product identifier is preceded by "US" and a colon (:), and the REN is encoded in the product identifier without a decimal point as the sixth and seventh characters following the colon. For example, the product identifier US:AAAEQ03T123XYZ would indicate an REN of 0.3. The REN is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. In most, but not all areas, the sum of all RENs should be five (5.0) or less. You may want to contact your local telephone company for more information.

2. Connection and use with the nationwide telephone network

The plug and jack used to connect this equipment to the premises wiring and the telephone network must comply with the applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See Installation Instructions in the user's manual. This equipment may not be used with Coin Telephone Lines or with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

3. Repair instructions

If this equipment is malfunctioning, it must be unplugged from the modular jack until

the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents. For repair procedures, follow the instructions outlined under the Limited Warranty.

4. Rights of the telephone company

If this equipment is causing harm to the telephone network, the telephone company may temporarily discontinue your telephone service. The telephone company is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone company is required to inform you of your right to file a complaint with the FCC. Your telephone company may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone company is required to notify you if such changes are planned.

5. Hearing aid compatibility

If this product is equipped with a corded or cordless Handset, it is hearing aid compatible.

6. Programming/testing of emergency numbers

If this product has memory dialing locations, you may choose to store police, fire department and emergency medical service telephone numbers in these locations. If you do, please keep three things in mind:

a. We recommend that you also write the telephone number on the directory card, so that you can still dial the emergency number manually if the memory dialing feature doesn't work.

b. This feature is provided only as a convenience, and the manufacturer assumes no responsibility for customer reliance upon the memory feature.

c. Testing the emergency telephone numbers you have stored is not recommended. However, if you do make a call to an emergency number:

• You must remain on the line and briefly explain the reason for the call before hanging up.

• Programming/testing of emergency numbers should be performed during offpeak hours, such as in the early morning or late evening, when the emergency services tend to be less busy.

IC (Industry Canada)

This telephone is registered for use in Canada.

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

Notice:

This equipment meets the applicable Industry Canada Terminal Equipment Technical

FCC, ACTA, and IC Regulations

Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

Notice:

The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of services in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution:

Users should not attempt to make such connections themselves, but should contact the appropriate electrical inspection authority, or electrician, as appropriate.

Your Cordless Phone is designed to operate at the maximum power allowed by the FCC and IC. This means your Handset and Base Unit can communicate only over a certain distance - which will depend on the location of the Base Unit and Handset, weather, and the construction and layout of your home or office.

Technical Specifications

FREQUENCY CONTROL

Crystal controlled PLL synthesizer

TRANSMIT FREQUENCY

Base: 5744.736 - 5825.952 MHz Handset: 2401.056 - 2482.272 MHz

RECEIVE FREQUENCY

Base: 2401.056 - 2482.272 MHz Handset: 5744.736 - 5825.952 MHz

CHANNELS

95 Channels

NOMINAL EFFECTIVE RANGE

Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use.

SIZE

Handset: 182mm x 55.3mm x 40mm (including antenna) Base: 115.8mm x 112.2mm x 62.6mm Charger: 76.5mm x 79.4mm x 45.2mm

WEIGHT

Handset: 146 grams (excluding Batteries) Base: 210 grams Charger: 225 grams

POWER REQUIREMENTS

Handset: 3.6V 600mAh NiMH (3 AAA cells) Base: 9 V @ 600mA Charger: 9 V @ 150mA

MEMORY

Speed Dial: 50 Memory locations; up to 32 digits per location CID: 50 Memory locations SPECIFICATIONS ARETYPICAL AND MAY CHANGE WITHOUT NOTICE.

vtech

VTECH TELECOMMUNICATIONS LTD.

vtech A member of THE VTECH GROUP OF COMPANIES.

Distributed in the U.S.A. by VTech Communications, Inc. Beaverton, Oregon, 97008

Distributed in Canada by VTech Telecommunications Canada Ltd. 200-7671 Alderbridge Way, Richmond, B.C. V6X 1Z9.

Printed in China

Table Of Contents

IMPORTANT SAFETY INSTRUCTIONS	1
INTRODUCTION	3
Parts Check List	4
The Handset Layout	
The Base Unit Layout	6
GETTING STARTED	7
SETUP	
Connecting power to Base Unit/ Handset Charger	
Installation of Battery Cells in Handset	8
Charging of the Handset Battery Cells	
Check Battery Indicator	
Connecting to Phone Line	
Checking for Dial Tone	
Tone/ Pulse selection	
Wall Mounting	
BASIC OPERATION	
Handset and Base Indicators	
Handset Icons	
Handset LEDs	
Base LEDs	
Handset Operation	
Making Calls	
Answering Calls	
Flash Function	
Redial Funtion	
Mute Function	
Intercom Call	
Call Forward	
Call Transfer	
Conference Call	
Base Operation Phonebook Operation	
Storing a New Entry	
Reviewing/Dialing from the Phonebook	10
Editing a Phonebook entry	
Delete a phonebook entry	
Calls Log (Caller ID - Call Waiting)	
Caller ID - Call Waiting ID.	
Reviewing Caller ID.	
Storing a Caller ID	
Dialing from Caller ID	
Deleting Caller ID.	20
Handset Settings	
Ringer Volume	
Ringer Tone	

Table Of Contents

Key Tone (preset to ON)	
Handset Name (preset as 'VTECH')	
Language (preset to English)	
Message Waiting	
Clear Message waiting	
Dial Type (preset to Tone)	
ADVANCED OPERATION	
HEADSET OPERATION	
ADDITIONAL INFORMATION	
In Case Of Difficulty	
Maintenance	
Warranty Statement	
FCC, ACTA, and IC Regulations	
Technical Specifications	

Congratulations on your purchase of this VTech product

NEED HELP?

Our representatives are here to help you with any questions concerning the operation of this product, available accessories, or any other related issues.

Call Toll Free: 1-800-595-9511 In Canada, Call: 1-800-267-7377

or visit our website at www. vtechphones. com