

Owner's Manual  
for Vehicle



The Ultimate  
Driving Machine



**X5 3.0i  
X5 4.4i  
X5 4.8is**

Congratulations, and thank you for choosing a BMW.

Thorough familiarity with your vehicle will provide you with enhanced control and security when you drive it. We therefore have this request:

Please take the time to read this Owner's Manual and familiarize yourself with the information that we have compiled for you before starting off in your new BMW. The manual contains important data and instructions intended to assist you in obtaining maximum satisfaction from your BMW's unique array of advanced technical features. It also contains information on vehicle maintenance designed to enhance operating safety while simultaneously helping you to maintain your BMW's value throughout an extended service life. For additional information refer to the supplemental manuals.

This Owner's Manual should be considered a permanent part of this vehicle. It should stay with the vehicle when sold to provide the next owner with important operating, safety and maintenance information.

We wish you an enjoyable driving experience.

BMW AG

# Contents

<b>Notes</b>	About this Owner's Manual <a href="#">8</a>
	Symbols used <a href="#">8</a>
	Your individual vehicle <a href="#">8</a>
	Status at time of printing <a href="#">9</a>
	For your own safety <a href="#">9</a>
	Symbol on vehicle parts <a href="#">10</a>
	Service and Warranty <a href="#">10</a>
	Reporting safety defects <a href="#">11</a>
<b>Overview</b>	Cockpit <a href="#">14</a>
	Instrument cluster <a href="#">15</a>
	Indicator and warning lamps <a href="#">19</a>
	Buttons on steering wheel <a href="#">23</a>
	Warning triangle <a href="#">24</a>
	First-aid kit <a href="#">24</a>
	Refueling <a href="#">24</a>
	Fuel specifications <a href="#">26</a>
<b>Controls and features</b>	<b>Locks and security systems:</b>
	Keys <a href="#">30</a>
	Central locking system <a href="#">30</a>
	Opening and closing: from outside <a href="#">31</a>
	Opening and closing: from inside <a href="#">34</a>
	Liftgate <a href="#">35</a>
	Tailgate <a href="#">36</a>
	Alarm system <a href="#">38</a>
	Windows <a href="#">39</a>
	Panorama glass roof <a href="#">41</a>
	<b>Adjustments:</b>
	Sitting safely <a href="#">43</a>
	Seats <a href="#">44</a>
	Mechanical seat adjustment <a href="#">45</a>
	Power seat adjustment <a href="#">46</a>
	Head restraints <a href="#">47</a>
	Power rear-seat backrest adjustment <a href="#">48</a>
	Safety belts <a href="#">49</a>
	Seat, mirror and steering wheel memory <a href="#">50</a>
	Heated seats <a href="#">52</a>
	Steering wheel <a href="#">52</a>
	Steering wheel heater <a href="#">53</a>
	Mirrors <a href="#">53</a>

© 2005 Bayerische Motoren Werke

Aktiengesellschaft

Munich, Germany

Reprinting, including excerpts,  
only with the written consent of  
BMW AG, Munich.

Order No. 01 41 0 159 867

US English VII/05

Printed in Germany

Printed on environmentally friendly paper,  
bleached without chlorine, suitable for recycling.

**Controls and features****Passenger safety systems:**

- Airbags 55
- Transporting children safely 57
- Vehicle Memory,  
Key Memory 61

**Driving:**

- Ignition lock 62
- Starting engine 62
- Switching off engine 63
- Handbrake 64
- Manual transmission 64
- Automatic transmission with  
Steptronic 65
- Turn signals/  
headlamp flasher 68
- Washer/wiper system/  
rain sensor 69
- Cruise control 71

**Everything under control:**

- Odometer, outside temperature  
display 73
- Tachometer 74
- Energy control 74
- Engine oil temperature gauge 75
- Fuel gauge 75
- Coolant temperature gauge 76
- Service Interval Display 76
- Check Control 77
- Computer 79
- MID Multi-Information  
Display 81

**Digital clock in MID 82****Computer in MID 85****Technology for safety and  
driving convenience:**

- PDC Park Distance Control 90
- Antilock Brake System 91
- DSC Dynamic Stability  
Control 92
- xDrive 94
- HDC Hill Descent Control 94
- Self-leveling suspension 95
- 2-axle self-leveling  
suspension 96
- Brake force display 98
- Flat Tire Monitor 98

**Lamps:**

- Parking lamps/low beams 100
- Adaptive Head Light 101
- High beams/roadside parking  
lamps 101
- Front fog lamps 102
- Instrument lighting 102
- Interior lamps 103

**Controlling the climate for  
pleasant driving:**

- Air conditioner 104
- Automatic climate control 107
- Roller sun blinds 113
- Parked car ventilation 113

**Cabin convenience:**

- Integrated universal remote  
control 114
- Telephone 116
- Interior rearview mirror with  
digital compass 117
- Glove compartment 119
- Storage compartments 119
- Cup holders 120
- Ashtray, front 121
- Ashtray, rear 121
- Cigarette lighter, rear 122

**Loading and transporting:**

- Ski bag 123
- Cargo area
  - Folding rear backrests  
down 124
  - Roll-up cover 125
  - Partition net 125
  - Covers in cargo area 127
  - Sockets 128
  - Pull-out cargo floor 128
- Cargo loading 130
- Roof-mounted luggage rack 132

# Contents

## Operation, maintenance

### Special operating instructions:

- Breaking-in 136
- General driving notes 137
- Driving your X5 138
- Safe braking 140

### Wheels and tires:

- Tire inflation pressure 141
- Tire identification marks 145
- Wheel/tire condition 146
- Replacing wheels/tires 148
- Snow chains 149

### Under the hood:

- Hood 150
- Engine compartment essentials 151
- Washer fluid 152
- Engine oil 152
- Coolant 154
- Brake fluid 155

### Care and maintenance:

- The BMW Maintenance System 156
- OBD interface socket 157

## Owner service procedures

### Replacement procedures:

- Onboard tool kit 160
- Windshield wiper blades 160
- Lamps and bulbs 161
- Changing a wheel 165
- Vehicle battery 171
- Fuses 172

### Assistance, giving and receiving:

- Receiving assistance 173
- Jump starting 174
- Tow-starting and towing 175

## Technical data

- Engine specifications 180
- Dimensions 181
- Weights 182
- Capacities 183

## Index

- Everything from A to Z 186

## 8 Notes

### About this Owner's Manual

We have made every effort to ensure that you are able to find what you need in this Owner's Manual as quickly as possible. The fastest way to find certain topics is by using the detailed index at the end. If you desire an initial overview of your vehicle, this can be found in the first chapter.

Should you want to sell your BMW some day, please remember to hand over the Owner's Manual as well; it is an important component of your vehicle.

#### Additional sources of information:

If you have any questions, your BMW Sports Activity Vehicle center will be glad to advise you.

You can find information on BMW, e.g. technology, on the Internet at [www.bmwusa.com](http://www.bmwusa.com).

### Symbols used

 Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.

 Indicates information that will assist you in gaining the optimum benefit from your vehicle and enable you to care more effectively for your vehicle.

 Refers to measures that can be taken to help protect the environment.

◀ Marks the end of a specific item of information.

\* Indicates special equipment, country-specific equipment and optional extras, as well as equipment and functions not yet available at the time of printing.

 Vehicle Memory, Key Memory, refer to page 61. Identifies functions that can be specifically adapted for a particular key or vehicle. These adjustments can be performed by your BMW Sports Activity Vehicle center.

### Your individual vehicle

On buying your BMW, you have decided in favor of a model with individualized equipment and features. This Owner's Manual describes all models and equipment that BMW offers within the same group.

We hope you will understand that equipment and features are included that you might not have chosen for your vehicle. Sections describing options and special equipment are marked by an asterisk \* to assist you in identifying possible differences between the descriptions in this manual and your own vehicle's equipment.

Should equipment of your BMW not be described in this Owner's Manual, please refer to the included Supplementary Owner's Manuals.

# Notes

## Status at time of printing

BMW pursues a policy of continuous, ongoing development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards combined with advanced, state-of-the-art technology. Thus in rare circumstances, the features described in this Owner's Manual may differ from those of your vehicle.

## For your own safety

Maintenance and repair:

 Advanced technology, e.g. the use of modern materials and high-performance electronics, requires specially adapted maintenance and repair methods. Therefore, only have corresponding work on your BMW carried out by a BMW Sports Activity Vehicle center or a workshop that works according to BMW repair procedures with correspondingly trained personnel. If work is carried out improperly, there is a danger of consequential damage and the related safety risks.◀

California Proposition 65 Warning:

California laws require us to state the following warning:

 Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to

cause cancer and birth defects or other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. Batteries also contain other chemicals known to the State of California to cause cancer. Wash your hands after handling.

Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.◀

Parts and accessories:

 For your own safety, use genuine parts and accessories approved by BMW.

When you purchase accessories tested and approved by BMW and Genuine BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle.

BMW warrants these parts to be free from defects in material and workmanship.

BMW will not accept any liability for damages resulting from installation of parts and accessories not approved by BMW.

## 10 Notes

BMW cannot test every product on the market to determine whether it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants.

Genuine BMW Parts, BMW Accessories and other products approved by BMW, together with professional advice on using these items, are available from all BMW Sports Activity Vehicle centers. Installation and operation of non-BMW approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones – including operation of any mobile phone from within the vehicle without using an externally mounted antenna – or transceiver equipment such as CBs, walkie-talkies, ham radios or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. Refer to your BMW Sports Activity Vehicle center for additional information.◀

 Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part.◀

### Symbol on vehicle parts

 Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

### Service and Warranty

This manual is supplemented by a Service and Warranty Information Booklet for US models or a Warranty and Service Guide Booklet for Canadian models.

We recommend that you read this publication thoroughly.

Your BMW is covered by the following warranties:

- ▷ New Vehicle Limited Warranty
- ▷ Rust Perforation Limited Warranty
- ▷ Federal Emissions System Defect Warranty
- ▷ Federal Emissions Performance Warranty
- ▷ California Emissions Control System Limited Warranty

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

# Notes

## Reporting safety defects

For US customers:

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-800-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>

For Canadian customers:

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may telephone the toll-free hotline 1-800-333-0510, or contact Transport Canada by mail at: Transport Canada, ASFAD, Place de Ville Tower C, 330 Sparks Street, Ottawa ON K1A 0N5.



## Overview

[Controls and features](#)

[Operation, maintenance](#)


[Owner service procedures](#)

[Technical data](#)

[Index](#)



## 14 Cockpit



- 530de427
- 1 Parking lamps/low beams 100
  - 2 Fog lamps 102
  - 3 ▷ Turn signals 68
    - ▷ Roadside parking lamps 101
    - ▷ High beams 101
    - ▷ Headlamp flasher 68
    - ▷ Computer 79
  - 4 Washer/wiper system/rain sensor 69
  - 5 Rear window defroster 105, 110
  - 6 Central locking system 30
  - 7 Hazard warning flashers
  - 8 Horn: the entire surface
  - 9 Adjusting steering wheel 52



1 Fuel gauge [75](#)

2 Indicator lamp for turn signals [22](#)

3 Speedometer

4 Indicator and warning lamps [19](#)  
to [22](#)

5 Tachometer [74](#)

Energy control [74](#)

6 Coolant temperature gauge [76](#)


## 16 Instrument cluster X5 3.0i, 4.4i



- 7 Indicator and warning lamps [19](#) to [22](#)  
8 Reset button for trip odometer [73](#)  
9 Display for Check Control [77](#)  
10 Odometer and trip odometer [73](#)


- 11 Display for computer; operation via turn signal lever, refer to page [79](#):  
▷ Outside temperature  
▷ Average fuel consumption  
▷ Cruising range  
▷ Average speed

- 12 Service Interval Display [76](#)  
13 Selector lever and program display for automatic transmission\* [65](#)  
14 Indicator and warning lamps [19](#) to [22](#)



- 1 Fuel gauge [75](#)
- 2 Indicator lamp for turn signals [22](#)
- 3 Speedometer
- 4 Indicator and warning lamps [19](#) to [22](#)
- 5 Tachometer [74](#)  
Energy control [74](#)
- 6 Coolant temperature gauge [76](#)
- 7 Indicator and warning lamps [19](#) to [22](#)
- 8 Reset button for trip odometer [73](#)
- 9 Service Interval Display [76](#)
- 10 Display for
  - ▷ Trip odometer/odometer [73](#)
  - ▷ Outside temperature [73](#)
- 11 Display for Check Control [77](#)
- 12 Selector lever and program display for automatic transmission\* [65](#)
- 13 CHECK button [77](#)
- 14 Indicator and warning lamps [19](#) to [22](#)

## 18 Instrument cluster X5 4.8is



- 530is252
- 1 Fuel gauge [75](#)
  - 2 Indicator lamp for turn signals [22](#)
  - 3 Speedometer
  - 4 Indicator and warning lamps [19](#) to [22](#)
  - 5 Tachometer [74](#)  
Engine oil temperature gauge
  - 6 Coolant temperature gauge [76](#)
  - 7 Indicator and warning lamps [19](#) to [22](#)
  - 8 Reset button for trip odometer [73](#)
  - 9 Service Interval Display [76](#)
  - 10 Display for
    - ▷ Trip odometer/odometer [73](#)
    - ▷ Outside temperature [73](#)
  - 11 Display for Check Control [77](#)
  - 12 Selector lever and program display for automatic transmission [65](#)
  - 13 CHECK button [77](#)
  - 14 Indicator and warning lamps [19](#) to [22](#)

# Indicator and warning lamps

## Technology that monitors itself

Indicator and warning lamps that are identified by ● are tested for proper functioning whenever the ignition key is turned. They each light up once for different periods of time.

If a malfunction should occur in one of the monitored systems, the corresponding lamp will not go out after the engine is started or it will light up while the vehicle is moving. The section below will instruct you on what to do in this situation.

## Red: stop immediately



Battery charge current ●  
The battery is not being charged. There is a malfunction of the alternator drive belt or in the charging circuit of the alternator. Have the system checked immediately.



If the drive belt is defective, do not continue driving. The engine could be damaged due to overheating. When the drive belt is defective, you will also have to exert increased steering effort.◀



Engine oil pressure ●  
Stop immediately and switch off the engine. Check the engine oil level; top up as required. If the oil level is correct: have the system checked immediately.



Do not continue driving. The engine could be damaged due to inadequate lubrication.◀



Handbrake\*/  
brake hydraulic system ●  
Lights up with handbrake engaged.  
For additional information, refer to page 64



Lights up although the handbrake is released: stop immediately. The brake fluid in the reservoir has fallen to below the minimum level. At the same time, a considerably longer brake pedal travel may be noticeable. Have the system checked immediately.



During continued driving, increased brake pedal pressure may be necessary and considerably longer braking distances may result. Please remember to adapt your driving style accordingly.◀



Before continuing your journey, be sure to read the notes on pages 140 and 155.

Also lights up in the Check Control with the message CHECK BRAKE LININGS.



Display of the previously described malfunction in Canadian models.

## 20 Indicator and warning lamps



Transmission temperature\* ●  
The transmission is overheated.  
Reduce speed immediately and  
stop at a suitable location so that the  
system can cool down again. Have the  
system checked immediately.

### Yellow: stop immediately



Flat Tire Monitor ●  
An acoustic signal also sounds:  
there is a flat tire or extensive  
inflation pressure loss. Reduce speed  
immediately for stopping while avoiding  
extreme braking and steering maneu-  
vers.

For additional information, refer to  
page 99

### Red or yellow: continue to drive cautiously



The red brake warning lamp  
lights up together with the warn-  
ing lamps for ABS and DSC/  
xDrive. In addition, a warning  
signal sounds:  
ABS, DSC, HDC and xDrive  
have failed. Drive may be being  
exerted exclusively via the rear  
axle. Have the system checked  
as soon as possible.  
For additional information, refer to  
pages 91, 92

Proceed cautiously and defen-  
sively. When driving on poor  
roads, avoid using full throttle or press-  
ing the accelerator beyond the kick-  
down point and also avoid forceful  
braking or full braking. Otherwise, the  
drive train may be damaged or acci-  
dents can occur.◀

If the brake warning lamp lights up in  
yellow in the above-described combi-  
nation, the EBV Electronic brake-force  
distribution is still available.



Display of the previously  
described malfunction in Cana-  
dian models.

# Indicator and warning lamps

## Red: an important reminder



Handbrake\*

Lights up with handbrake engaged.

For additional information, refer to page 64



Handbrake warning lamp\* for Canadian models



Please fasten safety belts ●

Indicator lamp flashes or lights up. In addition, a signal sounds and, depending on the equipment, a message\* appears in the Check Control. Please check safety belts for correct placement.

The belt reminder is activated when the safety belt on the driver's side has not yet been fastened.

The belt reminder is also active at speeds greater than approx. 5 mph/8 km/h when the passenger belt has not yet been fastened, heavy objects are placed on the front passenger seat, or passengers sitting in the front remove their safety belts.

For additional information on safety belts, refer to page 49



Airbags ●

Malfunction in airbag system. Have the system checked as soon as possible.

For additional information, refer to page 55



DBC Dynamic Brake Control ●

Malfunction in the DBC system. Please have the system checked as soon as possible.

For details on DBC, refer to page 91



Display of the previously described malfunction in Canadian models.



Engine oil level

Comes on while driving: the oil level is at the absolute minimum; refill as soon as possible. Do not drive more than approx. 30 miles/50 km until you do.

For additional information, refer to page 152



Engine oil level

Comes on after the engine has been switched off: add engine oil at your earliest opportunity, e.g. when you stop to refuel.

For additional information, refer to page 152



Automatic transmission\*

The automatic transmission switches into the emergency program due to a malfunction. Have the system checked as soon as possible. For additional information, refer to page 67



Brake pads\*

Have the condition of the brake pads checked.

For additional information, refer to page 140



Self-leveling suspension\*

The self-leveling suspension is inactive. Have the system checked as soon as possible.

For additional information, refer to page 95

## 22 Indicator and warning lamps



DSC Dynamic Stability Control/  
xDrive ●

The warning lamp lights up continuously and a warning signal sounds: DSC and HDC or the xDrive 4-wheel drive system have failed.

The stabilizing interventions of DSC or the xDrive 4-wheel drive system are no longer available. Drive may be being exerted exclusively via the rear axle. Have the system checked as soon as possible.

For additional information, refer to page 92



Proceed cautiously and defensively. When driving on poor roads, avoid using full throttle or pressing the accelerator beyond the kick-down point and also avoid forceful braking or full braking. Otherwise, the drive train may be damaged or accidents can occur. ◀



Engine electronics\*

Malfunction in the engine electronics. You can continue to drive with reduced engine output or engine speed. Have the system checked as soon as possible.



Service Engine Soon ●

If the indicator lamp lights up continuously or intermittently, there is a malfunction in the exhaust-relevant electronic systems. Although the vehicle remains operable, the system must be checked as soon as possible.

For additional information, refer to page 157



Display of the previously described malfunction in Canadian models.



Check Gas Cap\* ●

Warning lamp lights up. Fuel filler cap is not properly closed or is missing. Check whether the fuel filler cap is properly closed. For additional information, refer to page 25

### Green: for your information



Turn signals

Flashes when the turn signals are operated. Rapid flashing indicates a system malfunction.

For additional information, refer to page 68



Cruise control\*

Lights up when system is switched on: ready for operation using the buttons on the steering wheel.

For additional information, refer to page 71



Fog lamps

Lights up when fog lamps are switched on. For additional information, refer to page 102

### Blue: for your information



High beams

Lights up when the high beams are on or the headlamp flasher is actuated.

For additional information, refer to pages 68, 101

## Buttons on steering wheel\*

The buttons integrated into the steering wheel are provided so that you can operate a number of accessories quickly and without being distracted from traffic conditions. You may operate:

- ▷ selected functions of the audio sources\*
- ▷ the recirculated-air mode of the air conditioner\* or the steering-wheel heater\*
- ▷ the cruise control
- ▷ selected phone functions\* and the voice command system\*.

 In order to operate a system, the corresponding system must be switched on.◀



Press briefly:  
Accept incoming call, start dialing, terminate call.

Extended pressure:  
Switch voice command system on and off



Display/hide phonebook. Display the entries consecutively with the buttons for forward/back



Forward:

- ▷ Radio  
Press briefly: next stored station  
Extended pressure: station search function
- ▷ CD  
Press briefly: track search  
Extended pressure: fast forward in track
- ▷ Cassette  
Press briefly: stop track search or fast forward  
Extended pressure: fast forward
- ▷ Telephone  
Scroll through list of names



Reverse: functions the same as fast forward



Volume

On the sports steering wheel\*, there are +/- buttons for volume on the left side of the steering wheel.



Cruise control: resume



Cruise control: store and accelerate + as well as store and decelerate -

On the sports steering wheel\*, there are +/- buttons on the right side of the steering wheel for the cruise control.



Cruise control: activate/interrupt/deactivate



Recirculated-air mode\* and AUC automatic recirculated-air control or steering wheel heater\*: switch on/off

## 24 Warning triangle\*




1. Open the cover on the left in the cargo area by lifting the handle on the cover
2. Pull the tab of the retaining strap, refer to arrow, and remove the hazard warning triangle from the support bracket
3. To install: slide the hazard warning triangle into the support bracket and press on the retaining strap.

## First-aid kit\*



- The first-aid kit is located under the front passenger's seat.
- To open: pull the handle and fold the cover down.
- To close: fold the cover up.
- Some of the articles in the first-aid kit may be used within a limited time only. Therefore, check the expiration dates of the contents regularly and replace the contents concerned in good time as needed.

## Refueling



### Fuel filler door

Before filling the tank, switch off the engine. If you do not, fuel cannot be added to the tank and the Service Engine Soon lamp may come on.◀

To open the fuel filler door, press on the front edge.

In the event of an electrical malfunction, you can also open the fuel filler door manually:

1. Open the cover on the right in the cargo area by lifting the handle on the cover
2. Pull the knob with the fuel pump symbol.

## Refueling

**⚠** When handling fuels, always observe any safety guidelines posted at the service station. Never carry spare fuel containers in your vehicle. Whether empty or full, these containers can leak, cause an explosion, or lead to fire in the event of a collision. ◀



### Observe the following when refueling

**⚠** Open the filler cap carefully to prevent fuel from spraying out. Fuel spray may cause injury. Do not top off. Topping off may cause fuel spillage. ◀

Keep the filler cap in the bracket attached to the fuel filler door.

When refueling, insert the filler nozzle completely into the filler pipe. Pulling the nozzle out of the pipe during refueling

- ▷ results in premature pump shutoff
- ▷ and will reduce the effect of the vapor recovery system on the pump.

The fuel tank is full when the filler nozzle clicks off the first time.

To close the fuel filler cap:  
Fit the cap and turn it clockwise until you clearly hear a click.

**⚠** Close the filler cap carefully after refueling until a click is heard. While closing, be sure not to jam the strap attached to the cap between the gas cap and the vehicle. A loose or missing cap will activate the message CHECK GAS CAP in the Check Control\* or the Check Gas Cap lamp\*. ◀

Tank capacity:  
approx. 24.6 gal./93 liters,  
including a reserve of:  
6-cylinder engine: approx. 2.0 gal./  
8 liters:  
8-cylinder engine: approx. 2.5 gal./  
10 liters.

**⚠** Never attempt to continue driving until the tank is completely empty, as engine functions could be affected, and the vehicle could sustain damage as a result. ◀

## 26 Fuel specifications

The engine uses lead-free gasoline only.

### Required fuel

Premium Unleaded Gasoline,  
Minimum Octane Rating: 91.

Minimum Octane Rating corresponds to the Anti Knock Index AKI and is determined according to the so-called (R+M)/2 method.

 Do not use leaded gasoline: use of leaded fuel will permanently damage the lambda probe and catalytic converter of your vehicle.◀

### Use high-quality brands

Field experience has indicated significant differences in fuel quality: volatility, composition, additives, etc., among gasolines offered for sale in the United States and Canada. Fuels containing up to and including 10% ethanol or other oxygenates with up to 2.8% oxygen by weight, that is, 15% MTBE or 3% methanol plus an equivalent amount of co-solvent, will not void the applicable warranties with respect to defects in materials or workmanship.




The use of poor-quality fuels may result in drivability, starting and stalling problems, especially under certain environmental conditions such as high ambient temperature and high altitude.

Should you encounter drivability problems that you suspect could be related to the fuel you are using, we recommend that you respond by switching to a recognized high-quality brand.

Failure to comply with these recommendations may also result in unscheduled maintenance.◀





**Overview**


**Controls and features**

**Operation, maintenance**

**Owner service procedures**

**Technical data**

**Index**



### The key set

1 Each master key with remote control contains a long-life battery as a power supply, which is automatically recharged in the ignition lock while driving. It is therefore necessary to use each master key at least twice per year in order to maintain the charge. Depending on which master key the vehicle detects during unlocking, different settings will be requested and executed in the vehicle, refer to Vehicle and Key memory on page 61.

2 Spare key for storage in a safe place, such as in your wallet.

This key does not fit in the lock of the glove compartment. This is an advantage in a hotel, for example. The key is not intended for continuous use.

### Replacement keys

Additional or replacement keys are available at your BMW Sports Activity Vehicle center.

### The concept

The central locking system is ready for operation as soon as you close the front doors. The system engages or releases the locks on the

- ▷ doors
- ▷ liftgate/tailgate
- ▷ fuel filler door.

The central locking system can be operated

- ▷ from outside via the remote control as well as via the driver's door lock
- ▷ from inside via the button for the central locking system.

If the system is locked from inside, the fuel filler door remains unlocked, refer to page 34.

When the system is actuated from outside of the vehicle, the anti-theft system is actuated simultaneously. This prevents the doors from being unlocked via lock buttons or door handles. The alarm system is also armed or disarmed.

In an accident of sufficient severity the central locking system automatically unlocks, but only doors which have not been locked separately with the lock buttons, refer to page 34. In addition, the hazard warning flashers and the interior lamps are switched on.

# Opening and closing: from outside

## Using remote control

When you engage/release the vehicle locks, you also activate/deactivate the anti-theft system, arm/disarm the alarm system, and switch the interior lamps on/off.

 Protect the remote control against unauthorized use by handing over only the spare key, for example when using hotel valet parking.◀

You can find more detailed information on the alarm system on page 38.

 Since passengers or animals remaining in the vehicle might be able to lock the doors from the inside, take the vehicle's keys with you so that the vehicle can be opened again from the outside at any time.◀

## Unlocking vehicle



Press the button.

Press the button once to unlock the driver's door and the fuel filler door only; press a second time to unlock all remaining doors as well as the liftgate/tailgate.

## Convenience opening mode



Press the button briefly and then hold down.

The windows and the panorama glass roof open.

## Locking and securing



Press the button.

As a confirmation that the vehicle is correctly locked, the hazard warning flashers light up.

 If you so desire, you can have this function deactivated if your vehicle is not equipped with an alarm system.◀

## Switching on interior lamps



If the vehicle is locked, press the button.

With this function, you can also search for your vehicle, e.g. when parked in an underground garage.

## Switching off tilt alarm sensor and interior motion sensor



Press the button once again immediately after locking.

For more detailed information, refer to page 39.

## Opening liftgate



Briefly press the button.

The liftgate will open slightly, regardless of whether it was previously locked or unlocked.

## 32 Opening and closing: from outside

 If the vehicle is locked, the liftgate is also locked again when closed. Before and after a trip, be sure that the liftgate was not opened unintentionally.◀

### Panic mode



When the alarm system is armed, you can trigger an alarm in response to an impending danger by pressing and holding the button for more than two seconds.

To switch off the alarm



Press the button.

### Malfunction

The remote control can be subjected to malfunctions by local radio waves. Should the remote control fail to operate owing to interference of this kind, unlock and lock the vehicle via the door lock using the master key.

If it is no longer possible to lock the vehicle via the remote control, the battery is discharged. Use this remote control during an extended drive; this will recharge the battery, refer to page 30.

### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

FCC ID: LX8EWS  
LX8FZVS  
LX8FZVE


#### Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- ▷ This device may not cause harmful interference, and
- ▷ this device must accept any interference received, including interference that may cause undesired operation.

 Any unauthorized modifications to these devices could void the user's authority to operate the equipment.◀

# Opening and closing: from outside



## Using door lock

One turn of the key in the driver's door lock unlocks the driver's door only.

Turning the key a second time unlocks all of the remaining doors, the liftgate/tailgate and the fuel filler door.

As a confirmation that the vehicle is correctly locked, the hazard warning flashers light up.



If you so desire, you can deactivate this function if your vehicle is not equipped with an alarm system.◀

## Convenience operation

You also have the option of operating the windows and the panorama glass roof from the door lock.

- ▷ To open: with the door closed, turn the key to the Unlock position and hold it.
- ▷ To close: with the door closed, turn the key to the Lock position and hold it.

**⚠** Watch during the closing process to be sure that no one is injured.  
Releasing the key stops the operation.◀

## Manual operation

In the event of an electrical malfunction, turn the key to the extreme left or right to unlock/lock the door.

## 34 Opening and closing: from inside



This button serves to unlock or lock doors and the liftgate, but does not activate the anti-theft system. The fuel filler door remains unlocked.

 You have the option of setting the central locking system to lock automatically as soon as you begin to drive. This can be set to be key-specific.◀

- ▶ If only the driver's door was unlocked from the outside and you press the button
  - ▷ all other doors, the liftgate/tailgate and the fuel filler door will be unlocked when the driver's door is opened
  - ▷ the driver's door will be locked again when it is closed.◀

### Unlocking and opening doors

- ▷ Either unlock the doors together with the button for the central locking system and then pull the door handle above the armrest or
- ▷ pull the release handle for each door twice: the first pull unlocks the door, and the second one opens it.

### Locking


- ▷ Use the central locking button to lock all of the doors simultaneously, or
- ▷ press down the individual lock buttons. As an added design feature to prevent the driver from being inadvertently locked out of the vehicle, the driver's lock button will not engage as long as the door is open.



When the vehicle is moving, do not lock the doors with the lock buttons. Doors locked in this manner would not unlock automatically in the event of an accident.

Since passengers or animals remaining in the vehicle might be able to lock the doors from the inside, take the vehicle's keys with you so that the vehicle can be opened again from the outside at any time.◀

# Liftgate



## Opening from outside

Press the button, refer to arrow:  
The liftgate opens slightly.

The cargo area is illuminated whenever  
the liftgate is opened, refer also to  
page [103](#).

 With the liftgate open, the distance from the ground to the upper edge is more than 6.6 ft/2 m.  
Please remember this, e.g. when opening the liftgate in a garage.◀



## Opening from inside

Press this button to open the liftgate  
when the vehicle is stationary.

 If pointed or sharp-edged objects  
could strike the rear window while  
driving, be sure to provide protection  
around all edges. Failure to do so could  
result in damage to the heating conductors  
of the rear window.◀


For information on the cargo area cover  
and on other details in the cargo area,  
refer to Cargo area, beginning on  
page [124](#).



## Manual release

In the event of an electrical malfunction,  
you can release the liftgate manually:

1. Remove the plastic plug from inside  
the cargo area and pull toward the  
interior, refer to arrow. The liftgate  
will be released
2. Reinstall the plug.




### Closing

You can pull the liftgate down by placing both hands in the handle recesses, refer to arrows.

### Automatic Soft Close function

To close the liftgate, merely press it down gently. The closing process will then be carried out automatically.


**⚠** To avoid injuries, be sure that the travel path of the liftgate is clear when it is closed, as with all closing procedures.◀



### Opening

Press the button:  
You can fold the tailgate down.

**▶** When opened, the tailgate can accept loads of up to 440 lbs./200 kg. When the vehicle is stationary you may, for example, utilize the tailgate as a seat or as a loading platform for luggage or recreation gear.◀




### Manual release


In the event of an electrical malfunction, you can release the tailgate manually:

1. Unfasten the trim panel clip with the vehicle key or with a screwdriver, refer to arrow 1, and remove it toward the top, refer to arrow 2

# Tailgate



2. Using the same tool, press the latch in the direction of the arrow; the tailgate is released
3. Reinstall the trim panel.



## Luggage straps

Use the luggage straps on the cargo floor cover to secure smaller items of luggage.

Movement is reduced when objects are placed on the straps.

The lashing eyes located at the corners of the cargo area provide you with a convenient means of attaching luggage nets\* or flexible straps for securing luggage.

Refer also to Cargo loading on page [130](#).

## 38 Alarm system

### The concept

The vehicle alarm system responds:

- ▷ When a door, the hood or the liftgate is opened
- ▷ To movement in the vehicle interior: interior protection, refer to Tilt alarm sensor and Interior motion sensor
- ▷ To variations in the vehicle tilt angle such as occur during attempts to steal the wheels or tow the vehicle
- ▷ To interruption of battery voltage.

The system responds to unauthorized vehicle entry and attempted theft by simultaneously activating the following:

- ▷ An acoustical alarm, which sounds for 30 seconds
- ▷ The hazard warning flashers, which flash for approx. five minutes
- ▷ The high beams, which flash on and off in the same rhythm as the hazard warning flashers.


### Arming and disarming alarm system

When you lock or unlock the vehicle, either with the remote control or at the door lock, the alarm system is armed or disarmed at the same time.

 You can have different acknowledgement signals set to confirm arming and disarming. ◀



The liftgate can also be opened with the system armed using the button on the remote control, refer to page 31. The liftgate is locked again when closed. Pressing the button longer triggers the alarm: panic mode, refer to page 32.



### Indicator lamp displays

- ▷ The indicator lamp below the interior rearview mirror flashes continuously: the system is armed.
- ▷ The indicator lamp flashes when the vehicle is locked: the doors or liftgate are not properly closed. Even if you do not close the alerted area, the system begins to monitor the remaining areas, and the indicator lamp flashes continuously after 10 seconds. However, the interior motion sensor is not activated.
- ▷ The indicator lamp goes out when the vehicle is unlocked: no manipulation or attempted intrusions have been detected in the period since the system was armed.

# Alarm system

- ▷ The indicator lamp flashes for 10 seconds after the vehicle is unlocked: an attempted entry has been detected in the period since the system was armed.

Following triggering of an alarm, the indicator lamp will flash continuously.

## Tilt alarm sensor

The tilt of the vehicle is monitored. The alarm system reacts, for example, if someone attempts to steal the wheels or tow the vehicle.

## Interior motion sensor

In order for the interior motion sensor to function properly, the windows and panorama glass roof must be completely closed.

## Avoiding unintentional alarms

The tilt alarm sensor and interior motion sensor may be switched off at the same time. This prevents unintentional alarms, e.g. in the following situations:

- ▷ In duplex garages
- ▷ When transporting on car-carrying trains
- ▷ If animals are to remain in the vehicle.

To switch off the tilt alarm sensor and interior motion sensor:



Press the button on the remote control twice consecutively.

The indicator lamp lights up briefly and then flashes continuously. The tilt alarm sensor and the interior motion sensor are switched off until the next unlocking and locking actions are executed.

# Windows



**⚠** To prevent injuries, exercise care when closing the windows and keep them in your field of vision until they are shut.

Always take along the ignition key when you leave the vehicle, as otherwise children could, for example, operate the windows and injure themselves.◀

## Opening and closing windows

As of ignition key position 1:

- ▷ Press the switch up to the resistance point:  
The window continues to move downward as long as you continue to hold the switch
- ▷ Briefly press the switch beyond the resistance point:  
The window moves downward auto-

matically. Briefly press the switch again to stop the opening movement.

You can close the windows in the same manner by pulling the switch.

After the ignition has been switched off:

You can still operate the windows for approx. 1 minute, as long as no door has been opened.

For the convenience mode via the remote control or the door lock, refer to pages [31](#), [33](#).

### Anti-trapping mechanism

A contact strip is integrated into the inner side of each of the upper window frame sections. If pressure is exerted against this contact strip while a window is being raised, the system will respond by stopping the window and then retracting it a small distance.

**⚠** Despite the anti-trapping mechanism, be extremely careful that the closing path of the window is not obstructed whenever it is closed. Otherwise, an object might not touch the contact strip in some situations, with very thin objects, for instance. You can disable the anti-trapping mechanism by pulling the switch beyond the resistance point and holding it.

Because the power windows are sealed at high pressure to prevent wind noise when closed, a powerful motor is required for efficient closing. When closing the windows, always ensure that they are not obstructed in any way. Unsupervised use of these systems can result in serious personal injury. Remove the ignition key to deactivate the power windows whenever you leave the vehicle. Never leave the keys in the vehicle with unsupervised children. Never place anything that could obstruct the driver's vision on or next to the windows.◀



### Safety switch


With the safety switch, you can prevent the rear windows from being opened or closed via the switches in the rear passenger area, by children, for example. You can also prevent adjustments of the power rear-seat backrests from the rear passenger area, refer to page [48](#).

**⚠** Always press the safety switch when children ride in the rear, otherwise unchecked closing of the windows could lead to injuries.◀

## Panorama glass roof\*

**⚠** To avoid bodily injuries, be sure to watch the panorama glass roof while closing. Always take along the ignition key when you leave the vehicle, as otherwise children could, for example, operate the roof and injure themselves.◀

The panorama glass roof is operational with the ignition key in position 2.



### Raising, opening, closing

Press the switch or slide it in the desired direction up to the resistance point.

Release the switch to stop the motion.

The sliding visor is opened slightly when the panorama glass roof is raised.

The panorama glass roof can be opened or closed independently with the sliding visor open.

Ventilation setting:

The panorama glass roof is raised and the sliding visor is opened slightly: Briefly press the switch twice consecutively.

After the ignition has been switched off: You can still operate the roof for approx. 1 minute, as long as no door has been opened.

### Automatic opening and closing

Briefly press the switch beyond the resistance point and then release it. Briefly pressing the switch again stops the motion.

Opening and closing panorama glass roof and sliding visor together:

Briefly press the switch beyond the resistance point twice consecutively. Briefly pressing the switch again stops the motion.

## 42 Panorama glass roof\*

### Comfort position

Each time the panorama glass roof is completely opened or closed, it stops in the comfort position. Use the switch to continue the motion after this if you wish.

In the comfort position, the wind noises in the interior are reduced.


### Anti-trapping mechanism

If the panorama glass roof or sliding visor encounter resistance when closing from roughly one third of the roof opening or when closing from the raised position, the closing action is interrupted and the panorama glass roof and sliding visor reopen a little.

**⚠** Despite the anti-trapping mechanism, inspect the roof's travel path prior to closing it, as the safety system might fail to detect certain kinds of obstructions, such as very thin objects, and the roof would continue closing. The anti-trapping mechanism for closing the panorama glass roof is deactivated if the switch is pressed beyond the resistance point and held there. The closing action is interrupted when you release the switch.◀

### Following a power failure

Following interruptions in electrical power, for instance when the battery is disconnected, it is possible that the panorama glass roof will extend to its tilt-up position, but fail to respond to other commands. The system must be initialized. BMW recommends having this work carried out by your BMW Sports Activity Vehicle center.



### Manual operation

In the event of an electrical malfunction, you can operate the panorama glass roof manually.

1. Take the Allen wrench and screwdriver from onboard tool kit, refer to page [160](#)
2. Remove the cover panel on the headliner. To do so, insert the screwdriver from behind slightly off-center and carefully pry the cover out
3. Insert the Allen wrench into the opening provided and turn the panorama glass roof in the desired direction.

# Sitting safely

The ideal sitting position can make a vital contribution to relaxed driving that is as fatigue-free as possible. In conjunction with the safety belts, the head restraints and the airbags, the seat position also plays an important role for the passive safety of the occupants in an accident. To ensure that the safety systems operate with optimized efficiency, we strongly urge you to follow the instructions contained in the section below.

For additional information on transporting children safely, refer to page [57](#).

## Airbags

 Always maintain an adequate distance between yourself and the airbags. Always hold the steering wheel by its rim, with hands at the 9 o'clock and 3 o'clock positions to minimize the risk of injuries to your hands and arms in the event of airbag deployment. No one and nothing is to come between the airbags and the seat occupant. Do not use the cover of the front airbag on the front passenger side as a storage area. Make sure that the front passenger is correctly seated and does not rest feet or legs on the instrument panel, as otherwise leg injuries can occur if the front airbag is triggered.

Make sure that the occupants do not rest their heads on side or head airbags, as otherwise injuries can occur if the airbags are triggered. ◀

Even if you adhere to all instructions, injuries resulting from contact with airbags cannot be fully excluded, depending on the circumstances. The ignition and inflation noise may provoke a mild – usually temporary – hearing loss in extremely sensitive individuals.

For airbag locations and additional information on airbags, refer to page [55](#).

## Head restraint

A correctly adjusted head restraint reduces the risk of cervical injuries in accidents.

 Adjust the head restraint so that its center is approximately at the height of the ears, as otherwise there is an increased risk of injury in an accident. ◀

## Safety belt

For every trip, use the safety belt on all occupied seats. Airbags complement the safety belt as an additional safety device, but they do not represent a substitute.

Your vehicle has five seats that are all equipped with a safety belt.

 At all times, occupants should sit upright and be properly restrained – infants and small children in appropriate child-restraint systems; larger children and adults using the safety belts. Each safety belt should always be used by only one person; babies and children may not ride on the lap of another passenger.

In addition, pregnant women should always wear a safety belt, making especially sure that the belt rests low on the hips in the lap area, and does not press against the abdomen.

Do not route the belt across your neck or run it across sharp edges. Be sure that the belt does not become caught or jammed. Wear the safety belt without twisting, snugly across the lap and shoulders, as close to the body as possible. Be sure not to route it over solid or breakable objects, otherwise the belt can slip over the hips in the lap area in a

frontal impact and injure the abdomen. Avoid wearing clothing that prevents the belt from fitting properly and pull the belt in the upper body area periodically to readjust the tension in order to avoid a reduction in the restraint of the safety belt.◀

If the middle safety belt in the rear is used, the wider seatback must be locked, refer to page 124, otherwise the safety belt has no restraining action. Fasten safety belt, refer to page 49.

## Seats

### Note before adjusting



Never try to adjust your seat while operating the vehicle. The seat could respond with unexpected movement and the ensuing loss of vehicle control could lead to an accident. On the front passenger side as well, do not tilt the backrest too far toward the rear while driving. Failure to observe this precaution can prevent the belt from providing effective protection against injury, as the passenger could slide under the belt in an accident.◀


Also observe the information on the safety belts on page 49 and on the head restraints on page 47.

### Seat adjustment

- ▷ Mechanical seat adjustment, refer to following columns
- ▷ Power seat adjustment, refer to page 46
- ▷ Head restraints, refer to page 47
- ▷ Power rear-seat backrest adjustment, refer to page 48

# Mechanical seat adjustment

45



## Seat adjustment

### 1 Backward/forward

Pull the lever and slide the seat to the desired position.

After you release the lever, move the seat forward or backward slightly so that it engages fully.

### 2 Height


Pull the lever and apply weight to or remove weight from the seat as needed.



### 3 Backrest

Pull the lever and apply weight to or remove weight from the backrest as needed.

**⚠ Comply with the adjustment instructions on page 43. Failure to do so could result in diminished personal safety.◀**



## Sports seat\* adjustment

You can also adjust the thigh support:

Pull the lever and adjust the position of the thigh support for your personal comfort.


## 46 Power seat adjustment\*



### Seat adjustment

- 1 Angle
- 2 Backward/forward
- 3 Cushion height
- 4 Backrest angle

Adjust the head restraint manually, refer to page 47.



Comply with the adjustment instructions on page 43. Failure to do so could result in diminished personal safety.◀



### Comfort seat\* adjustment

This seat allows you to make additional adjustments for

- 1 Lumbar support
- 2 Shoulder support
- 3 Head restraint height

Lumbar support:

You can also adjust the contours of the backrest to obtain additional support in the lumbar region.

The upper hips and spinal column receive supplementary support to help you maintain a relaxed, upright sitting position.

- ▷ Increase or decrease curvature: push switch forward or backward.
- ▷ Shift curvature up or down: push switch up or down.

## Power seat adjustment\*



### Shoulder support:

Move the switch in the direction of the arrow to adjust the tilt angle of the shoulder support.

You can use the adjustable upper backrest for supplementary support in the shoulder region. This provides a relaxed sitting position and helps relieve stress on the shoulder muscles.

For optimum adjustment, the following is recommended:

### Driver and front passenger:

1. Adjust the upper backrest section to its extreme rear position
2. Adjust for the optimal sitting position as described on page 43
3. Bring the upper backrest section further forward until your shoulders are well supported.

Front passenger's seat adjusted for relaxed traveling:


1. Adjust the upper backrest section to its extreme rear position
2. Tilt the backrest down to a slightly more horizontal angle
3. Bring the upper backrest section forward until your shoulders are well supported.

**⚠** Make corrections in the forward/backward adjustment of the seat to ensure that the safety belt still fits firmly against your body. If you do not do this, the protection provided by the safety belt may be reduced. ◀

### Head restraint height:

Move the switch in the desired direction.

## Head restraints



A correctly adjusted head restraint reduces the risk of cervical injuries in accidents.


**⚠** Adjust the head restraint so that its center is approximately at the height of the ears, as otherwise there is an increased risk of injury in an accident. ◀

## Adjustments

To adjust the angle of the front head restraints, tilt the head restraint to the desired angle.

To adjust the height of the front or rear head restraints, pull the head restraint up or push it down.

Power height adjustment, refer to page 46.

**Removal – front**


1. Pull the head restraint upward to the stop
2. Press the button, refer to arrow, and remove the head restraint.

**Installation – front**

1. Press the button, refer to arrow, and insert the head restraint into the guides
2. Adjust the head restraint for your personal comfort.

**Removal and installation – rear**

To remove the head restraint, pull it outward with a firm movement. To install it, press it down firmly.



You can make separate adjustments of the backrest tilt angle on the right and left sides.

You can select a comfortable sitting position and also increase the capacity of the cargo area by moving the backrests into their full, upright position.

From the rear seats: press the corresponding switch.


You can prevent adjustments of the power rear-seat backrest from the rear passenger area with the safety switch for the power windows, refer to page 40.◀



From the cargo area: the switches are located on both sides of the cargo area.



In the back, the middle safety belt buckle is provided for use exclusively by the middle passenger. If it is not possible to extract the center belt, this indicates that the larger backrest is not securely locked, refer to page 124. ◀



Comply with the instructions on page 43. Failure to do so could result in diminished personal safety. ◀

Use the safety belts on all occupied seats for every trip. Airbags complement the safety belt as an additional safety device, but they do not represent a substitute.

## Fastening

Make sure you hear the latch plate engage in the belt buckle.

## Releasing

1. Press the red button in the belt buckle
2. Hold the belt firmly
3. Guide the belt back into its reel.

## Safety belt reminder for front seats



Indicator lamp flashes or lights up. In addition, a signal sounds and, depending on the equipment, a message\* appears in the Check Control. Please check to make sure safety belts are correctly fastened.

The belt reminder is activated when the safety belt on the driver's side has not yet been fastened.

The belt reminder is also active at speeds greater than approx. 5 mph/8 km/h when the passenger belt has not yet been fastened, heavy objects are placed on the front passenger seat, or passengers sitting in the front remove their safety belts.

## Safety belt height adjustment

You can adjust the safety belts to fit your own physical dimensions by using the safety belt height adjustment:

Slide the button up or down as required.

Also observe the instructions on adjusting the seats on page 44.

### Damage to safety belts

 If the safety belts are damaged or stretched in an accident: have the entire belt system, including the tensioning mechanisms, replaced at your BMW Sports Activity Vehicle center or at a workshop that works according to BMW repair procedures with correspondingly trained personnel. Have the belt anchorage points inspected for damage at the same time. Failure to observe this precaution may prevent the safety belts from effectively providing optimal protection when needed. If a child-restraint system was in the vehicle during an accident, consult the manufacturer's instructions regarding replacement.◀



You can store and recall three different seat, exterior mirror and steering wheel positions. The illustration shows the buttons on the seat for making these position adjustments.

### Storing

1. Turn the ignition key to position 1 or 2
2. Adjust the desired positions for the seat, exterior mirror and steering wheel
3. Press the **MEMORY** button: LED in the button lights up
4. Press memory button 1, 2 or 3, as desired: LED goes out.

 The adjustment of the lumbar support is not stored in the memory.◀

# Seat, mirror and steering wheel memory\*

## Calling up a stored setting

**⚠** Do not call up a position from the memory while the vehicle is moving. There is a risk of accident from unexpected movement of the seat or steering wheel.◀

### Convenience function:

1. Open the driver's door after unlocking the vehicle or place the ignition key in position 1
2. Briefly press memory button 1, 2 or 3, as desired.

Movement stops immediately when one of the seat-adjustment or memory buttons is activated during the adjustment process.

### Security function:

1. With the driver's door closed and the ignition key either removed or in position 0 or 2
2. Maintain pressure on the desired memory button 1, 2 or 3 until the adjustment process is completed.

**▶** If you press the MEMORY button accidentally: press the button again – the LED goes out.◀



You can have your vehicle programmed to automatically dial in your own individual adjustment settings for the seat, mirrors and steering wheel whenever you use your personal remote control to unlock the vehicle.◀



If you make use of this function, be sure that the footwell behind the driver's seat is unobstructed before unlocking the vehicle. If you fail to do so, any persons or objects behind the seat could be injured or damaged by a rearward movement of the seat.◀



## Passenger-side exterior mirror tilt function

Automatic curb monitor


### Activating:

1. Select the driver's mirror with the mirror selection switch
2. When you engage reverse gear or selector-lever position R, the exterior mirror glass on the front passenger side tilts downward slightly. This allows the driver to see the area immediately adjacent to the vehicle – such as a curb – when parking, etc.

### Deactivating:

Slide the mirror selection switch to the passenger's side position.

## 52 Heated seats\*



### Front

The seat cushion and backrest can be heated when the ignition key is in position 2.

You can call up different heating modes by repeatedly pressing the button.

You can also switch off the higher heating modes directly:

Press the button and hold it slightly longer.



### Rear

The operating concept is the same as for the front heated seats. You can select between two heating modes.

## Steering wheel



### Adjustments

The steering wheel can be moved in any of four directions. Adjust the steering wheel by moving the control lever in the desired direction.



Do not adjust the steering wheel while the vehicle is moving. There is a risk of accident from unexpected movement. ◀

To store the steering wheel setting, refer to Seat, mirror and steering wheel memory on page 50.

## Steering wheel

### Automatic steering wheel adjustment

only in conjunction with seat, mirror and steering wheel memory

In order to make it easier to get into and out of the vehicle, the steering wheel automatically moves into the top position and returns to the driving or memory position.

This automatic feature is influenced by the position of the ignition key and by the driver's door.

## Steering wheel heater\*



The steering wheel heater functions in ignition key position 2.

Press the button to activate or deactivate this system.


The LED in the button lights up when the steering wheel heater is switched on.

If your vehicle is not equipped with steering wheel heater, the button for the recirculated-air mode is located here, refer to page 23.

## Mirrors

### Exterior mirrors

 The mirror on the passenger's side is more curved than the driver's mirror. Objects reflected in the mirror are closer than they appear. Do not attempt to estimate the distance to following traffic based on the view in the mirrors, as otherwise an increased accident risk will result. ◀



- 1 Adjustments
- 2 Switching to the other mirror or to the automatic parking function\*
- 3 Folding mirrors in and out\*

To store the mirror settings, refer to Seat, mirror and steering wheel memory on page 50.

### Adjusting manually

The mirrors can also be adjusted manually by pressing the edges of the mirror glass.

### Folding mirrors in and out

Pressing button 3 allows you to fold mirrors in and out up to a speed of 6 mph/10 km/h. This is advantageous, for example, in narrow streets or for bringing mirrors that have been manually folded-in back into the correct position.

**⚠** Before going through a car wash, fold the exterior mirrors inward manually or using button 3; otherwise they could be damaged, depending on the width of the car wash system.◀

### Automatic heating


Below a certain outdoor temperature, both exterior mirrors are automatically heated when the motor is running or the ignition is switched on.



### Interior rearview mirror

To reduce glare from vehicles behind you when you are driving at night, tilt the mirror by turning the button.

# Airbags



- 1 Front airbags
- 2 Head airbags
- 3 Side airbags for front and rear\*

## Protective action

**⚠** Comply with the instructions on page 43. Failure to do so could result in diminished personal safety.◀

The front airbags supplement the safety belts by helping to provide additional protection for the front-seat occupants in the event of a severe frontal impact in which the protection afforded by the safety belts alone may no longer be sufficient. The head airbag and side airbag help provide protection in the event of a side impact. The respective side airbag is designed to help support the body at

the side of the chest region. The Side Impact Head Protection System protects the head.

The airbags are intentionally not triggered in every impact situation, e.g. not in minor accidents or rear-end collisions.

**▶** Stickers on the rear door frame indicate the status of the rear side airbags. If the status cannot be clearly recognized, or if you want to have the airbags activated/deactivated, please contact your BMW Sports Activity Vehicle center.◀

For information on the correct sitting position, refer to page 43.

**⚠** Do not apply adhesive materials to the cover panels of the airbags, cover them or modify them in any other way.

Do not attempt to remove the airbag restraint system from the vehicle. Do not modify or tamper with either the wiring or the individual components in the airbag system. These include the padded steering wheel hub, the instrument cluster, the side trim panels, the doors and the roof pillars or the sides of the headliner. Do not remove or dis-

mantle the steering wheel yourself. Do not touch the individual components directly after the system has been triggered, otherwise there is a danger of burns. If the airbag restraint system malfunctions, needs to be decommissioned, or has been triggered, only entrust the necessary repair work to a BMW Sports Activity Vehicle center or a workshop that works according to BMW repair procedures with correspondingly trained personnel and has the required explosives permits for testing, repair, dismantling or scrapping of the airbag generators. Unprofessional attempts to service the system could lead to failure in an emergency or undesired airbag activation, either of which could result in personal injury.◀

Warnings and information on the airbags is also provided on the sun visors.

## Automatically deactivating front passenger airbags

The occupation of the seat is detected by evaluating the imprint on the occupied seat surface of the front passenger seat. The front and side airbag on the front passenger side are activated or deactivated accordingly by the system.

 The current status of the front passenger airbag, i.e. deactivated or activated, is indicated by the indicator lamp over the interior rearview mirror, refer to Status of front passenger airbags in the following.◀

 Before transporting a child on the front passenger seat, observe the safety information and handling instructions under Transporting children safely, refer to page 57.

The front and side airbag on the front passenger side can be deactivated for teenagers and adults in certain seat positions; then the indicator lamp for the front passenger airbags lights up. In these cases, change the seat position so that the front passenger airbags are activated and the indicator lamp goes out. If the desired status cannot be produced by changing the seat position, transport the corresponding person on

the rear seat. Do not install protective covers, seat cushions, ball mats or other objects on the front passenger seat which are not specially recommended by BMW. Do not lay objects under the seat which could press against the seat from below. Otherwise a correct evaluation of the occupied seat surface cannot be ensured.◀



## Status of front passenger airbag

One of the illustrated indicator lamps is located above the interior rearview mirror.

The indicator lamp for the front passenger airbags indicates the operating status of the front and side airbag on the front passenger side depending on the seat occupation. The indicator lamp shows whether the front passenger airbags are activated or deactivated.

- ▷ The indicator lamp lights up when a child in a child restraint system intended for the purpose is properly detected on the seat.
- The front and side airbag on the front passenger side are not activated

▷ The indicator lamp does not light up when, for example, a correctly seated person of sufficient height is detected on the seat. The front and side airbag on the front passenger side are activated

▷ The indicator lamp does not light up when the seat is empty.  
The front and side airbag on the front passenger side are not activated.

## Operational readiness of airbag system

 As of ignition key position 1, the warning lamp in the instrument cluster lights up for a short time, thus indicating the operational readiness of the entire airbag system and the safety belt tensioners.

### Airbag system malfunction:

▷ Warning lamp does not light up as of ignition key position 1  
▷ Warning lamp lights up continuously.

 Have the airbag system checked immediately if a malfunction occurs, as otherwise there is a danger of the system failing to respond in the expected manner in an accident of corresponding severity.◀

## Transporting children safely

### The right place for children

 Do not leave children unattended in the vehicle, as otherwise they could endanger themselves and other persons, e.g. by opening the doors.◀

In principle, all seats in your BMW except the driver's seat are suitable for mounting universal child restraint systems for all ages which are approved for the respective age group.

Children always in the rear:

Accident research shows that the safest place for children is on the back seat.

 Only transport children under 13 years of age or less than 5 ft/150 cm tall in the rear in child restraint systems intended for the respective age, weight and height of the child. Otherwise there is an increased danger of injury in an accident.◀

Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint system can no longer be used due to their age, size and weight.

All rear seat positions in your vehicle comply with the recommendations of the standard SAE J1819 for the safe securing of child restraint systems in motor vehicles.

Exception for front passenger seat:

 Should it be necessary to use a child-restraint system on the front passenger seat, the front and side airbags must be deactivated. Otherwise, there is an increased risk of injury for the child when the airbags are triggered, even with a child-restraint system. Your BMW Sports Activity Vehicle center will be happy to advise you.◀

More information on automatic deactivation of the front passenger airbags, refer to page 56.

## Installing child-restraint systems


**!** Follow the child-restraint system manufacturer's instructions when selecting, installing and using child-restraint systems. Otherwise the degree of protection can be reduced. 

Commercially available child restraint systems are designed for securing with a lap belt or with the lap belt section of a three-point belt. Incorrectly or improperly installed child restraint systems can increase the risk of injury for children. Always follow the instructions for installing the system exactly.

On front passenger seat:

**!** Before mounting a child restraint system on the front passenger seat, make sure that the front and side airbag on the front passenger side are deactivated, as otherwise there is an increased risk of injury if the airbags are triggered. 

Before mounting a universal child-restraint system, move the front passenger seat into the highest position to achieve the best possible belt routing. Do not change this seat height.



## Child-restraint system security

All rear safety belts and the safety belt for the front passenger can be locked to prevent them from being pulled out, enabling them to be used for securing child restraint systems.

**Locking safety belt:**

1. Secure child restraint system with the belt
2. Pull out belt webbing completely
3. Allow belt webbing to be pulled in and pull taut against child restraint system. The safety belt is locked.

**Unlocking safety belt:**


1. Open belt buckle
2. Remove child restraint system
3. Allow belt webbing to be pulled in completely

## Child restraint system with tether strap


There are three additional mounting points for child restraint systems with a tether strap, refer to arrows.

# Transporting children safely

59



The illustration shows the fastening of the tether strap for the outer seats.




The illustration shows the fastening of the tether strap for the middle seat.

## Routing of the tether strap:

1. Push head restraint upward
2. Guide securing strap through head restraint bracket
3. Slide the head restraint into the bottom position.

When using the cargo area roll-up cover, also route the tether strap between the rear backrest and the casting of the roll-up cover.



## LATCH child-restraint fixing system

LATCH: Lower Anchor and Tethers for Children.

 To attach a LATCH child's seat, follow the operating and safety instructions of the system manufacturer. ◀

The rear outer seating positions are provided with anchors for a LATCH child-restraint fixing system.

The illustration shows the left rear seat as an example. The mounts for attachment of the LATCH child-restraint fixing system are located behind the cover panels.


## 60 Transporting children safely

Remove cover panels by pulling them toward the front.

To remount, simply slide into place.

### On trips

 If the rear is equipped with side airbags, make sure that children do not lean out of the child's seat towards the door panels. Otherwise severe injuries can be caused if the side airbags are triggered.◀



Child-safety locks of rear doors:

Slide down the safety lever on the rear doors:

The door can now be opened from the outside only.

Safety switch for power windows:

Always press the safety switch for the power windows, refer to page 40, when children are riding in the rear of the vehicle.

# Vehicle Memory, Key Memory

## How the system functions

You have probably frequently wished that you could configure individual functions of your vehicle meet your own personal requirements. In developing your vehicle, BMW has included several user-defined functions in the vehicle's design. Your BMW Sports Activity Vehicle center can make these settings for you.

There are vehicle and person-related adjustments: Vehicle Memory and Key Memory. You can have up to four different basic positions configured for four different persons. The only requirement is that each person uses his or her own remote control key.

When your vehicle is unlocked with the remote control, the vehicle recognizes the individual user by means of a data exchange with the key, and makes adjustments accordingly.

In order for you to distinguish between the master keys with remote control, color-coded decals are supplied together with the keys.

## What the system can do

Your BMW Sports Activity Vehicle center can provide you with details on the capabilities of the Vehicle Memory and Key Memory systems.



You will see this symbol throughout the Owner's Manual. It is to remind you at appropriate places of the settings that are available to you.◀




Following configuration of the memory functions, vehicle operation may differ from the description in the Owner's Manual. Should you want to sell your BMW some day, please remember to have the memory functions reset to the default state.◀

Examples for Key Memory:

- ▷ Automatic adjustment of the driver's seat, exterior mirror and steering wheel with settings stored in the memory for the individual driver when the vehicle is unlocked, refer to page 51
- ▷ Calling up customized settings for the automatic climate control when unlocking the vehicle, refer to page 109.

Examples for Vehicle Memory:

- ▷ Various signals that can serve as acknowledgment for locking and unlocking the vehicle, refer to pages 31, 33
- ▷ Deactivating/activating the Pathway lighting function, refer to page 100.



### Ignition key positions

- 0 Steering lock engaged
- 1 Steering lock disengaged
- 2 Ignition on
- 3 Starting engine

### Steering lock engaged

The key can only be inserted or removed in this position.

After removing the key, turn the steering wheel slightly to the left or right until you hear the lock engage.

If the key is not removed, an acoustic signal sounds after the driver's door is opened.



**Automatic transmission:**  
Only move the selector lever from position P with the engine running. To turn the key back to position 0 or to remove it, first place the selector lever in position P: interlock.◀

### Steering lock disengaged

Slightly moving the steering often makes it easier to turn the key from 0 to 1.

Individual electrical devices are ready for operation.

### Starting engine



**Manual transmission:**  
Depress the clutch when starting the engine. If you do not, a lock prevents the engine from starting.◀

## Starting engine

### Before starting

- ▷ Engage the handbrake
- ▷ Be sure that the gearshift lever is in Neutral or the selector lever in Park if the vehicle is equipped with an automatic transmission
- ▷ Depress the clutch.  
If the clutch is not depressed, the engine cannot be started
- ▷ Press the footbrake with an automatic transmission.



Do not run the engine in closed rooms, otherwise the inhalation of toxic exhaust gases can cause unconsciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless, but highly toxic gas.

Never leave an unattended vehicle with the engine running, as such a vehicle represents a potential safety hazard. To prevent the vehicle from rolling, always select neutral or the position P and engage the handbrake before leaving the vehicle with the engine running.◀

When starting the engine, do not press the accelerator pedal.

# Starting engine

Do not allow the engine to warm up by leaving it running while the vehicle remains stationary. Instead, begin to drive immediately at a moderate engine speed.

## X5 3.0i:

Do not end the starting procedure too soon, but do not continue for longer than approx. 20 seconds. Release the ignition key immediately as soon as the engine starts.

## X5 4.4i, 4.8is:

Your BMW is equipped with the convenience starting feature. With this feature, it is sufficient to turn the ignition key only briefly to position 3 'Start engine' and to let go of it right away.

The starter actuation continues to operate automatically for a certain period of time and is stopped automatically as soon as the engine has started.

The automatic starting mode will not operate or will be canceled if the battery voltage is insufficient. The engine can be jump started, refer to page 174.

Should the engine fail to start on the first attempt, if it is very hot or cold, for instance:

- ▷ Press the accelerator pedal halfway down while engaging the starter.

Cold starts at altitudes above 3,300 ft/1,000 meters and at very low temperatures, from approx. +5 °F/-15 °C:

- ▷ For the initial starting attempt, allow the starter to remain engaged somewhat longer, approx. 10 seconds.

Engine idle speed is controlled by the engine computer system. Increased speeds at startup are normal and should decrease as the engine warms up. If engine speed does not decrease, service is required.

To prevent the battery from being drained, always switch off electrical devices that are not in use. Switch the ignition off when the vehicle is not being driven.



Extended starting attempts, characterized by excessively frequent or long periods with the starter engaged, can lead to damage of the catalytic converter. ◀

# Switching off engine

Manual transmission:

1. Turn the ignition key to position 1 or 0

2. Shift into first gear or reverse.

Automatic transmission:

1. Shift into selector lever position P
2. Turn the ignition key to position 1 or 0.

 Do not remove the ignition key when the vehicle is moving, otherwise, the steering could lock.

When leaving the vehicle, always remove the ignition key and lock the steering.

Manual transmission:


Always engage the handbrake when parking on slopes and inclined surfaces. Even placing the gearshift lever in 1st gear or reverse may not provide adequate resistance to rolling.

Automatic transmission:

Place the selector lever in the P position. ◀

Automatic transmission:

The vehicle must be stationary and the selector lever in Park before you can remove the ignition key.



The handbrake is primarily intended to prevent the vehicle from rolling while parked; it brakes the rear wheels.

### Engaging

The lever engages automatically when you pull it up and the indicator lamp comes on in the instrument cluster in ignition key position 2, refer to pages 19, 21.

### Releasing

Pull up slightly on the lever, press the button and lower the lever.

**⚠** If exceptional circumstances should make it necessary to engage the handbrake while the vehicle is in motion, do not pull it too strongly. In doing so, continuously press the button of the handbrake lever. Otherwise strong application of the handbrake can lead to overbraking of the rear axle and associated 'fishtailing' of the vehicle rear end.

#### Manual transmission:

Always engage the handbrake when parking on slopes and inclined surfaces. Even placing the gearshift lever in 1st gear or reverse may not provide adequate resistance to rolling.

#### Automatic transmission:

Place the selector lever in Park. ◀

**▶** To prevent corrosion and one-sided braking action, occasionally apply the handbrake lightly when the vehicle is slowly coming to a stop if the traffic conditions are suitable.

The brake lamps do not light up when the handbrake is applied.



Press the clutch all the way down each time you shift, pressing the gearshift lever into its proper end position.

Depress the clutch when starting the vehicle, too. If the clutch is not depressed, the interlock will prevent the engine from starting.

**⚠** While shifting in the 5th/6th gear slot, press the gearshift lever toward the right, otherwise, accidental shifting into the 3rd or 4th gear could result in engine damage. ◀

## Manual transmission

### Reverse

Select only when the vehicle is stationary. Press the gearshift lever to the left to overcome the resistance.

As you do this, the backup lamps will turn on automatically when the ignition key is in position 2.

## Automatic transmission with Steptronic\*



In addition to fully automatic operation, you can also manually shift with the Steptronic, refer to page [67](#).

Under normal operating conditions, fuel consumption is lowest when driving in position D.

### Selector lever positions

P R N D M/S

The transmission range display varies in accordance with the equipment of your vehicle.

### Starting engine

The engine can only be started in the selector lever position Park or Neutral.

## Range selection

- ▷ The selector lever can be moved out of the P position with the ignition switched on or the engine running: interlock
- ▷ With the vehicle stationary, press the footbrake before shifting out of P or N, otherwise, the selector lever is blocked: shiftlock.  
Keep the brake pedal pressed down until you start off. The vehicle will otherwise creep when a drive position is engaged.



A lock prevents accidentally shifting into the selector lever positions R and P. To deactivate the lock, press the button on the front of the selector lever knob, refer to arrow.

### P Park

Select only when the vehicle is stationary. The transmission locks to prevent the rear wheels from turning.

### R Reverse

Select only when the vehicle is stationary.

### N Neutral, idle

For example, engage in automatic car washes. The vehicle can roll.

## D Drive, automatic driving position

This position is designed for driving under all normal operating conditions. All forward gears are available.

## Kick-down

The kick-down mode provides maximum acceleration.  
Depress the accelerator pedal past the increased resistance point at the full-throttle position.

# Automatic transmission with Steptronic\*



## Sport Program and manual operation M/S

Shift selector lever from position D toward the left into the shifting slot M/S: the Sport Program is activated and DS appears in the instrument cluster. This position is recommended for a performance-oriented driving style.

Briefly pressing the selector lever toward the front or rear activates manual operation and Steptronic changes gears. The following display appears in the instrument cluster, depending on the model:

- ▷ 1 to 5 or 1 to 6
- ▷ M1 to M5 or M1 to M6.

Upshifts and downshifts are executed only when they will result in a plausible combination of engine and vehicle speed; thus, for example, a downshift that would cause the engine to overrev will not be executed by the system. The gear selected will appear briefly in the instrument cluster and then the current gear will reappear.

To return to automatic mode, move the selector lever toward the right into position D.

## Malfunction



The warning lamp lights up or the message TRANS.FAILSAFE PROG appears in the Check Control. A malfunction has occurred in the transmission system. Avoid heavy loads.

Bring the vehicle to a stop. Move the transmission selector lever to P. Set the parking brake and switch the engine off by turning the ignition key to position 0.


Wait a few seconds, then start the engine.

If the indicator lamp goes out after a few seconds, normal transmission performance has been restored. You may continue to drive as usual. If the indicator lamp does not go out, you can place the selector lever in all positions, but the vehicle will now only drive forward with limited gear selection.

Have the system checked as soon as possible.

Information on jump starting, tow-starting and towing begins on page 174.

## Turn signals/headlamp flasher




- 1 High beams
- 2 Headlamp flasher
- 3 Turn signals

### Signaling briefly

Press lever to resistance point and hold for as long as you wish to signal.

 Atypically rapid flashing of the turn signal light indicates the failure of a turn signal lamp and when towing a trailer, may indicate the failure of one of the trailer's turn signal lamps.◀



- 0 Wipers retracted
- 1 Intermittent mode or rain sensor
- 2 Normal wipe
- 3 Fast wipe
- 4 Brief wipe
- 5 Windshield washing
- 6 Special wash program\*
- 7 Knurled wheel for control of the wipe interval or the sensitivity of the rain sensor

## Fold-out position

The left wiper is partially concealed by the hood. To bring the wipers to roughly a vertical position, which is important when changing the wiper blades or when folding the wipers out during frosty weather, for example, proceed as follows:

▷ With the lever in position 1, switch off the ignition as soon as the wipers come to a stop.

If equipped with a rain sensor:

1. Switch on the wipers with the lever in position 1, 2 or 4
2. When the wipers are roughly vertical, switch the ignition off.

For changing the wiper blades, refer to page [160](#).

**⚠** Fold the wipers back down onto the windshield before you turn the ignition key to position 1 or 2 again. If you do not, they could be damaged. ◀

## Intermittent mode

Not provided in vehicles with rain sensor.

You can set the wipe interval to four stages with the knurled wheel 7.

In addition, the wipe interval is varied automatically depending on road speed.

## Rain sensor

The rain sensor automatically controls the wiper operation as a function of the rain intensity. It is located on the windshield, directly in front of the interior rearview mirror.

To activate the rain sensor:

Move the lever to position 1 as of ignition key position 1. The wipers travel once across the windshield, regardless of the weather conditions.

You can leave the lever permanently in position 1. It is then only necessary to activate the rain sensor as of ignition key position 1.

To do this, turn the knurled wheel 7 briefly.

## 70 Washer/wiper system/rain sensor\*

To adjust the sensitivity of the rain sensor:

Turn the knurled wheel 7.

To deactivate the rain sensor:

Move the lever to position 0.

 Deactivate the rain sensor when passing through an automatic car wash. Failure to do so could result in damage caused by undesired wiper activation.◀

### Normal wipe

The system switches automatically to intermittent mode when the vehicle is stationary, not on vehicles with rain sensor.

### Fast wipe

The wipers operate at normal speed when the vehicle is not moving, not on vehicles with rain sensor.

### Windshield washing

The system sprays washer fluid against the windshield and activates the wipers for a brief period.

### Special wash program\*

As with 5; several additional wash cycles are carried out and the headlamps are cleaned\*.

This program is recommended after you have driven on extremely dirty roads.

### Headlamp washing\*

- ▷ With the special wash program 6
- ▷ At appropriate intervals, the headlamps will also be cleaned upon actuation of the windshield washer function 5 while the vehicle's headlamps are switched on.

 Do not use the washers if there is any danger that the fluid will freeze on the windshield. If you do so, your vision could be obscured. Use antifreeze to prevent this, refer to page 152.

Do not actuate washer systems when the fluid reservoir is empty, otherwise, the washer pump will be damaged.◀

### Windshield washer nozzles

The windshield washer jets are heated automatically when the ignition key is in position 2.



### Rear window wiper

- 0 Retracted position of the rear window wiper
- 1 Rear window wiper in intermittent mode. When the transmission is shifted into reverse, continuous rear wiper operation is switched on automatically
- 2 Cleaning rear window

You can also program the interval:

- ▷ Switch briefly from position 0 to position 1
- ▷ Wait the desired interval time and then switch from position 0 to 1 again to establish the programmed interval; max. 30 seconds.

Programming is deleted:

- ▷ approximately 10 seconds after the lever is placed in position 0 or
- ▷ after the engine is switched off.

For changing the wiper blade, refer to page 160.

You can automatically maintain and store any desired vehicle speed above approx. 20 mph/30 km/h.

You can use cruise control whenever the system is active while the engine is running.

On the sports steering wheel\*, there are +/- buttons on the right side of the steering wheel for the cruise control.



Do not use the cruise control when unfavorable conditions do not permit driving at constant speed. Otherwise you could lose control of the vehicle and cause an accident. These unfavorable conditions include winding roads, heavy traffic or poor road conditions, e.g. snow, rain, ice or a loose road surface.◀

**Activating system**

As of ignition key position 2:

Press the button; the indicator lamp in the instrument cluster comes on, refer to page 22. Cruise control is ready to use.

**Deactivating system**

Press the button repeatedly until the indicator lamp in the instrument cluster goes out.

The cruise control is also deactivated when the ignition key is turned to position 0.

The speed stored in the memory is deleted.

**Maintaining and storing speed or accelerating**

Briefly press button +:

The system maintains and stores the current vehicle speed. Every time you briefly press the button, the speed increases by approx. 0.6 mph/1 km/h.

Press and hold button +:

The vehicle accelerates without pressure on the accelerator pedal. When you release the button, the system maintains and stores the current speed.

On downhill grades, the controlled speed can be exceeded if the engine's braking action is insufficient. Speed can drop on uphill grades if the engine output is insufficient.

**Deceleration**

Briefly press button -:

When cruise control is active, every brief touch of the button reduces the speed by approx. 0.6 mph/1 km/h.

Press and hold button -:

With the cruise control active, the system automatically reduces the throttle opening to slow the vehicle. When you release the button, the system maintains and stores the current speed.

**Interrupting cruise control**

When the system is activated, press button 1. The indicator lamp stays on. You can use the cruise control again whenever required by resuming the speed that was stored last.


In addition, cruise control is interrupted automatically:

- ▷ When you apply pressure to the brake pedal
- ▷ When you apply pressure to the clutch pedal or when you move the automatic transmission selector lever from Drive to Neutral
- ▷ If you exceed or fall below the controlled speed for an extended period, by depressing the accelerator, for example
- ▷ When DSC Dynamic Stability Control is active.

**Resuming stored setting**

Press the button:

The vehicle accelerates to and maintains the last speed stored.



- 1 Odometer
- 2 Trip odometer
- 3 Outside temperature display

## Odometer

You can activate the displays shown in the illustration with the ignition key in position 0 by pressing the button in the instrument cluster, refer to arrow.

The range of available displays varies according to your individual vehicle's equipment.

## Trip odometer

To reset the trip odometer to zero, press the button, refer to arrow, with the ignition key in position 1 or 2.

## Outside temperature display

The outside temperature appears on the display as of ignition key position 1.

You can change the units of measure °F/°C by

1. pressing and holding down the button, refer to arrow, with the ignition key in position 1 and
2. then turning the ignition key to 0.  
At the same time the units of measurement in the temperature display of the automatic climate control will be changed, refer to page 107.

Refer also to page 80.

## Outside temperature warning

If the display drops to approx. +37.5 °F / +3 °C, a signal sounds as a warning and the display flashes for a brief period. There is an increased danger of ice.

 Even at temperatures above +37.5 °F / +3 °C ice can form. Therefore, drive carefully, e.g. on bridges and sections of road in the shade, as otherwise there is an increased accident risk.◀



### X5 3.0i, 4.4i

Do not operate the engine with the needle in the red overspeed zone of the gauge, refer to arrow.

In this range, the fuel supply is interrupted to protect the engine.



### X5 4.8is

The orange warning sector gradually moves upward as the engine warms to its normal operating temperature. As the engine temperature increases, an increasing number of sectors in this warning panel go out.

Avoid allowing the engine speed to rise as far as the orange warning sector whenever possible.

Do not operate the engine with the needle in the red overspeed zone of the gauge, refer to arrow.

In this range, the fuel supply is interrupted to protect the engine.



### X5 3.0i, 4.4i

Shows the current fuel consumption. This allows you to see whether your current driving style is conducive to fuel economy with minimum exhaust emissions.

## Engine oil temperature gauge



### X5 4.8is

The general operating temperature lies between 176 °F/80 °C and 248 °F/120 °C. Do not exceed the maximum value of 302 °F/150 °C.

## Fuel gauge



If the LED comes on and stays on, there are approx.

- ▷ 2.0 gal./8 liters, 6-cylinder engine
- ▷ 2.5 gal./10 liters, 8-cylinder engine of fuel still in the tank.

Tank capacity: approx. 24.6 gal./93 liters.

If the tilt of the vehicle varies, when you are driving in mountainous areas, for example, the indicator may fluctuate slightly.



Refuel well before the tank is empty, otherwise engine functions will not be ensured. Damage can occur if you drive down to the last drop. ◀

When you switch on the ignition, the LED lights up briefly to confirm that the system is operational.



### Between blue and red zones

Normal operating range. The dial may drift up to the red field.



### Blue

The engine is still cold. Drive at moderate engine and vehicle speeds.

### Red

When you switch on the ignition, the warning lamp\* comes on briefly to confirm that the system is operational.

If the warning lamp lights up during driving or the message COOLANT TEMPERATURE appears in the Check Control; the engine is overheated. Switch off the engine immediately and allow it to cool down.

Checking coolant level, refer to page 154.

The range of available displays varies according to your individual vehicle's equipment.

### Green lamps

The number of illuminated lamps decreases as the time for your next maintenance visit approaches.


### Yellow lamp

This field appears together with OILSERVICE or INSPECTION.

Maintenance is due. Please contact your BMW Sports Activity Vehicle center for an appointment.

### Red lamp

The maintenance deadline has been passed.



## Graphic display\*

The following alerts or status messages are displayed with icons as of ignition key position 2 until the defects are corrected:

- 1 Check low beams
- 2 Add washer fluid, goes out after approx. 1 minute
- 3 Door open
- 4 Tailgate open
- 5 Check brake and tail lamps. A defective center brake lamp is indicated by the upper symbol.

When you open the door after stopping, a warning signal sounds without a visual indicator for:

- ▷ LIGHTS ON
- ▷ KEY IN IGNITION LOCK.



## Alphanumeric display\*

Text messages are used to alert the driver to system malfunctions as of ignition key position 2. The alert is accompanied by an acoustic signal.

- 1 Status messages symbol
- 2 Display
- 3 CHECK button

Messages concerning system defects are differentiated based on two priorities:

### Priority 1

These defects are immediately indicated by an acoustic signal and a flashing warning symbol 1. Simultaneous defects will be displayed consecutively. These status messages remain on the display until the defects are corrected. They cannot be deleted by pressing the CHECK button 3:

- ▷ RELEASE PARKINGBRAKE
- ▷ COOLANT TEMPERATURE Temperature too high. Stop the vehicle immediately and switch off the engine, refer to pages 76 and 154
- ▷ STOP! ENGINE OILPRESS Oil pressure too low. Stop the vehicle immediately and switch off the engine, refer to pages 19 and 152

**▷ CHECK BRAKE FLUID**

Level has dropped approx. to minimum. Have the brake fluid replenished as soon as possible, refer to page 155. Have the reason for the brake fluid loss eliminated by your BMW Sports Activity Vehicle center

**▷ DSC/4x4 INACTIVE**

DSC and/or four-wheel drive system xDrive has failed.

The stabilizing interventions of DSC and/or the four-wheel drive system xDrive are no longer available. Drive may be being exerted exclusively via the rear axle.

Have the system checked at the nearest BMW Sports Activity Vehicle center.

For additional information, refer to page 94

**▷ SELFLEVEL SUSP.INACT\***

Please consult the nearest BMW Sports Activity Vehicle center

**▷ SELFLEVEL SUSP.INACT\***

MAX. 35 MPH/MAX. 60 KM/H\*

These messages are displayed consecutively.

Do not exceed a maximum speed of 35 mph/60 km/h.

Please consult the nearest BMW Sports Activity Vehicle center

**▷ TRANSMISS'N OVERHEAT\***

Reduce speed immediately and stop at a suitable location so that the system can cool down again. Please contact the nearest BMW Sports Activity Vehicle center.

**▷ LIMIT\***

Display when the programmed road-speed limit is exceeded, refer to page 85.

**Priority 2**

These displays appear for 20 seconds as of ignition key position 2. The warning symbols remain after the message disappears. You can open the messages again for display by pressing the CHECK button.

**▷ TRUNKLID OPEN**

This message only appears when starting off

**▷ DOOR OPEN**

This message appears after a minimal defined road speed has been exceeded

**▷ FASTEN SEAT BELTS\***

In addition, the indicator lamp with the belt symbol lights up and an acoustic signal sounds

**▷ WASHER FLUID LOW**

Too low, top up at the next opportunity, refer to page 152

**▷ CHECK ENGINE OIL LEV**

The oil level is at the absolute minimum point. Therefore, have the engine oil replenished as soon as possible, refer to page 152. Until then, do not drive more than approx. 30 miles/50 km.

**▷ CHECK GAS CAP**

Check to see whether the fuel filler cap has been closed properly, refer to page 25

**▷ OUTSIDE TEMP. +23 °F/-5 °C**

This display is only an example. The current temperature is displayed at outside temperatures of +37.5 °F / +3 °C and below, refer also to page 73

**▷ CHECK BRAKE LIGHTS**

A lamp has failed or the electrical circuit has a malfunction, refer to page 163 or consult a BMW Sports Activity Vehicle center

**▷ CHECK LOWBEAM LIGHTS**

CHECK SIDE LIGHTS

CHECK REAR LIGHTS

CHECK FRONT FOGLAMPS

CHECK LICPLATE LIGHT

CHECK HIGHBEAM LIGHT

CHECK BACK UP LIGHTS

The respective lamp may have failed or the electrical circuit may be defective, refer to page 161 or consult a BMW Sports Activity Vehicle center

# Check Control

## ▷ TRANS. FAILSAFE PROG\*

Please consult the nearest BMW Sports Activity Vehicle center, refer to page 67

## ▷ CHECK BRAKE LININGS

Have the brake pads inspected by your BMW Sports Activity Vehicle center, refer to page 140

## ▷ CHECK COOLANT LEVEL

Coolant too low, top off at the next opportunity, refer to page 154

## ▷ ENGINE FAILSAFE PROG

Fault in the engine electronics. You can continue to drive with reduced engine output or engine speed.

Please have the system inspected by your BMW Sports Activity Vehicle center.

## Displays after completion of trip

All of the malfunctions registered during the trip appear consecutively when the ignition key is turned to position 0.

The following displays will appear when appropriate:

### ▷ LIGHTS ON

### ▷ KEY IN IGNITION LOCK

### ▷ CHECK ENGINE OIL LEV

Replenish engine oil at the next opportunity, e.g. while refueling, refer to page 152.

This display appears when you open the driver's door after parking the vehicle. A supplementary acoustic signal also sounds.

Status messages remain available with the CHECK button 3 for a period of approx. three minutes after the display goes out and the key is removed from the ignition lock. If there are multiple messages, press the CHECK button repeatedly to view them all in sequence.

## Checking Check Control

Press the CHECK button 3 with the ignition key in position 2:

CHECK CONTROL OK appears on the display.


No malfunctions are present in the monitored systems.

## Computer

You can find a description of the computer below and on page 85 as well as in the Owner's Manual for Onboard Computer.

 You can have the Check Control and computer messages displayed in a different language.◀

# Computer



## Mode selection

As of ignition key position 1, you can request information from the computer using the computer button in the turn signal lever.

A new function appears each time you briefly press the computer button.

The display sequence:

- ▷ Outside temperature
- ▷ Average fuel consumption
- ▷ Cruising range
- ▷ Average speed.

As of ignition key position 1, the last active setting is displayed.

The range of available displays varies according to your individual vehicle's equipment.



## Outside temperature and average fuel consumption

You can change the units of measure °F / °C for the outside temperature display by

1. pressing and holding the trip odometer reset button with the ignition key in position 1 and
2. then turning the ignition key to 0.  
At the same time the units of measurement in the temperature display of the automatic climate control will be changed, refer to page 107.

Refer also to page 73.

The average fuel consumption is calculated for the time during which the engine is running.

## Cruising range and average speed

Displays the estimated cruising range available with the remaining fuel. The fuel level is measured and the range is calculated taking into account the driving style over the last 20 miles/30 km. Periods with the vehicle parked and the engine off are not included in the calculations of average speed.

## Canceling display

You can hide the computer display by briefly pressing the button in the turn signal lever while the average speed is being displayed.

## Restarting calculations

If you continue to press the computer button in the turn signal lever, the average values which were just displayed for fuel consumption and speed will be recalculated from that point. The engine must be running in order for this calculation to be executed.

## Computer with alphanumeric display\*

If your vehicle has Check Control with alphanumeric display, the system's computer is described beginning on page 85 and in the Owner's Manual for Onboard Computer.

# MID Multi-Information Display

## Central display

The MID is used for centralized display and operation for the following onboard systems:

- ▷ Digital clock, e.g. time display, date
- ▷ Audio systems: radio, cassette, CD
- ▷ Computer, e.g. fuel consumption, cruising range
- ▷ Telephone, e.g. dialing

You will find notes and instructions for operating the digital clock and the computer on the following pages. Please refer to the separate Owner's Manuals for operating the audio systems, the telephone and the onboard computer.

-  Any unrealistic numerical entries will not be accepted.  
All stored data will be lost if the power supply is interrupted. Time display, switch-on times for parked car ventilation, distance and cruise control speed limit may have to be reset once the power supply has been reestablished.◀



- 1 Function button for audio systems
- 2 Function button for the telephone
- 3 LED for parked car ventilation
  - ▷ remains on if switch-on time is active
  - ▷ flashes while operating
- 4 Function button for the digital clock and computer
- 5 Indicator display for the various onboard systems
- 6 Display for the entry and request buttons. Depending on the operating mode, the functions and options that can be selected with the buttons are displayed here
- 7 Entry and request buttons for operating the various onboard systems

## 82 Digital clock in MID

 To avoid endangering yourself or other road users, only make entries when the vehicle is stationary. ◀

### Displaying time or date



Press the left side of the button.

Display shows:



You can have the time displayed in 12 or 24 hours.

To change the display:



Press the left side of the button.

If the 12-hour time display is in use, AM or PM appears after the time.

### Changing time




BC

Press the left side of the button.



Press the right side of the button:  
The dots flash on the display.

To change the setting:



Press the left/right side of the button, or hold the button down.

To store the entry:



Press the right side of the button.

### Changing date



BC

Press the left side of the button.



Press the button.



Press the right side of the button:  
The dots and the DATE display flash.

To change the setting:



Press the left/right side of the button, or hold the button down.

To store the entry:



Press the right side of the button.

The clock takes leap years into account and therefore does not have to be reset manually.

# Digital clock in MID

## Reminder signal

You can program a reminder signal – memo – to be heard every hour, so that you are sure not to miss a news broadcast.



Press the left side of the button.



Press the button:

MEMO OFF appears on the display for entry and request buttons, and the tone symbol will appear in the upper right of the display.

A signal is then heard 15 seconds before each hour.

## Stopwatch



Press the left side of the button.



Press the button.

Display shows:



To start the stopwatch function:



Press the right side of the button.

To take an intermediate time reading:



Press the button.



Press the button:

The stopwatch display can be seen counting up; the stopwatch continues to run.

To halt the stopwatch:



Press the right side of the button.

The stopwatch is halted when the ignition key is turned back to 0, but starts to run again when the ignition key is turned to 1.◀

## 84 Digital clock in MID

### Entering switch-on times for parked car ventilation

You can enter two different switch-on times.

The ventilation will switch off automatically after 30 minutes.

 Please follow the instructions for operating the parked car ventilation that start on page [113](#).◀



Press the left side of the button.



Press the left/right side of the button.

Display shows:



Press the right side of the button:  
Display flashes, e.g. TIMER 1.

To enter the time:



Press the left/right side of the button, or hold the button down.

To confirm the entry:



Press the right side of the button.

The activated time is marked with an asterisk.



The switch-on times remain stored until new entries are made.

You can change switch-on times that have already been stored by making a new time entry as described above.

When the switch-on time is active, the LED comes on in the MID. During actual operation of the ventilation, the LED flashes. The LED goes out when the system is switched off.

To activate/deactivate the time:



Press the button twice.

### Switching parked car ventilation on and off directly

 The parked car ventilation function can only be requested in ignition key position 1.◀



Press the left side of the button.



Press the button.

## Computer\* in MID

 To avoid endangering yourself or other road users, only make entries when the vehicle is stationary. ▶

Computer calculations begin at the start of the journey.

Information can also be called up on the display by the remote control, refer to page 89.

### Speed limit

Speed limit entry:

You can enter the road speed at which you wish to hear and see a reminder signal: a signal will sound, the word LIMIT will flash, and with the Check Control with alphanumeric display\*, the speed limit warning stored in the memory will appear on the instrument cluster briefly: limit.

The speed limit reminder is only repeated if road speed has fallen at least 3 mph/5 km/h below the preset speed limit since the last time the speed limit reminder was triggered.



Press the right side of the button.



Press the button.



Press the right side of the button.

Display shows:



Enter the limit by pressing the function buttons.

To correct an entry:



Press the left side of the button and repeat the entry.

To store the entry:



Press the right side of the button.

## 86 Computer\* in MID

To adopt the current speed as the speed limit:



Press the right side of the button.



Press the button.



Press the right side of the button twice.

To deactivate the speed limit:



Press the right side of the button.



Press the button.

The LIMIT display goes out, but the stored value is not lost and can be reactivated by pressing the LIMIT button.

### Distance to destination

The remaining distance to the destination will be displayed on the screen.

Enter the entire distance before starting the journey.

To enter:



Press the right side of the button.



Press the left side of the button.



Press the right side of the button.

Display shows:

FM\_89.1\_ST DIST --- MLS  
1 2 3 4 5 6 7 8 9 0 CLR SET

You can enter the distance by pressing the function buttons.

To correct an entry:



Press the left side of the button and repeat the entry.

To store the entry:



Press the right side of the button.

To check a stored value:



Press the right side of the button.



Press the left side of the button.

# Computer\* in MID

## Estimated time of arrival

When you have entered the distance to your destination, you can obtain an estimated time of arrival display that is continuously updated by the computer as your average driving period varies.



Press the right side of the button.



Press the right side of the button:  
The estimated time of arrival is displayed.

## Cruising range

The distance that the vehicle should cover on the remaining fuel in the tank is displayed.



Press the right side of the button.



Press the button:  
The display shows the probable range.



Always refuel as soon as possible once your cruising range falls to below 30 miles/50 km, otherwise engine functions are not ensured and damage can occur.◀

The computer will only register fuel amounts over 1.8 gal/6 liters.

## Fuel consumption

You can have the average fuel consumption displayed for two different distances, for example a complete journey and part of the journey.

To start the calculation, select the function with the engine running:



Press the right side of the button.



Press the left or right side of the button:  
The display will show the average fuel consumption.

To restart the fuel consumption calculation:



Press the left or right side of the button.



Press the right side of the button.

## 88 Computer\* in MID

### Speed

You can open a display of the vehicle's average speed.

To start the calculation, select the function with the engine running:



Press the right side of the button.



Press the button:

The display shows the average speed.

To recalculate the speed:



Press the right side of the button.

### Extended immobilizer function

You can establish a code that will prevent the engine from being started unless the code is entered.

If you do not have access to the code, the emergency deactivation procedure will have to be carried out, refer to next page.

To establish and activate the code:



Press the right side of the button.



Press the left side of the button.

Display shows:



Enter the code with the function buttons.

To correct an entry:



Press the left side of the button and repeat the entry.

To store the entry:



Press the right side of the button.

Turn the ignition key to position 0.

To deactivate the code:

When you are asked to enter the code with the ignition key in position 1 or 2:

▷ Enter the code at the function buttons.



Press the right side of the button.

After the code has been entered correctly and confirmed with the SET button, the time display appears.

# Computer\* in MID


After three incorrect code entries, or three attempts to start the engine without a code entry, the alarm will sound for 30 seconds on vehicles fitted with an alarm system.

Deactivating the alarm in an emergency:

If you have forgotten the code, proceed as follows:

1. Disconnect the battery, wait approx. 2 minutes, then reconnect it. Note that on vehicles with an alarm system, the alarm will sound
2. Set the ignition key to position 1: the time display will count down for the next ten minutes
3. After ten minutes, start the engine.

 If the code becomes available again in the meantime, it can be entered during the waiting period after pressing the CODE button.◀



To have all the available information displayed, press

- ▷ the button on the lever until PROG shows on the display
- ▷ the SET button.

To obtain individual items of information, briefly press the button as often as necessary.

## Remote control

The computer button on the turn signal lever can be used to select the items of computer information to be displayed.

To do this, press:

- ▷ the button on the lever until PROG shows on the display
- ▷ the MID buttons in the order in which you wish the information to be displayed.

Each time an entry is stored, the program number appears on the display.

To terminate the selection procedure:



Press the right side of the button.

## 90 PDC Park Distance Control\*

### The concept

PDC provides extra safety and convenience during parking maneuvers. Signal tones indicate the current distance to an object behind or in front of your vehicle. To do this, four ultrasonic sensors in the front and rear bumpers each measure the distance to the nearest object. The detection range of the front sensors and the two sensors located at the ends of the rear bumper is approx. 2 ft/60 cm, while the rear center sensors can detect objects up to a distance of approx. 5 ft/1.50 m.

 PDC is a parking aid that can indicate objects when they are approached slowly, as is usually the case when parking. Avoid approaching objects too quickly; otherwise the physical circumstances may cause the system to issue the warning too late.◀

### Automatic operation

When the engine is running or the ignition is switched on, the PDC system starts to operate automatically approx. one second after you shift into reverse or move the selector lever into the R position. Wait this short period before backing up.



### Manual activation

Press the button; the LED lights up.

### Manual deactivation

Press the button again; the LED goes out.

### Automatic deactivation

After driving a distance of more than approx. 95 ft/30 m or exceeding a speed of approx. 20 mph/30 km/h, the system switches off and the LED goes out. You may switch the system on again manually as needed.

## Signal tones

The distance from an object is indicated in front with a higher intermittent tone, and at the rear with a lower intermittent tone. As the distance between vehicle and object decreases, the intervals between the tones become shorter. The signal tone becomes continuous once the distance to the nearest object falls to below roughly 1 ft/30 cm.

The warning signal is canceled after approx. 3 seconds if you are moving parallel to a wall.

## Malfunctions

The LED flashes and a short steady signal tone is sounded

- ▷ if you activate PDC with the button
- ▷ when you select reverse for the first time after switching on the ignition
- ▷ if a malfunction occurs while the PDC system is active.

Switch the system off and have the cause of the malfunction corrected by your BMW Sports Activity Vehicle center.

## System limits

 Even with PDC, final responsibility for estimating the distance between the vehicle and any obstructions always remains with the driver. Even when sensors are involved, there is a blind spot in which objects cannot be detected. This applies especially in those cases where the system approaches the physical constraints of ultrasonic measurement, as occurs with tow bars and trailer couplings, and in the vicinity of thin or wedge-shaped objects. It is also possible that low objects already displayed, such as curb edges, may come into the blind spot of the sensors before a continuous signal sounds or that higher, protruding objects, such as ledges, will not be detected.

Loud sources of sound, inside and outside the vehicle, could drown out the PDC signal tone.◀

 Keep the sensors clean and free of ice or snow in order to ensure that they will continue to operate effectively.

When using high-pressure washers, do not spray sensors for long periods and keep the sprayer at least 4 in/10 cm away from the sensors.◀

## The concept

The ABS Antilock Brake System prevents the wheel brakes from locking during braking. Safe steering response is maintained even during full braking. This increases active safety.

The ABS is operational every time you start the engine. Safe braking, refer to page 140.

## EBV Electronic brake-force distribution

EBV controls the brake system's application pressure at the rear wheels to ensure stable deceleration.

## DBC Dynamic Brake Control

When the brake pedal is depressed rapidly, this system automatically generates a maximum boost of braking force and thus aids in keeping braking distances as short as possible during full braking. This system exploits all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the brake application. DBC is deactivated when you release the brake pedal.

### Malfunctions

Please be absolutely sure to follow instructions regarding possible combinations of indicator lights on page 20.

### The concept

DSC prevents the drive wheels from slipping when starting off and accelerating. DSC also identifies unstable driving conditions, such as a loss of traction at the rear of the vehicle or sliding of the vehicle in its front wheels. Under these circumstances, DSC helps the vehicle maintain a safe course within the physical limits by reducing the engine output and by applying the brakes in the individual wheels.

The DSC is operational every time you start the engine.



The laws of physics cannot be repealed, even with DSC. An appropriate driving style always remains the responsibility of the driver. So please do not further limit the additional safety margin by taking unnecessary risks.◀

### Indicator lamp



The indicator lamp in the instrument cluster goes out shortly after the engine is started.

The indicator lamp flashes:  
DSC is active and is regulating drive and braking force.

The indicator lamp stays lit:  
DSC has been switched off using the button and the stabilizing interventions are no longer available.



## Switching DSC off

Press the button; the indicator lamp comes on and stays on.

Stabilizing interventions of the chassis control system DSC are no longer available. However, the braking interventions that simulate the function of the differential lock continue to be active.

In the following exceptional circumstances, it may be effective to switch off the DSC for a short period:

- ▷ When rocking a stuck vehicle free and when starting off in deep snow or on loose road surfaces
- ▷ On sandy road surfaces
- ▷ On poor surfaces with deep ruts

- ▷ If the wheels churn on muddy surfaces
- ▷ When driving with snow chains.

When the DSC system is switched off, braking maneuvers may subject the brakes to additional loads. Automatic limitation of braking action may briefly occur in order to limit brake temperatures.

To maintain vehicle stability, always drive with the system switched on when possible.◀



## Switching DSC on

Press the button a second time – the indicator lamp goes out. DSC is now activated.

## Malfunctions

Please be sure to read the information on the DSC Dynamic Stability Control/xDrive warning lamp on page 22 and on the possible lamp combinations that can light up on page 20.

## HDC Hill Descent Control

xDrive is the 4-wheel drive system of your X5. The combined effects of xDrive and DSC further optimize the traction and dynamic driving characteristics. The 4-wheel drive system xDrive variably distributes the drive torque to the front and rear axle depending on the driving situation and prevailing road conditions.

### **Malfunctions**

Please be sure to read the information on the DSC Dynamic Stability Control/xDrive warning lamp on page 22 and on the possible lamp combinations that can light up on page 20.

### **The concept**

HDC is a system for driving downhill in steep terrain. This system reduces vehicle speed on steep downhill gradients, thus allowing you to maintain even better control of your BMW under these conditions.

The vehicle moves at slightly more than walking speed without active intervention from the driver.

HDC is available for activation at vehicle speeds below approx. 20 mph/35 km/h. When driving down steep hills with a speed below approx. 20 mph/35 km/h, the vehicle reduces speed automatically down to slightly more than walking speed, approx. 5 mph/8 km/h, and then maintains this speed at a constant.

You can use the accelerator or brakes to vary this automatically controlled speed within a range extending from approx. 3 mph/5 km/h to 15 mph/25 km/h.

You can specify a target speed within the same range by using the +/- buttons of the cruise control.

HDC is automatically deactivated once vehicle speed again exceeds approx. 35 mph/60 km/h.



### **Activating system**

Press the button; the LED lights up.

The LED flashes when the brakes are applied automatically.

### **Deactivating system**

Press the button again; the LED goes out.

HDC is deactivated automatically above a road speed of approx. 35 mph/60 km/h and when the ignition is switched off.

# HDC Hill Descent Control Self-leveling suspension\*

## Using HDC

With manual transmission:

Use HDC in first gear and in Reverse since the engine's braking action is diminished in the higher gears.

With automatic transmission:

You can use HDC in every drive position.

## In case of a malfunction

If the LED in the button goes out during HDC operation or does not light up when the HDC is activated:

HDC is temporarily unavailable due to excessive brake temperature.



The warning lamp for the self-leveling suspension comes on, or the message SELFLEVEL SUSP.INACT appears in the Check Control: there is a malfunction in the self-leveling suspension.

Stop and inspect the vehicle. If the rear of the vehicle is visibly lower than the front, possibly accompanied by a tilt noticeable when you compare the left rear with the right rear, please respond by immediately proceeding to the nearest BMW Sports Activity Vehicle center. Drive with appropriate caution in the meantime. The vehicle has reduced ground clearance and driving comfort may be noticeably reduced.

Even when the position of the vehicle is normal, have the system checked as soon as possible when a malfunction is indicated.

## The concept

Your vehicle is equipped with 2-axle self-leveling suspension acting on both the front and rear suspension. This system combines automatic self-leveling, which compensates for variations in front-to-rear load-distribution patterns, with a selection feature allowing drivers to choose from among several ride-height options.

You may choose from among the following ride heights:

- ▷ Normal  
The standard setting is intended for most operating conditions, including trailer towing
- ▷ Off-Road  
Increased level for more ground clearance
- ▷ Access  
Lowers vehicle for more convenient cargo handling or easier passenger entries and exits.

Changes in ride height are initiated either manually, using the control button, refer to page 97, or automatically in response to specific speeds. When the ride height is selected manually, the driver has the additional option of revising the ride-height selection by entering

a new command during the adjustment process.

When the vehicle is stationary, the system executes ride-height changes in both directions – up and down – whenever the doors are closed. The tailgate/liftgate may be open. The system raises the vehicle only when the engine is running.

The system's automatic self-leveling feature automatically compensates for variations in the vehicle's load.

The ground clearance of the vehicle 6.5-9 in/16.5-22 cm, depending on the level selected.

 Frequent changes in ride height initiated at short intervals can overheat the compressor, causing the system to briefly suspend active operation.◀



## Self-leveling suspension display

- 1 Off-Road
- 2 Standard
- 3 Access

The LEDs not only show the current ride height, but also indicate changes:

- ▷ LED on: indicates the vehicle's current ride height
- ▷ Ride-height LED flashes while the LED for the earlier level remains on: the ride height is being adjusted to a new level, either automatically or in response to driver input at the button.

When the suspension reaches the new ride height the flashing LED reverts to continuous operation, and the LED for the earlier level goes out.

## 2-axle self-leveling suspension\*

- ▷ LED for current ride height flashes for roughly 3 seconds when you press the button: change in ride height is not possible.



### Raising

Available only when the engine is running.

From Standard to Off-Road:

Press button 1 while traveling at a speed of less than approx. 30 mph/50 km/h.

From Access to Standard:

- ▷ Press button 1 or
- ▷ automatically once the vehicle exceeds a speed of approx. 20 mph/35 km/h.

### Lowering

Available with ignition key in position 2.


From Standard to Access:

1. Press button 2 while traveling at less than approx. 50 mph/80 km/h. The system enters its preselection mode. The preselection mode is canceled
  - ▷ by pressing button 1
  - ▷ automatically once the vehicle exceeds a speed of approx. 50 mph/80 km/h or approx. 60 seconds after button 2 is pressed
2. Reduce speed to below approx. 15 mph/25 km/h within approx. 60 seconds after pressing button 2.

When you press button 2 at speeds below approx. 15 mph/25 km/h the system automatically lowers the vehicle to the Access level.◀

From Off-Road to Standard:

- ▷ Press button 2 or
- ▷ automatically once the vehicle exceeds a speed of approx. 30 mph/50 km/h.



530de400

The brake lamps light up in two stages, depending on how forcefully you apply the brakes.

- ▷ Normal braking:  
The brake lamp 1 and the center brake lamp light up
- ▷ Heavy braking:  
The brake lamps 1 and 2 light up together with the center brake lamp.

### The concept

The Flat Tire Monitor keeps track of the inflation pressures in the four fitted tires as you drive. The system provides an alert whenever the inflation pressure in one tire drops significantly in relation to the pressure in another tire.

The check of the tire inflation pressure is based on monitoring the relative speeds of the wheels. A flat is detected and reported on the basis of a deviation in certain speed ratios.

### Functional requirement

To ensure reliable operation, the system should have been initialized with the correct tire inflation pressure.

### System limits

The Flat Tire Monitor cannot indicate sudden severe tire damage caused by outside factors and does not detect a natural, even pressure drop in all four tires. ◀

In the following situations, the system could be delayed or malfunction:

- ▷ When driving on snow-covered or slippery road surfaces
- ▷ In the case of performance-oriented driving: slip in the drive wheels, high lateral acceleration
- ▷ False alarms and undetected loss of pressure may occur when you are driving with snow chains fitted.

# Flat Tire Monitor



## Initializing system

Perform the initialization immediately every time you correct the inflation pressure, change a tire or change a wheel or all wheels. The vehicle must be driven during initialization.◀

1. Start the engine, but do not begin to drive immediately.
2. Press the button until the yellow indicator lamp in the instrument cluster lights up for a few seconds.
3. Begin driving.

It takes a few minutes of driving before the Flat Tire Monitor can detect and report a flat tire.

When driving with snow chains, do not initialize the system.◀

## Indication of a flat tire



The warning lamp lights up yellow. There is a flat tire or extensive inflation pressure loss.

1. Reduce speed and stop the vehicle carefully. Avoid sudden braking and steering maneuvers
2. Identify damaged tire
 

If identification is not possible, contact your BMW Sports Activity Vehicle center.◀
3. Replace the damaged wheel, refer to Changing a wheel on page 165.



## Parking lamps/side marker lamps

 The front, rear and side vehicle lighting is switched on. You can use the parking lamps for parking. For lighting on one side for parking as an additional feature, refer to page 101.

## Low beams

 When the ignition is switched off and the low beams are on, only the parking lamps/side marker lamps remain on.

### Pathway lighting:

When you activate the headlamp flasher after parking the vehicle and switching off the lamps, the low beams will come on for a brief period. You may also have this function deactivated if you wish.◀

## Lights on warning

Whenever you open the driver's door, after having turned the ignition key to position 0, an acoustic signal will sound for a few seconds to remind you that the lamps have not been switched off.

### Alphanumeric Check Control\*:

The reminder is given through the Check Control.

## Daytime driving lamps\*

The headlamps are automatically switched on for daytime driving at ignition key position 2.

## Automatic headlamp control\*

 When you set the switch to this position, the system activates and switches on and off the low beams in response to changes in ambient light conditions, for instance, in tunnels, at dawn and dusk, and in rain and snow.

 The low beams remain switched on regardless of the ambient light when you switch on the front fog lamps.◀

 Automatic headlamp control cannot serve as a substitute for the driver's judgment in determining when the vehicle lamps should be switched on. For example, the system cannot detect fog. To avoid safety risks, you should always switch on the lamps manually under these conditions.◀

 You can have the sensitivity of the headlamp control system adjusted on your vehicle.◀

## Adaptive Head Light\*

### The concept

Adaptive Head Light is a variable head-lamp control system that enables better illumination of the road surface.

Depending on the steering angle and other assumptions, the light from the headlamp follows the course of the road.

### Activating Adaptive Head Light



In ignition key position 2, turn the light switch to the position 'Automatic headlamp control', refer to page 100.


To avoid blinding oncoming traffic, the Adaptive Head Light

- ▷ is not active when driving in reverse
- ▷ is active only when pointing toward the passenger side.

### Malfunctions

The LED next to the symbol for automatic headlamp control flashes. Adaptive Head Light is faulty or has failed. Have the system checked as soon as possible.

## High beams/roadside parking lamps



- 1 High beams
- 2 Headlamp flasher
- 3 Roadside parking lamps

### Roadside parking lamps, left or right\*

As an additional feature, you can illuminate your vehicle on either side for parking, if you wish:

With the ignition key in position 0, engage the lever in the appropriate turn signal position.



The roadside parking lamps drain the battery. Avoid use for extended periods of time, otherwise, it will no longer be possible to start the engine.◀




Briefly press the button to switch on/off.

 The parking lamps or low beams must be switched on for the fog lamps to operate. A green indicator lamp appears in the instrument cluster to indicate that the front fog lamps are on.

If the high beams are switched on, the front fog lamps go out.

 If the automatic headlamp control is activated, the low beams will automatically be switched on when the front fog lamps are switched on. 



The interior lamps operate automatically.

## Switching interior lamps on and off manually

Briefly press button 1.

If you want the interior lamps to remain off all the time, press and hold the button for approx. 3 seconds.

Briefly press the button to revert to normal operation.

The button for the interior lamps in the rear passenger area only switches these lamps on and off.

### Reading lamps\*

Reading lamps are located at the front and in the rear next to the dome light. They can be switched on and off with the respective buttons 2 located next to them.


### Footwell and cargo area lamps

The lamps are controlled in the same manner as the front interior lamps.

### Courtesy lighting\*

This lighting system in the two exterior mirrors illuminates the ground in the area near the two front doors. It is also controlled in the same manner as the front interior lamps, but it does not function while the vehicle is moving.

 In order to prevent battery discharge, all of the lamps in the vehicle are switched off automatically approx. 15 minutes after the ignition key is turned to position 0.◀



1 Airflow directed toward the wind-  
shield and side windows

2 Airflow for the upper body [106](#)

3 Front footwell ventilation

4 Rear footwell ventilation

5 Airflow for the upper body in the  
rear seat [106](#)

6 Temperature [105](#)

7 Air distribution [105](#)

8 Air supply [105](#)

9 Rear window defroster [105](#)

10 Air conditioning [105](#)

11 Recirculated-air mode [105](#)

# Air conditioner

## Temperature

 The graduations on the dial provide general reference values for the interior temperature. 70 °F/22 °C is recommended as a comfortable setting. After driving begins, the selected temperature is reached as quickly as possible and kept constant by the control system.

## Air distribution

 You can direct air to flow onto the windows , toward the upper body  and into the footwell . All intermediate settings are possible. In the  setting, there is a low flow of air onto the windows to keep them free of condensation.

## Air supply

 You can adjust the air supply through an infinitely-variable range. The heating and ventilation become more and more effective as the air supply settings are increased. In the 0 setting, the blower and climate control are switched off and the outside air supply is blocked.

## Rear window defroster

 When the rear window defroster is activated, the LED lights up. The rear window defroster switches off automatically.

## Air conditioning

 The air is cooled and dehumidified and – depending on the temperature setting – warmed again. Depending on the weather, the windshield may fog over briefly when the engine is started. You can reduce condensation forming on the windows by switching on the air conditioning.



 During air conditioning, condensation forms, which then exits under the vehicle. Traces of water on the ground are therefore normal.◀

## Recirculated-air mode

 You can respond to unpleasant odors outside the vehicle by temporarily switching off the outside air supply. The system then recirculates the air currently within the vehicle.

You can also use the button on the steering wheel to switch over to the recirculated-air mode, refer to page 23.

 If the windows fog over in the recirculated-air mode, switch the recirculated-air mode off and increase the air supply as required.◀



## Ventilation

The air vents for the upper body region are adjustable:

- 1 Knurled wheels for opening and closing the vent outlets through an infinitely-variable range
- 2 Levers for adjusting airflow direction
- 3 Use this knurled wheel to adjust the temperature of the incoming air:
  - ▷ Turn toward blue: colder
  - ▷ Turn toward red: warmer.

## Rear ventilation\*

- 1 Knurled wheel for opening and closing the vent outlets through an infinitely-variable range
- 2 Levers for adjusting airflow direction


The air that flows out here is somewhat cooler than the air delivered to the footwell.

## Microfilter

The microfilter removes dust and pollen from the incoming air and in the recirculated-air mode. It is replaced by your BMW Sports Activity Vehicle center during regular maintenance. A substantial reduction in air supply indicates that the filter must be replaced before normal maintenance.

## Defrosting windows and removing condensation


1. You can specify an interior temperature that is comfortable for you with the rotary temperature dial. A good starting point is 70 °F/22 °C
2. Set the air distribution rotary dial to
3. Set the blower/air supply rotary dial completely to the right
4. Close the vent outlets in the rear seating area
5. Switch on the rear window defroster to defrost the rear window.



- 1 Airflow directed toward the windshield and side windows
- 2 Airflow for the upper body [111](#)
- 3 Airflow for the footwell

- 4 Rear footwell ventilation
- 5 Airflow for the upper body in the rear seat [111](#)
- 6 Automatic air distribution and supply [109](#)

- 7 Individual air distribution [109](#)
- 8 Temperature, left side of passenger compartment [109](#)
- 9 Display for temperature and air supply [109](#)



- 10 Temperature, right side of passenger compartment [109](#)
- 11 Defrosting windows and removing condensation [109](#)
- 12 Air conditioning [110](#)

- 13 AUC Automatic recirculated-air control [110](#)
- 14 Rear window defroster [110](#)
- 15 Air supply [109](#)
- 16 Maximum cooling [110](#) or residual heat utilization [110](#)
- 17 Air grill for interior temperature sensor – please keep clear and unobstructed

## Tips for pleasant driving

For nearly all conditions, AUTO program 6 offers the optimal air distribution and airflow volume. Select the interior temperature that is comfortable for you.

Detailed setting options are described for you in the following section.

 Your BMW Sports Activity Vehicle center can program the settings of your vehicle in such a manner that, when you unlock the vehicle with your individualized key, your own personalized setting for the automatic climate control is initiated. ▶

## Automatic air distribution


 The AUTO program adjusts the airflow and distribution patterns for you while also using your preselected temperature setting as the basis for adjusting the interior climate to adapt to external influences: summer, winter.

## Individual air distribution



You can cancel the AUTO program by selecting specific air distribution patterns for your personal comfort, the automatic air supply remains in operation. You can direct air to flow onto the windows , toward the upper body , and into the foot-well . You can reactivate the automatic air distribution mode by pressing the AUTO button.

## Temperature



Set the desired temperature individually on the driver's and front passenger side.

The automatic climate control adjusts this temperature as quickly as possible at any time of year, if necessary with the maximum cooling or heating capacity, and then keeps it constant.



When switching between different temperature settings in rapid succession, the automatic climate control does not have sufficient time to adjust the set temperature. ▶

To change the units of measure in the display °F/°C, refer to page 73 or 80.

## Air supply



In the AUTO program, the air supply is automatically controlled, and AUTO appears on the display 9, refer to overview on page 107. You can vary the air supply by pressing the left or right half of the button. When your setting is displayed as bars, the automatic air supply is switched off. Automatic air distribution maintains its setting. You can reactivate the automatic air supply by pressing the AUTO button.

When you press the left side of the button during operation at minimum blower speed, all displays are canceled: the blower, heating and air conditioner are switched off. The outside air supply is closed. You can switch the system back on by pressing any button of the automatic climate control, except the MAX button 16.

## Defrosting windows and removing condensation



Quickly remove ice and condensation from the windshield and front side windows.

## Air conditioning

 The air is cooled and dehumidified and – depending on the temperature setting – warmed again. Depending on the weather, the windshield may fog over briefly when the engine is started. You can reduce condensation forming on the windows by switching on the air conditioning.

 During air conditioning, condensation forms, which then exits under the vehicle. That traces of water on the ground are therefore normal.◀

## Maximum cooling

 Maximally cooled air is obtained as quickly as possible from an outside temperature above 32 °F/0 °C and with the engine running. The automatic climate control changes over to the lowest temperature and switches into the recirculated-air mode. The maximum air quantity only flows out of the vents for the upper body. Therefore, open these vents for maximum cooling.

## AUC Automatic recirculated-air control

 You can respond to unpleasant odors or pollutants in the immediate environment by shutting off the supply of outside air. The system then recirculates the air currently within the vehicle. In AUC operating mode, a sensor detects pollutants in the external air and controls the shut-off automatically.

Press the button repeatedly to run through the following control sequence

- ▷ LEDs off: outside air supply operational
- ▷ Left LED on, AUC mode: the system detects pollutants in the outside air and blocks the flow of air when necessary. The system then recirculates the air currently within the vehicle. Depending on the air quality, the automatic system then switches back and forth between outside air supply and recirculation of the air within the vehicle
- ▷ Right LED on: the outside air supply into the vehicle is shut off continuously. The system then recirculates the air currently within the vehicle.

You can also use the button on the steering wheel to switch between Off and recirculated-air mode or between AUC and recirculated-air mode, refer to page 23.

 If the windows fog over in the recirculated-air mode, switch the recirculated-air mode off and increase the air supply as required.◀

## Rear window defroster

 When the rear window defroster is activated, the LED lights up. The rear window defroster switches off automatically after a while.

## Residual heat


 Press the button when the motor is switched off, but warm.

The heat stored in the engine is utilized for heating the interior when the engine has been switched off – while waiting at a railroad crossing, for instance.

This function may be activated when the outside temperature is below approx. 59 °F/15 °C, the engine is at operating temperature, and the battery

## Automatic climate control\*

is adequately charged. The LED on the button will light up when all conditions have been met.




### Ventilation

The air vents for the upper body region are adjustable:

- 1 Knurled wheels for opening and closing the vent outlets through an infinitely-variable range
- 2 Selector levers for airflow direction
- 3 Use this knurled wheel to control the temperature of the airflow:
  - ▷ Turn toward blue: colder
  - ▷ Turn toward red: warmer.

### Rear climate control\*

- 1 Air supply
- 2 Temperature
- 3 Adjusting the direction of the airflow



### Air supply

0 Blower off

I Maximum blower speed

You can adjust the air supply for the vent outlets through an infinitely-variable range between the 0 and I settings.

In the 0 setting, the blower is switched off and the supply of air through the vent outlets is blocked.

Individual adjustments on the front-seat control elements influence the air supply for rear passenger area climate control.



### Temperature

Passengers in the rear seating area can adjust their own temperature for the vent outlets:

- ▷ Turn toward blue: colder
- ▷ Turn toward red: warmer.

When you start the vehicle, this system ensures that the selected temperature is achieved as quickly as possible. It then maintains this temperature, regardless of the season.

 It is only possible to adjust the temperature when the blower is switched on, not in the 0 setting. ▲

### Microfilter/activated-charcoal filter

The microfilter removes dust and pollen from the incoming air. The activated-charcoal filter provides additional protection by filtering gaseous pollutants from the outside air. Your BMW Sports Activity Vehicle center replaces this combined filter as a standard part of your scheduled maintenance. A substantial reduction in air supply indicates that the filter must be replaced before normal maintenance.

## Roller sun blinds\*

### Roller sun blinds for rear side windows\*

Use the strap to pull out the blinds, then hook them in the attachment provided.

 With roller sun blinds attached, do not open the windows during travel. The blinds may otherwise be damaged by the wind.◀

## Parked car ventilation\*

You can use this system to ventilate the interior and lower its temperature, using the blower of the parked car ventilation or of the automatic climate control.

The parked car ventilation is operated via the MID Multi-Information Display, refer to page [84](#) or via the onboard computer, refer to the separate Owner's Manual.

You can set two different times for the system to start; it will remain active for 30 minutes. You can also switch it on and off directly. Since the system uses a substantial amount of electrical current, you should refrain from switching it on twice in succession without allowing the battery to be recharged in normal operation between uses.

When a preselected activation time is set, the parked car ventilation is operational at outside temperatures above approx. 60 °F /16 °C, or by direct switch activation.

The air enters the passenger compartment through the vent outlets in the instrument cluster, which can be adjusted for both direction and airflow. The vent outlets must therefore be open for the system to operate.

## The concept

The integrated universal remote control can replace as many as three hand-held transmitters for various remote-controlled accessories, such as door openers and house alarm systems. The integrated universal remote control recognizes and learns the transmitted signal of each of the original hand-held transmitters.

The signal of an original hand-held transmitter can be programmed on one of the three memory buttons 1. Following that, each of the devices can be actuated with the appropriately-programmed memory button 1. The LED 2 flashes to confirm transmission of the signal.

Should you sell your vehicle one day, be sure to delete the stored programs beforehand for your safety, refer to page [116](#).



To prevent possible damage or injury, before programming or using the integrated universal remote control, always inspect the immediate area to make certain that no people, animals or objects are within the travel range of the device. Also, comply with the safety precautions of the original hand-held transmitter.◀



To Canadian residents:  
During programming, your hand-held transmitter may automatically stop transmitting after two seconds, which may not be long enough to program the integrated universal remote control. If you are programming from one of these hand-held transmitters, the Universal Transmitter's light may begin to flash in a series of double-blinks. If this occurs, continue to hold the button of the integrated universal remote control while you reactivate your hand-held transmitter. You may have to repeat this function several times while programming.◀

## Checking compatibility



If you see this symbol on the packaging or in the manual supplied with the original hand-held transmitter, it is safe to assume that it is compatible with the integrated universal remote control.

A list of compatible hand transmitters is available via fax polling by calling +49 (0)6838 907283 3333. For details, please call the toll-free HomeLink Hotline at +49 (0)6838 907 277 or 0800 0466 35465 in Germany.

HomeLink is a registered trademark of Johnson Controls.



## Programming

- 1 Memory buttons
- 2 LED

### Fixed-code hand-held transmitter

1. Switch on the ignition.
2. For initial use: press both outer buttons 1 for approx. 20 seconds until the LED 2 flashes. The three memory buttons 1 are cleared.
3. Hold the original hand-held transmitter at a distance of approx. 2 to 8 in/5 to 20 cm from the memory buttons 1.

The required distance between the hand-held transmitter and memory buttons 1 depends on the relevant system of the original hand-held transmitter used.◀

4. Simultaneously press the transmit button on the original hand-held transmitter and the desired memory button 1 of the integrated universal remote control. The LED 2 flashes slowly at first. As soon as the LED 2 flashes rapidly, release both buttons. If the LED 2 does not flash rapidly after approx. 15 seconds, alter the distance.
5. To program other original hand-held transmitters, repeat steps 3 and 4.

The corresponding memory button 1 is now programmed with the signal of the original hand-held transmitter.

You can operate the system when the engine is running or when the ignition is switched on.

If the system cannot be operated after repeated programming, check whether the original hand-held transmitter uses an alternating-code system. To do so, either read the instructions of the original hand-held transmitter or press and hold down the programmed memory button 1 of the integrated universal remote control.

If the LED 2 on the integrated universal remote control flashes quickly for a brief period and then remains lit up for approx. two seconds, this indicates that the original hand-held transmitter is equipped with an alternating code. In the case of an alternating-code system, program the memory buttons 1 as described in the section on alternating-code hand-held transmitters.

If you have additional questions, please consult your BMW Sports Activity Vehicle center or call 1-800-355-3515. You can also visit our website [www.bmwusa.com](http://www.bmwusa.com).◀

### Alternating-code hand-held transmitter

To program the integrated universal remote control, consult the Owner's Manuals for the equipment to be set. You will find information there on the possibilities for synchronization. When programming alternating-code hand-held transmitters, please follow the supplementary instructions below:

Programming will be easier with the aid of a second person.◀

1. Park your vehicle within the range of the remote-controlled device
2. Program the integrated universal remote control as described at the section on fixed-code hand-held transmitters
3. Locate the button on the receiver of the device you want to set up, e.g. on the upper section of the motor
4. Press the button on the receiver of the device you want to set up. After step 4, you have approx. 30 seconds for step 5
5. Press the programmed memory button 1 on the integrated universal remote control three times.

The corresponding memory button 1 is now programmed with the signal of the original hand-held transmitter.


 If you have any additional questions, please contact your BMW Sports Activity Vehicle center.◀

### Clearing memory buttons

It is not possible to clear memory buttons 1 individually. To clear all three memory buttons 1, proceed as follows:

Press both outer buttons 1 of the integrated universal remote control for approx. 20 seconds, maintaining pressure until the LED 2 starts to flash.

### Car phone\*



### Hands-free system

On vehicles with telephone provisions\*, the hands-free microphone is located in the headliner.

For further information on the telephone, refer to the telephone Owner's Manual.



- 1 Adjusting knob for compass zones
- 2 Display

The display indicates the cardinal and/or intercardinal direction in which you are currently driving.

## Setting compass zones

Depending on where you and your vehicle are located, it is necessary to set the appropriate compass zone, refer to world map with compass zones, page 118.

To set the compass zone, press the adjusting button in the mirror frame for approx. 3-4 seconds with a sharp object, e.g. a ball-point pen or the like. The display indicates the number of the currently set compass zone.

To change the zone setting, press the adjusting button repeatedly until the number of the compass zone that applies to your current position is displayed.

The compass will be operational again after approximately 10 seconds.

For automatic dimming action, refer to Interior and exterior mirrors, automatic dimming feature on page 138.

## Calibrating digital compass

In the following situations, the digital compass must be calibrated:


- ▷ C or CAL appears on the display
- ▷ The wrong cardinal direction appears on the display
- ▷ The cardinal direction displayed does not change despite a change in the direction of travel
- ▷ Not all cardinal directions are displayed.


How to correct this:

1. Make sure that there are no large metal objects or overhead power lines in the vicinity of your vehicle and that you have enough space to drive in a circle
2. Input the currently applicable compass zone
3. Press the adjustment button to bring up C or CAL. Then drive in a complete circle at a maximum speed of 4 mph/7 km/h.

If the calibration was successful, the displays C or CAL are replaced with the points of the compass.

## 118 Interior rearview mirror with digital compass\*





## Opening

Pull the handle. The lamp inside the glove compartment comes on.

## Closing

Fold the cover up.

**⚠** To prevent injury in the event of an accident, close the glove compartment immediately after use.◀

## Locking

Use one of the master keys. A master key is also required for unlocking.


**▶** If you turn over only your spare key for valet parking, for example, refer to page 30, this prevents unauthorized access to the glove compartment.◀

## Rechargeable flashlight

Located on the left-hand side of the glove compartment.

Features integral overload-protection, so it can be left in its holder continuously.

**⚠** To avoid completely discharging and possibly damaging the lamp, always ensure that it is switched off before inserting it into the socket.◀



You will find two storage compartments in the armrest between the front seats.

To open the top compartment:

Press the button, refer to arrow 1. A built-in phone\* is located in this compartment.

To move the armrest or open the lower compartment:

Pull the handle, refer to arrow 2.

This compartment contains a coin tray and a storage compartment\* for cassettes or CDs.

You will find additional storage compartments in all of the doors as well as on the backrests of the front seats.


### Clothes hooks

 When suspending clothing from the hooks, ensure that it will not obstruct the driver's vision. Do not hang heavy objects on the hooks. If you do so, they could cause endanger passengers during braking or evasive maneuvers.◀



### Front

Below the sliding cover, refer to illustration.



### Rear

At the end of the center console under the lighter.

Briefly press to open; push back inward to close.

 Do not place glass containers in the cup holders, otherwise there is a danger of injury in an accident.◀

## Ashtray, front



### Socket

The cigarette lighter socket can be used to plug in hand flashlights, car vacuum cleaners etc., with power ratings of up to approx. 200 W at 12 V. Be careful not to damage the socket with unsuitable plugs.

Additional sockets are located in the cargo area, refer to page [128](#), and in the front passenger footwell.

### Emptying

Press the edge of the lid, refer to arrow: the ashtray moves up and can be removed.

### Cigarette lighter, front

Press the lighter 1 in.

The lighter can be removed as soon as it pops out.

**⚠** Hold or briefly press the hot cigarette lighter by the knob only.

Holding or touching it in other areas could result in burns.

The cigarette lighter remains operational when the ignition key has been removed. For this reason, do not leave unsupervised children in the vehicle. ◀

## Ashtray, rear



### Emptying

Remove the insert tray.

122 Cigarette lighter, rear



Press the lighter in.

The lighter can be removed as soon as it pops out.

 Hold or briefly press the hot cigarette lighter by the knob only.

Holding or touching it in other areas could result in burns.

The cigarette lighter remains operational when the ignition key has been removed. For this reason, do not leave unsupervised children in the vehicle.◀

## Ski bag\*

The ski bag allows the safe and clean transport of up to four pairs of standard skis or up to two snowboards.

With the length of the ski bag and the additional space in the cargo area, you can store skis up to 6.8 ft/2.1 m length. Because stowing skis of this maximum length causes the ski bag to narrow, it can only accommodate two pairs of skis with a length of 6.8 ft/2.1 m.




### Loading

1. Fold down the center armrest.  
Loosen the trim from the upper Velcro® fastener and place it onto the armrest

2. Press button 1 downward and swing the cover forward
3. Press button 2: the cover in the cargo area is unlocked.  
With pull-out cargo floor, refer to page 128: pull out floor, release cover and push back floor again; the floor then conceals the cover
4. Place ski bag between the front seats and load. The zip fastener facilitates access to the stowed items.

Make sure that only clean skis are loaded into the ski bag. Wrap sharp edges so that no damage occurs.



**⚠** If the cover in the cargo area is concealed by the pull-out cargo floor, do not fold the larger rear backrest down. If you do so, it will damage the cover.◀


### **Securing load**

After loading, secure the ski bag and its contents. To do so, tighten the retaining belt at the buckle.

**⚠** Secure the ski bag in this way. If you fail to do so, it could endanger occupants during braking or evasive maneuvers.◀

When stowing the ski bag, proceed in the reverse order from loading.

### **Cargo area**




### **Folding rear backrests down**

Reach into the recess and pull forward, refer to arrow.

**▶** When you fold back the backrest, be sure that the catch engages securely. The red warning indicator disappears in the recess when the catch is engaged.

The center safety belt can only be pulled out when the larger backrest is locked.◀




## Roll-up cover

Pull out the roll-up cover and hook it into the brackets at the rear.

You can carry light objects such as items of clothing on the roll-up cover.

**⚠** Do not place heavy or hard objects on the roll-up cover. If you do so, they could pose a danger to vehicle occupants during braking or evasive maneuvers.

Do not allow the roll-up cover to snap back, otherwise it could be damaged. 




## Removing roll-up cover

1. Unlock the case with the button, refer to arrow 1, lift it out of the bracket on the side and hold it in place on the opposite side with the other hand
2. Then push the case toward the side window, refer to arrow 2. This pulls it out of the second bracket and it can be removed.




## Installation

Lay the case in the two side brackets and then press down until it engages.



## Partition net\*

1. Remove the bag with the partition net from the retainer by releasing the hooks from the lashing eyes on both sides



2. Remove the partition net from the bag, unroll it half way and hook it into the retaining strap on both sides, refer to arrow



 Note how the partition net is stored in the bag and secured in the vehicle so that you can return everything to its proper place again after use.

If your vehicle has a pull-out cargo floor, follow the instructions on page [128](#).◀

3. Slide back the covers on the retainers for the partition net on both sides of the roof, refer to arrow
4. Insert the curved ends of the partition net rod into the retainers on both sides
5. Now you can slide the covers toward the front again, refer to arrow

6. Pull the partition net down by the loop on both sides, refer to arrow, and hook the hook into the eye on the backrest

 The case with the roll-up cover is not shown in the illustration. With the case removed, it is easier to hook the hooks of the partition net onto the backrest.◀



7. When the rear backrests are folded down, you can unhook the partition net from the retaining straps, completely unroll it, insert it in the front retainers on the roof and attach the three hooks into the eyes on the backrests.

The illustration shows securing at the bottom right as an example.

## Side covers

Pull the handle to open the side covers.


## Floor cover

To access the spare wheel.


To open: press the recess in the handle, refer to arrow, and raise the cover with the handle.



530de355



530us084



530de292

### Folding floor cover up

Disengage the loop end on the underside of the floor cover and hook it in with the catch on the upper frame of the liftgate cutout.

Before swinging down the floor cover, reengage the loop end in the retainer on the underside of the floor cover.

### Sockets

When you fold the cover caps up, you have access to additional sockets.

You can use the sockets for flashlights, car vacuum cleaners or other automotive appliances with up to approx. 200 watts at 12 volts. Be careful not to damage the socket with unsuitable plugs.

Also refer to page 121.

### Pull-out cargo floor\*

To release, pull the handle recess upward. Then pull the floor out.

**⚠** Do not drive when the cargo floor is pulled out.  
Do not release the cargo floor on steep grades. If you do, it could extend automatically and cause personal injuries. A load which is not properly secured could slide if the floor extends automatically and then drop to the ground as a result of the rapid braking of the cargo floor at the limit stop.◀


## Cargo area

When it is extended, you can load the cargo floor:

- ▷ With up to 990 lbs./450 kg, distributed evenly across the entire surface
- ▷ With up to 330 lbs./150 kg on the rear edge.

 Do not overload the cargo floor when it is extended. If you do so, it could cause damage.

When sliding the cargo floor back in, do not reach under the floor. Otherwise there is a risk of injury.◀



### Raising cargo floor

For access to the spare wheel or other stored items:

Swing the cargo floor up and secure it with the rod, refer to illustration.

 If your vehicle has a partition net:  
Take the bag with the partition net out of the retainer, refer to page 125, before you raise the cargo floor. Otherwise, the bag could slide downward.◀

**!** Avoid overloading the vehicle so that the permissible loading capacity of the tires is not exceeded. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. The ultimate result can assume the form of a sudden air loss.◀




### Determining loading limit

1. Locate the following statement on your vehicle's placard\*:


**!** The combined weight of occupants and cargo should never exceed XXX lbs. or YYY kg, otherwise the vehicle may be damaged and unstable driving conditions may result.◀
2. Determine the combined weight of the driver and passengers that will be riding in your vehicle
3. Subtract the combined weight of the driver and passengers from XXX lbs. or YYY kg

4. The resulting figure equals the available amount of cargo and luggage load capacity.  
For example, if the XXX amount equals 1,350 lbs. and there will be five 150 lbs. passengers in your vehicle, the amount of available cargo and luggage load capacity is 600 lbs.:  
 $1,350 \text{ lbs.} - 750 \text{ lbs.} = 600 \text{ lbs.}$
5. Determine the combined weight of luggage and cargo being loaded into the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4
6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult the manual for transporting a trailer to determine how this may reduce the available cargo and luggage load capacity of your vehicle.



## Load:

The permitted load is the total of the weight of occupants and cargo/luggage. The greater the weight of occupants, the less cargo/luggage can be transported.



## Stowing cargo

- ▷ Use the partition net to protect the occupants, refer to page 125
- ▷ Position heavy cargo as far forward as possible directly behind the backrests and as low as possible
- ▷ Cover sharp edges and corners
- ▷ Do not pile objects higher than the top edge of the backrest
- ▷ Appropriately wrap objects that could strike the rear window while driving
- ▷ If you are transporting very heavy loads when the rear seat is not occupied, secure the outer safety belts in the opposite buckles.


## Securing load

- ▷ Secure smaller, light pieces with the retaining straps or a luggage net\*, or use elastic straps, refer to page 37
- ▷ Heavy-duty cargo straps\* for securing larger and heavier objects are available at your BMW Sports Activity Vehicle center. The lashing eyes provided at the corners of the cargo area serve for mounting these heavy-duty cargo straps
- ▷ Read and comply with the information enclosed with the heavy-duty cargo straps.

## Roof-mounted luggage rack\*

**⚠** Always position and secure the load as described above. If you do not, it can endanger the passengers during braking or evasive maneuvers. Do not exceed the permissible gross vehicle weight and the permissible axle loads, refer to page 182. If you do, the operating safety of the vehicle is no longer ensured and you are in violation of the law.

You should never transport heavy or hard objects unsecured in the passenger compartment, as they could fly around and pose a safety hazard to the vehicle's occupants even during abrupt braking or evasive maneuvers. ◀



A special rack system is available as an option for your BMW. Please comply with the precautions included with the installation instructions.

### Mounting points

Access to the mounting points:  
To fold up the cover, refer to arrow,  
please use the tool which is provided  
with the rack system.

### Loading luggage rack

Roof-mounted luggage racks raise the center of gravity of the vehicle when they are loaded and therefore significantly effect the vehicle's handling and steering response.

It is thus crucial never to exceed the approved roof weight, the approved gross vehicle weight or the axle loads when loading the rack.

You will find the specifications under Technical data on page 182.

Make sure that the load is distributed evenly, and that it does not extend outward to beyond the limits of the loading surface. Always load the heaviest pieces on the bottom. Be sure that adequate clearance is maintained for raising the panorama glass roof, and that objects do not project into the opening path of the liftgate.

**⚠** Always ensure that roof-mounted loads are tightly secured, as loose loads can shift or even fly off the roof, posing a serious hazard for following traffic. ◀

Drive smoothly. Avoid sudden acceleration and braking maneuvers. Take corners gently.







Index

Technical data

Owner service procedures

Operation, maintenance

Controls and features

Overview

Moving parts should be allowed to break in. To ensure that your vehicle provides maximum economy throughout a long service life, we request that you comply with the following instructions:

### **Engine and differential**

Obey your local and state maximum speed limits.

Up to 1,200 miles/2,000 km:

Drive at varying engine speeds and road speeds, but do not exceed 4,500 rpm and the following road speeds during this initial period:

- ▷ 6-cylinder engine  
100 mph/160 km/h
- ▷ 8-cylinder engine  
106 mph/170 km/h

Avoid full-throttle operation and use of the transmission's kick-down mode during these initial miles.

From 1,200 miles/2,000 km:

The engine and vehicle speed can gradually be increased.

### **Tires**

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial break-in period. Therefore, drive reservedly during the first 200 miles/300 km.

Obey your local and state maximum speed limits.



When the vehicle is operated on wet or slushy roads, a wedge of water may form between the tire and the road surface. This phenomenon is referred to as hydroplaning and can lead to partial or complete loss of traction, vehicle control and braking effectiveness. Reduce your speed on wet roads.◀

### **Brake system**

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimal contact and wear patterns between brake pads and rotors.

To break in the separate handbrake drums, apply the handbrake lightly when coasting to a standstill at a traffic signal, for instance, provided that traffic conditions allow you to do so.

To avoid corrosion, repeat this procedure from time to time.



The brake lamps do not light up when the handbrake is applied. Vacuum for the brake system servo unit on your BMW is available only when the engine is running. When you move the vehicle with the engine switched off, when towing, for instance, substantially higher levels of pedal force will be required to brake the vehicle.◀

### **Clutch**

The function of the clutch is only at its optimized level after a distance driven of approx. 300 miles/500 km. During this break-in period, engage the clutch gently.

### **Following component replacements**

Observe the break-in instructions again if previously addressed components must be replaced again during subsequent driving.

## Closing liftgate/tailgate

 Operate the vehicle only when the tailgate and liftgate are completely closed. Otherwise, exhaust fumes could enter into the passenger compartment.◀

However, if special circumstances should make it absolutely necessary to operate the vehicle with the liftgate/tailgate open:

1. Close all windows and the panorama glass roof
2. Increase the air supply for the air conditioner or automatic climate control to a high level, refer to page [105](#) or [109](#).

## Hot exhaust system

 Extreme temperatures occur on the exhaust system on any vehicle. Do not remove the heat shields installed adjacent to it, and never apply undercoating to them. When driving, standing at idle and while parking, take care to avoid possible contact between a hot exhaust system and any highly flammable materials such as hay, leaves, grass etc. Otherwise, there is a danger of ignition and fire, with the risk of serious injuries and damage.◀

## Mobile communications devices in vehicle

 BMW advises against using mobile communications devices such as mobile phones inside the vehicle unless they are directly connected to the external antenna. Otherwise, it is impossible to prevent a mutual interference of the vehicle electronics with the mobile phone device. Also, there is no guarantee that the radiation generated by the transmission will be conveyed out from the interior of the vehicle.◀

## When vehicle is parked

Condensation forms in the air conditioner system during operation and then exits under the vehicle. Traces of water on the ground are therefore normal.

## Brakes

 Do not drive with your foot resting on the brake pedal. Even light but consistent pedal pressure can lead to excessively high temperatures, brake wear and possibly even brake failure.◀

## Road hazards

 If road hazards, obstacles or curbs are unavoidable, only drive over them very slowly and carefully, otherwise the wheels and suspension parts, especially on vehicles fitted with low profile tires, can be damaged.◀

For more information on wheels and tires, refer to page [146](#).

## Before driving into a car wash

Fold in the exterior mirrors, refer to page [53](#), otherwise they could be damaged due to the width of the vehicle.

## Hydroplaning


 When driving on wet or slushy roads, reduce road speed. If you do not, a wedge of water can form between tires and road surface. This state can cause a partial or total loss of contact with the road surface, of braking control and of control over the vehicle.◀

## Driving through water

**!** Do not drive through water on the road if it is deeper than 20 in/50 cm, and then only at walking speed at the most. Otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged. When equipped with 2-axle self leveling suspension\*, switch the vehicle into the Off-Road setting before driving through, refer to page 97.◀

## Using handbrake on slopes

**!** Do not hold the vehicle in place on slopes by slipping or riding the clutch; use the handbrake instead. Otherwise, severe clutch wear will result.◀



## Interior and exterior mirrors, automatic dimming feature\*

Two photocells serve to control the automatic dimming of the interior and exterior rearview mirrors. One photocell is in the mirror glass, refer to arrow, while the other is on the back of the mirror, offset somewhat from the first.

For trouble-free operation, keep the photocells clean and do not cover the area between the interior rearview mirror and the windshield. Do not attach any kind of stickers to the windshield in front of the mirror either.

## Driving your X5

### On poor roads

When you are driving on poor roads, there are a few points which you should strictly observe – for your own safety, for that of your passengers, and for the safety of the vehicle:

**!** Driving on unpaved terrain can cause damage to the vehicle.◀

▷ Always adapt the driving speed to the road conditions. The rougher or steeper the road surface is, the lower the speed should be

▷ You can operate your vehicle on uphill and downhill gradients with a maximum slope of 50%. If you want to drive on uphill or downhill gradients of this kind, make sure beforehand that the engine oil and coolant levels are near the max mark, refer to pages 152 and 154.

Use the HDC Hill Descent Control when driving down steep grades, refer to page 94.

It is possible to start off on grades of up to 33%.

The permissible body roll is also 50%

▷ While driving, watch carefully for obstacles such as rocks or holes. Try to avoid these obstacles whenever possible

- ▷ Please note that it is possible for the undercarriage to touch the ground, for example on crests and bumpy roads. The ground clearance of the vehicle is:
  - without self-leveling suspension X5 3.0i, 4.4i: 8 in/20 cm
  - X5 3.0d: 7 in/17.5 cm
  - with 2-axle self-leveling suspension\*  
6.5-9 in/16.5-22 cm, depending on the level selected.
- ▷ Only drive through water up to a maximum depth of 20 in/50 cm and only at walking speed, making sure not to stop in the process. When equipped with 2-axle self leveling suspension\*, switch the vehicle to the Off-Road setting before driving through, refer to page [97](#).  
After leaving the water, apply the footbrake lightly several times while driving at low speeds so as to dry the brakes by braking and to prevent decreased braking action due to wetness.

## Back onto paved road

Our recommendation that you observe the following points after driving on adverse road surfaces is not intended as a beauty treatment for your BMW. Instead, it is intended to maintain driving safety:

- ▷ Clean the worst of the dirt from the body and inspect the undercarriage for damage.
- ▷ Clean mud, snow, ice etc. from the wheels and tires and check the wheels for damage.
- ▷ Check to determine whether rocks, gravel or accumulations of dirt on the brake rotors and calipers could influence braking performance. Remove all such foreign objects.
- ▷ In order to clean the brake rotors, apply the footbrake gently several times while driving at a low speed. Be sure that following traffic is not endangered by this.
- ▷ For cleaning the handbrake, apply the lever slightly at approx. 25 mph/40 km/h and continue to drive for approx. 200 yards/200 meters, provided that traffic conditions allow you to do so.

## Emergency stops

You brake most effectively when you apply maximum pedal pressure in situations requiring it: emergency stops. Since the vehicle maintains steering responsiveness, you can nevertheless avoid possible obstacles with a minimum of steering effort.

Pulsation at the brake pedal combined with sounds from the hydraulic circuits indicates to the driver that ABS is in its active mode.

## Brake fluid level

If the brake fluid level is too low and brake pedal travel has become longer, there may be a malfunction in one of the two brake system's hydraulic circuits.

 Proceed to the nearest BMW Sports Activity Vehicle center. In so doing, increased pressure on the brake pedal may be required, and slight pulling to the side and longer braking distances may result. Please remember to adapt your driving style accordingly. ◀

## Disk brakes

When the vehicle is driven only occasionally, during extended periods when the vehicle is not used at all, and in operating conditions where brake applications are less frequent, there is an increased tendency for corrosion to form on rotors, while contaminants accumulate on the brake pads. This occurs because the minimal pressure that the pads must exert to clean the rotors during brake applications is not reached.

If the brake rotors are corroded, they will tend to respond to braking with a pulsating effect that even extended application will fail to cure.

When driving in wet conditions and in heavy rain, it is advisable to apply light pressure to the brake pedal from time to time. Monitor traffic conditions to ensure that this maneuver does not endanger other road users. The heat generated in this process helps dry the pads and rotors to ensure that the braking force is then immediately available when required.

Extended or steep mountain descents should be driven in the gear in which only minimal periodic brake application is required. This avoids excessive strain

on the brakes and possible impairment of braking action.



Do not drive with the clutch pedal depressed, at idle or with the engine switched off, as otherwise there will be no engine braking effect or power assistance for braking and steering.

BMW recommends having brake inspections performed at a BMW Sports Activity Vehicle center only. If you do not, parts of the 4-wheel drive system could be damaged.

No floor mats, carpets or other objects may lie in the area of pedal travel, as otherwise pedal operation may be impaired. ◀

## Brake pads

 For your own safety: use only brake pads that BMW has approved for your particular vehicle model. BMW cannot evaluate non-approved brake pads to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are installed. ◀

# Tire inflation pressure

## Information for your safety

The condition of the tires and the maintenance of the specified tire pressure are crucial not only to the tire's service life, but also to driving comfort and most importantly, driving safety.

## Checking pressure

Only check tire inflation pressure when the tires are cold. This means after a maximum of 1.25 miles/2 km driving or when the vehicle has been parked for at least 2 hours. When tires are warm, the tire inflation pressure increases.

**⚠ Check the tire inflation pressure regularly and correct it as needed, even on the spare wheel: at least twice a month and before starting long trips. If you fail to observe this precaution, you may be driving on tires with incorrect tire pressures, a condition that can not only compromise your vehicle's driving stability, but also lead to tire damage and the risk of an accident. Do not drive with deflated, i.e. flat, tires. A flat tire will seriously impair your vehicle's handling and braking response. Attempts to drive on a flat tire can lead to loss of control over the vehicle.◀**



After correcting the inflation pressure(s), always reinitialize the Flat Tire Monitor, refer to page 99.◀



530de225

## Inflation pressures for factory-installed tires

The tire inflation pressure specifications for your factory-installed tires at ambient temperature are listed on the edge of the driver's door and can be consulted when the door is open.

## Inflation pressures

The tire pressure tables in the following pages give all of the pressure specifications for the tire sizes indicated at ambient temperature.



The inflation pressures apply to the tire sizes and tire brands respectively approved and recommended by BMW; a list of these is available from your BMW Sports Activity Vehicle center.◀

## 142 Tire inflation pressure

For correct identification of the right tire inflation pressure for your tires, observe the following:

- ▷ Tire sizes for your vehicle
- ▷ Load conditions
- ▷ Maximum allowable driving speed

Tire inflation pressures for driving up to 100 mph or 160 km/h:

For normal driving up to 100 mph or 160 km/h adjust pressures to the respective tire inflation pressures listed on the following page in the traveling speeds column for normal driving at speeds up to a maximum of 100 mph or 160 km/h to achieve optimum driving comfort.

Tire inflation pressures for driving above 100 mph or 160 km/h:


 In order to drive at maximum speeds in excess of 100 mph or 160 km/h, please observe, and, if necessary, adjust tire pressures for speeds exceeding 100 mph or 160 km/h from the relevant table on the following pages. Otherwise tire damage and accidents could occur.◀

 The permissible top speed for these tire inflation pressures is 100 mph or 160 km/h. Do not exceed this speed, as otherwise tire damage and accidents may result.◀

BMW	Tire size	Pressure specifications in psi/kPa					
		Traveling speeds up to a max. of 100 mph/160 km/h		Traveling speeds including those exceeding 100 mph/160 km/h			
	All pressure specifications in the table are indicated in psi/kilopascal with cold tires, cold = ambient temperature						
X5 3.0i	235/65 R 17 104 H M+S 255/55 R 18 105 H M+S	32/220	33/230	32/220	32/220	32/220	39/270
	Front: 255/50 R 19 103 V Rear: 285/45 R 19 107 V Front: 275/40 R 20 102 W Rear: 315/35 R 20 106 W	32/220	-	32/220	-	32/220	-
		-	32/220	-	32/220	-	39/270
		32/220	-	32/220	-	32/220	-
		-	32/220	-	32/220	-	39/270

You will find more information on permissible loads and weights on page [182](#).

## 144 Tire inflation pressure

BMW	Tire size	Pressure specifications in psi/kPa					
		Traveling speeds up to a max. of 100 mph/160 km/h		Traveling speeds including those exceeding 100 mph/160 km/h			
	All pressure specifications in the table are indicated in psi/ kilopascal with cold tires, cold = ambient temperature						
	235/65 R 17 104 H M+S 255/55 R 18 105 H M+S	32/220	33/230	32/220	33/230	32/220	39/270
X5 4.4i	Front: 255/50 R 19 103 V	32/220	-	32/220	-	32/220	-
	Rear: 285/45 R 19 107 V	-	32/220	-	32/220	-	39/270
	Front: 275/40 R 20 102 W	32/220	-	32/220	-	32/220	-
	Rear: 315/35 R 20 106 W	-	32/220	-	32/220	-	39/270
X5 4.8is	Front: 275/40 R 20 102 W	32/220	-	32/220	-	33/230	-
	Rear: 315/35 R 20 106 W	-	35/240	-	35/240	-	39/270
	255/55 R 18 105 H M+S	32/220	35/240	32/220	35/240	33/230	39/270
	Compact wheel: T 155/80 R 19 114 M			61/420			

You will find more information on permissible loads and weights on page [182](#).

## Tire identification marks

Knowledge of the labeling on the side of the tire makes it easier to identify and choose the right tires.

### Tire size

e.g. 235/65 R 17 104 H

Nominal width in mm \_\_\_\_\_

Cross-sectional ratio in % \_\_\_\_\_

Belted construction radial \_\_\_\_\_

Rim diameter in inches \_\_\_\_\_

Load index, not with ZR tires \_\_\_\_\_

Speed code letter, with ZR tires before the R \_\_\_\_\_

Speed code letter:  
 Q = up to 105 mph/160 km/h  
 T = up to 118 mph/190 km/h  
 H = up to 131 mph/210 km/h  
 V = up to 150 mph/240 km/h  
 W = up to 167 mph/270 km/h

### Tire Identification Number

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

DOT code:

e.g. DOT xxxx xxx 2605

Manufacturer's code for tire brand \_\_\_\_\_

Tire size and tire model \_\_\_\_\_

Tire age \_\_\_\_\_

### Tire age

The manufacturer of your BMW recommends that all tires, i.e. including the spare wheel, be replaced regardless of the actual wear after 6 years at the latest.

The tire's date of manufacture is indicated on the sidewall:

DOT... 2605 indicates that the tire was manufactured in week 26 of 2005.

### Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

### DOT Quality Grades

Tread wear

Traction AA A B C

Temperature A B C

 All passenger car tires must conform to Federal Safety Requirements in addition to these grades. ▶

### Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and one-half, 1 1/2, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

## Traction

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

 The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.◀

## Temperature

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to a sudden flat tire. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

 The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible a tire failure.◀

## M+S

Winter and all-season tires. These have better winter properties than summer tires.

## Wheel/tire condition

### Wheel/tire damage

Inspect your wheels and tires frequently for tread wear, signs of damage and for foreign objects lodged in the tread. Check the tread pattern depth.

 Please note that low-profile tires make your wheels, tires and suspension parts more susceptible to road hazard and consequential damages. Unusual vibrations encountered during normal vehicle operation can indicate tire failure or some other vehicle malfunction. This can, for example, be caused by driving over curbs. This is also true for irregularities in the vehicle's handling characteristics, such as a pronounced tendency to pull to the left or right. Should this occur, respond by immediately reducing your speed. Carefully proceed – or have your vehicle towed – to the nearest BMW Sports Activity Vehicle center or tire dealer to have the wheels or tires inspected. Tire damage, extending to sudden and complete loss of pressure in extreme cases, can pose a potentially lethal safety hazard for the vehicle's occupants and other road users alike.◀

# Wheel/tire condition

## Tire tread

The tread depth should not fall below 0.12 in/3 mm although, for example, European regulations only require a minimum tread depth of 0.063 in/1.6 mm.

At tread depths below 0.12 in/3 mm, there is an increased risk of high-speed hydroplaning, even when only small amounts of water are present on the road surface.

As winter tires display a noticeable loss in their ability to cope with cold-weather driving conditions once the tread wears to below 0.16 in/4 mm, you should always have such tires replaced to ensure continued safety.



Wear indicators at the tread-groove base are distributed over the tire's circumference and are marked on the side of the tire with TWI – Tread Wear Indicator. If the tire tread has worn down to the wear indicators, then the legally permissible tread depth limit of 0.063 in/1.6 mm has been reached.

**⚠** Have new wheels and tires installed only by your BMW Sports Activity Vehicle center or tire shop that works according to BMW repair procedures with correspondingly trained personnel. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards.◀

### Retreaded tires

**⚠** BMW does not recommend the use of retreaded tires, otherwise driving safety may be reduced. The reason for this is that possible variations in the design and aging – which could be substantial – of the tire casing can result in a limited service life.◀

### The right wheels and tires

**⚠** BMW recommends that you use only wheel and tire combinations that BMW has tested and approved for your particular vehicle. Variations in factors such as manufacturing tolerances mean that even wheels and tires with identical official size ratings could actually have different dimensions than the approved units – these differences could lead to body contact, and with it the risk of severe accidents. If non-approved wheels and tires are used, BMW cannot evaluate their suitability, and therefore cannot be held liable for driving safety.◀

You can ask your BMW Sports Activity Vehicle center for the correct wheel/tire combination.

The correct wheel/tire combination also affects various systems whose function would otherwise be impaired, e.g. ABS, DSC, xDrive.

To maintain good handling and vehicle response, use only tires of a single tread configuration from a single manufacturer. After tire damage, always remember to have the original wheel and tire combination remounted on the vehicle as soon as possible.



**Recommended tire brands:**  
BMW recommends particular tire brands for each tire size. You will recognize them by the clearly visible BMW identification on the tire sidewall.

With proper use, these tires meet the highest standards for safety and handling characteristics.

## Special features of winter tires

BMW recommends winter tires for use in cold winter driving conditions.

Although all-season M+S tires provide better winter traction than summer tires, they generally fail to provide the same levels of cold-weather performance as winter tires.

When switching to winter tires, observe the description under Tire condition, page [146](#), and Replacing wheels/tires.

Observing speed ratings:

 Never exceed the maximum speed for which the winter tires are rated. Unprofessional attempts by laymen to service tires can lead to damage and accidents. Have this work performed by skilled professionals only.

The technicians at your BMW Sports Activity Vehicle center will be glad to assist you with the required professional knowledge and specialized equipment.◀

## Storage

Store wheels or tires in a cool, dry place, protecting them against light whenever possible. Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

## Snow chains\*

Only certain fine-link snow chains are tested, classified as road-safe, and recommended by BMW. Consult your BMW Sports Activity Vehicle center for details. Use is only permitted in pairs on the rear wheels with the following tire sizes:


X5 4.8is: 255/55 R 18

All other models: 235/65 R 17


Follow the manufacturer's instructions when installing snow chains. Do not exceed a maximum speed of 30 mph/50 km/h.

 Do not initialize the Flat Tire Monitor after mounting snow chains, as the monitor may then incorrectly indicate flat tires.


When you are driving with snow chains, it can be beneficial to switch off DSC briefly, refer to page [93](#).◀



530de295



530de296



530de369

### Unlocking

Pull the lever located under the left side of the instrument cluster.

**⚠** Never attempt to perform any service or repair operations on your vehicle without the required professional technical training. If you are not familiar with the regulations to be observed, only have work on your vehicle carried out by a BMW Sports Activity Vehicle center or a workshop that uses personnel trained in accordance with BMW requirements. If this work is not carried out properly, there is a danger of subsequent damage and related safety hazards.◀


### Opening

Pull the release handle and open the hood.

### Closing

Allow the hood to fall from a height of about 12 in/30 cm so that it audibly engages.

**⚠** Observe the same precautions that apply to all closing operations by ensuring that the hood's travel range is clear and unobstructed before allowing the hood to fall into position. If you discover that the hood is not completely closed while driving, stop immediately and close it securely.◀



1 Engine oil dipstick [152](#)


2 Brake fluid reservoir, located beneath  
the microfilter cover [155](#)

3 Auxiliary terminal for jump  
starting [174](#)

4 Coolant expansion tank [154](#)

5 Engine oil filler neck [152](#)

6 Reservoir for windshield and  
headlamp washer system [152](#)



## Windshield and headlamp washer system

Approximate capacity is 8.2 US quarts/7.8 liters.

Fill with water and – if required – with the addition of a washer antifreeze, according to manufacturer's recommendations.

 We recommend that you mix the washer fluid before adding it to the reservoir.◀


 Antifreeze agent for the washer systems is flammable. For this reason, keep it away from sources of flame and store it only in its original containers. Store it so that it is inaccessible to children. Comply with the instructions on the containers.◀

4. Slide the dipstick carefully all the way into the dipstick tube and pull it out again.  
The oil level should be in between the two marks on the dipstick
5. Slide the dipstick all the way into the dipstick tube again.

## Checking oil level

Oil consumption depends on driving style and operating conditions.

1. With the engine at operating temperature, i.e. after at least 6 miles/10 km of continuous driving, park the vehicle in a horizontal position
2. Switch off the engine
3. After approx. 5 minutes, pull the dipstick out and wipe it off with a clean lint-free cloth, paper towel, or similar material




530us205  
The oil volume between the two marks on the dipstick corresponds to approx. 1.1 US quarts/1 liter.

**⚠** Do not fill beyond the upper mark on the dipstick. Excess oil will damage the engine.◀

## X5 4.8is:

With a very sporty driving style, the engine oil level should be at the upper mark on the dipstick.



## Adding engine oil

Wait until the level has dropped to just above the lower mark on the dipstick before adding oil.

**⚠** Add oil within the next 30 miles/50 km, otherwise, the engine could be damaged.◀

**⚠** Keep oil, grease, etc. out of reach of children and heed warnings on the containers to avoid health risks.◀

## Oil change:

Have oil changed only by your BMW Sports Activity Vehicle center or by a repair shop that works according to BMW guidelines with appropriately trained personnel.

## Specified engine oils

The quality of the engine oil selected has critical significance for the operation and service life of an engine. Based on extensive testing, BMW has approved only certain engine oils.

Only use approved BMW High Performance Synthetic Oil.

If you are unable to obtain BMW High Performance Synthetic Oil, you can add small amounts of other synthetic oil in between oil changes. Only use oils with the API SH specification or higher.

**▶** Ask your BMW Sports Activity Vehicle center for details concerning the specific BMW High Performance Synthetic Oil or synthetic oils which have been approved.◀

You can also call BMW of North America at 1-800-831-1117 or visit this website: [www.bmwusa.com](http://www.bmwusa.com) to obtain this information.

**⚠** Never use oil additives as they can damage your engine under some circumstances.◀

## Coolant

### Viscosity ratings

Viscosity is the oil flow rating as established in SAE classes.

The selection of the correct SAE class depends on the climatic conditions in the area where you typically drive your BMW.

 Approved oils are in SAE classes 5W-40 and 5W-30.◀


These oils may be used for driving in all ambient temperatures.

 Do not open the cooling system when the engine is hot. Escaping coolant can cause burns.◀

Coolant is comprised of water and coolant additive. Not all commercially available additives are suitable for your BMW. Your BMW Sports Activity Vehicle center knows which additives are suitable.

 Use only suitable additives, otherwise you could damage your engine. The additives can be harmful to your health.◀

 Always observe all applicable environmental rules and regulations when disposing of coolant additives.◀



### Checking coolant level

1. The engine must be at ambient temperature.
2. Start by turning the cap of the expansion tank counterclockwise. Pause to allow any accumulated pressure to escape, then open.
3. The coolant level is correct when the end of the red float is aligned with the upper edge of the filler opening, refer to the arrow in the illustration, or max. 0.8 in/2 cm higher, i. e. up to the mark on the float, refer also to the schematic diagram, next to the cap.

4. When necessary, slowly add coolant until the correct level is reached; do not overfill.
5. Close the cap and tighten snugly.
6. Have the cause of the coolant loss corrected as soon as possible.

## Brake fluid level



If the warning lamp lights up or the message CHECK BRAKE FLUID appears in the Check Control: stop immediately. The brake fluid in the reservoir has fallen to below the minimum level.

## Add brake fluid

The brake fluid reservoir is located under the microfilter housing trim panel on the driver's side of the vehicle. For adding brake fluid or for determining and correcting the cause of brake fluid loss, consult your BMW Sports Activity Vehicle center. Your BMW Sports Activity Vehicle center is familiar with the specifications for factory-approved DOT 4 brake fluids.

Brake fluid loss may result in extended brake pedal travel. For this situation, refer to the notes on page 140.



Brake fluid is hygroscopic, that is, it absorbs moisture from the air over time.

In order to ensure the safety and reliability of the brake system, have the brake fluid changed every two years by a BMW Sports Activity Vehicle center. Refer also to the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

Brake fluid is toxic and also damages vehicle paintwork. Always store these agents in tightly-closed original containers kept well away from the reach of children.

Do not spill the fluid and do not refill the brake fluid reservoir to beyond the MAX mark. The brake fluid could ignite upon contact with hot engine parts and cause serious burns. ◀



Always observe all applicable environmental rules and regulations when disposing of used brake fluid. ◀



The BMW Maintenance System helps maintain the road and driving safety of your BMW.

Please keep in mind that regular maintenance is not only necessary for the safety of your vehicle, but also plays a significant role in maintaining the resale value of the vehicle.

### Service Interval Display

Conventional systems rely solely on distance traveled to determine when service is due. The BMW Maintenance System, on the other hand, began many years ago to take the actual conditions under which the vehicle is driven into consideration. After all, different drivers can accumulate mileage in very different ways.

From the point of view of maintenance, 62,000 miles/100,000 km accumulated in short-distance urban driving are not the equivalent of the same distance covered at moderate speeds in long-distance highway travel.

The BMW Maintenance System includes the Engine Oil Service and Inspections I and II.

Determining the maintenance intervals according to the actual loads on the vehicle covers every kind of operating situation. However, even those who drive only short distances, significantly less than 6,000 miles/10,000 km annually, should have the engine oil changed at least every 2 years since oil deteriorates over time, regardless of use.

### Service and Warranty Information Booklet for US models/Warranty and Service Guide Booklet for Canadian models

For additional information on maintenance intervals and procedures, please refer to the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

As a precaution against corrosion, it is advisable to have the body checked for damage from rocks or gravel at the same time, depending upon operating conditions.

 Have your BMW Sports Activity Vehicle center do the maintenance and repair.


Be sure that all maintenance work is confirmed in the Service and Warranty Information Booklet for US models or the Warranty and Service Guide Booklet for Canadian models.

These entries will constitute your proof that the vehicle has received regular maintenance. They are also required for warranty claims. ◀

### Car care

For all information on this subject, refer to the Caring for your vehicle brochure.

# OBD interface socket



The interface socket for the Onboard Diagnostics is located on the left of the driver's side at the bottom of the instrument cluster and under a cover. The cover has the letters OBD on it.

The purpose of the OBD system is to ensure proper operation of the emission control system for the vehicle's lifetime. The system monitors emission-related components and systems for deterioration and malfunction.

**SERVICE ENGINE SOON** An illuminated indicator lamp informs you of the need for service, not of the need to stop the vehicle. However, the systems should be checked by your BMW Sports Activity Vehicle center at the earliest possible opportunity.



Display of the previously described malfunction in Canadian models.

Under certain conditions, the indicator lamp will blink or flash. This indicates a rather severe level of engine misfire. When this occurs, you should reduce speed and consult the nearest BMW Sports Activity Vehicle center as soon as possible. Severe engine misfire over only a short period of time can seriously damage emission control components, especially the catalytic converter.



When the filler cap is not properly tightened, the OBD system can detect the vapor leak and the indicator lamp will light up. If the filler cap is subsequently tightened, the indicator lamp should extinguish within a few days. ▶

## Event Data Recorders

Your vehicle may be equipped with one or more sensing and diagnostic modules or a recording device capable of recording or transmitting certain vehicle data or information. In addition, if you have a Subscription Service Agreement for the BMW Assist system, certain vehicle information may be transmitted or recorded in order to provide such services.





Overview




Controls and features

Operation, maintenance

Owner service procedures

Technical data

Index

**Windshield wiper blades**

Under the cargo floor cover in a pocket.

**Front**

1. Move the wiper to a fold-out position, refer to page 69
2. Lift the wiper arm and press the securing spring, refer to arrow
3. Pull the wiper blade off toward the wiper arm
4. Insert the new blade and snap it into place.

Fold the wipers back down onto the windshield before you turn the ignition key to position 1 or 2 again. If you do not, they could be damaged.◀

**Rear**

1. Hold the wiper blade on the window and remove/unclip the wiper arm at the articulated joint, refer to arrow
2. Insert a new wiper blade and press it on/clip it into the wiper arm.

Use only wiper blades approved by BMW.◀



The lamps and bulbs make essential contributions to the safety of your vehicle. For this reason, follow the instructions below carefully when replacing a bulb. If you are not familiar with any of the procedures, consult your BMW Sports Activity Vehicle center.

 Never touch the glass on new bulbs with your bare fingers, as even minute amounts of contamination will burn into the bulb's surface and reduce its service life. Use a clean cloth, paper napkin, or a similar material, or hold the bulb by its metallic base.◀

A replacement bulb set is available from your BMW Sports Activity Vehicle center.

 To prevent short circuits, before working on any electrical system, equipment or accessory you should always switch it off and disconnect the cable from the battery's negative terminal before starting.

To avoid possible injury or equipment damage when replacing bulbs, follow any instructions provided by the bulb manufacturer.◀



## Releasing lamp cover

The illustration shows the right-hand side of the engine compartment.

### 1 Halogen low beams

Turn cover cap to left, refer to arrow

### 2 High beams and parking lamps

Press tab downward, refer to arrow

 For checking and adjusting head lamp aim, please contact your BMW Sports Activity Vehicle center.◀

## 1 Halogen low beams


H7 bulb, 55 watts

 The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Otherwise there is a danger of injury if the bulb is accidentally damaged during replacement.◀

1. Remove the cover

2. Turn the bulb holder to the left and remove

3. Pull bulb out of bulb holder by base and replace.



## 2 Halogen high beams

H1 bulb, 55 watts

**!** The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Otherwise there is a danger of injury if the bulb is accidentally damaged during replacement.►

1. Remove the cover
2. Disconnect the plug
3. Unhook wire spring
4. Remove and replace the bulb.

## 3 Parking lamps and roadside parking lamps


10 watt bulb: H 10 W

1. Remove the cover
2. Disconnect the plug
3. Turn reflector module with bulb to left and remove
4. Replace module with bulb.

## Xenon lamps\*

The operating life of these lamp units is extremely long and the likelihood of failure very low, provided that they are not switched on and off a very great number of times. If one of these bulbs should nevertheless fail, it is possible to continue driving with great caution using the fog lamps, provided traffic laws in your area do not prohibit this.

**!** To avoid risk of potentially fatal injuries: owing to the extremely high voltages at which these units operate, service work should always be entrusted to qualified personnel.►



## Side turn signals

5 watt bulb: WY 5 W

1. Use finger pressure against the rear end of the lamp, refer to arrow, to press it forward for removal
2. Apply gentle pressure to the bulb while turning it to the left and pull it out
3. Replace the bulb.

## Front turn signals/side-marker lamps

Bulb S8 yellow

Please contact a BMW Sports Activity Vehicle center in case of a malfunction.




## Front fog lamps

H11 bulb, 55 watts

**!** The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Otherwise there is a danger of injury if the bulb is accidentally damaged during replacement.◀

1. Pull the cover in front of the fog lamp forward.
2. Loosen the two screws, refer to arrows, and remove the fog lamp. When pulling out, overcome initial resistance and turn the headlamp slightly to the left.
3. Pull the cable connector off the bulb.
4. Turn the bulb to the left and remove.


5. Insert a new bulb in the headlamp and turn as far to the right as possible.
6. Connect the plug connector to the bulb, ensuring proper engagement.



## Tail lamps


21 watt bulbs: P 21 W and PY 21 W, recommendation: BMW special bulbs with neutral coloration

- 1 Turn signal
- 2 Rear lamp/side marker lamp
- 3 Backup lamp
- 4 Brake lamp
- 5 Reflector




Lamps in the side panel:

1. Open the cover in the side panel
2. Lift the side panel if necessary
3. Apply gentle pressure to the bulb holder while turning it to the left for removal and replacement
4. Remove the bulb.



Lamps in the tailgate:

1. Unclip the trim panel in the tailgate with a screwdriver
2. Apply gentle pressure to the bulb holder while turning it to the left for removal and replacement
3. Remove the bulb.



**License plate lamps**

- 5 watt bulb
1. Press the lamp out to the side with a screwdriver
  2. Remove the lamp and replace the bulb.

**Center brake lamp**

LED strip in the rear spoiler: please contact a BMW Sports Activity Vehicle center in case of a malfunction.

### Light-emitting diodes LEDs

Light-emitting diodes installed behind translucent lenses serve as the light source for many of the controls and displays in your vehicle. The concept behind their operation is related to that employed for lasers.

 Do not remove the covers, and never stare into the unfiltered light several hours, as irritation of the retina could result. ◀

## Changing a wheel

 Safety precautions to observe in the event of a flat and during all tire changes:

Park the vehicle as far as possible from passing traffic. Park on a firm, flat, surface. Switch on the hazard warning flashers.

Turn the steering wheel to the straight-ahead position, remove the key and engage the steering lock. Shift into 1st or reverse, selector lever in Park with automatic transmission, and engage the handbrake.

All passengers should be outside the vehicle and well away from your immediate working area, behind a guardrail, for instance.




If a warning triangle or portable hazard warning lamp is required, set it up on the roadside at an appropriate distance from the rear of the vehicle. Comply with all safety guidelines and regulations.

Change the wheel only on a level, firm surface that is not slippery. The vehicle or the jack could slip to the side if you attempt to raise the vehicle on a soft or slippery surface such as snow, ice, tiles, etc.

Position the jack on a firm support surface.

Do not place wooden blocks or similar objects under the jack. If this is done, the jack might not be able to reach its full support capacity because of the limited height. To avoid serious or fatal injury: never lie under the vehicle, and never start the engine while it is supported by the jack. ◀

Your BMW has either a compact wheel for temporary use to ensure your mobility, or a spare wheel of the size 235/65 R 17. Please observe the differences in handling when removing the wheel from the cargo area.



### What you will need

In order to avoid rattling noises later, note the position of the tools when you remove them and return them to their original position when you are through using them.


- ▷ Two wheel chocks  
Open liftgate and tailgate.  
Raise the floor panel flap or pull-out cargo floor in the cargo area, refer to page [128](#) or [129](#). On vehicles with a compact wheel, remove the cover, refer to page [167](#).  
Remove the wheel chocks, refer to arrow, next to the spare wheel

- ▷ Lug wrench  
Located beside the spare wheel

- ▷ Handle for the jack  
Remove from its holder

# Changing a wheel

167



## ▷ Jack

Remove the rubber band from the holder, refer to arrow, and take out the jack.

Following use, crank down the vehicle jack completely again and clip in the crank.




## Compact wheel

Remove the cover under the floor panel flap.


Vehicles with pull-out cargo floor: the cover is secured at the rear on both sides with quick-release locks.

1. Loosen the wing nut 1
2. Remove the plate 2 to the side
3. Remove the wheel.



## Spare wheel\*

1. Loosen the wing nut 1
2. Remove the plate 2 to the side
3. Unscrew the threaded rod 3 completely.



### **Removal aid for spare wheel**

By using this device, you do not have to lift the spare wheel out of the recess by hand.

Its task is to help you to move the wheel onto the tailgate, from where you can easily lift it off.


1. Close the tailgate again
2. Grasp the handle of the removal aid behind the spare wheel with both hands and pull upward over the tailgate, refer to arrow.

3. Hook both buckles into the latch of the tailgate, refer to arrow; the tailgate is released.

4. Remove the support rod from the bracket.

# Changing a wheel

169



5. Press the tailgate down and hold it there. The spare wheel is now pulled by means of the removal aid onto the tailgate.

**⚠** Hold the tailgate in the opened position and do not allow it to spring upward abruptly. If you do so, there is a risk of vehicle damage and injury.◀




6. Insert the support rod in the tailgate lock and press down until it engages, refer to arrow 1; then lock hook of rod in striker, refer to arrow 2.

**⚠** Make sure that the support rod is locked firmly in place. If you fail to do so, the tailgate could move upward quickly and cause personal injury and vehicle damage.◀

7. You can now release the locked tailgate and take down the spare wheel. It is recommended that you leave the tailgate locked into place until you have completed the wheel change and placed the wheel with the defective tire into the removal aid.

## Procedure

1. Read carefully and comply with the safety precautions on page 165.
2. Secure the vehicle to prevent it from rolling:  
Place the wedges – chocks – behind the wheels on the side opposite the side you are lifting. If the vehicle is parked on a downward slope, place the wedges securely in front of the wheels. If the wheel must be changed on a surface with a more severe slope, take additional precautions to secure the vehicle from rolling.
3. Loosen the lug bolts 1/2-turn.
4. Insert the jack handle into the jack, refer to the illustration in the next column.



5. Position the jack at the jacking point closest to the flat tire so that the jack base is vertically below the jacking point and the entire surface of the head of the jack will move into the square recess of the jacking point, refer to the illustration detail, when the jack is cranked.
6. Jack the vehicle up until the wheel you are changing is raised from the ground.
7. Unscrew the lug bolts and remove the wheel.
8. Remove accumulations of mud or dirt from the mounting surfaces of the wheel and hub. Clean the lug bolts.
9. Move the spare wheel into position. Secure the wheel by turning at least two lug bolts into opposite bolt holes.

10. Screw in the remaining lug bolts. Tighten all the bolts securely in a diagonal pattern.
11. Lower the jack and remove it from beneath the vehicle.
12. Tighten the lug bolts in a diagonal pattern.
13. Check and correct the tire inflation pressure at the earliest opportunity. After mounting the spare wheel or correcting the inflation pressure, reinitialize the Flat Tire Monitor, refer to page 99.

Protect valve stems and valves from dirt using screw-on valve stem caps. Dirt in the valve stems frequently leads to slow leaks.



The vehicle jack is designed for changing wheels only. Do not attempt to raise another vehicle model with it or to raise any load of any kind.

To do so could cause accidents and personal injury.

To ensure safety, always have the lug bolts checked with a calibrated torque wrench as soon as possible to ensure that they are tightened to the specified torque. The tightening torque is 101 lb ft/140 Nm.◀

Store the wheel and the tools in the order opposite that for removal.

**A** Before removing the support rod, be sure that the tailgate is held down firmly. If you fail to do so, it could spring upward abruptly and cause personal injury and vehicle damage. After you remove the rod, close the tailgate carefully. Continue to hold it firmly until it is completely closed.◀

If light-alloy wheels other than Genuine BMW light-alloy wheels have been mounted, it may be necessary to use different lug bolts for those wheels.

Replace the defective tire as soon as possible and have the new wheel/tire balanced.

### Driving with compact wheel

Drive reservedly and do not exceed a maximum speed of 50 mph/80 km/h.

Altered handling characteristics, such as reduced track stability during braking, longer braking distances and altered self-steering properties at the driving limit can occur. These properties are more apparent in conjunction with winter tires.

 Only one compact wheel may be mounted. Wheels and tires of the original size should be mounted again as soon as possible.◀

## Driving with spare wheel\*

 Do not exceed a speed of 130 mph/210 km/h, otherwise tire damage could lead to accidents.◀

 With certain wheel-and-tire combinations the size of the spare wheel differs from that of the other wheels. To restore the original state, the normal wheel should be remounted as soon as possible.◀

 Battery posts, terminals and related accessories contain lead and lead compounds. Wash hands after handling.◀

## Battery care

The battery is maintenance-free, that is, the original electrolyte will normally last for the service life of the battery under moderate climatic conditions. Your BMW Sports Activity Vehicle center will be glad to advise in all matters concerning the battery.

## Charging battery

Only charge the battery in the vehicle via the terminals in the engine compartment with the engine off. For correct connections, refer to Jump starting on page 174.


## Disposal

 Following replacement, have old batteries disposed of by your BMW Sports Activity Vehicle center or turn them over to a recycling center. Maintain the battery in an upright position for transport and storage. Always restrain the battery to prevent it from tipping over during transport.◀

## Power failure

Following a temporary power failure, e.g. in the case of a dead battery, some equipment is subject to restricted use and must be reinitialized. Individual settings are also lost and must be updated again:

- ▷ Seat, mirror and steering wheel memory  
The positions must be stored again, refer to page 50
- ▷ Time and date  
Have to be updated again, refer to page 82
- ▷ Activation time for parked car ventilation  
Has to be updated again, refer to page 84.



### In glove compartment

Open the fuse cover in the glove compartment by the indentations on the right and left.

### In cargo area

Open the right cover by pulling the handle.

 Never attempt to repair a blown fuse, and do not replace a defective fuse with a substitute of another color or amperage rating, as this could lead to a circuit overload, ultimately resulting in a fire in the vehicle.◀

## Receiving assistance

The Roadside Assistance of the BMW Group offers you assistance in the event of a breakdown around the clock, also on weekends and public holidays.

The phone numbers of the Roadside Assistance control center in your home country can be found in the BMW Dealer Directory.


In the case of vehicles with the corresponding equipment, you can use buttons in the headliner to contact Roadside Assistance or initiate an emergency call.

When the emergency call is initiated, a telephone connection with the BMW Assist response center is established.

In vehicles with activated BMW Assist, if the current position of your vehicle can be determined, it is transmitted to the BMW Assist response center.

The requirements for initiating an emergency call or contacting Roadside Assistance:

- ▷ Ignition key in position 1
- ▷ The car phone is logged on to a mobile telephone network
- ▷ The emergency call system is operable.



- 1 Initiating an emergency call
- 2 Establishing contact to Roadside Assistance

### Initiating an emergency call\*

Press button 1 for at least 2 seconds. The LED in the button lights up. As soon as the voice connection to the BMW Assist response center has been established, the LED flashes. If the LED flashes, but you are unable to hear the response center, you can still be heard by the response center.



For technical reasons, the emergency call cannot be guaranteed under the most unfavorable conditions. ▲

Under certain conditions, an emergency call is initiated automatically immediately after a severe accident. The automatic emergency call is not affected by the button being pressed.

### Roadside Assistance\*

Press button 2 for at least 2 seconds.

With the BMW Assist activated, the current position of your vehicle will be transmitted in the specific country.

When your battery is discharged, you can use two jumper cables to start your vehicle with power from the battery in a second vehicle. You can also use the same method to help start another vehicle. Use only jumper cables with fully-insulated clamp handles.

**⚠** To avoid the risk of potentially fatal injury, always avoid all contact with electrical components while the engine is running. Carefully observe the following instructions to avoid personal injury and/or damage to one or both vehicles.◀


## Preparing

1. Check whether the battery of the other vehicle has a voltage of 12 Volts and approximately the same capacitance in Ah. This information can be found on the battery.
2. Switch off the engine of the support vehicle.
3. Switch off any electrical systems and components in both vehicles.

**⚠** Ensure that no contact exists between the bodywork on the two vehicles, otherwise there is a danger of short circuits.◀

## Connecting jumper cables

**⚠** To avoid personal injury from sparks, always follow this sequence when connecting jumper cables.◀



On your BMW the so-called jump-start connection point in the engine compartment acts as the battery positive terminal, also refer to the engine compartment overview on page [151](#). The cover cap is marked with +.

1. Fold up the cap of the BMW jump-start connection point, refer to arrow.
2. Attach one end of the positive/+ jumper cable to the positive terminal of the battery or a jump-start connection point of the vehicle providing assistance.
3. Connect the second terminal clamp of the positive/+ jumper cable to the positive terminal of the battery or a jump-start connection point of the vehicle to be started.



Your BMW is equipped with a special nut on the left side panel as a body ground or negative terminal, refer to arrow in illustration.

4. Attach one end of the negative/- jumper cable to the negative terminal of the battery or to an engine or body ground of the vehicle providing assistance.
5. Connect the second terminal clamp of the negative/- jumper cable to the negative terminal of the battery or to the engine or body ground of the vehicle to be started.

## Starting engine

1. Start the engine on the support vehicle and allow it to run for several minutes at a fast idle.
2. Start the engine on the other vehicle in the usual way.  
If the first start attempt is not successful, wait a few minutes before another attempt in order to allow the discharged battery to recharge.
3. Let the engines run for a few minutes.
4. Disconnect the jumper cables by reversing the connection sequence.


Depending on the cause of the malfunction, have the battery recharged by your BMW Sports Activity Vehicle center.

 Never use spray fluids to start the engine.◀

## Using tow fitting

The screw-in tow fitting is stored beneath the cargo floor cover. Carry it with you at all times. It can be screwed in at the front or rear of the vehicle.


 Only use the tow fitting that comes with the vehicle and screw it in as far as it will go. Use the tow fitting for towing only on the roadway. Avoid lateral loading of the tow fitting, e.g. do not lift the vehicle by the tow fitting. Otherwise damage to the tow fitting and the vehicle can occur.◀



### Access to screw thread

Rear:

Use a screwdriver to press the right or left cover out, refer to arrows.



### Being towed

**⚠** Make sure that the ignition key is in position 1, otherwise the steering lock could engage and it would not be possible to steer the vehicle. When the engine is stopped, there is no power assist. This requires increased braking and steering effort.◀

Switch on the hazard warning flashers depending on the local regulations. If the electrical system fails, mark the vehicle to be towed, e.g. with a sign or warning triangle in the rear window.

**⚠** Do not exceed a towing speed of 30 mph/50 km/h and a towing distance of 95 miles/150 km, otherwise the automatic transmission may be damaged.◀

Manual transmission:  
Gearshift lever in idle position  
Automatic transmission:  
Selector lever in N.

### Towing methods

In some countries, towing with a tow bar or rope on public roads is not permitted.

Familiarize yourself with all regulations on towing in the respective country.

With tow bar:

**⚠** The towing vehicle may not be lighter than the vehicle to be towed, otherwise handling will be uncontrollable.◀

The tow fitting of both vehicles should be on the same side. If an angled position of the bar cannot be avoided, be aware of the following:

## Tow-starting and towing


- ▷ The freedom of movement is restricted during cornering
- ▷ The angled position of the tow bar creates lateral forces.

**⚠** Only attach the tow bar to the tow fittings, as attachment to other vehicle parts can lead to damage.◀

With tow-rope:

When starting off in the towing vehicle, make sure that the tow-rope is taut.

**⚠** Use nylon ropes or nylon straps for towing, and avoid all excessively sudden jerking movements. Only attach tow ropes to the tow fittings, as attachment to other vehicle parts can lead to damage.◀



With tow truck:

**⚠** Do not tow the X5 with the front or rear axle raised individually, otherwise the wheels may lock and the transfer case may be damaged.◀

The X5 may only be transported on a flat bed.


### Tow-starting

**▶** Do not tow-start vehicles with an automatic transmission.  
For information on jump starting, refer to page 174.◀

Only tow-start vehicles with a catalytic converter with the engine cold. It is better to jump start the engine, refer to page 174.

1. Switch on the hazard warning flashers and observe local regulations.
2. Turn the ignition key to position 2.
3. Shift into 3rd gear.
4. Tow-start with the clutch completely depressed and slowly release the clutch. After the engine starts, immediately depress the clutch again completely.
5. Stop at a suitable location, remove the tow bar or rope and switch off the hazard warning flashers.
6. Have the vehicle checked.

**▶** Do not activate the HDC Hill Descent Control during tow-starting, refer to page 94.◀



## Overview


Controls and features

Operation, maintenance

Owner service procedures

Technical data


Index



## 180 Engine specifications

		X5 3.0i	X5 4.4i	X5 4.8is
Displacement	cu in/cm <sup>3</sup>	181.8/2,979	268.4/4,398	292.9/4,799
Number of cylinders		6	8	8
Maximum output at engine speed	hp rpm	225 5,900	315 5,400	355 6,200
Maximum torque at engine speed	lb ft/Nm rpm	214/290 3,500	324/440 3,600	369/500 3,500

An engine performance test is authorized only on an appropriate chassis dynamometer.



All dimensions are given in inches/mm. Height: with self-leveling suspension 67.2/1,707; without self-leveling suspension 67.5/1,715; X5 4.8is 66.4-67.8/1,668-1,723. Height with roof-mounted luggage rack: with self-leveling suspension 68.5/1,740; without self-leveling suspension 68.9/1,750. Track width: X5 3.0i 62.0/1,576; X5 4.8is front 61.7/1,566, rear 62.8/1,596. Min. turning circle dia.: 39.7 ft/12.1 meters.

		X5 3.0i	X5 4.4i	X5 4.8is
Curb weight				
with manual transmission	lbs./kg	4,652/2,110	–	–
with automatic transmission	lbs./kg	4,696/2,130	4,927/2,235	5,016/2,275
Approved gross vehicle weight				
with manual transmission	lbs./kg	6,008/2,725	–	–
with automatic transmission	lbs./kg	6,008/2,725	6,008/2,725	6,008/2,725
Load				
with manual transmission	lbs./kg	1,356/615	–	–
with automatic transmission	lbs./kg	1,312/595	1,080/490	992/450
Approved front axle load	lbs./kg	2,712/1,230	2,789/1,265	2,789/1,265
Approved rear axle load	lbs./kg	3,307/1,500	3,307/1,500	3,307/1,500
Approved roof load capacity	lbs./kg		220/100	
Never exceed either the approved axle loads or the gross vehicle weight.				
Cargo area capacity	cu ft/l		16.4/465, according to DIN 69.01/1,955, according to SAE	

			Notes
Fuel tank including a reserve of: X5 3.0i X5 4.4i, 4.8is	gal./liters gal./liters gal./liters	approx. 24.6/approx. 93 approx. 2.1/approx. 8 approx. 2.6/approx. 10	Fuel specification: page 26
Windshield washer system with headlamp washer system	quarts/liters	approx. 8.2/approx. 7.8	For details: page 152
Engine with oil filter change X5 3.0i X5 4.4i, 4.8is	quarts/liters quarts/liters	8.0/7.5 8.5/8.0	BMW High Performance Synthetic Oil. For details: page 153

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z



Overview

Controls and features

Operation, maintenance

Owner service procedures

Technical data

Index

# Everything from A to Z

## A

Ability to climb, refer to  
Driving on poor roads [138](#)

ABS Antilock Brake  
System [91](#)  
warning lamp [20](#)

Accessories, refer to For  
your own safety [9](#)

Accident, refer to  
Emergency call [173](#)  
Roadside Assistance [173](#)

Activated-charcoal filter [112](#)

Adaptive Head Light [101](#)

Adjusting cooling capacity of  
rear climate control [112](#)

Adjusting seats [44](#)  
electric [46](#)  
electric comfort seat [46](#)  
mechanical [45](#)  
mechanical sports seat [45](#)

Air, drying, refer to Air  
conditioning [105, 110](#)

Airbags [55](#)  
sitting safely [43](#)  
warning lamp [21](#)

Air circulation, refer to  
Recirculated-air mode [105](#)

Air conditioner [104](#)

Air conditioning  
air conditioner [105](#)  
automatic climate  
control [110](#)

## Air distribution

air conditioner [105](#)  
automatic climate  
control [109](#)  
individual [109](#)

Airing, refer to  
Ventilation [106, 111](#)

Air outlets, refer to  
Ventilation [106, 111](#)

Air pressure, refer to Tire  
inflation pressure [141](#)

Air recirculation, refer to  
AUC Automatic recircu-  
lated-air control [110](#)

Air supply  
air conditioner [105](#)  
automatic climate  
control [109](#)  
rear climate control [112](#)

Air vents, refer to  
Ventilation [104, 107](#)

Alarm system [38](#)  
avoiding unintentional  
alarms [39](#)

All-season tires, refer to  
Special features of winter  
tires [149](#)

All-wheel drive, refer to  
xDrive [94](#)

Antenna, refer to Caring for  
your vehicle brochure

## Antifreeze

coolant [154](#)  
washer fluid [152](#)

Antilock Brake System  
ABS [91](#)  
warning lamp [20](#)

Anti-theft alarm system, refer  
to Alarm system [38](#)

Anti-theft system [30](#)

Anti-trapping  
mechanism [40, 42](#)  
panorama glass roof [42](#)  
power windows [40](#)

Armrest, refer to Storage  
compartments [119](#)

Artificial leather, refer to  
Caring for your vehicle  
brochure

Artificial wood trim, refer to  
Caring for your vehicle  
brochure

Ashtray [121](#)  
front [121](#)  
rear [121](#)

AUC Automatic recirculated-  
air control [110](#)

## Automatic

air distribution [109](#)  
air supply [109](#)  
cruise control [71](#)  
headlamp control [100](#)

recirculated-air control  
AUC [110](#)  
steering wheel  
adjustment [53](#)

Automatic car wash, refer to  
Caring for your vehicle  
brochure

Automatic climate  
control [107](#)

Automatic cruise control [71](#)

Automatic curb monitor [51](#)

Automatic headlamp  
control [100](#)

Automatic rear window  
washer [71](#)

Automatic Soft Close  
function, liftgate [36](#)

Automatic speed reduction  
for descents, refer to HDC  
Hill Descent Control [94](#)

Automatic transmission with  
Steptronic 65  
interlock 62  
selector lever interlock 66  
shiftlock 66  
towing 176  
tow-starting 176  
warning lamp 20, 21  
AUTO program, refer to  
Automatic air distribution  
and supply 109  
Average fuel  
consumption 80, 87  
Average speed 80, 88  
Avoiding alarms 39  
Axe loads, refer to  
Weights 182

## B

Backrest contour, refer to  
Lumbar support 46  
Backrests, refer to Adjusting  
seats 45, 46  
Backup lamps 65  
replacing bulbs 163  
Bandages, refer to First-aid  
kit 24  
Bar, towing 176

Battery 171  
disposal 171  
indicator lamp 19  
jump starting 174  
power failure 171  
remote control 30  
Belts, refer to Safety belts 49  
Beverage can holders, refer  
to Cup holders 120  
Beverage holder, refer to  
Cup holders 120  
Blower  
air conditioner 105  
automatic climate  
control 109  
refer to Air supply 105, 109  
BMW High Performance  
Synthetic Oil 153  
BMW Maintenance  
System 156  
Bottle holder, refer to Cup  
holders 120  
Brake fluid 155  
adding 155  
level 155  
replacing 155  
warning lamp 19  
Brake force display 98  
Brake hydraulic system 140  
warning lamp 19, 20  
Brake lamps, replacing  
bulbs 163

Brake lights, refer to Brake  
lamps 163  
Brake pads 140  
breaking-in 136  
warning lamp 19, 21  
Brake rotors  
brake system 140  
breaking-in 136  
Brakes 140  
ABS 91  
brake fluid 155  
brake pads 140  
breaking-in 136  
handbrake 64  
indicator/warning  
lamp 19, 20  
Brake system  
brake fluid 155  
brake fluid level 140, 155  
brake pads 140  
breaking-in 136  
disk brakes 140  
warning lamp 19  
Brake wear warning  
warning lamp 19, 21  
Breakdown, Flat Tire  
Monitor 98  
Breakdown assistance,  
refer to Roadside  
Assistance 173  
Breaking-in 136

Break wear warning, refer to  
Brake pads 140  
Buttons on steering wheel 23

## C

California Proposition  
65 Warning 9  
Calling, refer to telephone  
Owner's Manual  
Can holders, refer to Cup  
holders 120  
Capacities 183  
Car care, refer to Caring for  
your vehicle brochure  
Car-care products, refer to  
Caring for your vehicle  
brochure  
Care, refer to Caring for your  
vehicle brochure  
Care of paintwork, refer to  
Caring for your vehicle  
brochure

# Everything from A to Z

- Cargo area 124  
capacity 182  
cover, refer to Roll-up cover 125  
emergency operation, refer to Unlocking manually 35, 36  
enlarging 124  
floor cover 127  
lamps 103  
lid, refer to Liftgate/tailgate 35, 36  
opening, remote control 31  
opening/closing, refer to Liftgate 35  
opening/closing, refer to Tailgate 36  
opening from inside 35  
opening from outside 35  
Cargo-area partition net 125  
Cargo bay, refer to Cargo area 124  
Cargo floor, pull-out 128  
Cargo loading 130  
Caring for leather, refer to Caring for your vehicle brochure  
Caring for the carpet, refer to Caring for your vehicle brochure  
Car keys, refer to Keys 30
- Car phone, refer to separate Owner's Manual  
Car phone provision 116  
Car radio, refer to Owner's Manual for Radio/Onboard Computer  
Car wash, refer to Caring for your vehicle brochure  
Cassette operation, refer to Owner's Manual for Radio/Onboard Computer  
CD changer, refer to Owner's Manual for Radio/Onboard Computer  
CD operation, refer to Owner's Manual for Radio/Onboard Computer  
Center armrest, refer to Storage compartments 119  
Center brake lamp, replacing bulbs 164  
Central locking system 30 interior 34  
Changes, technical, refer to For your own safety 9  
Changing a wheel 165  
Changing gears with automatic transmission with Steptronic 66  
Changing tires 145
- Changing wheels compact wheel 167  
spare wheel 167  
Charge-current indicator lamp 19  
Charging battery 171  
CHECK button 77  
Check Control 77  
Child's seat, refer to Child-restraint systems 57  
Child-restraint fixing system LATCH 59  
Child-restraint systems 57  
Child-safety locks 60  
Chocks 166  
Chrome parts, care, refer to Caring for your vehicle brochure  
Cigarette lighter 121, 122  
Cigarette lighter socket, refer to Socket 121  
Circulation of air, refer to Recirculated-air mode 105, 110  
Cleaning, vehicle, refer to Caring for your vehicle brochure  
Cleaning rear window 71  
Climate control in the rear passenger area 111
- Clock 82  
12 or 24-hour mode 82  
hour signal 83  
setting 82  
setting, also refer to Owner's Manual for Radio/Onboard Computer  
setting time and date 82
- Closing from inside 34  
from outside 31  
Clothes hooks 120  
Clutch 136  
breaking-in 136  
Cockpit 14  
Code activating 88  
deactivating 89  
establishing 88
- Cold starting, refer to Starting engine 63  
Combination of wheels/tires 148  
Comfort seat 46  
Comfort starting, refer to Starting engine 63  
Compact Disc operation, refer to Owner's Manual for Radio/Onboard Computer  
Compact wheel, changing wheels 167

Compartments, refer to Storage compartments <a href="#">119</a>	Coolant <a href="#">154</a> level <a href="#">154</a> temperature gauge <a href="#">76</a> warning lamp <a href="#">76</a>	Cylinders, refer to Engine data <a href="#">180</a>	Defrosting windows and removing condensation air conditioner <a href="#">106</a> automatic climate control <a href="#">109</a>
Compass interior rearview mirror <a href="#">117</a>	Coolant temperature <a href="#">76</a>	<b>D</b>	Defrost position, refer to Defrosting windows <a href="#">106, 109</a>
Computer <a href="#">79, 85</a> also refer to Owner's Manual for Onboard Computer	Coolant temperature gauge <a href="#">76</a>	Dashboard, refer to Cockpit <a href="#">14</a>	Digital clock <a href="#">82</a> also refer to Owner's Manual for Onboard Computer
Condensation, refer to Air conditioning <a href="#">105, 110</a>	Cooling, maximum <a href="#">110</a>	Dashboard lighting, refer to Instrument lighting <a href="#">102</a>	Digital compass <a href="#">117</a>
Connecting vacuum cleaner, refer to Sockets <a href="#">121, 128</a>	Cooling, refer to Air conditioning <a href="#">105, 110</a> Temperature <a href="#">105, 109</a>	Data, technical <a href="#">180</a> dimensions <a href="#">181</a> engine <a href="#">180</a> filling capacities <a href="#">183</a> weights <a href="#">182</a>	Dimensions <a href="#">181</a>
Consumption, refer to Average fuel consumption <a href="#">80</a> Fuel consumption <a href="#">87</a>	Copyright <a href="#">4</a>	Date also refer to Owner's Manual for Onboard Computer changing <a href="#">82</a> displaying <a href="#">82</a>	Dimming feature, interior mirror <a href="#">138</a>
Consumption display, refer to Energy control <a href="#">74</a>	Cornering light, refer to Adaptive Head Light <a href="#">101</a>	Daytime driving lamps <a href="#">100</a>	Dipstick, engine oil <a href="#">152</a>
Consumption indicator, refer to Fuel gauge <a href="#">75</a>	Correct tires wheel/tire replacement <a href="#">148</a> winter tires <a href="#">149</a>	DBC Dynamic Brake Control <a href="#">91</a> indicator lamp <a href="#">21</a>	Directional indicators, refer to Turn signals <a href="#">68</a>
Contents <a href="#">4</a>	Courtesy illumination, refer to Courtesy lighting <a href="#">103</a>	Deactivating the alarm in an emergency <a href="#">89</a>	Disk brakes <a href="#">140</a>
Controls, refer to Cockpit <a href="#">14</a>	Courtesy lighting <a href="#">103</a>	Defective lamp <a href="#">161</a>	Displacement, refer to Engine specifications <a href="#">180</a>
Convenience opening mode panorama glass roof <a href="#">31</a> windows <a href="#">31</a>	Cruise control <a href="#">71</a> buttons on steering wheel <a href="#">23</a> indicator lamp <a href="#">22</a>	Defrosting windows <a href="#">106, 109</a> air conditioner <a href="#">106</a> automatic climate control <a href="#">109</a>	Display, refer to Instrument cluster <a href="#">15, 17, 18</a>
Convenience operation from outside <a href="#">33</a> panorama glass roof <a href="#">33</a> windows <a href="#">33</a>	Cruising range <a href="#">80, 87</a>	Display lighting, refer to Instrument lighting <a href="#">102</a>	Display lighting, refer to Instrument lighting <a href="#">102</a>
	Cup holders <a href="#">120</a>	Disposal, vehicle battery <a href="#">171</a>	Distance to destination <a href="#">86</a>
	Curb weight, refer to Weights <a href="#">182</a>	Distance warning, refer to PDC Park Distance Control <a href="#">90</a>	
	Current consumption, refer to Energy control <a href="#">74</a>		

# Everything from A to Z

Divided rear seat backrest,  
refer to Folding rear seat  
back **124**

Door keys **30**

Door lock **33**

DOT Quality Grades **145**

Draft-free  
ventilation **106, 111**

Driving lamps, refer to  
Parking lamps/low  
beams **100**

Driving notes  
breaking-in **136**  
driving hints **137, 138**  
Driving on poor roads **138**  
Driving stability control **92**  
Driving tips, refer to Driving  
notes **137**

Driving your X5 **138**

Dry air, refer to Air  
conditioning **105, 110**

DSC Dynamic Stability  
Control **92**  
warning lamp **22**

DVD changer, refer to  
Owner's Manual for Radio/  
Onboard Computer

Dynamic Brake Control  
DBC **91**

indicator lamp **21**

Dynamic Stability Control  
DSC **92**  
warning lamp **22**

## E

EBV Electronic brake-force  
distribution **91**

Electrical defect  
liftgate **35**  
tailgate **36**

Electrical malfunction  
automatic transmission  
with Steptronic **67**

door lock **33**  
driver's door **33**  
fuel filler door **24**  
panorama glass roof **42**

Electric steering wheel  
adjustment **52**

Electronic brake-force distri-  
bution EBV **91**

Electronic Stability Program  
ESP, refer to DSC Dynamic  
Stability Control **92**

Emergency call **173**

Emergency operation, refer  
to Manual operation  
driver's door **33**

fuel filler door **24**  
liftgate **35**  
panorama glass roof **42**  
tailgate **36**

Emergency Service, refer to  
Roadside Assistance **173**

Energy-conscious driving,  
refer to Energy control **74**

Energy control **74**

Engine  
breaking-in **136**  
data **180**  
electronic circuitry **22**  
overheated, refer to  
Coolant temperature  
gauge **76**  
speed **74**  
starting **62**  
switching off **63**

Engine compartment **151**

Engine coolant **154**

Engine oil **152**  
additives, refer to  
Specified engine oils **153**  
filling capacity **183**  
indicator/warning lamp **19**  
specified engine oils **153**

Engine oil level **152**  
indicator/warning lamp **21**

Engine oil pressure,  
indicator/warning lamp **19**

Engine oil temperature  
gauge **75**

Engine output, refer to  
Engine specifications **180**

Engine overheating, refer to  
Coolant temperature  
gauge **76**

Engine specifications **180**

Engine speed, refer to  
Engine specifications **180**

Environmentally friendly  
driving, refer to Energy  
control **74**

ESP Electronic Stability  
Program, refer to DSC  
Dynamic Stability  
Control **92**

Event Data Recorders **157**

Exhaust system **137**

Extended immobilizer  
function **88**

Exterior mirrors **53**  
automatic dimming  
feature **138**  
folding in and out **54**

External air, automatic  
climate control **110**

## F

Failure messages, refer to  
Check Control **77**

Failure of a current  
consumer **172**

False alarms, refer to  
Avoiding unintentional  
alarms **39**

Fastening seat belts  
refer to Safety belts 49

Fasten safety belts  
warning lamp 21, 49

Fault displays, refer to Check Control 77

Filter, refer to  
Microfilter 106

Microfilter/activated-charcoal filter 112

First aid, refer to First-aid kit 24

First-aid kit 24

Flashlight 119

Flat, compact wheel 167

Flat tire 165  
compact wheel 167

Flat Tire Monitor 98  
refer to Changing a wheel 165  
refer to Tire inflation pressure 141  
spare wheel 167

Flat Tire Monitor 98  
false alarms 98  
initializing system 99  
limits of system 98  
show chains 149  
warning lamp 99

Flooding, refer to Driving through water 138

Floor mats, refer to Caring for your vehicle brochure

Fluid level, indicator lamp 21

Fog lamps, indicator lamp 22

Folding floor cover up 128

Folding rear backrest 124

Folding rear seat back 124

Footbrake, refer to General driving notes 137

Footwell lamps 103

For information on breaking in the differential, refer to Engine and differential 136

Four-wheel drive system, refer to xDrive 94

Front airbags 55

Front fog lamps 102  
replacing bulbs 163

Fuel  
average  
consumption 80, 87  
display 75  
quality 26  
volume, refer to Capacities 183

Fuel display, refer to Fuel gauge 75

Fuel filler door 24  
manual operation 24

Fuel gauge 75

Fuel-saving driving, refer to Energy control 74

Fuel tank capacity, refer to Capacities 183

Full preparation package mobile phone, refer to separate Owner's Manual

Fuses 172

## G

Garage-door opener, refer to Integrated universal remote control 114

Gasoline, refer to Fuel quality 26

Gasoline display, refer to Fuel gauge 75

Gear display 65

Gearshift lever, manual transmission 64

General driving notes 137

Glove box, refer to Glove compartment 119

Glove compartment 119

Grills, refer to Ventilation 106, 111

Gross weight, refer to Weights 182

Ground clearance 139

## H

Handbrake 64  
indicator lamp 19, 21

Hand lamp, refer to Rechargeable flashlight 119

Hands-free microphone, refer to Telephone 116

Hands-free system 116  
refer to Microphone 116

Hazard warning flashers 14

HDC Hill Descent Control 94

Head airbags 55

Headlamp control, automatic 100

Headlamp cover, care, refer to Caring for your vehicle brochure

Headlamp flasher 68  
indicator lamp 22

Headlamps  
care, refer to Caring for your vehicle brochure  
replacing bulbs 161

Headlamp washer reservoir 152  
volume, refer to Filling capacities 183

Headlamp washer system headlamp washing 70  
washer fluid 152

# Everything from A to Z

- Head restraints 47  
adjusting 47  
installing in front 48  
removing and installing in rear 48  
removing in front 48  
sitting safely 43  
Heated mirrors 54  
Heated rear window  
air conditioner 105  
automatic climate control 110  
Heated seats 52  
Heated steering wheel 53  
Heater  
rear window 105, 110  
steering wheel 53  
Heating  
exterior mirror 54  
residual heat utilization 110  
seats 52  
Heating and ventilation 104, 107  
Heating while stationary 110  
Heavy cargo, refer to Cargo loading 131  
Heavy-duty cargo straps, refer to Cargo loading 131  
Height, refer to Dimensions 181
- Height adjustment  
seats 45, 46  
steering wheel 52  
High beams 101  
headlamp flasher 68  
indicator lamp 22  
replacing bulbs 162  
High temperatures 137  
Hill Descent Control HDC 94  
Hills 138, 140  
Holder for cups 120  
Hood 150  
Horn 14  
Hotel function 30  
Hot exhaust system 137  
Hydraulic brake assistant, refer to DBC 91  
Hydraulic system, brakes 19  
Hydroplaning 137, 147
- I**
- Ice, refer to Outside temperature warning 73  
Identification, tire 145  
Ignition 62  
Ignition key 30  
Ignition key positions, refer to Ignition lock 62  
Ignition lock 62  
Immobilizer function 88  
Imprint 4
- Independent ventilation, refer to Parked car ventilation 113  
Indicating elements 15, 17, 18  
Indicator/warning lamp  
airbags 57  
alarm system 38  
automatic transmission with Steptronic 67  
brakes 155  
coolant temperature 76  
DSC 92  
engine temperature 76  
fasten safety belts 49  
Flat Tire Monitor 99  
front fog lamps 102  
reserve 75  
self-leveling suspension 95  
Indicator and warning lamps, overview 19  
Indicator lighting, refer to Instrument lighting 102  
Individual air distribution 109  
Individual settings, refer to Vehicle Memory, Key Memory 61  
Inflation pressure, tires, refer to Tire inflation pressure 141
- Initializing, refer to Power loss 42  
**INSPECTION 76**  
Instrument cluster 15, 17, 18  
refer to Cockpit 14  
Instrument lighting 102  
Instrument panel 14  
Integrated universal remote control 114  
Interface socket for Onboard Diagnostics 157  
Interior lamps 103  
remote control 31  
Interior mirror, automatic dimming feature 138  
Interior motion sensor 39  
switching off 31, 39  
Interior rearview mirror 54  
compass 117  
Interlock, refer to Steering lock engaged 62  
Intermittent operation of wipers 69, 71  
Interval Display, Service 76
- J**
- Jacking points for vehicle jack 170  
Jumpering, refer to Jump starting 174  
Jump starting 174

K	Light-alloy wheels, care, refer to Caring for your vehicle brochure	L	Low-fuel indicator lamp, refer to Fuel gauge 75	M	Malfunction automatic transmission with Steptronic 67
Key Memory 61	Keys 30 key-related settings, refer to Vehicle Memory, Key Memory 61	Light-emitting diodes LEDs 165	Lug bolts 169 torque 170	door lock 33	fuel filler door 24
Keys 30 key-related settings, refer to Vehicle Memory, Key Memory 61	Lighter 121, 122	Lighting of instruments 102	Luggage compartment capacity 182 opening from inside 35	liftgate 35	panorama glass roof 42
Kick-down 66	Lights on warning 100	Lights on warning 100	Luggage compartment, refer to Cargo area 124	tailgate 36	tailgate 36
L	Light switch 100	Limit 85	Luggage compartment cover, refer to Roll-up cover 125	Manual operation	door lock 33
Lamps, refer to Parking lamps/low beams 100	Limit speed, refer to Speed limit 85	Load, refer to Cargo loading 130	Luggage compartment lamps, refer to Cargo area lamps 103	driver's door 33	fuel filler door 24
Lamps and bulbs 161	Loading, securing load 131	Lock buttons, doors, refer to Locking 34	Luggage compartment lid refer to Liftgate 35 refer to Tailgate 36	liftgate 35	panorama glass roof 42
Lashing eyes, refer to Securing load 131	Locking	Locking, vehicle from inside 34 from outside 31	Luggage net, refer to Partition net 125	tailgate 36	tailgate 36
LATCH child-restraint fixing system 59	Locking, vehicle from inside 34 from outside 31	Locking and unlocking doors from inside 34 from outside 31	Luggage rack, refer to Roof-mounted luggage rack 132	Manual transmission 64	
Length, refer to Dimensions 181	Locking and unlocking doors from inside 34 from outside 31	Low beams 100 automatic 100 replacing bulbs 161	Luggage straps 37	Master key 30 with remote control 30	
License plate lamp, replacing bulbs 164	Lower back support, refer to Lumbar support 46	Lumbar support 46	Lumbar support 46	Maximum cooling 110	
Liftgate 35 emergency operation, refer to Unlocking manually 35 opening, remote control 31	M	M+S tires, refer to Winter tires 149	M	Maximum roof weight 182	
Liftgate/tailgate opening from inside 35 opening from the outside 35 unlocking manually 35, 36	M+	Maintenance, refer to Service Interval Display 76	M+	Maximum speed with winter tires 149	
	Maintenance	Maintenance system 156	Maintenance	Measurements, refer to Dimensions 181	
	system		Mechanical key, refer to Door and ignition key 30	Mechanical seats 45	
			Memo 83		

# Everything from A to Z

Memory, refer to  
Seat, mirror and steering wheel memory 50  
Vehicle Memory, Key Memory 61  
Microfilter  
air conditioner 106  
automatic climate control 112  
Microphone for telephone, refer to Car phone 116  
MID Multi-Information Display  
displays and controls 81  
information display 81  
Mirror dimming feature 138  
Mirrors 53  
automatic curb monitor 51  
mirror heating 54  
mirror memory, refer to Seat, mirror and steering wheel memory 50  
Mobile communications devices in vehicle 137  
Mobile phone, refer to separate Owner's Manual  
Monitoring pressure of tires, refer to Flat Tire Monitor 98  
Multi-function steering wheel, refer to Buttons on steering wheel 23

Multifunction switch  
turn signals/headlamp flasher 68  
washer/wiper system 69  
Multi-Information Display MID 81  
**N**  
Navigation system, refer to separate Owner's Manual  
Neck support, refer to Head restraints 47  
Nozzles, refer to Ventilation 106, 111  
Nylon rope, refer to Tow-starting and towing 177  
**O**  
OBD interface socket 157  
Odometer 73  
Oil  
additives, refer to Specified engine oils 153  
consumption 152  
consumption, refer to Engine oil, checking 152  
dipstick 152  
filling capacity 183  
level 152  
refilling, refer to Engine oil, adding 153  
specified engine oils 153

Oil change interval, refer to Service and Warranty Information Booklet, US models or Warranty and Service Guide Booklet, Canadian models  
Oil consumption 152  
Oil level 152  
checking 152  
Oil pressure, indicator/ warning lamp 19  
OILSERVICE 76  
Oil temperature 75  
Old batteries, refer to Disposal 171  
Onboard tool kit 160  
Opening and closing  
from inside 34  
from outside 31  
using the door lock 33  
using the remote control 31  
Output, refer to Engine specifications 180  
Outside air, air conditioner 105  
Outside temperature display 73  
changing unit of measure 73, 80  
on onboard computer 80

**P**  
Package shelf, refer to Roll-up cover 125  
Panorama glass roof 41  
automatic opening and closing 41  
closing in the event of an electrical malfunction 42  
comfort operation 33  
comfort position 42  
initializing 42  
power failure 42  
remote control 31  
Park Distance Control PDC 90  
Parked car ventilation 113  
activating/deactivating switch-on times 84  
also refer to Owner's Manual for Onboard Computer  
entering switch-on times 84  
switching on and off directly 84  
Parking, vehicle 63  
Parking aid, refer to PDC Park Distance Control 90  
Parking assistant, refer to PDC Park Distance Control 90

Parking brake, refer to Handbrake 64  
Parking lamps 100  
    replacing bulbs 162  
Parking lamps/low beams 100  
Parts and accessories, refer to For your own safety 9  
Passenger-side mirror tilt function 51  
Pathway lighting 100  
PDC Park Distance Control 90  
Permissible axle load, refer to Weights 182  
Permissible gross weight, refer to Weights 182  
Plastic, care, refer to Caring for your vehicle brochure  
Pollen, refer to Microfilter 106  
    Microfilter/activated-charcoal filter 112  
Power electric seat 46  
Power failure 171  
Power rear seat backrest 48  
Power windows 39  
    safety switch 40  
Pressure, tires 141  
Pressure monitoring, tires 98  
    Flat Tire Monitor 98

Programming settings, refer to Vehicle Memory, Key Memory 61  
Protective function, panorama glass roof 42  
Pull-out cargo floor 128  
**R**  
Radio, refer to Owner's Manual for Radio/Onboard Computer  
Radio-control key, refer to Master key with remote control 30  
Radio navigation, refer to separate Owner's Manual  
Rain sensor 69  
Reading lamps  
    front 103  
    rear 103  
Real wood, refer to Caring for your vehicle brochure  
Rear backrests, power 48  
Rear climate control 111  
    air supply 112  
    temperature 112  
Rear lamps  
    refer to Tail lamps 163  
    replacing bulbs 163  
Rear seat back, folding 124

Rear seat backrest, electric 48  
Rear-seat backrest, folding down 124  
Rear seats, heating 52  
Rearview mirror 53  
Rear window blinds, refer to Roller sun blinds 113  
Rear window defroster  
    air conditioner 105  
    automatic climate control 110  
Rear window safety switch 40  
Rear window wiper 71  
    replacing bulbs 160  
Rechargeable flashlight 119  
Recirculated-air mode  
    air conditioner 105  
    automatic climate control 110  
Reflectors, refer to Tail lamps 163  
Refueling 24  
    fuel filler door 24  
Remaining distance, refer to Cruising range 80, 87  
Remaining distance for service, refer to Service Interval Display 76

Remote control 31  
    garage door opener, refer to Integrated universal remote control 114  
liftgate 31  
malfunction 32  
Removal aid for spare wheel 168  
Removing condensation, windows  
    air conditioner 106  
    automatic climate control 109  
Replacement fuses 172  
Replacement keys 30  
Replacement tire 167  
Replacing bulbs, refer to Lamps and bulbs 161  
Replacing light bulbs 161  
Replacing tires  
    changing a wheel 165  
    tire replacement 145  
Reporting an accident, refer to Initiating an emergency call 173  
Reporting safety defects 11  
Residual heat 110  
Restraint systems, refer to Safety belts 49  
Restraint systems for children 57

# Everything from A to Z

- Reverse gear  
automatic transmission  
with Steptronic [66](#)  
manual transmission [65](#)
- Roadside Assistance [173](#)
- Roadside parking lamps [101](#)  
replacing bulbs [162](#)
- Roller blind for cargo area,  
refer to Roll-up cover [125](#)
- Roller sun blinds [113](#)
- Roll-up cover [125](#)
- Roof-mounted luggage  
rack [132](#)
- Rope, refer to Tow-starting  
and towing [177](#)
- Rotating coin holder, refer to  
Storage  
compartments [119](#)
- S**
- Safe braking [140](#)
- Safety belt height  
adjustment [49](#)
- Safety belts [49](#)  
adjusting belt height [49](#)  
care, refer to Caring for  
your vehicle brochure  
sitting safely [43](#)  
warning lamp [21, 49](#)
- Safety belt tensioners, refer  
to Safety belts [50](#)
- Safety defects [11](#)
- Safety feature, power  
windows [40](#)
- Safety systems, refer to  
Airbags [55](#)
- Antilock Brake System [91](#)
- Brake system [140](#)
- DSC Dynamic Stability  
Control [92](#)
- xDrive [94](#)
- Screw thread for tow  
fitting [176](#)
- Seat heating [52](#)
- Seat memory, refer to Seat,  
mirror and steering wheel  
memory [50](#)
- Seats [44](#)  
adjusting comfort seat [46](#)  
adjusting electrically [46](#)  
adjusting sports seat [45](#)  
heating [52](#)  
memory, refer to Seat,  
mirror and steering wheel  
memory [50](#)  
sitting safely [43](#)  
storing adjustment [50](#)
- Securing cargo, refer to  
Cargo loading [130](#)
- Securing load [131](#)
- Selector lever, automatic  
transmission with  
Steptronic [66](#)
- Selector lever interlock, refer  
to Changing selector lever  
positions [66](#)
- Selector lever positions,  
automatic transmission  
with Steptronic [65](#)
- Self-leveling suspension [95](#)  
2-axle self-leveling  
suspension [96](#)  
inactive [95](#)
- Service, refer to Roadside  
Assistance [173](#)
- Service and Warranty Infor-  
mation Booklet for US  
models [156](#)
- Service Interval  
Display [76, 156](#)
- Setting interior  
temperature [105, 109](#)
- Setting time, refer to Pre-  
selecting switch-on times [84](#)
- Shifting  
automatic transmission  
with Steptronic [66](#)  
manual transmission [64](#)
- Shiftlock [66](#)
- Shoulder support [47](#)
- Side airbags [55](#)
- Side Impact Head Protection  
System [55](#)
- Side tilt, permissible [138](#)
- Side turn signals, replacing  
bulbs [162](#)
- Side window blinds, refer to  
Roller sun blinds [113](#)
- Signal horn, refer to Horn [14](#)
- Signaling briefly [68](#)
- Sitting safely [43](#)  
with airbags [43](#)  
with head restraint [43](#)  
with safety belts [43](#)
- Ski bag [123](#)
- Sliding sunroof, refer to  
Panorama glass roof [41](#)
- Snow chains [149](#)
- Sockets [121](#)
- Sockets in cargo area [128](#)
- Soft closure aid for liftgate,  
refer to Automatic Soft  
Close function [36](#)
- Spare fuses [172](#)
- Spare key [30](#)
- Spare wheel [167](#)  
removal aid [168](#)
- Special wash program [70](#)
- Specified engine oils [153](#)
- Speed  
with compact wheel [170](#)  
with spare wheel [171](#)  
with winter tires [149](#)
- Speed limit [85](#)

- Speedometer 15, 17, 18  
refer to Instrument cluster 15, 17, 18
- Sport Program, automatic transmission with Steptronic 67
- Sports seat 45
- Stability control, refer to DSC Dynamic Stability Control 92
- xDrive 94
- Starting, refer to Starting engine 62
- Starting engine 62
- Starting problems at very low temperatures 63
- jump starting 174
- Status of this Owner's Manual at time of printing 9
- Steering lock 62
- Steering wheel adjustment 52
- buttons on steering wheel 23
- entry/exit aid 53
- heating 53
- lock 62
- memory 50
- Steering wheel adjustment, automatic 53
- Steering wheel heater 53
- Steering wheel memory 50
- Steering wheel with multi-function buttons 23
- Steptronic, refer to Manual operation 67
- Stopwatch 83
- Storage compartments 119
- Storage compartments in cargo area 127
- Storage space, refer to Cargo area 124
- Storing desired speed, refer to Cruise control 71
- Storing seat adjustment 50
- Storing sitting position, refer to Seat, mirror and steering wheel memory 50
- Storing tires 149
- Supply reservoir, washer systems 152
- Switches, refer to Cockpit 14
- Switching air conditioner mode on and off manually 105, 110
- Switching off engine 63
- Switching on hour signal 83
- Switch-on times, entering 84
- Symbols 8
- Synthetic oil 153
- T**
- Tachometer 74
- Tailgate 36
- emergency operation, refer to Unlocking manually 35, 36
- opening, remote control 31
- remote control 31
- unlocking manually 36
- Tail lamps, replacing bulbs 163
- Taking time, refer to Stopwatch 83
- Tank capacity, refer to Fuel tank capacity 183
- Technical data 180
- Technical modifications 9
- Telephone 116
- refer to separate Owner's Manual
- Telephone provisions, refer to Hands-free telephone operation 116
- Temperature air conditioner 105
- automatic climate control 109
- Temperature display interior temperature 109
- outside temperature 73, 80
- outside temperature warning 73
- setting the units 73, 80
- Temperature of coolant, refer to Coolant temperature gauge 76
- Temperature warning 73
- Tempomat, refer to Cruise control 71
- Thigh support adjustment 45
- Third brake lamp refer to Center brake lamp 164
- replacing bulbs 164
- Three-point belt 49
- Tightening torque of lug bolts 170
- Tilt alarm sensor 39
- remote control 31
- switching off 39
- Tilt function, passenger-side mirror 51
- Time of arrival 87
- Timer, refer to Stopwatch 83
- Tire Identification Number 145
- Tire inflation pressure 141
- producing 141
- Tire inflation pressure monitoring, refer to Flat Tire Monitor 98
- Tire Quality Grading 145

# Everything from A to Z

- Tires  
age 145  
breaking-in 136  
changing 148, 165  
condition 146  
damage 146  
DOT Quality Grades 145  
flat 165  
inflation pressure 141  
size 145  
storage 149  
traction 146  
tread 147  
tread wear 145  
Uniform Tire Quality Grading 145  
wear indicators, refer to  
Tire tread 147  
winter tires 149
- Tools, refer to Onboard tool kit 160
- Torque  
engine 180  
lug bolts 170
- Tow bar 176
- Tow fittings 175
- Towing the vehicle 175, 176  
with automatic transmission 176
- Tow-rope 177
- Tow sockets for tow fitting 176
- Tow-starting 175
- Track width, refer to Dimensions 181
- Traction 146
- Traction aid, refer to DSC Dynamic Stability Control 92
- Traction control, refer to DSC Dynamic Stability Control 92
- Transmission  
automatic transmission with Steptronic 65  
manual transmission 64
- Transmission lockout, refer to P Park 66
- Transmission malfunction, refer to Malfunction 67
- Transporting children safely 57
- Transport securing device, refer to Securing load 131
- Tread depth, refer to Tire tread 147
- Tread wear 145
- Trip-distance counter, refer to Trip odometer 73
- Trip odometer 73
- Trunk lamps, refer to Cargo area lamps 103
- Trunk lid, refer to  
Liftgate 35  
Tailgate 36
- Turning circle, refer to Dimensions 181
- Turn signals 68  
indicator lamp 22  
replacing bulbs 162, 163
- Turn signals, side, replacing bulbs 162
- TV function, refer to Owner's Manual for Onboard Computer
- TV set, refer to Owner's Manual for Onboard Computer
- Two-axle self-leveling suspension display 96  
lowering 97  
raising 97
- U**
- Underbody protection, refer to Caring for your vehicle brochure
- Uniform Tire Quality Grading 145
- Units,  
temperature 73, 80, 109
- Universal garage door control, refer to Integrated universal remote control 114
- Universal remote control 114
- Unlocking  
from inside 34  
from outside 31  
hood 150
- Using antifreeze 152, 154
- V**
- Vacuum cleaner, connecting, refer to Sockets 121, 128
- Valve  
inserts 170  
screw caps 170
- Vehicle  
battery 171  
breaking-in 136  
care, refer to Caring for your vehicle brochure  
cargo loading 130  
measurements, refer to Dimensions 181  
parking 63  
storage, refer to Caring for your vehicle brochure  
washing, refer to Caring for your vehicle brochure  
weight 182

Vehicle battery 171  
Vehicle jack 167  
  jacking points 170  
Vehicle Memory 61  
Ventilation 106, 111  
Ventilation in the rear 106  
Ventilation while parked 113  
Viscosity 154  
Voice command system 23  
Voice control, refer to  
  separate Owner's Manual  
Volume, cargo area 182

**W**

Warning and indicator  
  lamps 19  
Warnings, refer to Check  
  Control 77  
Warning triangle 24  
Warranty 10  
  refer also to Service and  
  Warranty Information  
Booklet for US models or  
  Warranty and Service  
  Guide Booklet for  
  Canadian models  
Warranty and Service Guide  
  Booklet for Canadian  
  models 156  
Washer fluid 152  
Washer fluid reservoir,  
  content 183

Washer jets, refer to  
  Windshield washer  
  nozzles 70  
Washer reservoir, refer to  
  Windshield and headlamp  
  washer system 152  
Waste container, refer to  
  Ashtray 121  
Water on roads, flooding 138  
Wear indicators in tires, refer  
  to Tire tread 147  
Weights 182  
Wheel/tire combinations 148  
Wheelbase, refer to  
  Dimensions 181  
Wheel bolts, wrench 166  
Wheel replacement 148  
Width, refer to  
  Dimensions 181  
Windows 39  
  convenience operation 33  
  defrosting, refer to  
  Defrosting  
  windows 106, 109  
  safety switch 40  
Windshield  
  defrosting, refer to  
  Defrosting  
  windshield 106, 109  
  washing 70

Windshield cleaner reservoir  
  volume, refer to Filling  
  capacities 183  
Windshield washer, washer  
  fluid 152  
Windshield washer fluid  
  reservoir 152  
Windshield washer  
  nozzles 70  
Windshield washer system,  
  washer/wiper system 69  
Windshield wiper blades  
  care, refer to Caring for  
  your vehicle brochure  
  replacement 160  
Windshield wipers, refer to  
  Wiper/washer system 69  
Winter tires 149  
  changing 149  
  condition 146  
  storage 149  
Wiper blade  
  replacement 160  
Wiper system 69  
Working in the engine  
  compartment 150  
Wrenches/screwdrivers,  
  refer to Onboard  
  toolkit 160

**X**  
xDrive 94  
Xenon lamps, replacing  
  bulbs 162

**Y**  
Your individual vehicle 8

# Refueling

BMW recommends 

So that you will have important specifications available when you stop to refuel, we recommend that you fill in this table with data which apply to your vehicle.

Consult the index for individual specifications.

## Fuel

Designation	
-------------	--

Please enter your preferred fuel here.

## Engine oil

Quality	
---------	--

The oil volume between the two marks on the oil dipstick corresponds to approx. 1.1 US quarts/1 liter.

## Tire inflation pressures

Tire inflation pressures	Summer tires		Winter tires	
	Front	Rear	Front	Rear
4 persons				
5 persons or 4 plus luggage				

More about BMW



[bmwusa.com](http://bmwusa.com)

The Ultimate  
Driving Machine

01410159867 ue

X5 US-EN