
Electronic Modular Switching System

P



For 7000 Series telephones

Model KX-T206E

7000 Series Telephone Features

Thank you for purchasing the Panasonic Model KX-T206E, Electronic Modular Switching System

	Model Number	Description
System Unit	KX-T206E	Electronic Modular Switching
		System
Telephones	KX-T7130E	Proprietary telephone with display
	KX-T7020E	Handsfree proprietary telephone
	KX-T7050E	Proprietary telephone
User Supplied Equipment	Single line telephones	

System Component

Notes • In this manual the suffix E of each model number is omitted

- A proprietary telephone is abbreviated as "PT"
- A single line telephone is abbreviated as "SLT"

APPROVED for connection to
telecommunication systems specified
in the instructions for use subject to th
conditions set out in them

Contents

MAKING CALLS	5
INTERCOM CALLING Outward Dialling System Speed Dialling One-Touch Dialling Doorphone	5 5 5 5
WHEN A LINE IS BUSY	6
LAST NUMBER REDIAL	6
RECEIVING CALLS	6
Answer Handsfree Answer-back Call Pickup	6
WHILE HAVING A CONVERSATION	7
Call Hold Call Hold Retrieve Call Transfer	7 7
WHILE HAVING A CONVERSATION (CONTD.)	8
Call Waiting Conference	
WHILE HAVING A CONVERSATION (CONTD.)	9
CALL SPLITTING	9
PAGING FEATURES	9
PAGING ALL EXTENSIONS PAGING ANSWER	9
OTHER FEATURES	10
CALL PICKUP DENY	0
OTHER FEATURES (CONTD.) 1	1
Do Not Disturb (DND)	1 1 1
OTHER FEATURES (CONTD.)	2
Auto Line Hunting 1 Intercom Alerting Mode 1 Pulse to tone conversion 1 Station Feature Clear 1	12 12
OTHER FEATURES (CONTD.) 1	
Time Setting (extension 21 only) 1 Date Setting (extension 21 only) 1 Flexible Night Service 1	13
STATION PROGRAMMING 1	4
FLEXIBLE BUTTON ASSIGNMENT	4

7000 Series Telephone Features


THE INDICATION OF STATUS	15
FEATURE NUMBER LIST	15
Flexible CO button Assignment	14
ONE-TOUCH DIALLING BUTTON ASSIGNMENT	14
DIRECT STATION SELECTION (DSS) BUTTON ASSIGNMENT	14


Making Calls

<NOTE>

Off-Hook: Lift the handset, or press the **SP-PHONE** button or **MONITOR** button. On-hook: Replace the handset, or press the **SP-PHONE** button or **MONITOR** button again


Intercom Calling





Outward Dialling

Allows you to make a call to an outside party




Line access code

- Automatic Line Access Code: 0 or 9 (depending on the system programming) See page 28 of the Installation Manual.
- Individual Line Access code:
- 81 (Line 1) or *" (Line 2)
- The elapsed time is displayed on the
- LCD of the KX-T7130E.


System Speed Dialling

Allows you to make outside calls using previously programmed speed dial numbers. This system supports forty speed dial numbers which are available to all extension users



One-Touch Dialling

Allows you to call a number or access a system feature with the touch of a button.



• For programming, see page13

Doorphone

Allows you to have a conversation with a visitor at your door





To unlock the door while talking to the doorphone:



• You can unlock the door for a preprogrammed time.

When a Line is Busy

Last Number Redial

Allows you to automatically re-dial the last outside number dialled.


Receiving Calls






Off-hook

Handsfree Answer-back



• The indicator light turns on when it is set and off when it is cancelled.

Call Pickup



While Having a Conversation

Call Hold

Allows you to place an intercom or outside call on hold.

To place a call on hold:

Press HOLD button

• Depending on the system programming you may need to dial 6 after pressing the recall button. For programming, see page 28 of the installation manual.

To retrieve a call on hold:

Press the CO or INTERCOM button which is flashing green

Call Hold Retrieve

Allows you to receive a call that has been placed on hold by another extension.

With a Line key:




Press CO button which is flashing red slowly

With a fe	ature nu	mber:
^c		I
Ä	5	
Off-hook	Dial 5	Dial line number

• You can dial the extension number (21 through 26) which held the call or the line number.

Call Transfer

Allows you to perform a screened or Unscreened call transfer to another



• For programming the hold recall time, see page 28 of the Installation Manual.


While Having a Conversation (contd.)

Call Waiting Conference During a conversation, a call waiting tone Allows you to add a third party to a twosignals that there is a call waiting. You can party conversation and make a three respond to the waiting call by party conference. You can have the disconnecting from the first call or by following combination of calls on the line: three extensions, two extensions and placing the first call on hold. one line, or one extension and two lines. To talk to the new party by terminating the current call: To establish a conference: П • The current party is paced on hold Press CONF button Press flashing CO button To talk to the new party holding the current call: Dial extension number Press CONF button after of the third party the third party answers н To leave the conference: Press HOLD button Press flashing CO button On-hook • The other two parties can continue their conversation provided they are not both lines. To hold one party and talk to the other: Π Press the desired CO or INTERCOM button

While Having a Conversation (contd.)

Call Splitting

Allows you to have two callers on a line and alternate between them. You can place the current call on hold and have a conversation with the other party.



Press Hold Dial the second button party and talk



Press HOLD button

Press CO or INTERCOM button of the first caller


• You can alternate between callers by pressing the HOLD button and then the desired CO or INTERCOM button.

Paging Features

The Paging features allow you to make a voice announcement to several persons at the same time. Your message is announced over the built-in speaker of proprietary telephones. The paged person can answer your page from a nearby telephone.


Paging All Extensions

Allows you to make a voice announcement to all extensions. Your message is announced over the built-in speaker of the proprietary telephones.




Paging Answer

Allows you to answer an announced page at any extension within the system




Paging and transfer

Allows you to transfer a call using the Paging to Extension feature.




Other Features

Call forwarding You can redirect all of your calls to another extension




To cancel:



• If your telephone is not equipped with the FWD/DND button, dial 7 extension number # to set. Dial 70# to cancel.

Call Pickup Deny

Allows you to prevent another extension from picking up your calls with the "Call Pickup" feature.



Other Features (contd.)

Do Not Disturb (DND)

Allows you to prevent other parties from disturbing you. Your extension will not receive intercom or outside calls







• You may dial "0" instead of "#".

Data Line Security

Your extension is protected against interruptions from "Call Waiting", "Hold Alarm", and "Executive Busy Override" features. Data communication devices, such as computers and facsimiles will operate as usual.






Executive Busy Override

Allows you to connect to an existing exchange line call or add a third party to your existing conversation.

-	8
C	
丛	
Off-hook	Press CO button corresponding to
	the call that you want to enter

External Feature Access


Allows you to access special features (e.g. Call Waiting) offered by a host PBX or Local Exchange. This feature is effective only during an outside call.



Other Features (contd.)

Auto Line Hunting


Allows you to access an idle outside line automatically, when you go off hook.



• When this feature is set, press the INTERCOM button after going off-hook to have access to other features.

Intercom Alerting Mode


Allows you to switch voice calling to ring calling when making an intercom call. In Voice-Calling mode, you can talk to the other party immediately after the confirmation tone.



• For programming, see page 28 of the Installation Manual.

Pulse to tone conversion

Allows you to change from Pulse to Tone dialling so that you can access special services such as Computer based banking services.



Station Feature Clear

Allows you to reset the following station features to the default setting:


- Call Forwarding Data Line Security
- Call Pickup Deny Do Not Disturb

To clear the setting: To clear the setting:

Other Features (contd.)

Time Setting (extension 21 only)

Sets the correct time.




• The clock starts immediately after pressing #.

Date Setting (extension 21 only)

Sets the current date.

#

Dial #



Flexible Night Service

(extension 21 only) This system supports both DAY and NIGHT modes of operation. The system operation for originating and receiving calls can be different in night and day modes. To set the night mode:





On-hook

To return to day mode:





Dial 781#

Confirming the current mode (with a display PT only):

781

Dial

Station Programming

Station Programming allows you to program a certain feature from your telephone individually. You need to switch you telephone to the station programming mode for programming. During programming mode, your telephone is busy to all callers. If you want to make a normal call handling operation, you should exit the programming mode.

To enter the Extension Programming mode:

1. Set the **MEMORY** switch on your telephone to "**PROGRAM**".


• Make sure the handset is on the cradle and the SP-PHONE button is off.

Flexible Button Assignment

CO and MESSAGE buttons on you telephone can be assigned as a Direct Station Selection (DSS, One-Touch Dialling button, or One Touch Access for System Features. Programmable Feature (PF) buttons can be assigned as a One touch Dialling button or One Touch Access for System Features.


Direct Station Selection (DSS) Button Assignment

Allows you to assign a flexible (CO and MESSAGE) button as a DSS button.



One-Touch Dialling Button Assignment


Allows you to assign a flexible button as a One-Touch Dialling button. Make sure to enter line access code (9, 81, 82 or 0) first.





Flexible CO button Assignment

CO buttons can be changed to another line number.



To exit the programming mode: Set the MEMORY switch to "SET"

Feature Number List

Feature	Number
Call Forward Set/Cancel	7 (extension number) # / 70#
Call Hold retrieve	5 (Line or Extension number)
Call Pickup	40
Call Pickup Deny Set/Cancel	731# / 730#
Conference	3
Data Line Security Set/Cancel	741# / 740#
Date Setting	76 Year Month Day Day-of-the-week #
Do Not Disturb Set/Cancel	720# / 70#
Doorphone Calling/Unlock	31 / 32
/Unlock during conversation	3
Extension Calling	21 through 26
Flexible night service Set/Cancel	782# / 781#
Intercom Alerting Mode	*
Last Number Redial	80
Line access, Automatic	9 or 0 (depending upon system program)
Line access, Individual	81 or 82
Paging All Extensions	33
Paging Answer	43
Station Feature Clear	79#
System Speed Dialling	*00 through *79
Time setting	77 Hour Minute 0(AM)/1(PM) #32

Note

• you can enter "0" instead of "#" except with Date Setting, Flexible Night Service and Time Setting.

The Indication of Status

The CO or INTERCOM buttons on the proprietary telephone inform the line conditions by a variety of lighting patterns. This allows you to check which lines are idle or in use at a glance.

INTERCOM BUTTON	Intercom Line Condition
Off	Idle
Green	Intercom call in
	progress
Green slow flash	Intercom call on hold
Green rapid flash	Incoming intercom /
	doorphone call
	acceptione dull

CO Button	CO Line Condition
Off	Idle
Green	You are using
Green slow flash	You are holding
Red	In use by other
Red slow flash	Held by other
Red rapid flash	Incoming call

Panasonic Business Systems U.K.

Panasonic House, Willoughby Road, Bracknell, Berkshire RG12 4FP

Produced by Paul White

KX-T206E/7000

This document is available from the Panasonic bulletin board on 01344-862072 filename 207_7000.EXE