

FEATURE	CODE	DISABLE
Account Code	89	
Alarm Clock -- Extension	FEAT 92	FEAT *92
Alarm Key	FEAT 62	
Answer Machine Emulation and Voicemail Message Button	FEAT 64	
Attendant	0	
Attendant Administration	FEAT #0	
Auto Selection (Intercom/CO Line)	FEAT 95	FEAT *95
Automatic Hold	FEAT 94	FEAT *94
Automatic Redial	FEAT 78	
Background Music	800 OR 801	
Busy Call Forward (28-Button Telephone)	FEAT 21	
Busy Call Forward (Analog Telephone)	#21 + EXT	#*21
Busy Ring Allowed	FEAT #2	
Call Back	EXT + #	
Call Back Cancel	FEAT ##	
Call Forward	FEAT 2	FEAT 2
Call Park	FEAT 73 + EXT	
Call Pickup - Directed (Suffix Code)	EXT + *6	
Call Pickup - Directed Analog Telephone (Suffix Code)	EXT + 6	
Call Pickup -- Group	*	
Caller ID Table -- Call Back	FEAT 6#	
Camp On (Suffix Code)	EXT + 4	
CO Line 1 - 24	700 TO 723	
CO Line Flash	FEAT 3	
CO Lines T1 (Future)	728 TO 751	
CO Lines VoIP (Future)	724 TO 727	
Conference	FEAT 60	
Conference (Supervised / Unsupervised)	FEAT 77	
Conference Rooms	860 TO 867	
Day, Night, Service (Attendant Extension)	FEAT 63	
DB Programming	FEAT *#	
Default Set	FEAT 69	
Dial Pad Touch Tone (On/Off)	FEAT #1	
Direct Call Forward (28-Button Telephone)	FEAT 22	
Direct Call Forward (Analog Telephone)	#22 + EXT	#*22
Directory number for system modem	400	
Directory Number for Telephones	401 TO 464	
Directory Number for Voicemail	465 TO 472	
Distinctive Ring - Extension	FEAT #7	
DND Override (Suffix Code)	EXT + 3	
Do Not Disturb	FEAT 4	
External Call Forward (28-Button Telephone)	FEAT 26	
External Paging	820	
Feat/Dir Lookup	FEAT #5	
Feature Key Programming	FEAT #3	
Feature Key Reset	FEAT 58	
Feature Status	FEAT #8	
Follow (FM) Call Forward (28-Button Telephone)	FEAT 23	
Follow Me Call Forward (Analog Telephone)	#23 + EXT	#*23
Follow To: Call Forward (28-Button Telephone)	FEAT 25	
Forced Intercom Call Forwarding	FEAT 4	
Forced Intercom Tone Ring	EXT + *	
Forced Release (Conference)	FEAT 74	
Get Held CO Line	FEAT 7*	
Headset Mode	FEAT 9#	FEAT *9#
Help	FEAT 72	
Hold	HOLD	
Hold - Exclusive	FEAT HOLD	

Hot Key on/off	FEAT #6	
Hot Line	FEAT 9*	FEAT *9*
Intercom Key (Requires a Button)	FEAT 65	
Intercom Mode Selection	FEAT 98	
Intrusion (Suffix Code) ↗	EXT + 8	
Last Number Redial	FEAT 8	
Loud bell number	810	
Loud bell number	810	
Memo Pad	FEAT 5*	
Message Wait (Suffix Code) ↗	EXT + 9	
Messages (Call Me, Text, Voice)	FEAT 90	
Messaging - Call me, Text, Voice	FEAT 96	
Monitor (Suffix Code) ↗	EXT + 1	
Mute Key	FEAT 76	
No Answer Call Forward (28-Button Telephone)	FEAT 24	
No Answer Call Forward (Analog Telephone)	#24 + EXT	#*24
One Touch Record	FEAT 67	
Page All Extension	209	
Page Allow/Deny	FEAT #9	
Page Group Numbers	201 TO 208	
Page Tenant 1	200	
Paging Answer Key (Meet Me Page)	FEAT 59	
Paging Receive (Meet Me Page)	#9	
Pause (Insertion Speed Dial)	FEAT 70	
Phone Lock/Unlock	FEAT 97	
Pick up Group Numbers	260 TO 267	
Private Talk (Conference)	FEAT 57	
Programming DSS Feature Buttons	FEAT #4	
Programming Feature Buttons	FEAT #3	
Pulse to Tone Conversion	*	
Release Key	FEAT 52	
Room Status	FEAT 7#	
Saved Number Redial	FEAT 51	
SLT Message Waiting Indication on/off	#96	#*96
Speed Dial Numbers -- Personal	500 TO 519	
Speed Dial Numbers -- System	600 TO 699	
Speed Dial Programming	FEAT 1	
Status Message	FEAT 90	
Trans and Answer (One Button Operation)	FEAT 68	
Transfer Beep Enabled	FEAT 56	
UCD Agent Log off	FEAT 91	
UCD Agent Log on	FEAT *91	
UCD Group Numbers	230 TO 253	
Virtual Numbers	830 TO 859	
Volume Beep	FEAT 53	
↗ The suffix code may require the "*" key, to invoke ringing, before operating correctly.		