

44'' TRAILMOWER® REMOTE BLADE ENGAGE KIT

Assembly Operation Service and Adjustment Repair Parts



1602 CORPORATE DRIVE, P.O. BOX 67, WARRENSBURG, MISSOURI 64093 PHONE 660-747-8183 FAX 660-747-8650

Made In The

USA

Manufacturing quality lawn care equipment since1945

ON4607




Tools required

3/8''-7/16''-1/2''-15/16'' open end wrenches Nyloc nuts are difficult to remove and may require two wrenches

REMOVING MANUAL ENGAGEMENT ASSEMBLE See figure - 1


- Shut off mower and allow time to cool.
- Loosen and remove four _'' screws [NB161]and remove both belt covers [4524].
- Loosen and remove nuts [NB181 & NB170], bolt [NB501], washers [NB556], spring [6048], and tension rod [NB260].
- Loosen and remove two _'' bolts [NB250] in engagement standoff [4547TK] .
- Remove nut [NB210]on tension rod at pivot plate[4578TK] and remove entire assembly. [detail-1]

FIGURE - 1



INSTALLATION OF REMOTE ENGAGEMENT KIT See FIGURE - 2


- Insert one 5/16" bolt [NB501] into hole closest to the end of [4504TK] spring bracket and one 5/16" nut [NB170] onto bolt upside down [DO NOT TIGHTEN]. Plate should pivot freely.
- Place spring bracket [4504TK] onto the arm of idler bracket [4530TK]and tighten with one nut [NB170].
- On other end of spring bracket [4504TK] place one 5/16" bolt [NB501] into hole up from the bottom and tighten one 5/16" nut [NB170] tight.
- Place two washers [NB272] onto bolt and one 5/16" nylock nut [NB181] allow for the spring on the engagement cable to fit between the two washers



Mounting remote cable bracket [4599TK]


- •After removing the standard engagement assembly attach the remote cable bracket in the same location using two _"-20 bolts [NB250] and two _"-20 nuts [NB524]. Tighten bracket to mower.
- •Place wires and cable from harness into bracket as shown in FIGURE-4 [leave adjustment nuts loose at this point.]
- •Route smaller tube of wires under hitch bracket over to key switch .
- •Unplug wires and remove key switch FIGURE-3
- •Insert tube and wires from new harness into key switch hole and reconnect, remember green wire to green wire and red wire to red wire.
- •Route spring cable through slot and attach to spring mount arm [4604TK]. Spring should move freely.
- •Adjust cable nuts at this point. The goal is to minimize slack **DO NOT ADJUST CABLE TIGHT** -- this can cause damage to the cable.

FIGURE - 3



Mounting remote console

Attach console to fan hitch [4582] using nuts and bolts provided in this kit. **NOTE:** Wiring harness should **not** be pulled tight -- this can cause damage when making sharp turns.



TESTING AND CONDITIONING REMOTE BLADE ENGAGE ASSEMBLY

IMPORTANT

NEVER START OR OPPERATE MOWER UNTIL COVERS , GUARDS , AND ALL OTHER SAFETY PIECES ARE PROPERLY IN PLACE!

- Ensure area is free of debris that may be thrown by blades.
- •Be aware of anyone that may be in the discharge path, especially small children.
- Start engine and allow a few seconds to warm up.
- •Using the remote handles cycle blade engage between full speed and full stop. Repeat several times to ensure proper installation .
- •It may be necessary to adjust cable to improve function [figure-4 page -3] NOTE: Remember to allow time for mower to cool between adjustments and return covers and guards before re-starting.

