

Panasonic



Key Telephone/Digital Single Line Telephone Quick Reference

Note: Some features may not be available depending upon system programming.

PLACING OUTSIDE CALLS

Make a call using pooled line access

→ access line (9, 81-84) → phone number → (talk)

Set Personal Speed Dial (PSD) numbers

→ **Key Tel** → **PROG** → **MEMORY** → PSD bin number (80-99) → phone number → **HOLD** →
DSL → **7^{PRS}** → **1** → **0^{OPER}**

Access speed dial numbers

→ **MEMORY** → speed dial bin number →

Check speed dial numbers (Key Telephone Only)

→ **CONF** → **MEMORY** → speed dial bin number → data displayed →

Delete speed dial numbers

→ **Key Tel** → **PROG** → **MEMORY** → speed dial bin number → **HOLD** →
DSL → **7^{PRS}** → **1** → **0^{OPER}**

Automatically redial the last number dialed

→ **REDIAL** → (talk)

Have a busy outside line call you back when it becomes open/free

→ access line (9, 81-84) → busy tone → **3^{DEF}** → → extension rings when line is free → → dial phone number

Assign an account code before making a call

→ **8^{TUV}** → **#** → account code → **#** → access line (9, 81-84) → phone number

Assign an account code for a client during a call

(talk) → **MEMORY** → **#** → account code → **#** → (talk)

HANDLING INCOMING CALLS

Answer a call ringing at someone else's phone in your call pickup group

→ **7^{PRS}** → **0^{OPER}** → **1** → (talk)

Answer a call ringing at another extension

→ **7^{PRS}** → **0^{OPER}** → **4^{GHI}** → ringing extension number → (talk)

Place a call on hold (and then retrieve it)

(talk) → **HOLD** (to retrieve) **HOLD**


Answer a second call and toggle between the two calls

(talk) → **HOLD** → (talk) → **HOLD**


Retrieve a call that has been placed on Floating Hold

→ ***** → **9^{WXYZ}** → Floating Hold number

Supervise the transfer of a call to an extension or outside number



Transfer a call to an extension or outside number without supervising the call



Transfer a call to a busy extension




COMMUNICATING WITHIN YOUR OFFICE

Answer a ringing phone



Call another extension




Page another party or make an announcement



Answer a page using Meet-Me Answer




Set Call Forwarding for:




NOTE: If forwarding calls to an outside number, press the # key, and then enter a preassigned system speed dial number.

Cancel Call Forwarding for:



Camp-on to a busy extension and send a call waiting signal



Answer a camp-on signal



Have a busy extension call you back when it becomes free

→ extension number → busy tone → → ringback tone →

Respond to a callback request

→ (talk)

Send a message waiting indication to another extension

→ extension number → ring or busy tone → →

Answer a message waiting indication

→ hear message waiting tone → → (talk)

Cancel a message waiting indication sent by another extension

→ →

Turn Do-Not-Disturb on or off

→ →

Interrupt another extension's call and make an announcement

→ extension number → busy tone → → (talk)

Using Additional Features

Establish a three-party conference call from your current call

→ extension number → access line (9 or 81-84) → phone number → (talk) → → (talk)

Set a reminder alarm

→ → enter time (24 hour format) →

Cancel a reminder alarm

→ →

Have the system redial a busy outside number until the called number answers

→ access line (9, 81-84) → phone number → (system makes redials up to 15 redial attempts)

Turn background music on and off

→ →