

PROTEGÉ® Keyset with LCD Quick Reference Guide

The Quick Reference Guide lists the keystrokes that allow you to use the basic features of the keyset. Included in the instructions are terms such as "Press," "Dial" and "F1, F2, F3". Press means to press and release a key. Dial means to press the desired numbers on the dial pad. F1, F2 and F3 refer to the function keys that are found directly below the LCD display. The function keys are interactive keys with selections displayed on the second line of the LCD. There may be several methods for selecting a particular feature that are not found in this Guide. Or your system programming may not allow certain features to be used. Check your User Guide for complete instructions and with your System Administrator to learn more about your system's programming. **See the User Guide for complete instructions.**

OUTSIDE CALL

Answer:

- Lift handset or press **SPEAKER** key **Place:**
 - Select TRUNK key or dial 9
 - Dial telephone number

INTERCOM CALL

Answer:

- Lift handset or press **SPEAKER** key **Place:**
 - Dial extension number

TRANSFER

On Call:

- Press **XFR/CONF** and dial extension number
- Press CLEAR or hang up

INDIVIDUAL ABBR. DIALING

To Store Numbers:

- While on hook, press **FUNCTION** key Dial **1** and dial directory number
- Press F2 key below show
- Press F1 key below tel
- Press F1 key below number
- Press F3 key below chg
- Dial telephone number
- Press F2 key below save
- Press the **CLEAR** key to exit

To Dial Number:

• Dial Directory number of desired stored ABBR. #

Material Code 699202 Part Number: 381-181387 – C – Rev 1 Copyright © 1998

COMMON ABBR. DIALING

To Dial Number:
Dial Directory number of desired stored ABBR. #

CALL BACK

- **Busy Trunk or Extension:**
- Receive busy signal
- Press the F1 key below cbck

To Cancel All Callbacks:

- Press the **FUNCTION** key
- Dial * # 5 *

CAMP ON

- To Camp On a Busy Extension:
- Hear busy signal
- Press F3 below next
- Press F1 below camp

MESSAGES

To Send a Call Me Message to an Extension:

- Call extension
- Press **F2** key below **msg**
- Press F1 key below call me

To Send a Preprogrammed Message to an Extension:

- Call extension
- Press **F2** key below **msg**
- Press **F3** key below **preprog**
- Press F2 key to select message
- Press **F1** key below **send**



PROTEGÉ® Keyset with LCD Quick Reference Guide

The Quick Reference Guide lists the keystrokes that allow you to use the basic features of the keyset. Included in the instructions are terms such as "Press," "Dial" and "F1, F2, F3". Press means to press and release a key. Dial means to press the desired numbers on the dial pad. F1, F2 and F3 refer to the function keys that are found directly below the LCD display. The function keys are interactive keys with selections displayed on the second line of the LCD. There may be several methods for selecting a particular feature that are not found in this Guide. Or your system programming may not allow certain features to be used. Check your User Guide for complete instructions and with your System Administrator to learn more about your system's programming. **See the User Guide for complete instructions.**

OUTSIDE CALL

• Dial telephone number

Answer:

• Lift handset or press **SPEAKER** key **Place:**

• Select **TRUNK** key or dial 9

INTERCOM CALL

Answer:

• Lift handset or press **SPEAKER** key **Place:**

• Dial extension number

TRANSFER

On Call:

- Press **XFR/CONF** and dial extension number
- Press **CLEAR** or hang up

INDIVIDUAL ABBR. DIALING

To Store Numbers:

- While on hook, press FUNCTION key Dial 1 and dial directory number
- Press F2 key below show
- Press F1 key below tel
- Press **F1** key below **number**
- Press **F3** key below **chg**
- Dial telephone number
- Press **F2** key below save
- Press the **CLEAR** key to exit

To Dial Number:

• Dial Directory number of desired stored ABBR. #

Material Code 699202 Part Number: 381-181387 – C – Rev 1 Copyright © 1998

COMMON ABBR. DIALING

To Dial Number:

• Dial Directory number of desired stored ABBR. #

CALL BACK

Busy Trunk or Extension:

- Receive busy signal
- Press the F1 key below cbck

To Cancel All Callbacks:

- Press the **FUNCTION** key
- Dial * # **5 ***

CAMP ON

- To Camp On a Busy Extension:
 - Hear busy signal

to an Extension:

• Call extension

- Press F3 below next
- $\bullet \ \mbox{Press} \ F1$ below camp

MESSAGES

To Send a Call Me Message to an Extension: • Call extension

• Press F1 key below call me

To Send a Preprogrammed Message

• Press **F2** key below **msg**

• Press **F2** key below **msg**

• Press F1 key below send

• Press **F3** key below **preprog**

• Press F2 key to select message

To Answer Call Me Message: • Press F2 key below reply

To Cancel Messages:

- Press **F3** key below **del**
- Press **F1** key to delete individual message
- Press **F3** key to delete all messages

CONFERENCE

To Start a Conference Call:

- On an existing call, press HOLD
- Dial extension number or press **TRUNK** key and dial telephone number
- Press the **FUNCTION** key, then press the **XFR/CONF** key
- Repeat for additional party

To Speak Privately with One Party:

- On conference call, press **FUNCTION** key, dial **57**
- Dial the Directory and speak privately

To Return to Conference:

• Press FUNCTION key, then press XFR/CONF key

To Release Party:

- On Conference call, press FUNCTION key, dial 74
- Dial directory number of party to be released

To End the Conference:

- Wait for other extensions to hang up, or release them
- Hang up your extension

CALL FORWARD (DIVERSION)

To Activate:

- Press the feature key marked CALL FWD
- Select type of Call Forward from LCD display by pressing the corresponding **F1**, **F2** or **F3** key below the display
- Dial the Extension number to which the calls are to be forwarded
- Select the type of calls, (co -Outside calls only or icm/co – internal and outside calls)

To Cancel:

- Press the feature key marked CALL FWD
- Press the F1 key below cancel

PAGING

To Page a Tenant Group:

- Lift handset, press **PAGE** key for group or dial Tenant Group Page number
- To Page a Group:
 - Lift handset, press **PAGE** key for group or dial Group Page number
- To Answer a Page:
 - Lift handset, press **FUNCTION** key, dial **59**
 - Speak to Paging Party

REDIAL

Last Number Redial:

• Press the **REDIAL** key to dial the last number dialed

Save Number Redial

To Store:

• While on a call, press **FUNCTION** key, dial **51**

To Dial:

• Handset on hook, press FUNCTION key, dial 51

User Saved Redial

- To Store:
 - While on a call, press FUNCTION key, dial 5*
 - Dial number to be saved
- Press F2 key below save

To Dial:

 Handset on hook, press FUNCTION key, dial 5*

HOLD

- While on a call, press **HOLD** key
- To return to a call, press the **TRUNK** key or press **FUNCTION** key, dial 7*

DO-NOT-DISTURB

To Activate:

• Press the feature key marked **DND**; LED will light

To Cancel:

• Press the feature key marked **DND**; LED will go out

To Answer Call Me Message: • Press F2 key below reply

To Cancel Messages:

- Press **F3** key below **del**
- Press **F1** key to delete individual message
- Press **F3** key to delete all messages

CONFERENCE

To Start a Conference Call:

- On an existing call, press HOLDDial extension number or press
- **TRUNK** key and dial telephone number
- Press the **FUNCTION** key, then press the **XFR/CONF** key

• Repeat for additional party

To Speak Privately with One Party:

- On conference call, press FUNCTION key, dial 57
- Dial the Directory and speak privately

To Return to Conference:

• Press **FUNCTION** key, then press **XFR/CONF** key

To Release Party:

- On Conference call, press **FUNCTION** key, dial **74**
- Dial directory number of party to be released

To End the Conference:

- Wait for other extensions to hang up, or release them
- Hang up your extension

CALL FORWARD (DIVERSION)

To Activate:

- Press the feature key marked CALL FWD
- Select type of Call Forward from LCD display by pressing the corresponding **F1**, **F2** or **F3** key below the display
- Dial the Extension number to which the calls are to be forwarded
- Select the type of calls, (co -Outside calls only or icm/co – internal and outside calls)

To Cancel:

- Press the feature key marked CALL FWD
- Press the F1 key below cancel

PAGING

To Page a Tenant Group:

 Lift handset, press PAGE key for group or dial Tenant Group Page number

To Page a Group:

• Lift handset, press **PAGE** key for group or dial Group Page number

To Answer a Page:

Last Number Redial:

Save Number Redial

User Saved Redial

To Store:

To Dial:

To Store:

To Dial:

To Activate:

To Cancel:

last number dialed

• While on a call, press

• Handset on hook, press

• While on a call, press

FUNCTION key, dial 51

FUNCTION key, dial 51

FUNCTION key, dial 5*

• Dial number to be saved

• Press **F2** key below **save**

• Handset on hook, press

FUNCTION key, dial 5*

HOLD

• To return to a call, press the

FUNCTION key, dial 7*

DO-NOT-DISTURB

• Press the feature key marked

• Press the feature key marked

DND; LED will go out

DND; LED will light

TRUNK key or press

• While on a call, press **HOLD** key

• Lift handset, press **FUNCTION** key, dial **59**

REDIAL

• Press the **REDIAL** key to dial the

• Speak to Paging Party