# **Configuring Traps for XOS/AOS Switches**

Use the Configure Traps wizard to configure switches to send traps to the OmniVista server. To launch the Configure Traps wizard, click the Configure Traps icon in the toolbar.

Until you configure traps and set the NMS trap subscription state to **On**, you will not be able to receive or view any trap notifications through the Notifications Log.

Configuring traps is a two-part process: first you select the switches for which you want to configure traps, then you specify the traps you want to be sent to the OmniVista server. At the end of the process, OmniVista displays a summary of all the switches and traps you selected, and indicates whether the configuration was successful or not.

Currently, the Configure Traps wizard supports trap configuration for XOS and AOS switches. To learn how to configure traps for all other devices, see Configuring Traps for Non-XOS/AOS Switches.

#### Note:

- The Configure Traps wizard can be launched from any application whose toolbar includes the **Configure Traps** icon. Currently, the Configure Traps wizard can be launched from either Notifications or Topology.
- In Topology, you can also invoke the Configure Traps wizard by right-clicking one or more switches in the All Discovered Devices table, then selecting Configure Traps from the pop-up menu. When this method is used, the pre-selected devices automatically appear in the "Selecting Switches" window.
- If you do not have administrative privileges, the Configure Traps button will be disabled.

### **Selecting Switches**

The "Selecting Switches" window is divided into three main areas: (1) Server Information,(2) the Switch Selection Area, and (3) the Message Area. See below for detailed descriptions.

|                 | 🖉 Configure Traps  |                                  |                  |                |                                      |   |               | ×          |
|-----------------|--|----------------------------------|------------------|----------------|--------------------------------------|---|---------------|------------|
|                 | Select Devices for Co  | nfiguration                      |                  |                |                                      |   |               |            |
| Sanuan          | Server Information   |                                  |                  |                |                                      |   |               |            |
| Jerver          | ID Address: 129.251  | 10.49                            |                  |                | Tran nort                            | 162                                     |               |            |
| Information     | IF MULICOS, 120.201  | 10.40                            |                  |                | Trap pore                            | 102                                     |               |            |
|                 | Available Device Type  | es: 💿                            | Ali 🔾            | xos            | O AOS                                |   |               |            |
|                 | Available Devices :  |                                  |                  |                |                                      | Configure Trans for                     |               |            |
|                 | FITGINGING DEFICED I   |                                  | <b>.</b>         | -              |                                      | compare requerer                        |               | A THURSDAY |
|                 | Mana   | Address                          | DNICA            |                |                                      | Mama                                    | a delega e e  | DNIC Name  |
|                 | DCTestnetCore  | 10 255 10 3                      | DINOT            |                |                                      | WV FLUIT 128                            | 10 255 11 126 | DINO Marin |
|                 | wTarget  | 10.255.11.61                     |                  |                | -                                    | W FUI2 129                              | 10.255.11.129 |            |
| Custorela       | wTarget  | 10.255.11.63                     |                  | 1              | Add->                                | FALCON-137                              | 10.255.11.221 |            |
| Switch          | nms-test-103   | 10.255.11.103                    |                  | 1              |                                      | OmniSwitch                              | 10.255.11.244 |            |
| Selection       | no-name-119  | 10.255.11.119                    |                  |                | <- <u>R</u> emove                    |   |               |            |
| 4000            | 🔳 no-name  | 10.255.11.120                    |                  |                |                                      |   |               |            |
| Area            | 😡 vxTarget   | 10.255.11.121                    |                  |                | Add All->                            |   |               |            |
|                 | WV_HAWK_122  | 10.255.11.122                    |                  |                | < Pomon All                          | 1                                       |               |            |
|                 | NMS_123_Hawk   | 10.255.11.123                    |                  | H              | 2-148[[[[0A6 Wi                      |   |               |            |
|                 | ES0001A-1  | 10.255.11.130                    |                  |                |                                      |   |               |            |
|                 | 💓 Kite_135   | 10.255.11.135                    |                  |                |                                      |   |               |            |
|                 | Kite2_NMS  | 10.255.11.144                    |                  | Ŀ.             |                                      |   |               |            |
|                 | AIMC fact 140  | 10 255 11 170                    | Þ                |                |                                      | 4                                       |               | •          |
| -               |  |                                  |                  |                |                                      |   |               |            |
|                 | Message Area   |                                  |                  |                |                                      |   |               |            |
| Message<br>Area | [2:11:11 PM] > A09<br>10.255.11.244<br>[2:11:12 PM] > Cor<br>10.255.11.244 | 5 devices to b<br>afiguration no | e conf<br>t foun | igur<br>d fo   | ed: 10.255.11.1;<br>r: 10.255.11.120 | 26, 10.255.11.129,<br>5, 10.255.11.129, | 10.255.11.22  | 1,         |
|                 |  |                                  |                  |                |                                      |   |               | *          |
|                 |  | < Back                           |                  | le <u>x</u> t∶ | > Einish                             | Cancel Help                             |               |            |

### The Configure Traps Wizard "Selecting Switches"

- Server Information. Shows the IP address of the OmniVista server, and the server port number on which traps are received. Both are read-only fields. The trap port number is set using the **Trap Port Number** field in the Preferences window. For information on changing the port number, see the Preferences help: Setting Preferences > System-Wide Preferences > Notifications Stored.
- Switch Selection Area. Enables you to create a list of switches for which you want to configure traps. The list of selected switches displays in the "Configure Traps for:" pane.
- **Message Area**. Displays messages related to trap configuration. These messages are also written to "trapconfig.log" in the Audit application (see the Audit help, "Getting Started with Audit").

| Color | Message Type         | Example   |
|-------|----------------------|---|
| Blue  | General information  | message listing the names of the devices for which you want to configure traps. |
| Black | Progress information | A message telling you that certain switches were successfully configured.       |
|       | Error massage or     | "Table Full" - you must delete one or more subscriptions.                       |
| Red   | warning              | "SNMP Timeout" - the switch may be busy; try again or verify using Telnet.      |

Messages are color-coded as follows:

#### To select switches:

1. First, use the "Devices" radio buttons to specify whether you want to see a list of All switches (XOS and AOS), only XOS switches, or only AOS switches. Switches that are in a down state when (a) the "Selecting Switches" window first opens, or (b) a different device type is selected with the "Devices" radio buttons, will be considered "unavailable" and will therefore not be included in the list that displays through the Switches Available pane.

2. Use the Add/Remove buttons to create the list of switches for which you want to configure traps.

**3.** When you are done selecting switches, click the Next button, to continue to the next screen in the Configure Traps Wizard (the "Selecting Traps" window). The message area should list the switches you specified. If there were any difficulties connecting to the switch, or if the trap table is full, the message area will so indicate.

## **Selecting Traps**

From the "Selecting Traps" screen (see the below illustration), select the traps that you want to send to the OmniVista server. There are two versions of this window: one for XOS switches and one for AOS switches. They are identical except that the AOS version has one additional field, namely, "Protocol." In the previous window ("Selecting Switches), if you selected both XOS and AOS switches, you will first see the "Selecting Traps" window for XOS switches, followed by the "Selecting Traps" window for AOS switches. In the example below, the window for AOS Switches is shown.



To specify the trap information, follow these steps:

1. State. Use the radio buttons to specify an NMS trap subscription state. The choices are:

**On**. The OmniVista Server will be notified about traps. (The default value is On.) **Off**. The OmniVista Server will <u>not</u> be notified about traps. **Delete**. Deletes the trap configuration information previously saved to the switch. Use the Delete option when the OmniVista server has been moved to a different computer and now has a different IP address.

2. Save. From the Save drop-down menu, select from one of the following options:

All. Saves all trap configuration information specified in the "Selecting Switches" and "Selecting Traps" windows, including port number, server IP address, selected switches, selected traps, state, and protocol.

**Port Only**. Saves only the port number and no other trap configuration information. Use this save option after configuring the OmniVista Server to receive traps on a different port.

**Note:** To change the port number, see the Preferences help: Setting Preferences > System-Wide Preferences > Notifications Stored.

**State Only**. Saves only the state information (On, Off, or Delete) and no other trap configuration information. If Delete is selected, the entry for the OmniVista server is removed from the trap configuration table for the selected switches.

**Traps Only**. Saves only the trap information specified. Does not save Port or State information.

**Protocol Only** (applies only to AOS switches). Saves only the protocol used to send traps to the NMS server (SNMPv1, SNMPv2, or SNMPv3).

**Note:** If you select one of the "Only" Save options (Port Only, State Only, Traps Only, or Protocol Only), and no trap information had previously been configured for the specified device, then, when you click **Finish**, the entire configuration displayed through the Configure Traps window will be saved. This is comparable to doing a Save "All."

**3. Protocol** (only applies to AOS switches). Specify the protocol used to send traps to the NMS server. The choices are: SNMPv1, SNMPv2, or SNMPv3. (The default value is SNMPv3.)

**4.** Use the Add/Remove buttons to select the traps to enable or disable. If "Save All" or "Save Traps Only" is selected, traps listed in the Available Traps pane will be disabled and traps listed in the Traps to Apply pane will be enabled.

**5.** When you finish specifying the trap information, click the **Next** button, to continue to the last screen in the Configure Traps wizard (the Summary window).

### Summary

The Summary screen shows all the configuration information that displayed previously through the Selecting Switches screen and the Selecting Traps screen, including Server IP address, trap port number, NMS state, Save option, and a list of all the switches and traps you selected for both XOS and AOS.

| Configure | Trap  | s Wizard: |
|-----------|-------|-----------|
| "Su       | immar | ry"       |

| Server         I28.251.19.48         Trap Port:         162           Configure AOS Traps         Save:         All           Protocol:         SNMPv3         Traps to Enable:         alaDoSTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrClearedSlotTrap       | summary   |  |   |  |   |
|--|---|--|---|--|---|
| P Address:         128.251.19.48         Trap Port:         162           Configure AOS Traps         Save:         All           Protocol:         SNMPv3         Traps to Enable:         alaDoSTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrDuplicateRoleTrap | Server  |  |   |  |   |
| WV_FUJI2_129 (10.255.11.22)         Traps to Enable:         alaDoSTrap<br>alaStackMgrDuplicateRoleTrap<br>alaStackMgrDuplicateRoleTrap  | IP Address:   | 128.251.19.48  | Trap Port:                              | 162  |   |
| State:     On     Save:     All       Protocol:     SNMPv3     alaDoSTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrDuplicateRoleTrap  | Configure A   | OS Traps   |   |  |   |
| WW_FUJI1_126 (10.255.11.126)         alaDoSTrap           WW_FUJI2_129 (10.255.11.129)         Traps to Enable:         alaStackMgrClearedSlotTrap           FALCON-137 (10.255.11.221)         Traps to Enable:         alaStackMgrDuplicateRoleTrap  | State:  | On   | Save:                                   | All  |   |
| WV_FUJI1_126 (10.255.11.126)         alaDoSTrap           WW_FUJI2_129 (10.255.11.129)         Traps to Enable:           FALCON-137 (10.255.11.221)         Traps to Enable:  | Protocol:   | SNMPv3   |   |  |   |
| OmniSwitch (10.255.11.244) alaStackMgrDuplicateSlotTrap  | Switches:   | WV_FUJI1_126 (10.255.11.126)<br>WV_FUJI2_129 (10.255.11.129)<br>FALCON-137 (10.255.11.221)<br>OmniSwitch (10.255.11.244) | Traps to Enable:                        | alaDoSTrap<br>alaStackMgrClearedSlotTrap<br>alaStackMgrDuplicateRoleTrap<br>alaStackMgrDuplicateSlotTrap | 4 |
|  |   |  |   |  |   |
| essage Area  | essage Arc  | 13   |   |  |   |
| essage Area<br>2:12:29 PM] > A03 devices to be configured: 10.255.11.126, 10.255.11.129, 10.255.11.221,  | essage Are  | ma<br>1] > AOS devices to be configur  | ed: 10.255.11.126,                      | 10.255.11.129, 10.255.11.221,  |   |
| <pre>lessage Area 2:12:29 PM] &gt; A0S devices to be configured: 10.255.11.126, 10.255.11.129, 10.255.11.221, 0.255.11.244 2:12:30 PM] &gt; Configuration not found for: 10.255.11.126, 10.255.11.129, 10.255.11.221, 0.255.11.244</pre>   | essage Are<br>2:12:29 P<br>0.255.11.<br>2:12:30 P<br>0.255.11.  | a<br>1] > AOS devices to be configur<br>244<br>1] > Configuration not found fo<br>244                                    | ed: 10.255.11.126,<br>r: 10.255.11.126, | 10.255.11.129, 10.255.11.221,<br>10.255.11.129, 10.255.11.221,   |   |
| <pre>lessage Area 2:12:29 PM] &gt; A0S devices to be configured: 10.255.11.126, 10.255.11.129, 10.255.11.221, 0.255.11.244 2:12:30 PM] &gt; Configuration not found for: 10.255.11.126, 10.255.11.129, 10.255.11.221, 0.255.11.244</pre>   | lessage Ard<br>2:12:29 P<br>0.255.11.<br>2:12:30 P<br>0.255.11. | a<br>1] > AOS devices to be configur<br>244<br>1] > Configuration not found fo<br>244                                    | ed: 10.255.11.126,<br>r: 10.255.11.126, | 10.255.11.129, 10.255.11.221,<br>10.255.11.129, 10.255.11.221,   |   |

The message area confirms the list of switches you specified and provides information on any problems that may have been encountered.

In this screen, you can do the following:

1. Review the information in the Summary screen. If you need to make changes, use the **Back** button to return to earlier windows. Otherwise, click **Finish**. The message area will tell you which configurations were successful and which were not.

2. Click Cancel to exit and return to the main application window.

## **Configuring Traps for Non-XOS/AOS Switches**

To configure traps for a non-XOS/AOS switch, use the web configuration tool available for that particular device. To access the tool, go to the tree-control and right-click the switch for which you want to configure traps, then select WebPage (as shown below).



The tool will vary in its appearance, depending on the type of device you select. Generally, each tool provides its own online help information.

Currently, there is a web configuration tool for each of the following devices:

- OmniStack 1024, 6024, 6124, and 8088
- OmniMss
- OmniCore 5052-V3see

**Note:** OmniVista recognizes trap configuration changes made through the Configure Traps wizard only. It does not reflect trap configuration changes made through a non-XOS/AOS switch configuration WebPage.