


User Guide

vantageXesprit



General Information 2

Common to
vantage 8/12/24/48

Paging Calls	4
Answering Calls	8
Paging Intercom Calls	10
Answering Intercom Calls	12
Conferencing	14
Transferring Calls	16
Other Features	18

- Listen while on hold
- End to end signalling
- Access the attendant
- Do not disturb


Common to
vantage 8/12

Speed Calling	22
Call Forwarding	24
Ring Assignment	24
Message Waiting	26
Paging	26


Common to
vantage 24/48

Speed Calling	28
Accessing Special Line Groups	30
Call Forwarding	30
Call Pick-up	32
Direct Station Selection	34
Message Waiting	36
Other Features	38

- Voice prohibit
- Signal call
- Paging



If your set has these two buttons labelled "INTERCOM", you have a Vantage 24/48 System. Please refer to pages 1 - 16 and 28 - 38 for user instructions.



If your set has these two buttons labelled "INTERCOM" and "FEATURE", you have a Vantage 8 or a Vantage 12 System. Please refer to pages 1 - 27 for user instructions.

Prime telephone

Vantage 8/12

The prime telephone set is the main answering position for calls that would otherwise go unanswered. Held calls will also ring the prime set if they have been on HOLD for two minutes or longer.

Vantage 24/48

There may be up to six prime telephones in the Vantage 24/48 system. These telephones are prime for all lines appearing on them. All calls that would otherwise go unanswered will ring at the prime set after a specified period of time. Held calls will also ring the prime set if they have been on HOLD for two minutes or longer.

Warning: Do not insert the plug at the free end of the handset cord directly into any wall or baseboard jack. Such misuse may result in damage to hearing.

Audible signals (Ringing alert)

Incoming call

Consists of an intermittent warble tone.
Note: For Vantage 48 only, an incoming call transferred through the Central Answering Position consists of a "triple" burst of warble tone.

Intercom signal call

Consists of a "double" burst of warble tone.

Intercom voice call

Consists of a single warble tone, repeated at 20 second intervals.

Visual signals

Each line button and designated feature button has an associated light to provide a visual indication of their operational condition.

-  ON indicates a line or feature is activated
-  Slow flash indicates an incoming call
-  Medium flash indicates a line put on Hold at other sets
-  Fast flash indicates a line put on Hold at the initiating set
-  Intermittent flash indicates Call Forwarding on Vantage 8/12
-  OFF indicates a line is idle or a feature is deactivated.

Automatic privacy


Common to all outside lines and intercom paths, automatic privacy ensures that no other Vantage user can hear your conversation.


Handsfree option

Not all telephones are equipped for handsfree operation. If you do not have an on/mute button, you do not have handsfree capability.



Ringing tone

Pressing down on both ends of the volume control simultaneously will change the ringing tone of your phone.





Handset operation






This button should always give you access to an outside line.

These buttons could be outside lines.

- Lift handset
- Press an idle outside line button if one was not selected automatically
- Dial number
- To end call, replace handset


Handsfree operation

Mute "ON"
Pressing **3** will cause the light to flutter. The set will not transmit your voice to the far end, enabling you to have a private conversation at your end.

Mute "OFF"
Pressing **3** again turns the light "ON" and your voice will be transmitted to the far end.

- Press **3**. It lights up
- Press an idle outside line button if one was not selected automatically
- Dial number
- When party answers, talk directly towards telephone
- To end call, press **3**



Automatic redial of your last number

- 1 Press an idle outside line button
- 2 Press **Line** .
(Your last number is automatically redialed)
- 3 Lift handset or press **Line** when party answers

Note: Last number redial does not work with speed called numbers.

Handsfree/Handset operation

Any operation described as "Lifting the handset" can also be activated by pressing **Line** . It will light up indicating the handsfree mode is operational.

Changing from handset to handsfree






- 1 Press **Line** . It will light up
- 2 Hang up

Changing from handsfree to handset




- 1 Lift handset






Voice call
 An Intercom Voice call permits you to speak directly to the called party via their set speaker. The call is connected automatically.




- Handset operation**
- 1 Press idle and dial the required 2 digit extension number
 - 2 Lift handset and dial the required 2 digit extension number
 - 3 Listen for single ringback tone and announce call
 - 4 To end call, hang-up




- Handsfree operation**
- 1 Press idle and dial the required 2 digit extension number
 - 2 Press and dial the required 2 digit extension number
 - 3 Listen for single ringback tone and announce call
 - 4 To end call, press

Note: For Vantage 8/12, the and buttons may be used interchangeably.



Signal call
 An Intercom Signal call requires the called party to answer your ring before the call is connected.



- Handset operation**
- 1 Press idle and dial the required 2-digit extension number
 - 2 Lift handset when party answers
 - 3 To end call, hang-up



- Handsfree operation**
- 1 Press idle and dial the required 2-digit extension number
 - 2 When party answers press and talk normally towards phone
 - 3 To end call, press