

Panasonic

Integrated Telephone System
Model No. **KX-TS6W**
Pulse-or-tone dialing capability

Operating Instructions



PLEASE READ BEFORE USE AND SAVE.

Panasonic World Wide Web address:
<http://www.panasonic.com>
for customers in the USA or Puerto Rico

Attach your purchase receipt here.

For your future reference

Serial No.
(found on the bottom of the unit)

Date of purchase

Name and address of dealer

If you need assistance with the set-up
or operation, please call
1-800-211-PANA(7262)


**Panasonic Consumer Electronics
Company,**
Division of Matsushita Electric
Corporation of America
One Panasonic Way, Secaucus, New Jersey
07094

Panasonic Sales Company,
Division of Matsushita Electric
of Puerto Rico, Inc.
Ave. 65 de Infantería, Km. 9.5, San Gabriel
Industrial Park Carolina, Puerto Rico 00985

Printed in USA **PQQX13390ZA** AG0302AS0

1 Getting Started

1-A Location of Controls




Accessories (included)

- Handset.....one
- Handset Cord.....one
- Telephone Line Cord.....one

• To order accessories, call 1-800-332-5368.

1-B Settings


- 1 Connect the handset cord.
- 2 Connect the telephone line cord, then lift the handset to confirm the dial tone.



- 3 Set the DIALING MODE selector to TONE.
• If you cannot dial, set to PULSE.




- 4 Set the RINGER selector to HIGH, LOW or OFF.
(Ex: "LOW" is selected.)



• When set to OFF, the unit will not ring.



- 5 Set the HANDSET VOLUME selector to HIGH, MEDIUM or LOW.
(Ex: "MEDIUM" is selected.)



1-C Wall Mounting

The unit can be mounted on a wall phone plate.

- 1 Connect the telephone line cord to the unit.
- 2 Connect the telephone line cord to Single-Line Telephone Jack. Mount the unit, then slide down.



To temporarily set the handset down during a conversation, place it as shown here.

2 Operation

2-A Making Calls

- 1 Lift the handset.
- 2 Dial a phone number.
• If you misdial, hang up and start again from step 1.
- 3 When finished talking, hang up.

To redial the last number dialed

- 1 Lift the handset.
 - 2 Press **REDIAL**.
- **REDIAL** will dial the last number you called manually.

2-B Answering Calls

- 1 When the unit rings, lift the handset.
- 2 When finished talking, hang up.

3 Speed Dialer

3-A Storing Phone Numbers in Memory

You can store up to 10 phone numbers in the memory stations. The dialing buttons (0 to 9) function as memory stations. To prevent misdialing, store correct information in memory location before using speed dial


- 1 Lift the handset.
 - 2 Press **PROGRAM**.
 - 3 Enter a phone number up to 16 digits.
• If you misdial, hang up and start again from step 1.
 - 4 Press **PROGRAM**.
 - 5 Press a memory station number (0 to 9).
 - 6 When finished, hang up.
• To store other number, repeat steps 1 to 6.
- If a pause is required for dialing, press **PAUSE** where needed. Pressing **PAUSE** counts as one digit (5-C).

To store a dialed number in memory (During a conversation)

- Lift the handset →
→ Phone number (up to 16 digits) →
→ During a conversation, Press **PROGRAM** twice → Station number (0 to 9). →
→ Hang up.

Speed Dial Card

Remove the speed dial card and use it as a name or phone number index for stored numbers.



To erase a stored number

- Lift the handset → press **PROGRAM** →
→ **PAUSE** → **PROGRAM** →
→ Station number (0 to 9). →
→ Hang up.

3-B Dialing a Stored Number

- 1 Lift the handset.
 - 2 Press **AUTO**.
 - 3 Press a memory station number (0 to 9).
• The stored number is dialed.
- The **REDIAL** button does not work for Speed Dialer. To dial the number again, hang up and repeat steps 1 to 3.
• If the telephone line cord is disconnected more than 3 days, the stored numbers may be erased. Store phone numbers again.

For assistance, please call: 1-800-211-PANA(7262)

For assistance, please call: 1-800-211-PANA(7262)

4 One-Touch Dialer

4-A Storing Phone Numbers in Memory

You can store a number in each auto dial button (**DIRECT** or **EMERGENCY**). Do not press any one-touch auto dial buttons before storing to prevent misoperation.

It is recommended that you program an emergency number in the **EMERGENCY** button.

- Lift the handset.
- Press **PROGRAM**.
- Enter a phone number up to 16 digits.
 - If you misdial, hang up and start again from step 1.
- Press **PROGRAM**.
- Press a one-touch auto dial button (**DIRECT** or **EMERGENCY**).

- When finished, hang up.
 - To store other number repeat step 1 to 6.
- If a pause is required for dialing, press **PAUSE** where needed. Pressing **PAUSE** counts as one digit (5-C).

To store a dialed number in memory (During a conversation)

- Lift the handset →
- Phone number (up to 16 digits) →
- During a conversation, press **PROGRAM** twice →
- one-touch auto dial button (**DIRECT** or **EMERGENCY**). →
- Hang up.

To erase a stored number

- Lift the handset → press **PROGRAM** →
- **PAUSE** → **PROGRAM** →
- one-touch auto dial buttons (**DIRECT** or **EMERGENCY**). →
- Hang up.

4-B Dialing a Stored Number

- Lift the handset.
- Press the one-touch auto dial button (**DIRECT** or **EMERGENCY**).
 - The stored number is dialed.
- The **REDIAL** button does not work for one-touch dialer. To dial the number again, hang up and repeat steps 1 to 2.
- If the telephone line cord is disconnected more than 3 days, the stored numbers may be erased. Store phone numbers again.

6 Things You Should Know

6-A Troubleshooting

Problem	Remedy
The unit does not work.	<ul style="list-style-type: none"> Check the settings (1-B).
The call cannot be connected even when you dialed correctly.	<ul style="list-style-type: none"> Check whether the DIALING MODE selector is set correctly (1-B).
The unit does not ring.	<ul style="list-style-type: none"> The RINGER selector is set to OFF. Set to HIGH or LOW (1-B).
You cannot store a phone number in memory.	<ul style="list-style-type: none"> Confirm the handset is off the cradle. Do not enter a phone number longer than 16 digits, otherwise only the first 16 digits will be recorded and the previous registered number will be erased.
You cannot redial by pressing REDIAL .	<ul style="list-style-type: none"> If the last number dialed was longer than 32 digits, the number will not be redialed.

Problem	Remedy
If you cannot solve your problem	<ul style="list-style-type: none"> Call our customer call center at 1-800-211-PANA(7262). Panasonic's e-mail address for customer inquiries: consumerproducts@panasonic.com for customer in the USA or Puerto Rico ONLY

6-B Helpful Information

- Environment** – do not place the unit in room where the temperature is less than 5°C (41°F) or greater than 40°C (104°F). Allow 10 cm (4") clearance around the unit for proper ventilation. Avoid excessive smoke, dust, mechanical vibration, shock or direct sunlight.
- Routine care** – wipe the unit with a soft cloth. Do not use benzine, thinner, or any abrasive powder.

For assistance, please call: 1-800-211-PANA(7262)

- If there is any trouble** – disconnect the unit from the telephone line and connect a known working phone. If the known working phone does not operate properly, consult your telephone company.

For product service

- Call 1-800-211-PANA(7262) or 1-800-833-9626 for the location of an authorized servicenter.
- Panasonic's e-mail address for customer inquiries: consumerproducts@panasonic.com for customers in the USA or Puerto Rico ONLY.

When you ship the product

- Carefully pack your unit, preferably in the original carton.
- Attach a letter, detailing the symptom, to the outside of the carton.

Symptom

- Send the unit to an authorized servicenter, prepaid and adequately insured.
- Do not send your unit to the Panasonic Consumer Electronics Company listed on the back cover or to executive or regional sales offices. These locations do not repair consumer products.

5 Special Features

5-A For Call Waiting Service Users

Press **FLASH** if you hear a call-waiting tone while talking.

- The first call is put on hold and you can answer the second call.
- To return to the first caller, press **FLASH** again.

5-B Temporary Tone Dialing (For Rotary or Pulse Service Users)

Press **TONE** before entering access numbers which require tone dialing.

- After a few seconds, the dialing mode changes to tone. You can enter numbers to access answering services, electronic banking services, etc. When you hang up, the dialing mode will return to pulse.

5-C How to Use the PAUSE Button (For Analog PBX Line/Long Distance Service Users)

We recommend that you press **PAUSE** if a pause is required for dialing with a PBX or to access a long distance service. Ex. Line access number **9** (PBX)


9 → **PAUSE** → Phone number

- Pressing **PAUSE** once creates a few seconds pause. This prevents misdialing when you redial or dial a stored number.
- Pressing **PAUSE** more than once increases the length of the pause between numbers.

7 Referencia Rápida

7-A Pasos Iniciales

- Conecte el cordón del auricular.



- Conecte el cordón de línea telefónica, luego levante el auricular para confirmar que tiene tono para marcar.
- Coloque el selector del modo de discado (DIALING MODE) a TONE (tono).
 - Si usted no puede marcar colóquelo en PULSE (pulso).

For assistance, please call: 1-800-211-PANA(7262)

- Coloque el selector del timbre (RINGER) a HIGH (alto), LOW (bajo) u OFF (apagado).
 - Cuando esté colocado en OFF, la unidad no sonará.
- Coloque el selector de volumen del auricular en HIGH (alto), MEDIUM (medio) o LOW (bajo).

7-B Realizando Llamadas

- Levante el auricular.
- Marque el número telefónico.
 - Si usted se equivoca al marcar, cuelgue e inicie a partir del paso 1.
- Cuando termine de hablar, cuelgue.

Para remarcar el último número

Levante el auricular → Presione **REDIAL**.

- REDIAL** marcará el último número al que usted llamó manualmente y no así un número del marcado rápido o un número del marcado de un solo toque.

7-C Contestando Llamadas

- Cuando la unidad timbra, levante el auricular.
- Cuando termine de hablar, cuelgue.