

**EXTROM**

**ELECTRONIC KEY TELEPHONE SYSTEM**

**HMS-1032**

**INSTALLATION MANUAL**

PAN ORIENT COMMUNICATIONS COMPANY

137 EXPRESS STREET, PLAINVIEW,  
NEW YORK 11803

PHONE: (516) 988-5811 / TELEX: 221569

434-1200

10M HEAD TP

## CONTENTS

1.	INTRODUCTION .....	1
2.	UNPACK AND INSPECT EQUIPMENT .....	2
3.	INSTALL KEY SERVICE UNIT (KSU) .....	4
3.1	Mount KSU Cabinet on the Wall .....	4
3.2	Ground KSU Cabinet .....	6
3.3	Install Circuit Cards .....	7
3.3.1	Install 4COU Card .....	10
3.3.2	Install 8STU Card .....	11
3.3.3	Install MISCU Card .....	12
3.3.4	Install DB INFU Card .....	13
3.4	Connect Customer-provided Equipment .....	14
3.4.1	Connect External Music Source Equipment .....	14
3.4.2	Connect External Paging/Amplifier System .....	15
3.5	Install C.O. Lines .....	16
3.6	Connect Telephone Lines .....	18
3.6.1	Connect Telephone Lines (Connectorized Version) in Buildings Not Prewired with House Cable .....	18
3.6.2	Connect Telephone Lines (Add Each 8 Station Sets) .....	22
3.7	Cable Mounting .....	23
4.	INSTALL TELEPHONE SET .....	24
4.1	Install HFU Card .....	24
4.2	Mount Telephone Set on the Wall .....	25
4.3	Install Adjustable Bracket .....	27
4.4	Attach Function Description Plate .....	28
5.	INSTALL DSS/BLF CONSOLE AND DSS/BLF TELEPHONE SET .....	29
5.1	Plug DSS/BLF Console into the DSS/BLF Telephone Set .....	29
5.2	Plug in of Amphenol Connector from DSS/BLF Console .....	30
6.	INSTALL POWER FAILURE UNIT .....	31
7.	PROGRAMMING .....	34
7.1	Program at the Installation of the System .....	36
7.2	Change Programmed Service .....	37
8.	TURN THE SYSTEM ON .....	41
9.	RESET THE SYSTEM .....	42